



Configuring IPv6 Routing on VSP Operating System Software

Release 5.1
NN47227-507
Issue 06.02
March 2016

© 2015-2016, Avaya, Inc.
All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya may generally make available to users of its products and Hosted Services. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on Avaya hardware and software. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: <https://support.avaya.com/helpcenter/getGenericDetails?detailId=C20091120112456651010> under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if You acquired the product(s) from an authorized Avaya Channel Partner outside of the United States and Canada, the warranty is provided to You by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means a hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES IF YOU PURCHASE A HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, [HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO](https://support.avaya.com/LicenseInfo) UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE, BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE

TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE. YOUR USE OF THE HOSTED SERVICE SHALL BE LIMITED BY THE NUMBER AND TYPE OF LICENSES PURCHASED UNDER YOUR CONTRACT FOR THE HOSTED SERVICE, PROVIDED, HOWEVER, THAT FOR CERTAIN HOSTED SERVICES IF APPLICABLE, YOU MAY HAVE THE OPPORTUNITY TO USE FLEX LICENSES, WHICH WILL BE INVOICED ACCORDING TO ACTUAL USAGE ABOVE THE CONTRACT LICENSE LEVEL. CONTACT AVAYA OR AVAYA'S CHANNEL PARTNER FOR MORE INFORMATION ABOUT THE LICENSES FOR THE APPLICABLE HOSTED SERVICE, THE AVAILABILITY OF ANY FLEX LICENSES (IF APPLICABLE), PRICING AND BILLING INFORMATION, AND OTHER IMPORTANT INFORMATION REGARDING THE HOSTED SERVICE.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO](https://support.avaya.com/LicenseInfo), UNDER THE LINK "AVAYA SOFTWARE LICENSE TERMS (Avaya Products)" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AVAYA CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA CHANNEL PARTNER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants You a license within the scope of the license types described below, with the exception of Heritage Nortel Software, for which the scope of the license is detailed below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to You. "Software" means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products, pre-installed on hardware products, and any upgrades, updates, patches, bug fixes, or modified versions thereto. "Designated Processor" means a single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users. "Instance" means a single copy of the Software executing at a particular time: (i) on one physical machine; or (ii) on one deployed software virtual machine ("VM") or similar deployment.

Licence types

Designated System(s) License (DS). End User may install and use each copy or an Instance of the Software only on a number of Designated Processors up to the number indicated in the order. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software is the software contained within the list of Heritage Nortel Products located at <https://support.avaya.com/LicenseInfo> under the link "Heritage

Nortel Products” or such successor site as designated by Avaya. For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Note that each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

Third Party Components

“Third Party Components” mean certain software programs or portions thereof included in the Software or Hosted Service may contain software (including open source software) distributed under third party agreements (“Third Party Components”), which contain terms regarding the rights to use certain portions of the Software (“Third Party Terms”). As required, information regarding distributed Linux OS source code (for those products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the products, Documentation or on Avaya’s website at: <https://support.avaya.com/Copyright> or such successor site as designated by Avaya. The open source software license terms provided as Third Party Terms are consistent with the license rights granted in these Software License Terms, and may contain additional rights benefiting You, such as modification and distribution of the open source software. The Third Party Terms shall take precedence over these Software License Terms, solely with respect to the applicable Third Party Components to the extent that these Software License Terms impose greater restrictions on You than the applicable Third Party Terms.

The following applies if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD (“AVC VIDEO”) AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE <HTTP://WWW.MPEGLA.COM>.

Service Provider

THE FOLLOWING APPLIES TO AVAYA CHANNEL PARTNER’S HOSTING OF AVAYA PRODUCTS OR SERVICES. THE PRODUCT OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM THE THIRD PARTY SUPPLIER. AN AVAYA CHANNEL PARTNER’S HOSTING OF AVAYA PRODUCTS MUST BE AUTHORIZED IN WRITING BY AVAYA AND IF THOSE HOSTED PRODUCTS USE OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING BUT NOT LIMITED TO MICROSOFT

SOFTWARE OR CODECS, THE AVAYA CHANNEL PARTNER IS REQUIRED TO INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE AGREEMENTS, AT THE AVAYA CHANNEL PARTNER’S EXPENSE, DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.

WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE G.729 CODEC, H.264 CODEC, OR H.265 CODEC, THE AVAYA CHANNEL PARTNER ACKNOWLEDGES AND AGREES THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE G.729 CODEC IS LICENSED BY SIPRO LAB TELECOM INC. SEE <WWW.SIPRO.COM/CONTACT.HTML>. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (I) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD (“AVC VIDEO”) AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE <HTTP://WWW.MPEGLA.COM>.

Compliance with Laws

Customer acknowledges and agrees that it is responsible for complying with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

Preventing Toll Fraud

“Toll Fraud” is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company’s behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: <https://support.avaya.com> or such successor site as designated by Avaya.

Security Vulnerabilities

Information about Avaya’s security support policies can be found in the Security Policies and Support section of <https://support.avaya.com/security>.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (<https://support.avaya.com/css/P8/documents/100161515>).

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: <https://support.avaya.com>, or such successor site as designated by Avaya.

Contact Avaya Support

See the Avaya Support website: <https://support.avaya.com> for product or Hosted Service notices and articles, or to report a problem with your Avaya product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <https://support.avaya.com> (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Trademarks

The trademarks, logos and service marks (“Marks”) displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such

Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners. Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

Contents

Chapter 1: Introduction	10
Purpose.....	10
Related resources.....	11
Documentation.....	11
Training.....	11
Viewing Avaya Mentor videos.....	11
Subscribing to e-notifications.....	12
Support.....	14
Searching a documentation collection.....	14
Chapter 2: New in this document	16
Chapter 3: IPv6 basics	18
Origins of IPv6.....	18
Advantages of IPv6.....	18
Comparison of IPv4 and IPv6.....	19
IPv6 packet.....	20
IPv6 header.....	20
IPv6 extension headers.....	21
IPv6 address component summary.....	23
IPv6 address formats.....	24
Address types.....	24
IP address prefix.....	29
Interface ID.....	29
How to write an IPv6 address	30
ICMPv6.....	30
Path MTU discovery.....	31
Routing.....	32
VSP switch route scaling.....	36
IPv6 Circuitless IP.....	38
Equal Cost Multipath.....	39
ECMP with static routes.....	39
Disable IPv6 ICMP multicast.....	40
IPv6 basic configuration using ACLI.....	40
Enabling the IPv6-mode boot config flag.....	40
Configuring an IPv6 static neighbor address.....	41
Configuring an IPv6 interface	43
Assigning IPv6 addresses to a brouter port or VLAN.....	47
Configuring IPv6 route preferences.....	48
Viewing global IPv6 information.....	50
Creating IPv6 static routes.....	54

Viewing routes information.....	56
Creating an IPv6 CLIP interface.....	58
Enabling IPv6 ECMP globally.....	59
Configuring maximum number of ECMP paths	60
Enabling or disabling IPv6 ICMP multicast globally.....	61
IPv6 basic configuration using EDM.....	62
Enabling the IPv6-mode boot config flag.....	62
Configuring IPv6 globally.....	62
Configuring an IPv6 interface.....	64
Assigning IPv6 addresses to interfaces.....	66
Creating IPv6 static routes.....	68
Configuring IPv6 route preferences.....	70
Viewing route information.....	71
Chapter 4: Neighbor discovery.....	72
Neighbor discovery.....	72
Host autoconfiguration.....	76
Neighbor discovery configuration using ACLI.....	78
Configuring an IPv6 discovery prefix.....	78
Configuring route advertisement.....	80
Configuring the neighbor cache.....	85
Viewing cached destination information.....	87
Neighbor discovery configuration using EDM.....	89
Configuring an IPv6 discovery prefix.....	89
Configuring route advertisement.....	91
Configuring the neighbor cache.....	93
Viewing cached destination information.....	94
Chapter 5: DHCP Relay.....	96
DHCP Relay.....	96
DHCP Relay configuration using ACLI.....	97
Configuring a DHCP Relay forwarding path.....	97
Configuring DHCP Relay for an interface.....	99
Viewing DHCP Relay information.....	101
DHCP Relay configuration using EDM.....	102
Configuring a DHCP Relay forwarding path.....	102
Configuring DHCP Relay for an interface.....	103
Modifying DHCP Relay for a VLAN.....	104
Modifying DHCP Relay for a port.....	105
Chapter 6: Tunneling.....	107
Tunneling.....	107
Tunneling configuration using ACLI.....	108
Configuring a tunnel.....	108
Viewing tunnel interfaces.....	109
Modifying tunnel hop limits.....	110

Tunnel configuration using EDM.....	111
Configuring a tunnel.....	111
Modifying tunnel hop limits.....	113
Chapter 7: OSPFv3.....	115
OSPFv3.....	115
IPsec support with OSPFv3.....	118
OSPF Graceful Restart.....	119
Helper mode.....	119
ECMP with OSPFv3.....	120
OSPFv3 configuration using ACLI.....	121
Configuring OSPF globally.....	121
Creating an OSPF area.....	122
Creating OSPF area ranges.....	124
Creating an OSPF virtual link.....	125
Configuring IPsec for the OSPF virtual link.....	127
Configuring OSPF default metrics.....	129
Configuring OSPF on a port or VLAN.....	130
Configuring OSPF on a tunnel.....	134
Viewing OSPFv3 information.....	136
Viewing OSPFv3 default cost information.....	139
Adding an NBMA neighbor.....	140
Configuring link LSA suppression.....	141
Enabling OSPF route redistribution.....	142
Viewing the status of OSPFv3 redistribution.....	143
Disabling Helper mode for OSPFv3.....	143
OSPFv3 configuration using EDM.....	144
Configuring OSPF globally.....	144
Creating an OSPF area.....	146
Creating OSPF area ranges.....	148
Creating an OSPF virtual link.....	149
Configuring IPsec for the OSPF virtual link.....	151
Creating an OSPF interface.....	152
Creating an OSPF VLAN interface.....	155
Viewing the AS-scope link-state database.....	157
Viewing the area-scope LSDB.....	158
Viewing the link-scope LSDB.....	159
Adding an NBMA neighbor.....	160
Enabling OSPF route redistribution.....	161
Modifying an OSPF interface.....	162
Viewing OSPF neighbors.....	164
Viewing virtual neighbors.....	166
Chapter 8: RIPng.....	168
RIPng fundamentals.....	168

RIPng Configuration using ACLI.....	170
Configuring RIPng globally.....	170
Configuring RIPng on an interface.....	170
Configuring RIPng custom values	172
Configuring RIPng route distribution.....	174
RIPng Configuration using EDM.....	176
Configuring an IPv6 RIPng interface.....	176
Configuring route redistribution to RIPng.....	177
Viewing stats for RIPng interfaces.....	177
Configuring RIPng globally.....	178
Chapter 9: VRRP	180
VRRP.....	180
VRRPv3.....	184
VRRPv3 guidelines.....	185
VRRP configuration using ACLI.....	186
Configuring the VRRP interface.....	186
Viewing VRRP information.....	188
Configuring VRRP notification control.....	190
Configuring additional VRRP parameters for an interface.....	191
Enabling IPv6 VRRP preempt-mode.....	193
VRRP configuration using EDM.....	194
Configuring VRRP for an interface.....	194
Configuring VRRP notification control.....	197
Configuring additional addresses on the VRRP interface.....	198
Chapter 10: RSMLT	199
RSMLT.....	199
RSMLT configuration using ACLI.....	200
Configuring RSMLT on a VLAN.....	200
Enabling RSMLT Edge support.....	202
Viewing RSMLT information.....	202
RSMLT configuration using EDM.....	204
Configuring RSMLT on a VLAN.....	204
Enabling RSMLT Edge support.....	205
Modifying the RSMLT local information.....	206
Modifying RSMLT peer information.....	207
Viewing RSMLT Edge peers.....	208
Chapter 11: Viewing IPv6 connections	209
Viewing IPv6 connections using ACLI.....	209
Viewing TCP and UDP information.....	209
Viewing IPv6 connections using EDM.....	211
Viewing TCP global information.....	211
Viewing TCP connections information.....	212
Viewing TCP listeners information.....	213

Viewing UDP endpoint information.....	214
Chapter 12: IPv6 Alternative Routes	216
Alternative routes.....	216
Configuring IPv6 alternative routes.....	217
Chapter 13: IPv6 configuration examples	220
IPv6 tunnels.....	220
OSPFv3.....	224
IPv6 alternative routes configuration example.....	225
Appendix A: ICMPv6 type and code	237
Glossary	239

Chapter 1: Introduction

Purpose

This document provides information on features in VSP Operating System Software (VOSS). VOSS runs on the following product families:

- Avaya Virtual Services Platform 4000 Series
- Avaya Virtual Services Platform 7200 Series
- Avaya Virtual Services Platform 8000 Series

This document provides conceptual and procedural information to configure IPv6 routing operations. Included in this document are Operations, Administration, and Management (OA&M), DHCP Relay, Virtual Router Redundancy Protocol (VRRP), static routes, Open Shortest Path First version 3 (OSPFv3), IPv6 tunnels, and Routed Split MultiLink Trunking (RSMLT).

* Note:

The software does not support IPv4-mapped IPv6 addresses, for example, 0::FFFF:a.b.c.d, or IPv4-compatible IPv6 addresses, for example, 0::a.b.c.d.

Examples and network illustrations in this document may illustrate only one of the supported platforms. Unless otherwise noted, the concept illustrated applies to all supported platforms.

IPv6 uses the following key security features: SNMP version 3 (SNMPv3) and Secure Shell (SSH).

For detailed information about SNMPv3, see *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601 or *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601.

For detailed information about SSH, see *Administering Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-600 or *Administration for Avaya Virtual Services Platform 4000 Series*, NN46251-600.

For information about IPv6 prefix lists for route policies, see *Configuring IP Routing on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-505 or *Configuration - IP Routing for Avaya Virtual Services Platform 4000 Series*, NN46251-505

For information about IPv6 shortcuts and IPv6 Inter-VSN routing, see *Configuring Avaya Fabric Connect on VSP Operating System Software*, NN47227-510.

Related resources

Documentation

For installation and initial setup information of the Open Networking Adapter (ONA), refer to the Quick Install Guide that came with your ONA.

*** Note:**

The ONA works only with the Avaya Virtual Services Platform 4000 Series. For more information about configuring features, refer to the VOSS documentation. See *Documentation Reference for VSP Operating System Software*, NN47227-100 for a list of all the VSP 4000 documents.

Training

Ongoing product training is available. For more information or to register, you can access the Web site at <http://avaya-learning.com/>.

Viewing Avaya Mentor videos

Avaya Mentor videos provide technical content on how to install, configure, and troubleshoot Avaya products.

About this task

Videos are available on the Avaya Support website, listed under the video document type, and on the Avaya-run channel on YouTube.

Procedure

- To find videos on the Avaya Support website, go to <http://support.avaya.com> and perform one of the following actions:
 - In **Search**, type `Avaya Mentor Videos` to see a list of the available videos.
 - In **Search**, type the product name. On the Search Results page, select **Video** in the **Content Type** column on the left.
- To find the Avaya Mentor videos on YouTube, go to www.youtube.com/AvayaMentor and perform one of the following actions:
 - Enter a key word or key words in the **Search Channel** to search for a specific product or topic.
 - Scroll down Playlists, and click the name of a topic to see the available list of videos posted on the website.

 **Note:**

Videos are not available for all products.

Subscribing to e-notifications

Subscribe to e-notifications to receive an email notification when documents are added to or changed on the Avaya Support website.

About this task

You can subscribe to different types of general notifications, for example, Product Correction Notices (PCN), which apply to any product or a specific product. You can also subscribe to specific types of documentation for a specific product, for example, Application & Technical Notes for Virtual Services Platform 7000.

Procedure

1. In an Internet browser, go to <https://support.avaya.com>.
2. Type your username and password, and then click **Login**.
3. Under **My Information**, select **SSO login Profile**.
4. Click **E-NOTIFICATIONS**.
5. In the GENERAL NOTIFICATIONS area, select the required documentation types, and then click **UPDATE**.

GENERAL NOTIFICATIONS

1/5 Notifications Selected

End of Sale and/or Manufacturer Support Notices	<input type="checkbox"/>
Product Correction Notices (PCN)	<input checked="" type="checkbox"/>
Product Support Notices	<input type="checkbox"/>
Security Advisories	<input type="checkbox"/>
Services Support Notices	<input type="checkbox"/>

UPDATE >>

6. Click **OK**.
7. In the PRODUCT NOTIFICATIONS area, click **Add More Products**.

PRODUCT NOTIFICATIONS

Show Details

Add More Products

1 Notices

8. Scroll through the list, and then select the product name.
9. Select a release version.
10. Select the check box next to the required documentation types.

The screenshot shows a web interface with two main panels. The left panel, titled 'PRODUCTS', lists several Avaya products: Virtual Services Platform 7000, Virtualization Provisioning Service, Visual Messenger™ for OCTEL® 250/350, Visual Vectors, Visualization Performance and Fault Manager, Voice Portal, Voice over IP Monitoring, W310 Wireless LAN Gateway, WLAN 2200 Series, and WLAN Handset 2200 Series. A 'My Notifications' link is visible in the top right of this panel. The right panel, titled 'VIRTUAL SERVICES PLATFORM 7000', contains a 'Select a Release Version' dropdown menu set to 'All and Future'. Below this are several checkboxes for documentation categories: Administration and System Programming, Application Developer Information, Application Notes, Application and Technical Notes (checked), Declarations of Conformity, and Documentation Library (checked). A red 'SUBMIT >>' button is located at the bottom right of the right panel.

11. Click **Submit**.

Support

Go to the Avaya Support website at <http://support.avaya.com> for the most up-to-date documentation, product notices, and knowledge articles. You can also search for release notes, downloads, and resolutions to issues. Use the online service request system to create a service request. Chat with live agents to get answers to questions, or request an agent to connect you to a support team if an issue requires additional expertise.

Searching a documentation collection

On the Avaya Support website, you can download the documentation library for a specific product and software release to perform searches across an entire document collection. For example, you can perform a single, simultaneous search across the collection to quickly find all occurrences of a particular feature. Use this procedure to perform an index search of your documentation collection.

Before you begin

- Download the documentation collection zip file to your local computer.
- You must have Adobe Acrobat or Adobe Reader installed on your computer.

Procedure

1. Extract the document collection zip file into a folder.
2. Navigate to the folder that contains the extracted files and open the file named `<product_name_release>.pdx`.

3. In the Search dialog box, select the option **In the index named <product_name_release>.pdx**.
4. Enter a search word or phrase.
5. Select any of the following to narrow your search:
 - Whole Words Only
 - Case-Sensitive
 - Include Bookmarks
 - Include Comments
6. Click **Search**.

The search results show the number of documents and instances found. You can sort the search results by Relevance Ranking, Date Modified, Filename, or Location. The default is Relevance Ranking.

Chapter 2: New in this document

The following sections detail what is new in *Configuring IPv6 Routing on VSP Operating System Software*, NN47227-507.

Release 5.1

IPv6 Alternative Routes

To avoid traffic interruption, enable alternative routes globally on the switch, to replace the best route with the next-best route if the best route becomes unavailable.

For more information, see [Alternative routes](#) on page 216.

To configure IPv6 Alternative Routes using the ACLI, see [Configuring IPv6 alternative routes](#) on page 217. To enable this feature using the EDM, see [Configuring IPv6 globally](#) on page 62.

For a configuration example, see [IPv6 alternative routes configuration example](#) on page 225.

VRRPv3

VRRPv3 is a combined protocol for both IPv4 and IPv6. It specifies an election protocol that dynamically assigns responsibility for a virtual router to one of the VRRP routers on a LAN. The VRRP router controlling the IPv4 or IPv6 addresses associated with a virtual router is called Master, and it forwards packets sent to these IPv4 or IPv6 addresses. VRRP Backups wait for a Master and take ownership when the Master is no longer detected.

The following VRRPv3 enhancements are available as part of this release:

1. Adding VRRPv3 for IPv4.
2. Making both IPv4 and IPv6 VRRPv3 features compliant to RFC5798.

For more information, see [Enabling IPv6 VRRP preempt-mode](#) on page 193.

IPv6 ECMP

With Equal Cost Multipath (ECMP), the switch can determine up to eight equal-cost paths to the same destination prefix. You can use multiple paths for load sharing of traffic. These multiple paths allow faster convergence to other active paths in case of network failure.

For more information, see:

- [Equal Cost Multipath](#) on page 39
- [Enabling IPv6 ECMP globally](#) on page 59
- [Configuring maximum number of ECMP paths](#) on page 60

- [Configuring IPv6 globally](#) on page 62

ECMP support for OSPFv3

This release introduces ECMP support for dynamic routing protocols. The ECMP feature supports and complements OSPFv3 protocol. For more information, see [ECMP with OSPFv3](#) on page 120.

Enable or disable IPv6 ICMP multicast

This release introduces the option to enable or disable IPv6 ICMP multicast processing. For more information, see:

- [Disable IPv6 ICMP multicast](#) on page 40
- [Enabling or disabling IPv6 ICMP multicast globally](#) on page 61
- [Configuring IPv6 globally](#) on page 62

OSPFv2 and OSPFv3 route metric value updates

New parameter VLAN added for configuring default-cost under router OSPF configuration, for both ACLI and EDM. For more information, see:

- [Configuring OSPF default metrics](#) on page 129
- [Viewing OSPFv3 default cost information](#) on page 139

Chapter 3: IPv6 basics

This chapter provides concepts and procedures to complete basic IPv6 configuration, for example, IPv6 forwarding and static routes.

Origins of IPv6

The growth of IP address use is exponential.

Predictions indicated that the IPv4 address pool could be exhausted as early as 1994.

So, in July 1991, the Internet Engineering Task Force (IETF) began researching a replacement for IPv4.

That replacement is IPv6.

The Internet Assigned Numbers Authority (IANA) free pool of IPv4 addresses reached 0% in February 2011, according to the American Registry for Internet Numbers (ARIN).

While IPv4 addresses may remain available for some time within reserved pools, no further IPv4 addresses are available for reservation.

Although IPv6 is designed to replace IPv4, IPv6 is not backward-compatible and IPv4 and IPv6 need to coexist within your network during and after the transition to IPv6.

Advantages of IPv6

IPv6 can provide more addresses and support more networks than IPv4. For example, IPv6 offers enough addresses for every person on Earth to have 1 million addresses.

Because IPv6 offers a larger address space it offers improved scalability.

Following are additional advantages of IPv6 over IPv4:

- With 128 bit addresses, the larger IPv6 address space offers global access and scalability and solves the pending exhaustion of IP addresses.
- Network Address Translation (NAT) is no longer required.

Flat address space and transparency are restored by IPv6 because NAT is eliminated.

- Routing efficiency is improved due to the hierarchical network architecture.

IPv6 allows for hierarchical routing and effective route summarization.

- IPv6 supports Auto-configuration.
- IPv6 supports plug-and-play.
- Enhanced support is included for mobile IP and mobile computing devices.

Addresses can be permanently assigned to end devices such as DSL, PDAs, mobile terminals and PCs.

- Neighbor discovery (ND) replaces ARP in IPv6.

ND combines the IPv4 services for IPv4 Address Resolution Protocol (ARP) and router discovery.

Comparison of IPv4 and IPv6

The following table compares the key differences between IPv4 and IPv6.

*** Note:**

This information may not reflect IPv6 support in the current release.

Table 1: IPv4 and IPv6 key differences compared

Feature	IPv4	IPv6
Address length	32 bits	128 bits
IPsec support	Optional	Required
QoS support	Limited	Improved
Fragmentation	Hosts and routers	Hosts only
Minimum MTU packet size	576 bytes	1280 bytes
Checksum in header	Yes	No
Options in header	Yes	Yes
Link-layer address resolution	ARP (broadcast)	Multicast neighbor discovery messages
Multicast membership	IGMP	Multicast Listener Discovery
Router discovery	Optional	Optional
Uses broadcasts	Yes	No
Address configuration	Manual, DHCP	Automatic, DHCP

IPv6 packet

Each IPv6 packet can include mandatory and non-mandatory components.

An IPv6 packet includes:

- The basic header, which has a fixed length and is mandatory
- Extension header(s) , which has a variable length and is not mandatory
- Payload, which has a variable length and is not mandatory

The following figure illustrates the components of an IPv6 packet.




Figure 1: IPv6 packet components

*** Note:**

Nodes must be able to handle packets up to 1,280 octets in length.

IPv6 header

The IPv6 header basic length is fixed at 40 octets (bytes) and it contains the following fields:

Table 2: Fields in the IPv6 header

Field	Size in bits
Ver—Internet Protocol version number, with a value of 6	4
DS byte—Traffic class field, similar to Type of Service in IPv4	8
Flow label—identifies traffic flow for additional Quality of Service (QoS)	20
Payload Length—Unsigned integer, the length of the IPv6 payload	16
Next header selector—identifies the next header	8
Hop limit unsigned integer—decrements by 1 each time a node forwards the packet (nodes discard packets with hop limit values of 0)	8
Source address	128
Destination address	128

The following figure illustrates the basic IPv6 header, without extension headers.




Figure 2: IPv6 header

IPv6 extension headers

IPv6 extension headers describe processing options.

Each extension header contains a separate category of options and is identified by a number, similar to protocol identification numbers.

An IPv6 packet can include extension headers, but they are not mandatory.

The following figure illustrates the IPv6 header with extension headers.




Figure 3: IPv6 header with extension headers

IPv6 examines the destination address in the main header of each packet it receives.

This examination determines whether the router is

- the packet destination - if the router is the packet destination, IPv6 examines the header extensions that contain options for destination processing.

- an intermediate node in the packet data path - if the router is an intermediate node, IPv6 examines the header extensions that contain forwarding options.

By examining only the extension headers that apply to the operations it performs, IPv6 reduces the amount of time and resources required to process a packet.

IPv6 defines the following extension headers as described in the following table:

Table 3: IPv6 extension headers

Extension header name	Description
hop-by-hop	Contains optional information, and sub-options for Router Alert and Jumbo Payload, that all intermediate IPv6 routers examine between the source and the destination.
destinations-options	Contains optional information for the destination node. This option can appear twice, once for way points and once for final destination.
source-routing	Contains a list of one or more intermediate nodes that define a path for the packet to follow through the network to the destination. The packet source creates this list. The source-routing function is similar to the IPv6 source routing options.
fragmentation	Uses an IPv6 source to send packets larger than the size specified for the path maximum transmission unit (MTU).
authentication	provides security for IPv6 datagrams
encapsulated security payload (ESP)	provides security for IPv6 datagrams
The authentication extension header and the encapsulated security payload extension header can be used together to provide security services for IPv6 datagrams.	

The recommended extension header order is:

- Hop-by-hop
- Destination option 1
- Routing
- Fragmentation
- Authentication/ESP
- Destination Option 2

The presence of particular extension headers within a packet can cause slower packet processing if the IPv6 implementation handles only certain headers and diverts others to a slow path. For example, many IPv6 implementations usually process Hop-by-Hop extension headers on the control plane.

IPv6 address component summary

The IPv6 Internet is divided into addressing zones and IPv6 addresses can be categorized by type and scope.

IPv6 addressing is represented in RFC 4291.

Address types

IPv6 addresses are divided into the following types:

- Unicast
- Multicast
- Anycast

Unicast:

Unicast addresses provide one-to-one communication.

Unicast addresses can be

- Global
- Link local
- Special, for example: Unspecified and Loopback

Multicast:

Multicast addresses are similar in operation to IPv4 and provide one-to-many communication.

Anycast:

An Anycast address is a Unicast address used for several devices to allow them to communicate with the device closest to the source; one-to-nearest communication.

The switch supports Subnet-Router Anycast: example <prefix>::0.

Broadcast:

In IPv6, broadcast addresses have been superseded by multicast addresses per RFC 4291.

Address scopes

Following are IPv6 address scopes:

- node-local
- link-local
- global

The switch does not support site-local addresses and, according to RFC 4193, site-local addresses will be replaced by unique-local addresses.

For more information about address types and scopes, see [IPv6 address formats](#) on page 24

Address zones

The IPv6 Internet is divided into zones.

For example:

- Each node is a separate zone of the node-local scope.
- Each link is a separate zone of the link-local scope.
- The entire Internet is a single zone of global scope.

Zones of the same scope do not overlap.

IPv6 address formats

IPv6 addresses are 128 bits long. In comparison, IPv4 addresses are 32 bits in length.

The IPv6 address contains an

- address type
- address prefix
- interface ID

The following figure illustrates the IPv6 address format.

Type	Address prefix	Interface ID
------	----------------	--------------

Figure 4: IPv6 address format

Address types

IPv6 uses three main address types to help route packets.

Address types are:

- Unicast: global, link—local, special unspecified, special loopback
- Multicast
- Anycast

Unicast addresses

Unicast addresses provide one-to-one communication.

Global:

A Unicast global address identifies a single interface and is similar to an IPv4 public address.

Unicast global addresses are globally routable in the same manner as IPv4 addresses.

The following figure illustrates the Unicast global address parts.




Figure 5: Unicast global address parts

An IPv6 Unicast global address is composed of the following 3 levels:

- public topology (48 bit Global Routing Prefix)
 - 001, specifies an IPv6 Unicast global address
 - Top Level Aggregation Identifier (TLA ID), the highest level in routing hierarchy
 - Res, reserved for future use
 - Next Level Aggregation Identifier (NLA ID), specifies a customer site
- site topology (16 bit Subnet ID)
 - Site Level Aggregation Identifier (SLA ID); assigned within the site, an ISP cannot affect the SLA ID, enables up to 65,536 subnets within a site
- interface ID (64 bits)
 - specifies the interface for a node on a subnet

The system uses the 48 bit global routing prefix for the route prefix exchange.

The IPv6 Prefix for Unicast global is 2000::/3 (RFC3513).

Link-local:

Hosts on the same link/subnet use automatically configured IPv6 Unicast link-local addresses to communicate with each other.

Link-local addresses are automatically configured on all interfaces.

Routers do not forward packets containing a destination or source address with a link-local address.

IPv6 uses neighbor discovery (ND) for address resolution.

The IPv6 prefix for link-local Unicast addresses is FE80::/10 (RFC3513).

The following figure illustrates the parts of a Unicast Link-local address.




Figure 6: Unicast Link-local address

Special addresses:

The Unicast/special/unspecified address indicates the absence of an address and is the only valid SRC address for IPv6 Duplicate Address Detection (DAD).

Equivalent to the IPv4 unspecified address 0.0.0.0, represented as 0:0:0:0:0:0:0:0 or ::1; an IPv6 host that does not have a valid address uses the unspecified address as its source address when it sends a packet to discover whether an address is used by another node (during the boot process when the host requests address configuration information).

*** Note:**

Do not assign an unspecified address, either statically or dynamically, to an interface.

The Unicast/special/loopback address is a special case Unicast address only found inside a single node.

The switch does not support the loopback address.

Equivalent to the IPv4 loopback address 127.0.0.1, represented as 0:0:0:0:0:0:0:1 or ::1; a node uses a loopback address to send a packet to itself.

The loopback address is beneficial in troubleshooting and testing the IP stack because you can use it to send a packet to the protocol stack without sending it onto the subnet.

*** Note:**

Do not assign a loopback address, either statically or dynamically, to an interface.

Both Loopback and Unspecified addresses are not valid destination addresses.

IPv6 Unicast address example:

An example of a unicast IPv6 address is 1080:0:0:0:8:8000:200C:417A

IPv6 Link-local Unicast address example:

An example of a link-local Unicast IPv6 address is FE80::4445:4eff:fe54:1212

Multicast addresses

Multicast addresses provide one-to-many communication.

An IPv6 multicast address identifies a group of nodes.

The scope is built into the multicast address structure.

The system uses a multicast address to send traffic to multiple destinations. In this situation traffic experiences less delay with a multicast address than it would with Unicast address.

The following figure shows the format of an IPv6 multicast address.

8 bits	4 bits	4 bits	112 bits
11111111	flags	scope	group ID

Figure 7: IPv6 multicast address format

A value of FF (11111111) in the 8 high-order bits of an IPv6 address indicates that the address is an IP multicast address.

The Multicast IPv6 Prefix is FF00::/8 (RFC3513).

Flags:

The 4-bit flags field indicates whether the group is permanent or transient. The first 3 bits are reserved and the 4th bit represents the Transient flag. Currently only the Transient (T) flag is defined. A T flag set to 0 specifies a permanently assigned multicast address. A T flag set to 1 specifies a transient address.

Group ID:

The 112 bit group ID identifies the multicast group.

An example of a multicast address is FF01:0:0:0:0:0:101

Scope field:

The 4-bit scope field within the group ID specifies the multicast traffic scope.

Following is a list of the scope options that limit the scope of the multicast address:

- 1 - node-local
- 2 - link-local
- 3 - subnet local
- 4 - admin local
- 5 - site-local – not supported
- 8 - organization-local
- B - community-local
- E - global

Examples of multicast addresses:

All-nodes addresses look like this:

FF01::1 (Node Local), FF02::1 (Link Local)

All-routers addresses look like this:

FF01::2 (Node Local), FF02::2 (Link Local)

A solicited node or host address looks like this:

FF02::1:FF1E:8329.

In this case the MAC is 00-02-B3-1E-83-29 and the IPv6 address is fe80::202:B3FF:FE1E:8329.

The following table lists some well-known multicast IPv6 addresses

Table 4: Well known multicast IPv6 addresses

Name	Address
All Nodes	FF02:0:0:0:0:0:1
All Routers	FF02:0:0:0:0:0:2
OSPFGRP	FF02:0:0:0:0:0:5

Table continues...

Name	Address
OSPF/IGP Designated Routers	FF02:0:0:0:0:0:6
All PIM Routers	FF02:0:0:0:0:0:D
VRRP	FF02:0:0:0:0:0:12
All MLDv2-capable routers	FF02:0:0:0:0:0:16
All DHCP agents	FF02:0:0:0:0:0:2
Solicited Node address	FF02::1:FF00:0000/104

Anycast

Anycast addresses provide one-to-nearest (one to one-of-many) communication.

An anycast address designates a set of interfaces that share an address.

A packet sent to an anycast address goes only to the nearest member of the group. Considering routing distance, the system delivers packets with Anycast addresses only to the nearest member of a group of multiple interfaces.

Restrictions:

An anycast address must not be:

- used as the source address in an IPv6 packet
- assigned to an IPv6 host (you can assign an anycast address to an IPv6 router)

Anycast address scopes:

Anycast addresses have the following scopes:

- Link-local—the local link; nodes on the same subnet
- Global—IPv6 Internet addresses

Similar to anycast IPv4 addresses, IPv6 anycast addresses are more efficient. They use the unicast address space but identify multiple interfaces.

IPv6 delivers a packet bearing an anycast address to the nearest interface identified by the address.

Currently anycast addresses are assigned to routers and are used as destination addresses. Because packets bearing anycast addresses are delivered to the closest router, you can also access the closest name server or time server with an anycast address.

Visually there is no distinction between an anycast address and a unicast address.

* Note:

The switch supports only the subnet-router anycast address.

You cannot configure any specific anycast addresses beyond the automatic, generic subnet-router anycast address.

Difference between multicast and anycast

Anycast address delivery is from one to one-of-many, whereas multicast address delivery is from one to many.

IP address prefix

Address prefixes represent one of the following:

- network identifier
- fixed address part

Examples of IP address prefixes:

2001:10F2::/48 represents a summarized route prefix

2001:10F2:0:102F::/64 represents a subnet or link prefix

FF00::/8 represents Multicast IPv6

Interface ID

Interface identifiers identify interfaces on a link.

As long as the interfaces are attached to different subnets, you can use the same identifier on more than one interface on a single node.

The IPv6 interface ID is as unique as the MAC address.

The interface ID is derived by a formula that uses the link layer 48-bit MAC address. In most cases, the interface ID is a 64-bit interface ID that contains the 48-bit MAC address. If you enter less than 64 bits, the system adds leading zeroes to extend the interface ID length to 64 bits.

You can configure the interface ID in the following ways:

- Manual configuration
- DHCPv6 (can configure the whole address)
- Automatic derivation from EUI-64 (MAC address or other HW serial)—enables serverless or stateless auto-configuration when combined with high order part of address learned from router advertisements
- Pseudo-random generation (client privacy)—enables serverless or stateless auto-configuration when combined with high order part of address learned from router advertisements

The switch supports manual interface ID configuration or automatic derivation from EUI-64.

Note:

You must manually specify the network prefix, regardless of the interface ID formation method.

For stateless autoconfiguration, the ID is 64 bits in length.

For more information about stateless autoconfiguration, see [Host autoconfiguration](#) on page 76.

How to write an IPv6 address

The appearance of IPv6 addresses differs from IPv4 addresses and you express them differently.

The 128 bits in an IPv6 address are divided into 8 blocks of 16 bits each.

Following is the preferred IPv6 address format:

```
XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX
```

Hexadecimal IPv6 address representations:

Each 16 bit block in an IPv6 address is converted into a 1 to 4 digit hexadecimal number separated by colons (:).

The format to represent an IPv6 address is n:n:n:n:n:n:n, where n is the hexadecimal representation of 16 bits in the address; for example, FF01:0:0:0:0:0:0:43.

Each nonzero field must contain at least one numeral.

Within a hexadecimal field, you do not need leading zeros.

Certain classes of IPv6 addresses commonly include multiple adjacent fields that contain hexadecimal 0.

The sample address—FF01::43—includes six adjacent fields that contain zeroes represented by a double colon (::) .

You can use a double colon to compress the leading zero fields in a hexadecimal address.

A double colon can appear only once in an address.

Four more ways to write an IPv6 address:

```
2001:10F2:0000:0000:25AB:0000:0000:0001  
2001:10F2:0:0:25AB:0:0:1  
2001:10F2:0:0:25AB::1  
2001:10F2::25AB:0:0:1
```

ICMPv6

Internet Control Message Protocol version 6 (ICMPv6) maintains and improves on features from ICMP for IPv4.

ICMPv6 reports the delivery of forwarding errors.

For example:

- Destination unreachable
- Packet too big (path MTU)
- Time exceeded (fragmentation)
- Parameter problem

ICMPv6 also delivers information messages such as ping, otherwise known as

- Echo request
- Echo reply

! **Important:**

By providing a framework for informational messages, ICMPv6 plays an important role in IPv6 features such as

- Neighbor discovery (ND)
- Path MTU discovery
- Multicast Listener Discovery (MLD)

You can identify an IPv6 ICMP packet because the Next Header field in the IPv6 packet header is 58.

Internet Protocol Security (IPsec) with ICMPv6

You can configure IPsec with ICMPv6. For a configuration example of IPsec with ICMPv6, see *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601 or *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601.

Path MTU discovery

IPv6 routers do not fragment packets.

The source node may send packets less than or equal to the maximum transmission unit (MTU) of the link layer.

As the packet travels through the network to the source it may encounter a link with a smaller MTU. If so, the router sends the source node an ICMP error message that contains the MTU size of the next link. The source IPv6 node then resends a packet equal to the size of the MTU included in the ICMP message.

The default Layer 3 IPv6 MTU value is 1500 where the system MTU default value is 1950.

The default IPv6 MTU value is always less than the default System MTU value.

You can configure the MTU for each IPv6 interface.

***** **Note:**

To configure separate Layer 3 MTU values for IPv4 and IPv6 packets on the same VLAN interface, you must enable the Unicast Reverse Path Forwarding (uRPF) mode using the command `boot config flags urpf-mode`. Otherwise, both IPv4 and IPv6 packets will have the same MTU values.

Routing

A routing table is present on all nodes.

The routing table stores information about IPv6 network prefixes and how to reach them.

*** Note:**

The switch requires routing protocols, such as OSPFv3 to exchange IPv6 routing prefixes.

For each incoming packet, the switch checks the destination neighbor cache first. If the destination is not in the destination neighbor cache, the routing table determines:

- the next-hop interface (the interface used for forwarding)
- the next-hop address

*** Note:**

The system uses the IPv6 Neighbor Cache for on-link, directly-connected destinations only. Off-link destinations go through a next-hop router, as determined by the next-hop address lookup.

IPv6 routes in a routing table can be:

- directly attached network routes using a 64-bit prefix
- remote network routes using a 64-bit or lower prefix
- host routes using a 128-bit prefix length
- the default route using a prefix of `::/0`

The switch supports OSPFv3 as the IPv6 routing protocol.

You can redistribute directly connected routes and Pv6 static routes into OSPFv3.

This document focuses on OSPFv3. For information about OSPFv2, see *Configuring OSPF and RIP on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-506 or *Configuring OSPF and RIP on Avaya Virtual Services Platform 4000 Series*, NN46251-506.

To configure IPv6 routing on a VLAN, an IP address is assigned to the VLAN. This IP address is not associated with any particular physical port, but is used on all ports where this VLAN is a member.

On a brouter port, a single port VLAN is used to route the traffic. IPv4 and IPv6 traffic is routed in the single-port brouter VLAN.

Other VLANs (which are multiple port VLANs) can bridge and route the traffic.

Virtual routing between IPv6 subnets

The switch supports IPv6 routing between subnets.

When you add an IP address to the VLAN, the system maps an IP subnet to the VLAN.

As shown in the following figure, although VLAN 1 and VLAN 2 reside on the same switch, for traffic to flow from VLAN 1 to VLAN 2, you must route the traffic.

You must enable IPv6 forwarding to route IPv6 traffic between VLANs. And you must enable IPv6 both globally and on a specific VLAN basis in order for forwarding to function. You can enable or disable IPv6, either globally or on a specific VLAN basis.




Figure 8: IPv6 routing between VLANs

When you configure routing on a VLAN, an IPv6 address assigned to the VLAN is the VLAN IP interface.

The VLAN IPv6 address can be reached through any VLAN port, and frames route from the VLAN through the gateway IPv6 address.

You can forward traffic to any IPv6 subnet in the switch. A VLAN can be reached only if it has an IPv6 interface configured on it.

Because a port can belong to multiple VLANs, a one-to-one correspondence no longer exists between the physical port and the router interface when VLAN tagging is enabled.

If you do not enable VLAN tagging a single port can belong only to one port-based VLAN, but that same single port can belong to multiple policy-based VLANs.

As with any IPv6 address, you can use any VLAN IP interface for device management.

For the Simple Network Management Protocol (SNMP) or Telnet management, you can use any VLAN IP interface to access the switch while routing is enabled on the VLAN.

Brouter ports

A brouter port is a single-port VLAN that can route IP packets and bridge all nonroutable traffic.

The difference between a brouter port and a standard protocol-based VLAN configured for routing is that the routing interface of the brouter port is not subject to the spanning tree state of the port. A brouter port can be in the blocking state for nonroutable traffic while it routes IP traffic.

* Note:

Because a brouter port is a one-port VLAN, each brouter port decreases the number of available VLANs by one and uses one VLAN ID.

Static routes

Static routes provide an alternative method for establishing route reachability.

Static routes, with dynamic routes, provide routing information from the forwarding database.

Only enabled static routes whose nexthop address is reachable are submitted to the Route Table Manager (RTM), which determines the best route based on reachability, route preference, and cost.

The RTM communicates all updates to best routes.

If the nexthop is not reachable you can use the `show ipv6 route static` command to display the status. If the nexthop is not reachable, the status is `TryToResolve` and the route does not appear in the RTM until the nexthop address is resolved.

For directly-connected IPv6 Subnets you do not need to specify a nexthop address; you can specify outgoing Tunnel-ID, VLAN, or port. If you use outgoing Tunnel-ID, VLAN, or port, the implied nexthop value is `0::0`.

When you configure static routes with a link-local nexthop, you must also specify the outgoing Tunnel-ID, VLAN, or port because link-local addresses are ambiguous unless the proper interface binding is attached. For example: `ipv6 route 1234::/64 cost 1 next-hop fe80::1 vlan 1900`.

You must provide the following options to configure a static route:

- local or nonlocal hop option

Configure a static route either with a next hop that exists on a locally attached network or a next hop that is reachable through a dynamic route. The static route is available as long as the next hop is reachable.

- route preference

You can specify the route preference for the static routes as follows:

- Global value for all static routes: the preference is either static or dynamic routes.
- Preference for each static route entry: if specified, this value overrides the global value for the entry which provides flexibility to change the general behavior of a specific static route.

- Administrative status

Controls when the static route is considered for forwarding. Administrative status differs from the operational status. An admin-enabled static route can still be unreachable and not used for forwarding. An admin-disabled static route is operationally a nonexistent route.

- Multiple static routes

Specify alternative paths to the same destination. Multiple static routes provide stability and load balancing.

To configure a default static route, supply a value of 0 for the prefix and the prefix length.

The following table describes events that affect static route operation.

Table 5: Events and their affects on static route operation

Action	Result
Change the administrative status of the static route	Makes the static route unavailable for forwarding You can use one ACLI command to administratively enable or disable all static routes as follows <code>ipv6 route static enable</code> . You can administratively disable all routes but preserve the static route configuration when you use the following ACLI command: <code>no ipv6 static route enable</code> .
Delete the IPv6 addresses of a VLAN or brouter port	Permanently deletes the static routes with the corresponding local neighbors from the RTM, the forwarding database, and the configuration database
Delete a VLAN	Removes static routes with a local next-hop option from the configuration database. Static routes with a

Table continues...

Action	Result
	nonlocal next-hop option become inactive (they are removed from the forwarding database).
Disable forwarding on a VLAN or brouter port	Static routes reachable through the locally attached network become inactive
Disable a VLAN or brouter port	Makes the static route inactive
Disable IPv6 forwarding globally	Stops forwarding all IPv6 traffic
Learn changes about a dynamically learned neighbor	After a neighbor becomes unreachable or is deleted, the static route with the neighbor becomes inactive, and the configuration is not affected. The static route with the neighbor becomes active in the configuration and is added to the RTM and forwarding database when the neighbor becomes reachable.
Enable a static route	Adds the route to the RTM to change certain static routes to active.
Delete a static route	Permanently deletes a static route from the configuration.
Disable a static route	Stops traffic on the static route but does not remove the route from the configuration.
Change a route preference	After the static route preference changes, the best routes for the entries use both static and dynamic paths.
Delete or disable a tunnel	Removes the tunnel entry from the forwarding table
Enable a tunnel	Activates the tunnel static routes and adds an entry to the forwarding table.

The local-next-hop flag is not required for Pv6.

An IPv4 device cannot learn a neighbor ARP entry unless the device uses a local route entry.

In IPv6, a host can learn a neighbor entry if the device is physically connected to the neighbor (one hop).

The static route becomes active when the next hop is reachable by a dynamic route neighbor resolution. The static route takes the forwarding information from the dynamic route. If the next hop is reachable using a local route, the neighbor resolution is required.

Static route table:

The static route table is separate from the system routing table that the router uses to make forwarding decisions.

You can use the static route table to directly change static routes.

Although the tables are separate, the system routing table automatically reflects the static routing table manager entries if the next-hop address in the static route is reachable and if the static route is enabled.

The static route table is indexed by four attributes:

- destination network
- destination mask
- next hop
- interface

The maximum number of entries is 10,000, except for Avaya Virtual Services Platform 4000 Series, which has a maximum of 1,000. You can insert static routes by using the static route table, and you can delete static routes by using either the static route table or the system routing table.

! Important:

The system routing table stores only active static routes with the best route preference. A static route is active only if the route is enabled and if the next-hop address is reachable; for example, if a valid IPv6 neighbor cache entry exists for the next hop.

You can enter multiple routes (for example, multiple default routes) that use different costs and the lowest cost route that is reachable appears in the routing table.

If you enter multiple next hops for the same route with the same cost, the switch does not replace the existing route.

If you enter the same route with the same cost and a different next hop, the switch uses the first route. If that first route becomes unreachable, the system activates the second route, with a different next-hop, with no connectivity loss.

VSP switch route scaling

The following table provides switch route scaling information for IPv4 and IPv6, and shows the impact of configuring the `boot config flags ipv6-mode` flag.

Table 6: VSP switch route scaling

	VSP 4000 Series	VSP 7200 Series and VSP 8000 Series
<code>boot config flags ipv6-mode</code> is not configured (this is the default)	16,000 single-wide route entries shared between IPv4 and IPv6 routes, where: <ul style="list-style-type: none"> • 256 are reserved for local routes • Each IPv4 route uses 1 route entry (maximum of 15,744 IPv4 routes) • Each IPv6 route uses 2 route entries (maximum of 7,887 IPv6 routes with a prefix length less than or equal to 64 bits), plus (256 entries for IPv6 	Route table in the hardware is not segmented. 16,000 single-wide route entries shared between IPv4 and IPv6 routes, where: <ul style="list-style-type: none"> • 512 are reserved for local routes • Each IPv4 route uses 1 route entry (maximum of 15,488 IPv4 routes) • Each IPv6 route uses 2 route entries (maximum of 7,744 IPv6 routes)

Table continues...



	VSP 4000 Series	VSP 7200 Series and VSP 8000 Series
	routes with a prefix length greater than 64 bits)	<p>with a prefix length less than or equal to 64 bits</p> <p>A mixed IPv4 and IPv6 combination cannot exceed 15,488.</p> <p> Note:</p> <p>IPv6 routes with a prefix length greater than 64 bits are not supported.</p>
<code>boot config flags ipv6-mode</code> is configured	Same as above; <code>boot config flags ipv6-mode</code> does not apply to VSP 4000.	<p>Hardware route table is segmented into two portions.</p> <p>16,000 single-wide route entries are split into two tables, each with 8,000 entries:</p> <ul style="list-style-type: none"> • Table-1, which has 8,000 entries, contains only IPv6 routes of prefix length greater than 64 bits. Each IPv6 route (prefix length greater than 64 bits) uses 4 route entries, so there is support for a maximum of 2,000 IPv6 routes (prefix length greater than 64 bits). • Table-2, which has 8,000 entries, can contain IPv6 routes with a prefix length less than or equal to 64 bits, or IPv4 routes. <ul style="list-style-type: none"> - 512 are reserved for local routes - Each IPv4 route uses 1 route entry so there is support for a maximum of 7,488 IPv4 routes. - Each IPv6 route (prefix length less than or equal to 64 bits) uses two route entries, so there is support for a maximum of 3,744 IPv6 routes. <p>A mixed IPv4 and IPv6 combination cannot exceed 7,488.</p> <p> Note:</p> <p>Table-1 and Table-2 are reserved for each of the route types. Even if Table-2 is empty, IPv6 routes of greater than 64 bit</p>

Table continues...

	VSP 4000 Series	VSP 7200 Series and VSP 8000 Series
		prefix length cannot be stored in Table-2. Similarly, even if Table-1 is empty IPv4 routes or IPv6 routes of prefix length less than or equal to 64 bits cannot be stored in Table-1

IPv6 Circuitless IP

IPv6 Circuitless IP (CLIP) is a virtual interface that is not associated with any physical port. You can use an IPv6 CLIP interface to provide uninterrupted connectivity to your switch as long as an actual path exists to reach the device. The system treats the IPv6 CLIP interface like an IPv6 interface and treats the network associated with the IPv6 CLIP as a local network attached to the device. This route always exists and the circuit is always up because no physical attachment exists.

You can use an IPv6 CLIP address as a logical IPv6 address for network management, as well as for other purposes. The IPv6 CLIP is typically a host address with any prefix length. You can redistribute this address as part of any other routing protocol update, so that the CLIP address is known to neighbors and available for use in routing or other types of connectivity. You can use IPv6 CLIP for many kinds of management connectivity such as telnet or SSH. You can also use IPv6 CLIP as a source IP address for sending Syslog messages.

IPv6 CLIP restrictions and limitations

This section describes the restrictions and limitations associated with IPv6 CLIP.

- Stateless address autoconfiguration (SLAAC) is not supported on IPv6 CLIP interfaces.
- IPv6 CLIP does not support link-local address configuration.
- To configure an IPv6 address with a prefix length from 65 to 127 on a CLIP interface, you must enable the ipv6 mode flag.

*** Note:**

This limitation applies only to VSP 8000 switches. It does not apply to VSP 4000 switches.

- Neighbor discovery (ND) does not run on an IPv6 CLIP interface. Therefore, the system does not detect duplicate IPv6 address assignment to this interface.
- Multiple IPv6 address configuration on an IPv6 CLIP interface is not supported.
- You can configure a maximum of 64 IPv6 CLIP interfaces.
- IPv6 CLIP interface is enabled by default and it cannot be disabled.

Equal Cost Multipath

With Equal Cost Multipath (ECMP), the switch can determine equal-cost paths to the same destination prefix. You can use multiple paths for load sharing of traffic. These multiple paths allow faster convergence to other active paths in case of network failure. By maximizing load sharing among equal-cost paths, you can use your links between routers more efficiently when sending IP traffic. ECMP is formed using routes from the same source or protocol, and the ECMP routes are evaluated within each routing protocol.

The ECMP feature supports and complements the following protocols and route types:

- OSPFv3
- Static routes
- BGP+
- IS-IS
- IP Shortcut

ECMP with static routes

ECMP supports and complements static routes.

The following points need to be considered while configuring ECMP with static routes:

- When ECMP is globally enabled, the equal cost static routes are added in the Routing Table Manager (RTM).
- Static routes that are configured only using an interface, such as VLAN or port, do not support ECMP as these routes have a preference value of 0 and are treated like local routes.
- On VSP 7200 Series and VSP 8000 Series switches, static routes configured on a management interface do not support ECMP.
- Static routes configured by next-hop are not considered equal cost with routes that are configured by tunnel even if the routes have the same cost and preference.
- A static route configured by tunnel is the least preferred and is programmed only when a next-hop or an interface does not configure a static route.
- Static routes configured by next-hop that resolves their next-hop using another static route will be in the `notReachable` state even if the next-hop can be pinged.
- If there are two static routes configured by next-hop, and both next-hops are resolved via a dynamic protocol to the same value, then only one route will be in the `reachableInRtm` state. The state of the other route will be `reachableNotInRtm`.

Disable IPv6 ICMP multicast

On IPv6 networks, a packet can be directed to an individual machine or multicast to a set of hosts. When a packet is sent to an IPv6 multicast address from a machine on the local network, that packet is delivered to a subset or all machines on that network.

If the packet that is sent to the multicast address is an ICMP Echo Request packet, the machines on the network will receive this ICMPv6 echo request packet and send an ICMP echo reply packet back. When all the machines on a network respond to this ICMPv6 echo request, the result can be severe network congestion or outages.

VOSS devices always respond to the IPv6 ICMP packets sent to a multicast address. However, you can disable the processing of IPv6 ICMP packets sent to a multicast address on the device. On disabling the ICMP multicast processing, all the packets containing ICMP sent to multicast addresses are dropped when the packets reach the control plane.

IPv6 basic configuration using ACLI

Enabling the IPv6–mode boot config flag

To enable IPv6 mode, you need to enable the IPv6-mode boot config flag. This flag is disabled by default. Use this procedure to enable (set to true) the IPv6-mode boot config flag.

Enable this flag to support IPv6 routes with prefix-lengths greater than 64 bits.

When the IPv6-mode boot config flag is enabled, the maximum number of IPv4 routing table entries decreases. For scaling information, see *Release Notes for VSP Operating System Software*, NN47227-401.

About this task

This procedure does not apply to VSP 4000 Series.

Procedure

1. Enter Global Configuration mode:

```
enable
```

```
configure terminal
```
2. Enable the IPv6-mode boot config flag:

```
boot config flags ipv6-mode
```
3. Save the configuration, and then reboot the switch for the change to the IPv6-mode boot config flag to take effect.
4. After you reboot the switch, verify that the IPv6-mode boot config flag is set to true:


```
show boot config flags
```

Configuring an IPv6 static neighbor address

You can use static IPv6 neighbors to manually specify the link-layer address for a given IPv6 endpoint.

Before you begin

- Enable IPv6 forwarding.

About this task

Under normal operation you do not need to configure static IPv6 neighbors.

However, IPv6 static neighbors can be used to:

- avoid the overhead associated with dynamic neighbor discovery protocol traffic
- help troubleshoot specific network scenarios

Because IPv6 forwarding is disabled by default, you can only use local IPv6 connections and traffic does not traverse an IPv6 network.

To configure an IPv6 static neighbor address you must enable IPv6 forwarding.

Procedure

1. Enter Global Configuration mode:

```
enable
```

```
configure terminal
```

2. Enable forwarding:

```
ipv6 forwarding
```

3. Configure an IPv6 neighbor address:

```
ipv6 neighbor WORD<0-128> port {slot/port[sub-port]} mac
<0x00:0x00:0x00:0x00:0x00:0x00> [vlan <1-4059>]
```

4. Configure optional parameters if the default values do not meet your requirements:

- a. Configure the hop limit:

```
ipv6 hop-limit <0-255>
```

The default is 64.

- b. Configure the ICMP error interval:

```
ipv6 icmp error-interval <0-2147483647>
```

The interval is in milliseconds. An interval of 0 results in no error messages. The default is 1000.

- c. Configure the ICMP error quota:

```
ipv6 icmp error-quota <0-2000000>
```

The default is 50.

- d. Enable ICMP redirect messages:

```
ipv6 icmp redirect-msg
```

The default is disabled.

- e. Enable ICMP network unreachable messages:

```
ipv6 icmp unreach-msg
```

The default is disabled.

Example

Enable IPv6 forwarding:

```
Switch:1(config)#ipv6 forwarding
```

Add an IPv6 neighbor for a brouter port:

```
Switch:1(config)#ipv6 neighbor 3000:0:0:0:0:0:2 port 1/11 mac 00:0c:42:07:35:90
```

Add an IPv6 neighbor for a VLAN:

```
Switch:1(config)#ipv6 neighbor 3000::3 port 1/12 mac 01:02:03:04:05:06
vlan 20
```

Variable definitions

Use the data in the following table to use the `ipv6` commands in this procedure.

Variable	Value
forwarding	Configures whether this entity is an IPv6 router with respect to the forwarding of datagrams received by, but not addressed to, this entity. Enable forwarding to act as a router. The default is disabled.
hop-limit <0-255>	Configures the hop limit. The default is 64.
icmp error interval <0-2147483647>	Configures the interval (in milliseconds) for sending ICMPv6 error messages. The default is 1000. An entry of 0 seconds results in no sent ICMPv6 error messages
icmp error-quota <0-2000000>	Configures the number of ICMP error messages that can be sent during the ICMP error interval. A value of zero instructs the system not to send an ICMP error messages. The default value is 50.
icmp redirect-msg	Enables ICMP redirect messages. The default is disabled.

Table continues...

Variable	Value
icmp unreachable-msg	Enables ICMP network unreachable messages. The default is disabled.
neighbor <i>WORD</i> <0-128> port {slot/port[sub-port]} mac <0x00:0x00:0x00:0x00:0x00:0x00> [vlan <1-4059>]	<p>Creates a static IPv6 neighbor with the following variables:</p> <ul style="list-style-type: none"> • <i>WORD</i><0-128> specifies the IPv6 address of the neighbor in hexadecimal colon format. • {slot/port[/sub-port]} specifies the brouter port to use for the neighbor. Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port. • mac <0x00:0x00:0x00:0x00:0x00:0x00> specifies the MAC address of the neighbor. • vlan <1-4059> specifies the VLAN ID to use for the neighbor. <p>Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.</p> <p>Static IPv6 neighbors do not maintain any state machine and the system assumes that they are always reachable.</p>

Configuring an IPv6 interface

The information in this section can help you configure an IPv6 interface to make IPv6 active on the interface and fine-tune IPv6 neighbor discovery to control the frequency of protocol traffic.

By default, IPv6 forwarding is enabled on an interface.

Compared to IPv4/ARP, the IPv6 neighbor discovery mechanism maintains more protocol state, timers, and protocol traffic overhead.

There are two important tunable parameters for IPv6 ND that can control the frequency of protocol traffic:

- ipv6 interface reachable-time
- ipv6 interface retransmit-timer

Before you begin

- Before you can assign an IPv6 address to the interface, you must configure an IPv6 interface for a VLAN or brouter port.

You must configure a VLAN before you can give the VLAN an interface identifier or an IPv6 address.

The switch supports port-based, protocol-based, and MAC-source-based VLANs.

For information about how to configure VLANs, see the following documents:

- *Configuring VLANs, Spanning Tree, and NLB on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-500
- *Configuring VLANs and Spanning Tree on Avaya Virtual Services Platform 4000 Series*, NN46251-500
- *Configuring Link Aggregation, MLT, SMLT, and vIST on VSP Operating System Software*, NN47227-503
- *Configuring Link Aggregation, MLT and SMLT on VSP Operating System Software*, NN47227-503

Procedure

1. Enter Interface Configuration mode:

```
enable

configure terminal

interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-
port]][, ...]} OR interface vlan <1-4059>
```

Note:

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Create IPv6 interface:

```
ipv6 interface
```

3. Configure optional parameters to meet your requirements:

- a. Enable IPv6 router advertisement on the interface:

```
ipv6 nd send-ra
```

- b. Configure the maximum number of hops before packets drop:

```
ipv6 interface hop-limit <1-255>
```

- c. Configure the link-local address:

```
ipv6 interface link-local WORD<0-19>
```

- d. Configure the mac offset:

```
ipv6 interface mac-offset <0-511><0-511>
```

- e. Configure the maximum transmission unit (MTU):

```
ipv6 interface mtu <1280-9500>
```

- f. Configure an interface description:

```
ipv6 interface name WORD<0-255>
```

- g. Configure the time a neighbor is considered reachable after receiving a reachability confirmation:

```
ipv6 interface reachable-time <1-3600000>
```

- h. Configure the time between retransmissions of neighbor solicitation messages to a neighbor when resolving the address or when probing the reachability of a neighbor:

```
ipv6 interface retransmit-timer <1-4294967295>
```

- i. Configure a brouter port as part of an IPv6 VLAN:

```
ipv6 interface vlan <1-4059>
```

- j. Configure the interface to perform IPv6 unicast reverse path forwarding:

- To enable urpf-mode boot flag, enter:

```
boot config flags urpf-mode
```

- To configure unicast reverse path forwarding, enter:

```
ipv6 rvs-path-chk mode {strict|exist-only}
```

Example

Create and administratively enable the interface:

```
Switch:1(config-if)#ipv6 interface enable
```

* Note:

In contrast to IPv6 interface creation and address assignment in EDM, you use the **ipv6 interface** ACLI command to create an interface and specify a single global address in one step.

Variable definitions

Use the data in the following table to use the **ipv6 interface** command.

Variable	Value
hop-limit <1-255>	Configures the maximum hops. The default is 64.
link-local WORD<0-19>	Specifies the 64-bit interface ID used to calculate the actual link-local address as a name up to 19 characters long.
mac-offset <0-511>	Use mac-offset to request a particular MAC for an IPv6 VLAN. You can specify a MAC offset when you configure IPv6 on a VLAN, or the system can assign a MAC address from within the available range.
mtu <1280-9500>	Configures the maximum transmission unit for the interface: 1280-1500, 1850, or 9500. This value

Table continues...

Variable	Value
	<p>must be the same for all addresses defined on this interface.</p> <p>The default is 1500.</p>
name <i>WORD</i> <0-255>	<p>Assigns a descriptive name. The network management system also configures this string.</p>
reachable-time <0-3600000>	<p>Controls how long IPv6 neighbor entries learned on an interface remain in the REACHABLE state (as described in RFC 4861).</p> <p>The system randomizes the value you configure, per RFC specifications, to be 50%-150% of the configured value.</p> <p>By default the reachable-time base value is 30 seconds, with an actual 15-45 second range when you consider the randomization factor.</p> <p>The default is 3000 milliseconds</p>
retransmit-timer <0-4294967295>	<p>Controls the time, in milliseconds, between retransmission of Neighbor Solicitation messages when the system attempts to resolve or reconfirm the reachability of an IPv6 neighbor.</p> <p>By default, the system sends three Neighbor Solicitation messages with a one second interval between each message. If the system does not receive a corresponding Neighbor Advertisement within an interval equal to 3 X retransmit-timer milliseconds, the system declares the IPv6 neighbor unreachable.</p> <p>+ Tip:</p> <p>You can increase the retransmit-timer to extend the interval that the switch waits until it declares the neighbor unreachable. For example: a retransmit-timer value of 5000 means the switch waits 3 X 5000 milliseconds which equals 15000 milliseconds or 15 seconds.</p> <p>The default is 1000 milliseconds</p>
vlan <1-4059>	<p>Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.</p> <p>This value corresponds to the lower 12 bits of the IEEE 802.1Q VLAN tag.</p>

Use the data in the following table to use the `ipv6 rvs-path-chk` command.

Variable	Value
mode{strict exist-only}	<p>Specifies the mode for Unicast Reverse Path Forwarding (uRPF).</p> <p>In strict mode, uRPF checks whether the source IP address of the incoming packet exists in the FIB. If the incoming interface is not the best reverse path, the packet check fails and uRPF drops the packet.</p> <p>In exist-only mode, uRPF checks whether the source IP address of the incoming packet exists in the FIB. The packet is dropped only if the source address is not reachable via any interface on that router.</p>

Use the data in the following table to use the **interface** command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Assigning IPv6 addresses to a router port or VLAN

Assign IPv6 addresses to interfaces to configure IPv6 routing for the interface.

Procedure

1. Enter Interface Configuration mode:

```
enable
```

```
configure terminal
```

```
interface GigabitEthernet {slot/port[/sub-port][-slot/port[/sub-port]][,...]} or interface vlan <1-4059>
```

 **Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Assign an IPv6 address:

```
ipv6 interface address WORD<0-255>
```

Example

Assign an IPv6 address specifying the full 128 bits of the address:

```
Switch:1(config-if)#ipv6 interface address 30:0:0:0:0:0:0:ffff/64
```

Assign an IPv6 address specifying only the upper 64 bits of the address:

```
Switch:1(config-if)#ipv6 nd prefix-interface <prefix> eui <1-3>
```

In this example you specify only the upper 64 bits of the address and allow the system to auto-generate the lower 64 bits from the MAC address.

Variable definitions

Use the data in the following table to use the **ipv6 interface address** command.

Variable	Value
WORD<0-255>	Specifies the IPv6 address for the port or VLAN.

Use the data in the following table to use the **interface** command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Configuring IPv6 route preferences

Before you begin

Important:

Changing route preferences can affect system performance and network accessibility while you perform the procedure. Change a prefix list or a routing protocol before you activate the protocols.

About this task

Configure IPv6 route preferences to give preference to routes learned for a specific protocol.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Configure the route preference:

```
ipv6 route preference protocol <static|ebgp|ibgp|ospfv3-intra|
ospfv3-inter|ospfv3-extern1|ospfv3-extern2|ripng|spbm-level1>
<0-255>
```

3. Confirm that the configuration is correct:

```
show ipv6 route preference
```

Example

Configure the route preference to RIPng and confirm the configuration is correct.

```
Switch:1>enable
Switch:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch:1(config)#ipv6 route preference protocol ripng 10
Switch:1(config)#show ipv6 route preference
```

```
=====
                        IPv6 Route Preference
=====
PROTOCOL          DEFAULT    CONFIG
-----
LOCAL              0          0
STATIC             5          5
SPBM_L1            7          7
OSPFv3_INTRA      20         20
OSPFv3_INTER      25         25
EBGP               45         45
RIPNG              100        10
OSPFv3_E1         120        120
OSPFv3_E2         125        125
IBGP               175        175
```

Variable definitions

Use the data in the following table to use the `ipv6 route preference` and the `show ipv6 route preference` commands.

Variable	Value
<0-255>	Assigns a route preference value.
ebgp	Configures the preference for protocol type EBGp.
ibgp	Configures the preference for protocol type IBGP.
ospfv3-extern1	Configures the preference for protocol type OSPFv3 external type 1.
ospfv3-extern2	Configures the preference for protocol type OSPFv3 external type 2.
ospfv3-intra	Configures the preference for protocol type OSPFv3 intra-area.

Table continues...

Variable	Value
ospfv3-inter	Configures the preference for protocol type OSPFv3 inter-area.
ripng	Configures the preference for protocol type RIPng.
spbm-level1	Configures the preference for protocol type spbm-level1.
static	Configures the preference for protocol type static.

Viewing global IPv6 information

Use the following procedure to view and manage general IPv6 information.

Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. Display IPv6 information for an interface:

```
show ipv6 interface [gigabitethernet {slot/port[/sub-port]}[-slot/
port[/sub-port]][,...]] [loopback <1-256>][mgmtEthernet {slot/
port[/sub-port]}[-slot/port[/sub-port]][,...]] [tunnel <1-2000>][vlan
<1-4059>]
```

3. Display IPv6 tunnel information:

```
show ipv6 interface tunnel
```

4. Display IPv6 address information for the specified slot and port:

```
show ipv6 address interface gigabitethernet {slot/port[/sub-port]}[-
slot/port[/sub-port]][,...]]
```

5. Display IPv6 address information for the specified IPv6 address:

```
show ipv6 address interface ip WORD<0-46>
```

6. Display IPv6 address information for the specified tunnel :

```
show ipv6 address interface tunnel <1-2000>
```

7. Display IPv6 address information for the specified VLAN:

```
show ipv6 address interface vlan <1-4059>
```

8. Display the current state of IPv6 forwarding:

```
show ipv6 forwarding
```

9. Display information on the current state of IPv6 functionality:

```
show ipv6 global
```

10. Display IPv6 Gigabit Ethernet (GbE) router advertisement information:

```
show ipv6 nd interface gigabitethernet [{slot/port[/sub-port]}[-slot/
port[/sub-port]][,...]]
```

11. Display IPv6 VLAN router advertisement information:

```
show ipv6 nd interface vlan [<1-4059>]
```

12. Display detailed information in IPv6 router advertisements:

```
show ipv6 nd-prefix detail
```

13. Display GbE interface information in IPv6 router advertisements:

```
show ipv6 nd-prefix interface gigabitethernet [ {slot/port[/sub-
port]}[-slot/port[/sub-port]][,...]]
```

14. Display VLAN interface information in IPv6 router advertisements:

```
show ipv6 nd-prefix interface vlan [<1-4059>]
```

15. Display VLAN information in IPv6 router advertisements:

```
show ipv6 nd-prefix vlan <1-4059>
```

16. Display IPv6 neighbor entries with specific router port numbers:

```
show ipv6 neighbor interface gigabitethernet {slot/port[sub-port]}
```

17. Display IPv6 neighbor information for neighbors of the specified type:

```
show ipv6 neighbor type <1-4>
```

18. Display IPv6 neighbor information:

```
show ipv6 neighbor [WORD<0-46>]
```

Example

```
Switch:1(config)#show ipv6 interface vlan
```

```
=====
Vlan Ipv6 Interface
=====
IFINDX  VLAN  PHYSICAL          ADMIN  OPER  TYPE  MTU  HOP  REACHABLE  RETRANSMIT  MCAST  IPSEC  RPC  RPCMODE
INDX    ADDRESS  STATE    STATE  TYPE  LMT  TIME  TIME  STATUS
-----
2070   22    e4:5d:52:3c:65:02  disable down  ETHER 1500 64  30000    1000    disable  disable  disable  existonly
=====
Vlan Ipv6 Address
=====
IPV6 ADDRESS          VLAN-ID  TYPE  ORIGIN  STATUS
-----
fe80:0:0:0:e65d:52ff:fe3c:6502  V-22    UNICAST LINKLAYER  INACCESSIBLE

1 out of 2 Total Num of Interface Entries displayed.
1 out of 2 Total Num of Address Entries displayed.
```

```
Switch:1#show ipv6 interface tunnel
```

```
=====
Tunnel Ipv6 Interface
=====
IF  Descr    VLAN  PHYSICAL          ADMIN  OPER  TYPE  MTU  HOP  REACHABLE  RETRANSMIT  MCAST
INDX                                     STATE  STATE  TYPE  LMT  TIME  TIME  STATUS
-----
6656 T-1      0    n/a                enable  up    P2P   1280 64  30000    1000    disable
6657 T-2      0    n/a                enable  up    P2P   1280 64  30000    1000    disable
```

IPv6 basics

```

=====
Tunnel Ipv6 Address
=====
IPV6 ADDRESS                TUNNEL-ID  TYPE    ORIGIN  STATUS
-----
2011:beef:3:0:0:0:0:67      T-1        UNICAST MANUAL  PREFERRED
fe80:0:0:0:0:0:4301:101    T-1        UNICAST LINKLAYER PREFERRED
2011:beef:4:0:0:0:0:67      T-2        UNICAST MANUAL  PREFERRED
fe80:0:0:0:0:0:4301:101    T-2        UNICAST LINKLAYER PREFERRED

```

2 out of 10 Total Num of Interface Entries displayed.
 4 out of 20 Total Num of Address Entries displayed.

Switch:1#show ipv6 address interface tunnel 2

```

=====
Address Information
=====
IPV6 ADDRESS/PREFIX LENGTH          VID/BID/TID  TYPE    ORIGIN  STATUS
-----
44:211:0:0:0:0:0:2/64                T-2          UNICAST MANUAL  PREFERRED
fe80:0:0:0:0:0:d301:3702/64          T-2          UNICAST LINKLAYER PREFERRED

```

2 out of 407 Total Num of Address Entries displayed.

Switch:1#show ipv6 address interface vlan 100

```

=====
Address Information
=====
IPV6 ADDRESS/PREFIX LENGTH          VID/BID/TID  TYPE    ORIGIN  STATUS
-----
10:1:50:0:0:0:0:7/64                 V-100        UNICAST MANUAL  PREFERRED
fe80:0:0:0:b2ad:aaff:fe46:f19a/64    V-100        UNICAST LINKLAYER PREFERRED

```

2 out of 407 Total Num of Address Entries displayed.

```

Switch:1#show ipv6 forwarding
Global forwarding      : enable
ecmp                   : disable
ecmp-max-path          : 1

```

```

Switch:1#show ipv6 global
forwarding             : enable
default-hop-cnt       : 64
number-of-interfaces  : 11
icmp-error-interval    : 1000
icmp-error-quota      : 50
icmp-unreach-msg      : disable
icmp-redirect-msg     : disable
static-route-admin-status : enable
ecmp                  : enable
ecmp-max-path         : 4
source-route          : disable

```

Switch:1#show ipv6 nd interface vlan

```

=====
Vlan Ipv6 Nd
=====
IFID VLAN  RTR-ADV MAX-INT MIN-INT LIFETIME MANAG OTHER DAD-NS MTU  HOP  REACHABLE RETRANSMIT
FLAG CONF  TIME    TIME    TIME    FLAG CONF  TIME  LIMIT  TIME      TIME
-----
2148 V-100  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2158 V-110  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2248 V-200  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2258 V-210  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2548 V-500  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2648 V-600  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)
2948 V-900  True   600    200    1800    False False 1  0(d)  64(d) 0(d)  0(d)

```

Note: (s) = Set, (d) = Default, (i) = inherit.

7 out of 11 Total Num of Ipv6 ND Entries displayed.

Switch:1#show ipv6 nd-prefix interface gigabitethernet

```

=====
Port Ipv6 Nd Prefix
=====

```

```

INTF  IPV6
INDEX ADDRESS/PREFIX
-----
344   2011:beef:4004:0:0:0:0/64   5/25  2592000  604800 1

```

1 out of 9 Total Num of Ipv6 ND prefix Entries displayed.

```
Switch:1#show ipv6 nd-prefix interface vlan
```

```

=====
Vlan Ipv6 Nd Prefix
=====
INTF  IPV6
INDEX ADDRESS/PREFIX
-----
2148  2011:beef:100:0:0:0:0/64      100  2592000  604800 1
2158  2011:beef:110:0:0:0:0/64      110  2592000  604800 1
2248  2011:beef:200:0:0:0:0/64      200  2592000  604800 1
2258  2011:beef:210:0:0:0:0/48      210  2592000  604800 1
2548  2011:beef:500:0:0:0:0/64      500  2592000  604800 1
2648  2011:beef:600:0:0:0:0/64      600  2592000  604800 1
2948  2011:beef:900:0:0:0:0/64      900  2592000  604800 1

```

7 out of 9 Total Num of Ipv6 ND prefix Entries displayed.

```
Switch:1#show ipv6 nd-prefix vlan 100
```

```

=====
Nd-Prefix Address Information
=====
INTF  IPV6
INDEX ADDRESS/PREFIX
-----
2148  2011:beef:100:0:0:0:0/64      100  2592000  604800 1

```

Legend: EUI: eui-not-used(1), eui-used-with-ul-complement(2) eui-used-without-ul-complement(3)

```
Switch:1#show ipv6 neighbor type 2
```

```

=====
Neighbor Information
=====
NET ADDRESS/
PHYSICAL ADDRESS
-----
2013:47:17:120:0:0:0:1/  1/1  1/1  DYNAMIC REACHABLE  5640  00:1d:af:64:a2:01
2013:47:17:120:0:0:0:2/  1/1  1/1  DYNAMIC STALE      5170  00:18:b0:5a:92:01
2013:47:17:120:1:0:0:7/  1/1  1/1  DYNAMIC STALE      5321  80:17:7d:76:63:fd
2013:47:17:120:1:0:0:23/ 1/1  1/1  DYNAMIC STALE      5126  00:24:7f:a1:63:fd
2013:47:17:120:1:0:0:231/ 1/1  1/1  DYNAMIC STALE      5398  80:17:7d:76:63:ff
2013:47:17:120:1:0:0:233/ 1/1  1/1  DYNAMIC STALE      5195  80:17:7d:75:93:ff
2013:47:17:120:1:0:0:239/ 1/1  1/1  DYNAMIC STALE      5207  80:17:7d:75:93:fd
2013:47:17:120:1:0:0:243/ 1/1  1/1  DYNAMIC STALE      5190  00:24:7f:a1:63:ff

```

--More-- (q = quit)

```
Switch:1(config)#show ipv6 neighbor
```

```

=====
Neighbor Information
=====
NET ADDRESS/
PHYSICAL ADDRESS
-----
2013:47:17:120:0:0:0:1/  1/1  1/1  DYNAMIC STALE      5681
00:1d:af:64:a2:01
2013:47:17:120:0:0:0:2/  1/1  1/1  DYNAMIC STALE      5170
00:18:b0:5a:92:01
2013:47:17:120:1:0:0:7/  1/1  1/1  DYNAMIC STALE      5321
80:17:7d:76:63:fd
2013:47:17:120:1:0:0:23/ 1/1  1/1  DYNAMIC STALE      5126
00:24:7f:a1:63:fd
2013:47:17:120:1:0:0:231/ 1/1  1/1  DYNAMIC STALE      5398
80:17:7d:76:63:ff
2013:47:17:120:1:0:0:233/ 1/1  1/1  DYNAMIC STALE      5195
80:17:7d:75:93:ff
2013:47:17:120:1:0:0:239/ 1/1  1/1  DYNAMIC STALE      5207
80:17:7d:75:93:fd
2013:47:17:120:1:0:0:243/ 1/1  1/1  DYNAMIC STALE      5190
00:24:7f:a1:63:ff

```

--More-- (q = quit)

Variable definitions

Use the data in the following table to use the **show ipv6** commands.

Variable	Value
address interface ip <i>WORD</i> <0-46>	Specifies the IPv6 address.
neighbor [<i>WORD</i> <0-46>]	Specifies the IPv6 address of the neighbor.
loopback <1-256>	Specifies the loopback interface ID value. If you do not specify a value, the output includes all IPv6 loopback interfaces.
{slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
type <1-4>	Specifies the neighbor type as one of the following: <ul style="list-style-type: none"> • 1 - other • 2 - dynamic • 3 - static • 4 - local
tunnel <1-2000>	Specifies the tunnel ID.
vlan <1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.

Creating IPv6 static routes

Use static routes to manually configure routes to destination IPv6 address prefixes.

Before you begin

- Enable IPv6 forwarding.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```
2. Enable IPv6 static routes globally:

```
ipv6 route static enable
```

If you disable static routes globally, the system removes all enabled static routes from the RTM and does not add new static routes to the RTM.

3. Configure a static route:

```
ipv6 route WORD<0-46> [enable] [cost <1-65535>] [next-hop WORD<0-46>] [preference <1-255>] [tunnel <1-2000>] [port {slot/port[sub-port]}] [vlan <1-4059>]
```

4. (Optional) Disable all IPv6 static routes:

```
no ipv6 route static enable
```

5. (Optional) Permanently delete the IPv6 static route configuration:

```
clear ipv6 route static
```

Example

Enable IPv6 static routes globally:

```
Switch:1(config)#ipv6 route static enable
```

Create and enable a static route through a global nexthop:

```
Switch:1(config)#ipv6 route 4000::/64 cost 1 next-hop 3000::2 enable
```

Create and enable a static route through an outgoing interface (VLAN or brouter port):

```
Switch:1(config)# ipv6 route 4000::/64 cost 1 vlan 1900 enable
```

Create and enable a static route through a link local nexthop and an outgoing interface:

```
Switch:1(config)# ipv6 route 4000::/64 cost 1 next-hop fe80::1 vlan 1900 enable
```

In the preceding example, you must specify the outgoing interface so that the system can apply the correct context to the link-local address.

Variable definitions

Use the data in the following table to use the `ipv6 route` command.

Variable	Value
<i>WORD</i> <0-46>	Specifies the IPv6 destination address and prefix.
enable	Enables the static route. The default is enabled.
cost <1-65535>	Specifies the cost or distance ratio to reach the destination for this static route. The default is 1.
next-hop <i>Word</i> <0-46>	Specifies the IPv6 address of the next hop on this route. You do not need to specify the next hop if the devices directly connect to one another. Configure the next hop if the two nodes do not share the same network prefix but reside on the same link.

Table continues...

Variable	Value
preference <1–255>	Specifies the routing preference of the destination IPv6 address. The default is 5.
{slot/port[/sub-port]}	Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
tunnel <1–2000>	Specifies the tunnel ID.
vlan <1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.

Viewing routes information

View routes information to view the current configuration.

Procedure

1. Enter Privileged EXEC mode:
`enable`
2. Show the number of OSPF, RIP, static, and local routes:
`show ipv6 route count-summary`
3. Show route information for a destination:
`show ipv6 route dest WORD<0-46>`
4. Show route information for a port:
`show ipv6 route gigabitethernet {slot/port[sub-port]}`
5. Show route information for a next-hop address:
`show ipv6 route next-hop WORD<0-46>`
6. Show route information for an SPBM IPv6 route:
`show ipv6 route spbm-nh-as-mac`
7. Show route information for a static route:
`show ipv6 route static`
8. Show route information for a tunnel:
`show ipv6 route tunnel <1-2000>`
9. Show route information for a VLAN:
`show ipv6 route vlan <1-4059>`

Example

```
Switch:1#show ipv6 route count-summary
```

```
=====
                          IPv6 Route Summary
=====
```

TOTAL	OSPF	RIP	BGP	STATIC	LOCAL	ISIS
13	10	0	3	1	2	7

```
=====
```

```
Switch:1#show ipv6 route static
```

```
=====
                          Static Route Information
=====
```

DEST-IP NEXT-HOP	NET IFINDX (VID/BRT/TUN)	ENABLE	STATUS
0:aa:1:0:0:0:0:0 NotReachable0:2910:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:1:0:0:0:0 NotReachable0:2911:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:2:0:0:0:0 NotReachable0:2912:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:3:0:0:0:0 NotReachable0:2913:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:4:0:0:0:0 NotReachable0:2914:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:5:0:0:0:0 NotReachable0:2915:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:6:0:0:0:0 NotReachable0:2916:0:0:0:0:0:10	64 0 (0)	enable	5
0:aa:1:7:0:0:0:0 NotReachable0:2917:0:0:0:0:0:10	64 0 (0)	enable	5

```
=====
```

```
8 out of 42 Total Num of Static Routes displayed.
```

```
Global IPv6 Static Routes Admin Status: enable
```

```
Switch:1#show ipv6 route spbm-nh-as-mac
```

```
=====
                          IPv6 Routing Table Information
=====
```

Destination Address/PrefixLen	NEXT HOP	VID/BID/TID	PROTO	COST
2001:cdab:0:0:0:0:0:0/32	0:0:0:0:0:0:0:0	V-611	LOCAL	1
2001:cdab:0:0:0:0:0:1/128	0:0:0:0:0:0:0:0	V-611	LOCAL	1
2002:cdab:0:0:0:0:0:0/32	80:2d:30:00:00:01	V-10	ISIS	1

```
=====
```

Variable definitions

Use the data in the following table to use the **show ipv6 route** command.

Variable	Value
count-summary	Shows the total number of OSPF, static, and local routes.

Table continues...

Variable	Value
dest <i>WORD</i> <0–46>	Specifies the IPv6 destination network address. The prefix value must match the prefix length.
next-hop <i>WORD</i> <0–46>	Specifies the IPv6 address of the next hop on this route.
spbm-nh-as-mac	Shows the B-MAC address as the next hop rather than the host name.
{slot/port[/sub-port]}	Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
<i>static</i>	Shows static IPv6 routes.
tunnel <1–2000>	Shows route entries for a specific tunnel ID.
vlan<1-4059>	Shows route entries for a specific VLAN ID.

Creating an IPv6 CLIP interface

About this task

Create an IPv6 CLIP interface

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```
2. Specify an interface ID value:

```
interface loopback <1-256>
```
3. Create an IPv6 loopback interface address:

```
ipv6 interface address WORD <0-255>
```
4. Ensure the configuration is correct:

```
show ipv6 interface loopback
```

Example

```
Switch:1#show ipv6 interface loopback
```

```
=====
                        Loopback IPv6 Interface
=====
IF   Descr          VLAN PHYSICAL          ADMIN  OPER  TYPE  MTU  HOP  REACHABLE  RETRANSMIT
INDX                                STATE  STATE                                LMT  TIME      TIME
-----
1344 CLIPv6-1      --   00:00:00:00:00:01 enable  up    ETHER 1500  64   30000      1000
=====
                        Loopback IPv6 Address
=====
```

```

IPV6 ADDRESS/PREFIX LENGTH          LOOPBACK-ID  TYPE      ORIGIN      STATUS
-----
1:210:0:0:0:0:210/128              C-1          UNICAST   MANUAL      PREFERRED

Legend: NA - Information not available

1 out of 204 Total Num of Interface Entries displayed.
1 out of 407 Total Num of Address Entries displayed.

```

Variable definitions

Use the data in the following table to use the `ipv6` commands.

Variable	Value
WORD<1–256>	Specifies the CLIP interface ID.
WORD<0–255>	Specifies the IPv6 address.

Enabling IPv6 ECMP globally

About this task

Use the following procedure to enable IPv6 ECMP globally. IPv6 ECMP is disabled by default.

Procedure

1. Enter Global Configuration mode:


```
enable
configure terminal
```
2. Enter the following command to enable IPv6 ECMP:



```
ipv6 ecmp enable
```
3. Set the default value, IPv6 ECMP is disabled by default.


```
default ipv6 ecmp enable
```
4. Disable IPv6 ECMP globally:


```
no ipv6 ecmp enable
```

Variable definitions

Use the data in the following table to use the `ipv6 ecmp` command.

Variable	Value
<code>enable</code>	Enables IPv6 ECMP globally.  Note: <ul style="list-style-type: none"> Enabling IPv6 ECMP sets the maximum number of paths configured to its default value, that is 8 for VSP 7000 and 8000 Series and 4 for VSP 4000 Series

Variable	Value
	<ul style="list-style-type: none"> Disabling IPv6 ECMP sets the maximum number of paths configured to 1

Configuring maximum number of ECMP paths

Before you begin

Enable ECMP on the switch before configuring the max-path value. For more information, see [Enabling IPv6 ECMP globally](#) on page 59.

About this task

Use the following procedure to configure the maximum number of ECMP paths.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enter the following command to configure maximum number of ECMP paths:

- For VSP 4000 Series:

```
ipv6 ecmp max-path <1-4>
```

- For VSP 7000 and 8000 Series:

```
ipv6 ecmp max-path <1-8>
```

3. Set the configured maximum number of ECMP paths to its default value:

```
default ipv6 ecmp max-path
```

Note:

The default value for max-path is the maximum value, depending on the platform.

Example

```
Switch:1>enable
Switch:1#configure terminal
```

Enable ECMP on the switch:

```
Switch:1(config)#ipv6 ecmp enable
```

Configure the maximum number of ECMP paths to 4:

```
Switch:1(config)#ipv6 ecmp max-path 4
```

Variable definitions

Use the data in the following table to use the `ipv6 ecmp max-path` command.

Variable	Value
<i>max-path</i>	Sets the maximum number of ECMP paths.
<1-4>	Maximum ECMP paths that can be configured on VSP 4000 Series.
<1-8>	Maximum ECMP paths that can be configured on VSP 7200 Series and VSP 8000 Series.

Enabling or disabling IPv6 ICMP multicast globally

On disabling the ICMP multicast processing, all the packets containing ICMP sent to multicast addresses are dropped when they reach the control plane.

About this task

Use this procedure to enable or disable the IPv6 ICMP multicast on the global router.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enable IPv6 ICMP multicast, enter:

```
ipv6 icmp echo-multicast-request
```

3. Disable IPv6 ICMP multicast, enter:

```
no ipv6 icmp echo-multicast-request
```

4. Set IPv6 ICMP multicast to default state, enter:

```
default ipv6 icmp echo-multicast-request
```

Note:

By default, the IPv6 ICMP multicast feature is enabled.

5. View the IPv6 ICMP multicast state:

```
show ipv6 global
```

IPv6 basic configuration using EDM

Enabling the IPv6–mode boot config flag

To enable IPv6 mode, you need to enable the IPv6-mode boot config flag. This flag is disabled by default. Use this procedure to enable (set to true) the IPv6-mode boot config flag.

Enable this flag to support IPv6 routes with prefix-lengths greater than 65 bits.

When the IPv6-mode boot config flag is enabled, the maximum number of IPv4 routing table entries decreases. For scaling information, see *Release Notes for VSP Operating System Software*, NN47227-401.

About this task

This procedure does not apply to VSP 4000 Series.

Procedure

1. In the navigation pane, expand the following folders: **Configuration > Edit**,
2. Click **Chassis**.
3. Click the **Boot Config** tab.
4. Select the **EnableIpv6Mode** check box.
5. Click **Apply**.
6. Save the configuration, and then reboot the switch for the change to the IPv6-mode boot config flag to take effect.

Configuring IPv6 globally

Global configuration includes the following:

- IPv6 forwarding: Enable the device to forward IPv6 traffic. By default, IPv6 forwarding is disabled, which means you can only use local IPv6 connections, and traffic does not traverse an IPv6 network.
- IPv6 alternative routes: To avoid traffic interruption, enable alternative routes globally on the switch, to replace the best route with the next-best route if the best route becomes unavailable. By default, this feature is enabled.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Globals** tab.
4. To enable IPv6 forwarding, select **forwarding**.

5. To enable IPv6 multicast, click **IcmpMulticastRequestEnable**.
6. To enable IPv6 Source Routing, click **SourceRouteEnable**.
7. To enable IPv6 alternative routes, click **AlternativeRouteEnable**.
8. To configure IPv6 ECMP globally, select **enable** or **disable**, in the **EcmpEnable** option box.
9. In the **EcmpMaxPath** box, enter the preferred number of equal-cost paths.
10. Click **Apply**.

Globals field descriptions

Use the data in the following table to use the **Globals** tab.

Name	Description
Forwarding	Configures whether this switch is an IPv6 router with respect to the forwarding of datagrams received by, but not addressed to, the switch. Select forwarding for the switch to act as a router for IPv6 traffic. Select notForwarding to not act as a router for IPv6 traffic. The default is notForwarding . You must enable forwarding to use Telnet or Ping with IPv6.
DefaultHopLimit	Configures the hop limit. The default is 64. The range is 0 to 255.
Interfaces	Shows the number of interfaces.
IfTableLastChange	Shows the date of the last interface table change.
IcmpNetUnreach	Enables ICMP network unreachable messages. The default is disabled.
IcmpErrorInterval	Configures the interval (in milliseconds) for sending ICMPv6 error messages. The default is 1000. An entry of 0 seconds results in no sent ICMPv6 error messages. The range is 0 to 2147483647 milliseconds.
IcmpErrorQuota	Configures the number of ICMP error messages that the system can send during the ICMP error interval. A value of zero specifies not to send any. The default value is 50.
IcmpMulticastRequestEnable	Globally enables or disables the IPv6 ICMP echo multicast request feature. This is enabled by default.
StaticRouteGlobalAdminEnabled	Enables IPv6 static routes globally. If you disable static routes globally, the system removes all enabled static routes from the RTM and does not add new static routes to the RTM. The default is enabled.

Table continues...

Name	Description
RouteStaticClear	Clears all IPv6 static routes.
SourceRouteEnable	Globally enables or disables the IPv6 Source Routing feature. It is disabled by default.
PrefixListTableSize	Displays the prefix list table size.
RoutePrefTableSize	Displays the route preference table size.
AlternativeRouteEnable	Globally enables or disables the IPv6 alternative route feature. By default, this feature is enabled.
EcmpEnable	Enables or disables the IPv6 ECMP globally. By default, it is disabled.
EcmpMaxPath	<p>Globally configures the maximum number of ECMP paths.</p> <p>The number of paths supported is:</p> <ul style="list-style-type: none"> • 1 to 4 for VSP 4000 • 1 to 8 for VSP 7200 Series and VSP 8000 Series <p>When ECMP is disabled, the value is automatically set to 1.</p> <p>When ECMP is enabled, the default value is 8 for VSP 7200 Series and VSP 8000 Series. The default value is 4 for the VSP 4000.</p> <p>You cannot configure this feature unless ECMP is enabled globally.</p>

Configuring an IPv6 interface

You must configure an IPv6 interface for a VLAN or brouter port before you can assign an IPv6 address to the interface.

Before you begin

- You must configure a VLAN before you can give the VLAN an interface identifier or an IPv6 address. The switch supports port-based, protocol-based, and MAC-source-based VLANs.

For information about how to configure VLANs, see the following documents:

- *Configuring VLANs, Spanning Tree, and NLB on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-500
- *Configuring VLANs and Spanning Tree on Avaya Virtual Services Platform 4000 Series*, NN46251-500
- *Configuring Link Aggregation, MLT, SMLT, and vIST on VSP Operating System Software*, NN47227-503
- *Configuring Link Aggregation, MLT and SMLT on VSP Operating System Software*, NN47227-503

About this task

You can also configure an IPv6 interface for a brouter port through the **Edit > Port > IPv6** navigation path, and for a VLAN through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 navigation path where you can create both types of interfaces.

Procedure

1. In the navigation pane, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Interfaces** tab.
4. Click **Insert**.
5. In the **Interface** field, click **Port** or **VLAN**.
6. Select a port or VLAN.
7. Click **OK**.
8. Select the **AdminStatus** field to activate the interface.
9. Configure the remaining parameters as required.
10. Click **Insert**.
11. Click **Apply**.

Interfaces field descriptions

Use the data in the following table to use the **Interfaces** tab.

Name	Description
Interface	Specifies the port or VLAN.
Identifier	Shows the IPv6 address interface identifiers. This value is a binary string of up to 8 octets in network byte-order.
IdentifierLength	Shows the length of the identifier, in bits.
Descr	Specifies a description of the interface. The network management system also configures this string.
VlanId	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1. This value corresponds to the lower 12 bits of the IEEE 802.1Q VLAN tag.
Type	Shows the interface type.
ReasmMaxSize(MTU)	Specifies the maximum size of the MTU of this IPv6 interface. This value must be the same for all the IP

Table continues...

Name	Description
	addresses defined on this interface. The default value is 1500.
PhysAddress	Specifies the media-dependent physical address. For Ethernet, this is a MAC address.
AdminStatus	Specifies if IPv6 is active on this interface. The default is false (disabled).
OperStatus	Specifies the current operational status of the interface.
ReachableTime	Specifies the time, in milliseconds, that a neighbor is considered reachable after receiving a reachability confirmation. The default is 30000.
RetransmitTimer	Specifies the time, in milliseconds, between retransmissions of neighbor solicitation messages to a neighbor when resolving the address, or when probing the reachability of a neighbor. The default is 1000.
CurHopLimit	Specifies the current hop limit field sent in router advertisements from this interface. The value must be the current diameter of the Internet. A value of zero indicates that the advertisement does not specify a value for CurHopLimit. The default is 64.
MulticastAdminStatus	The option to select MulticastAdminStatus is disabled. You cannot configure the administrative status for multicast in this context.
MacOffset	Requests a particular MAC for an IPv6 VLAN. The system has 1536 MAC addresses. The last four addresses are reserved. You can specify a MAC offset when you configure IPv6 on a VLAN, or the system can assign a MAC address from within the available range.
ForwardingEnabled	Indicates whether IPv6 forwarding is enabled. The default is disabled.
RSMLTEnable	Shows whether RSMLT is enabled on the interface. The default value is disabled (false).

Assigning IPv6 addresses to interfaces

Assign IPv6 addresses to interfaces to configure IPv6 routing for the interface.

You can assign an IPv6 address to a VLAN or brouter port.

About this task

To create MLT and LAG interfaces with IPv6, you must configure VLAN-based connections and you cannot use brouter ports.

You can also assign an IPv6 address through the **Edit > Port > IPv6** navigation path, and through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 navigation path where you can assign IPv6 addresses to both types of interfaces.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Addresses** tab.
4. Click **Insert**.
5. In the **Interface** field, click **Port** or **VLAN**.
6. Select one of the following:
 - port
 - VLAN
7. Click **OK**.
8. Type the IPv6 address and prefix length.
9. Click **Insert**.
10. Click **Apply**.

Addresses field descriptions

Use the data in the following table to use the **Addresses** tab.


Name	Description
Interface	Specifies the interface to which this entry applies.
Addr	Specifies the IPv6 address to which this entry applies.  Important: If the IPv6 address exceeds 116 octets, the object identifiers (OIDs) of instances of columns in this row are more than 128 subidentifiers and you cannot use SNMP-v1, SNMPv2c, or SNMPv3 to access them.
AddrLen	Specifies the prefix length value for this address. You cannot change the address length after you create it. You must provide this value to create an entry in this table.
Type	Specifies the type of address. The default is unicast.

Table continues...

Name	Description
Origin	Specifies the origin of the address. The following list shows the possible origins: <ul style="list-style-type: none"> • other • manual • dhcp • linklayer • random
Status	Specifies the status of the address, describing whether the address is used for communication. The following list shows the possible statuses: <ul style="list-style-type: none"> • preferred (default) • deprecated • invalid • inaccessible • unknown • tentative • duplicate
Created	Specifies the sysUpTime of the creation of this entry. If the entry was created prior to the last reinitialization of the local management subsystem, the object contains a zero value.
LastChanged	Specifies the value of sysUpTime of the last modification to this entry. If the entry was created prior to the last reinitialization of the local management subsystem, the object contains a zero value.

Creating IPv6 static routes

Use static routes to manually configure routes to destination IPv6 address prefixes.

Before you begin

- Enable IPv6 forwarding.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Globals** tab.

4. Select the **StaticRouteGlobalAdminEnabled** check box.
If you disable static routes globally, the system removes all enabled static routes from the RTM and does not add new static routes to the RTM. The default is enabled.
5. Click **Apply**.
6. Click the **Static Routes** tab.
7. Click **Insert**.
8. In the **Dest** field, type the IPv6 address.
9. In the **PrefixLength** field, type the length of the prefix for the IPv6 address.
10. In the **NextHop** field, type the IPv6 address of the router through which the specified route is accessible.
11. Beside the **Interface** field, click **Port** or **Vlan**.
12. Select the interface, and then click **OK**.
13. In the **Cost** field, type a number for the distance.
14. Select the **Enable** check box.
15. Click **Insert**.

Static Routes field descriptions

Use the data in the following table to use the **Static Routes** tab.

Name	Description
Dest	Specifies the IPv6 destination network address. The prefix value must match the PrefixLength.
PrefixLength	Specifies the number bits you want to advertise from the prefix. The prefix value must match the value in the Dest field. The range is 0 to 128.
NextHop	Specifies the IPv6 address of the next hop on this route. You do not need to specify the next hop if the devices directly connect to one another. Configure the next hop if the two nodes do not share the same network prefix but reside on the same link.
Interface	Specifies the interface to which this entry applies. You must specify the port or VLAN if the next hop is a link-local address.
Cost	Specifies the cost or distance ratio to reach the destination for this node. The range is 1-65535. The default value is 1.
Enable	Enables the static route on the port. The default value is enable.

Table continues...

Name	Description
Status	<p>Shows the status of the static route as one of the following:</p> <ul style="list-style-type: none"> • notReachable: The route is not reachable and no neighbor request entry is built to resolved the next-hop. This status appears if no route or neighbor exists to reach the next-hop of the static route. • tryToResolve: The route is not reachable but a neighbor request entry is built to resolve the next-hop. This status appears if a local equivalent route exists in the system to reach the next-hop but the neighbor is not learned. • reachableNotInRtm: The static route is reachable but it is not in RTM. This status appears if the static route is reachable, but it is not the best among alternative static routes. • reachableInRtm: The static route is reachable and it is in RTM. This status appears if the static route is reachable, and it is the best among alternative static routes to be added into RTM.
Preference	<p>Specifies the routing preference of the destination IPv6 address. The range is 1-255. The default value is 5.</p>

Configuring IPv6 route preferences

Change IPv6 route preferences to force the routing protocols to prefer one route over another. Configure route preferences to override default route preferences and give preference to routes learned for a specific protocol.

About this task

Important:

Changing route preferences is a process-oriented operation that can affect system performance and network reachability while you perform the procedures. If you want to change default preferences for routing protocols, do so before you enable the protocols.

Procedure

1. In the navigation pane, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **RoutePref** tab.
4. In the **ConfiguredValue** column, double-click a parameter to change the preference for the given protocol.

5. Click **Apply**.

RoutePref field descriptions

Use the data in the following table to use the **RoutePref** tab.

Name	Description
DefaultValue	Specifies the default preference value for the specified protocol.
Protocol	Specifies the protocol name.
ConfiguredValue	Configures the preference value for the specified protocol.

Viewing route information

View routes information to view the current configuration.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Routes** tab.

Routes field descriptions

Use the data in the following table to use the **Routes** tab.

Name	Description
Dest	Specifies the IPv6 destination network address. The prefix value must match the PrefixLength.
PfxLength	Specifies the number bits you want to advertise from the prefix. The prefix value must match the value in the Dest field. The range is 0 to 128.
Interface	Specifies the interface to which this entry applies.
NextHop	Specifies the IPv6 address of the next hop on this route.
Protocol	Specifies the routing protocol, such as OSPF.
Metric	Specifies the metric assigned to this interface. The default value of the metric is the reference bandwidth or ifSpeed. The value of the reference bandwidth is configured by the rcOspf3ReferenceBandwidth object. For more information about reference bandwidth, see Globals field descriptions on page 145.
NextHopId	Identifier of the next-hop, hostname, or mac address.

Chapter 4: Neighbor discovery

This chapter provides concepts and procedures to complete IPv6 neighbor discovery configuration.

Neighbor discovery

IPv6 nodes (routers and hosts) on the same link use neighbor discovery (ND) to discover link-layer addresses and to obtain and advertise various network parameters and reachability information. ND combines the services for IPv4 with the Address Resolution Protocol (ARP) and router discovery. In IPv6 ND performs a function similar to ARP (Address Resolution Protocol) in IPv4.

Hosts use ND to discover the routers in the network that you can use as the default routers, and to determine the link-layer address of neighbors attached to local links. Routers also use ND to discover neighbors and link-layer information. ND updates the neighbor database with valid entries, invalid entries, and entries migrated to various locations.

The ND protocol provides the following services:

- address and prefix discovery

Hosts determine the set of addresses that are on-link for the given link. Nodes determine which addresses or prefixes are locally reachable or remote with address and prefix discovery.

- router discovery

Hosts discover neighboring routers with router discovery. Hosts establish neighbors as default packet-forwarding routers.

- parameter discovery

Hosts and routers discover link parameters such as the link MTU or the hop-limit value placed in outgoing packets.

- address autoconfiguration

Hosts configure an address for an interface with address autoconfiguration.

- duplicate address detection

Hosts and nodes determine if an address is assigned to another router or a host.

- address resolution

Hosts determine link-layer addresses (MAC for Ethernet) of the local neighbors (attached on the local network), provided the IP address is known.

- next-hop determination

Hosts determine how to forward local or remote traffic with next-hop determination. The next hop can be a local or remote router.

- neighbor unreachability detection

Hosts determine if the neighbor is unreachable, and if address resolution must be performed again to update the database. For neighbors you use as routers, hosts attempt to forward traffic through alternative default routers.

- redirect

Routers inform the host of more efficient routes with redirect messages.

Neighbor discovery uses three components:

- host-router discovery

Host-router discovery performs the following functions:

- router discovery
- prefix discovery
- parameter discovery
- address autoconfiguration

- host-host communication

Host-host communication performs the following functions:

- address resolution
- next-hop determination
- neighbor unreachability detection
- duplicate address detection

- route redirect

*** Note:**

When a neighbor transitions to the STALE state, to initiate Neighbor Unreachability detection (NUD), a duplicate copy of the traffic destined to this neighbor is sent to the switch Control Processor (CP) on a low priority queue (queue 0). The original packet is forwarded to this neighbor. Once NUD is initiated, the hardware records are updated and the traffic is no longer sent to the CP. When a high rate of such traffic is sent to CP, the switch can drop some of these packets due to the in built CP rate limiting feature, which protects the CP from DOS attacks.

Use the command `show qos cosq-stats cpu-port` to view drop statistics on the CPU queue. This design does not result in loss of traffic.

Use the command `ipv6 nd reachable-time <0-3600000>` to increase the default value of 3000 milliseconds which in turn delays the scenario of data path sending STALE neighbor destined packets to the CP.

ND messages

The following table compares the ICMP message types.

Table 7: IPv4 and IPv6 neighbor comparison

IPv4 function	IPv6 function	Description
ARP request message	Neighbor solicitation message	A node sends this message to determine the link-layer address of a neighbor or to verify that a neighbor is still reachable through a cached link-layer address. You can also use neighbor solicitations for duplicate address detection.
ARP reply message	Neighbor advertisement	A node sends this message either in response to a received neighbor solicitation message or to communicate a link-layer address change.
ARP cache	Neighbor cache	The neighbor cache contains information about neighbor types on the network.
Gratuitous ARP	Duplicate address detection New VRRP master interface announcement	A host or node sends a request with its own IP address to determine if another router or host uses the address. If the sender receives a reply, then there is a device with a duplicate address. Both hosts and routers use this function. Gratuitous ARP can also be used to announce the new VRRP master interface so that all switches can adjust their MAC tables.
Router solicitation message (optional)	Router solicitation message (required)	The host sends this message after it detects a change in a network interface operational state. The message includes a request for routers to generate router advertisement immediately rather than at the scheduled time.
Router advertisement message (optional)	Router advertisement message (required)	Routers send this message to advertise their presence with various links and Internet parameters either periodically or in response to a router solicitation

Table continues...

IPv4 function	IPv6 function	Description
		message. Router advertisements contain prefixes that you use for on-link determination or address configuration, and a suggested hop limit value.
Redirect message	Redirect message	Routers send this message to inform hosts of a better first hop for a destination.

Neighbor discovery cache

The neighbor discovery cache lists information about neighbors in the network and can contain the following types of neighbors:

- static: a configured neighbor
- local: a device on the local system
- dynamic: a discovered neighbor

The following table describes the states in the neighbor cache.

Table 8: Neighbor cache states

State	Description
Incomplete	<p>Address resolution is in progress and the system has not yet determined the link-layer address of the neighbor.</p> <p>The neighbor cache may also enter the Incomplete state when the switch cannot confirm subsequent reachability during the ND process for router neighbors. By contrast, the system deletes host neighbors, rather than enter the Incomplete state, if ND fails to confirm reachability.</p> <p>+ Tip:</p> <p>Router neighbors: when the R bit is set in the received neighbor advertisement</p> <p>Host neighbors: when the R bit is not set in the received neighbor advertisement</p>
Reachable	A node receives positive confirmation within the last reachable time period.
Stale	<p>Reachability of the neighbor is unknown.</p> <p>Until the system sends traffic to the neighbor, make no attempt to verify its reachability.</p>
Delay	A time period longer than the reachable time period passes since the node received the last positive

Table continues...

State	Description
	confirmation, and a packet was sent within the last DELAY_FIRST_PROBE_TIME period. If no reachability confirmation is received within the DELAY_FIRST_PROBE_TIME period after entering the DELAY state, neighbor solicitation is sent and the state changes to probe.
Probe	Reachability confirmation is sought from the device every retransmit timer period.

The following events involve Layer 2 and Layer 3 interaction during processing and affect the neighbor cache:

- flushing the virtual LAN (VLAN) MAC
- removing a VLAN or brouter port
- performing an action on all VLANs
- removing a port from a VLAN
- removing a port from a spanning tree group (STG)
- removing a multilink trunk (MLT) group from a VLAN
- removing an MLT port from a VLAN
- removing an MLT port from an STG
- performing an action that disables a VLAN, such as removing all ports from a VLAN
- disabling a tagged port that is a member of multiple routable VLANs

Router discovery

IPv6 nodes discover routers on the local link with router discovery.

Router advertisement:

Configured interfaces on an IPv6 router send router-advertisement messages. Interfaces also send router advertisements in response to router-solicitation messages from IPv6 nodes on the link.

Router solicitation:

An IPv6 host without a configured unicast address sends router solicitation messages.

Host autoconfiguration

The switch can automatically configure a host (node), and assign IPv6 addresses automatically. This process is called stateless address autoconfiguration (SLAAC). The neighbor discovery (ND) protocol performs autoconfiguration.

Stateless autoconfiguration enables serverless basic configuration of IPv6 nodes and renumbering from a mathematical perspective.

Stateless autoconfiguration uses the following equation:

Stateless autoconfiguration = *network prefix (router advertisement) + IPv6 interface identifiers*

Stateless autoconfiguration uses the network prefix information in the router advertisement and integrates this with the interface ID to form the node global address(es).

*** Note:**

The switch cannot autoconfigure an IPv6 address local to itself because IPv6 routers do not process router advertisements in the same manner as hosts. That is, routers check only for consistency in information advertised in IPv6 Router Advertisements on the same link.

+ Tip:

You must manually assign all addresses/prefixes local to the switch.

Assuming an EUI-64 based interface ID is used, the IPv6 interface address is created from the 48-bit (6-byte) MAC address as follows:

1. EUI-64 hexadecimal digits 0xff-fe are inserted between the third and fourth bytes of the MAC address to obtain the EUI-64.
2. The universal or local bit, the second lower-order bit of the first byte of the MAC address, is complemented.

For example, the IPv6 identifier for host A uses the MAC address 00-AA-00-3F-2A-1C.

To automatically assign an address, the following occurs:

1. Convert to EUI-64 format
00-AA-00-FF-FE-3F-2A-1C
2. Complement the Universal/Local (U/L) bit.

The first byte in binary form is 00000000. When the seventh bit is complemented, it becomes 00000010 (0x02).

The result is 02-AA-00-FF-FE-3F-2A-1C or 2AA:FF:FE3F:2A1C.

Host A with MAC address 00-AA-00-3F-2A-1C, combined with network prefix 2001::/64 provided by router advertisement, uses an IPv6 address 2001::2AA:FF:FE3F:2A1C.

A host generates a link-local address with the prefix FE80 regardless of whether an IPv6 router is present or not.

The link-local address for a node with the MAC address 00-AA-00-3F-2A-1C is FE80::2AA:FF:FE3F:2A1C.

The following list explains the states of an autoconfiguration address:

- Tentative: the address is being verified as unique (link-local address)
- Valid: an address from which unicast traffic can be sent and received; can be in one of two states—either preferred or deprecated
- Preferred: an address for which uniqueness was verified for unrestricted use; can be in one of three states—either tentative, preferred, or deprecated

- **Deprecated:** an address that remains valid but is withheld for new communication
- **Invalid:** an address for which a node can no longer send or receive unicast traffic

Neighbor discovery configuration using ACLI

Configuring an IPv6 discovery prefix

Configure the discovery prefixes to send in router advertisement.

About this task

Hosts on the link use router advertisements to perform IPv6 autoconfiguration.

The discovery prefix controls which IPv6 addresses will be automatically configured, and for how long they are valid.

Procedure

1. Enter Interface Configuration mode:

```
enable

configure terminal

interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-
port]] [, ...]} or interface vlan <1-4059>
```

* Note:

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Create neighbor discovery prefixes for an interface:

```
ipv6 nd prefix-interface WORD<0-255> [eui <1-3>] [no-advertise] [no-
autoconfig] [no-onlink]
```

3. Modify an existing neighbor discovery prefix:

```
ipv6 nd prefix WORD<0-255> infinite [no-advertise] [preferred-life
<0-4294967295>] [valid-life <0-4294967295>]
```

Example

Create a new neighbor discovery prefix:

```
Switch:1(config-if)#ipv6 nd prefix-interface fd48:bfb6:4c09:9499::1/64
```

Variable definitions

Use the data in the following table to use the `ipv6 nd prefix` and `ipv6 nd prefix-interface` commands.

Variable	Value
eui <1–3>	<p>Configures the EUI address. The values are:</p> <ul style="list-style-type: none"> • (1) EUI not used • (2) EUI with Universal/Local bit (U/L) complement enabled • (3) EUI used without U/L <p>Use an EUI-64 interface ID in the address field. If enabled, use EUI, or use EUI-64 and the complement Universal/Local (U/L) bit. This operation provides for both global- and link-local addresses. After you create the entry, you cannot modify this value. This value is valid for use only when the prefix length is 64 or less. The default is EUI not used.</p> <p>If you select EUI not used, this configuration creates an IPv6 ND prefix but no associated IPv6 address on the router. If you select either EUI used with UL complement or EUI used without UL complement, an associated IPv6 address is created by concatenating the specified prefix with the EUI-64 interface ID.</p>
infinite	Configures the prefix valid lifetime so it never expires. The default is disabled, which means the prefix expires.
no-advertise	Removes the prefix from the neighbor advertisement. The default is disabled, which means the prefix is advertised.
no-autoconfig	Configures the prefix for use as the autonomous address configuration. This value is placed in the autoflag field in the prefix information option. The value is a 1-bit flag. The default is enabled.
no-onlink	Configures the prefix for use when determining if a node is online. This value is placed in the L-bit field in the prefix information option. The value is a 1-bit flag. The default is enabled.
preferred-life <0–4294967295>	<p>Configures the preferred lifetime in seconds that indicates the length of time this prefix is advertised. The default value is 604800.</p> <p>The preferred lifetime is the length of time for the tentative, preferred, and deprecated state of an autoconfiguration address.</p>

Table continues...

Variable	Value
	The preferred lifetime value must be less than the valid lifetime value. If you must configure the valid lifetime value to a value lower than the current preferred lifetime, you must lower the preferred lifetime value first.
valid-life <0-0-4294967295>	Configures the valid lifetime in seconds that indicates the length of time this prefix is advertised. The default is 2592000. A valid lifetime is the length of time of the preferred and depreciated state of an autoconfiguration address. The preferred lifetime value must be less than the valid lifetime value. If you must configure the valid lifetime to a value lower than the current preferred lifetime, you must lower the preferred lifetime value first.
WORD <0-255>	Specifies the IPv6 address and prefix.

Use the data in the following table to use the **interface** command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Configuring route advertisement

Configure route advertisement in IPv6 for neighbor discovery (ND).

About this task

IPv6 nodes on the same link use ND to discover link-layer addresses and to obtain and advertise various network parameters and reachability information. ND combines the services provided by Address Resolution Protocol (ARP) and router discovery for IPv4.

Procedure

1. Enter Interface Configuration mode:


```
enable
configure terminal
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-
port]][,...]} or interface vlan <1-4059>
```

*** Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Configure the number of neighbor solicitation messages from duplicate address detection:

```
ipv6 nd dad-ns <0-600>
```

3. Configure the hop limit sent in router advertisements:

```
ipv6 nd hop-limit <0-255>
```

4. Enable managed address configuration (M-bit) on the router:

```
ipv6 nd managed-config-flag
```

5. Configure the MTU for router advertisements:

```
ipv6 nd mtu <0-9500>
```

6. Enable other stateful configuration (O-bit) on the router:

```
ipv6 nd other-config-flag
```

7. Configure the router lifetime included in router advertisement:

```
ipv6 nd ra-lifetime <0-9000>
```

8. Configure the neighbor reachable time:

```
ipv6 nd reachable-time <0-3600000>
```

9. Configure the time between neighbor solicitation messages:

```
ipv6 nd retransmit-timer <0-4294967295>
```

10. Configure the maximum time allowed between sending unsolicited multicast router advertisements:

```
ipv6 nd rtr-advert-max-interval <4-1800>
```

11. Configure the minimum time allowed between sending unsolicited multicast router advertisements:

```
ipv6 nd rtr-advert-min-interval <3-1350>
```

12. Enable periodic router advertisement messages:

```
ipv6 nd send-ra
```

Example

Configure the maximum time between sending unsolicited router advertisements:

Neighbor discovery

```
Switch:1(config-if)#ipv6 nd rtr-advert-max-interval 700
```

Configure the minimum time between sending unsolicited router advertisements:

```
Switch:1(config-if)#ipv6 nd rtr-advert-min-interval 500
```

Enable periodic router advertisement messages:

```
Switch:1(config-if)#ipv6 nd send-ra
```

Variable definitions

Use the data in the following table to use the `ipv6 nd` commands.

Variable	Value
<code>dad-ns <0-600></code>	<p>Specifies the number of neighbor solicitation messages for duplicate address detection (DAD).</p> <p>A value of 0 disables the DAD process on this interface.</p> <p>A value of 1 sends one advertisement without retransmissions.</p>
<code>hop-limit <0-255></code>	<p>Specifies the current hop limit field sent in router advertisements from this interface.</p> <p>The value must be the current diameter of the Internet.</p> <p>A value of zero indicates that the advertisement does not specify a hop-limit value.</p> <p>The default is 64.</p>
<code>managed-config-flag</code>	<p>Enables the system to configure the M-bit, or managed address configuration flag, in the router advertisements</p> <p>When set, the M-bit flag indicates that addresses are available through DHCPv6.</p> <p>If the M flag is set, the O flag is redundant because DHCPv6 returns all available configuration information.</p> <p>If neither the M nor O flags are set, no information is available through DHCPv6.</p> <p>The default is disabled.</p>
<code>mtu <0-9500></code>	<p>Shows the MTU value sent in router advertisements on this interface.</p> <p>A value of zero indicates that the system sends no MTU options.</p> <p>The default is 0.</p>

Table continues...

Variable	Value
other-config-flag	<p>Enables the O-bit, or other stateful configuration, flag in the router advertisement.</p> <p>Other stateful configuration autoconfigures received information without addresses.</p> <p>When set, the O-bit flag indicates that other configuration information is available through DHCPv6; for example, DNS-related information or information about other servers within the network.</p> <p>If neither the M nor O flags are set, no information is available through DHCPv6.</p> <p>The default is disabled.</p>
ra-lifetime <0–9000>	<p>Specifies a value placed in the router lifetime field of router advertisements sent from this interface.</p> <p>This value must be either 0, or 4 to 9000 seconds.</p> <p>A value of zero indicates that the system is not a default router.</p> <p>The default is 1800.</p>
reachable-time <0–3600000>	<p>Specifies a value (in milliseconds) placed in the router advertisement message sent by the router.</p> <p>The value zero means unspecified (by this system).</p> <p>Configure the amount of time that a remote IPv6 node is considered reachable after a reachability confirmation event.</p> <p>The default is 0.</p>
retransmit-timer <0–4294967295>	<p>Specifies a value (in milliseconds) placed in the retransmit timer field in the router advertisement message sent from this interface.</p> <p>The value zero means unspecified (by this system).</p> <p>The value configures the amount of time the system waits for the transmission to occur.</p> <p>The default is 0.</p>
rtr-advert-max-interval <4–1800>	<p>Specifies the maximum interval (in seconds) at which the transmission of route advertisements occurs on this interface.</p> <p>The default is 600.</p>
rtr-advert-min-interval <3–1350>	<p>Specifies the minimum interval (in seconds) at which the transmission of route advertisements occurs on this interface.</p> <p>The default is 200.</p>

Table continues...

Variable	Value
send-ra	Specifies whether the router sends periodic router advertisements and responds to router solicitations on this interface. The default is enabled.

Use the data in the following table to use the **interface** command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][/-slot/port[/sub-port]][,....]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

System interface values versus advertised values

There are differences in the relationship between the system interface values and advertised values related to Neighbor Discovery (ND). The information in this section describes differences and similarities and provides examples for important IPv6 interface and IPv6 ND commands.

Comparison of default values per interface and as advertised

The following table compares the default behavior of values per interface and advertised values.

Default values per interface	Default advertised values
hop-limit 64	hop-limit 64
mtu 1500	mtu 0 (unspecified)
reachable-time 30000 ms	reachable-time 0 (unspecified)
retransmit-timer 1000 ms	retransmit-timer 0 (unspecified)

What happens when you change the per interface value and the advertised value:

When you change per-interface values from default to non-default values, the system changes the advertised values to match the interface values.

For example, when you enter the `ipv6 interface mtu 1300` command the values become

- interface mtu 1300
- advertised mtu 1300

Then, when you enter the `show ipv6 nd interface` command, the system marks the mtu value with an (i) which signifies that the ND advertised value is inherited from the interface configuration.

Example:

```
Switch:1(config-if)#ipv6 interface mtu 1300
Switch:1(config-if)# show ipv6 nd interface GigabitEthernet 1/1
```

```
=====
                          Port Ipv6 Nd
=====
IFID BTR  RTR-  MAX-  MIN-  LIFE-  MANAG  OTHER  DAD-NS  MTU    HOP  REACH-  RETRANS-
      ADV  INT  INT   INT   TIME   MANAG  LIMIT  TIME    TIME   HOP  ABLE    MIT
      FLAG
-----
320  1/1  True  600   200    0     False False   1     1300(i) 64(d) 0(d)   0(d)
Note: (s) = Set, (d) = Default, (i) = inherit
-----
```

What happens when you change the per interface value but do not change the advertised value:

To change the per-interface value from the default value to a non-default value but retain the advertised value of 0 (unspecified), you must enter two commands.

For example, to set the reachable-time to 60000 but retain the advertised value of the reachable-time parameter at 0, enter the following commands:

```
ipv6 interface reachable-time 6000
ipv6 nd reachable-time 0
```

When you enter the `show ipv6 nd interface` command, the system marks the reachable-time value with an (s) to signify that this value is explicitly set by the ND configuration.

Example:

```
Switch:1(config-if)#ipv6 interface reachable-time 60000
Switch:1(config-if)#ipv6 nd reachable-time 0
Switch:1(config-if)#show ipv6 nd interface GigabitEthernet 1/1
```

```
=====
                          Port Ipv6 Nd
=====
IFID BTR  RTR-  MAX-  MIN-  LIFETIME  MANAG  OTHER  DAD-NS  MTU    HOP  REACH-  RETRANS-
      ADV  INT  INT   INT   CONF     MANAG  LIMIT  TIME    TIME   HOP  ABLE    MIT
      FLAG
-----
320  1/1  True  600   200   0         False False   1     1500(i) 64(d) 0(s)   0(d)
Note: (s) = Set, (d) = Default, (i) = inherit
-----
```

Configuring the neighbor cache

Configure the address translation table used to map IPv6 addresses to physical addresses. You can manually add static neighbors to the cache.

About this task

Neighbor cache in IPv6 is similar to the IPv4 Address Resolution Protocol (ARP) table.

The neighbor cache is a set of entries for individual neighbors to which traffic was recently sent.

You make entries on the neighbor on-link unicast IP address, including information such as the link-layer address.

A neighbor cache entry contains information used by the Neighbor Unreachability Detection algorithm, including the reachability state, the number of unanswered probes, and the time the next Neighbor Unreachability Detection event is scheduled.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Create a static neighbor:

```
ipv6 neighbor WORD<0-128> port {slot/port[sub-port]} mac
<0x00:0x00:0x00:0x00:0x00:0x00> [vlan <1-4059> ]
```

When you create a static neighbor, it always remains in the reachable state. This differs from the general neighbor cache behavior where, among other things, timers and neighbor unreachability detection events can be generated.

Example

Create a static neighbor:

```
Switch:1(config)#ipv6 neighbor 3000::3 port 1/11 mac 00-1A-4B-8A-FB-6B
```

Variable definitions

Use the data in the following table to use the `ipv6 neighbor` command.

Variable	Value
mac <0x00:0x00:0x00:0x00:0x00:0x00>	Specifies the MAC address.
{slot/port[/sub-port]}	Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
vlan <1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
WORD<0-128>	Specifies the IPv6 address in hexadecimal colon format.

Viewing cached destination information

View the destination cache to see next-hop addresses for destinations.

The destination cache is only populated or updated when IPv6 packets originate locally on the central processor of the switch.

The main purpose of the destination cache is to store, on a per-destination basis, the dynamic Path MTU value currently used when transmitting packets from the local system to the remote destination.

The system uses the PMTU value to calculate how many bytes can fit into an individual packet before fragmentation should be applied.

About this task

The command output shows the following information:

- the IPv6 destination address
- the IPv6 address for the next hop to the destination
- the path maximum transmission unit (MTU) for the destination
- the time, in seconds, since an ICMPv6 packet-too-big message was received

Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. View the destination cache for all interfaces:

```
show ipv6 dcache
```

3. View the destination cache for a brouter port:

```
show ipv6 dcache gigabitethernet {slot/port[sub-port]}
```

4. View the destination cache for a management port:

```
show ipv6 dcache mgmtethernet {slot/port[sub-port]}
```

5. View the destination cache for a specific tunnel ID:

```
show ipv6 dcache tunnel <1-2000>
```

6. View the destination cache for a VLAN:

```
show ipv6 dcache vlan <1-4059>
```

7. Clear the destination cache:

```
clear ipv6 dcache [gigabitethernet {slot/port[sub-port]]  
[mgmtethernet {slot/port[sub-port]] [tunnel <1-2000>] [vlan  
<1-4059> ]
```

Example

```
Switch:1(config-if)#show ipv6 dcache
=====
                        IPv6 Destination Cache Information
=====
Destination Address  NEXT HOP                VID/BID/TID  IF_TYPE  IF_DATA  PMTU  PMTU_
                                         AGE
-----
2:0:0:0:0:0:0:36    0:0:0:0:0:0:0:0        V-2          real     -        1500  0
3:0:0:0:0:0:0:36    0:0:0:0:0:0:0:0        V-3          real     -        1500  0
4:0:0:0:0:0:0:36    0:0:0:0:0:0:0:0        V-4          real     -        1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        6/7         real     -        1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-2          real     -        1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-3          real     -        1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-4          real     -        1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        T-25        real     -        1280  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-2          virtual  rsmlt    1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-3          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-4          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-4          virtual  vrId-10  1500  0
ff02:0:0:0:0:0:0:1  0:0:0:0:0:0:0:0        V-3          virtual  vrId-255 1500  0
ff02:0:0:0:0:0:0:12 0:0:0:0:0:0:0:0        V-3          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:12 0:0:0:0:0:0:0:0        V-4          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:12 0:0:0:0:0:0:0:0        V-4          virtual  vrId-10  1500  0
ff02:0:0:0:0:0:0:12 0:0:0:0:0:0:0:0        V-3          virtual  vrId-255 1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-2          real     -        1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-3          real     -        1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-4          real     -        1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        T-25        real     -        1280  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-2          virtual  rsmlt    1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-3          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-4          virtual  vrId-1   1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-4          virtual  vrId-10  1500  0
ff02:0:0:0:0:0:0:16 0:0:0:0:0:0:0:0        V-3          virtual  vrId-255 1500  0
=====
```

Variable definitions

Use the data in the following table to use the **show ipv6 dcache** and **clear ipv6 dcache** commands.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port]}	Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Neighbor discovery configuration using EDM

Configuring an IPv6 discovery prefix

Configure the discovery prefixes to send in router advertisement.

About this task

Hosts on the link use router advertisements to perform IPv6 autoconfiguration. The discovery prefix controls what IPv6 addresses to autoconfigure and how long they are valid.

You can also configure an IPv6 interface for a brouter port through the **Edit > Port > IPv6** navigation path, and for a VLAN through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 navigation path where you can configure both types of interfaces.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Discovery Prefix** tab.
4. Click **Insert**.
5. Beside the **Interface** field, click **Port** or **VLAN**.
6. Select a port or VLAN.
7. Click **OK**.
8. Specify the prefix and prefix length.
9. Click **Insert**.
10. Click **Apply**.

IPv6 Discovery Prefix field descriptions

Use the data in the following table to use the **IPv6 Discovery Prefix** tab.

Name	Description
Interface	Shows a read-only value that indicates an IPv6 interface. For the brouter port, it is the ifindex of the port and, in the case of the VLAN, it is the ifindex of the VLAN.
Prefix	Configures the prefix to create an IPv6 prefix entry as either advertised or suppressed.
PrefixLen	Configures the mask to create an IPv6 address in the IPv6 interface table.

Table continues...

Name	Description
VlanId	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
UseDefaultVal	Specifies one included value to use the default value, or use all bits to configure all options to their default value.
ValidLifetime	<p>Configures the valid lifetime in seconds that indicates the length of time this prefix is advertised. The default is 2592000.</p> <p>A valid lifetime is the length of time of the preferred and depreciated state of an autoconfiguration address.</p> <p>The preferred lifetime value must be less than the valid lifetime value. If you must configure the valid lifetime value to a value lower than the current preferred lifetime, you must lower the preferred lifetime value first.</p>
PreferedLifetime	<p>Configures the preferred lifetime in seconds that indicates the length of time this prefix is advertised. The default value is 604800.</p> <p>The preferred lifetime is the length of time for the tentative, preferred, and depreciated state of an autoconfiguration address.</p> <p>The preferred lifetime value must be less than the valid lifetime value. If you must configure the valid lifetime value to a value lower than the current preferred lifetime, you must lower the preferred lifetime value first.</p>
Infinite	Configures the prefix valid lifetime so it never expires. The default is false.
OnLinkFlag	Configures the prefix for use when determining if a node is online. This value is placed in the L-bit field in the prefix information option. It is a 1-bit flag. The default is true.
AutoFlag	Configures the prefix for use as the autonomous address configuration. This value is placed in the autoflag field in the prefix information option. It is a 1-bit flag. The default is true.
AddressEui	Configures the EUI address. Use an EUI-64 interface ID in the address field. If enabled, use EUI, or use EUI-64 and the complement Universal/Local (U/L)

Table continues...

Name	Description
	<p>bit. This operation provides for both global and link-local addresses. After you create the entry, you cannot modify this value. This value is valid for use only when the PrefixLength is 64 or less. The default is eui-not-used.</p> <p>If you select eui-not-used, this configuration creates an IPv6 ND prefix but no associated IPv6 address on the router. If you select either eui-used-with-ul-complement or eui-used-without-ul-complement, an associated IPv6 address is created by concatenating the specified prefix with the EUI-64 interface ID.</p>
NoAdvertise	Configures if the prefix is included in the router advertisement. Select true to not include the prefix in the router advertisement. The default is false.

Configuring route advertisement

Configure route advertisement in IPv6 for neighbor discovery (ND).

About this task

IPv6 nodes on the same link use ND to discover link-layer addresses and to obtain and advertise various network parameters and reachability information. ND combines the services provided by Address Resolution Protocol (ARP) and router discovery for IPv4.

* Note:

You only use the ND level configuration when you want to create advertised values that differ from the interface values for reachable-time, retransmit-timer, mtu, or hop-limit.

You can also configure an IPv6 interface for a brouter port through the **Edit > Port > IPv6** navigation path, and for a VLAN through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 navigation path where you can configure both types of interfaces.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Route Advertisement** tab.
4. Double-click a parameter to change the current value.

You cannot modify the parameters in gray shading.

5. Click **Apply**.

Route Advertisement field descriptions

Use the data in the following table to use the **Route Advertisement** tab.

Name	Description
Interface	Specifies the interface to which this entry applies.
SendAdverts	Specifies whether the router sends periodic router advertisements and responds to router solicitations on this interface. The default is True.
UseDefaultVal	Specifies one included value to use the default value, or use all bits to configure all options to their default value.
MaxInterval	Specifies the maximum interval (in seconds) at which the transmission of route advertisements occurs on this interface. The value must be between 4 seconds and 1800 seconds. The default is 600.
MinInterval	Specifies the minimum interval (in seconds) at which the transmission of route advertisements occurs on this interface. The value must be between 3 seconds and 0.75 x max-interval. The default is 200.
ReachableTime	Shows a value (in milliseconds) placed in the router advertisement message sent by the router. The value zero means unspecified (by this system). Configure the amount of time that a remote IPv6 node is considered reachable after a reachability confirmation event. You cannot modify this parameter; use the Interfaces tab to change the value for the interface.
RetransmitTime	Shows a value (in milliseconds) placed in the retransmit timer field in the router advertisement message sent from this interface. The value zero means unspecified (by this system). The value configures the amount of time the system waits for the transmission to occur. You cannot modify this parameter; use the Interfaces tab to change the value for the interface.
DefaultLifeTime	Specifies a value placed in the router lifetime field of router advertisements sent from this interface. This value must be either 0 or between 4 and 9000 seconds. A value of zero indicates that the system is not a default router. The default is 1800.
CurHopLimit	Specifies the current hop limit field sent in router advertisements from this interface. The value must be the current diameter of the Internet. A value of zero indicates that the advertisement does not specify a value for CurHopLimit. The default is 64.
ManagedFlag	Enables the system to configure the M-bit or managed address configuration in the router advertisements. The default is false.

Table continues...

Name	Description
DadNsNum	Specifies the number of neighbor solicitation messages for duplicate address detection (DAD). A value of 0 disables the DAD process on this interface. A value of 1 sends one advertisement without retransmissions.
LinkMTU	Shows the MTU value sent in router advertisements on this interface. A value of zero indicates that the system sends no MTU options.
OtherConfigFlag	Enables the O-bit (other stateful configuration) in the router advertisement. Other stateful configuration autoconfigures received information without addresses. The default is disabled.

Configuring the neighbor cache

Configure the address translation table used to map IPv6 addresses to physical addresses. You can manually add static neighbors to the cache.

About this task

Neighbor cache in IPv6 is similar to the IPv4 Address Resolution Protocol (ARP) table. The neighbor cache is a set of entries for individual neighbors to which traffic was sent recently. You make entries on the neighbor on-link unicast IP address, including information such as the link-layer address. A neighbor cache entry contains information used by the Neighbor Unreachability Detection algorithm, including the reachability state, the number of unanswered probes, and the time the next Neighbor Unreachability Detection event is scheduled.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Neighbors** tab.
4. Click **Insert**.
5. Beside the **Interface** field, click **Port** or **VLAN**.
6. Select a port or VLAN.
7. Configure the remaining parameters as required.
8. Click **Insert**.
9. Click **Apply**.

Neighbors field descriptions

Use the data in the following table to use the **Neighbors** tab.

Name	Description
Interface	Specifies the interface to which this entry applies.
NetAddress	Specifies the IP address of the media-dependent physical address.
PhyAddress	Specifies the MAC address, in the range of 0-65535.
Interface	Specifies a physical port ID or a MLT port ID.
LastUpdated	Specifies the value of sysUpTime of the last modification to this entry. If the entry was created prior to the last reinitialization of the local management subsystem, the object contains a zero value.
Type	Specifies the mapping type from manually configured entries. While the selection of either dynamic, static, or local is allowed; static is currently the only valid selection.
State	Specifies the Neighbor Unreachability Detection state for the interface after the address mapping in this entry is used. If Neighbor Unreachability Detection is not in use (for example, for IPv4), this object is always unknown. The options include the following: <ul style="list-style-type: none"> • reachable: confirmed reachability • stale: unconfirmed reachability • delay: waiting for reachability confirmation before entering the probe state • probe: actively probing • invalid: an invalidated mapping • unknown: state cannot be determined. • incomplete: address resolution is being performed
BMac	Specifies the backbone MAC address.

Viewing cached destination information

View the destination cache to see next-hop addresses for destinations.

The destination cache is only populated or updated when IPv6 packets are locally originated on the central processor of the switch.

The main purpose of the destination cache is to store, on a per-destination basis, the dynamic Path MTU value currently used when transmitting packets from the local system to the remote destination. The PMTU value itself is used to calculate how many bytes can fit into an individual packet before fragmentation should be applied.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6**.
3. Click the **Destination Cache** tab.

Destination Cache field descriptions

Use the data in the following table to use the **Destination Cache** tab.

Name	Description
DestAddr	Shows the IPv6 destination address.
Interface	Shows the interface number that is used to reach the destination.
NextHop	Shows the IPv6 address for the next hop to the destination.
IfType	Specifies the interface type (tunnel, VLAN, or brouter) or virtual circuit (VRRP, RSMLT).
IfData	Displays additional information about virtual circuits. For instance, for a VRRP or RSMLT the virtual router ID displays. If the interface type is tunnel, VLAN, or brouter, no additional information displays.
Pmtu	Shows the path maximum transmission unit (MTU) for the destination.
PmtuAge	Shows the time, in seconds, since an ICMPv6 packet too big message was received.

Chapter 5: DHCP Relay

This chapter provides concepts and procedures to complete IPv6 DHCP Relay configuration.

DHCP Relay

The Dynamic Host Configuration Protocol (DHCP) for IPv6 (RFC 3315) enables DHCP servers to pass configuration parameters such as IPv6 network addresses to IPv6 nodes. DHCP supports automatic allocation of reusable network addresses and of additional configuration parameters. This protocol is a stateful counterpart to stateless address autoconfiguration, and you can use it separately or concurrently with the latter to obtain configuration parameters. For more information about stateless address autoconfiguration, see [Host autoconfiguration](#) on page 76.

To request the assignment of one or more IPv6 addresses, a client first locates a DHCP server, and then requests the assignment of addresses and other configuration information from the server:

1. The client sends a solicit message to the All_DHCP_Relay_Agents_and_Servers (FF02::1:2) multicast address to find available DHCP servers.
2. Any server that can meet the requirements responds with an advertise message.
3. The client then chooses one of the servers and sends a request message to the server asking for confirmed assignment of addresses and other configuration information.
4. The server responds with a reply message that contains the confirmed addresses and configuration.

If a DHCP client does not need a DHCP server to assign it an IPv6 address, the client can obtain configuration information such as a list of available DNS servers or NTP servers through a single message and reply exchanged with a DHCP server.

IPv6 DHCP clients use link-local addresses to send and receive DHCP messages. To permit a DHCP client to send a message to a DHCP server that is not attached to the same link, you must configure a DHCP relay agent on the client link to relay messages between the client and server. The operation of the relay agent is transparent to the client.

A relay agent relays messages from clients and messages from other relay agents. The switch supports DHCP Relay for IPv6. Configure at least one relay agent when the client and server are in different networks.

You must configure the relay agent to use a list of destination addresses for available DHCP servers. This release does not support IPv6 multicast for site-local and global addresses.

The DHCP relay can be a Virtual Router Redundancy Protocol (VRRP) Address. The relay forwards the DHCP messages only if VRRP is in the Master state, otherwise the relay discards the messages.

*** Note:**

Since DHCP cannot work on the backup VRRP if the master fails, to achieve optimum results and to leverage redundancy you must configure DHCP on the backup VRRP.

Clients listen for DHCP messages on UDP port 546. Servers and relay agents listen for DHCP messages on UDP port 547.

Remote ID

IPv6 DHCP Relay supports the remote ID parameter (RFC4649). After you enable remote ID on the switch, the relay agent adds information about the relay to DHCPv6 messages before relaying the messages to the DHCP server. The server can use the supplied information in the process of assigning the addresses, delegated prefixes, and configuration parameters that the client is to receive.

The remote ID option contains two fields:

- vendor ID
- MAC address of the client

The switch uses a vendor ID of 1584.

Limitations

The following list identifies configuration limitations:

- You can configure only one relay for a VLAN, regardless of how many addresses are configured on that VLAN. The default address is the smallest address configured. If the relay is a VRRP address, the default value is the first VRRP address configured.
- The maximum servers to which a relay can send a message from one client is 10.
- You can configure a maximum of 512 forwarding paths per system.

DHCP Relay configuration using ACLI

Configuring a DHCP Relay forwarding path

Configure a forwarding path to specify the relay agent address and the DHCP server address to which to forward packets.

To use DHCP Relay for IPv6, you must configure at least one forwarding path and enable the relay on one interface.

About this task

The relay agent can use the IPv6 address of the interface or the VRRP global address linked to that interface. The relay forwards the DHCP messages only if VRRP is in the master state, otherwise the relay discards the messages.

You can configure only one relay agent on an interface. If you need to change the relay agent, you must delete all the forwarding paths with the old relay agent, and then configure the new relay agent.

You can configure a maximum of 512 forwarding paths.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Configure a forwarding path:

```
ipv6 dhcp-relay fwd-path WORD<0-255> WORD<0-255> [enable]
```

If you configure the forwarding path globally, the relay agent address can be any configured IP address of the relay interface or the VRRP global address linked to the relay interface.

3. To configure a forwarding path on an interface, enter Interface Configuration mode:

```
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-port]] [, ...]}
```

OR

```
interface vlan <1-4059>
```

4. Configure a forwarding path:

```
ipv6 dhcp-relay fwd-path WORD<0-255> [enable] [vrid WORD<1-255>]
```

If you configure the forwarding path on an interface, the relay agent address is either the smallest IP configured on the interface or the first VRRP global address configured, if the relay is the VRRP master. You do not specify the relay agent address as part of the command.

Example

Configure a forwarding path globally:

```
Switch:1(config)#ipv6 dhcp-relay fwd-path 1111::1111 1234::1234 enable
```

Configure a forwarding path on an interface:

```
Switch:1(config)#interface GigabitEthernet 1/1
```

```
Switch:1(config-if)#ipv6 dhcp-relay fwd-path 1234::1234 enable
```

OR

Configure the VRRP master as the relay:

```
Switch:1(config-if)#ipv6 dhcp-relay fwd-path 1234::1234 vrid 12 enable
```

Variable definitions

Use the data in the following table to use the `ipv6 dhcp-relay fwd-path` command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
enable	Enables the forwarding path. The default is disabled.
{slot/port[/sub-port][-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
vrid WORD<1-255>	Specifies the VRRP ID to use the VRRP master as the relay agent interface.
WORD<0-255>	Specifies the IPv6 address of the DHCP server for the interface configuration.
WORD<0-255> WORD<0-255>	Specifies the IPv6 address of the relay agent interface and the IPv6 address of the DHCP server for the global configuration.

Configuring DHCP Relay for an interface

Configure the DHCP relay behavior on the interface.

About this task

You can configure only one relay for a VLAN, regardless of how many addresses are configured on that VLAN. The default address is the smallest address configured. If the relay is a VRRP address, the default value is the first VRRP address configured.

Procedure

1. Enter Interface Configuration mode:

```
enable
```

```
configure terminal
```

```
interface GigabitEthernet {slot/port[/sub-port][-slot/port[/sub-port]][,...]} or interface vlan <1-4059>
```

*** Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Enable DHCP on the interface:

```
ipv6 dhcp-relay
```

3. Configure the maximum hop count:

```
ipv6 dhcp-relay max-hop <1-32>
```

4. Enable the remote ID:

```
ipv6 dhcp-relay remote-id
```

Example

Configure the maximum hop count:

```
Switch:1(config-if)#ipv6 dhcp-relay max-hop 30
```

Disable the remote ID:

```
Switch:1(config-if)#no ipv6 dhcp-relay remote-id
```

Variable definitions

Use the data in the following table to use the `ipv6 dhcp-relay` command.

Variable	Value
max-hop <1-32>	Specifies the maximum number of hops a DHCP packet can take from the DHCP client to the DHCP server. The default is 32.
remote-id	Enables the relay agent to add information about the relay to DHCPv6 messages before relaying the messages to the DHCP server. The default is disabled

Use the data in the following table to use the `interface` command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Viewing DHCP Relay information

View DHCP Relay information to display the current configuration for the forwarding path and the interface configuration.

Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. View forwarding path information:

```
show ipv6 dhcp-relay fwd-path
```

3. View IPv6 DHCP Relay interface configuration:

```
show ipv6 dhcp-relay interface {gigabitEthernet {slot/port[/sub-
port]}[-slot/port[/sub-port]][,...]}|vlan <1-4059> }
```

* Note:

The `no ipv6 dhcp-relay` command disables DHCP on the interface but does not delete the entry.

Example

```
Switch:1(config-if)#show ipv6 dhcp-relay fwd-path
```

```
=====
                        DHCPv6 Fwd-path
=====
INTERFACE                SERVER                ENABLE
-----
1111:0:0:0:0:0:1111      1234:0:0:0:0:0:1234      enable
```

```
Switch:1(config-if)#show ipv6 dhcp-relay interface gigabitEthernet 5/1
```

```
=====
                        Port Dhcipv6
=====
PORT NUM   IF INDEX   MAX HOP   DHCP-RELAY   REMOTE ID
-----
1/1        320        30        enable        disable
```

Variable definitions

Use the information in the following table to help you use the `show ipv6 dhcp-relay` command.

Variable	Value
{slot/port[/sub-port]}[-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports

Table continues...

Variable	Value
	and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
vlan<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.

DHCP Relay configuration using EDM

Configuring a DHCP Relay forwarding path

Configure a forwarding path to specify the relay agent address and the DHCP server address to which to forward packets.

To use DHCP Relay for IPv6, you must configure at least one forwarding path and enable the relay on one interface.

About this task

The relay agent can use the IPv6 address of the interface or the VRRP global address linked to that interface. The relay forwards the DHCP messages only if VRRP is in the Master state, otherwise the relay discards the messages.

You can configure only one relay agent on an interface. If you need to change the relay agent, you must delete all the forwarding paths with the old relay agent, and then configure the new relay agent.

You can configure a maximum of 512 forwarding paths.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **DHCP Relay**.
3. Click the **Forward Path** tab.
4. Click **Insert**.
5. In the **AgentAddr** field, type the address of the input interface that forwards the packets.
6. In the **ServerAddr** field, type the address of the DHCP server.
7. Select **Enabled**.
8. Click **Insert**.

Forward Path field descriptions

Use the data in the following table to use the **Forward Path** tab.

Name	Description
AgentAddr	Specifies the IP address of the input interface (relay agent) on which the DHCP request packets are received for forwarding. This address is the IPv6 or VRRP global address of either a brouter port or a VLAN for which forwarding is enabled.
ServerAddr	Specifies the IP address of the DHCP server. The request is unicast to the server address.
Enabled	Enables DHCP Relay for the system. The default is disabled (clear).

Configuring DHCP Relay for an interface

Configure the DHCP relay behavior on the interface.

About this task

You can configure only one relay for a VLAN, regardless of how many addresses are configured on that VLAN. The default address is the smallest address configured. If the relay is a VRRP address, the default value is the first VRRP address configured.

You can modify the DHCP Relay configuration for a brouter port through the **Edit > Port > IPv6** navigation path, and for a VLAN through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 navigation path where you can configure both types of interfaces.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **DHCP Relay**.
3. Click the **Interface** tab.
4. Click **Insert**.
5. Beside the **IfIndex** field, click **Port** or **Vlan**.
6. Select a port or VLAN, and then click **OK**.
7. Click **Insert**.

Interface field descriptions

Use the data in the following table to use the **Interface** tab and the **DHCP Relay** tab for brouter ports.

Name	Description
Ifindex	Shows the unique value to identify an IPv6 interface. For the brouter port, the value is the ifindex of the port and, in the case of the VLAN, the value is the ifindex of the VLAN.
MaxHop	Specifies the maximum number of hops a DHCP packet can take from the DHCP client to the DHCP server. The default is 32.
RemoteldEnabled	Enables the relay agent to add information about the relay to DHCPv6 messages before relaying the messages to the DHCP server. The default is disabled (clear or false).
DhcpEnabled	Enables (true) or disables (false) DHCP Relay for an interface with an existing DHCP Relay configuration. This field appears only on the DHCP Relay tab for a brouter port if you modify an existing configuration. This field does not appear if you create a new DHCP Relay port configuration.

Modifying DHCP Relay for a VLAN

Modify the existing DHCP relay behavior on the VLAN interface.

About this task

You can configure only one relay for a VLAN, regardless of how many addresses are configured on that VLAN. The default address is the smallest address configured. If the relay is a VRRP address, the default value is the first VRRP address configured.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > VLAN**.
2. Click **VLANs**.
3. Click the **Basic** tab.
4. Select a VLAN.
5. Click **IPv6**.
6. Click the **DHCP Relay** tab.
7. Double-click a cell to change the value.
8. Click **Apply**.

DHCP field descriptions

Use the data in the following table to use the **DHCP Relay** tab.

Name	Description
IfIndex	Shows the unique value to identify an IPv6 interface.
MaxHop	Specifies the maximum number of hops a DHCP packet can take from the DHCP client to the DHCP server. The default is 32.
RemoteldEnabled	Enables the relay agent to add information about the relay to DHCPv6 messages before relaying the messages to the DHCP server. The default is disabled (clear or false).
DhcpEnabled	Enables (true) or disables (false) DHCP Relay for an interface with an existing DHCP Relay configuration.

Modifying DHCP Relay for a port

Modify the existing DHCP relay behavior on the brouter port interface.

About this task

The default address is the smallest address configured. If the relay is a VRRP address, the default value is the first VRRP address configured.

Procedure

1. In the Device Physical View, select the port.
2. In the navigation tree, expand the following folders: **Configuration > Edit > Port**.
3. Click **IPv6**.
4. Click the **DHCP Relay** tab.
5. Double-click a cell to change the value.
6. Click **Apply**.

Interface field descriptions

Use the data in the following table to use the **Interface** tab and the **DHCP Relay** tab for brouter ports.

Name	Description
IfIndex	Shows the unique value to identify an IPv6 interface. For the brouter port, the value is the ifindex of the port and, in the case of the VLAN, the value is the ifindex of the VLAN.
MaxHop	Specifies the maximum number of hops a DHCP packet can take from the DHCP client to the DHCP server. The default is 32.

Table continues...

Name	Description
RemoteldEnabled	Enables the relay agent to add information about the relay to DHCPv6 messages before relaying the messages to the DHCP server. The default is disabled (clear or false).
DhcpEnabled	Enables (true) or disables (false) DHCP Relay for an interface with an existing DHCP Relay configuration. This field appears only on the DHCP Relay tab for a brouter port if you modify an existing configuration. This field does not appear if you create a new DHCP Relay port configuration.

Chapter 6: Tunneling

This chapter provides concepts and procedures to complete IPv6 tunnel configuration.

Tunneling

Tunneling provides a mechanism to transfer IPv6 traffic through an IPv4-only network.

How tunneling works:

IPv6 tunneling encapsulates IPv6 packets in IPv4 packets for delivery across an IPv4 infrastructure.

At the tunnel source, or head end, the system encapsulates an IPv6 packet into an IPv4 packet and sends it to the remote tunnel destination.

The tunnel destination strips the IPv4 packet header and forwards the original IPv6 packet further into an IPv6 cloud.

These types of tunnels are called dual-stack tunnels because they support both IPv4 and IPv6.

Manually configured tunnels

Manually configured tunnels can provide communication between two isolated IPv6 domains over an IPv4 network.

Manually configured tunnels are point-to-point.

You can configure tunnel endpoints to create a point-to-point connection between two isolated IPv6 domains by configuring IPv6 and IPv4 addresses at each end of the tunnel.

Note:

The router or host at the source and destination ends of the tunnel must support both IPv4 and IPv6 protocol stacks.

IPv6 reachability enables tunnel forwarding but tunnel operational status depends on the IPv4 reachability of the tunnel endpoint.

The IPv4 tunnel endpoint configuration must be symmetrical; that is, if you configure a tunnel with a source of 10.10.10.1 and a destination of 11.11.11.1 from switch A, then Switch B must have a source of 11.11.11.1 and a destination of 10.10.10.1.

Tunnel interfaces are logical point-to-point interfaces.

You can enable dynamic routing when you enable a routing protocol, for example OSPFv3, on the tunnel interfaces.

Unicast routing protocols can detect link loss and redirect IPv6 route information:

There is no explicit signaling protocol applied to IPv6-in-IPv4 configured tunnels (refer to RFC 4213).

Therefore, if the remote endpoint of a tunnel that terminates several Layer 3 hops away in the network fails, the local state of the tunnel remains active even though the endpoint has failed.

However, you can enable unicast routing protocols over tunnels, for example OSPFv3. These unicast routing protocols introduce their own protocol-specific signaling and, when a unicast routing protocol is present over the tunnel link, the routing protocol can detect link loss and re-direct the IPv6 route information to use an alternate, reachable nexthop.

Operational events that trigger tunnel state transition:

The switch must be able to locally detect operational events that can trigger a tunnel state transition.

These events include:

- deletion of local IPv4 interface
- change or loss of the IPv4 route to the remote tunnel endpoint
- change in the nexthop of the IPv4 route to the remote tunnel endpoint
- loss of the ARP entry for the nexthop router that is used to reach the IPv4 tunnel endpoint

Tunnels and MTU:

You cannot configure the MTU for tunnels.

The default MTU value for tunnels is 1280.

Packets are forwarded through the tunnel using the line card network processing units (NPUs) only. Since the packets are not forwarded through the central processing unit (CPU) they do not impact the CPU load.

Tunneling configuration using ACLI

Configuring a tunnel

Configure a tunnel for IPv6 VLANs or brouter ports to communicate through an IPv4-only network. Create a point-to-point connection between the two isolated IPv6 devices by configuring the tunnel endpoints.

Do not create tunnels in a native IPv6 network.

Before you begin

- The router or host at the source and destination of the tunnel must support both IPv4 and IPv6 protocol stacks.

About this task

Manual tunnels are point-to-point, so you configure both source and destination addresses. You must configure both IPv6 and IPv4 addresses for both source and destination devices. The IPv6 addresses must represent the same network, for example 6666::1/96 and 6666::2/96.

Tunnel interfaces are automatically configured with a link-local address in the format fe80::<local_ipv4_source_address>.

You cannot configure the maximum transmission unit (MTU) for tunnels. The default MTU value for tunnels is 1280.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Create a tunnel:

```
ipv6 tunnel <1-2000> source {A.B.C.D} address WORD<0-46> destination
{A.B.C.D}
```

Example

Create tunnel 2:

```
Switch:1(config)#ipv6 tunnel 2 source 11.11.11.1 address
3000:0:0:0:0:0:1/64 destination 12.12.12.2
```

Variable definitions

Use the data in the following table to use the `ipv6 tunnel` command.

Variable	Value
<1-2000>	Configures the ID for the tunnel.
address WORD<0-46>	Assigns an IPv6 address and prefix to the tunnel.
destination {A.B.C.D}	Configures the address of the remote endpoint of the tunnel.
source {A.B.C.D}	Configures the address of the local endpoint of the tunnel.

Viewing tunnel interfaces

View tunnel interfaces to verify the current configuration and operational status of IPv6 tunnels.

Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. Show IPv6 tunnel information:

```
show ipv6 tunnel [<1-2000>] [detail] [local {A.B.C.D}] [remote {A.B.C.D}]
```

Example

```
Switch:1#show ipv6 tunnel detail

=====
                        Tunnel Interface Information
=====
ID          LOCAL ADDRESS    REMOTE ADDRESS  OPER STATUS  TYPE
-----
2           211.1.55.2         44.1.55.1      active       manual
1           211.1.55.2         44.1.55.43     active       manual
210        211.1.60.2         47.1.60.1      active       manual

3 out of 3 Total number of entries displayed.

-----

=====
                        Address Information
=====
IPV6 ADDRESS/PREFIX LENGTH          TYPE    ORIGIN    STATUS
-----
43:210:0:0:0:0:0:2/64                UNICAST MANUAL    PREFERRED
fe80:0:0:0:0:0:d301:3702/64          UNICAST LINKLAYER PREFERRED
44:211:0:0:0:0:0:2/64                UNICAST MANUAL    PREFERRED
fe80:0:0:0:0:0:d301:3702/64          UNICAST LINKLAYER PREFERRED
```

Variable definitions

Use the data in the following table to use the `show ipv6 tunnel` command.

Variable	Value
<1-2000>	Shows information for a specific tunnel ID.
detail	Shows detailed address information for the tunnel.
local {A.B.C.D}	Shows information for a specific local address (the local endpoint of the tunnel).
remote {A.B.C.D}	Shows information for a specific remote address (the remote endpoint of the tunnel).

Modifying tunnel hop limits

Modify tunnel hop limits to update hop-limit values on previously configured tunnels.

About this task

The tunnel hop limit configures the value of the time-to-live (TTL) for IPv4 packets.

Procedure

1. Enter Global Configuration mode:

```

enable
configure terminal
2. Modify the hop limit:
ipv6 tunnel <1-2000> hop-limit <0-255>

```

Example

Modify the hop limit for tunnel ID 5:

```
Switch:1(config)#ipv6 tunnel 5 hop-limit 200
```

Variable definitions

Use the data in the following table to use the `ipv6 tunnel` command.

Variable	Value
<0-255>	Configures the maximum number of hops in the tunnel. The default value is 255.
<1-2000>	Specifies the tunnel ID.

Tunnel configuration using EDM

Configuring a tunnel

Configure a tunnel for IPv6 VLANs or brouter ports to communicate through an IPv4-only network. Create a point-to-point connection between the two isolated IPv6 devices by configuring the tunnel endpoints.

Do not create tunnels in a native IPv6 network.

Before you begin

- The router or host at the source and destination of the tunnel must support both IPv4 and IPv6 protocol stacks.

About this task

Manual tunnels are point-to-point, so you configure both source and destination addresses. You must configure both IPv6 and IPv4 addresses for both source and destination devices. The IPv6 addresses must represent the same network, for example 6666::1/96 and 6666::2/96.

Tunnel interfaces are automatically configured with a link-local address in the format fe80::<local_ipv4_source_address>.

You cannot configure the maximum transmission unit (MTU) for tunnels. The default MTU value for tunnels is 1280.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **Tunnel**.
3. Click the **Tunnel Config** tab.
4. Click **Insert**.
5. Beside the **LocalAddress** field, click the button, and then select the IPv4 address for the local VLAN or brouter port.
6. In the **RemoteAddress** field, type the IPv4 address for the destination VLAN or brouter port.
7. In the **ID** field, type a number to represent the tunnel.
8. In the **IPv6AddressAddr** field, type the IPv6 address for the tunnel VLAN or brouter port.
9. In the **IPv6AddressPrefixLength** field, type the number of bits to advertise in the IPv6 address.
10. Click **Insert**.

Tunnel Config field descriptions

Use the data in the following table to use the **Tunnel Config** tab.

Name	Description
AddressType	Shows the address type over which the tunnel encapsulates packets.
LocalAddress	Configures the address of the local endpoint of the tunnel.
RemoteAddress	Configures the address of the remote endpoint of the tunnel.
EncapsMethod	Configures the tunnel mode, which is manual for manually configured tunnels.
ID	Configures the ID for the tunnel.
IfIndex	Shows the value of ifIndex that corresponds to the tunnel interface. A value of 0 indicates that the interface index has not yet been assigned. This field appears only on the Tunnel Config tab.
Ipv6AddressAddr	Specifies the IPv6 address for the local VLAN or brouter port. This field appears only on the Insert Tunnel Config dialog box.
Ipv6AddressPrefixLength	Specifies the number of bits to advertise in the IPv6 address. This field appears only on the Insert Tunnel Config dialog box.

Modifying tunnel hop limits

Modify tunnel hop limits to update hop-limit values on previously configured tunnels.

About this task

The tunnel hop limit configures the value of the time-to-live (TTL) for IPv4 packets.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **Tunnel**.
3. Click the **Tunnel Interface** tab to modify multiple tunnels simultaneously *OR* click the **Tunnel Config** tab, select a tunnel, and then click the **Tunnel Interface** button to modify a specific tunnel.
4. Double-click the **HopLimit** value to modify the information as required.
5. Click **Apply**.

Tunnel Interface field descriptions

Use the data in the following table to use the **Tunnel Interface** tab.

Name	Description
Index	Identifies the tunnel interface internally. The value is derived from the tunnel ID.
EncapsMethod	Displays the encapsulation method for the tunnel: manual for manually configured tunnels and 6to4 for automatically configured tunnels.
HopLimit	Configures the maximum number of hops in the tunnel. The default value is 255.
Security	Indicates the type of security on the tunnel interface.
TOS	Displays the method used to configure the high 6 bits (the differentiated services codepoint) of the IPv4 type of service (TOS) or IPv6 traffic class in the outer IP header. A value of -1 indicates that the bits are copied from the payload header. A value of -2 indicates that a traffic conditioner is invoked and more information can be available in a traffic conditioner MIB module. A value from 0 to 63 indicates that the bit field is configured to the indicated value.
FlowLabel	Displays the method used to configure the IPv6 flow label value. This object is not required where AddressType indicates the tunnel is not over IPv6. A

Table continues...

Name	Description
	value of -1 indicates that a traffic conditioner is invoked and more information can be available in a traffic conditioner MIB. Any other value indicates that the flow label field is configured to the indicated value.
AddressType	Displays manual for a manually configured tunnel, or sixToFour for autoconfigured tunnels.
LocalNetAddress	Identifies the local endpoint address of the tunnel.
RemoteNetAddress	Identifies the remote endpoint of the tunnel.
EncapsLimit	Displays the maximum number of additional encapsulations permitted for packets undergoing encapsulation at this node. A value of -1 indicates that no limit exists, except as a result of the packet size.

Chapter 7: OSPFv3

This chapter provides concepts and procedures to complete IPv6 Open Shortest Path First (OSPF)v3 configuration.

OSPFv3

The Open Shortest Path First Protocol (OSPF) for IPv6, defined in RFC 2740 and RFC 5340, is an Interior Gateway Protocol used to distribute IPv6 routing information within a single Autonomous System (AS).

In IPv6 the term link replaces the IPv4 terms subnet and network. An IPv6 link is a communication medium between nodes at the link layer. You can assign multiple IP subnets (prefixes) to a link. Two IPv6 nodes with common or different prefixes can communicate over a single link.

OSPF for IPv6 operates on each link rather than each subnet as in IPv4. IPv6 makes the following changes to how packets are received and to the contents of network LSAs and hello packets:

- The OSPF packet contains no IPv6 addresses. LSA payloads carried in link state update packets contain IPv6 addresses.
- The following IDs remain at 32-bits and are not assigned IPv6 addresses: area IDs, LSA link state IDs, and OSPF router IDs.
- IPv6 OSPF neighbors use Router IDs to identify neighboring routers on broadcast and nonbroadcast multiaccess (NBMA) networks and for other communication media, point to point.

Flooding scope

LSA flooding scope is generalized in OSPFv3 and coded in the LS type field of the LSA. The following three flooding scopes are available for LSAs:

- Link scope: The LSA is not flooded beyond the local link.
- Area scope: The LSA is flooded in a single OSPF area. Area scope is used in router LSAs, network LSAs, Inter-Area-Prefix-LSAs, Inter-Area-Router LSAs, and Intra-Area-Prefix-LSAs.
- AS scope: The LSA is flooded through the routing domain. AS scope is used for AS external-LSAs.

Link-local addresses

IPv6 uses link-local addresses on a single link. Link-local addresses facilitate features such as neighbor discovery and autoconfiguration. Datagrams with link-local sources are not forwarded. Instead, routers assign link-local unicast addresses from the IPv6 address range.

OSPF for IPv6 does not assign link-local unicast addresses to physical segments attached to a router, it assumes that each router already has link-local unicast addresses assigned. The source for all OSPF packets sent on OSPF physical interfaces is the associated link-local unicast address. Routers learn link-local addresses for all other nodes on links. The nexthop information during packet forwarding includes the learned addresses.

OSPFv3 packets always use link-local addresses as the source and destination, except on a virtual link. All OSPFv3 packets sent over a virtual link use global addresses.

Link LSA is the only OSPF LSA type that includes link-local addresses. Link-local addresses must not be advertised in other LSA types.

Authentication

OSPFv3 for IPv6 requires the IP authentication header and the IP encapsulating security payload for authentication and security.

* Note:

OSPFv3 does not support the authentication feature from OSPFv2.

Packet format

OSPFv3 runs directly over IPv6. All other addressing information is absent in OSPF packet headers. OSPFv3 is network-protocol-independent. LSA types contain addressing information.

OSPFv3 implements the following packet changes from OSPFv2:

- The hello packet and database description packet operations fields are expanded to 24 bits.
- The packet header does not include Authentication and AuType fields.
- The interface ID replaces the address information in the hello packet. The Interface ID becomes the network LSA link-state ID, if the router becomes the designated router on the link.
- Router-bit (R-bit) and V6-bit in the options field process router LSAs during Shortest Path First (SPF) calculation. R-bits and V6-bits determine participation in topology distribution. The V6-bit specializes the R-bit. If the V6-bit is clear, the OSPF speaker can participate in the OSPF topology distribution without forwarding IPv6 datagrams. If the R-bit is set and the V6-bit is clear, the OSPF speaker still does not forward IPv6 datagrams, but it can forward IPv4 datagrams.
- The packet header includes the instance ID, which allows multiple OSPF protocol instances on the same link.

R-bit

Unlike OSPF for IPv4, OSPFv3 for IPv6 supports the R-bit. The R-bit indicates whether the originating node is an active router. If the R-bit is cleared, routes that transit the advertising node cannot be calculated.

For example, if a multi-homed host participates in routing without forwarding non-locally-addressed packets, the R-bit is cleared.

An IPv6-enabled switch can continue to operate as an OSPFv3 neighbor even if you disable IPv6 forwarding on the switch. This behavior differs from IPv4 OSPF, in which the switch drops a neighbor, if IP forwarding on the neighbor is disabled.

LSAs

OSPFv3 includes link LSAs and Intra-Area-Prefix LSAs.

Link LSA:

The link LSA uses link flooding scope, not flooded beyond the associated link.

Link LSAs have three purposes:

- to provide the link-local address of the router to all other nodes on the link
- to provide the list of IPv6 prefixes associated with the link
- to allow the router to associate options bits with the network LSA for the link

Intra-Area-Prefix LSA:

The Intra-Area-Prefix-LSA carries all IPv6 prefix information. In IPv4, this information is in router LSAs and network LSAs.

Unknown LSA types:

In OSPFv3, unknown LSA types are either stored and flooded as though understood or given link flooding scope. Specific behavior is coded in the LS type field of the header.

Link LSA Suppression

To decrease unnecessary link LSA generation and flooding for non-broadcast and non-NBMA interfaces, the Link LSA Suppression interface configuration parameter has been added in RFC 5340. If Link LSA Suppression is configured for an interface, and the interface type is not broadcast or NBMA, the originated link LSA may be suppressed. Link LSA suppression is disabled, by default. For more information on configuration see, [Configuring OSPF on a port or VLAN](#) on page 130.

Stub area

OSPFv3 retains the concept of stub areas, which minimize link-state databases and routing table sizes.

IPv6 stub areas carry only router LSAs, network LSAs, Inter-Area-Prefix-LSAs, link LSAs, and Intra-Area-Prefix-LSAs.

Unlike IPv4, IPv6 can store LSAs with unrecognized link-state (LS) types or flood them as though they are understood. Rules applied to the stub area prevent the excessive growth of the link-state database. An LSA with an unrecognized link state can be flooded only if the LSA uses area- or link-flooding scope, and the LSA U-bit is 1 throughout stub and NSSA areas.

Deprecation of MOSPF for IPV6

OSPFv3 in RFC 5340 deprecates Multicast Extensions to OSPF (MOSPF) support, and its attendant protocol fields.

NSSA Specification

RFC 2740 partially specifies this protocol feature, the level of specification was insufficient to implement it. However, RFC 5340 includes an NSSA specification unique to OSPFv3. This specification coupled with NSSA provide sufficient specification for implementation. Current Infinity

IPv6 OSPF has full support for NSSA feature and is consistent with the additional specifications in RFC 5340.

Stub Area Unknown LSA Flooding Restriction Deprecated

In RFC 2740, flooding of unknown LSA was restricted within stub and NSSA areas. Following were the restrictions:

- Unlike IPv4, in IPv6 you can label unrecognized LS types as "Store and flood the LSA, as if type understood". Uncontrolled introduction of such LSAs could cause a stub area's link-state database to grow larger than its component router's capacities
- To guard the above situation, the following rule regarding stub areas has been established:

An LSA whose LS type is unrecognized can be flooded only into a stub area, if both the LSAs have area or link-local flooding scope, and the LSA has U-bit set to 0

Now the above restrictions have been deprecated. OSPFv3 routers flood link and area scope LSAs whose LS type is unrecognized and U-bit is set to 1 throughout stub and NSSA areas. The only backward compatibility issue is that the OSPFv3 routers still supporting the restrictions may not propagate newly defined LSA types.

LSA Options and Prefix Options Updates

The LSA Options and Prefix Options fields have been updated to reflect recent protocol additions. Specifically, bits related to MOSPF have been deprecated, Options field bits common with OSPFv2 have been reserved, and the DN-bit has been added to the prefix- options.

IPv6 Site-Local Address

All references to IPv6 site-local addresses have been removed in RFC 5340. Infinity IPv6 OSPF does not contain any reference to IPv6 site-local addresses and is already compliant with RFC 5340 for this.

IPsec support with OSPFv3

You can use Internet Protocol Security (IPsec) with OSPFv3 virtual link for the security protection of communication between the end points. You can also use IPsec with OSPFv3 on a brouter port or VLAN interface, for example, if you want to encrypt OSPFv3 control traffic on a broadcast network.

OSPF virtual link provides connectivity to the OSPF backbone area for redundancy or to provide a virtual link if a physical connection is not possible. IPsec only supports IPv6 addresses for this release.

Because the device does not know the IPv6 addresses of the OSPFv3 virtual link end points at the time of configuration, you cannot manually configure the security policy ahead of time. The system must self-manage its security policy dynamically. The device also dynamically manages the IPsec enable flag, which the virtual link uses on a layer 2 interface, either a VLAN or brouter port interface.

The following events can trigger an IPsec policy activation:

1. An OSPFv3 routing module detects the establishment of a virtual link.
2. IPsec is enabled on the already established virtual link.

On the other hand, the following two events can dynamically trigger an IPsec policy deactivation:

1. The virtual link is turn down.
2. IPsec is disabled on the virtual link.

IPsec policies can also change dynamically if a neighbor address or a local address changes.

You can enable IPsec support for IPv6 OSPF virtual link at the system level through ACLI. You must disable IPsec before you can perform virtual link policy configuration changes.

Until you enable IPsec on both sides of the virtual links, the links cannot exchange OSPFv3 control messages, and the system drops OSPFv3 exchange packets.

You can configure the direction you want IPsec to protect, either, ingress, egress, or both. In addition, you can permit or drop communication for the OSPF virtual link.

You can also use IPsec with OSPFv3 on a brouter port or VLAN interface. For a full configuration example and more information on IPsec, see *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601 or *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601.

OSPF Graceful Restart

In the current OSPF networks, OSPF routers removes a restarting OSPF router from the network topology, if the router is restarted. This causes all OSPF routers to re-converge and route around the restarting router. The OSPF Graceful Restart feature is an enhancement to allow an OSPF router to stay on the forwarding path when the software is restarting.

This feature is documented under RFC 3623 for OSPFv2 (IPv4) and RFC 5187 for OSPFv3 (IPv6). The current release supports only helper mode for both OSPFv2 and OSPFv3 protocols.

Helper mode

Helper mode is a part of OSPF Graceful restart feature. It uses the OSPF routers to help other OSPF routers on the network, to stay on the forwarding path while the software is restarting. The OSPF router sends a new type of LSA called a GRACE-LSA to inform the other OSPF routers that it is restarting it's software. When an OSPF router receives a GRACE-LSA from a neighbor OSPF Router, it enters the Helper mode for that neighbor on that network. An OSPF router supports Helper mode by default.

Operations of Helper mode

The following section describes the operations in the Helper mode:

- Entering Helper mode — An OSPF router enters the Helper mode provided the following conditions are true:
 - It is fully adjacent with the neighbor already
 - No changes made in the LSDB, since the neighbor router started

- The grace period has not expired
- Local policy configured parameters allow it to help the neighbor
- It is not in the process of restarting itself

The OSPF router will not help the neighbor, if any of the above conditions are not met.

If the OSPF router is already helping a neighbor, and receives another GRACE-LSA from the neighbor, it should accept the latest GRACE-LSA, and update the grace period accordingly. The OSPF router in Helper mode will continue to advertise its LSAs like the neighbor it is helping is still full, until any changes are made on the network during the grace period.

- Exiting Helper mode — An OSPF router exits the Helper mode, under the following conditions:
 - The GRACE-LSA is flushed. It means graceful restart has successfully terminated
 - The GRACE-LSA's grace period expires
 - There is a network topology change

When an OSPF router exits Helper mode:

- It recalculates the DR for the network
- It re-originates its router LSA
- If it is the DR, it re-originates the network LSA for the network
- If it is a virtual link, it re-originates its router LSA for the virtual link's transit area

ECMP with OSPFv3

The ECMP feature supports and complements OSPFv3 protocol.

With Equal Cost Multipath (ECMP), the Virtual Services Platform can determine up to four equal-cost paths on a VSP 4000 series device and up to eight equal-cost paths on a VSP 8000 or VSP 7000 series device to the same destination prefix. You can use multiple paths for load sharing of traffic. These multiple paths allow faster convergence to other active paths in case of network failure. By maximizing load sharing among equal-cost paths, you can use your links between routers more efficiently when sending IP and IPv6 traffic. Equal Cost Multipath is formed using routes from the same protocol.

 **Note:**

To add OSPFv3 equal cost paths in the routing table, you must first enable IPv6 ECMP feature globally.

OSPFv3 configuration using ACLI

Configuring OSPF globally

Configure OSPFv3 globally to enable it on the system and to configure the router ID.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enable OSPFv3 for IPv6:

```
router ospf ipv6-enable
```

The default is disabled.

3. Log on to OSPF Router Configuration mode:

```
router ospf
```

4. Specify the router ID:

```
ipv6 router-id {A.B.C.D}
```

5. Optionally, make the router an autonomous system (AS) boundary router (BR):

```
ipv6 as-boundary-router enable
```

Enable the ASBR if the router attaches at the edge of the OSPF network, and has one or more interfaces that run an interdomain routing protocol. The default is disabled.

Example

Enable OSPFv3 for IPv6:

```
Switch:1(config)#router ospf ipv6-enable
```

Log on to OSPF Router Configuration mode:

```
Switch:1(config)#router ospf
```

Specify the router ID:

```
Switch:1(config-ospf)#ipv6 router-id 1.1.1.1
```

Variable definitions

Use the data in the following table to use the `ipv6 router-id` command.

Variable	Value
{A.B.C.D}	Specifies a 32-bit integer that identifies the router in the autonomous system. This value must be unique.

Variable	Value
	The default value will be one of the IPv4 interface addresses.

Creating an OSPF area

Create an area to subdivide the autonomous system (AS) into areas that group contiguous networks, routers that connect to these networks, and attached hosts. Subdividing the AS into areas significantly reduces the amount of routing protocol traffic compared to treating the entire AS like a single link-state domain.

About this task

A stub area does not receive advertisements for external routes, which reduces the size of the link-state database (LSDB). A stub area uses only one area border router (ABR). Any packets destined for outside the area are routed to the area border exit point, examined by the ABR, and forwarded to a destination.

A not so stubby area (NSSA) prevents the flooding of AS-External link-state advertisements into the area by replacing them with a default route. NSSAs also import small stub (non- OSPF) routing domains into OSPF.

Procedure

1. Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

2. Specify the area ID:

```
ipv6 area {A.B.C.D}
```

3. Configure optional area parameters if the default values do not meet your requirements:

- a. Configure the area type if you need a stub or NSSA area:

```
ipv6 area {A.B.C.D} type <nssa|stub>
```

By default, the area is a normal area; neither a stub nor NSSA area.

- b. Configure the default cost:

```
ipv6 area {A.B.C.D} default-cost <0-16777215>
```

You do not need to configure this parameter if the area is a normal area.

- c. Configure the area support for importing advertisements:

```
ipv6 area {A.B.C.D} import <external|noexternal|nssa>
```

The default is external.

- d. Disable the importation of summary advertisements into a stub area:

```
no ipv6 area {A.B.C.D} import-summaries enable
```

The default is enabled.

- e. Configure translation of Type 7 LSAs into Type 5 LSAs:

```
ipv6 area {A.B.C.D} translator-role <1-2>
```

The default value is 2—candidate.

Example

Specify the area ID:

```
Switch:1(config-ospf)#ipv6 area 0.0.0.1
```

Variable definitions

Use the data in the following table to use the **ipv6 area** command.

Variable	Value
{A.B.C.D}	Specifies a 32-bit integer to uniquely identify an area. Use 0.0.0.0 for the OSPFv3 backbone.
default-cost <0-16777215>	Configures the metric value advertised for the default route to stub and NSSA areas.
import <external noexternal nssa>	Configures area support for importing AS-external LSAs: <ul style="list-style-type: none"> external—normal area noexternal—stub area nssa—not-so-stubby area AS-scope LSAs are not imported into stub areas or NSSAs. NSSAs import AS-External data at Type 7 LSAs, which use area scope. The default is external.
import-summaries enable	Controls the import of inter-area LSAs into a stub area. If you disable this parameter, the router does not originate nor propagate inter-area LSAs into the stub area. If you enable this parameter (the default), the router both summarizes and propagates inter-area LSAs.
<nssa stub>	Configures the type of area. By default, the area is neither a stub area or an NSSA.
translator-role <1-2>	Indicates if the NSSA border router can perform NSSA translation of Type 7 LSAs to Type 6 LSAs. The possible values are always (1) or candidate (2). The default is candidate (2).

Creating OSPF area ranges

Create an area address range on the OSPF router to reduce the number of area border router (ABR) advertisements into other OSPF areas. An area address range is an implied contiguous range of area network addresses for which the ABR advertises a single summary route.

Before you begin

- You must create the OSPF area.

About this task

If you create two ranges, and one range is a subset of the other, the router uses the most specific match.

Procedure

- Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

- Create an area range:

```
ipv6 area range {A.B.C.D} WORD<0-255> [inter-area-prefix-link|nssa-
extlink] advertise-mode <advertise|not-advertise> [advertise-metric
<0-65535>]
```

Example

Create an area range:

```
Switch:1(config-ospf)#ipv6 area range 0.0.0.1 3000::0/16 advertise-mode
advertise
```

Variable definitions

Use the data in the following table to use the **ipv6 area range** command.

Variable	Value
{A.B.C.D}	Specifies the area in which the address aggregate exists. Use dotted decimal notation to specify the area name.
advertise-metric <0-65535>	Specifies a cost value to advertise for the OSPF area range. This value applies to summary LSAs (Type 3). If the value is 0, OSPF uses the cost to the farthest point in the network that is summarized.
advertise-mode <advertise not-advertise>	Specifies the advertisement mode for prefixes in the range. advertise advertises the aggregate summary

Table continues...

Variable	Value
	LSA with the same link-state ID. not-advertise does not advertise networks that fall within the range. The default is advertise.
<inter-area-prefix-link nssa-extlink>	Specifies the area LSDB type to which the address aggregate applies. inter-area-prefix-link generates an aggregated summary. nssa-extlink generates an NSSA link summary.
WORD<0-255>	Specifies the IPv6 address and prefix.

Creating an OSPF virtual link

Create a virtual link if the switch does not connect directly to the backbone. The switch can create automatic virtual links or you can perform this procedure to create virtual links manually. Manual virtual links conserve resources and provide specific control over virtual link placement in your OSPF configuration.

Before you begin

- The router must be an ABR to create a virtual router interface.

About this task

Virtual linking is similar to backup redundancy. The switch creates a virtual link for vital traffic paths in your OSPF configuration if traffic is interrupted, such as when an interface cable that provides a connection to the backbone (either directly or indirectly) is disconnected from the switch. Automatic virtual linking ensures that a link is created by using another switch.

OSPF routes cannot be learned through an ABR unless it connects to the backbone directly or through a virtual link.

Procedure

- Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

- Create a virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D}
```

- Configure optional parameters for the virtual link if the default values do not meet your requirements:

- Configure the router dead interval:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} dead-interval
<1-65535>
```

The default is 60 seconds.

b. Configure the hello interval:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} hello-interval
<1-65535>
```

The default is 10 seconds.

c. Configure the retransmit interval:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} retransmit-interval
<1-1800>
```

The default is 5 seconds.

d. Configure the transit delay:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} transit-delay
<1-1800>
```

The default is 1 second.

Example

Create a virtual link:

```
Switch:1(config-ospf)#ipv6 area virtual-link 0.0.0.1 2.2.2.2
```

Configure optional parameters for a virtual link:

```
Switch:1(config-ospf)#ipv6 area virtual-link 0.0.0.1 4.4.4.4 dead-
interval 90 retransmit-interval 10
```

Variable definitions

Use the data in the following table to use the `ipv6 area virtual-link` command.

Variable	Value
{A.B.C.D} {A.B.C.D}	Specifies the ID for the transit area that the virtual link traverses and the router ID of the virtual neighbor. Do not use 0.0.0.0 for the transit area.
dead-interval <1-65535>	Specifies the number of seconds after which the neighbor declares the router down if it does not receive hello packets. Configure this value as a multiple of the hello interval. You must configure the same value on the virtual neighbor. The default is 60 seconds.
hello-interval <1-65535>	Specifies the number of seconds between hello packets that the router sends on this interface. Configure the same value on the virtual neighbor. The default is 10 seconds.
retransmit-interval <1-1800>	Specifies the number of seconds between link-state advertisement retransmissions for adjacencies that

Table continues...

Variable	Value
	belong to this interface. This value also applies to the retransmissions of database description and link-state request packets. The default is 5 seconds.
transit-delay <1-1800>	Specifies the estimated number of seconds to transmit a link-state update packet over this interface. The default is 1 second.

Configuring IPsec for the OSPF virtual link

Use the following procedure to configure and enable IPsec for the OSPF virtual link.

The device only supports IPsec for IPv6 traffic, and an interface must support IPv6 to apply IPsec.

IPsec is disabled by default.

Before you begin

- Configure the OSPF virtual link.
- Create the IPsec security association. For more information on configuration of IPsec security associations and IPsec policies, and how to enable policies on an interface, see *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601 or *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601 .

About this task

Until you enable IPsec on both sides of the virtual links, the links cannot exchange OSPFv3 control messages, and the system drops OSPFv3 exchange packets.

You must disable IPsec before you can perform virtual link policy configuration changes.

For configuration examples of IPsec used with OSPFv3 virtual link, see *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601 or *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601.

Procedure

1. Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

2. Create the IPsec policy under the OSPF virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} ipsec
```

3. Configure the action of the IPsec policy under the OSPF virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} ipsec action <drop|
permit>
```

4. Configure the direction of the IPsec policy under the OSPF virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} ipsec direction <both|in|out>
```

5. Link the security association to the OSPF virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} ipsec security-association WORD<0-32>
```

6. Enable the IPsec policy created under the OSPF virtual link:

```
ipv6 area virtual-link {A.B.C.D} {A.B.C.D} ipsec enable
```

Example

```
Switch:1>enable
Switch:1#configure terminal
Switch:1#(config)router ospf
Switch:1(config-ospf)#ipv6 area virtual-link 1.1.1.1 2.2.2.2 ipsec
Switch:1(config-ospf)#ipv6 area virtual-link 1.1.1.1 2.2.2.2 ipsec action permit
Switch:1(config-ospf)#ipv6 area virtual-link 1.1.1.1 2.2.2.2 ipsec direction both
Switch:1(config-ospf)#ipv6 area virtual-link 1.1.1.1 2.2.2.2 ipsec security-association test1
Switch:1(config-ospf)#ipv6 area virtual-link 1.1.1.1 2.2.2.2 ipsec enable
```

Variable definitions

Use the data in the following table to use the **ipv6 area virtual link {A.B.C.D} {A.B.C.D} ipsec** command.

Variable	Value
{A.B.C.D}{A.B.C.D}	The first IP address specifies the area IP address, and the second IP address specifies the virtual-link IP address.
action <drop permit>	Configures the action of the IPsec policy under the OSPF virtual tunnel to one of the following: <ul style="list-style-type: none"> drop—Drops the IP packets. permit—Permits the IP packets. The default is permit.
direction <both in out>	Specifies the direction you want to protect with IPsec: <ul style="list-style-type: none"> in—Specifies ingress traffic. out—Specifies egress traffic. both—Specifies both ingress and egress traffic. The default is both.
enable	Enables the IPsec policy under the OSPF virtual link.
security-association WORD<0-32>	Links the security association to the OSPF virtual link.

Configuring OSPF default metrics

About this task

Use the following procedure to configure global OSPF default metrics.

Procedure

1. Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

2. Configure OSPF default-cost:

For VSP 7200 Series and VSP 8000 Series:

```
ipv6 default-cost [{ethernet|fast-ethernet|gig-ethernet|ten-gig-ethernet|forty-gig-ethernet|vlan} <1-65535>]
```

For VSP 4000 Series:

```
ipv6 default-cost [{ethernet|fast-ethernet|gig-ethernet|ten-gig-ethernet|vlan} <1-65535>]
```

Example

Configure IPv6 default cost metric for Ethernet to 100, for fast Ethernet to 10, for gig-Ethernet and ten-gig-Ethernet to 1, and VLAN to 1.

```
Switch:1>enable
Switch:1#configure terminal
Switch:1(config)#router ospf
Switch:1(config-ospf)#ipv6 default-cost ethernet 100
Switch:1(config-ospf)#ipv6 default-cost fast-ethernet 10
Switch:1(config-ospf)#ipv6 default-cost gig-ethernet 1
Switch:1(config-ospf)#ipv6 default-cost ten-gig-ethernet 1
Switch:1(config-ospf)#ipv6 default-cost Forty-gig-ethernet 1
Switch:1(config-ospf)#ipv6 default-cost vlan 1
```

Variable definitions

Use the data in the following table to use the `ipv6 default-cost` command.

Variable	Value
ethernet <1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. ethernet is for 10 Mb/s Ethernet (default is 100).

Table continues...

Variable	Value
fast-ethernet <1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. fast-ethernet is for 100 Mb/s Fast-Ethernet (default is 100).
gigabit-ethernet <1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. gigabit-ethernet is for 10 Mb/s Gigabit-Ethernet (default is 1).
ten-gig-ethernet <1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. ten-gig-ethernet is for 10 Mb/s Ten-Gigabit-Ethernet (default is 1).
forty-gig-ethernet <1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. forty-gig-ethernet is for 10 Mb/s Forty-Gigabit-Ethernet (default is 1).
vlan<1-65535>	Configures the IPv6 OSPF default metrics. The range is 1–65535. vlan is for Vlan interfaces (default is 10).

Configuring OSPF on a port or VLAN

Configure the OSPF protocol on IPv6 interface to support dynamic routing on the interface.

Before you begin

- The IPv6 interface must exist.

Procedure

1. Enter Interface Configuration mode:

```
enable
```

```
configure terminal
```

```
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-port]][, ...]} OR interface vlan <1-4059>
```

*** Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Create an OSPF area on the interface:

```
ipv6 ospf area {A.B.C.D}
```

3. Enable OSPFv3 on the interface:

```
ipv6 ospf enable
```

The default is disabled.

4. Configure optional parameters to meet your requirements:

- a. Configure the interface metric:

```
ipv6 ospf cost <0-65535>
```

The default for a brouter port or VLAN is 1.

- b. Configure the router dead interval:

```
ipv6 ospf dead-interval <1-65535>
```

The default is 40 seconds.

- c. Configure the hello interval:

```
ipv6 ospf hello-interval <1-65535>
```

The default is 10 seconds.

- d. Configure the link LSA suppression:

```
ipv6 ospf link-lsa-suppression
```

*** Note:**

Before configuring Link LSA suppression for OSPF, configure Link LSA suppression for OSPF area for point to point (p2p) or point to multipoint interfaces (p2mp), otherwise it defaults to a broadcast interface type where you cannot use Link LSA suppression.

- e. Configure the poll interval:

```
ipv6 ospf poll-interval <0-65535>
```

The default is 120 seconds.

- f. Configure the interface priority:

```
ipv6 ospf priority <0-255>
```

The default is 1.

- g. Configure the retransmit interval:

```
ipv6 ospf retransmit-interval <1-1800>
```

The default is 5 seconds.

h. Configure the transit delay:

```
ipv6 ospf transit-delay <1-1800>
```

The default is 1 second.

Example

Create an OSPF area on the interface:

```
Switch:1(config-if)#ipv6 ospf area 0.0.0.0
```

Enable OSPFv3 on the interface:

```
Switch:1(config-if)#ipv6 ospf enable
```

Variable definitions

Use the data in the following table to use the `ipv6 ospf` command.

Variable	Value
area {A.B.C.D}	Specifies the area ID to which the IPv6 interface connects. Use 0.0.0.0 for the OSPFv3 backbone.
cost <0-65535>	Specifies the cost for the interface. A value of zero indicates the metric value depends on the speed of the interface, when the state of the interface is up. The default for a brouter port or VLAN is 1.
dead-interval <1-65535>	Specifies the number of seconds after which the neighbor declares the router down, if it does not receive hello packets. Configure this value as a multiple of the hello interval. You must configure the same value on the virtual neighbor. The default is 40 seconds.
enable	Specifies the administrative status for the OSPFv3 interface. If you enable the status, it is advertised as an interal route to some areas. If you disable the status, the interface is external to OSPFv3. The default is disabled.
hello-interval <1-65535>	Specifies the number of seconds between hello packets that the router sends on this interface. Configure the same value on the virtual neighbor. The default is 10 seconds.

Table continues...

Variable	Value
link-lsa-suppression	Configures link LSA suppression on the specified port or VLAN. It is only used for point to point or point to multipoint interfaces. By default, it is disabled.
poll-interval <0-65535>	Specifies the number of seconds between hello packets sent to an inactive NBMA neighbor. The default is 120.
priority <0-255>	Specifies the priority of this interface. Multiaccess networks use the priority in the designated router election. A higher priority value increases the chance the router becomes the designated router. A value of zero (0) indicates the router cannot become the designated router for the network. If more than one router uses the same priority value, the router ID determines the designated router. The default is 1.
retransmit-interval <1-1800>	Specifies the number of seconds between link-state advertisement retransmissions for adjacencies that belong to this interface. This value also applies to the retransmissions of database description and link-state request packets. The default is 5 seconds.
transit-delay <1-1800>	Specifies the estimated number of seconds to transmit a link-state update packet over this interface. The default is 1 second.

Use the data in the following table to use the **interface** command.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.
{slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Configuring OSPF on a tunnel

Configure the OSPF protocol on IPv6 interface to support dynamic routing on the interface.

Before you begin

- The IPv6 interface must exist.

Procedure

1. Enter OSPF Router Configuration mode:

```
enable
configure terminal
router ospf
```

2. Create an OSPF area on the interface:

```
ipv6 tunnel <1-2000> area {A.B.C.D}
```

3. Enable OSPFv3 on the interface:

```
ipv6 tunnel <1-2000> enable
```

4. Configure optional parameters to meet your requirements:

- a. Configure the router dead interval:

```
ipv6 tunnel <1-2000> dead-interval <1-65535>
```

The default is 40 seconds.

- b. Configure the hello interval:

```
ipv6 tunnel <1-2000> hello-interval <1-65535>
```

The default is 10 seconds.

- c. Configure the interface metric:

```
ipv6 tunnel <1-2000> metric <0-65535>
```

- d. Configure the poll interval:

```
ipv6 tunnel <1-2000> poll-interval <0-65535>
```

The default is 120 seconds.

- e. Configure the interface priority:

```
ipv6 tunnel <1-2000> priority <0-255>
```

The default is 1.

- f. Configure the retransmit interval:

```
ipv6 tunnel <1-2000> retransmit-interval <1-1800>
```

The default is 5 seconds.

g. Configure the transit delay:

```
ipv6 tunnel <1-2000> transit-delay <1-1800>
```

The default is 1 second.

Example

Create an OSPF area on the interface:

```
Switch:1(config-if)#ipv6 tunnel 4 area 0.0.0.0
```

Enable OSPFv3 on the interface:

```
Switch:1(config-if)#ipv6 tunnel 4 enable
```

Variable definitions

Use the data in the following table to use the `ipv6 tunnel` command.

Variable	Value
<1-2000>	Specifies the tunnel ID.
area {A.B.C.D}	Specifies the area ID to which the IPv6 interface connects. Use 0.0.0.0 for the OSPFv3 backbone.
dead-interval <1-65535>	Specifies the number of seconds after which the neighbor declares the router down if it does not receive hello packets. Configure this value as a multiple of the hello interval. + Tip: You must configure the same value on the virtual neighbor. The default is 40 seconds.
enable	Specifies the administrative status for the OSPFv3 interface. If you enable the status, it is advertised as an internal route to some areas. If you disable the status, the interface is external to OSPFv3. The default is enabled.
hello-interval <1-65535>	Specifies the number of seconds between hello packets that the router sends on this interface. + Tip: You must configure the same value on the virtual neighbor.

Table continues...

Variable	Value
	The default is 10 seconds.
metric <0-65535>	Specifies the cost for the interface. A value of zero indicates the metric value depends on the speed of the interface, when the state of the interface is up. The default for a tunnel is 100.
poll-interval <0-65535>	Specifies the number of seconds between hello packets sent to an inactive NBMA neighbor. The default is 120.
priority <0-255>	Specifies the priority of this interface. Multiaccess networks use the priority in the designated router election. A higher priority value increases the likelihood that the router becomes the designated router. A value of zero (0) indicates the router cannot become the designated router for the network. If more than one router uses the same priority value, the system uses the router ID to determine which router becomes the designated router. The default is 1.
retransmit-interval <1-1800>	Specifies the number of seconds between link-state advertisement retransmissions for adjacencies that belong to this interface. The retransmit-interval value also applies to the retransmissions of database description and link-state request packets. The default is 5 seconds.
transit-delay <1-1800>	Specifies the estimated number of seconds required to transmit a link-state update packet over this interface. The default is 1 second.

Viewing OSPFv3 information

View information about OSPF to view the current configuration.

Procedure

1. Enter Privileged EXEC mode:

```
enable
```


2. View OSPF global information:

```
show ipv6 ospf
```

3. View OSPF areas:

```
show ipv6 ospf area
```

4. View OSPF interface information

```
show ipv6 ospf interface [gigabitEthernet {slot/port[sub-port]}|vlan
<1-4059>]
```

5. View OSPF interface timers:

```
show ipv6 ospf int-timers
```

6. View the link-state database (LSDB) table:

```
show ipv6 ospf lsdb [adv-rtr <A.B.C.D>] [area <A.B.C.D>] [interface
gigabitEthernet {slot/port[sub-port]}|vlan <1-4059> ] [lsa-type
<1-8>] [lsid <0-4294967295>] [scope <1-3>] [tunnel <1-2000>]
[detail]
```

7. View OSPF neighbors to see routers with interfaces to a common network, including neighbors on the virtual link to the OSPF backbone:

```
show ipv6 ospf neighbor
```

Example

```
Switch:1#show ipv6 ospf
```

```
=====
                        OSPFv3 Global Information
=====
router-id                : 170.66.72.0
admin-state              : DISABLE
version                  : 3
area-bdr-rtr-state      : FALSE
as-bdr-rtr-state        : FALSE
helper-mode              : ENABLED
as-scope-lsa-count      : 0
lsa-checksum             : 0
originate-new-lsas      : 0
rx-new-lsas              : 0
ext-lsa-count           : 0
```

```
Switch:1>show ipv6 ospf area
```

```
=====
                        OSPF Area
=====
AREA_ID      STUB_AREA  NSSA  IMPORT_SUM  TRANS_ROLE
-----
0.0.0.0      false      false true         always
STUB_METRIC  SPF_RUNS  BDR_RTR_CNT  ASBDR_RTR_CNT  LSA_CNT  LSACK_SUM
-----
10           0         0           0             0         0
```

```
Switch:1#show ipv6 ospf interface
```

```
Total ospf areas: 1
Total ospf interfaces: 2
```

OSPFv3

```

=====
                        OSPF Interface
=====
IFINDX(VID/BRT)  AREAID          ADM IFSTATE  METRIC PRI DR/BDR          IFTYPE
-----
331   (5/12   ) 0.0.0.0          ena DOWN     1     1  0.0.0.0          PT-PT
                                0.0.0.0          lnklsaSup
2078  (30     ) 0.0.0.0          ena DR       1     1  197.146.128.0   BROADCAST
                                0.0.0.0
=====
2 out of 2 Total Num of ospf interfaces displayed
Total ospf virtual interfaces: 0

```

Switch:1#show ipv6 ospf int-timers

```

=====
                        OSPF Interface Timers
=====
IFINDX(VID/BRT)  AREAID          TRANSIT  RETRANS  HELLO    DEAD    POLL
                  DELAY          INTERVAL INTERVAL INTERVAL INTERVAL INTERVAL
-----
2059  (11     ) 0.0.0.0          1         5        10       40      120
2060  (12     ) 0.0.0.0          1         5        10       40      120
=====
                        OSPF Virtual Interface Timers
=====
AREAID          NBRIPADDR          TRANSIT  RETRANS  HELLO    DEAD
                  DELAY          INTERVAL INTERVAL INTERVAL INTERVAL
-----

```

Switch:1#show ipv6 ospf neighbor

```

=====
                        OSPF Neighbor
=====
IFINDX(VID/BRT)  NBRROUTERID      NBRIPADDR          STATE          TTL
-----
331   (10/19) 97.146.128.0     fe80:0:0:0:2ef4:c5ff:fe92:8a00  Restart       120
=====
1 out of 1 Total Num of Neighbor Entries displayed.

```

```

=====
                        OSPF Virtual Neighbor
=====
NBRAREAID      NBRROUTERID      VIRTINTFID NBRIPV6ADDR
STATE
-----
0 out of 0 Total Num of Virtual Neighbor Entries displayed.

```

```

=====
                        OSPF NBMA Neighbor
=====
INTERFACE NBRROUTERID      NBRIPADDR          STATE
-----
0 out of 0 Total Num of NBMA Neighbor Entries displayed.

```

OSPF NBMA Neighbor

```
=====
INTERFACE NBRROUTERID          NBRIPADDR          STATE
=====
0 out of 0 Total Num of NBMA Neighbor Entries displayed.
```

Variable definitions

Use the data in the following table to use the `show ipv6 ospf lsdb` commands.

Variable	Value
adv-rtr <A.B.C.D>	Shows information for the specified advertising router.
area <A.B.C.D>	Shows information for the specified area.
detail	Shows information beyond the basic information.
{slot/port[/sub-port]}	Identifies a single slot and port. If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
lsa-type <1-8>	Shows information for the specified LSA type.
lsid <0-4294967295>	Shows information for the specified link-state ID.
scope <1-3>	Shows information for the specified scope: <ol style="list-style-type: none"> 1. link-scope LSAs-View the link-scope LSDB to view the LSAs that are not flooded beyond the local link. 2. area-scope LSAs-View the area-scope LSDB to see the LSAs that are flooded in a single OSPF area. Area scope is used in router LSAs, network LSAs, Inter-Area-Prefix-LSAs, Inter-Area-Router LSAs, and Intra-Area-Prefix-LSAs. 3. AS-scope LSAs-View the AS-scope LSDB to see the LSAs that are flooded through the routing domain. The AS scope is used for ASexternal- LSAs.
tunnel <1-2000>	Specifies the ID number of the tunnel.
vlan <1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.

Viewing OSPFv3 default cost information

About this task

Use the following procedure to View the OSPF default cost information, to ensure accuracy.

Procedure

1. Enter Privileged EXEC mode:


```
enable
```
2. View the OSPF cost information:


```
show ipv6 ospf default-cost
```

Example

For VSP 8000 Series:

```
Switch:1#show ipv6 ospf default-cost
=====
                        IPv6 OSPF Default Metric
=====
10MbpsPortDefaultMetric: 100
100MbpsPortDefaultMetric: 10
1000MbpsPortDefaultMetric: 1
10000MbpsPortDefaultMetric: 1
40000MbpsPortDefaultMetric: 1
VlanDefaultMetric: 10
```

Adding an NBMA neighbor

Add an NBMA neighbor for each interface that is eligible to become the DR.

An NBMA interface with a positive nonzero router priority is eligible to become the DR for the NBMA network and is configured with the identification of all attached routers, IPv6 addresses, and router priorities.

Before you begin

- Identify the following information:
 - specific interfaces to include in the NBMA network
 - the IPv6 address for each interface
 - the router priority for each interface
 - the hello interval for the network
 - the router dead interval for the network
 - the poll interval for the network

About this task

In contrast to a broadcast network where switches multicast (send to AllSPFRouters and AllDRouters) certain OSPF protocol packets, switches replicate and send NBMA packets to each neighboring router as unicast. NBMA networks drop all OSPF packets with destination addresses AllSPFRouters and AllDRouters. Because the NBMA network does not broadcast, you must manually configure a list of neighbors and priorities for all routers in the network that can become the DR. Potential DRs use a positive nonzero router priority.

Procedure

1. Enter Interface Configuration mode:

```
enable
configure terminal
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-port]] [, ...]} or interface vlan <1-4059>
```

*** Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Create a new NBMA neighbor:

```
ipv6 ospf nbma-nbr WORD<0-43> <0-255>
```

3. Change the priority of an existing NBMA neighbor:

```
ipv6 ospf nbma-nbr WORD<0-43> priority <0-255>
```

Example

Create an NBMA neighbor that will not become the DR:

```
Switch:1(config-if)#ipv6 ospf nbma-nbr fe80:0:0:0:8217:7dff:fe76:8a03 0
```

Variable definitions

Use the data in the following table to use the `ipv6 ospf nbma-nbr` command.

Variable	Value
priority <0-255>	Specifies the priority to use for this neighbor in the designated router election process. A value of 0 indicates the neighbor cannot become the designated router. The higher the priority value, the higher chance the switch will win the election process. The default is 1.
WORD<0-43>	Specifies the IPv6 address of the neighbor.

Configuring link LSA suppression

About this task

Use the following procedure to configure link LSA suppression on a port or a VLAN, to decrease unnecessary link LSA generation and flooding for non-broadcast and non-NBMA interface.

Procedure

1. Enter Interface Configuration mode:

```
enable
```

```
configure terminal

interface GigabitEthernet {slot/port[/sub-port]}[-slot/port[/sub-
port]][,...]} or interface vlan <1-4059>
```

*** Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Enter the following command:

```
ipv6 ospf area {A.B.C.D} network {p2p | p2mp} link-lsa-suppression
```

Example

Variable definitions

Following table describes the variables to the `ipv6 ospf area {A.B.C.D} network p2p link-lsa-suppression` command.

Variable	Description
<i>area {A.B.C.D}</i>	Create an IPv6 OSPF area.
<i>network</i>	Sets the type of interface.
<i>[eth NBMA p2mp p2p passive]</i>	Specifies the type of interface.
<i>link-lsa-suppression</i>	Enables link LSA suppression.

Enabling OSPF route redistribution

Enable redistribution to announce routes, of a certain source protocol type, into the OSPFv3 domain.

You can redistribute directly connected routes, IS-IS routes, and static routes into OSPFv3.

About this task

If you do not configure a redistribution entry, the switch generates external LSAs for non-OSPF routes.

Procedure

1. Enter OSPF Router Configuration mode:

```
enable

configure terminal

router ospf
```

2. Enable IPv6 router redistribution:

```
ipv6 redistribute <bgp|direct|isis|rip|static> enable
```

Example

Announce IPv6 static routes into the OSPFv3 domain:

```
Switch:1(config-ospf)#ipv6 redistribute static enable
```

Variable definitions

Use the data in the following table to use the `ipv6 redistribute` command.

Variable	Value
<direct isis static>	Shows the source protocol from which to receive routes to insert into the OSPFv3 domain. The possibilities are direct routes, IS-IS routes, and static routes. By default, no routes are announced. Route redistribution is disabled.

Viewing the status of OSPFv3 redistribution

View the status of OSPFv3 route redistribution to verify the current configuration. You can redistribute directly connected routes and IPv6 static routes into OSPFv3.

Procedure

1. Enter Privileged EXEC mode:
enable
2. View the current configuration:
show ipv6 ospf redistribute

Example

```
Switch:1#show ipv6 ospf redistribute
```

```
=====
                        OSPF Redistribute List
=====
  direct                : disabled
  static                : disabled
=====
```

Disabling Helper mode for OSPFv3**About this task**

By default, OSPF Helper mode is enabled when OSPF is configured. You can disable helper mode by the following command and re-enable it again by using “no” or “default” commands.

Procedure

1. Enter OSPF Router Configuration mode:
enable
configure terminal
router ospf
2. Enter the following command to disable Helper mode:
ipv6 helper-mode-disable
3. Enter the following command to enable Helper mode:
no ipv6 helper-mode-disable
Or
default ipv6 helper-mode disable

Example

Disabling Helper mode:

```
Switch:1>enable
Switch:1#configure terminal
Switch:1(config)#router ospf
Switch:1(config-ospf)#ipv6 helper-mode-disable
```

Enabling Helper mode:

```
Switch:1>enable
Switch:1#configure terminal
Switch:1(config)#router ospf
Switch:1(config-ospf)#no ipv6 helper-mode-disable
```

OSPFv3 configuration using EDM

Configuring OSPF globally

Configure OSPFv3 globally to enable it on the system and to configure the router ID.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Globals** tab.
4. Type the router ID, in the format of an IPv4 address.
5. Select **enabled**.

6. Optionally, select **ASBdrRtrStatus** to make the router an AS boundary router.

Enable the ASBR if the router attaches at the edge of the OSPF network, and has one or more interfaces that run an interdomain routing protocol. The default is disabled.

7. Click **Apply**.

Globals field descriptions

Use the data in the following table to use the **Globals** tab.

Name	Description
RouterId	Specifies a 32-bit integer that identifies the router in the autonomous system. This value must be unique. The default value will be one of the IPv4 interface addresses.
AdminStat	Enables or disables OSPFv3 on the router. If you disable OSPFv3 globally, you disable it on all interfaces. The default is disabled.
VersionNumber	Shows the OSPF version number, which for IPv6 is version 3.
AreaBdrRtrStatus	Shows if the router is an area border router.
ASBdrRtrStatus	Configures the router as an autonomous system boundary router. The default is disabled (clear).
AsScopeLsaCount	Shows the number of AS-external link-state advertisements in the LSDB.
AsScopeLsaCksumSum	Shows the sum of the checksums for the link-scope LSAs in the LSDB. Use the sum to determine if a change in the LSDB occurs, and to compare the LSDBs of the two routers.
OriginateNewLsas	Shows the number of new link-state advertisements. The number increases each time the router originates a new LSA.
RxNewLsas	Shows the number of new link-state advertisements received. This number does not include new instances of self-originated link-state advertisements.
ExtLsaCount	Shows the number of external (LS type 0x4005) LSAs in the LSDB.
10MbpsPortDefaultMetric	Indicates the default cost applied to 10 Mb/s interfaces (ports). The default is 100.
100MbpsPortDefaultMetric	Indicates the default cost applied to 100 Mb/s interfaces (ports). The default is 10.
1000MbpsPortDefaultMetric	Indicates the default cost applied to 1000 Mb/s interfaces (ports). The default is 1.

Table continues...

Name	Description
10000MbpsPortDefaultMetric	Indicates the default cost applied to 10000 Mb/s interfaces (ports). The default is 1.
40000MbpsPortDefaultMetric	Indicates the default cost applied to 40000 Mb/s interfaces (ports). The default is 1.
vlanDefaultMetric	Indicates the default cost applied to VLAN interfaces. The default is 10.

Creating an OSPF area

Create an area to subdivide the autonomous system (AS) into areas that group contiguous networks, routers that connect to these networks, and attached hosts. Subdividing the AS into areas significantly reduces the amount of routing protocol traffic compared to treating the entire AS like a single link-state domain.

About this task

A stub area does not receive advertisements for external routes, which reduces the size of the link-state database (LSDB). A stub area uses only one area border router (ABR). Any packets destined for outside the area are routed to the area border exit point, examined by the ABR, and forwarded to a destination.

A not so stubby area (NSSA) prevents the flooding of AS-External link-state advertisements into the area by replacing them with a default route. NSSAs also import small stub (non- OSPF) routing domains into OSPF.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Areas** tab.
4. Click **Insert**.
5. Type the area ID.
6. Click **Insert**.

Areas field descriptions

Use the data in the following table to use the **Areas** tab.

Name	Description
Id	Specifies a 32-bit integer to uniquely identify an area. Use 0.0.0.0 for the OSPFv3 backbone.

Table continues...

Name	Description
ImportasExtern	<p>Indicates the support for importing AS-external LSAs::</p> <ul style="list-style-type: none"> • importExternal—normal area • importNoExternal—stub area • importNssa—not-so-stubby-area <p>AS-scope LSAs are not imported into stub areas or NSSAs. NSSAs import AS-External data at Type 7 LSAs, which use area scope. importExternal is the default.</p>
SpfRuns	Shows the number of times the intra-area route table was calculated using the LSDB of this area.
BdrRtrCount	Shows the number of reachable ABRs in this area. The value starts at zero (0). The system calculates this value in each SPF run.
AsBdrRtrCount	Shows the number of reachable ASBRs in this area. The value starts at zero (0). The system calculates this value in each SPF run.
ScopeLsaCount	Shows the number of area-scope LSAs in the LSDB for this area.
ScopeLsaCksumSum	Shows the sum of the checksums for the area-scope LSAs in the LSDB. Use the sum to determine if a change in the LSDB occurs, and to compare the LSDBs of the two routers.
Summary	Controls the import of inter-area LSAs into a stub area. If the value is noAreaSummary , the router does not originate nor propagate inter-area LSAs into the stub area. If the value is sendAreaSummary (the default), the router both summarizes and propagates inter-area LSAs.
StubMetric	Configures the metric value advertised for the default route to stub and NSSA areas.
NssaTranslatorRole	Indicates if the NSSA border router can perform NSSA translation of Type 7 LSAs to Type 6 LSAs. The possible values are always or candidate. The default is candidate.
NssaTranslatorState	<p>Indicates if and how an NSSA border router translates Type 7 LSAs to Type 5 LSAs. The possible values are</p> <ul style="list-style-type: none"> • enabled—The border router always translates the LSAs. • elected—A candidate border router translates the LSAs.

Table continues...

Name	Description
	<ul style="list-style-type: none"> • disabled—A candidate border router does not translate the LSAs.
StubMetricType	<p>Specifies the type of metric advertised as a default route. The possible values are:</p> <ul style="list-style-type: none"> • ospfv3Metric—OSPF metric • comparableCost—external Type 1 • nonComparable—external Type 2 <p>The default is ospfv3Metric.</p>

Creating OSPF area ranges

Create an area address range on the OSPF router to reduce the number of area border router (ABR) advertisements into other OSPF areas. An area address range is an implied contiguous range of area network addresses for which the ABR advertises a single summary route.

Before you begin

- You must create the OSPF area.

About this task

If you create two ranges, and one range is a subset of the other, the router uses the most specific match.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Area Aggregate** tab.
4. Click **Insert**.
5. Select the area ID.
6. Select the type of area.
 - interAreaPrefixLsa** generates an aggregated summary.
 - nssaExternalLink** generates an NSSA link summary.
7. Type the prefix for the IPv6 area address.
8. Type the number of bits from the IPv6 address that you want to advertise.
9. Click **Insert**.

Area Aggregate field descriptions

Use the data in the following table to use the **Area Aggregate** tab.

Name	Description
AreaID	Specifies the area in which the address aggregate exists. Use dotted decimal notation to specify the area name.
AreaLsdbType	Specifies the area LSDB type to which the address aggregate applies. interAreaPrefixLsa generates an aggregated summary. nssaExternalLink generates an NSSA link summary.
Prefix	Specifies the IPv6 prefix. The prefix and prefix length define the range.
PrefixLength	Specifies the length of the prefix, in bits. The prefix cannot be shorter than 3 bits. The prefix and prefix length define the range.
Effect	Specifies the advertisement mode for prefixes in the range. advertiseMatching advertises the aggregate summary LSA with the same link-state ID. doNotAdvertiseMatching does not advertise networks that fall within the range.
AdvertiseMetric	Specifies a cost value to advertise for the OSPF area range. This value applies to summary LSAs (Type 3). If the value is 0, OSPF uses the cost to the farthest point in the network that is summarized.

Creating an OSPF virtual link

Create a virtual link if the switch does not connect directly to the backbone. The switch can create automatic virtual links or you can perform this procedure to create virtual links manually. Manual virtual links conserve resources and provide specific control over virtual link placement in your OSPF configuration.

Before you begin

- The router must be an ABR to create a virtual router interface.

About this task

Virtual linking is similar to backup redundancy. The switch creates a virtual link for vital traffic paths in your OSPF configuration if traffic is interrupted, such as when an interface cable that provides a connection to the backbone (either directly or indirectly) is disconnected from the switch. Automatic virtual linking ensures that a link is created by using another switch.

OSPF routes cannot be learned through an ABR unless it connects to the backbone directly or through a virtual link.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.

3. Click the **Virtual If** tab.
4. Click **Insert**.
5. Specify the ID for the transit area.

The transit area is the common area between two ABRs.

6. Specify the router ID for the virtual neighbor.

The neighbor ID is the IP router ID of the ABR through which the other ABR must route traffic destined for the backbone.

7. Click **Insert**.
8. Click **Refresh** to verify that the virtual link is active.

If the state is point-to-point, the virtual link is active. If the state is down, the virtual link is configured incorrectly.

Virtual If field descriptions

Use the data in the following table to use the **Virtual If** tab.

Name	Description
AreaId	Specifies the ID for the transit area that the virtual link traverses. Do not use 0.0.0.0.
Neighbor	Specifies the router ID of the virtual neighbor.
TransitDelay	Specifies the estimated number of seconds to transmit a link-state update packet over this interface. The default is 1 second.
RetransInterval	Specifies the number of seconds between link-state advertisement retransmissions for adjacencies that belong to this interface. This value also applies to the retransmissions of database description and link-state request packets. The default is 5 seconds.
HelloInterval	Specifies the number of seconds between hello packets that the router sends on this interface. Configure the same value on the virtual neighbor. The default is 10 seconds.
RtrDeadInterval	Specifies the number of seconds after which the neighbor declares the router down if it does not receive hello packets. Configure this value as a multiple of the hello interval. You must configure the same value on the virtual neighbor. The default is 60 seconds.
State	Shows the state of the virtual interface: either down or pointToPoint.

Table continues...

Name	Description
Events	Shows the number of state changes or error events on the virtual link.
LinkScopeLsaCount	Shows the number of link-scope LSAs in the LSDB for the virtual link.
LinkLsaCksumSum	Shows the sum of the checksums for the link-scope LSAs in the LSDB. Use the sum to determine if a change in the LSDB occurs, and to compare the LSDBs of the two routers.

Configuring IPsec for the OSPF virtual link

Use the following procedure to configure and enable IPsec for the OSPF virtual link.

The device only supports IPsec for IPv6 traffic, and an interface must support IPv6 to apply IPsec. IPsec is disabled by default.

About this task

Until you enable IPsec on both sides of the virtual links, the links cannot exchange OSPFv3 control messages, and the system drops OSPFv3 exchange packets.

You must disable IPsec before you can perform virtual link policy configuration changes.

Before you begin

- Configure the OSPF virtual link.
- Create the IPsec security association. For more information about how to configure IPsec security associations and IPsec policies, and how to enable policies on an interface, see the following documents:
 - *Security for Avaya Virtual Services Platform 4000 Series*, NN46251-601
 - *Configuring Security on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-601

Procedure

1. In the navigation pane, expand the following folders: **Configuration > IPv6**.
2. Click **IPSec**.
3. Click the **OSPF Virtual Link** tab.
4. Click **Insert**.
5. Specify the area ID.
6. Specify the neighbor address.
7. Complete the remaining optional configuration.
8. Click **Insert**.

OSPF Virtual Link field descriptions

Use the data in the following table to use the **OSPF Virtual Link** tab.

Name	Description
AreaId	Identifies the OSPF virtual link area.
Neighbor	Identifies the OSPF virtual link neighbor.
SAName	Links the security association to the OSPF virtual link.
AdminStatus	Enables the policy. The default is disabled.
Action	Configures the action of the IPsec policy under the OSPF virtual tunnel to one of the following: <ul style="list-style-type: none"> • permit—Permits the IP packets. • drop—Drops the IP packets. The default is permit.
Direction	Specifies the direction you want to protect with IPsec: <ul style="list-style-type: none"> • inBound—Specifies ingress traffic. • outBound—Specifies egress traffic. • bothDirections—Specifies both ingress and egress traffic. The default is bothDirections.
SrcAddress	Shows the address of the source interface to which the policy applies.
DstAddress	Shows the address of the destination interface to which the policy applies.
LinkID	Shows a unique ID for the OSPF virtual link. The default is 0.
IfIndex	Shows the interface index to which OSPF virtual link the policy applies.
OperStatus	Shows the operational status of the link, either up or down. The default is down.

Creating an OSPF interface

Configure the OSPF protocol on an IPv6 interface to support dynamic routing on the interface. Perform this procedure to create an OSPF interface on a brouter port or tunnel.

If you want to modify existing OSPFv3 interfaces, see [Modifying an OSPF interface](#) on page 162. To configure OSPFv3 on an IPv6 VLAN, see [Creating an OSPF VLAN interface](#) on page 155.

Before you begin

- The IPv6 interface must exist.

Procedure

1. Configure OSPF on an IPv6 port:
 - a. In the Device Physical view, select a port.
 - b. In the navigation tree, expand the following folders: **Configuration > Edit > Port**.
 - c. Click **IPv6**.
 - d. Click the **IPv6 OSPF Interface** tab.
 - e. Click **Insert**.
 - f. Select the area ID.
 - g. Select **enabled**.
 - h. Click **Insert**.
2. Configure OSPF on an IPv6 tunnel:
 - a. In the navigation tree, expand the following folders: **Configuration > IPv6**.
 - b. Click **Tunnel**.
 - c. Click the **Tunnel Config** tab.
 - d. Select a configured tunnel.
 - e. Click **IPv6 OSPF**.
 - f. Click **Insert**.
 - g. Select the area ID.
 - h. Select **enabled**.
 - i. Click **Insert**.

IPv6 OSPF Interface field descriptions

Use the data in the following table to use the **IPv6 OSPF Interface** tab.

Name	Description
Index	Shows the interface index for the IPv6 interface on which OSPFv3 is configured.
Areald	Specifies the area ID to which the IPv6 interface connects. Use 0.0.0.0 for the OSPFv3 backbone.
Type	Specifies the OSPFv3 interface type as one of the following: <ul style="list-style-type: none"> • broadcast • NBMA

Table continues...

Name	Description
	<ul style="list-style-type: none"> • point-to-point • point-to-multipoint
AdminStat	Specifies the administrative status for the OSPFv3 interface. If you enable the status, it is advertised as an internal route to some areas. If you disable the status, the interface is external to OSPFv3. The default is enabled.
RtrPriority	<p>Specifies the priority of this interface. Multiaccess networks use the priority in the designated router election.</p> <p>A higher priority value increases the chance the router becomes the designated router. A value of zero (0) indicates the router cannot become the designated router for the network. If more than one router uses the same priority value, the router ID determines the designated router.</p> <p>The default is 1.</p>
TransitDelay	Specifies the estimated number of seconds to transmit a link-state-update packet over this interface. The default is 1.
RetransInterval	Specifies the number of seconds between retransmission of link-state advertisements for the adjacencies that belong to this interface, and for database description and link-state request packets. The default is 5.
HelloInterval	Specifies the number of seconds between the hello packets that the router sends on this interface. You must configure this field to the same value for all routers attached to a common network. The default is 10.
RtrDeadInterval	Specifies the number of seconds after which to declare a router down if no hello packets are received. You must configure this field to the same value for all routers attached to a common network. The default is 40.
PollInterval	Specifies the number of seconds between hello packets sent to an inactive NBMA neighbor. The default is 120.
State	<p>Shows the state of the OSPFv3 interface as one of the following:</p> <ul style="list-style-type: none"> • down • loopback

Table continues...

Name	Description
	<ul style="list-style-type: none"> • waiting • pointToPoint • designatedRouter • backupDesignatedRouter • otherDesignatedRouter
DesignatedRouter	Shows the router ID for the designated router.
BackupDesignatedRouter	Shows the router ID for the backup designated router.
MetricValue	Specifies the cost for the interface. A value of zero indicates the metric value depends on the speed of the interface, when the state of the interface is up. The default value for a brouter port or VLAN is 1. The default value for a tunnel is 100.

Creating an OSPF VLAN interface

Configure the OSPF protocol on an IPv6 VLAN to support dynamic routing on the interface.

If you want to modify existing OSPFv3 interfaces, see [Modifying an OSPF interface](#) on page 162.

Before you begin

- The IPv6 interface must exist.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > VLAN**.
2. Click **VLANs**.
3. Click the **Basic** tab.
4. Select a **VLAN**.
5. Click **IPv6**.
6. Click the **IPv6 OSPF Interface** tab.
7. Click **Insert**.
8. Select the area ID.
9. Select **enabled**.
10. Click **Insert**.

IPv6 OSPF Interface field descriptions

Use the data in the following table to use the **IPv6 OSPF Interface** tab.

Name	Description
Index	Shows the interface index for the IPv6 interface on which OSPFv3 is configured.
AreaId	Specifies the area ID to which the IPv6 interface connects. Use 0.0.0.0 for the OSPFv3 backbone.
Type	Specifies the OSPFv3 interface type as one of the following: <ul style="list-style-type: none"> • broadcast • NBMA • point-to-point • point-to-multipoint
AdminStat	Specifies the administrative status for the OSPFv3 interface. If you enable the status, it is advertised as an internal route to some areas. If you disable the status, the interface is external to OSPFv3. The default is enabled.
RtrPriority	Specifies the priority of this interface. Multiaccess networks use the priority in the designated router election. A higher priority value increases the chance the router becomes the designated router. A value of zero (0) indicates the router cannot become the designated router for the network. If more than one router uses the same priority value, the router ID determines the designated router. The default is 1.
TransitDelay	Specifies the estimated number of seconds to transmit a link-state-update packet over this interface. The default is 1.
RetransInterval	Specifies the number of seconds between retransmission of link-state advertisements for the adjacencies that belong to this interface, and for database description and link-state request packets. The default is 5.
HelloInterval	Specifies the number of seconds between the hello packets that the router sends on this interface. You must configure this field to the same value for all routers attached to a common network. The default is 10.
RtrDeadInterval	Specifies the number of seconds after which to declare a router down if no hello packets are received. You must configure this field to the same

Table continues...

Name	Description
	value for all routers attached to a common network. The default is 40.
PollInterval	Specifies the number of seconds between hello packets sent to an inactive NBMA neighbor. The default is 120.
State	Shows the state of the OSPFv3 interface as one of the following: <ul style="list-style-type: none"> • down • loopback • waiting • pointToPoint • designatedRouter • backupDesignatedRouter • otherDesignatedRouter
DesignatedRouter	Shows the router ID for the designated router.
BackupDesignatedRouter	Shows the router ID for the backup designated router.
MetricValue	Specifies the cost for the interface. A value of zero indicates the metric value depends on the speed of the interface, when the state of the interface is up. The default value for a brouter port or VLAN is 1. The default value for a tunnel is 100.

Viewing the AS-scope link-state database

View the AS-scope link-state database (LSDB) to see the LSAs that are flooded through the routing domain. The AS scope is used for ASexternal- LSAs.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **AS-scope LSDB** tab.

AS-scope LSDB field descriptions

Use the data in the following table to use the **AS-scope LSDB** tab.

Name	Description
Type	Shows the type of the link-state advertisement. Each link state type has a separate advertisement format. AS-scope LSAs not recognized by the router may be stored in the database.
RouterId	Shows the 32 bit number that uniquely identifies the originating router in the autonomous system.
Lsid	Identifies the piece of the routing domain that is being described by the advertisement.
Sequence	Shows a signed 32-bit integer that detects old and duplicate link-state advertisements. The larger the sequence number, the more recent the advertisement.
Age	Shows the age of the link-state advertisement in seconds.
Checksum	Indicates the checksum of the complete contents of the advertisement, except the age field. The age field is not affected so that the advertisement age value increments without updating the checksum. The checksum used is the same for ISO connectionless datagrams, the Fletcher checksum.

Viewing the area-scope LSDB

View the area-scope LSDB to see the LSAs that are flooded in a single OSPF area. Area scope is used in router LSAs, network LSAs, Inter-Area-Prefix-LSAs, Inter-Area-Router LSAs, and Intra-Area-Prefix-LSAs.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Area-scope LSDB** tab.

Area-scope LSDB field descriptions

Use the data in the following table to use the **Area-scope LSDB** tab.

Name	Description
Areald	Identifies the area ID from which the LSA is received. Area ID 0.0.0.0 is the OSPF backbone.
Type	Identifies the type of the link-state advertisement. Each link-state type has a separate advertisement

Table continues...

Name	Description
	format. Area-scope LSAs unrecognized by the router are also stored in this database.
RouterId	Identifies the originating router in the autonomous system.
Lsid	Identifies the piece of the routing domain that is described by the advertisement.
Sequence	Shows a signed 32-bit integer that detects old and duplicate link-state advertisements. The larger the sequence number, the more recent the advertisement.
Age	Shows the age of the link-state advertisement in seconds.
Checksum	Indicates the checksum of the complete contents of the advertisement, except the age field. The age field is not affected so that the advertisement age value increments without updating the checksum. The checksum used is the same for ISO connectionless datagrams, the Fletcher checksum.

Viewing the link-scope LSDB

View the link-scope LSDB to view the LSAs that are not flooded beyond the local link.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Link-scope LSDB** tab.

Link-scope LSDB field descriptions

Use the data in the following table to use the **Link-scope LSDB** tab.

Name	Description
Ifindex	Shows the identifier of the link from which the LSA was received.
Type	Shows the type of the link-state advertisement. Each link state type has a separate advertisement format. Link-scope LSAs not recognized by the router may be stored in the database.
RouterId	Shows the 32 bit number that uniquely identifies the originating router in the autonomous system.

Table continues...

Name	Description
Lsid	Identifies the piece of the routing domain that is being described by the advertisement.
Sequence	Shows a signed 32-bit integer that detects old and duplicate link-state advertisements. The larger the sequence number, the more recent the advertisement.
Age	Shows the age of the link-state advertisement in seconds.
Checksum	Indicates the checksum of the complete contents of the advertisement, except the age field. The age field is not affected so that the advertisement age value increments without updating the checksum. The checksum used is the same for ISO connectionless datagrams, the Fletcher checksum.

Adding an NBMA neighbor

Add an NBMA neighbor for each interface that is eligible to become the DR.

An NBMA interface with a positive nonzero router priority is eligible to become the DR for the NBMA network and is configured with the identification of all attached routers, IPv6 addresses, and router priorities.

Before you begin

- Identify the following information:
 - specific interfaces to include in the NBMA network
 - the IPv6 address for each interface
 - the router priority for each interface
 - the hello interval for the network
 - the router dead interval for the network
 - the poll interval for the network

About this task

In contrast to a broadcast network where switches multicast (send to AllSPFRouters and AllDRouters) certain OSPF protocol packets, switches replicate and send NBMA packets to each neighboring router as unicast. NBMA networks drop all OSPF packets with destination addresses AllSPFRouters and AllDRouters. Because the NBMA network does not broadcast, you must manually configure a list of neighbors and priorities for all routers in the network that can become the DR. Potential DRs use a positive nonzero router priority.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.

3. Click the **NBMA Neighbors** tab.
4. Click **Insert**.
5. Select the IPv6 port or VLAN interface.
6. Specify the IPv6 address for the neighbor.
7. Specify the priority for the neighbor.
8. Click **Insert**.

NBMA Neighbors field descriptions

Use the data in the following table to use the **NBMA Neighbors** tab.

Name	Description
Ifindex	Specifies the link ID for the link over which the switch reaches the neighbor.
Address	Specifies the IPv6 address of the neighbor.
Priority	Specifies the priority to use for this neighbor in the designated router election process. A value of 0 indicates the neighbor cannot become the designated router. The higher the priority value, the higher chance the switch will win the election process. The default is 1.
Rtrid	Identifies the neighboring router in the autonomous system. The value is 0.0.0.0 until the switch receives a hello message from the neighbor.
State	Identifies the state of the relationship with the neighbor. The state can be one of the following: <ul style="list-style-type: none"> • down • attempt • init • twoWay • exchangeStart • exchange • loading • full

Enabling OSPF route redistribution

Enable redistribution to announce routes of a certain source protocol type into the OSPFv3 domain.

You can redistribute directly connected routes, IPv6 static routes, IPv6 BGP routes, IPv6 IS-IS routes, and RIPng routes into OSPFv3.

About this task

If you do not configure a redistribution entry, the switch generates external LSAs for non-OSPF routes.

You can also redistribute directly connected routes, IPv6 static routes, and IPv6 OSPFv3 routes into BGP.

For information about BGP for IPv6, see *Configuring BGP Services on VSP Operating System Software*, NN47227-508.

Procedure

1. In the navigation pane, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Redistribute** tab.
4. For the type of route source, double-click the cell in the **Enable** column to change the value.
5. Select **enable**.
6. Click **Apply**.

Redistribute field descriptions

Use the data in the following table to use the **Redistribute** tab.

Name	Description
DstVrflid	Shows the ID of the destination virtual router and forwarder (VRF). Because IPv6 is not virtualized, the value is 0 for the Global Router.
Protocol	Shows the routing protocol that receives the external routing information. In this case, the routing protocol is OSPFv3.
SrcVrflid	Shows the ID of the source VRF. Because IPv6 is not virtualized, the value is 0 for the Global Router.
RouteSource	Shows the source protocol from which to receive routes to insert into the OSPFv3 domain. The possibilities are direct routes and static routes.
Enable	Configures the status of route redistribution. The default is disable.

Modifying an OSPF interface

Configure the OSPF protocol on IPv6 interface to support dynamic routing on the interface. An IPv6 interface can be a tunnel, port, or VLAN.

Before you begin

- The OSPF interface must exist.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Interfaces** tab.
4. Double-click a cell to edit the value.
5. Click **Apply**.

Interfaces field descriptions

Use the data in the following table to use the **Interfaces** tab.

Name	Description
Index	Shows the interface index for the IPv6 interface on which OSPFv3 is configured.
Areald	Specifies the area ID to which the IPv6 interface connects. Use 0.0.0.0 for the OSPFv3 backbone.
Type	Specifies the OSPFv3 interface type as one of the following: <ul style="list-style-type: none"> • broadcast • NBMA • point-to-point • point-to-multipoint
AdminStat	Specifies the administrative status for the OSPFv3 interface. If you enable the status, it is advertised as an internal route to some areas. If you disable the status, the interface is external to OSPFv3. The default is enabled.
RtrPriority	Specifies the priority of this interface. Multiaccess networks use the priority in the designated router election. A higher priority value increases the chance the router becomes the designated router. A value of zero (0) indicates the router cannot become the designated router for the network. If more than one router uses the same priority value, the router ID determines the designated router. The default is 1.
TransitDelay	Specifies the estimated number of seconds to transmit a link-state-update packet over this interface. The default is 1.

Table continues...

Name	Description
RetransInterval	Specifies the number of seconds between retransmission of link-state advertisements for the adjacencies that belong to this interface, and for database description and link-state request packets. The default is 5.
HelloInterval	Specifies the number of seconds between the hello packets that the router sends on this interface. You must configure this field to the same value for all routers attached to a common network. The default is 10.
RtrDeadInterval	Specifies the number of seconds after which to declare a router down if no hello packets are received. You must configure this field to the same value for all routers attached to a common network. The default is 40.
PollInterval	Specifies the number of seconds between hello packets sent to an inactive NBMA neighbor. The default is 120.
State	Shows the state of the OSPFv3 interface as one of the following: <ul style="list-style-type: none"> • down • loopback • waiting • pointToPoint • designatedRouter • backupDesginatedRouter • otherDesignatedRouter
DesignatedRouter	Shows the router ID for the designated router.
BackupDesignatedRouter	Shows the router ID for the backup designated router.
MetricValue	Specifies the cost for the interface. A value of zero indicates the metric value depends on the speed of the interface, when the state of the interface is up. The default value for a brouter port or VLAN is 1. The default value for a tunnel is 100.

Viewing OSPF neighbors

View OSPF neighbors to see routers with interfaces to a common network.

The OSPF hello protocol maintains and dynamically discovers neighbor relationships.

The exception is an NBMA network; you manually configure permanent neighbors on each router eligible to become the designated router (DR).

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Neighbors** tab.

Neighbors field descriptions

Use the data in the following table to use the **Neighbors** tab.

Name	Description
IfIndex	Displays the local-link ID of the link over which the neighbor can be reached.
RtrId	Identifies the neighboring router in the Autonomous System. The value is the router ID of the neighboring router, which in OSPF uses the same format as an IPv6 address but identifies the router independent of IPv6 address.
Address	Displays the IPv6 address for the neighbor associated with the local link.
Options	Displays the bit mask that corresponds to the options field on the neighbor.
State	Displays the state of the relationship with the neighbor. The value can be one of the following: <ul style="list-style-type: none"> • down • attempt • init • twoWay • exchangeStart • exchange • loading • full
NbrIfId	Displays the interface ID that the neighbor advertises in its hello packets on this link.
DeadIntCnt	Displays the Dead interval Count or TTL (time to live) field that indicates how many seconds remain before the system declares the Neighbor down.

Table continues...

Name	Description
	<p>The starting value is the Router Dead Interval value and it decrements to 0 if no Hello is received for that neighbor within the interval. If no Hello is received within the interval, then the system declares the neighbor down.</p> <p>When a hello is received for the neighbor, the system resets the value to the Router Dead Interval value.</p>

Viewing virtual neighbors

View information about the neighbors on the virtual link to the OSPF backbone.

Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **OSPF**.
3. Click the **Virtual Neighbors** tab.

Virtual Neighbors field descriptions

Use the data in the following table to use the **Virtual Neighbors** tab.

Name	Description
Area	Shows the ID for the transit area.
Rtrid	Shows the ID for the neighboring router in the autonomous system.
LocalIfIndex	Shows the local interface ID for the virtual link over which the switch can reach the neighbor.
AddressType	<p>Shows the type of address as one of the following:</p> <ul style="list-style-type: none"> • ipv4 • ipv6 • ipv4z • ipv6z • dns <p>ipv4z and ipv6z indicate a scope zone.</p>
Address	Shows the IPv6 address that this virtual neighbor advertises. This value must be a global scope address.

Table continues...

Name	Description
Options	Shows a bit mask that corresponds to the OSPF options field of the neighbor.
State	Shows the state of the virtual neighbor relationship. The value can be one of the following: <ul style="list-style-type: none">• down• attempt• init• twoWay• exchangeStart• exchange• loading• full

Chapter 8: RIPng

This chapter provides concepts and procedures to complete RIPng configuration.

Related links

[RIPng fundamentals](#) on page 168

RIPng fundamentals

Routing Information Protocol next generation (RIPng) allows routers to exchange information for computing routes through an IPv6-based network. You should implement RIPng only on routers. IPv6 provides neighbor router information required by RIPng protocol to function as intended. A RIPng router is assumed to have interfaces in several networks and the protocol relies primarily on the metric of each network to compute routes using the distance vector algorithm.

RIP identifies network reachability based on cost, and cost is defined as hop count. One hop is the distance from one router to the next. This cost, or hop count, is the metric.

RIPng-enabled routers use UDP port 521 (the RIPng port) to exchange routing information. RIPng responds to a request by sending a message to the port from which the request originates. Specific queries can be sent from ports other than the RIPng port, but they must be directed to the RIPng port on the target machine.

Each router advertises routing information by sending an update every 30 seconds (one interval). If RIPng does not receive information about a network for 180 seconds, the metric associated with the network rises to infinity (U); that is, the metric resets to 16, which means the network becomes unreachable. If RIP does not receive information about a network for 120 seconds, it removes the network from the routing table.

Note:

These time interval values are default values which are configurable by the user.

Each router that implements RIPng contains a routing table. This table contains one entry for every destination that is reachable throughout the system operating RIPng. At a minimum, each routing table entry contains the following information:

- The IPv6 prefix of the destination.
- A metric that represents the total cost of getting a datagram from the router to that destination. The metric is the sum of the costs of traversing the networks to arrive at the destination.

- The IPv6 address of the next router in the path to the destination (the next hop). The next-hop IPv6 address is a linklocal address.
- The VLAN or brouter port on which the RIPng routes were learned.
- The age of the RIPng route.

RIPng protocol implementation is specified in IETF document RFC 2080.

RIPng messages and packet format

RIPng-enabled routers use UDP port 521 (the RIPng port) to send and receive datagrams.

The following figure shows the RIPng packet format:




Figure 9: RIPng packet format

A RIPng packet header consists of the following components:

- **command:** Specifies the purpose of the message.
- **version:** The version of RIPng.

Originate Default route

Generally you use a default route when it is not convenient to list every possible network in RIPng updates, and one or more routers in the system are able to handle traffic to networks that RIPng does not explicitly list.

RIPng is enabled with the default route only option. When you enable default route only on an interface, it suppresses all other routes in the update sent for the interface, and advertises only the default route.

Timers

RIPng states four different timer intervals for protocol operation:

- **Update timer:** The RIPng process sends a complete routing table to each neighboring router every 30 seconds. To prevent collisions on broadcast networks, the process adds an offset value to the timer.

- **Timeout time interval:** This is a 180 second time interval associated with every route. If the time interval expires, the metric for this route updates to the value of infinity (16) and the route is no longer valid. However, the routing table retains the value for another 120 seconds.
- **Garbage collection time interval:** After the timeout time interval expires and the route becomes invalid, it remains in the routing table until the garbage collection time interval expires. The garbage collection time interval is 120 seconds. Until the garbage collection time interval expires all updates sent by this router include the invalid route. When the garbage collection timer expires, the process removes the route from the routing table.
- **Triggered update time interval:** The triggered update time interval is set to a random value between 1 and 5 seconds after a triggered update is sent. A single update is sent even if multiple triggered updates occur before the timer expires.

VOSS Release 5.0 supports configuration of these timers or time intervals at the ACLI/SNMP/EDM level. VOSS 5.0 does not support timer or time interval configuration at the interface/port level.

Related links

[RIPng](#) on page 168

RIPng Configuration using ACLI

Configuring RIPng globally

Configure RIPng parameters on the router so you can control RIPng behavior on the system.

Before you begin

You can configure RIPng only on a global router. You cannot configure RIPng on a VRF instance.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enable RIPng globally:

```
router rip ipv6-enable
```

Related links

[RIPng](#) on page 168

Configuring RIPng on an interface

Configure RIPng on Ethernet ports and VLANs so that they can participate in RIPng routing.

About this task

RIPng does not operate on a port or VLAN until you enable it both globally and on the port or VLAN.

Before you begin

- Assign an IP address to the port or VLAN.
- Configure RIPng and enable it globally.

Procedure

1. Enter Global configuration mode:

```
enable
configure terminal
```

2. Enter the port or VLAN Interface configuration mode:

```
interface vlan <1-4059> or interface gigabitEthernet {slot/port [-
slot/port], [,...]}
```

3. Create a RIPng interface:

```
ipv6 rip
```

4. Enable the RIPng interface:

```
ipv6 rip enable
```

Example

```
Switch:1>enable
Switch:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch:1(config)#interface vlan 22
Switch:1(config-if)#ipv6 rip
Switch:1(config-if)#ipv6 rip enable
Switch:1(config-if)#show ipv6 rip interface
```

Total RIPng interfaces: 2

RIPng Interface - GlobalRouter					
IFINDEX	COST	POISON STATUS	SEND DEFAULT	ADMIN STATUS	OPER STATUS
257 (2/2)	2	disable	disable	enable	enable
2070 (22)	5	disable	disable	enable	disable

2 out of 2 Total Num of RIPng interfaces displayed

Related links

[RIPng](#) on page 168

[Variable definitions](#) on page 171

Variable definitions

Use the data in the following table to use the `ipv6 rip` command.

Variable	Value
<1–4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1. This variable applies only to VLAN interfaces, not ports.
port {slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port).If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

Related links

[Configuring RIPng on an interface](#) on page 170

Configuring RIPng custom values

Configure custom values for RIPng parameters to replace default values.

Before you begin

- Configure RIPng and enable it globally.

Procedure

1. Enter Global configuration mode:

```
enable
configure terminal
```

2. Enter the port or VLAN Interface configuration mode:

```
interface vlan <1-4059> or interface gigabitEthernet {slot/port [-slot/port], [,...]}
```

3. Enable RIPng poison:

```
ipv6 rip poison enable
```

4. Specify the RIPng cost:

```
ipv6 rip cost <1-15 Cost>
```

5. Access router Rip configuration mode:

```
router rip
```

6. Specify the RIPng holddown timer value:

```
ipv6 timers basic holddown <0-360>
```

7. Specify the RIPng timeout timer value:

```
ipv6 timers basic timeout <15-259200>
```

8. Specify the RIPng update timer value:

```
ipv6 timers basic update <1-360>
```

9. Specify the default route metric value:

```
ipv6 default-information metric <1-15>
```

10. Enable default information globally:

```
ipv6 default-information enable
```

11. Ensure the configuration is correct:

```
show ipv6 rip
```

Example

Configure custom values for RIPng.

```
Switch:1>enable
Switch:1#configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Switch:1(config)#router rip
Switch:1(config-rip)#ipv6 default-information metric 1
Switch:1(config-rip)#ipv6 default-information enable
Switch:1(config-rip)#ipv6 timers basic update 30
Switch:1(config-rip)#ipv6 timers basic timeout 180
Switch:1(config-rip)#ipv6 timers basic holddown 120
Switch:1(config-rip)#router rip ipv6-enable
Switch:1(config)#show ipv6 rip

=====
                        RIPng Global - GlobalRouter
=====
                Rip : Enabled
                HoldDown Time : 120
                Timeout Interval : 180
                Update Time : 30
                Default Info Metric : 1
                Default Info State : Enabled
                Default Import Metric : 1
```

Related links

[RIPng](#) on page 168

[Variable definitions](#) on page 173

Variable definitions

Use the data in the following table to use the `ipv6 rip poison`, `ipv6 default-information` and `ipv6 timers basic` commands.

Variable	Value
<1-4059>	Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for

Table continues...

Variable	Value
	internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1. This variable applies only to VLAN interfaces, not ports.
port {slot/port[/sub-port][/-slot/port[/sub-port]][,...]}	Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port).If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.
poison enable	Enables Poison Reverse. If you disable Poison Reverse (no poison enable). Split Horizon is enabled. By default, Split Horizon is enabled. If you enable Split Horizon, the interface does not advertise IP routes learned from an immediate neighbor back to the neighbor. If you enable Poison Reverse, the RIP updates sent to a neighbor from which a route is learned are poisoned with a metric of 16. Therefore, the receiver neighbor ignores this route because the metric 16 indicates infinite hops in the network These mechanisms prevent routing loops.
<1-15 Cost>	Configures the RIPng cost for this port (link).
holddown <0-360>	Configures the RIPng holddown timer value, the length of time (in seconds) that RIPng continues to advertise a network after it determines that the network is unreachable. The default is 120.
timeout <15-259200>	Configures the RIPng timeout interval. The default is 180.
update <1-360>	Configure the RIPng update timer. The update time is the time interval between RIPng updates.
default-information <1-15>	Configure the default route metric value.

Related links

[Configuring RIPng custom values](#) on page 172

Configuring RIPng route distribution

Configure a redistribute entry to announce certain routes into the RIPng domain, including static routes, direct routes, Open Shortest Path First (OSPFv3), IS-IS, or Border Gateway Protocol (BGP+).

Before you begin

- Enable RIPng globally.

Procedure

1. Enter Global configuration mode:

```
enable
```

- ```
configure terminal
```
2. Access router RIP configuration mode:  
`router rip`
  3. Enable the redistribution:  
`ipv6 redistribute {direct|isis|static|ospf|bgp} enable`
  4. Ensure the configuration is correct:  
`show ipv6 rip redistribute`

### Example

Enable the redistribution instance.

```
Switch:1#enable
Switch:1#configure terminal
Switch:1(config)#router rip
Switch:1(config-rip)#ipv6 redistribute bgp enable
Switch:1(config-rip)#ipv6 redistribute direct enable
Switch:1(config-rip)#ipv6 redistribute isis enable
Switch:1(config-rip)#ipv6 redistribute ospf enable
Switch:1(config-rip)#ipv6 redistribute static enable
Switch:1(config-rip)#show ipv6 rip redistribute
```

```
=====
 RIPng Redistribute List
=====
 direct : enabled
 static : enabled
 ospf : enabled
 bgp : enabled
 isis : enabled

```

### Related links

[RIPng](#) on page 168

[Variable definitions](#) on page 175

### Variable definitions

Use the data in the following table to use the `ipv6 redistribute` command.

| Variable                      | Value                                                                                                                     |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| <bgp direct isis ospf static> | Specifies the type of routes to redistribute (the protocol source). Valid options are bgp, isis, direct, ospf, or static. |

### Related links

[Configuring RIPng route distribution](#) on page 174

---

## RIPng Configuration using EDM

---

### Configuring an IPv6 RIPng interface

Configure RIPng parameters on an interface so you can control RIPng behavior on the interface.

#### About this task

RIPng does not operate on an interface until you enable it globally and on the interface.

You can also configure an IPv6 RIPng interface for a brouter port by selecting **Device Physical View**, selecting a port, and following the **Edit > Port > IPv6** navigation path. You can configure an IPv6 RIPng interface for a VLAN through the **VLAN > VLANs > Basic > IPv6** navigation path. This procedure uses the main IPv6 RIPng navigation path where you can create both types of interfaces.

#### Before you begin

- Configure a routing interface (either a brouter port or a virtual routing interface).
- Assign an IP address to the interface.
- Enable RIPng globally.

#### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6 RIPng**.
3. Click the **Interfaces** tab.
4. Click **Insert**.
5. In the **IfIndex** box, type a value to identify the IPv6 interface.
6. In the **RipAdminStatus** option box, select **enable**.
7. Configure other parameters as required.
8. Click **Insert**.

### Interfaces field descriptions

Use the data in the following table to use the **Interfaces** tab.

| Name                    | Description                                                    |
|-------------------------|----------------------------------------------------------------|
| <b>IfIndex</b>          | RIPng interface index.                                         |
| <b>RipAdminStatus</b>   | Enable or disable RIPng on an interface.                       |
| <b>DefaultInfoState</b> | Enable or disable default information at the interface level.  |
| <b>Cost</b>             | Specifies the RIPng metric cost.                               |
| <b>Poison</b>           | Enable or disable poison reverse on an RIPng interface.        |
| <b>RipOperStatus</b>    | Enable or disable the RIPng operational state on an interface. |



---

## Configuring route redistribution to RIPng

Configure a redistribute entry to announce routes of a certain source protocol type into the RIPng domain, for example, static, RIP, or direct. Use a route policy to control the redistribution of routes.

### Before you begin

- Enable RIP globally.
- Configure a route policy.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6 RIPng**.
3. Click the **Redistribute** tab.
4. Double-click the value in the **Enable** column that corresponds with the source protocol type you want to enable or disable.
5. Select **enable** or **disable** from the list.
6. Click **Apply**.

## Redistribute field descriptions

Use the data in the following table to use the **Redistribute** tab.

| Name               | Description                                                                            |
|--------------------|----------------------------------------------------------------------------------------|
| <b>Protocol</b>    | Specifies the dynamic routing protocol that receives the external routing information. |
| <b>RouteSource</b> | Specifies the route source protocol for the redistribution entry.                      |
| <b>Enable</b>      | Enables (or disables) a RIPng redistribute entry for a specified source type.          |

---

## Viewing stats for RIPng interfaces

View statistics for RIPng interfaces.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6 RIPng**.
3. Click the **Stats** tab.

## Stats field descriptions

Use the data in the following table to use the **Stats** tab.

| Name                 | Description                                                                                                                                                               |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IfIndex</b>       | Shows the unique value to identify an IPv6 interface.                                                                                                                     |
| <b>RcvBadPackets</b> | The number of RIP response packets received by the RIP process that were subsequently discarded for any reason (examples: a version 0 packet or an unknown command type). |
| <b>RcvBadRoutes</b>  | The number of routes, in valid RIP packets, that were ignored for any reason (examples: unknown address family or invalid metric).                                        |
| <b>SentUpdates</b>   | The number of triggered RIP updates actually sent on this interface.                                                                                                      |
| <b>RcvUpdates</b>    | The number of triggered RIPng updates actually received on this interface. This explicitly does not include full updates received containing new information.             |

## Configuring RIPng globally

Configure RIPng global parameters on the switch so you can control RIPng behavior on the system.

### About this task

All router interfaces that use RIPng use the RIPng global parameters. Both brouter ports and VLAN virtual routing interfaces use the same RIPng global parameters.

You can configure RIPng on interfaces while RIPng is globally disabled. This way, you can configure all interfaces before you enable RIPng for the switch

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **IPv6 RIPng**.
3. Click the **Globals** tab.
4. Select the **enable** option button.
5. Configure other global RIPng parameters as required.
6. Click **Apply**.

## Globals field descriptions

Use the data in the following table to use the **Globals** tab.

| Name                | Description                                                                                                                                                         |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>AdminState</b>   | Enables or disables RIPng globally. The default is disabled.                                                                                                        |
| <b>UpdateTime</b>   | Specifies the time interval between RIPng updates for all interfaces. The default is 30 seconds, and the range is 1–360.                                            |
| <b>HoldDownTime</b> | Configures the length of time that RIPng continues to advertise a network after the network is unreachable. The range is 0–360 seconds. The default is 120 seconds. |

*Table continues...*

| Name                     | Description                                                                                        |
|--------------------------|----------------------------------------------------------------------------------------------------|
| <b>TimeoutInterval</b>   | Configures the RIPng timeout interval. The range is 15–259200 seconds. The default is 180 seconds. |
| <b>DefaultInfoMetric</b> | RIPng default-information metric.                                                                  |
| <b>DefaultInfoState</b>  | Default-information enable or disable at the global level                                          |

# Chapter 9: VRRP

This chapter provides concepts and procedures to complete IPv6 Virtual Router Redundancy Protocol (VRRP) configuration.

---

## VRRP

For IPv6 hosts on a LAN to learn about one or more default routers, IPv6-enabled routers send router advertisements using the IPv6 ND protocol. The routers multicast these router advertisements every few minutes.

The ND protocol uses a mechanism called neighbor unreachability detection to detect the failure of a neighbor node (router or host) or the failure of the forwarding path to a neighbor. Nodes can monitor the health of a forwarding path by sending unicast ND neighbor solicitation messages to the neighbor node. To reduce traffic, nodes only send neighbor solicitations to neighbors to which they actively send traffic and only after the node receives no positive indication that the neighbors are up for a period of time. A host takes a minimum of 5 seconds to learn that a router is unreachable before it switches to another default router, but this minimum value increases ND traffic. This delay can cause service disruption.

VRRP for IPv6 provides a faster switchover to an alternate default router than is possible using the ND protocol. With VRRP for IPv6, a backup router can take over for a failed default router in approximately three seconds (using default parameters). The switchover is accomplished without interaction with the hosts and with a minimum amount of VRRP traffic.

The IPv6 VRRP implementation is similar to the existing IPv4 VRRP operation, including support for holddown timer, critical IP, fast advertisements, and backup master. With backup master enabled, the backup switch routes all traffic according to its routing table. The backup master switch does not perform Layer 2 switching for the traffic to the VRRP master.

You must specify a link-local address to associate with the virtual router. Optionally, you can also assign global unicast IPv6 addresses to associate with the virtual router. Network prefixes for the virtual router are derived from the global IPv6 addresses assigned to the virtual router.


With the current implementation of VRRP, one active master switch exists for each IPv6 network prefix. All other VRRP interfaces in a network are in backup mode.

## VRRP for IPv6 operation

VRRP uses a virtual IP address shared between two or more routers connecting the common network prefix to the enterprise network. With the virtual IP address as the default gateway on end hosts, VRRP provides dynamic default gateway redundancy in the event of failover.

The VRRP router with higher priority is called the master router. In case of equal priority the router with higher link-local address becomes the master router. The master router forwards packets sent to the virtual router IP addresses.

The following figure shows the minimum VRRP topology.



**Figure 10: VRRP network topology**

Traffic flows between users A and users B.

Router A uses VRRP global addresses as next hops for users B, and Router B for users A.

The VRRP master forwards the traffic and sends VRRP advertisements in the VLAN to announce to the backups that it is the master. If the master is no longer available, the backup takes over and becomes master. The only change occurs to the state of VRRP.

The VRRP router then transitions to the controlling state.

### \* Note:

The VRRP virtual IP address cannot be same as the local IP address of the port or VLAN on which VRRP is enabled.

In the controlling state, the VRRP router functions as the forwarding router for the IP addresses associated with the virtual router. The router responds to ND neighbor solicitation and ND router solicitation messages for these IP addresses, forwards packets with a destination MAC address equal to the virtual router MAC address, and accepts packets addressed to IP addresses associated with the virtual router.

If you initialize the VRRP router and the priority is not 255, the router transitions to the backup state to ensure that all Layer 2 switches in the downstream path relearn the new origin of the VRRP MAC addresses.

In the backup state, a VRRP router monitors the availability and state of the master router. The backup does not respond to ND neighbor solicitation and ND router solicitation messages for virtual router IP addresses and discards packets with a MAC address equal to the virtual router MAC address. The backup does not accept packets addressed to IP addresses associated with the virtual router. If a shutdown occurs, it transitions back to the initialize state. If the master router goes down, the backup router sends the VRRP advertisement and unsolicited ND neighbor advertisements and ND router advertisements described in the preceding paragraphs and transitions to the controlling state.

### VRRP advertisements and master router failover

When you initialize a VRRP router, the master router continues to send advertisement messages at the advertisement interval period.

#### \* Note:

The VRRP virtual IP address cannot be same as the local IP address of the port or VLAN on which VRRP is enabled.

The other VRRP routers transition to the backup state in the following situations:

- if the priority in the received advertisement is greater than the local priority
- if the priority in the received advertisement is the same as the local priority and the primary IP address of the sender is greater than the local primary IP address

The backup routers use the advertisements from the master router as a keepalive to monitor the health of the master router. If the backup router does not receive an advertisement during the master downtime interval, calculated as  $3 * \text{advertisement interval}$ , then the master router is declared down.

If a shutdown occurs, the master router sends a VRRP advertisement with a priority of 0 and transitions to the initialize state

The priority value 0 indicates that the master router has stopped participating in VRRP. This value triggers the backup router to transition to the master state without waiting for the current master to time out.

### Critical IPv6 address and holddown timer

The critical IPv6 address is an interface that has primary impact on VRRP. If you enable critical IPv6 and the status of the critical IP changes, the master and backup relationship also changes.

If you configure and enable critical IPv6 address, the master transitions to backup if the critical IPv6 is down, and the backup becomes the master. After the critical IPv6 address of the original master resumes, if the hold-down timer is configured to 0, it becomes the master immediately. Otherwise, the original master transitions to the master state after the hold-down timer time out.

You can specify the local router IP interface uplink from the VRRP router to the network as the critical IP address. This ensures that, if the local uplink interface fails, VRRP initiates a master router failover to one of the backup routers.

The critical address can be one of the global unicast IPv6 addresses assigned to any local IPv6 interfaces.

The holddown timer is a proprietary Avaya enhancement to VRRP.

After a master transitions to backup by critical IP changing, one of the backup routers will be elected as the master router. After the critical IPv6 of the original master is restored, the original master

remains in the backup state for a period of time that you configure by using the `holddown-timer` parameter. The router becomes the master immediately if you use the command `ipv6 vrrp <1-255> action preempt`.

The holddown timer allows the master router enough time to detect and update the dynamic routes. The timer delays the preemption of the master over the backup, when the master becomes available. If the hold-timer is configured to 0, it becomes the master router immediately. Otherwise, it transitions to the master state only after the holddown timer times out.

The holddown timer does not apply during failovers caused by VRRP router priority change. The holddown timer applies only to failovers caused by a critical IP failure.

Configure all of your routers to use identical values for the holddown timer.

### **Important:**

Do not use VRRP backup master and critical IP at the same time. Use one or the other. The critical IP address must be a local address.

## **VRRP backup master with triangular SMLT**

The standard implementation of VRRP supports one active master switch for each IPv6 subnet. All other VRRP interfaces in a network are in backup mode.

A deficiency occurs when VRRP-enabled switches use SMLT. If VRRP switches are aggregated into two SMLT switches, the end host traffic is load-shared on all uplinks to the aggregation switches (based on the Multilink Trunk [MLT] traffic distribution algorithm).

However, VRRP usually has only one active routing interface enabled. All other VRRP routers are in backup mode. Therefore, all traffic that reaches the backup VRRP router is forwarded over Virtual Inter-Switch Trunk (vIST) toward the master VRRP router. In this case, vIST potentially does not have enough bandwidth to carry all the aggregated traffic.

To resolve this issue, assign the backup router as the backup master router. The backup master router can actively load-share the routing traffic with a master router.

Because the two VRRP peer nodes exchange MAC address tables, the VRRP backup master can forward traffic directly, on behalf of the master router. The switch in the backup master state routes all traffic received on the backup master IP interface according to its routing table. The backup master switch does not perform Layer 2 switching for the traffic to the VRRP master.

If you enable SMLT on the backup master router, the incoming host traffic is forwarded over the SMLT links as usual.

### **Important:**

Do not use VRRP backup master and critical IP at the same time. Use one or the other.

## **Fast advertisement**

You can configure the advertisement time interval (in seconds) between sending advertisement messages. This interval permits fast network convergence with standardized VRRP failover. However, losing connections to servers for more than a second can result in missing critical failures. Customer network uptime in many cases requires faster network convergence, which means network problems must be detected within hundreds of milliseconds.

To meet these requirements, the fast advertisement interval are provided.

The fast advertisement interval is similar to the advertisement interval parameter except for the unit of measure and the range. The fast advertisement interval is expressed in milliseconds and the range is from 200 to 1,000 milliseconds. This unit of measure must be in multiples of 200 milliseconds.

To configure fast advertisement, you must specify a fast advertisement interval and explicitly enable the fast advertisement option. After you enable fast advertisement, the fast advertisement interval is used instead of the advertisement interval.

If you enable fast advertisement, VRRP can only communicate with other Avaya products with the same configuration.

### IPv6 VRRP and ICMP redirects

In IPv6 networks, do not enable ICMP redirects on VRRP VLANs. If you enable this option (using the `ipv6 icmp redirect-msg` command), VRRP cannot function. The option is disabled by default.

### Accept-mode

When you configure VRRP for IPv6 on an interface you can configure the accept-mode parameter, which controls whether the VRRP master or backup master accepts packets destined for the IPv6 address associated with the virtual router.

By default, accept-mode is disabled. The accept-mode parameter does not affect the Neighbor Discovery packets. The master router forwards packets with a destination link-layer MAC address that matches the virtual MAC address, and accepts packets forwarded over the virtual interswitch trunk (vIST) toward the master router, if accept-mode is enabled. If you disable accept-mode, you cannot ping the virtual IPv6 address. If you enable accept-mode, the master router accepts packets addressed to the IPv6 address that is associated with the virtual router.

When you configure VRRP for IPv6 on an interface, you can configure the accept-mode parameter. By default, accept-mode is disabled. If you disable accept-mode, the master router does not drop neighbor solicitations or neighbor advertisements. The master router forwards packets with a destination link-layer MAC address that matches the virtual MAC address. If you disable accept-mode, you cannot ping the virtual IPv6 address.

#### Note:

The VRRP virtual IP address cannot be same as the local IP address of the port or VLAN on which VRRP is enabled.

---

## VRRPv3

VRRPv3 is a combined protocol for both IPv4 and IPv6. It specifies an election protocol that dynamically assigns responsibility for a virtual router to one of the VRRP routers on a LAN. The VRRP router controlling the IPv4 or IPv6 addresses associated with a virtual router is called Master, and it forwards packets sent to these IPv4 or IPv6 addresses. VRRP Backups wait for a Master and take ownership when the Master is no longer detected.

The election protocol provides dynamic failover in the forwarding responsibility when the Master is unavailable. VRRP for IPv4 gains a higher-availability default path without configuring dynamic



routing or router discovery protocols on every end-host. VRRP for IPv6 gains a quick switch-over to Backup routers compared to the standard IPv6 Neighbor Discovery mechanisms.

In the previous releases VRRPv2 for IPv4 and VRRPv3 for IPv6 (draft-ietf-vrrp-ipv6-spec-08.txt) were implemented on the switch. The current release adds VRRPv3 for IPv4 and makes VRRPv3 for IPv6 compliant to RFC5798. The existing VRRPv2 for IPv4 feature remains unchanged.

---

## VRRPv3 guidelines

The switch also supports VRRPv2 for IPv4. If VRRP IPv6 is set on an interface it will run independent of the IPv4 version. Set the version of the VRRP IPv4 on the interface before configuring any other IPv4 VRRP attributes. The version is not set by default to a particular value. However, when sourcing older configuration files that do not have the version saved on them, the router will set it to VRRPv2 by default. If you change the version, all IPv4 configuration under that interface is automatically removed, and you are prompted for a confirmation before this operation.

ACL configuration is done through `ip vrrp` or `ipv6 vrrp` nodes; ACL commands for IPv4 will be common for version 2 and version 3 and ACL commands for IPv6 will remain the same.

Following features are added to make both IPv4 and IPv6 VRRPv3 features compliant to RFC5798:

- Advertisement vs Fast-advertisement — Prior to RFC5798, the minimum advertisement interval was 1 second, with Fast-advertisement a sub-second interval could be configured. When this feature is enabled, the VRRP ADVERTISEMENT packets are sent with type 7 instead of 1. With RFC5798 the sub-second interval is standardised, and in this release we send all packets for VRRPv3 with type 1. The use of Fast-advertisement remains the same. VRRPv2 packets will still be sent with type 7, if Fast-advertisement is enabled.
- Add Master-advertisement-interval — Previously, all virtual routers on the same VLAN were to have the same Advertisement-Interval configured. RFC 5798 states that, you can have different Advertisement Intervals on the Master and Backup. On Master, the Master-advertisement-interval and the Advertisement-Interval have the same value. On Backup, the Master-advertisement-interval is used to calculate the timers, and the locally configured Advertisement-Interval is ignored until the Backup transitions to Master. The Master-advertisement-interval value is put in the advertisement packet type sent by the Master
- Transition to master as specified in RFC 5798 — Previously, if a Backup receives an advertisement with a lower priority (or same priority but lower IP), it immediately sends its own advertisement and transitions to Master. However, RFC 5798 states that such packet must be discarded, which means it will transition to Master after the Master\_Down\_Timer expires
- Add skew-time — Skew-time is a new feature supported in this release, RFC 5798 states that skew-time is calculated depending on the priority, and Master-advertisement-interval assures that the Backup with highest priority sends the first advertisement when the Master goes down  
Skew time is calculated using the formula:  $((256 - \text{priority}) * \text{Master\_Adver\_Interval}) / 256$ .
- Add preempt-mode — Preempt-mode is a new attribute, and it is different from the `ipv6 vrrp <vrid> action preempt` command, which is an operational command issued when you want to stop the hold-down timer. RFC5798 states that preempt-mode should be set to false when you do not want a higher priority Backup to transition to Master. By default, it is set to true

**\* Note:**

Accept-mode is not fully implemented for IPv4 VRRPv3. You can only ping the virtual IP address, the same way as it is for IPv4 VRRPv2.

---

## VRRP configuration using ACLI

---

### Configuring the VRRP interface

Configure VRRP to provide fast failover of a default router for IPv6 LAN hosts, in order to create a VRRP instance.

#### Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.
- Do not configure RSMLT on the VLAN.
- You must specify a link-local address to associate with the virtual router.

#### About this task

VRRP supports a virtual IPv6 address shared between two or more routers that connect the common subnet to the enterprise network.

VRRP for IPv6 provides a faster switchover to an alternate default router than is possible using the ND protocol.

Perform this procedure to also configure the additional addresses for which the virtual router acts as a backup.

#### Procedure

1. Enter Interface Configuration mode:

```
enable

configure terminal

interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-port]] [, ...]} or interface vlan <1-4059>
```

**\* Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Associate an address with the virtual router for either link-local or global:
  - `ipv6 vrrp address <1-255> link-local WORD <0-127>`
  - `ipv6 vrrp address <1-255> global WORD <0-255>`

**\* Note:**

You must configure the link-local address before you configure the global address.

3. Enable VRRP for the interface:

```
ipv6 vrrp <1-255> enable
```

**Example**

Associate a link-local address with the virtual router ID 12:

```
Switch:1(config-if)#ipv6 vrrp address 12 link-local fe80::1234
```

Associate a global address with the virtual router ID 12

```
Switch:1(config-if)#ipv6 vrrp address 12 global 3333::1234/64
```

Enable VRRP for the interface:

```
Switch:1(config-if)#ipv6 vrrp 12 enable
```

## Variable definitions

Use the data in the following table to use the **ipv6 vrrp address** command.

| Variable                | Value                                                                                                                |
|-------------------------|----------------------------------------------------------------------------------------------------------------------|
| <1-255>                 | Specifies the virtual router ID. The virtual router acts as the default router for one or more associated addresses. |
| enable                  | Enables IPv6 VRRP. The default is disabled.                                                                          |
| global WORD <0-255>     | Specifies a global IPv6 address and mask to associate with the virtual router.                                       |
| link-local WORD <0-127> | Specifies a link-local IPv6 address to associate with the virtual router.                                            |

Use the data in the following table to use the **interface** command.

| Variable                                             | Value                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <1-4059>                                             | Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.                                                                                                                                                       |
| {slot/port[/sub-port][/-slot/port[/sub-port]][,...]} | Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port. |

## Viewing VRRP information

Display VRRP port or VLAN information to verify your configuration. Show VRRP information by IPv6 address or virtual router ID. If you enter a virtual router ID or an IPv6 address when you view VRRP information, the information applies only to that virtual router ID or for that interface.

### Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. View the configuration information for all interfaces:

```
show ipv6 vrrp interface [verbose]
```

3. View the configuration information for one or more ports:

```
show ipv6 vrrp interface gigabitethernet {slot/port[/sub-port]}[-slot/port[/sub-port]][,...][verbose]
```

4. View the configuration information for one or more VLANs:

```
show ipv6 vrrp interface vlan [<1-4059>] [verbose]
```

5. View the configuration information for one or more virtual router IDs:

```
show ipv6 vrrp interface vrid <1-255> [verbose]
```

6. View VRRP address information:

```
show ipv6 vrrp address
```

7. View VRRP address information for a link-local address:

```
show ipv6 vrrp address link-local WORD<0-127> [verbose]
```

8. View VRRP address information for a virtual router ID:

```
show ipv6 vrrp address vrid <1-255>
```

### Example

```
Switch:1>show ipv6 vrrp address
```

```
=====
 VRRP Info - GlobalRouter
=====
VRID P/V IP MAC STATE CONTROL

12 1/1 fe80:0:0:0:0:0:0:1234 00:00:5e:00:02:0c Init Disabled
VRID P/V MASTER PRIO ADV UP TIME

12 1/1 0:0:0:0:0:0:0:0 100 1 0 day(s), 00:00:00
VRID P/V CRITICAL IP CRITICAL IP ACCEPT
 ENABLED MODE
=====
```

```

12 1/1 0:0:0:0:0:0:0:0 No disable
VRID P/V BACKUP BACKUP-MASTER FAST (ENABLED) ACTION HLD REM
 P/V MASTER STATE ADV

12 1/1 disable down 400 (YES) none 30 0
VRID P/V GLOBAL ADDRESS

12 1/1 1111::2222/64
Flags Legend:
HLD DWN: Configured hold-down timer value, REM: REMaining hold-down timer value
--More-- (q = quit)

```

Switch:1#show ipv6 vrrp interface verbose

```

=====
Vlan Vrrp for IPv6 Extended
=====
VLAN VRRP MASTER
ID ID STATE CONTROL PRIORITY IPADDR

3 3 master enable 100 fe80:0:0:0:b2ad:aaff:fe40:4501
All 1 Vlan Vrrp Extended Entries out of 2 Total Num of Vrrp displayed
VLAN VRRP HOLDDWN ACTION CRITICAL CRITICAL
ID ID TIME IP ENABLE IPADDR

3 3 0 none disable 0:0:0:0:0:0:0:0
All 1 Vlan Vrrp Extended Entries out of 2 Total Num of Vrrp displayed
VLAN VRRP BACKUP BACKUP ADVERTISE FAST ADV FAST ADV MASTER ADV PREEMPT
ID ID MASTER MASTER INTERVAL INTERVAL ENABLE INTERVAL MODE
STATE (s) (ms) (ms)

3 3 disable down 1 200 disable 1000 enable
All 1 Vlan Vrrp Extended Entries out of 2 Total Num of Vrrp displayed
=====
Port Vrrp for IPv6 Extended
=====
PORT VRRP MASTER
NUM ID STATE CONTROL PRIORITY IPADDR

1/1 2 master enable 100 fe80:0:0:0:b2ad:aaff:fe40:4500
All 1 Port Vrrp Extended Entries out of 2 Total Num of Vrrp displayed
PORT VRRP HOLDDWN ACTION CRITICAL CRITICAL
NUM ID TIME IP ENABLE IPADDR

1/1 2 0 none disable 0:0:0:0:0:0:0:0
All 1 Port Vrrp Extended Entries out of 2 Total Num of Vrrp displayed

```

## VRRP

| PORT<br>NUM | VRRP<br>ID | BACKUP<br>MASTER | BACKUP<br>MASTER<br>STATE | ADVERTISE<br>INTERVAL<br>(s) | FAST ADV<br>INTERVAL<br>(ms) | FAST ADV<br>ENABLE | MASTER ADV<br>INTERVAL<br>(ms) | PREEMPT<br>MODE |
|-------------|------------|------------------|---------------------------|------------------------------|------------------------------|--------------------|--------------------------------|-----------------|
| 1/1         | 2          | disable          | down                      | 1                            | 200                          | disable            | 1000                           | enable          |

All 1 Port Vrrp Extended Entries out of 2 Total Num of Vrrp displayed

## Variable definitions

Use the data in the following table to use the `show ipv6 vrrp` commands.

| Variable                                             | Value                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| {slot/port[/sub-port][/-slot/port[/sub-port]][,...]} | Identifies the slot and port in one of the following formats: a single slot and port (slot/port), a range of slots and ports (slot/port-slot/port), or a series of slots and ports (slot/port,slot/port,slot/port). If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port. |
| link-local <i>WORD</i> <0–127>                       | Displays information by link-local IPv6 address.                                                                                                                                                                                                                                                                                                                                 |
| verbose                                              | Displays extended information.                                                                                                                                                                                                                                                                                                                                                   |
| vlan [ <i>&lt;1-4059&gt;</i> ]                       | Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.                                                                                                                                                       |
| vrid <i>&lt;1–255&gt;</i>                            | Displays information by virtual router ID.                                                                                                                                                                                                                                                                                                                                       |

## Configuring VRRP notification control

Perform this procedure to configure VRRP notification control.

### Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.

### About this task

By default, generation of SNMP traps for VRRP events is enabled.

### Procedure

1. Enter VRRP Router Configuration mode:

```
enable
configure terminal
router vrrp
```

2. Enable the VRRP-router to generate SNMP traps for events:

```
ipv6 send-trap enable
```

### Example

Disable generation of SNMP traps for VRRP events:

```
Switch:1(config-vrrp)#no ipv6 send-trap enable
```

---

## Configuring additional VRRP parameters for an interface

Configure VRRP to provide fast failover of a default router for IPv6 LAN hosts. VRRP supports a virtual IPv6 address shared between two or more routers that connect the common subnet to the enterprise network. VRRP for IPv6 provides a faster switchover to an alternate default router than is possible using the ND protocol.

Configure the parameters in this procedure if the default values do not meet your requirements.

### Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.
- Do not configure RSMLT on the VLAN.

### About this task

A switch that acts as a VRRP master does not reply to SNMP get requests to the VRRP virtual interface address. The switch will, however, respond to SNMP get requests to the physical IP address.

### Procedure

1. Enter Interface Configuration mode:

```
enable
```

```
configure terminal
```

```
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-
port]][, ...]} or interface vlan <1-4059>
```

#### Note:

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Configure the accept mode of the master router:

```
ipv6 vrrp <1-255> accept-mode enable
```

3. Determine if the router overrides the holddown timer:

```
ipv6 vrrp <1-255> action <none|preempt>
```

4. Configure the interval between advertisement messages:

## VRRP

```
ipv6 vrrp <1-255> adver-int <1-40>
```

5. Enable the backup VRRP switch for traffic forwarding:

```
ipv6 vrrp <1-255> backup-master enable
```

6. Configure the IP interface on the local router:

```
ipv6 vrrp <1-255> critical-ipv6-addr WORD<0-46> [critical-ipv6 enable]
```

7. Configure the fast advertisement interval:

```
ipv6 vrrp <1-255> fast-adv enable [fast-adv-int <200-1000>]
```

8. Configure the holddown timer:

```
ipv6 vrrp <1-255> holddown-timer <0-21600>
```

9. Configure the priority for the VRRP router:

```
ipv6 vrrp <1-255> priority <1-255>
```

### Example

Configure the fast advertisement interval:

```
Switch:1(config-if)#ipv6 vrrp 12 fast-adv enable fast-adv-int 400
```

Configure the holddown timer:

```
Switch:1(config-if)#ipv6 vrrp 12 holddown-timer 30
```

## Variable definitions

Use the data in the following table to use the **ipv6 vrrp** command.

| Variable              | Value                                                                                                                                                                                                                                                              |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <1-255>               | Specifies a number that uniquely identifies a virtual router on a VRRP router. The virtual router acts as the default router for one or more assigned addresses.                                                                                                   |
| accept-mode enable    | Controls whether the VRRP master or backup master accepts packets (other than neighbor discovery packets) destined to the IPv6 address associated with the virtual router. The default value is disable.                                                           |
| action <none preempt> | Lists options to override the holddown timer manually and force preemption: <ul style="list-style-type: none"><li>• none does not override the timer.</li><li>• preempt preempts the timer.</li></ul> This parameter applies only if the holddown timer is active. |

*Table continues...*



| Variable                      | Value                                                                                                                                                                                                                  |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| adver-int <1-40>              | Specifies the time interval, in seconds, between sending advertisement messages. The default is 1 second. Only the master router sends advertisements.                                                                 |
| backup-master enable          | Uses the backup VRRP switch for traffic forwarding. This option reduces the traffic on the vIST. The default is disabled.                                                                                              |
| critical-ipv6 enable          | Enables or disables the use of critical IP. When disabled, the VRRP ignores the availability of the address configured as critical IP. This address must be a local address. The default is disabled.                  |
| critical-ipv6-addr WORD<0-46> | Specifies an IP interface on the local router configured so that a change in its state causes a role switch in the virtual router (for example, from master to backup) in case the interface stops responding.         |
| fast-adv enable               | Enables or disables the fast advertisement interval. When disabled, the regular advertisement interval is used. The default is disable.                                                                                |
| fast-adv-int <200-1000>       | Configures the interval between VRRP advertisement messages. You must configure the same value on all participating routers.<br><br>This unit of measure must be in multiples of 200 milliseconds. The default is 200. |
| holddown-timer <0-21600>      | Configures the amount of time, in seconds, to wait before preempting the current VRRP master. The default is 0.                                                                                                        |
| priority <1-255>              | Specifies the priority value used by this VRRP router. The value 255 is reserved for the router that owns the IP addresses associated with the virtual router. The default is 100.                                     |

## Enabling IPv6 VRRP preempt-mode

You can configure IPv6 VRRP to preempt the existing router. If a new VRRP router is added to the network with a higher priority than the existing routers, then the new router becomes the master. If preempt-mode is disabled, then the new router does not become a master, it transitions to master only when the current master is down. By default, preempt-mode is enabled.

### Procedure

1. Enter Interface Configuration mode:

```
enable
configure terminal
```

```
interface GigabitEthernet {slot/port[/sub-port] [-slot/port[/sub-
port]] [,...]} or interface vlan <1-4059>
```

**\* Note:**

If your platform supports channelization for 40 Gbps ports and the port is channelized, you must also specify the sub-port in the format slot/port/sub-port.

2. Enter the following command:

```
ipv6 vrrp <vrid> preempt-mode enable
```

3. Use the following command to set the IPv6 VRRP preempt-mode to its default value:

```
default ipv6 vrrp <vrid> preempt-mode
```

4. Use the following command to disable the IPv6 VRRP preempt-mode:

```
no ipv6 <vrid> preempt-mode enable
```

### Example

```
Switch:1> enable
Switch:1# configure terminal
Switch:1(config)# interface gigabitethernet 1/2
```

#### Enabling IPv6 VRRP preempt-mode for interface 1/2

```
Switch:1(config-if)# ipv6 vrrp 1 preempt-mode enable
```

## Variable definitions

Use the data in the following table to use the `ipv6 vrrp <vrid>` command.

| Variable                                                   | Value                                                            |
|------------------------------------------------------------|------------------------------------------------------------------|
| <code>preempt-mode enable</code>                           | Enables preempt-mode for VRRPv3 for IPv6.                        |
| <code>default ipv6 vrrp &lt;vrid&gt; preempt-mode</code>   | Set the default preempt-mode value (enable) for VRRPv3 for IPv6. |
| <code>no ipv6 vrrp &lt;vrid&gt; preempt-mode enable</code> | Disables preempt-mode for VRRPv3 for IPv6.                       |

## VRRP configuration using EDM

### Configuring VRRP for an interface

Configure VRRP to provide fast failover of a default router for IPv6 LAN hosts. VRRP supports a virtual IPv6 address shared between two or more routers that connect the common subnet to the enterprise network. VRRP for IPv6 provides a faster switchover to an alternate default router than is possible using the ND protocol.

Perform this procedure to configure VRRP on either a brouter port or a VLAN.

## Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.
- Do not configure RSMLT on the VLAN.

## Procedure

1. In the navigation pane, expand the following folders: **Configuration > IPv6**.
2. Click **VRRP**.
3. Click the **Interface** tab.
4. Click **Insert**.
5. Beside the **IfIndex** field, click **Port** or **VLAN**.
6. Select a port or VLAN.
7. Click **OK**.
8. Type the virtual router ID.
9. Check **AcceptMode**, to control the packets sent to the IPv6 address associated to the virtual router.
10. Type the primary IP address.
11. Click **Insert**.

## Interface field descriptions

Use the data in the following table to use the **Interface** tab.

| Name                  | Description                                                                                                                                                                                                                                                                                                                             |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IfIndex</b>        | Shows the index value that uniquely identifies the interface to which this entry applies.                                                                                                                                                                                                                                               |
| <b>Vrld</b>           | Specifies a number that uniquely identifies a virtual router on a VRRP router.                                                                                                                                                                                                                                                          |
| <b>PrimaryIpAddr</b>  | Specifies the link-local address assigned to the VRRP.                                                                                                                                                                                                                                                                                  |
| <b>VirtualMacAddr</b> | Specifies the MAC address of the virtual router interface.                                                                                                                                                                                                                                                                              |
| <b>State</b>          | Shows the state of the virtual router interface. The possible states are <ul style="list-style-type: none"> <li>• initialize—waiting for a startup event</li> <li>• backup—monitoring availability and state of the master router</li> <li>• master—functioning as the forwarding router for the virtual router IP addresses</li> </ul> |

*Table continues...*

| Name                            | Description                                                                                                                                                                                              |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Control</b>                  | Displays whether VRRP is enabled or disabled for the port or VLAN.                                                                                                                                       |
| <b>Priority</b>                 | Specifies the priority value used by this VRRP router. The value 255 is reserved for the router that owns the IP addresses associated with the virtual router. The default is 100.                       |
| <b>AdvInterval</b>              | Specifies the time interval, in seconds, between sending advertisement messages. The default is 1 second.                                                                                                |
| <b>MasterIpAddr</b>             | Specifies the IP address of the physical interface of the Master's virtual router.                                                                                                                       |
| <b>UpTime</b>                   | Indicates the time interval since this virtual router exited the INIT state.                                                                                                                             |
| <b>CriticalIpAddr</b>           | Indicates the IP address of the interface that is critical to VRRP. If that IP interface is down, the VRRP state will transition to Backup, even if it has higher priority.                              |
| <b>CriticalIpAddrEnabled</b>    | Enables or disables the use of critical IP. When disabled, the VRRP ignores the availability of the address configured as critical IP. This address must be a local address. The default is disabled.    |
| <b>BackUpMaster</b>             | Uses the backup VRRP switch for traffic forwarding. This option reduces the traffic on the vIST. The default is disabled.                                                                                |
| <b>BackUpMasterState</b>        | Indicates if the Backup-Master is up. If the switch is in Master state, but Backup-Master is enabled, then the BACKUP MASTER STATE will be down.                                                         |
| <b>FasterAdvIntervalEnabled</b> | Enables or disables the fast advertisement interval. When disabled, the regular advertisement interval is used. The default is disable.                                                                  |
| <b>FasterAdvInterval</b>        | Configures the interval between VRRP advertisement messages. The default is 200.<br>Enter the values in multiples of 200 milliseconds.                                                                   |
| <b>AcceptMode</b>               | Controls whether the VRRP master or backup master accepts packets (other than neighbor discovery packets) destined to the IPv6 address associated with the virtual router. The default value is disable. |
| <b>PreemptMode</b>              | Issued to preempt the existing router. If a new router is added to the network with its priority higher than the existing routers, then the new router becomes the master.                               |

*Table continues...*

| Name                         | Description                                                                                                                                                                                                                                                                                       |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Action</b>                | Lists options to override the hold-down timer manually and force preemption: <ul style="list-style-type: none"> <li>• <b>none</b> does not override the timer.</li> <li>• <b>preemptHoldDownTimer</b> preempts the timer.</li> </ul> This parameter applies only if the holddown timer is active. |
| <b>HoldDownTimer</b>         | Configures the amount of time, in seconds, to wait before preempting the current VRRP master. The default is 0.                                                                                                                                                                                   |
| <b>HoldDownTimeRemaining</b> | Indicates the amount of time, in seconds, left before the HoldDownTimer expires.                                                                                                                                                                                                                  |
| <b>MasterAdvInterval</b>     | On the VRRP master, the master advertisement interval is same as the advertisement interval. On the VRRPv3 Backup, the master advertisement interval is set to the Advertisement configured on the Master (received in the packet).                                                               |

---

## Configuring VRRP notification control

Perform this procedure to configure VRRP notification control.

### Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **VRRP**.
3. Click the **Globals** tab.
4. Select **enabled**.
5. Click **Apply**.

## Globals field descriptions

Use the data in the following table to use the **Globals** tab.

| Name                     | Description                                                                                                                                                         |
|--------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NotificationCntrl</b> | Indicates whether the VRRP-enabled router generates SNMP traps for events. <ul style="list-style-type: none"> <li>• <b>enabled</b>: Generate SNMP traps.</li> </ul> |

| Name | Description                                                                                                              |
|------|--------------------------------------------------------------------------------------------------------------------------|
|      | <ul style="list-style-type: none"> <li>• <b>disabled</b>: Do not generate SNMP traps.</li> </ul> The default is enabled. |

## Configuring additional addresses on the VRRP interface

Perform this procedure to configure the additional addresses for which the virtual router acts as a back up.

### Before you begin

- Assign an IPv6 address to the interface.
- Enable routing globally.
- Do not configure RSMLT on the VLAN.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **VRRP**.
3. Click the **Interface** tab.
4. Select an interface.
5. Click **AssociatedIPAddr**.
6. Click **Insert**.
7. Type the address.
8. Type the prefix length.
9. Click **Insert**.

## Address List field descriptions

Use the data in the following table to use the **Address List** tab.

| Name                      | Description                                                                                                                                                                     |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IpAddr</b>             | Specifies an IP address that is associated with a virtual router. The number of rows on this tab equals the number of IP addresses associated (backed up) by the virtual router |
| <b>IpAddrPrefixLength</b> | Specifies the length of the prefix in bits.                                                                                                                                     |

# Chapter 10: RSMLT

This chapter provides concepts and procedures to complete IPv6 Routed Split MultiLink Trunking (RSMLT) configuration.

---

## RSMLT

Routed Split Multi-Link Trunking (RSMLT) is an enhancement to SMLT that enables the exchange of Layer 3 information between peer nodes in a switch cluster. RSMLT provides two main advantages over SMLT:

- provides backup for the peer after the peer goes down
- routes traffic on behalf of the peer to prevent Virtual Inter-Switch Trunk (vIST) overload

IPv6 RSMLT enables the subsecond failover for IPv6 forwarding.

The overall model for IPv6 RSMLT is essentially identical to that of IPv4 RSMLT. In short, RSMLT peers exchange their IPv6 configuration and track their states by using vIST messages. An RSMLT node always performs IPv6 forwarding on the IPv6 packets destined to the MAC addresses of the peer. If an RSMLT node detects that the RSMLT peer is down, the node forwards IPv6 traffic destined to the IPv6 addresses of the peer.

With RSMLT enabled, an SMLT switch performs IP forwarding on behalf of the SMLT peer, which prevents IP traffic from being sent over the vIST.

IPv6 RSMLT supports the full set of topologies and features supported by IPv4 RSMLT, including SMLT triangles, squares, and SMLT full-mesh topologies, with routing enabled on the core VLANs.

Because you configure RSMLT on a VLAN, not at the IP layer, the configuration applies to both IPv4 and IPv6. You cannot enable or disable RSMLT on a VLAN for IPv6 but not IPv4; or for IPv4 but not IPv6.

With IPv6, you must configure the RSMLT peers to use the same set of IPv6 prefixes.

Supported routing protocols include the following:

- IPv6 static routes
- OSPFv3

For more information about the IPv4 RSMLT model, see *Configuring IP Routing on Avaya Virtual Services Platform 7200 Series and 8000 Series*, NN47227-505 or *Configuration - IP Routing for*

*Avaya Virtual Services Platform 4000 Series, NN46251-505.* This section focuses on the differences between the IPv4 and IPv6 models.

### IPv6 differences

The following list identifies ways in which the IPv6 implementation of RSMLT differs from the IPv4 implementation of RSMLT.

- After the switch begins to forward traffic on behalf of the peer, duplicate address detection (DAD) is not executed for the IPv6 address of the peer. The implementation assumes that the peer IPv6 address is already known to be unique.
- An RSMLT switch installs a neighbor entry for the peer IPv6 address immediately after the peer disappearance is detected, possibly while a route for the peer still exists. This action can result in packets destined to the peer IPv6 address being delivered to the CP for a short period of time.
- You cannot configure a vIST with IPv6 peer address
- In a dual-stack VLAN, adding or deleting IPv4 or IPv6 does not affect the RSMLT functionality of one another. If you add IPv4 or IPv6 to an existing IPv6 or IPv4 RSMLT VLAN, the RSMLT state for the protocol you add second will be the same as the previous RSMLT state.

---

## RSMLT configuration using ACLI

---

### Configuring RSMLT on a VLAN

Configure RSMLT on a VLAN to exchange Layer 3 information between peer nodes in a switch cluster. This configuration applies to both IPv4 and IPv6.

#### Before you begin

- An IP routing protocol is enabled on VLAN Layer 3 interfaces.
- VLANs with Layer 3 interfaces participate in Split MultiLink Trunking (SMLT).

#### About this task

The VLAN can be either IPv4 or IPv6, or both. RSMLT configuration on a VLAN simultaneously affects both IPv4 and IPv6. By default, RSMLT is disabled on a VLAN.

#### Procedure

1. Enter VLAN Interface Configuration mode:

```
enable
configure terminal
interface vlan <1-4059>
```

2. Configure the holddown timer:

```
ip rsmlt holddown-timer <0-3600>
```



## 3. Configure the holdup timer:

```
ip rsmlt holdup-timer <0-9999>
```

## 4. Enable RSMLT on the VLAN:

```
ip rsmlt
```

**Example**

Configure the holddown timer:

```
Switch:1(config-if)#ip rsmlt holddown-timer 100
```

Configure the holdup timer:

```
Switch:1(config-if)#ip rsmlt holdup-timer 200
```

Enable RSMLT on the VLAN:

```
Switch:1(config-if)#ip rsmlt
```

**Variable definitions**

Use the data in the following table to use the `ip rsmlt` command.

| Variable                | Value                                                                                                                                                                                                                                                                              |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| holddown-timer <0-3600> | <p>Defines how long the recovering or restarting system remains in a non-Layer 3 forwarding mode for the peer router MAC address. The default is 60.</p> <p>If you disable RSMLT on a VLAN, non default values for this variable do not save across restarts.</p>                  |
| holdup-timer <0-9999>   | <p>Defines how long the RSMLT system maintains forwarding for its peer. The value is a range from 0 to 3600 seconds or 9999. 9999 means infinity. The default is 180.</p> <p>If you disable RSMLT on a VLAN, non default values for this variable do not save across restarts.</p> |

Use the data in the following table to use the `interface` command.

| Variable | Value                                                                                                                                                                                                                             |
|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <1-4059> | <p>Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1.</p> |

---

## Enabling RSMLT Edge support

Enable RSMLT Edge support to store the RSMLT peer MAC and IP address-pair in the local configuration file and restore the configuration if the peer does not restore after a simultaneous restart of both RSMLT peer systems.

### About this task

RSMLT Edge support configuration applies to both IPv4 and IPv6. You do not configure IPv4 and IPv6 separately.

The RSMLT Edge support default is disabled.

### Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enable RSMLT Edge support:

```
ip rsmlt edge-support
```

### Example

If you have enabled RSMLT Edge Support, disable the feature as follows:

```
Switch:1(config)#no ip rsmlt edge-support
```

---

## Viewing RSMLT information

Show RSMLT information to view data about all RSMLT interfaces. The output of the command includes IPv6 information for the local and peer nodes.

### Procedure

1. Enter Privileged EXEC mode:

```
enable
```

2. Show RSMLT information about the interface:

```
show ip rsmlt [local|peer] [vrf WORD<1-16>] [vrfids WORD<0-512>]
```

3. View the status of the switch to act as a peer forwarder:

```
show ip rsmlt edge-support
```

### Example

```
Switch:1>show ip rsmlt
```

```
=====
Ip Rsmlt Local Info - GlobalRouter
=====
```

```

VID IP MAC ADMIN OPER HDTMR HUTMR

101 101.1.1.32 00:24:7f:9e:da:01 Enable Up 100 200
102 102.1.1.32 00:24:7f:9e:da:02 Enable Up 60 180

VID SMLT ID

101 101
102 102

VID IPv6 MAC ADMIN OPER HDTMR HUTMR

101 1010:0:0:0:0:0:0:0/64
 1010:0:0:0:0:0:0:0:32/64
 fe80:0:0:0:224:7fff:fe9e:da01/128
102 1020:0:0:0:0:0:0:0/64
 1020:0:0:0:0:0:0:0:32/64
 fe80:0:0:0:224:7fff:fe9e:da02/128
 00:24:7f:9e:da:02 Enable Up 60 180

VID SMLT ID

101 101
102 102

=====
 Ip Rsmlt Peer Info - GlobalRouter
=====

VID IP MAC ADMIN OPER HDTMR HUTMR

101 101.1.1.33 00:24:7f:9e:ea:01 Enable Up 100 200
102 102.1.1.33 00:24:7f:9e:ea:00 Enable Up 60 180

VID HDT REMAIN HUT REMAIN SMLT ID

101 60 180 101
102 60 180 102

VID IPv6 MAC ADMIN OPER HDTMR HUTMR

101 1010:0:0:0:0:0:0:0/64
 1010:0:0:0:0:0:0:0:33/64
 fe80:0:0:0:224:7fff:fe9e:ea01/128
102 1020:0:0:0:0:0:0:0/64
 1020:0:0:0:0:0:0:0:33/64
 fe80:0:0:0:224:7fff:fe9e:ea00/128
 00:24:7f:9e:ea:00 Enable Up 60 180

VID HDT REMAIN HUT REMAIN SMLT ID

101 60 180
101
102 60 180
102

```

```
Switch:1>show ip rsmlt edge-support
RSMLT Peer Info:
 rsmlt-peer-forwarding : disable
```

## Variable definitions

Use the data in the following table to use the `show ip rsmlt` command.

| Variable                   | Value                                      |
|----------------------------|--------------------------------------------|
| local                      | Shows local RSMLT information.             |
| peer                       | Shows RSMLT information for the peer.      |
| vrf <i>WORD</i> <1-16>     | Shows information for a specific VRF name. |
| vrfids <i>WORD</i> <0-512> | Shows information for a specific VRF ID.   |

---

## RSMLT configuration using EDM

---

### Configuring RSMLT on a VLAN

Configure RSMLT on a VLAN to exchange Layer 3 information between peer nodes in a switch cluster. This configuration applies to both IPv4 and IPv6.

#### Before you begin

- Enable an IP routing protocol on VLAN Layer 3 interfaces.
- Ensure VLANs with Layer 3 interfaces participate in Split MultiLink Trunking (SMLT).

#### About this task

The VLAN can be either IPv4 or IPv6, or both. RSMLT configuration on a VLAN simultaneously affects both IPv4 and IPv6.

#### Procedure

1. In the navigation tree, expand the following folders: **Configuration > VLAN**.
2. Click **VLANs**.
3. Click the **Basic** tab.
4. Select a VLAN.
5. Click **IP**.
6. Click the **RSMLT** tab.
7. Select **Enable**.

8. In the **HoldDownTimer** field, type a hold-down timer value.
9. In the **HoldUpTimer** field, type a holdup timer value.
10. Click **Apply**.

## RSMLT field descriptions

Use the data in the following table to use the **RSMLT** tab.

| Name                 | Description                                                                                                                                                                                                                                                                                                              |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Enable</b>        | Enables RSMLT. The default is disabled.                                                                                                                                                                                                                                                                                  |
| <b>HoldDownTimer</b> | <p>Defines how long the recovering or restarting system remains in a non-Layer 3 forwarding mode for the peer router MAC address.</p> <p>The range of this value is from 0 to 3600 seconds. The default is 60.</p> <p>If you disable RSMLT on a VLAN, non default values for this field do not save across restarts.</p> |
| <b>HoldUpTimer</b>   | <p>Defines how long the RSMLT system maintains forwarding for its peer. The value is a range from 0 to 3600 seconds or 9999. 9999 means infinity. The default is 180.</p> <p>If you disable RSMLT on a VLAN, non default values for this field do not save across restarts.</p>                                          |

---

## Enabling RSMLT Edge support

Enable RSMLT Edge support to store the RSMLT peer MAC and IP address-pair in the local configuration file and restore the configuration if the peer does not restore after a simultaneous restart of both RSMLT peer systems.

The default is disabled.

### About this task

RSMLT Edge support configuration applies to both IPv4 and IPv6.

### Procedure

1. In the navigation pane, expand the following folders: **Configuration > IP**.
2. Click **RSMLT**.
3. Click the **Globals** tab.
4. Select **EdgeSupportEnable**.
5. Click **Apply**.

## Modifying the RSMLT local information

Edit the existing RSMLT configuration for the local node in the cluster.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **RSMLT**.
3. Click the **Local** tab.
4. Double-click a cell to change the value.
5. Click **Apply**.

### Local field descriptions

Use the data in the following table to use the **Local** tab.

| Name                    | Description                                                                                                                                                             |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IfIndex</b>          | Shows the route SMLT operation index.                                                                                                                                   |
| <b>Ipv6Addr</b>         | Configures the IPv6 address of the RSMLT interface.                                                                                                                     |
| <b>Ipv6PrefixLength</b> | Configures the IPv6 prefix length.                                                                                                                                      |
| <b>Enable</b>           | Enables or disables RSMLT. The default is disabled.                                                                                                                     |
| <b>HoldDownTimer</b>    | Defines how long the recovering/rebooting switch remains in a non-Layer 3 forwarding mode for the peer router MAC address.<br><br>The default is 0.                     |
| <b>HoldUpTimer</b>      | Defines how long the RSMLT switch maintains forwarding for its peer. The value is a range from 0 to 3600 seconds or 9999. 9999 means infinity.<br><br>The default is 0. |
| <b>OperStatus</b>       | Displays the RSMLT operating status as either up or down.                                                                                                               |
| <b>SmltId</b>           | Specifies the ID range for the SMLT.                                                                                                                                    |
| <b>VlanId</b>           | Configures the VLAN ID.                                                                                                                                                 |
| <b>MacAddr</b>          | Configures the MAC address of the VLAN.                                                                                                                                 |
| <b>VrfId</b>            | Indicates the virtual router ID to which the local RSMLT instance belongs.                                                                                              |
| <b>VrfName</b>          | Indicates the virtual router name to which the local RSMLT instance belongs.                                                                                            |

## Modifying RSMLT peer information

Edit the existing configuration for the RSMLT peer node in the cluster.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **RSMLT**.
3. Click the **Peer** tab.
4. Double-click a cell to change the value.
5. Click **Apply**.

### Peer field descriptions

Use the data in the following table to use the **Peer** tab.

| Name                         | Description                                                                                                                                                                                                                |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IfIndex</b>               | Shows the route SMLT operation index.                                                                                                                                                                                      |
| <b>Ipv6Addr</b>              | Configures the IPv6 address of the RSMLT interface.                                                                                                                                                                        |
| <b>Ipv6PrefixLength</b>      | Configures the IPv6 prefix length.                                                                                                                                                                                         |
| <b>AdminStatus</b>           | Shows the administrative status of RSMLT on the peer.                                                                                                                                                                      |
| <b>HoldDownTimer</b>         | Defines how long the recovering/rebooting switch remains in a non-Layer 3 forwarding mode for the peer router MAC address.<br><br>The default is 0.                                                                        |
| <b>HoldDownTimeRemaining</b> | Indicates the time remaining in the HoldDownTimer.                                                                                                                                                                         |
| <b>HoldUpTimer</b>           | Defines how long the RSMLT switch maintains forwarding for its peer. The value is a range from 0 to 3600 seconds or 9999. 9999 means infinity.<br><br>The default is 0.                                                    |
| <b>HoldUpTimeRemaining</b>   | Indicates the time remaining in the HoldUpTimer.                                                                                                                                                                           |
| <b>OperStatus</b>            | Displays the RSMLT operating status as either up or down.                                                                                                                                                                  |
| <b>SmltId</b>                | Specifies the ID range for the SMLT.                                                                                                                                                                                       |
| <b>VlanId</b>                | Specifies the VLAN ID in the range of 1 to 4059. VLAN IDs 1 to 4059 are configurable. The system reserves VLAN IDs 4060 to 4094 for internal use. VLAN ID 1 is the default VLAN and you cannot create or delete VLAN ID 1. |
| <b>MacAddr</b>               | Configures the MAC address of the VLAN.                                                                                                                                                                                    |

*Table continues...*

| Name           | Description                                                  |
|----------------|--------------------------------------------------------------|
| <b>VrfId</b>   | Indicates the virtual router ID to which the peer belongs.   |
| <b>VrfName</b> | Indicates the virtual router name to which the peer belongs. |

---

## Viewing RSMLT Edge peers

View the RSMLT peers for which the switch acts as a peer forwarder.

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IPv6**.
2. Click **RSMLT**.
3. Click the **Edge Peers** tab.

## Edge Peers field descriptions

Use the data in the following table to use the **Edge Peers** tab.

| Name                        | Description                                              |
|-----------------------------|----------------------------------------------------------|
| <b>PeerVlanId</b>           | Specifies the ID of the VLAN associated with this entry. |
| <b>PeerIpv6Address</b>      | Specifies the IPv6 address of the peer RSMLT interface.  |
| <b>PeerIpv6PrefixLength</b> | Specifies the peer IPv6 address prefix.                  |
| <b>PeerMacAddress</b>       | Specifies the peer MAC address.                          |



# Chapter 11: Viewing IPv6 connections

This chapter provides procedures you can use to view IPv6 connection information.

You can establish network connectivity with the following protocols:

- Transmission Control Protocol (TCP), for connection-oriented sessions
- User Datagram Protocol (UDP), for connectionless sessions

When you view TCP information you can

- check the health of the connections, from the switch perspective, as they traverse the network
- detect intermittent connectivity
- detect attacks on resources
- determine which applications are active by checking the port numbers

UDP endpoint information tells you about local and remote UDP activity.

When you view UDP information you can

- determine which applications are active by checking the local and remote port numbers
- identify processes within a UDP session to allow multiplexing of a port mapping for UDP

---

## Viewing IPv6 connections using ACLI

---

### Viewing TCP and UDP information

Perform this procedure to view the TCP and UDP configuration information for IPv6.

#### Procedure

1. Enter Privileged EXEC mode:  
`enable`
2. Display IPv6 TCP connection information:  
`show ipv6 tcp connections`
3. Display IPv6 TCP listener information for the specified IPv6 address:

## Viewing IPv6 connections

```
show ipv6 tcp listener
```

### 4. Display IPv6 TCP properties

```
show ipv6 tcp properties
```

### 5. Display IPv6 TCP statistics

```
show ipv6 tcp statistics
```

### 6. Display IPv6 UDP information:

```
show ipv6 udp endpoints
```

**OR**

```
show ipv6 udp local_addr WORD<0-128> [{slot/port[sub-port]}]
```

**OR**

```
show ipv6 udp remote_addr WORD<0-128> [{slot/port[sub-port]}]
```

## Example

```
Switch:1>show ipv6 tcp connections
```

```
=====
TCP connection table info
=====
```

| LOCALPORT | LOCALADDR          | REMOTEPORT | REMOTEADDR | STATE       |
|-----------|--------------------|------------|------------|-------------|
| 23        | 3000:0:0:0:0:0:0:1 |            |            |             |
| 33471     | 3000:0:0:0:0:0:0:2 |            |            | established |
| 23        | 4000:0:0:0:0:0:0:1 |            |            |             |
| 3472      | 4000:0:0:0:0:0:0:2 |            |            | established |

```
Switch:1>show ipv6 tcp listener
```

```
=====
TCP listener table info
=====
```

| LOCALPORT | LOCALADDR        |
|-----------|------------------|
| 21        | 0:0:0:0:0:0:0:0: |
| 22        | 0:0:0:0:0:0:0:0: |
| 23        | 0:0:0:0:0:0:0:0: |
| 80        | 0:0:0:0:0:0:0:0: |
| 443       | 0:0:0:0:0:0:0:0: |
| 513       | 0:0:0:0:0:0:0:0: |

```
Switch:1#show ipv6 tcp properties
```

```
show ip tcp global properties command:
```

```

RtoAlgorighm constant
RtoMin 5002 milliseconds
RtoMax 60128 milliseconds
MaxConn 127
```

```
Switch:1#show ipv6 tcp statistics
```

```
show ipv6 tcp global statistics:
```

```

ActiveOpens: 0
PassiveOpens: 6
AttemptFails: 0
EstabResets: 0
CurrEstab: 2
InSegs: 50
OutSegs: 38
```

```
RetransSegs: 0
InErrs: 0
OutRsts: 2
HCInSegs: 38
HCOutSegs: 38
```

```
Switch:1>show ipv6 udp endpoints
```

```
=====
 UDP endpoint table info
=====
LOCALPORT LOCALADDR
REMOTEPORT REMOTEADDR INSTANCE PROCESS

69 0:0:0:0:0:0:0:0
0 0:0:0:0:0:0:0:0 1219584048 0
161 0:0:0:0:0:0:0:0
0 0:0:0:0:0:0:0:0 1219585596 0
```

---

## Viewing IPv6 connections using EDM

---

### Viewing TCP global information

View TCP and UDP information to view the current configuration.

#### About this task

The fields on the TCP global tab provide information about the handshake (SYN) configuration and the maximum number of TCP connections you can create on your system.

When you initiate a TCP connection, both end points send handshake information to create the channel.

The retransmission algorithm and fields display the configured timeout value and minimum and maximum retransmission times that your system uses to terminate a connection attempt that falls outside your specified parameters.

#### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IP** or **Configuration > IPv6**.
2. Click **TCP/UDP**.
3. Click the **TCP Globals** tab.

### TCP Global field descriptions

Use the data in the following table to use the **TCP Globals** tab.

| Name                | Description                                                                                                   |
|---------------------|---------------------------------------------------------------------------------------------------------------|
| <b>RtoAlgorithm</b> | Determines the timeout value used for retransmitting unacknowledged octets.                                   |
| <b>RtoMin</b>       | Displays the minimum time (in milliseconds) permitted by a TCP implementation for the retransmission timeout. |
| <b>RtoMax</b>       | Displays the maximum time (in milliseconds) permitted by a TCP implementation for the retransmission timeout. |
| <b>MaxConn</b>      | Displays the maximum connections for the device.                                                              |

## Viewing TCP connections information

View information about TCP connections.

### About this task

Among other things, the fields on the TCP connections tab provide important information about the health of connections that traverse your switch.

In particular, the state column lets you know the state of each TCP connection. Of these, synSent, synReceived, and established indicate whether or not a channel is established and listen indicates when an end system is waiting for a returning handshake (SYN).

### Procedure

1. In the navigation tree, expand the following folders: **Configuration > IP** or **Configuration > IPv6**.
2. Click **TCP/UDP**.
3. Click the **TCP Connections** tab.

## TCP Connections field descriptions

Use the data in the following table to use the **TCP Connections** tab.

| Name                    | Description                                                                    |
|-------------------------|--------------------------------------------------------------------------------|
| <b>LocalAddressType</b> | Displays the type (IPv6 or IPv4) for the address in the LocalAddress field.    |
| <b>LocalAddress</b>     | Displays the IPv6 address for the TCP connection.                              |
| <b>LocalPort</b>        | Displays the local port number for the TCP connection.                         |
| <b>RemAddressType</b>   | Displays the type (IPv6 or IPv4) for the remote address of the TCP connection. |
| <b>RemAddress</b>       | Displays the IPv6 address for the remote TCP connection.                       |

*Table continues...*

| Name           | Description                                                                                                                                                                                                                                                                                                                                                    |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>RemPort</b> | Displays the remote port number for the TCP connection.                                                                                                                                                                                                                                                                                                        |
| <b>State</b>   | Displays an integer that represents the state for the connection: <ul style="list-style-type: none"> <li>• closed</li> <li>• listen</li> <li>• synSent</li> <li>• synReceived</li> <li>• established</li> <li>• finWait1</li> <li>• finWait2</li> <li>• closeWait</li> <li>• lastAck(9)</li> <li>• closing</li> <li>• timeWait</li> <li>• deleteTCB</li> </ul> |
| <b>Process</b> | Displays the process ID for the system process associated with the TCP connection.                                                                                                                                                                                                                                                                             |

---

## Viewing TCP listeners information

View TCP listener information.

### About this task

The TCP listeners table provides a detailed list of systems that are in the listening state.

When a connection is in the listen state an end point system is waiting for a returning handshake (SYN). The normal listening state should be very transient, changing all of the time.

Two or more systems going to a common system in an extended listening state indicates the need for further investigation.

End systems in an extended listening state can indicate a broken TCP connection or a DOS attack on a resource.

This type of DOS attack, known as a SYN attack, results from the transmission of SYNs with no response to return replies.

While many systems can detect a SYN attack, the TCP listener statistics can provide additional forensic information.

**Procedure**

1. In the navigation tree, expand the following folders: **Configuration > IP** or **Configuration > IPv6**.
2. Click **TCP/UDP**.
3. Click the **TCP Listeners** tab.

**TCP Listeners field descriptions**

Use the data in the following table to use the **TCP Listeners** tab.

| Name                    | Description                                                                        |
|-------------------------|------------------------------------------------------------------------------------|
| <b>LocalAddressType</b> | Displays the type (IPv6 or IPv4) for the address in the LocalAddress field.        |
| <b>LocalAddress</b>     | Displays the IPv6 address for the TCP connection.                                  |
| <b>LocalPort</b>        | Displays the local port number for the TCP connection.                             |
| <b>Process</b>          | Displays the process ID for the system process associated with the TCP connection. |

**Viewing UDP endpoint information**

View UDP Endpoints to confirm correct configuration.

**About this task**

You can use UDP endpoint information to display local and remote UDP activity.

Since UDP is a protocol used to establish connectionless network sessions, you need to monitor local and remote UDP activity and to know which applications are running over UDP.

You can determine which applications are active by checking the port number.

Processes are further identified with a UDP session to allow for the multiplexing of a port mapping for UDP.

**Procedure**

1. In the navigation tree, expand the following folders: **Configuration > IP** or **Configuration > IPv6**.
2. Click **TCP/UDP**.
3. Click the **UDP Endpoints** tab.

**UDP Endpoints field descriptions**

Use the data in the following table to use the **UDP Endpoints** tab.

| <b>Name</b>              | <b>Description</b>                                                      |
|--------------------------|-------------------------------------------------------------------------|
| <b>LocalAddressType</b>  | Displays the local address type (IPv6 or IPv4).                         |
| <b>LocalAddress</b>      | Displays the local IPv6 address.                                        |
| <b>LocalPort</b>         | Displays the local port number.                                         |
| <b>RemoteAddressType</b> | Displays the remote address type (IPv6 or IPv4).                        |
| <b>RemoteAddress</b>     | Displays the remote IPv6 address.                                       |
| <b>RemotePort</b>        | Displays the remote port number.                                        |
| <b>Instance</b>          | Distinguishes between multiple processes connected to the UDP endpoint. |
| <b>Process</b>           | Displays the ID for the UDP process.                                    |

# Chapter 12: IPv6 Alternative Routes

This chapter provides concepts and procedures to complete IPv6 alternative routes configuration using the ACLI.

## Related links

[Alternative routes](#) on page 216

[Configuring IPv6 alternative routes](#) on page 217

---

## Alternative routes

To avoid traffic interruption, you can globally enable the alternative routes feature so the router can use the next-best route, also known as an alternative route, if the best route becomes unavailable.

Routers learn routes to a destination through routing protocols. Routers maintain a routing table of the learned alternative routes sorted in order by route preference, route costs, and route sources. The first route on the list is the best route and the route that the router prefers to use.

The alternative route concept also applies between routing protocols. For example, if an OSPFv3 route becomes unavailable and an alternative RIPng route is available, the system activates the RIPng route without waiting for the update interval to expire.

### Route preference

On the switch, all standard routing protocols have default preference values that determine the routing priority of the protocol. The router uses default preferences to select the best route when a clash exists in preference between the protocols.

You can modify the global preference for a protocol to give the protocol a higher or lower priority than other protocols. If you change the global preference for a static route and all best routes remain best routes, only the local route tables change. However, if the protocol preference change causes best routes to no longer be best routes, the change affects neighboring route tables.

### Important:

Changing route preferences is a process-intensive operation that can affect system performance and network reach while you perform route preference procedures. Avaya recommends that if you want to change preferences for static routes or routing protocols, do so when you configure routes or during a maintenance window.

If a router learns a route with the same network mask and cost values from multiple sources, the router uses the route preferences to select the best route to add to the forwarding database.



**\* Note:**

With IPv6 routes, to modify the preference for a route, you do *not* need to disable a route before you edit the configuration.

**Preferences for static routes**

When you configure a static route on the switch, you can specify a global preference for the route. You can also specify an individual route preference that overrides the global static route preference. The preference value can be between 0 and 255, with 0 reserved for local routes and 255 representing an unreachable route.

**Preferences for dynamic routes**

You can modify the preference value for dynamic routes through route filtering and IP policies, and this value overrides the global preference for the protocol.

The following table shows the default preferences for routing protocols and route types. Use this table to help you modify the global preference value.

**Table 9: Routing protocol default preferences**

| Protocol               | Default preference |
|------------------------|--------------------|
| Local                  | 0                  |
| Static                 | 5                  |
| SPBM_L1                | 7                  |
| OSPF intra-area        | 20                 |
| OSPF inter-area        | 25                 |
| Exterior BGP           | 45                 |
| RIP/RIPng              | 100                |
| OSPF external type 1   | 120                |
| OSPF external type 2   | 125                |
| IBGP                   | 175                |
| Staticv6               | 5                  |
| OSPFv3 intra-area      | 20                 |
| OSPFv3 inter-area      | 25                 |
| OSPFv3 external type 1 | 120                |
| OSPFv3 external type 2 | 125                |

**Related links**

[IPv6 Alternative Routes](#) on page 216

---

## Configuring IPv6 alternative routes

Use this procedure to configure IPv6 alternative routes and view the configuration on the switch.

**Procedure**

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Configure an IPv6 alternative route:

```
[no] [default] ipv6 alternative-route
```

**\* Note:**

IPv6 alternative routes are enabled by default.

3. Verify the configuration of the IPv6 alternative route:

```
show ipv6 global
show ipv6 route alternative
```

**Example:**

```
Switch:1>enable
Switch:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch:1(config)#ipv6 alternative-route
```

```
Switch:1#show ipv6 global
forwarding : disable
default-hop-cnt : 64
number-of-interfaces : 0
icmp-error-interval : 1000
icmp-error-quota : 50
icmp-unreach-msg : disable
icmp-echo-multicast-request : enable
static-route-admin-status : enable
alternative-route : enable
ecmp : disable
ecmp-max-path : 1
source-route : disable
```

```
Switch:1#show ipv6 route alternative
```

```
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

0:0:0:0:0:ffff:301:a02/128 0:0:0:0:0:0:0:0 T-10 STATIC 1 0 B 5
2910:0:0:1:0:0:0:0/64 fe80:0:0:0:b2ad:aaff:fe42:dd00 V-3 OSPF 2 0 B 20
2912:0:0:1:0:0:0:0/64 0:0:0:0:0:0:0:0 V-1001 LOCAL 1 0 B 0
2912:0:0:1:0:0:0:0/64 0:0:0:0:0:0:0:0 T-10 BGP 1 0 A 45
2912:0:0:1:0:0:12:1/128 0:0:0:0:0:0:0:0 V-1001 LOCAL 1 0 B 0
3000:0:0:1:0:0:0:0/64 0:0:0:0:0:0:0:0 V-3 LOCAL 1 0 B 0
3000:0:0:1:0:0:12:1/128 0:0:0:0:0:0:0:0 V-3 LOCAL 1 0 B 0
4001:0:0:1:0:0:0:0/64 0:0:0:0:0:0:0:0 T-10 LOCAL 1 0 B 0
4001:0:0:1:0:0:0:1/128 0:0:0:0:0:0:0:0 T-10 LOCAL 1 0 B 0
5910:0:0:1:0:0:0:0/64 0:0:0:0:0:0:0:0 T-10 BGP 1 0 B 45
5910:0:0:1:0:0:0:0/64 fe80:0:0:0:b2ad:aaff:fe42:dd00 V-3 OSPF 2 0 A 120
5910:0:0:2:0:0:0:0/64 0:0:0:0:0:0:0:0 T-10 BGP 1 0 B 45
5910:0:0:2:0:0:0:0/64 fe80:0:0:0:b2ad:aaff:fe42:dd00 V-3 OSPF 2 0 A 120
=====
```

```
13 out of 13 Total Num of Route Entries displayed.
```

---

TYPE Legend:  
A=Alternative Route, B=Best Route, E=Ecmp Route

**Related links**

[IPv6 Alternative Routes](#) on page 216

# Chapter 13: IPv6 configuration examples

The following sections show configuration examples for IPv6 deployment options.


---

## IPv6 tunnels

This section shows examples of manually configured tunnels between router ports and VLANs.

### Between router ports

The following figure shows the tunnel configuration between router ports.



**Figure 11: Tunnel configuration between router ports**

You must configure static routes, RIP, or OSPF on both the source (Switch 1) and destination (Switch 2) IPv4 interfaces to communicate on the IPv4 network. You must configure IPv4 addresses on the source and destination.

### On the source device:

Create an IPv6 VLAN and add ports to the VLAN.

```
vlan create 10 type port-mstprstp 1
vlan mlt 10 4
vlan members 10 1/1 portmember
interface vlan 10
ipv6 interface
ipv6 interface enable
```

```
ipv6 interface address 4000:0:0:0:0:0:0:1/64
exit
```

Create an IPv4 router port and enable OSPF on the port.

```
interface GigabitEthernet 1/30
brouter port 1/30 vlan 1000 subnet 172.21.80.1/255.255.255.0 mac-offset
6
```

Create the tunnel from the source to the destination.

```
ipv6 tunnel 1 source 172.21.80.1 address 2500:0000:0000:0000:0000:0000:0000:0001/64
destination 192.168.20.1
```

Configure a static route on the source.

```
ipv6 route 4000:0:0:0:0:0:0:2/64 cost 1 tunnel 1
```

Optionally, you can create an OSPFv3 interface through the tunnel.

```
router ospf ipv6-enable
router ospf
ipv6 tunnel 1 area 0.0.0.0
ipv6 tunnel 1 enable
exit
```

**On the destination device:**

Create an IPv6 VLAN and add ports to the VLAN.

```
vlan create 40 type port-mstprstp 1
vlan mlt 40 4
vlan members 40 1/2 portmember
interface vlan 40
ipv6 interface
ipv6 interface enable
ipv6 interface address 4000:0:0:0:0:0:0:2/64
exit
```

Create an IPv4 router port and enable OSPF on the port.

```
interface GigabitEthernet 1/30
brouter port 1/30 vlan 2000 subnet 192.168.20.1/255.255.255.0 mac-offset 6
```

Create the tunnel from the destination to the source.

```
ipv6 tunnel 1 source 192.168.20.1 address 2500:0000:0000:0000:0000:0000:0000:0002/64
destination 172.21.80.1
```

Configure a static route on the destination.


```
ipv6 route 4000:0:0:0:0:0:0:1/64 cost 1 tunnel 1
```

Optionally, you can create an OSPFv3 interface through the tunnel.

```
router ospf ipv6-enable
router ospf
ipv6 tunnel 1 area 0.0.0.0
ipv6 tunnel 1 enable
exit
```

## Between VLANs

The following figure shows the tunnel configuration between VLANs.



**Figure 12: Tunnel configuration between VLANs**

You must configure static routes, and either RIP or OSPF on both the source (Switch 1) and destination (Switch 2) IPv4 interfaces to communicate on the IPv4 network. You must configure IPv4 addresses on the VLANs.

**On the source device:**

Create an IPv6 VLAN and add ports to the VLAN.

```
vlan create 10 type port-mstprstp 1
vlan mlt 10 4
vlan members 10 1/1 portmember
interface vlan 10
ipv6 interface
ipv6 interface enable
ipv6 interface address 4000:0:0:0:0:0:0:1/64
exit
```

Create an IPv4 VLAN, add ports to the VLAN, and enable OSPF on the VLAN.

```
vlan create 20 type port-mstprstp 1
vlan mlt 20 4
vlan members 20 1/30 portmember
interface vlan 20
ip address 172.21.80.1 255.0.0.0
ip ospf enable
exit
```

Create the tunnel from the source to the destination.

```
ipv6 tunnel
1 source 172.21.80.1 address 2500:0000:0000:0000:0000:0000:0000:0001/64
destination 192.168.20.1
```

**On the destination device:**

Create an IPv6 VLAN and add ports to the VLAN.

```
vlan create 40 type port-mstprstp 1
vlan mlt 40 4
vlan members 40 1/2 portmember
interface vlan 40
ipv6 interface
ipv6 interface enable
```

```
ipv6 interface address 4000:0:0:0:0:0:0:2/64
exit
```

### Create an IPv4 VLAN , add ports to the VLAN, and enable OSPF on the VLAN.

```
vlan create 30 type port-mstprstp 1
vlan mlt 30 4
vlan members 30 1/30 portmember
interface vlan 30
ip address 192.168.20.1 255.0.0.0
ip ospf enable
exit
```

### Create the tunnel from the destination to the source.

```
ipv6 tunnel 1 source 192.168.20.1 address 2500:0000:0000:0000:0000:0000:0002/64
destination 172.21.80.1
```

## Verification

### On the source device:

```
Switch:1(config)#show ipv6 tunnel 1 detail
=====
Tunnel Interface Information
=====
ID LOCAL ADDRESS REMOTE ADDRESS OPER STATUS TYPE

1 172.21.80.1 192.168.20.1 active manual

1 out of 1 Total number of entries displayed.

=====
Address Information
=====
IPV6 ADDRESS TYPE ORIGIN STATUS

2500:0:0:0:0:0:0:1 UNICAST MANUAL PREFERRED
fe80:0:0:0:0:0:0:ac15:5001 UNICAST LINKLAYER PREFERRED

2 out of 2 Total number of entries displayed.
```

### On the destination device:

```
Switch:1(config)#show ipv6 tunnel 1 detail
=====
Tunnel Interface Information
=====
ID LOCAL ADDRESS REMOTE ADDRESS OPER STATUS TYPE

1 192.168.20.1 172.21.80.1 active manual

1 out of 1 Total number of entries displayed.

=====
Address Information
=====
IPV6 ADDRESS TYPE ORIGIN STATUS

```


```

2500:0:0:0:0:0:0:2 UNICAST MANUAL PREFERRED
fe80:0:0:0:0:0:c0a8:1401 UNICAST LINKLAYER PREFERRED
```

2 out of 2 Total number of entries displayed.

## OSPFv3

This section shows an example of OSPFv3 configuration. The following figure shows the network.



**Figure 13: OSPFv3 configuration**

To complete the configuration, you must perform the following actions:

- Configure an IPv6 VLAN (VLAN 2) with port member 1/1.
- Configure an IPv6 brouter port (1/2).
- Use IPv6 address 2001:100:102::/64.

Configure VLAN 2 and add port members.

```
vlan create 2 type port-mstprstp 1
vlan mlt 2 4
vlan members 2 1/1 portmember
interface vlan 2
ipv6 interface
ipv6 interface enable
ipv6 interface address 2001:100:102:202:0:0:0:1/64
exit
```

Enable OSPFv3 on VLAN 2.

```
IPV6 OSPF VLAN CONFIGURATION
interface vlan 2
ipv6 ospf area 0.0.0.0
ipv6 ospf poll-interval 0
ipv6 ospf enable
exit
```

Create brouter port 1/2 with IPv6 and OSPFv3.

```
interface gigabitethernet 1/2
ipv6 interface vlan 3999
ipv6 interface enable
ipv6 interface address 2001:100:102:201:0:0:0:1/64
ipv6 ospf area 0.0.0.0
```



```
ipv6 ospf enable
exit
```

**Verification:**

```
Switch:1#show ipv6 ospf area
```

```
=====
 OSPF Area
=====
AREA_ID STUB_AREA NSSA IMPORT_SUM TRANS_ROLE TRANS_STATE

0.0.0.0 false false true always disabled
STUB_METRIC STUB_METRIC_TYPE SPF_RUNS BDR_RTR_CNT ASBDR_RTR_CNT LSA_CNT LSACK_SUM

10 ospfv3Metric 0 0 0 0 0
```

```
VSP-switch:1#show ipv6 interface vlan 2
```

```
=====
 Vlan Ipv6 Interface
=====
IF VLAN PHYSICAL ADMIN OPER TYPE MTU HOP REACH RETRAN MCAST IPSEC RPC RPC
INDX ADDRESS STATE STATE LMT TIME TIME TIME STATUS

2070 2 00:24:7f: enable up ETHER 1500 64 30000 1000 disable disable exist
 al:7a:06 only
=====
 Vlan Ipv6 Address
=====
IPV6 ADDRESS VLAN-ID TYPE ORIGIN STATUS

2001:100:102:202:0:0:0:1 V-2 UNICAST MANUAL PREFERRED
fe80:0:0:0:224:7fff:feal:7a06 V-2 UNICAST LINKLAYER PREFERRED

1 out of 2 Total Num of Interface Entries displayed.
2 out of 5 Total Num of Address Entries displayed.
```

---

## IPv6 alternative routes configuration example


To avoid traffic interruption, you can enable alternative routes globally to replace the best route with the next-best route, if the best route becomes unavailable.

The concept of alternative route applies between routing protocols. For example, if an OSPFv3 route becomes unavailable and an alternative RIPng route is available, the system activates the RIPng route immediately without waiting for an update interval to expire.

By default, the alternative routes feature is globally enabled on the switch.

The following example demonstrates this behavior.

In this example, you configure OSPFv3 and RIPng routes on two VSP 8000 Series switches VSP 8401-1 and VSP 8404-2, as shown in the following figure.



## Configuration on VSP 8000 Series — VSP 8404-1

### VLAN configuration:

On VSP 8404-1, configure VLAN 2 and the IPv6 interface address 2000:0:0:0:0:0:1/64.

```
Switch1:1:1>enable
Switch1:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.

Switch1:1(config)#vlan create 2 type port-mstprstp 0
Switch1:1(config)#vlan members 2 4/5
Switch1:1(config)#interface vlan 2
Switch1:1(config-if)#ipv6 interface address 2000:0:0:0:0:0:1/64
Switch1:1(config-if)#ipv6 interface enable
Switch1:1(config-if)#exit
```

```
Switch1:1(config)#show vlan basic
```

```
=====
 Vlan Basic
=====
```

| VLAN ID | NAME    | TYPE   | MSTP INST_ID | PROTOCOLID | SUBNETADDR | SUBNETMASK | VRFLID |
|---------|---------|--------|--------------|------------|------------|------------|--------|
| 1       | Default | byPort | 0            | none       | N/A        | N/A        | 0      |
| 2       | VLAN-2  | byPort | 0            | none       | N/A        | N/A        | 0      |

All 2 out of 2 Total Num of Vlans displayed

```
Switch1:1(config)#show vlan members
```

```
=====
 Vlan Port
=====
```

| VLAN ID | PORT MEMBER                                                                                           | ACTIVE MEMBER                                                                                         | STATIC MEMBER | NOT_ALLOW MEMBER |
|---------|-------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|---------------|------------------|
| 1       | 1/1-1/16, 1/17/1-1/17/4, 1/18/1-1/18/4, 2/1-2/16, 2/17/1-2/17/4, 2/18/1-2/18/4, 3/1-3/6, 4/1-4/4, 4/6 | 1/1-1/16, 1/17/1-1/17/4, 1/18/1-1/18/4, 2/1-2/16, 2/17/1-2/17/4, 2/18/1-2/18/4, 3/1-3/6, 4/1-4/4, 4/6 |               |                  |
| 2       | 4/5                                                                                                   | 4/5                                                                                                   |               |                  |

All 2 out of 2 Total Num of Port Entries displayed

```
Switch1:1(config)#show ipv6 interface vlan 2
```

```
=====
 Vlan Ipv6 Interface
=====
```

```

=====
IFINDEX VLAN PHYSICAL ADMIN OPER TYPE MTU HOP REACHABLE RETRANSMIT MCAST IPSEC RPC RPCMODE
INDX ADDRESS STATE STATE LMT TIME TIME STATUS
=====
2050 2 b0:ad:aa:4e:59:00 enable up ETHER 1500 64 30000 1000 disable disable disable existonly
=====
 Vlan Ipv6 Address
=====
IPV6 ADDRESS VLAN-ID TYPE ORIGIN STATUS

2000:0:0:0:0:0:0:1/64 V-2 UNICAST MANUAL PREFERRED
fe80:0:0:0:b2ad:aaff:fe4e:5900/64 V-2 UNICAST LINKLAYER PREFERRED

1 out of 1 Total Num of Interface Entries displayed.
2 out of 2 Total Num of Address Entries displayed.

```

**Port configuration:**

```

Switch1:1(config)#interface gigabitEthernet 4/5
Switch1:1(config-if)#encapsulation dot1q
Switch1:1(config-if)#no shutdown
Switch1:1(config-if)#exit

```

**IPv6 global configuration:**

```

Switch1:1(config)#ipv6 forwarding

Switch1:1(config)#show ipv6 forwarding
Global forwarding : enable
ecmp : disable
ecmp-max-path : 1

```

**IPv6 OSPFv3 VLAN configuration:**

```

Switch1:1(config)#interface vlan 2
Switch1:1(config-if)#ipv6 ospf area 0.0.0.0
Switch1:1(config-if)#ipv6 ospf enable

Switch1:1(config-if)#show ipv6 ospf interface vlan 2
admin-status : enable
area : 0.0.0.0
dead-interval : 40
hello-interval : 10
metric : 1
poll-interval : 120
priority : 1
retransmit-interval : 5
transit-delay : 1
type : BROADCAST

```

**IPv6 OSPFv3 router configuration:**

```

Switch1:1(config-if)#exit
Switch1:1(config)#router ospf ipv6-enable
Switch1:1(config)#show ipv6 ospf

```

```

=====
 OSPFv3 Global Information
=====
router-id : 170.78.88.0
admin-state : ENABLED
version : 3
area-bdr-rtr-state : FALSE
as-bdr-rtr-state : FALSE
helper-mode : ENABLED
as-scope-lsa-count : 0
lsa-checksum : 0

```

## IPv6 configuration examples

```
originate-new-lsas : 22
rx-new-lsas : 11
ext-lsa-count : 0
```

```
Switch1:1(config)#show ipv6 ospf neighbor
```

```
=====
 OSPF Neighbor
=====
IFINDX(VID/BRT) NBRROUTERID NBRIPADDR STATE TTL

2050 (2) 170.78.84.0 fe80:0:0:0:b2ad:aaff:fe4e:5500 Full 31
```

```
1 out of 1 Total Num of Neighbor Entries displayed.
```

```
=====
 OSPF Virtual Neighbor
=====
NBRAREAID NBRROUTERID VIRTINTFID NBRIPV6ADDR STATE

```

```
0 out of 0 Total Num of Virtual Neighbor Entries displayed.
```

```
=====
 OSPF NBMA Neighbor
=====
INTERFACE NBRROUTERID NBRIPADDR STATE

```

```
0 out of 0 Total Num of NBMA Neighbor Entries displayed.
```

H = Helping a Restarting neighbor

```
Switch1:1(config-if)#exit
```

### IPv6 RIPng configuration on VLAN:

```
Switch1:1(config)#interface vlan 2
Switch1:1(config-if)#ipv6 rip
Switch1:1(config-if)#ipv6 rip enable
```

```
Switch1:1(config-if)#show ipv6 rip interface
```

```
Total RIPng interfaces: 1
```

```
=====
 RIPng Interface - GlobalRouter
=====
IFINDX COST POISON SEND ADMIN OPER
----- - - - - -
 STATUS DEFAULT STATUS STATUS

2050 (2) 1 disable disable enable enable
```

```
1 out of 1 Total Num of RIPng interfaces displayed
```

**IPv6 RIPng global router configuration:**

```
Switch1:1(config)#router rip ipv6-enable
Switch1:1(config)#router rip
```

```
Switch1:1(config)#show ipv6 rip
```

```
=====
 RIPng Global - GlobalRouter
=====

 Rip : Enabled
 HoldDown Time : 120
 Timeout Interval : 180
 Update Time : 30
 Default Info Metric : 1
 Default Info State : Disabled
 Default Import Metric : 1
```

**Configuration on VSP 8000 Series — VSP 8404-2**

On VSP 8404-2, configure VLAN 2 and VLAN 3 with the IPv6 interfaces 2000:0:0:0:0:0:0:2/64 and 3000:0:0:0:0:0:0:2/64 respectively.

**VLAN configuration:**

```
Switch2:1>enable
Switch2:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Switch2:1(config)#vlan create 2 type port-mstprstp 0
Switch2:1(config)#vlan members 2 4/5 portmember
Switch2:1(config)#interface vlan 2

Switch2:1(config-if)#ipv6 interface address 2000:0:0:0:0:0:0:2/64
Switch2:1(config-if)#ipv6 interface enable
Switch2:1(config-if)#ipv6 forwarding
Switch2:1(config-if)#exit
```

```
Switch2:1(config)#vlan create 3 type port-mstprstp 0
Switch2:1(config)#vlan members 3 4/6 portmember
Switch2:1(config)#interface vlan 3

Switch2:1(config-if)#ipv6 interface address 3000:0:0:0:0:0:0:2/64
Switch2:1(config-if)#ipv6 interface enable
Switch2:1(config-if)#ipv6 forwarding
Switch2:1(config-if)#exit
```

```
Switch2:1(config)#show vlan basic
```

```
=====
 Vlan Basic
=====
VLAN
ID NAME TYPE MSTP
 INST_ID PROTOCOLID SUBNETADDR SUBNETMASK VRFID

1 Default byPort 0 none N/A N/A 0
2 VLAN-2 byPort 0 none N/A N/A 0
3 VLAN-3 byPort 0 none N/A N/A 0
```

```
All 3 out of 3 Total Num of Vlans displayed
```

```
Switch2:1(config)#show vlan members
```

```
=====
```

## IPv6 configuration examples

| Vlan Port |                                                                                           |                                                                                           |               |                  |
|-----------|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------|------------------|
| VLAN ID   | PORT MEMBER                                                                               | ACTIVE MEMBER                                                                             | STATIC MEMBER | NOT_ALLOW MEMBER |
| 1         | 1/1-1/16,1/17/1-1/17/4,1/18/1-1/18/4,2/1-2/16,2/17/1-2/17/4,2/18/1-2/18/4,3/1-3/6,4/1-4/4 | 1/1-1/16,1/17/1-1/17/4,1/18/1-1/18/4,2/1-2/16,2/17/1-2/17/4,2/18/1-2/18/4,3/1-3/6,4/1-4/4 |               |                  |
| 2         | 4/5                                                                                       | 4/5                                                                                       |               |                  |
| 3         | 4/6                                                                                       | 4/6                                                                                       |               |                  |

All 3 out of 3 Total Num of Port Entries displayed

```
Switch2:1(config)#show ipv6 interface vlan
```

| Vlan Ipv6 Interface |      |                   |             |            |       |      |         |                |                 |              |         |         |           |
|---------------------|------|-------------------|-------------|------------|-------|------|---------|----------------|-----------------|--------------|---------|---------|-----------|
| IFINDX              | VLAN | PHYSICAL ADDRESS  | ADMIN STATE | OPER STATE | TYPE  | MTU  | HOP LMT | REACHABLE TIME | RETRANSMIT TIME | MCAST STATUS | IPSEC   | RPC     | RPCMODE   |
| 2050                | 2    | b0:ad:aa:4e:55:00 | enable      | up         | ETHER | 1500 | 64      | 30000          | 1000            | disable      | disable | disable | existonly |
| 2051                | 3    | b0:ad:aa:4e:55:01 | enable      | up         | ETHER | 1500 | 64      | 30000          | 1000            | disable      | disable | disable | existonly |

| Vlan Ipv6 Address                 |         |         |           |           |
|-----------------------------------|---------|---------|-----------|-----------|
| IPV6 ADDRESS                      | VLAN-ID | TYPE    | ORIGIN    | STATUS    |
| 2000:0:0:0:0:0:2/64               | V-2     | UNICAST | MANUAL    | PREFERRED |
| fe80:0:0:0:b2ad:aaff:fe4e:5500/64 | V-2     | UNICAST | LINKLAYER | PREFERRED |
| 3000:0:0:0:0:0:2/64               | V-3     | UNICAST | MANUAL    | PREFERRED |
| fe80:0:0:0:b2ad:aaff:fe4e:5501/64 | V-3     | UNICAST | LINKLAYER | PREFERRED |

2 out of 2 Total Num of Interface Entries displayed.  
4 out of 4 Total Num of Address Entries displayed.

### Port configuration:

```
Switch2:1(config)#interface GigabitEthernet 4/5
Switch2:1(config)#encapsulation dot1q
Switch2:1(config)#no shutdown
```

```
Switch2:1(config)#interface GigabitEthernet 4/6
Switch2:1(config)#encapsulation dot1q
Switch2:1(config)#no shutdown
```

### IPv6 global configuration:

```
Switch2:1(config)#ipv6 forwarding
```

```
Switch2:1(config)#show ipv6 forwarding
Global forwarding : enable
ecmp : disable
ecmp-max-path : 1
```

### IPv6 OSPFv3 VLAN configuration:

```
Switch2:1(config)#interface vlan 2
Switch2:1(config-if)#ipv6 ospf area 0.0.0.0
Switch2:1(config-if)#ipv6 ospf enable
```

```
Switch2:1(config)#interface vlan 3
```



## IPv6 configuration examples

```
=====
 OSPF Virtual Neighbor
=====
NBRAREAID NBRROUTERID VIRTINTFID NBRIPV6ADDR STATE

0 out of 0 Total Num of Virtual Neighbor Entries displayed.
=====
 OSPF NBMA Neighbor
=====
INTERFACE NBRROUTERID NBRIPADDR STATE

0 out of 0 Total Num of NBMA Neighbor Entries displayed.

H = Helping a Restarting neighbor
```

### IPv6 OSPFv3 global router configuration:

```
Switch2:1(config-if)#exit
Switch2:1(config)#router ospf ipv6-enable
Switch1:1(config)#show ipv6 ospf
```

```
=====
 OSPFv3 Global Information
=====
router-id : 170.78.88.0
admin-state : ENABLED
version : 3
area-bdr-rtr-state : FALSE
as-bdr-rtr-state : FALSE
helper-mode : ENABLED
as-scope-lsa-count : 0
lsa-checksum : 0
originate-new-lsas : 22
rx-new-lsas : 11
ext-lsa-count : 0
```

### IPv6 RIPng configuration:

```
Switch2:1(config)#interface vlan 2
Switch2:1(config-if)#ipv6 rip
Switch2:1(config-if)#ipv6 rip enable
Switch2:1(config-if)#exit

Switch2:1(config)#interface vlan 3
Switch2:1(config-if)#ipv6 rip
Switch2:1(config-if)#ipv6 rip enable
Switch2:1(config-if)#exit
Switch2:1(config)#

Switch2:1(config)#show ipv6 rip interface

Total RIPng interfaces: 2

=====
 RIPng Interface - GlobalRouter
```



```

=====
IFINDEX COST POISON SEND ADMIN OPER
STATUS STATUS STATUS DEFAULT STATUS STATUS

2050 (2) 1 disable disable enable enable
2051 (3) 1 disable disable enable enable
=====

```

2 out of 2 Total Num of RIPng interfaces displayed

### IPv6 RIPng global router configuration:

```

Switch2:1(config)#router rip ipv6-enable
Switch2:1(config)#router rip

```

```

Switch2:1(config)#show ipv6 rip

```

```

=====
RIPng Global - GlobalRouter
=====
Rip : Enabled
HoldDown Time : 120
Timeout Interval : 180
Update Time : 30
Default Info Metric : 1
Default Info State : Disabled
Default Import Metric : 1
=====

```

### Viewing route and alternative route configuration on the VSP switches

On the VSP switches 8404-1 and 8404-2, the route 3000:0:0:0:0:0:2/64 is learned using the protocols RIPng and OSPFv3. The OSPFv3 route is learned as the best route because of its route preference value of 20. The RIPng route is added as alternative route as it has the route preference 100, which is greater than the OSPFv3 route preference of 20. On VSP 8404-2, the route 3000:0:0:0:0:0:2/64 is a local route.

### Viewing route and alternative route configuration on VSP 8404-1:

```

Switch1:1(config)#show ipv6 route alternative

```

```

=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:1/64 0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:1/128 0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 RIP 2 0 A 100
=====

```

4 out of 4 Total Num of Route Entries displayed.

```

TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route

```

```

Switch1:1(config)#show ipv6 route

```

```

=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:1/64 0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:1/128 0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
=====

```

3 out of 3 Total Num of Route Entries displayed.

```

TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route

```

**Viewing route and alternative route configuration on VSP 8404-2:**

```
Switch2:1(config)#show ipv6 route alternative
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:2/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 LOCAL 2 0 B 20
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 LOCAL 2 0 A 100
=====
4 out of 4 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route
```

```
Switch2:1#show ipv6 route
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:2/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:2/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 0:0:0:0:0:0:0:0 V-3 LOCAL 1 0 B 20
3000:0:0:0:0:0:2/128 0:0:0:0:0:0:0:0 V-3 LOCAL 1 0 B 100
=====
4 out of 4 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route
```

**Changing the route preference on VSP 8404-1**

On the switch, default preferences are assigned to all standard routing protocols. You can modify the global preference for a protocol to give it a higher or lower priority than other protocols. When you change the preference for a static route, if all best routes remain best routes, only the local route tables change. However, if changing the protocol preference causes best routes to no longer be best routes, neighboring route tables can be affected.

In the following example scenario, you configure a different routing preference for the RIPng protocol on VSP 8404-1 and observe the learning of best and alternative routes. The existing route preference for RIPng is 100.

```
Switch1:1#show ipv6 route alternative
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:1/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 RIP 2 0 A 100
=====
4 out of 4 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route

Switch1:1(config)#show ipv6 route
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:1/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
=====
3 out of 3 Total Num of Route Entries displayed.
=====
```

TYPE Legend:  
A=Alternative Route, B=Best Route, E=Ecmp Route

Configure a different route preference for the RIPng protocol, for example, 19:

```
Switch1:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch1:1(config)#ipv6 route preference protocol ripng 19
Switch1:1(config)#exit
```

Verify the route preference configuration:

```
Switch1:1#show ipv6 route preference
```

```
=====
 IPv6 Route Preference
=====
```

| PROTOCOL     | DEFAULT | CONFIG |
|--------------|---------|--------|
| LOCAL        | 0       | 0      |
| STATIC       | 5       | 5      |
| SPBM_L1      | 7       | 7      |
| OSPFv3_INTRA | 20      | 20     |
| OSPFv3_INTER | 25      | 25     |
| EBGP         | 45      | 45     |
| RIPNG        | 100     | 19     |
| OSPFv3_E1    | 120     | 120    |
| OSPFv3_E2    | 125     | 125    |
| IBGP         | 175     | 175    |

View the updated route preference (for RIPng) on VSP 8404-1. The RIPng route is now learnt as the best route as it has lesser value of route preference (19) than that of OSPFv3 (20), as shown below.

```
Switch1:1(config)#show ipv6 route
```

```
=====
 IPv6 Routing Table Information
=====
```

| Destination Address/PrefixLen | NEXT HOP                       | VID/BID/TID | PROTO | COST | AGE | TYPE | PREF |
|-------------------------------|--------------------------------|-------------|-------|------|-----|------|------|
| 2000:0:0:0:0:0:0:1/64         | 0:0:0:0:0:0:0:0                | V-2         | LOCAL | 1    | 0   | B    | 0    |
| 2000:0:0:0:0:0:0:1/128        | 0:0:0:0:0:0:0:0                | V-2         | LOCAL | 1    | 0   | B    | 0    |
| 3000:0:0:0:0:0:0:2/64         | fe80:0:0:0:b2ad:aaff:fe4e:5500 | V-2         | RIP   | 2    | 0   | B    | 19   |

3 out of 3 Total Num of Route Entries displayed.

TYPE Legend:  
A=Alternative Route, B=Best Route, E=Ecmp Route

```
Switch1:1#show ipv6 route alternative
```

```
=====
 IPv6 Routing Table Information
=====
```

| Destination Address/PrefixLen | NEXT HOP                       | VID/BID/TID | PROTO | COST | AGE | TYPE | PREF |
|-------------------------------|--------------------------------|-------------|-------|------|-----|------|------|
| 2000:0:0:0:0:0:0:1/64         | 0:0:0:0:0:0:0:0                | V-2         | LOCAL | 1    | 0   | B    | 0    |
| 2000:0:0:0:0:0:0:1/128        | 0:0:0:0:0:0:0:0                | V-2         | LOCAL | 1    | 0   | B    | 0    |
| 3000:0:0:0:0:0:0:2/64         | fe80:0:0:0:b2ad:aaff:fe4e:5500 | V-2         | RIP   | 2    | 0   | B    | 19   |
| 3000:0:0:0:0:0:0:2/64         | fe80:0:0:0:b2ad:aaff:fe4e:5500 | V-2         | OSPF  | 2    | 0   | A    | 20   |

4 out of 4 Total Num of Route Entries displayed.

TYPE Legend:  
A=Alternative Route, B=Best Route, E=Ecmp Route

## Disable alternative route learning on VSP 8404-1

The following example demonstrates disabling alternative route learning on VSP 8404-1.

View the alternative routes on VSP 8404-1.

```
Switch1:1(config)#show ipv6 route alternative
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:0:1/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
3000:0:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 RIP 2 0 A 100
=====
4 out of 4 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route
```

Disable IPv6 alternative routes on VSP 8404-1.

```
Switch1:1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch1:1(config)#no ipv6 alternative-route
Switch1:1(config)#exit
```

Verify that alternative route learning is disabled.

```
Switch1:1#show ipv6 global
forwarding : enable
default-hop-cnt : 64
number-of-interfaces : 1
icmp-error-interval : 1000
icmp-error-quota : 50
icmp-unreach-msg : disable
icmp-echo-multicast-request : enable
static-route-admin-status : enable
alternative-route : disable
ecmp : disable
ecmp-max-path : 1
source-route : disable
```

```
Switch1:1(config)#show ipv6 route
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:0:1/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
=====
3 out of 3 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route
```

Note that the alternative route (RIPng) is not learnt.

```
Switch1:1(config)#show ipv6 route alternative
=====
IPv6 Routing Table Information
=====
Destination Address/PrefixLen NEXT HOP VID/BID/TID PROTO COST AGE TYPE PREF

2000:0:0:0:0:0:0:1/64 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
2000:0:0:0:0:0:0:1/128 0:0:0:0:0:0:0:0 V-2 LOCAL 1 0 B 0
3000:0:0:0:0:0:0:2/64 fe80:0:0:0:b2ad:aaff:fe4e:5500 V-2 OSPF 2 0 B 20
=====
3 out of 3 Total Num of Route Entries displayed.
=====
TYPE Legend:
A=Alternative Route, B=Best Route, E=Ecmp Route
```

# Appendix A: ICMPv6 type and code

The Internet Control Message Protocol (ICMPv6) uses many messages identified by a type and code field (see RFC 4443). Error messages use message types 0 to 127. Informational messages use message types 128 to 255. The following table provides the type and code reference.

**Table 10: ICMPv6 type and code details**

| Type | Name                      | Code                                                                                                                                                         | Reference |
|------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| 1    | Destination Unreachable   | 0—no route to destination<br>1—communication with destination administratively prohibited<br>2—(not assigned)<br>3—address unreachable<br>4—port unreachable | RFC 4443  |
| 2    | Packet Too Big            | N/A                                                                                                                                                          | RFC 4443  |
| 3    | Time Exceeded             | 0—hop limit exceeded in transit<br>1—fragment reassembly time exceeded                                                                                       | RFC 4443  |
| 4    | Parameter Problem         | 0—erroneous header field encountered<br>1—unrecognized Next Header type encountered<br>2—unrecognized IPv6 option encountered                                | RFC 4443  |
| 128  | Echo Request              | N/A                                                                                                                                                          | RFC 4443  |
| 129  | Echo Reply                | N/A                                                                                                                                                          | RFC 4443  |
| 130  | Multicast Listener Query  | N/A                                                                                                                                                          |           |
| 131  | Multicast Listener Report | N/A                                                                                                                                                          |           |
| 132  | Multicast Listener Done   | N/A                                                                                                                                                          |           |
| 133  | Router Solicitation       | N/A                                                                                                                                                          | RFC 4861  |

*Table continues...*

ICMPv6 type and code

| Type | Name                                             | Code                                                                                     | Reference |
|------|--------------------------------------------------|------------------------------------------------------------------------------------------|-----------|
| 134  | Router Advertisement                             | N/A                                                                                      | RFC 4861  |
| 135  | Neighbor Solicitation                            | N/A                                                                                      | RFC 4861  |
| 136  | Neighbor Advertisement                           | N/A                                                                                      | RFC 4861  |
| 137  | Redirect Message                                 | N/A                                                                                      | RFC 4861  |
| 138  | Router Renumbering                               | 0—router renumbering command<br>1—router renumbering result<br>255—sequence number reset |           |
| 139  | ICMP Node Information Query                      | N/A                                                                                      |           |
| 140  | ICMP Node Information Response                   | N/A                                                                                      |           |
| 141  | Inverse neighbor discovery Solicitation Message  | N/A                                                                                      | RFC 3122  |
| 142  | Inverse neighbor discovery Advertisement Message | N/A                                                                                      | RFC 3122  |
| 143  | Version 2 Multicast Listener Report              | N/A                                                                                      | RFC 3810  |
| 144  | Home Agent Address Discovery Request Message     | N/A                                                                                      | RFC 3775  |
| 145  | Home Agent Address Discovery Reply Message       | N/A                                                                                      | RFC 3775  |
| 146  | Mobile Prefix Solicitation                       | N/A                                                                                      | RFC 3775  |
| 147  | Mobile Prefix Advertisement                      | N/A                                                                                      | RFC 3775  |

# Glossary

|                                                      |                                                                                                                                                                              |
|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>All_DHCP_Relay_Agents_and_Servers (FF02::1:2)</b> | A link-scoped multicast address used by a client to communicate with neighboring relay agents and servers. All servers and relay agents are members of this multicast group. |
| <b>Dual stack</b>                                    | Supports both the IPv4 and IPv6 protocol.                                                                                                                                    |
| <b>Extended Unique Identifier (EUI)</b>              | A 64-bit format used in assigning addresses automatically to IPv6 interfaces.                                                                                                |
| <b>route table manager (RTM)</b>                     | Determines the best route to a destination based on reachability, route preference, and cost.                                                                                |
| <b>Spanning Tree Group (STG)</b>                     | A collection of ports in one spanning-tree instance.                                                                                                                         |
| <b>stateless address autoconfiguration (SLAAC)</b>   | Uses a mathematical equation to automatically configure and assign IPv6 addresses to hosts or nodes on a network. RFC 4862 describes SLAAC.                                  |