

Quick Start Configuration for Ethernet Routing Switch 3600 Series

Release 6.4 9036469-00 Rev AA February 2020 © 2017-2020, Extreme Networks, Inc. All Rights Reserved.

Legal Notice

Extreme Networks, Inc. reserves the right to make changes in specifications and other information contained in this document and its website without prior notice. The reader should in all cases consult representatives of Extreme Networks to determine whether any such changes have been made.

The hardware, firmware, software or any specifications described or referred to in this document are subject to change without notice.

Trademarks

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries.

All other names (including any product names) mentioned in this document are the property of their respective owners and may be trademarks or registered trademarks of their respective companies/ owners.

For additional information on Extreme Networks trademarks, please see: <u>www.extremenetworks.com/company/legal/trademarks</u>

Open Source Declarations

Some software files have been licensed under certain open source or third-party licenses. End-user license agreements and open source declarations can be found at: www.extremenetworks.com/support/ policies/software-licensing

Contents

Chapter 1: About this Document	5
Purpose	5
Conventions	5
Text Conventions	5
Documentation and Training	7
Getting Help	7
Providing Feedback	
Chapter 2: New in this document	10
Chapter 3: Quick Start Configuration	11
Fundamentals	11
System connection.	
Connecting a terminal to the switch.	
System logon	
Password encryption	
Quick Start.	
Password complexity	
Password aging and lockout policy	
Enterprise Device Manager	
Configuring the switch using Command Line Interface	17
Configuring with Quick Start using CLI	17
Configuring the terminal	19
BootP automatic IP configuration and MAC address	
Setting user access limits using CLI	
Customizing the opening banner	23
Configuring Simple Network Time Protocol	25
Configuring local time zone	25
Configuring daylight savings time	
Specifying summer-time recurring dates	
Displaying the local time zone settings	
Displaying the daylight savings time settings	28
Configuring a static route using CLI	29
Enabling remote access	30
Using telnet to log on to the device	31
Enabling the web server management interface	31
Accessing the switch through the web interface	31
Creating a VLAN using CLI	32
Saving the configuration	33
Configuring system identification	34
Configuring the IP address	35

Clearing the IP address	36
Configuring the IP address	37
Configuring the IP address to the default value	38
Displaying IP address information	38
Changing subnet netmask value	38
Configuring the default gateway	39
Displaying IP configuration	40
Pinging an IP device	41
Displaying the agent and diagnostic software load	42
Displaying RMON Alarms using CLI	43
Configuring the switch using Enterprise Device Manager	43
Configuring Quick Start using EDM	43
Setting user access limits using Enterprise Device Manager	44

Chapter 1: About this Document

This section discusses the purpose of this document, the conventions used, ways to provide feedback, additional help, and information regarding other Extreme Networks publications.

Purpose

This document provides basic instructions to perform the basic configuration of the Extreme Networks ERS 3600 Series chassis and software.

Conventions

This section discusses the conventions used in this guide.

Text Conventions

The following tables list text conventions that can be used throughout this document.

Table 1: Notice Icons

Icon	Alerts you to
Important:	A situation that can cause serious inconvenience.
Note:	Important features or instructions.
🔁 Tip:	Helpful tips and notices for using the product.
A Danger:	Situations that will result in severe bodily injury; up to and including death.
🔥 Warning:	Risk of severe personal injury or critical loss of data.
Caution:	Risk of personal injury, system damage, or loss of data.

Table 2: Text Conventions

Convention	Description
Angle brackets (< >)	Angle brackets (< >) indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when you enter the command.
	<pre>If the command syntax is cfm maintenance- domain maintenance-level <0-7> , you can enter cfm maintenance-domain maintenance-level 4.</pre>
Bold text	Bold text indicates the GUI object name you must act upon.
	Examples:
	• Click OK.
	On the Tools menu, choose Options.
Braces ({ })	Braces ({ }) indicate required elements in syntax descriptions. Do not type the braces when you enter the command.
	For example, if the command syntax is ip address {A.B.C.D}, you must enter the IP address in dotted, decimal notation.
Brackets([])	Brackets ([]) indicate optional elements in syntax descriptions. Do not type the brackets when you enter the command.
	For example, if the command syntax is show clock [detail], you can enter either show clock or show clock detail.
Ellipses ()	An ellipsis () indicates that you repeat the last element of the command as needed.
	For example, if the command syntax is ethernet/2/1 [<parameter> <value>], you enter ethernet/2/1 and as many parameter-value pairs as you need.</value></parameter>
Italic Text	Italics emphasize a point or denote new terms at the place where they are defined in the text. Italics are also used when referring to publication titles that are not active links.
Plain Courier Text	Plain Courier text indicates command names, options, and text that you must enter. Plain Courier text also indicates command syntax and system output, for example, prompts and system messages.

Table continues...

Convention	Description
	Examples: • show ip route
	• Error: Invalid command syntax [Failed][2013-03-22 13:37:03.303 -04:00]
Separator (>)	A greater than sign (>) shows separation in menu paths.
	For example, in the Navigation tree, expand the Configuration > Edit folders.
Vertical Line ()	A vertical line () separates choices for command keywords and arguments. Enter only one choice. Do not type the vertical line when you enter the command.
	<pre>For example, if the command syntax is access- policy by-mac action { allow deny }, you enter either access-policy by-mac action allow Or access-policy by-mac action deny, but not both.</pre>

Documentation and Training

Find Extreme Networks product information at the following locations:

Current Product Documentation Release Notes Hardware/software compatibility matrices for Campus and Edge products Supported transceivers and cables for Data Center products Other resources, like white papers, data sheets, and case studies

Extreme Networks offers product training courses, both online and in person, as well as specialized certifications. For details, visit <u>www.extremenetworks.com/education/</u>.

Getting Help

If you require assistance, contact Extreme Networks using one of the following methods:

Extreme Search the GTAC (Global Technical Assistance Center) knowledge base; manage support cases and service contracts; download software; and obtain product licensing, training, and certifications.

- **The Hub** A forum for Extreme Networks customers to connect with one another, answer questions, and share ideas and feedback. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.
- <u>Call GTAC</u> For immediate support: (800) 998 2408 (toll-free in U.S. and Canada) or 1 (408) 579 2826. For the support phone number in your country, visit: <u>www.extremenetworks.com/support/contact</u>

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number, or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any actions already taken to resolve the problem
- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- · Any related RMA (Return Material Authorization) numbers

Subscribe to Service Notifications

You can subscribe to email notifications for product and software release announcements, Vulnerability Notices, and Service Notifications.

- 1. Go to www.extremenetworks.com/support/service-notification-form.
- 2. Complete the form (all fields are required).
- 3. Select the products for which you would like to receive notifications.

😵 Note:

You can modify your product selections or unsubscribe at any time.

4. Select Submit.

Providing Feedback

The Information Development team at Extreme Networks has made every effort to ensure the accuracy and completeness of this document. We are always striving to improve our documentation and help you work better, so we want to hear from you. We welcome all feedback, but we especially want to know about:

- Content errors, or confusing or conflicting information.
- Improvements that would help you find relevant information in the document.

• Broken links or usability issues.

If you would like to provide feedback, you can do so in three ways:

- In a web browser, select the feedback icon and complete the online feedback form.
- Access the feedback form at https://www.extremenetworks.com/documentation-feedback/.
- Email us at documentation@extremenetworks.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

Chapter 2: New in this document

There are no new feature changes in this document.

Chapter 3: Quick Start Configuration

This section provides conceptual information and procedures to perform basic switch configuration using Command Line Interface (CLI) and Enterprise Device Manager (EDM.

Fundamentals

This document includes the minimum but essential configuration steps to:

- provide a default, starting point configuration
- · establish a management interface
- · establish basic security on the node

The shipment includes the following:

- An installation kit
- A foldout poster ()

For more information about hardware specifications and installation procedures, see .

For more information about how to configure security, see <u>Configuring Security on Ethernet Routing</u> <u>Switch 3600 Series</u>.

System connection

Use the console cable to connect the terminal to the switch console port. The console cable and connector must match the console port on the switch (DB-9 or RJ-45, depending on your model). The following are the default communication protocol settings for the console port:

- 9600 baud
- 8 data bits
- 1 stop bit
- No parity
- · No flow control
- VT100 or VT100/ANSI Terminal Protocol

To use the console port, you need the following equipment:

- A terminal or TeleTypewriter (TTY)-compatible terminal, or a portable computer with a serial port and terminal-emulation software.
- An Underwriters Laboratories (UL)-listed straight-through or null modem RS-232 cable with a female DB-9 connector for the console port on the switch. The other end of the cable must use a connector appropriate to the serial port on your computer or terminal.

You must shield the cable that connects to the console port to comply with emissions regulations and requirement

Connecting a terminal to the switch

This procedure describes the steps to connect a terminal to the console port on the switch.

Before you begin

To use the console port, you need the following equipment:

• Terminal with AC power cord and keyboard. Any terminal or PC with an appropriate terminal emulator can be used as the management station.

For more information, see for a list of the terminal emulation settings that must be used with any terminal emulation software used to connect to the switch.

• Use the RJ-45 console cable to connect the switch console port to your management terminal. The maximum length for the console port cable is 25 feet (8.3 meters).

For more information, see <u>Configuring Security on Ethernet Routing Switch 3600 Series</u> for console port pin-out information. You can use the pin-out information to verify or create a console cable for use with your maintenance terminal.

Procedure

- 1. Connect one end of the serial cable to the connector on the terminal or PC.
- 2. Connect the other end of the serial cable to the console port on the switch.
- 3. Turn the terminal or PC on.
- Set the terminal protocol on the terminal or terminal emulation program to VT100 or VT100/ ANSI.
- 5. Connect to the switch using the terminal or terminal emulation application. The switch banner appears when you connect to the switch through the console port.
- 6. Press Ctrl+Y and type the following CLI commands:

After entering the requested info, the configuration will be applied and stored into the switch NVRAM.

Once the basic connectivity settings are applied, additional configuration can be done using the available management interfaces. Use Ctrl+C to abort the configuration at any time.

System logon

After the platform boot sequence is complete, a logon prompt displays.

The following table shows the default values for logon and password for console and Telnet sessions.

Access level	Description	Default Logon	Default Password
Read-only	Permits view-only configuration and status information. Is equivalent to Simple Network Management Protocol (SNMP) read-only community access.	RO	user
Read/write	View and change configuration and status information across the switch. You can change security and password settings. This access level is equivalent to SNMP read/write community access.	RW	secure

Password encryption

The local passwords for the switch are stored in the configuration file, encrypted with an Extreme Networks proprietary algorithm.

Important:

For security reasons, it is recommended that you configure the passwords to values other than the factory defaults.

For more information about configuring passwords, see <u>Configuring Security on Ethernet Routing</u> <u>Switch 3600 Series</u>.

Quick Start

You can use the install command in Command Line Interface (CLI) or the Quick Start menu in Enterprise Device Manager (EDM) to configure the following:

- quick start VLAN
- in-band IP address and subnet mask
- default gateway
- DHCP server configuration
- management subnet mask, management IP address and management default gateway
- · read-only and read-write community strings
- · IPv6 in-band address and IPv6 default gateway
- management IPV6 address and management IPV6 default gateway

Password complexity

Password complexity feature enforces complexity password rules. The rules are different when the switch is upgraded from an unsupported to a supported release for the first time. The following rules can be configured and applied when you enable this feature:

- · Minimum password length and valid characters
- Number of passwords retained in password history
- · Check for sequential and repeated characters in password

For more information, see Configuring Security on Ethernet Routing Switch 3600 Series.

Password aging and lockout policy

Passwords expire after a specified aging period. The values for aging can be configured. The default values are different when the switch is upgraded from an unsupported to a supported release for the first time.

The management passwords can be configured to comply with company security policies. The following rules can be configured and applied when you enable this feature:

- · Number of days before password expiration
- Failed login attempts

For more information, see Configuring Security on Ethernet Routing Switch 3600 Series .

Enterprise Device Manager

Enterprise Device Manager (EDM) is an embedded graphical user interface (GUI) that you can use to manage and monitor the platform through a standard web browser. EDM is embedded in the switch software, and the switch operates as a web server, so you do not require additional client software.

For more information about EDM, see Using CLI and EDM on Ethernet Routing Switch 3600 Series.

Enterprise Device Manager access

To access EDM, open http://<deviceip>/login.html or https://<deviceip>/ login.html from either Microsoft Internet Explorer (minimum version 8.x), or Mozilla Firefox (minimum version 3.x).

Important:

You must enable the web server from CLI to enable HTTP access to EDM. If you want HTTP access to the device, you must also disable the web server secure-only option. The web server secure-only option is enabled by default and allows HTTPS access to the device. Take the appropriate security precautions within the network if you use HTTP.

If you experience issues while connecting to EDM, check the proxy settings. Proxy settings can affect EDM connectivity to the switch. Clear the browser cache, and do not use a proxy when connecting to the device.

Default user name and password

To log on the switch for the first time when password security is enabled, use the default password. For the standard software image, the default password for RO is *user* and *secure* for RW. For the secure software image, the default password for RO is *userpasswd* and *securepasswd* for RW.

For more information about changing the passwords, see <u>Configuring Security on Ethernet Routing</u> <u>Switch 3600 Series</u>.

EDM window

The EDM window contains the following parts:

- 1. navigation tree—the navigation pane on the left side of the window that displays available command folders in a tree format
- 2. menu bar—the area at the top of the window that displays primary and secondary tabs that you accessed during the session; the tabs remain available until you close them
- 3. toolbar—the area just below the menu bar that provides quick access to the most common operational commands such as **Apply**, **Refresh**, and **Help**
- 4. work area—the main area on the right side of the window that displays the dialog boxes where you view or configure switch parameters

😵 Note:

Depending on your hardware model, information displayed may appear different than the figure shown in this section.

arch: X P				
Configuration	Apply BRefresh OHelp	43		
Administration	TftpServerInetAddressType:	ipv4 () ipv6		
Device	TftpServerInetAddress:	172.16.3.2		2000 C 1000 C
	1 BinaryConfinEllename:			← 4
D Chassis	ImageEleName:	3500 520 ima		
Eridge	Englishinger liendirie.	5500_520.mg		
E File System	FwFieName(Diagnostics):			
Diagnostics	Action:	ather	Config	@ unldConfig
E SNTP/Clock	15.1.5.5.6%	aldIma	 deldImeTBlewer 	deldImeticReset
Snmp Server		o deluting		O dridingvokeset
Security				
b 🧰 Graph		O dnldFwFromSttp	O dnldConfigFromSttp	O upldConfigToSftp
Power Management		O dnldImgFromSftpNoReset	O dnldFwFromSftpNoReset	
	Status:	other		
D PV6		MOC		
D CoS				
Serviceability				

Figure 1: EDM window

Device Physical View

When you access EDM, the first panel in the work area displays a switch summary view. The tab behind the summary view is a real-time physical view of the front panel of a device or stack called the Device Physical View.

Objects in the Device Physical View are

- a stand-alone switch, called a unit
- · a switch stack, called a chassis
- a port

From the Device Physical View you can

- · determine the hardware operating status
- select a switch or a port to perform management tasks on specific objects or view fault, configuration, and performance information for specific objects

To select an object, click the object. The system outlines the object in yellow, indicating that the object selected.

The conventions on the device view are similar to the actual switch appearance except that LEDs in Device Physical View do not blink. The LEDs and the ports are color-coded to reflect hardware status. Green indicates the port is up and running; red indicates that the port is disabled.

From the menu bar you can click the Device Physical View tab to open the Device Physical View any time during a session.



Figure 2: Device Physical View

😵 Note:

Depending on your hardware model, your switch might appear different than the figure shown in this section.

Configuring the switch using Command Line Interface

This section provides procedures to configure the switch using Command Line Interface (CLI).

Configuring with Quick Start using CLI

The **Install** script consists of a series of prompts that are used to set up the minimum configuration information.

You must enter the following information when prompted:

IP address

- Subnet mask
- · Default gateway
- Read-only community string
- Read-write community string
- Quick start VLAN
- IPV6 address/prefix
- IPV6 default gateway
- DHCP server information (optional)

Before you begin

• Connect to the switch using the terminal or terminal emulation application.

Procedure

- 1. Press
 - CTRL + Y to obtain a CLI prompt.
- 2. Enter enable
- 3. Enter install

The switch setup utility banner appears.

4. Enter VLAN ID for the Quick Start at the following prompt:

Please provide the Quick Start VLAN <1-4094> [1]:

5. Enter the IP address at the following prompt:

Please provide the in-band IP Address [192.0.2.1]:

6. Enter the sub-net mask address at the following prompt:

Please provide the in-band sub-net mask [255.255.255.0]:

7. Enter the default gateway IP address at the following prompt:

Please provide the Default Gateway [0.0.0.0]:

- 8. Enter the read only community string at the following prompt:
 - Please provide the Read-Only Community String [********]:
- 9. Enter the read write community string at the following prompt:

Please provide the Read-Write Community String [********]:

10. Enter the in-band IPv6 address at the following prompt:

Please provide the in-band IPV6 Address/Prefix_length [: :/0]:

11. Enter the in-band IPv6 default gateway at the following prompt:

Please provide the in-band IPV6 Default Gateway [: :]:

12. At the Do you want to enable the DHCP server? prompt, enter Y to enable the DHCP server, OR leave the prompt at N if you do not want to enable the DHCP server.

Successful completion displays the following message: Basic stack parameters have now been configured and saved.

Example

***** Welcome to the ERS3500 setup utility. You will be requested to provide the switch basic connectivity settings. After entering the requested info, the configuration will be applied and stored into the switch NVRAM. Once the basic connectivity settings are applied, additional configuration can be done using the available management interfaces. Use Ctrl+C to abort the configuration at any time. ************* Please provide the Quick Start VLAN <1-4094> [1]: Please provide the in-band IP Address[192.0.2.1]: Please provide the in-band sub-net mask [255.255.255.0]: Please provide the Default Gateway[0.0.0.0]: Please provide the Read-Only Community String[********]: Please provide the Read-Write Community String[********]: Please provide the in-band IPV6 Address/Prefix length[::/0]: Please provide the in-band IPV6 Default Gateway[::]: Do you want to enable the DHCP server? y/n [n]: ************ Basic stack parameters have now been configured and saved.

Configuring the terminal

You can configure the switch terminal settings to suit your preferences for the terminal speed and display.

About this task

Use the following procedure to configure terminal settings including the terminal connection speed, and terminal display width and length, in number of characters.

Important:

After you modify the terminal configuration, the new settings are applied to the current active session and to all future sessions (serial, telnet or SSH). Terminal configuration change does not affect open concurrent sessions.

Procedure

- 1. To enter User EXEC mode, log on to the switch.
- 2. At the command prompt, enter the following command:

terminal {speed <2400 | 4800 | 9600 | 19200 | 38400> | length <1-132> | width <1-132>}

3. To display the current serial port information, enter the following command:

show terminal

Example

The following example shows the output from the **show** terminal command.

Switch#show terminal Terminal speed: 9600 Terminal width: 79 Terminal length: 24

Variable definitions

The following table describes the parameters for the **terminal** command.

Variable	Value
speed {2400 4800 9600 19200 38400}	Sets the transmit and receive baud rates for the terminal. You can set the speed to one of the five options shown.
	DEFAULT: 9600
length <1-132>	Sets the length of the terminal display in characters.
	RANGE: 1 to 132
	DEFAULT: 24
width <1–132>	Sets the width of the terminal display in characters.
	RANGE: 1 to 132
	DEFAULT: 79

BootP automatic IP configuration and MAC address

The switch supports the Bootstrap protocol (BootP). You can use BootP to retrieve an ASCII configuration file name and configuration server address. With a properly configured BootP server, the switch automatically learns its assigned IP address, its subnet mask, and the IP address of the default router (default gateway).

The switch has a unique 48-bit hardware address, or MAC address, that is printed on a label on the back panel. Use this MAC address when you configure the network BootP server to recognize the switch BootP requests.

The BootP modes supported by the switch are:

- · BootP or Last Address mode
- BootP or Default IP
- · BootP Always

BootP Disabled



Whenever the switch is broadcasting BootP requests, the BootP process eventually times out if a reply is not received. When the process times out, the BootP request mode automatically changes to BootP or Default IP mode. To restart the BootP process, change the BootP request mode to any of the following modes:

- Always
- · Disabled
- Last
- · Default-ip

Setting user access limits using CLI

The administrator can use CLI to limit user access by creating and maintaining passwords for web, telnet, and console access. This is a two-step process that requires that you first create the password and then enable it.

Setting the system user name and password using CLI

Use the following procedure to configure the system user name and password for access through the serial console port and Telnet. This procedure supports only one read-only and one read-write user on the switch.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

```
username <username> <password> [<ro | rw>]
```

3. To set the username and password to the system default settings, enter the following command:

```
default username [<ro | rw>]
```

😵 Note:

After you configure the user name and password with the username command, you can update the password without changing the username by using the cli password command, the console interface, or EDM.

Variable definitions

The following table describes the parameters for the username command.

Variable	Definition
<username> <password></password></username>	Enter your user name for the first variable, and your password for the second variable. The default user name values are RO for read-only access and RW for read/write access.
ro rw	Specifies that you are modifying the read-only (ro) user name or the read-write (rw) user name. The ro/rw variable is optional. If it is omitted, the command applies to the read-only mode.

Enabling and disabling passwords

After you set the read-only and read-write passwords, you can individually enable or disable them for the various switch-access methods.

Procedure

1. Enter Global Configuration mode:

enable configure terminal

2. Enter the following commands to configure the password for selected access or a specific authentication type:

```
cli password {telnet | serial} {none | local | radius | tacacs}
cli password {read-only | read-write} [<password>]
```

Variable definitions

The following table describes the parameters for the cli password command.

Variable	Definition	
read-only read-write	Modifies the read only password or the read/write password.	
<password></password>	Specifies the password.	
	😵 Note:	
	This parameter is not available when Password Security is enabled, in which case the switch prompts you to enter and confirm the new password.	
	For information about password security, see <u>Configuring Security on Ethernet Routing</u> <u>Switch 3600 Series</u> .	
serial telnet	Modify the password for serial console access or for Telnet access.	

Table continues...

Variable	Definition
none local radius tacacs	Indicates the password type being modified:
	none: disable the password
	 local: uses the locally defined password for serial console or Telnet access
	 radius: uses RADIUS authentication for serial console or Telnet access
	 tacacs: uses TACACS+ authentication, authorization, and accounting (AAA) services for serial console or Telnet access

Customizing the opening banner

You can customize the banner that appears when you connect to the switch. You can customize the text that reads **Extreme Networks**; however, you cannot customize the second line that reads **Enter [Ctrl]+y** to begin.

The Banner Control feature provides an option to specify the banner text. The Banner display that you select is used for subsequent console sessions. For executing the new mode in the console, you must logout. For Telnet access, all subsequent sessions use the selected mode.

You can disable the banner. The system enters the CLI command mode through the default command interface. You do not have to press the Ctrl+y keys.

Customizing the opening CLI banner

Specifies the banner displayed at startup; either static or custom.

Procedure

1. Enter Global Configuration mode:

enable configure terminal

2. At the command prompt, enter the following command:

```
banner [custom | static | <1-19> LINE ]
```

Variable definitions

The following table describes the parameters for the **banner** command.

Variable	Value
static	Displays the default agent-banner
custom	Displays the custom agent-banner
disabled	Skips the agent-banner display

Table continues...

Variable	Value
<1–19> LINE	Fills the Nth line of the custom banner (1 <n<19) in="" line<="" specified="" td="" text="" the="" with=""></n<19)>
no	Clears all lines of a previously stored custom banner

Displaying the current banner

Display the current banner.

Procedure

1. Enter Global Configuration mode:

```
enable
```

```
configure terminal
```

2. At the command prompt, enter the following command:

```
show banner [custom | static]
```

Variable definitions

The following table describes the parameters for the show banner command.

Variable	Value
static	Displays default banner
custom	Displays custom banner
(if empty)	Displays static, custom or disabled status if parameter is not entered

Disabling the CLI banner

About this task

Use the following procedure to disable the banner and to remove the requirement to press the $Ctrl +_Y$ keys to begin.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. Enter the following command to disable the banner:

banner disabled

3. Enter the following command to reenable the banner and add the requirement to press the Ctrl+y keys to begin:

no banner

Example

The following example provides sample of the output of the **banner** disabled command.

```
Switch(config)#banner disabled
Switch(config)#show banner
Current banner setting: DISABLED
```

Configuring Simple Network Time Protocol

The Simple Network Time Protocol (SNTP) feature synchronizes the Universal Coordinated Time (UTC) to an accuracy within 1 second. This feature adheres to the IEEE RFC 2030 (MIB is the s5agent). With this feature, the system can obtain the time from any RFC 2030-compliant NTP/ SNTP server.

For more information on SNTP, see Configuring Systems on Ethernet Routing Switch 3600 Series.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. Enter the following command:

[no] sntp server <primary | secondary> address <A.B.C.D>

Variable definitions

Use the data in the following table to use the **sntp** server command.

Variable	Definition
<a.b.c.d></a.b.c.d>	Specifies the IP address of the primary or secondary NTP server in the format XXX.XXX.XXX.XXX.

Configuring local time zone

Configure the time zone to use an internal system clock to maintain accurate time. The time zone data does not include daylight saving time changes. You must configure daylight saving time.

😵 Note:

SNTP uses Universal Coordinated Time UTC for all time synchronizations so it is not affected by different time zones.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

[no] clock time-zone <zone> <hours> <minutes>

Variable definitions

The following table describes the parameters for the clock time-zone command.

Variable	Value
zone	Specifies time zone acronym that can be displayed when showing system time; for example, EST for Eastern Standard Time. RANGE: Up to 4 characters
hours	Specify the hours difference from UTC.
	RANGE: —12 to + 12
minutes	Optional minutes difference from UTC.
	RANGE: 0–59
no	Disables the clock time zone feature

Configuring daylight savings time

Configure the daylight savings time with start and end dates, or disable the daylight savings time feature.

Procedure

1. Enter Global Configuration mode:

enable configure terminal

2. At the command prompt, enter the following command:

```
[no] clock summer-time <zone> [date {<day> <month> <year> <hh:mm>}
{<day> <month> <year> <hh:mm>}] [<offset>]
```

Variable definitions

The following table describes the parameters for the clock summer-time command.

Variable	Value
zone	Specifies the acronym to be displayed when summer time is in effect. If unspecified, defaults to the time zone acronym.

Table continues...

Variable	Value
	RANGE: up to 4 characters
date { <day> <month> <year> <hh:mm>} {<day> <month> <year> <hh:mm>}</hh:mm></year></month></day></hh:mm></year></month></day>	The first date specifies when summer time starts, and the second date specifies when summer time ends.
	 day — day of the month (RANGE: 1 to 31)
	 month — month (RANGE: first three letters by name)
	 hh:mm — time in military format (24–hour clock), in hours and minutes
	Important:
	<day> <month> parameters can also be entered in order: <month> <day>.</day></month></month></day>
offset	Number of minutes to add during summer time
	RANGE:840 to 840
no	Disables the daylight savings time feature

Specifying summer-time recurring dates

Specify the dates that recur during the summer-time clock every year. This procedure provides flexibility for countries where the Daylight Savings Time is different than North America.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

clock summer-time recurring <1-5> <DAY> <MONTH> hh:mm> <1-5> <DAY>
<MONTH> <hh:mm> <1-1440>

Example

The following figure provides a sample of the output of the **clock** summer-time recurring command.

```
Switch(config)#clock summer-time recurring 1 tues Jun 12:01 3 sat Sep 23:57 1
Summer time recurring is set to:
start: 1st week of June on Tuesday at 12:01
end: 3rd week of September on Saturday at 23:57
Offset: 60 minutes.
```

Variable definitions

The following table describes the parameters for the summer-time recurring command.

Variable	Value
<1–5>	Specifies the week of the month. The first occurrence specifies when the recurring starts, and the second specifies when the recurring stops.
<day></day>	Specifies the day of the week as the first 3 letters of the name. The first occurrence specifies when the recurring starts, and the second specifies when the recurring stops.
<month></month>	Specifies the Month using the first 3 letters of the name. The first occurrence specifies when the recurring starts, and the second specifies when the recurring stops.
<hh:mm></hh:mm>	Specifies the time in hours and minutes in military format (24–hr). The first occurrence specifies when the recurring starts, and the second specifies when the recurring stops.
<1–1440>	Specifies the number of minutes to add or subtract during summer-time recurring.

Displaying the local time zone settings

Display the settings for the local time zone.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

show clock time-zone

Example

The following figure provides a sample of the output of the **show clock time-zone** command.

```
switch(config)#show clock time-zone
    Time zone offset from UTC is 00:00
```

Displaying the daylight savings time settings

Display the daylight savings time settings.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. At the command prompt, enter the following command:

show clock summer-time

Example

The following figure provides a sample of the output of the **show clock summer-time** command.

```
switch(config)#show clock summer-time
Summer time recurring is set to:
start: on Tuesday in the 1st week of June at 12:01
end: on Saturday in the 3rd week of September at 23:59
Offset: 60 minutes.
Daylight saving time is disabled
```

Configuring a static route using CLI

Create static routes to manually configure a path to destination IP address prefixes.

Before you begin

- Enable IP routing globally.
- Enable IP routing and configure an IP address on the VLANs to be routed.

Procedure

- 1. Log on to CLI in Global Configuration command mode.
- 2. At the command prompt, enter the following command:

```
[no] ip route <dest-ip> <mask> <next-hop> [<cost>] [disable]
[enable] [weight <cost>]
```

Variable definitions

The following table describes the parameters for the ip route command.

Variable	Value
[no]	Removes the specified static route.
<dest-ip></dest-ip>	Specifies the destination IP address for the route being added.
	DEFAULT:
	0.0.0.0 is considered the default route.
<mask></mask>	Specifies the destination subnet mask for the route being added.

Table continues...

Variable	Value
<next-hop></next-hop>	Specifies the next hop IP address for the route being added.
[<cost>]</cost>	Specifies the weight, or cost, of the route being added.
	RANGE:
	1–65535
[enable]	Enables the specified static route.
[disable]	Disables the specified static route.
[weight <cost>]</cost>	Changes the weight, or cost, of an existing static route.
	RANGE:
	1–65535

Enabling remote access

You can enable remote access for telnet, SSH (on SSH software images), SNMP, and webpage access.

About this task

Use the following procedure to enable and configure remote access to the management features of the switch.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. To enable telnet remote access, enter the following command:

telnet-access enable

3. To enable SSH remote access, enter the following command:

ssh

4. To enable SNMP remote access, enter the following command:

snmp-server enable

5. To enable webpage remote access, enter the following command:

web-server enable

Example

The following is an example of enabling telnet remote access:

```
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#telnet-access enable
Switch(config)#
```

Using telnet to log on to the device

Procedure

1. From a computer or terminal, start a telnet session:

telnet <IPv4 address>

where <IPv4_address> is the IP address of the switch. The stand-alone units use the default IP address of 192.168.1.1 and the stacking units use the default IP address of 192.168.1.2 if the switch does not obtain its IP address from another source.

2. Enter the user ID and password when prompted.

Enabling the web server management interface

The web server must be enabled to access Enterprise Device manager (EDM). If you do not want EDM to be accessible on the device, disable the web server. By default, the web server is enabled.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

web-server enable

Accessing the switch through the web interface

You can use EDM to configure and maintain your switch through a web-based graphical user interface. You can monitor the switch through a web browser from anywhere on the network.

By default, you can access the web interface using Hypertext Transfer Protocol Secure (HTTPS) only.

By default, the web interface uses a 15 minute time-out period. If no activity occurs for 15 minutes, the system logs off the switch web interface, and you must reenter the password information.

For more information, see .

Before you begin

- Ensure that the switch is running.
- Note the switch IP address.
- Ensure that the web server is enabled.
- Note the user name and password.
- Open one of the supported web browsers.

For more information about the supported browsers, see <u>Using CLI and EDM on Ethernet</u> <u>Routing Switch 3600 Series</u>.

About this task

Use this procedure to access the switch through a web browser.

Procedure

- 1. Start your web browser.
- 2. Type the switch IP address as the URL in the Web address field.

```
http://<IP Address>
```

OR

https://<IP Address>

- 3. Enter the user name.
- 4. Enter the password.
- 5. Click Log On.

Creating a VLAN using CLI

Use this procedure to create port-based or IPv6 protocol-based VLANs.

Important:

This procedure fails if the VLAN already exists.

Procedure

1. Enter Global Configuration mode:

enable configure terminal

2. At the command prompt, enter the following command:

```
vlan create {<1-4094> | <vid_list>} [name <WORD>] [ type { port |
protocol-ipv6Ether2 | voice-vlan}] | [voice-vlan] [msti <1-7> |
cist]
```

Example

```
vlan create 2-10,80 type port
vlan create 15 type voice-vlan
```

Variable definitions

The following table describes the parameters for the **vlan** create command.

Variable	Value
<1-4094> <vid_list></vid_list>	Enter the ID of the VLAN you want to create or enter as a list or range of VLAN IDs to create multiple VLANs simultaneously. A VLAN ID can range from 1 to 4094
name <word></word>	Enter the new name you want for the VLAN.
type	Enter the type of VLAN. Values include:
	port — port-based VLAN
	protocol-ipv6Ether2 — IPv6 protocol-based VLAN
	voice-vlan — voice VLAN
msti <1–7> <i>cist</i>	This parameter is available only in MSTP mode. It associates the VLAN with either an MSTI instance or the CIST.

Saving the configuration

After you change the configuration, you must save the changes. Save the configuration to a file to retain the configuration settings.

😵 Note:

File Transfer Protocol (FTP) and TFTP support both IPv4 and IPv6 addresses, with no difference in functionality or configuration.

Before you begin

Enable the Trivial File Transfer Protocol (TFTP) on the switch.

About this task

Use this procedure to save the configuration.

Procedure

1. Enter Privileged EXEC mode:

enable

2. At the command prompt, enter the following command:

save config

Configuring system identification

About this task

You can configure system identification to specify the system name, contact person, and location of the switch, and to add a trap receiver to the trap-receiver table.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. Enable the Simple Network Management Protocol (SNMP) server:

snmp-server enable

3. Configure the read-only community name:

```
snmp-server community ro
```

😵 Note:

Enter the community string twice.

If you ran the install script to set up the configuration information, the read-only community name is already configured.

4. Configure the read-write community name:

```
snmp-server community rw
```

Note:

Enter the community string twice.

If you ran the install script to set up the configuration information, the read-write community name is already configured.

5. Configure the system name:

snmp-server name <text>

6. Configure the system contact:

snmp-server contact <text>

7. Configure the location:

snmp-server location <text>

8. Configure the SNMP host to add a trap receiver to the trap-receiver table:

```
snmp-server host <host-ip> <community-string>
```

Variable definitions

Use the definitions in the following table to use the **snmp-server** name command.

Table 3: snmp-server name command

Variable	Definition
<text></text>	Specify the SNMP system name value. Enter an alphanumeric string of up to 255 characters.
	✤ Note:
	On the console, the SNMP server name is truncated. On the web interface, the full SNMP server name appears.

Use the definitions in the following table to use the **snmp-server** contact command.

Table 4: snmp-server contact command

Variable	Definition
<text></text>	Specify the SNMP system contact value. Enter an ASCII string of up to 255 characters.

Use the definitions in the following table to use the snmp-server location command.

Table 5: snmp-server location command

Variable	Definition
<text></text>	Specify the SNMP system location value. Enter an alphanumeric string of up to 255 characters.

Use the definitions in the following table to use the **snmp-server** host command.

Table 6: snmp-server host command

Variable	Definition
<host-ip></host-ip>	Specify an IPv4 or IPv6 address for a host intended to be the trap destination.
<community-string></community-string>	If you are using the proprietary method for SNMP, enter a community string that works as a password and permits access to the SNMP protocol.

Configuring the IP address

Use this procedure to configure the IP address and subnet mask for the switch or stack. You can also use this procedure to select the boot mode for the next switch reboot.

Important:

When you change the IP address or subnet mask, you can lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial Console port to configure a new IP address.

😵 Note:

If you do not specify the stack or switch parameter, the system automatically modifies the stack IP address when in stack mode and modifies the switch IP address when in standalone mode.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. At the command prompt, enter the following command:

```
ip address [switch|stack|unit<1-8>][<A.B.C.D>] [netmask <A.B.C.D>]
[default-gateway <A.B.C.D>]
```

Variable definitions

The following table describes the parameters for the ip address command.

Variable	Value
A.B.C.D	Enters the IP address or subnet mask of the switch in the format XXX.XXX.XXX.XXX; netmask is optional.
switch stack unit <1-8>	Specifies whether to set the IP address for the switch, the stack, or another unit in a stack.
netmask	Sets the IP subnet mask.
default-gateway <a.b.c.d></a.b.c.d>	Sets the IP address of the default gateway.

Clearing the IP address

Use this procedure to clear the existing IP address and subnet mask for the switch or stack or another unit of a stack.

Important:

When you change the IP address or subnet mask, you can lose connection to Telnet and the Web. You also disable any new Telnet connection, and you must connect to the serial Console port to configure a new IP address.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. At the command prompt, enter the following command:

```
no ip address [switch|stack|unit<1-8>]
```

Configuring the IP address

Use this procedure to automatically obtain an in-band management IP address, subnet mask and default gateway on the switch or stack.

About this task

When you use DHCP, the switch or stack can also obtain up to three DNS server IP addresses.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

```
ip address source {bootp-always | bootp-last-address | bootp-when-
needed | configured-address | dhcp-always | dhcp-last-address |
dhcp-when-needed}
```

Variable definitions

The following table describes the parameters for the ip address sourcecommand.

Variable	Value
bootp-always	Always use the BootP server.
bootp-last-address	Use the last BootP server.
bootp-when-needed	Use the BootP server when needed.
	DEFAULT: bootp-when-needed
configured-address	Use the manually configured IP configuration.
dhcp-always	Always use the DHCP server.
dhcp-last-address	Use the last DHCP server.
dhcp-when-needed	Use DHCP client when needed.

Configuring the IP address to the default value

The default value for the switch is 192.168.1.1 for Standalone Mode or 192.168.1.2 for Stacking Mode.

Procedure

1. Enter Global Configuration mode:

```
enable
configure terminal
```

2. At the command prompt, enter the following command:

default ip address

Displaying IP address information

Use this procedure to display IP configurations, switch address, subnet mask, and gateway address.

Procedure

- 1. To enter User EXEC mode, log on to the switch.
- 2. At the command prompt, enter the following command:

show ip address

Example

The following figure displays a sample output for the **show** ip **address** command.

Switch>show ip address

	Configured	In Use	Last BootP/DHCP
Stack IP Address:	192.0.1.1		0.0.0.0
Switch IP Address:	192.0.1.2	192.0.1.2	0.0.0.0
Switch Subnet Mask:	255.255.255.0	255.255.255.0	0.0.0.0

😵 Note:

The Router and DNS IP addresses are global, or common. Addresses and pools that do not have Router and DNS addresses configured within them use these global addresses.

Changing subnet netmask value

The subnet mask is configured using procedure <u>Configuring the IP address</u> on page 35. Use this procedure to change the subnet mask to the default value or clear the subnet mask.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

[default] [no] ip netmask

Variable definitions

The following table describes the parameters for the ip netmask command.

Variable	Value
default	Sets the subnet mask to the default value (255.255.255.0).
no	Sets the subnet mask for a switch to all zeros (0.0.0.0).

Configuring the default gateway

Use this procedure to configure the IP default gateway address for a switch, to change the IP default gateway address to the default address, or to clear the IP default gateway address.

Important:

When you change the IP gateway address, you can lose connection to Telnet and the Web. You also can disable any new Telnet connection required to connect to the serial Console port to configure a new IP Gateway address.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

[no] [default] ip default-gateway <A.B.C.D>

Variable definitions

The following table describes the parameters for the ip default-gateway command.

Variable	Value	
<a.b.c.d></a.b.c.d>	Enter the IP address of the default IP gateway in the format XXX.XXX.XXX.XXX.	
	DEFAULT: 0.0.0.0.	
	Important:	
	When you change the IP gateway, you can lose connection to Telnet and the Web. You can also disable any new Telnet connection required to connect to the serial Console port to configure a new IP Gateway address.	
no	Clears the IP address of the default IP gateway. Sets the IP default gateway address to zeros (0).	
default	Sets the IP default gateway address to all zeros (0.0.0.0).	

Displaying IP configuration

This procedure is used to display the IP configuration, specifically BootP mode, switch or stack or unit address, subnet mask, and gateway address. These parameters are displayed for what is configured, what is in use, and the last BootP.

Procedure

- 1. To enter User EXEC mode, log on to the switch.
- 2. At the command prompt, enter the following command:

```
show ip [bootp][default-gateway [address [switch | stack | unit <1-
8>]][dns]
```

If you do not enter any parameters, the **show ip** command displays all IP-related configuration information.

Example

The following figure displays a sample output of the **show** ip command.

Variable definitions

The following table describes the parameters for the **show** ip command.

Variable	Value
bootp mode	Displays BootP-related IP information.
default-gateway	Displays the IP address of the default gateway.
address	Displays the current IP address.
switch stack unit <1–8>	Specifies the current IP address of the switch or stack or specified unit.
dns	Displays the DNS configuration.

Pinging an IP device

You can ping a device to test the connection between a switch and another network device. After you ping a device, the switch sends an Internet Control Message Protocol (ICMP) packet to the target device. If the device receives the packet, it sends a ping reply. After the switch receives the reply, a message appears that indicates traffic can reach the specified IP address. If the switch does not receive a reply, the message indicates the address does not respond.

Before you begin

The local IP address must be configured before issuing the ping command.

Procedure

- 1. To enter User EXEC mode, log on to the switch.
- 2. At the command prompt, enter the following command:

ping <IP_address>

where <IP_address> is an IPv4 or IPv6 address.

Example

The following figure shows a sample ping response.

```
Switch>ping 1292.0.1.1
Host is reachable
```

Variable definitions

The following table describes the parameters for the ping command.

Variable	Value
<a.b.c.d> <dns_host_name> <word></word></dns_host_name></a.b.c.d>	Specifies the IP address, DNS host name, or IPv6 address of the unit to test.
datasize<64-4096>	Specifies the size of the ICMP packet to be sent. The data size range is from 64 to 4096 bytes.
{count <1–9999>} continuous	Sets the number of ICMP packets to be sent. The continuous mode sets the ping running until the user interrupts it by entering Ctrl-C.

Table continues...

Variable	Value
{timeout -t} <1-120>	Sets the timeout using either the timeout or -t parameter, followed by the number of seconds the switch must wait before timing out.
interval<1-60>	Specifies the number of seconds between transmitted packets.
debug	Provides additional output information such as ICMP sequence number and trip time.
source <a.b.c.d></a.b.c.d>	Specifies the source IP address of the packet. Must be a configured address on the switch.
ttl<0–255>	Specifies the maximum hop limit for the packet. Range of 0 to 255.

Displaying the agent and diagnostic software load

Display the currently loaded and operational software status for agent and diagnostic loads, either individually or combined, for a switch or stack.

Procedure

- 1. To enter User EXEC mode, log on to the switch.
- 2. At the command prompt, enter the following command:

show boot [diag] [image]

Example

The following figure provides a sample output of the **show** boot command.

Variable definitions

The following table describes the parameters for the **show** boot command.

Variable	Value
diag	Displays information for the diagnostic load only.
image	Displays information for the image load only.

Displaying RMON Alarms using CLI

Displays information about RMON alarms.

Procedure

1. Enter Global Configuration mode:

enable

configure terminal

2. At the command prompt, enter the following command:

show rmon alarm

Configuring the switch using Enterprise Device Manager

This section provides procedures to configure the switch using Enterprise Device Manager (EDM).

Configuring Quick Start using EDM

Perform this procedure to configure Quick Start to enter the setup mode through a single screen.

Procedure

- 1. From the navigation tree, click **Administration**.
- 2. In the Administration Tree, click Quick Start.
- 3. In the In-Band Switch IP address, type a switch address.
- 4. In the In-Band Subnet Mask dialog box, type a subnet mask.
- 5. In the **Default Gateway** dialog box, type an IP address.
- 6. In the Read-Only Community String box, type a character string.
- 7. In the **Re-enter to verify** dialog box immediately following the Read-Only Community String box, retype the character string from Step 6.
- 8. In the Read-Write Community String dialog box, type a character string.
- 9. In the **Re-enter to verify** dialog box immediately following the Read-Write Community String box, retype the character string from Step 8.
- 10. In the Quick Start VLAN dialog box, type a VLAN ID.
- 11. To enable the DHCP Server, select the **ServerEnable** check box and enter the DHCP server information.

12. Click Apply.

Example

ER53500 - 🔍	Device Physical View	h Summary 🛞 🛅 Quick Start 🛞	
2 2 1 1 2 2	IP/Community/Vlan		
iearch: × P	✓ Apply SRefresh @Help		
Configuration Gamma Administration	In-Band Stack IP Address:	172.16.120.12 172.16.120.12	
Quick Start Remote Access	In-Band Subnet Mask:	255.255.255.0 255.255.0	
E Run Script	Default Gateway:	172.16.120.1 172.16.120.1	
	Read-Only Community String		
 □ Edit □ Security □ Graph □ Power Management □ VLAN 	Read-Write Community String:	Re-enter to verify	
Þ 🗀 P		No-uncur co reasy	
▷ 🛄 IPv6 ▷ 🧰 QoS	Quick Start VLAN:	14094	
⊳ 🧰 Serviceability ⊳ 🦳 Help	DHCP Server	ServerEnable	
	Pool Name:		
	StartAddress:	(A.B.C.D)	
	EndAddress:	(A.B.C.D)	
	SubnetMask:	(A.B.C.D)	
	Router(s):	(A.B.C.D, empty=ignore, use , for more than on	e entry, max:2)
	DNS Server(s):	(A.B.C.D, empty=ignore, use , for more than on	e entry, max:2)

Setting user access limits using Enterprise Device Manager

You can use Enterprise Device Manager (EDM) to limit user access by creating and maintaining passwords for web, telnet, and console access.

Configuring a console password using EDM

Use this procedure to configure a Console password for an individual switch.

Procedure

- 1. From the navigation tree, double-click **Security** to open the Security tree.
- 2. From the Security tree, click **Web/Telnet/Console**.
- 3. In the work area, click the Console Password tab.
- 4. In the Console Switch Password Setting, select a value from the **Console Password Type** list.
- 5. In the Read-Only Switch Password dialog box, type a character string.
- 6. In the **Re-enter to verify** dialog box for the Read-Only Switch Password, retype the character string.
- 7. In the Read-Write Switch Password dialog box, type a character string.

- 8. In the **Re-enter to verify** dialog box for the Read-Write Switch Password, retype the character string.
- 9. On the toolbar, click **Apply**.

Field Descriptions

Use the descriptions in the following table to configure the console switch password.

Name	Description
Console Stack Password Type	Specify the type of password to use. Values include:
	 none—Disables the password
	 Local Password—Use the locally-defined password for serial console access
	 RADIUS Authentication—Use RADIUS authentication for serial console access
	 TACACS Authentication—Use TACACS+ authentication, authorization and accounting (AAA) services authentication for console access
Read-Only Stack Password	Specify the read-only password for stack or switch access.
Read-Write Stack Password	Specify the read-write password for stack or switch access.

Configuring a Web and Telnet password using EDM

Use this procedure to configure a Web and Telnet password for an individual switch.

Procedure

- 1. From the navigation tree, double-click **Security** to open the Security tree.
- 2. In the Security tree, double-click Web/Telnet/Console.
- 3. In the work area, click the **Web/Telnet Password** tab.
- 4. In the Web/Telnet Switch Password Setting, select a value from the **Web/Telnet Switch Password Type** list.
- 5. In the Read-Only Switch Password dialog box, type a character string.
- 6. In the **Re-enter to verify** dialog box for the Read-Only Switch Password, retype the character string.
- 7. In the Read-Write Switch Password dialog box, type a character string.
- 8. In the **Re-enter to verify** dialog box for the Read-Write Switch Password, retype the character string
- 9. On the toolbar, click **Apply**.

Field Descriptions

Use the descriptions in the following table to configure the console switch password.

Name	Description
Web/Telnet Stack Password Type	Specify the type of password to use. Values include:
	 none—Disables the password
	 Local Password—Use the locally-defined password for serial console access
	 RADIUS Authentication—Use RADIUS authentication for serial console access
	 TACACS Authentication—Use TACACS+ authentication, authorization and accounting (AAA) services authentication for console access
Read-Only Stack Password	Specify the read-only password for stack or switch access. The maximum length of the password is 15 characters.
Read-Write Stack Password	Specify the read-write password for stack or switch access. The maximum length of the password is 15 characters.