

## Service Release Notes for WiNG 5.8.6.8-002R

**Please Note:** Service releases are made available to fix specific customer reported issues in a timely manner. Service releases are not as extensively tested as main releases (such as 5.8.6.0-011R). The next maintenance or manufacturing release will incorporate all qualifying and preceding service releases.

This document is an addendum to the release notes for the main release 5.8.6.0-011R.

### Contents

- Resolved Issues
- Platforms supported
- Upgrade/Downgrade Process

### Resolved Issues

This service release 5.8.6.8-002R contains important fixes WPA2 KRACK vulnerability.

Following is a list of changes in this release:

SPR/CQ	Description
WING-36015	WPA2 KRACK: Patch Client Bridge Supplicant (CVE-2017-13078, CVE-2017-13080)
WSP-9040	Support for ADSP sensor to detect KRACK signature
SPR-3394	AP 75XX when receiving wireless packets with VLAN tag – preserves the tag and doesn't update it with correct VLAN.

### 2. Platforms Supported

This release applies to all platforms released with WiNG 5.8.6.0-011R.

Reminder:

Dependent AP platforms: AP 621, 622, 650 are EOL and engineering support has ended.

Independent AP platforms: AP 6511, AP 6511E, AP 7131, AP 7181, AP 8222, ES 6510 are EOL and engineering support has ended.

Controller platforms: RFS 4011, RFS 7000, NX 9000, NX 45XX and NX 65XX platforms are EOL and engineering support has ended.

### 3. Firmware Upgrade/Downgrade Procedure

The method described in this section uses the Command Line Interface (CLI) procedures. To log into the CLI, either SSH, Telnet or serial access can be used.

**For detailed upgrade procedure – please refer to WiNG 5.8.6 release notes.**

#### Upgrade from WiNG v5.x.x.x to WiNG v5.8.6.x

1. Copy the controller image to your tftp/ftp server.
2. Use the **—upgrade ftp://<username>:<password>@<ip address of server>/<name of file>**, or **—upgrade tftp://<ip address of server>/<name of file>** command from CLI or **Switch->Firmware->Update Firmware** option from the GUI. You may need to specify the username and password for your ftp server.
3. Restart the controller. From CLI the command is **—reload**.