

ExtremeSwitching™

Installing Ethernet Routing Switch 3500 Series

Release 5.3.6
NN47203-304
Issue 02.01
December 2017

© 2017, Extreme Networks, Inc.
All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Extreme Networks, Inc. assumes no liability for any errors. Extreme Networks, Inc. reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published in varying mediums which may include product information, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Extreme Networks shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Extreme Networks. End User agrees to indemnify and hold harmless Extreme Networks, Extreme Networks' agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Extreme Networks is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Extreme Networks. Extreme Networks is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Extreme Networks does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Extreme Networks provides a limited warranty on Extreme Networks hardware and software. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Extreme Networks' standard warranty language, as well as information regarding support for this product while under warranty is available to Extreme Networks customers and other parties through the Extreme Networks Support website: <http://www.extremenetworks.com/support> under the link "Policies" or such successor site as designated by Extreme Networks. Please note that if You acquired the product(s) from an authorized Extreme Networks Channel Partner outside of the United States and Canada, the warranty is provided to You by said Extreme Networks Channel Partner and not by Extreme Networks.

"Hosted Service" means an Extreme Networks hosted service subscription that You acquire from either Extreme Networks or an authorized Extreme Networks Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Extreme Networks or Extreme Networks Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN EXTREME NETWORKS HOSTED SERVICE SUBSCRIPTION FROM EXTREME NETWORKS OR AN EXTREME NETWORKS CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE EXTREME NETWORKS WEBSITE, <https://extremeportal.force.com> OR SUCH SUCCESSOR SITE AS DESIGNATED BY EXTREME NETWORKS, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU

REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE EXTREME NETWORKS WEBSITE, <https://extremeportal.force.com> OR SUCH SUCCESSOR SITE AS DESIGNATED BY EXTREME NETWORKS, ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS EXTREME NETWORKS SOFTWARE, PURCHASED FROM EXTREME NETWORKS, INC., ANY EXTREME NETWORKS AFFILIATE, OR AN EXTREME NETWORKS CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH EXTREME NETWORKS OR AN EXTREME NETWORKS CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY EXTREME NETWORKS IN WRITING, EXTREME NETWORKS DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN EXTREME NETWORKS, AN EXTREME NETWORKS AFFILIATE OR AN EXTREME NETWORKS CHANNEL PARTNER; EXTREME NETWORKS RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND EXTREME NETWORKS, INC. OR THE APPLICABLE EXTREME NETWORKS AFFILIATE ("EXTREME NETWORKS").

Extreme Networks grants You a license within the scope of the license types described below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License as set forth below in the Designated System(s) License (DS) section as applicable. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to You. "Software" means computer programs in object code, provided by Extreme Networks or an Extreme Networks Channel Partner, whether as stand-alone products, pre-installed on hardware products, and any upgrades, updates, patches, bug fixes, or modified versions thereto. "Designated Processor" means a single stand-alone computing device. "Server" means a set of Designated Processors that hosts (physically or virtually) a software application to be accessed by multiple users. "Instance" means a single copy of the Software executing at a particular time: (i) on one physical machine; or (ii) on one deployed software virtual machine ("VM") or similar deployment.

License type(s)

Designated System(s) License (DS). End User may install and use each copy or an Instance of the Software only: 1) on a number of Designated Processors up to the number indicated in the order; or 2) up to the number of Instances of the Software as indicated in the order, Documentation, or as authorized by Extreme Networks in writing. Extreme Networks may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other specific designation, or to be provided by End User to Extreme Networks through electronic means established by Extreme Networks specifically for this purpose.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Extreme Networks. All content on this site, the documentation, Hosted Service, and the product provided by Extreme Networks including the selection, arrangement and design of the content is owned either by Extreme Networks or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part,

including any code and software unless expressly authorized by Extreme Networks. Unauthorized reproduction, transmission, dissemination, storage, and/or use without the express written consent of Extreme Networks can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Note, unless otherwise stated, that each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Extreme Networks Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

Third Party Components

"Third Party Components" mean certain software programs or portions thereof included in the Software or Hosted Service may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). As required, information regarding distributed Linux OS source code (for those products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the products, Documentation or on Extreme Networks' website at: <http://www.extremenetworks.com/support/policies/software-licensing> or such successor site as designated by Extreme Networks. The open source software license terms provided as Third Party Terms are consistent with the license rights granted in these Software License Terms, and may contain additional rights benefiting You, such as modification and distribution of the open source software. The Third Party Terms shall take precedence over these Software License Terms, solely with respect to the applicable Third Party Components to the extent that these Software License Terms impose greater restrictions on You than the applicable Third Party Terms.

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://WWW.MPEGLA.COM).

Service Provider

THE FOLLOWING APPLIES TO EXTREME NETWORKS CHANNEL PARTNER'S HOSTING OF EXTREME NETWORKS PRODUCTS OR SERVICES. THE PRODUCT OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM THE THIRD PARTY SUPPLIER. AN EXTREME NETWORKS CHANNEL PARTNER'S HOSTING OF EXTREME NETWORKS PRODUCTS MUST BE AUTHORIZED IN WRITING BY EXTREME NETWORKS AND IF THOSE HOSTED PRODUCTS USE OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING BUT NOT LIMITED TO MICROSOFT SOFTWARE OR CODECS, THE EXTREME NETWORKS CHANNEL PARTNER IS REQUIRED TO INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE AGREEMENTS, AT THE EXTREME NETWORKS CHANNEL PARTNER'S EXPENSE, DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.

WITH RESPECT TO CODECS, IF THE EXTREME NETWORKS CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE G.729 CODEC, H.264 CODEC, OR H.265 CODEC, THE EXTREME NETWORKS CHANNEL PARTNER ACKNOWLEDGES AND AGREES THE EXTREME NETWORKS CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE G.729 CODEC IS LICENSED BY SIPRO LAB TELECOM INC. SEE WWW.SIPRO.COM/CONTACT.HTML. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR

THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (I) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://WWW.MPEGLA.COM).

Compliance with Laws

You acknowledge and agree that it is Your responsibility for complying with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Extreme Networks product is used.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Security Vulnerabilities

Information about Extreme Networks' security support policies can be found in the Global Technical Assistance Center Knowledgebase at <https://gtacknowledge.extremenetworks.com/>.

Downloading Documentation

For the most current versions of Documentation, see the Extreme Networks Support website: <http://documentation.extremenetworks.com>, or such successor site as designated by Extreme Networks.

Contact Extreme Networks Support

See the Extreme Networks Support website: <http://www.extremenetworks.com/support> for product or Hosted Service notices and articles, or to report a problem with your Extreme Networks product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Extreme Networks Support website: <http://www.extremenetworks.com/support/contact/> (or such successor site as designated by Extreme Networks), scroll to the bottom of the page, and select Contact Extreme Networks Support.

Contact Avaya Support

See the Avaya Support website: <https://support.avaya.com> for product or Hosted Service notices and articles, or to report a problem with your Avaya product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <https://support.avaya.com> (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Extreme Networks are the registered or unregistered Marks of Extreme Networks, Inc., its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Extreme Networks or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Extreme Networks or the applicable third party.

Extreme Networks is a registered trademark of Extreme Networks, Inc.

All non-Extreme Networks trademarks are the property of their respective owners. Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

For additional information on Extreme Networks trademarks, please see: <http://www.extremenetworks.com/company/legal/>

Contents

Chapter 1: Preface	6
Purpose.....	6
Training.....	6
Providing Feedback to Us.....	6
Getting Help.....	6
Extreme Networks Documentation.....	7
Subscribing to service notifications.....	8
Chapter 2: New in this document	9
Chapter 3: Hardware compatibility for ERS 3500 Series	10
Switch models.....	10
Chapter 4: Preinstallation checklist	13
Chapter 5: Installing the ERS 3500 Series	15
Installation checklist.....	15
Installation fundamentals.....	16
Front panel view.....	16
Electrostatic discharge.....	17
Technical specifications.....	18
Equipment requirement.....	21
Package contents.....	21
Cable requirements.....	22
Switch installation.....	22
Installing an ERS 3500 Series switch in an equipment rack.....	22
Installation and removal of transceivers.....	32
Installing an SFP.....	32
Removing an SFP.....	34
Stacking switches.....	34
Stacking capabilities.....	35
Connecting switches in a stack.....	37
Connecting AC power.....	41
AC power specifications.....	42
Console port pin assignments.....	44
LED state definitions.....	45

Chapter 1: Preface

Purpose

This document provides conceptual information and installation procedures for the switch hardware.

Training

Ongoing product training is available. For more information or to register, you can access the Web site at www.extremenetworks.com/education/.

Providing Feedback to Us

We are always striving to improve our documentation and help you work better, so we want to hear from you! We welcome all feedback but especially want to know about:

- Content errors or confusing or conflicting information.
- Ideas for improvements to our documentation so you can find the information you need faster.
- Broken links or usability issues.

If you would like to provide feedback to the Extreme Networks Information Development team about this document, please contact us using our short [online feedback form](#). You can also email us directly at internalinfodev@extremenetworks.com

Getting Help

Product purchased from Extreme Networks

If you purchased your product from Extreme Networks, use the following support contact information to get help.

If you require assistance, contact Extreme Networks using one of the following methods:

- [GTAC \(Global Technical Assistance Center\) for Immediate Support](#)
 - Phone: 1-800-998-2408 (toll-free in U.S. and Canada) or +1 408-579-2826. For the support phone number in your country, visit: www.extremenetworks.com/support/contact
 - Email: support@extremenetworks.com. To expedite your message, enter the product name or model number in the subject line.
- [GTAC Knowledge](#) – Get on-demand and tested resolutions from the GTAC Knowledgebase, or create a help case if you need more guidance.
- [The Hub](#) – A forum for Extreme customers to connect with one another, get questions answered, share ideas and feedback, and get problems solved. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.
- [Support Portal](#) – Manage cases, downloads, service contracts, product licensing, and training and certifications.

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number and/or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any action(s) already taken to resolve the problem
- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- Any related RMA (Return Material Authorization) numbers

Product purchased from Avaya

If you purchased your product from Avaya, use the following support contact information to get help.

Go to the Avaya Support website at <http://support.avaya.com> for the most up-to-date documentation, product notices, and knowledge articles. You can also search for release notes, downloads, and resolutions to issues. Use the online service request system to create a service request. Chat with live agents to get answers to questions, or request an agent to connect you to a support team if an issue requires additional expertise.

Extreme Networks Documentation

To find Extreme Networks product guides, visit our documentation pages at:

Current Product Documentation

www.extremenetworks.com/documentation/

Table continues...

Archived Documentation (for previous versions and legacy products)
Release Notes

www.extremenetworks.com/support/documentation-archives/

www.extremenetworks.com/support/release-notes

Open Source Declarations

Some software files have been licensed under certain open source licenses. More information is available at: www.extremenetworks.com/support/policies/software-licensing.

Subscribing to service notifications

Subscribe to receive an email notification for product and software release announcements, Vulnerability Notices, and Service Notifications.

About this task

You can modify your product selections at any time.

Procedure

1. In an Internet browser, go to <http://www.extremenetworks.com/support/service-notification-form/>.
2. Type your first and last name.
3. Type the name of your company.
4. Type your email address.
5. Type your job title.
6. Select the industry in which your company operates.
7. Confirm your geographic information is correct.
8. Select the products for which you would like to receive notifications.
9. Click **Submit**.

Chapter 2: New in this document

There are no new feature changes in this release.

Chapter 3: Hardware compatibility for ERS 3500 Series

This chapter lists the hardware.

Switch models

The following table describes the ERS 3500 Series models.

All switch models support autopolarity.

Model	Part Number	Description
ERS 3510GT	AL3500A04–E6	10 port Ethernet Switch configured as: <ul style="list-style-type: none">• 8 ports of 10/100/1000BASE-T with 2 SFP ports• Fanless operation• Standalone
ERS 3510GT-PWR+	AL3500A14–E6	10 port Ethernet Switch configured as: <ul style="list-style-type: none">• 8 ports of 10/100/1000BASE-T (support for IEEE 802.3af PoE or IEEE 802.3at PoE+) with 2 SFP ports• Dual power modes - fanless operation in Low Power Budget mode at 60W max PoE budget, or normal fan operation in High Power Budget mode at 170W max PoE budget• Standalone
ERS 3524GT	AL3500A05–E6	24 port Ethernet Switch configured as: <ul style="list-style-type: none">• 24 ports of 10/100/1000BASE-T with 4 shared SFP ports (combo with ports 21-24)• 2 rear SFP ports can be used as additional ports in Standalone Mode or 2 rear HiStack ports delivering up to 10Gbps Full Duplex

Table continues...

Model	Part Number	Description
		(FDX) of Stackable Chassis throughput per switch in Stacking Mode
ERS 3524GT-PWR+	AL3500A15-E6	24 port Ethernet Switch configured as: <ul style="list-style-type: none"> • 24 ports of 10/100/1000BASE-T (support for IEEE 802.3af PoE or IEEE 802.3at PoE+) with 4 shared SFP ports (combo with ports 21-24) • 2 rear SFP ports can be used as additional ports in Standalone Mode or as 2 rear HiStack ports delivering up to 10Gbps (FDX) of Stackable Chassis throughput per switch in Stacking Mode
ERS 3526T	AL3500A01-E6	26 port Ethernet Switch can be configured as: <ul style="list-style-type: none"> • 24 ports of 10/100Base-TX, plus 2 combo 10/100/1000BASE-T or SFP ports • 2 rear SFP ports can be used as additional ports in Standalone Mode or 2 rear HiStack ports delivering up to 10Gbps (FDX) of Stackable Chassis throughput per switch in Stacking Mode • Fanless operation
ERS 3526T-PWR+	AL3500A11-E6	26 port Ethernet Switch can be configured as: <ul style="list-style-type: none"> • 24 ports of 10/100BASE-TX (support for IEEE 802.3af PoE or IEEE 802.3at PoE+), plus 2 combo 10/100/1000BASE-T or SFP ports • Rear SFP ports can be used as additional ports in Standalone Mode or 2 rear HiStack ports delivering up to 10Gbps (FDX) of Stackable Chassis throughput per switch in Stacking Mode
ERS 3549GTS	AL3500A06-E6	49 port Ethernet Switch configured as: <ul style="list-style-type: none"> • 48 ports of 10/100/1000BASE-T with 2 shared SFP ports (combo with ports 47-48) • 1 SFP+ (1Gig or 10Gig) uplink port • 2 rear SFP ports can be used as additional ports in Standalone Mode or 2 rear HiStack ports delivering up to 10Gbps (FDX) of Stackable Chassis throughput per switch in Stacking Mode

Table continues...

Model	Part Number	Description
ERS 3549GTS-PWR+	AL3500A16-E6	49 port Ethernet Switch configured as: <ul style="list-style-type: none"> • 48 ports of 10/100/1000BASE-T (support for IEEE 802.3af PoE or IEEE 802.3at PoE+) with 2 shared SFP ports (combo with ports 47-48) • 1 SFP+ (1Gig or 10Gig) uplink port • 2 rear SFP ports can be used as additional ports in Standalone Mode or 2 rear HiStack ports delivering up to 10Gbps (FDX) of Stackable Chassis throughput per switch in Stacking Mode
ERS 3550T	AL3500A07-E6	<ul style="list-style-type: none"> • 48 ports of 10/100 Ethernet • 2 ports of combo 10/100/1000/SFP • 2 ports of rear dual mode / stacking
ERS 3550T-PWR+	AL3500A17-E6	<ul style="list-style-type: none"> • 48 ports of 10/100 Ethernet 802.3at PoE+ • 2 ports of combo 10/100/1000/SFP • 2 ports of rear dual mode / stacking

 **Note:**

AC power cords are not packaged with the switch. Ensure you order the correct power cord for your region. For more information, see [Supported power cords](#) on page 43.

Chapter 4: Preinstallation checklist

Before you install the ERS 3500 Series, make sure that you complete the tasks in the preinstallation checklist.

No.	Task	Description	✓
1.	Review the technical specification for the switch. Make sure that the area where you install the switch and where it will operate meet the requirements.	For the physical, electrical, and environmental specifications, see Technical specifications on page 18.	
2.	Verify the AC power specifications. Optionally order a redundant Power Supply Unit (PSU) to provide redundancy and load sharing.	See AC power specifications on page 42.	
3.	Make sure that you have the following tools and cables: <ul style="list-style-type: none"> • Phillips #2 screwdriver • RJ-45 console port cable • ESD cable 	See Cable requirements on page 22.	
4.	Unpack the equipment.	Observe ESD precautions when you unpack the equipment. See Electrostatic discharge on page 17.	
5.	Verify the contents of the shipped package.	See Package contents on page 21 for a description of the components that are provided with the switch.	
6.	Make sure that the power cord has the correct country-specific termination.	See AC power cord specifications on page 42.	
7.	Depending on the switch model, prepare the shelf or table or prepare the equipment rack.	If the switch model is ERS 3510GT or ERS 3510 GT PWR+, prepare shelf or table and ensure the surface supports the combined weight of the switch and attached cables from 15 and 20 pounds (7 to 9 kilograms).	

Table continues...

Preinstallation checklist

No.	Task	Description	✓
		<p>See Installing ERS 3510GT or ERS 3510GT PWR+ on a table or shelf on page 25.</p> <p>Optionally, prepare the rack. See Installing a single ERS 3510GT or ERS 3510GT-PWR+ switch in an equipment rack on page 26 or Installing two ERS 3510GT or ERS 3510GT-PWR+ switches in an equipment rack on page 28.</p> <p>For the other switch models in ERS 3500 series, prepare the equipment rack and ensure that there is enough rack space of 1.75 inches (4.45 centimeters).</p> <p>See Installing ERS 3500 in an equipment rack on page 22.</p>	

Chapter 5: Installing the ERS 3500 Series

This chapter provides the information and procedures to install the ERS 3500 Series.

Installation checklist

Use this checklist to install the ERS 3500 Series.

Table 1: Installation checklist

No.	Task	Description	✓
1.	Install the switch. Installation depends on the switch model. ERS 3510T or ERS 3510GT-PWR+ can be mounted on a wall, table, or shelf. Optionally, it can also be mounted in an equipment rack. All the other switches in the ERS 3500 Series are installed in an equipment rack.	Do any one of the following: <ul style="list-style-type: none">• Installing ERS 3500 in an equipment rack on page 22• Installing ERS 3510GT or ERS 3510GT PWR+ on a table or shelf on page 25• Installing a single ERS 3510GT or ERS 3510GT-PWR+ switch in an equipment rack on page 26• Installing two ERS 3510GT or ERS 3510GT-PWR+ switches in an equipment rack on page 28	
2.	Connect the AC power cord to the switch.	See, Connecting the AC power cord to the switch on page 41.	
3.	Check LEDs to verify the installation.	See, LED state definitions on page 45.	
4.	(Optional) Connect the switches in a stack.	See, Connecting the switches in a stack on page 37.	

Installation fundamentals

This section provides information about the switches and their front panel view.

Front panel view

The following figures illustrate the front panel ports for the switch series.

Ethernet Routing Switch 3500 Series




Figure 1: ERS 3500 Series front panel illustrations

Table 2: Key

Item	Description
1	Console RJ45 port
2	1000Base-X SFP ports
3	10/100 RJ45 ports
4	10/100 RJ45 PoE+ ports
5	10/100/1000 RJ45 ports
6	10/100/1000 RJ45 PoE+ ports
7	SFP+ for SFP+ port

Electrostatic discharge

This section provides information and procedures to prevent electrostatic discharge during installation.

Preventing electrostatic discharge damage

Electrostatic discharge (ESD) is a discharge of stored static electricity that can damage equipment and impair electrical circuitry. Electrostatic voltages can result from friction including, pulling cabling through conduits, walking across carpeted areas, and building static charge in clothing. When you improperly handle electronic components, ESD damage occurs and can result in complete or intermittent failures. While networking equipment is commonly designed and tested to withstand common mode ESD events, voltage can sometimes discharge to some connector pins, which can potentially damage the networking equipment.

Caution:

To protect the switch against ESD damage, take the following measures before you connect data cables to the device:

- Always use antistatic wrist straps. Make sure you adjust the strap to provide good skin contact.
- Ensure that you properly ground work surfaces and equipment racks for protection against electrostatic discharge. You must connect the common point to the building ground wire. In a properly wired building, the nearest reliable ground is typically at the electrical outlet.
- Avoid contact between equipment and clothing. The wrist or ankle strap protects only the equipment from ESD voltages on the body; ESD voltages on clothing can still cause damage.
- Avoid touching any connector pins.
- Do not remove the wrist or ankle strap until the installation is complete.

Preventing electrostatic damage in new cable installations

With new cable installations, Extreme Networks recommends that you use an ESD discharge cable to reduce the potential for damage from static, that can build up in cables. The following figure illustrates an ESD cable.




Figure 2: ESD discharge cable

To install the ESD discharge cable, perform this procedure.

1. Connect the ground lug on the ESD discharge cable to a safe and suitable earth ground.
2. Connect all RJ-45 cable connectors to the female RJ-45 connector of the ESD discharge cable for at least 5 seconds, and then connect each RJ-45 cable connector to the switch.
3. Leave cables connected to the networking equipment. After you connect cables to networking equipment, the cables do not build up charge.

Technical specifications

The following table provides the technical specifications for the individual switches in the ERS 3500 Series. Ensure that the area where you install the switch and where it operates meets these requirements.

⚠ Warning:

To avoid bodily injury from hazardous electrical shock and current, never remove the top of the device. No user-serviceable components are inside.

Table 3: Physical specifications

	Switch	Specification
Height	ERS 3526T, ERS 3526T-PWR+, ERS 3510GT, ERS 3510GT-PWR + ERS 3524GT, ERS 3524GTPWR+, RS 3549GTS, and ERS 549GTS-PWR+	1U or 44.5mm / 1.75"
Width	ERS 3526T, ERS 3526T-PWR+, ERS 3524GT, ERS 3524GT-PWR +, ERS 3549GTS ERS and 3549GTS-PWR+	440mm / 17.5"
	ERS 3510GT, ERS 3510GT-PWR	220mm / 8.75"
	ERS 3526T, ERS 3526T-PWR+, ERS 3510GT-PWR+, ERS 3524GT, and ERS 3524GT-PWR+	280mm / 11"
	ERS 3510GT	200mm / 8"
	ERS 3549GTS and ERS 3549GTS-PWR+	405mm / 15.75"
Weight	ERS 3526T	3.60kg / 8lb
	ERS 3526T-PWR+	4.50kg / 10lb
	ERS 3510GT	1.75kg / 3.9lb
	ERS 3510GT-PWR+	2.70kg / 6lb
	ERS 3524GT	3.55kg / 7.8lb
	ERS 3524GT-PWR+	4.61kg / 10.2lb
	ERS 3549GTS and ERS 3549GTS-PWR+	6.15kg / 13.55lb
	ERS 3510GT	1.75 kg / 3.85 lb
	ERS 3510GT-PWR+	2.70 kg / 5.9 lb

Table 4: Electrical specifications

Electrical component	Switch details	Specification
Power consumption	ERS 3526T	28.5 Watts max
	ERS 3526T-PWR+	500 Watts max
	ERS 3510GT	18 Watts max
	ERS 3510GT-PWR+	210 Watts
	ERS 3524GT	28.5 Watts max
	ERS 3524GT-PWR+	500 Watts max

Table continues...

Electrical component	Switch details	Specification
	ERS 3549GTS	65 Watts max
	ERS 3549GTS-PWR+	484 Watts max
Thermal rating	ERS 3526T	65 BTU/hr max
	ERS 3526T-PWR+	360 BTU/hr max
	ERS 3510GT	61 BTU/hr max
	ERS 3510GT-PWR+	156 BTU/hr max
	ERS 3524GT	95 BTU/hr max
	ERS 3524GT-PWR+	357 BTU/hr max
	ERS 3549GTS	223 BTU/hr max
	ERS 3549GTS-PWR+	424 BTU/hr max
MTBF rating	ERS 3526T	645,510 hrs
	ERS 3526T-PWR+	332,778
	ERS 3510GT	892,667 hrs
	ERS 3510GT-PWR+	673,452 hrs
	ERS 3524GT	657,619 hrs
	ERS 3524GT-PWR+	336,357 hrs
	ERS 3549GTS	471,289 hours
	ERS 3549GTS-PWR+	259,615 hours

Table 5: Environmental specifications

Environmental component	Specification for ERS 3500 series
Operating Temperature	32° and 122° F (0° and 50° C)
Storage Temperature	-40C to 70C
Operating Humidity	95% RH non-condensing
Storage Humidity	95% RH non-condensing
Maximum Operating Altitude	10,000 ft
Storage Altitude	10,000 ft
Acoustic Noise (db)	ERS 3510GT — 0; ERS 3510GT-PWR+ — 36.4; ERS 3524GT— 36.1; ERS 3524GT-PWR+ — 40; ERS 3526T— 0; ERS 3526T-PWR+ — 40; ERS 3549GTS — 58; ERS 3549GTS-PWR+ — 58.
Miscellaneous Operating Considerations	<ul style="list-style-type: none"> • At least 5cm (2") on each side of the switch unit for ventilation • Adequate power source within six feet. One 15 amp circuit required for each power supply • No excessive dust • No nearby sources of severe electromagnetic noise

Table continues...


Environmental component	Specification for ERS 3500 series
	<ul style="list-style-type: none"> No nearby heat sources such as hot air vents or direct sunlight

Equipment requirement

After unpacking this switch, check the contents to be that sure you have received all the components. Then, before beginning the installation, be sure that you have all other necessary installation equipment.

Package contents

AC power cords are not packaged with the switch. Ensure you order the correct power cord for your region.



1. Ethernet Routing Switch 3500 Series
2. Rack-mounting hardware that includes: (not applicable to ERS 3510GT or ERS 3510GT-PWR+)
 - Rack-mount brackets (2)
 - Screws to attach brackets to the switch (8)
 - Screws to attach the switch to the equipment rack (3x4)
3. Rubber footpads (ERS 3510GT and ERS 3510GT-PWR+ only)
4. Documentation includes the Quick Install poster and Regulatory documents
5. Screws (2) and wall anchors (2) for wall mounting (ERS 3510GT and ERS 3510GT-PWR+ only)

Cable requirements

The following table describes the cables required for ERS 3500 Series.

Category 5E or higher specification cabling should be used for 1 Gbps/1000 Mbps operation.

Required Cable	Description
RJ45 console kit	1.8m cable with DB-9 Female for PC and RJ-45 for console port
DB-9/USB integrated console cable	1.5m cable with USB Connector for PC and DB-9 for device console port, also included USB Driver.

Stacking cables

Stacking cables are not included and must be ordered separately for ERS 3500 Series 24-port and 48-port models.

Order code	Description
AL3518001-E6	46cm SFP direct connect stack cable
AL3518002-E6	1.5 meter SFP direct connect stack cab
AL3518003-E6	3 meter SFP direct connect stack cable

Switch installation

This section describes how to install the switch on a table or shelf, or in an equipment rack. The installation procedure is different for ERS 3510GT / ERS 3510GT-PWR+ from the other switch models in the series.

ERS 3510GT / ERS 3510GT-PWR+ can be installed on a table or shelf, or wall mounted. It can also be installed in an equipment rack like the other switches in the ERS 3500 Series.

See the following procedures to install the switch:

- [Installing ERS 3500 in an equipment rack](#) on page 22
- [Installing ERS 3510GT or ERS 3510GT-PWR+](#) on page 24

Installing an ERS 3500 Series switch in an equipment rack

About this task

Install an ERS 3500 Series switch in an equipment rack using the supplied brackets. The brackets secure the chassis and prevent it from sliding around during vibration or when inserting or extracting transceivers.


Before you begin

Check for the following rack and bracket requirements:


- Space of 2.8 inches (7.1 cm) (or one vertical rack width) for each switch in an E1A or 1EC standard 19 inch (48.2 cm) equipment rack and T1A 23 inch (58.5 cm) equipment rack.
- Appropriate rack space to accommodate 1U switch height (44 mm).
- Rack bolted to floor and braced if necessary.
- Rack must be grounded to the same grounding electrode used by the power service in the area. The group path must be permanent and must not exceed 1 Ohm of resistance from the rack to the grounding electrode.
- One Spare Rack Mount Kit. This kit can be used as a replacement rack mount kit for the ERS switch and must be ordered separately (Order Code AL3511001–E6).

Procedure

1. Ensure power is disconnected from the switch.
2. Attach a bracket to each side of the switch with the included screws.



3. Slide the switch into the rack. Insert and tighten the rack mount screws.



4. Verify that the switch is securely fastened to the rack.

Installing an ERS 3510GT or ERS 3510GT-PWR+

The following procedures describe how to install the switch models ERS 3510GT or ERS 3510GT PWR+ on a table or shelf, or in an equipment rack:

- [Installing ERS 3510GT or ERS 3510GT PWR+ on a table or shelf](#) on page 25
- [Installing a single ERS 3510GT or ERS 3510GT-PWR+ switch in an equipment rack](#) on page 26

- [Installing two ERS 3510GT or ERS 3510GT-PWR+ switches in an equipment rack](#) on page 28

Installing an ERS 3510GT or ERS 3510GT-PWR+ switch on a table or shelf

About this task


Install the switch models ERS 3510GT or ERS 3510GT-PWR+ on a flat surface such as a table or shelf.

Before you begin


- Ensure the surface supports the combined weight of the switch and attached cables. Cable weight varies for each installation.
- Allow at least 2 inches (5.1 cm) on each side of the switch for proper ventilation and at least 5 inches (12.7 cm) at the back of the switch for power cord clearance.

Procedure

1. Attach the rubber feet at the marked locations.



2. Set the switch on a table or shelf.



Installing a single ERS 3510GT or ERS 3510GT-PWR+ switch in an equipment rack

About this task

Install the switch using the supplied brackets. The brackets secure the chassis and prevent it from sliding around during vibration or when inserting or extracting transceivers.


Before you begin

Check for the following rack and bracket requirements:


- Ensure to provide the equivalent of one rack of vertical space for each switch in an E1A or 1EC standard 19 inch (48.2 cm) and T1A 23 inch (58.5 cm) equipment rack.
- Appropriate rack space to accommodate 1U switch height (44 mm).
- Rack bolted to floor and braced if necessary.
- Rack must be grounded to the same grounding electrode used by the power service in the area. The group path must be permanent and must not exceed 1 Ohm of resistance from the rack to the grounding electrode.
- one 3510–Single Rack Mount Kit. For more information, see [Package contents](#) on page 21.

Procedure

1. Ensure power is disconnected from the switch.
2. With the front of the ERS 3510GT or ERS 3510GT-PWR+ unit facing you, attach the small bracket from the optional kit to the right side of the switch using the flathead screws provided.



3. With the front of the ERS 3510GT or ERS 3510GT-PWR+ unit facing you, attach the long bracket from the optional kit (see Figure that follows) to the left side of the switch using the flathead screws provided.



4. Slide the switch into the rack as shown in the figure that follows. Insert and tighten the rack mount screws.

About this task

Install two ERS 3510GT or ERS 3510GT-PWR+ units together to form one standard width rack-wide system using a 19 inch side-by-side Rack Mount Kit (ordered separately).

Before you begin

Check for the following rack and bracket requirements:


- Provide the equivalent of one rack of vertical space for each switch in an E1A or 1EC standard 19 inch (48.2 cm) equipment rack and T1A 23 inch (58.5 cm) equipment rack.
- Appropriate rack space to accommodate 1U switch height (44 mm).
- Rack bolted to floor and braced if necessary.
- Rack must be grounded to the same grounding electrode used by the power service in the area. The group path must be permanent and must not exceed 1 Ohm of resistance from the rack to the grounding electrode.
- Pair or side-by-side rack mount kit. For more information, see [Package contents](#) on page 21.
- When mounting two 3510GT-PWR+ units side by side in an equipment rack, run the switches in high power mode to ensure adequate airflow. In high power mode, the available power is 170 Watts.

```
#show poe-main-status
PoE Main Status - Stand-alone
-----
Power Mode : High Power Budget
Available DTE Power : 170 Watts
DTE Power Status : Normal
DTE Power Consumption : 0 Watts
DTE Power Usage Threshold : 80%
PD Detect Type : 802.3at and Legacy
Power Source Present : AC Only
AC Power Status : Present
DC Power Status : Not Present
```


- The PoE+ model supports Power over Ethernet+ with compatibility to 802.3at PoE+. 802.3at is backward compatible for detection with 802.3af.

Procedure


1. Ensure power is disconnected from the switch.
2. Connect the two ERS 3510GT switches together by opening the hinged bracket to 90° and attaching it to each ERS 3510GT switch with three M4 flat head screws (included), as shown below.



3. Attach the standard rack mount bracket ears to the outer end of each switch as shown below.




4. After the switches are joined together, fold the hinged bracket inward.



5. Perform one of the following:


- **To connect two ERS 3510GT or two 3510GT-PWR+ switches together** use the rear bracket as shown below, with four M4 pan head screws to secure the switches at the rear. Once the rear bracket has been installed, the switches can be installed in the rack.



- **To connect one ERS 3510GT switch and one ERS 3510GT-PWR+ switch together** use the offset rear bracket with four M4 pan head screws to join the switches at the rear. Once the rear bracket has been installed, the switches can be installed in the rack.

*** Note:**

If you are mounting a mix of ERS 3510GT and ERS 3510GT-PWR+ units side by side, ensure that the ERS 3510GT unit is mounted on the LEFT side (when viewed from the front) for adequate airflow.



6. Slide the switches into the rack. Insert and tighten the rack mount screws.
7. Verify that the switch is securely fastened to the rack.

Installation and removal of transceivers

The following sections describe how to install and remove transceivers in the ERS 3500 Series switch. In this context, the term *transceiver* refers to Small Form Factor (SFP) and SFP+.

For more information about transceiver use and designation, see *Installing Transceivers and Optical Components on Ethernet Routing Switch 3500 Series*.

Installing an SFP

Install an SFP to provide an interface between the device and the network cable.

Before you begin

- Verify that the SFP is the correct model for your network configuration.
- Before you install the fiber, ensure that the connector is clean.

 **Danger:**

Risk of eye injury by laser

Fiber optic equipment can emit laser or infrared light that can injure your eyes. Never look into an optical fiber or connector port. Always assume that fiber optic cables are connected to a light source.

 **Electrostatic alert:**

ESD can damage electronic circuits. Do not touch electronic hardware unless you wear a grounding wrist strap or other static-dissipating device.

 **Warning:**

Risk of equipment damage

Only trained personnel can install this product.

About this task

Installing an SFP takes approximately 3 minutes.

Procedure

1. Remove the SFP from its protective packaging.
2. Grasp the SFP transceiver between your thumb and forefinger.
3. Insert the device into the port on the module.

Depending on the module type, you must insert some SFP transceivers into the port with the bail facing up and some SFP transceivers with the bail facing down.

 **Warning:**

Risk of equipment damage


Transceivers are keyed to prevent incorrect insertion. If the transceiver resists pressure, do not force it; turn it over, and reinsert it.

Apply a light pressure to the device until it clicks and locks into position.

4. Remove the dust cover from the optical bore, and insert the fiber optic connector.

Example


The following figure shows an example installation of a bore plug transceiver with the bail latch facing up. The figure does not represent a specific product.



Job aid

Depending on the transceiver manufacturer, the SFP transceiver can use different types of locking and extractor mechanisms.

The following figure shows the typical mechanism used on SFP transceivers; other locking mechanisms exist although they are not shown here. In the following figure, the SFP transceiver uses the bore plug. Pull the bail to release the device.



Removing an SFP

Remove an SFP to replace it or to commission it elsewhere.

Before you begin

- Wear an antistatic wrist strap.

Danger:

Risk of eye injury by laser

Fiber optic equipment can emit laser or infrared light that can injure your eyes. Never look into an optical fiber or connector port. Always assume that fiber optic cables connect to a light source.

Electrostatic alert:

ESD can damage electronic circuits. Do not touch electronic hardware unless you wear a grounding wrist strap or other static-dissipating device.

Procedure

1. Disconnect the network fiber optic cable from the SFP connector.
2. Depending on your SFP model, there are different locking mechanisms to release the SFP transceiver. The following describes the typical mechanism used on SFP transceivers; other locking and extractor mechanisms exist, although they are not described here.
 - Bail latch: Pull the swing-down latch handle to the fully lowered position and hold the handle to extract the module.
3. Slide the SFP out of the module SFP slot.

If the SFP does not slide easily from the module slot, use a gentle side-to-side rocking motion while firmly pulling the SFP from the slot.

4. Affix dust covers over the fiber optic bore and connector.
5. Store the SFP in a safe place until needed.

Important:

If you discard the SFP transceiver, dispose of it according to all national laws and regulations.

Stacking switches

All the switches in the ERS 3500 Series other than ERS 3510GT, include up/down stack ports located in the rear of the unit in the form of SFP ethernet ports.

The stack ports can be used in one of two different modes and are not reserved as stacking ports. The two modes are Standalone Mode and Stacking Mode.

*** Note:**

Before adding switches to a stack, ensure that all switches for the stack have the same software image installed, or that the Agent Auto Unit Replacement (AAUR) functionality is enabled on all switches participating in a stack. AAUR automatically installs the stack software image to any unit that has a dissimilar image. AAUR is enabled by default on a switch.


For more information about AAUR, see *Quick Start Configuration for Ethernet Routing Switch 3500 Series*.

Stacking capabilities

ERS 3500 Series supports stacking capability. The two rear ports on these models can be used in either standalone mode (default) or stacking mode.


The ERS 3500 supports stacking capability. The two rear ports on these models can be used in either standalone mode (default) or stacking mode.

- **Standalone Mode** — In this mode, the switch front panel function as follows:
 - Provides two additional uplinks or connections to servers or power users and supports regular port configuration parameters such as Spanning Tree, EAP, VLAN Tagging, MLT/DMLT/VLACP, and port enable/disable
 - Provides fixed port speed at 1000 Mbps Full Duplex operation with the insertion of a supported SFP in the rear ports. Link and traffic indications are provided on the front left of each switch where the LEDs for the rear ports illustrate “Down / 27” and “Up / 28” for the ERS 3526T models, “Down / 25” and “Up / 26” on the ERS 3524GT models, “Down / 50” and “Up / 51” on the ERS 3549GTS models, and “Down / 51” and “Up / 52” on the ERS 3550T models as shown in the figures that follow.
- **Stacking Mode** — In this mode, the switch rear ports function as follows:
 - Provides resilient stacking of up to eight stackable units when the two rear SFP ports are configured for “stacking mode” operation.
 - LEDs on the front panel of the switches indicate “Base Unit” selection and rear stack port Up/Down connection status.
 - Rear ports operate at 2.5 Gbps bandwidth (bi-directional) for an aggregate of up to 80 Gbps for a stack of eight units.




- 1 = Cascade down port
- 2 = Cascade up port
- 3 = Base Unit Select Switch - used to designate the Base Unit in a stack. When set to the RIGHT position, this unit acts as the Base Unit for the stack

Figure 3: ERS 3526T and ERS 3526T-PWR+ rear ports



- 1 = Cascade down port
- 2 = Cascade up port
- 3 = Base Unit Select Switch - used to designate the Base Unit in a stack. When set to the RIGHT position, this unit acts as the Base Unit for the stack

Figure 4: ERS 3524GT and ERS 3524GT-PWR+ rear ports



- 1 = Cascade down port
- 2 = Cascade up port
- 3 = Base Unit Select Switch - used to designate the Base Unit in a stack. When set to the RIGHT position, this unit acts as the Base Unit for the stack

Figure 5: ERS 3549GTS and ERS 3549GTS-PWR+ rear ports




Figure 6: ERS 3550T and ERS 3550T-PWR+ rear ports

Stacking cables must be ordered separately. The correct SFP direct attach cable is required in order to enable and use stacking mode. For more information see, [Cable requirements](#) on page 22.

Connecting switches in a stack

Cascading down or cascading up ports

About this task

Connect a switch to the next unit in the stack through a cascade cable.

The stack parameters are associated with the base unit, the physical stack order depends on the base unit position and whether you configure the stack cascade up (stack up) or cascade down (stack down). This designation depends on the stack cabling arrangement.

* Note:

Extreme Networks recommends that you use a Cascade Down configuration.

Before you begin

- Order the appropriate ERS 3500 Series cascade cables to ensure fail-safe stacking. For more information, see [Cable requirements](#) on page 22.

Procedure

1. Ensure that all switches for the stack are rack mounted.
2. Slide the Unit Select switches on the back of the units to the appropriate position, depending on whether they are a base unit or non-base unit:

- **Base Unit (Unit 1)** - Slide the Unit Select switch to the RIGHT
- **Non-Base Unit (Units 2-8)** - Slide the Unit Select switch to the LEFT

 **Note:**

The Base Unit Select switch defaults to be in the Non-Base position. Only one switch in the stack must have the Base Unit Select switch set to the Base position.

3. Connect stacking cables as required for a Cascade Up (stack up) or Cascade Down (stack down) configuration as shown below:




Figure 7: Cascade Down




Figure 8: Cascade Up

Next steps

For making a standalone switch a stack for the first time and adding a switch to an already existing stack, see *Quick Start Configuration for Ethernet Routing Switch 3500 Series*, NN47203-301.

Connecting AC power

Before you begin


- Ensure to check AC power specifications for the switch.
- Ensure to check the AC power cord for international use. You must use a power cord that is approved for the receptacle type in your country.

Procedure

1. Connect the AC power cord to the back of the switch, and then connect the cord to a power outlet.

*** Note:**

ERS 3500 Series does not have a power switch. When you connect the AC power cord to a suitable AC power outlet, the switch powers up immediately.



2. Check the front-panel LEDs as the device is powered on to be sure the PWR LED is lit. If not, check that the power cable is correctly plugged in.

Connect the AC power cord to the back of the switch, and then connect the cord to a power outlet.

 **Danger:**

Using power cords with a proper grounding path

Use only power cords that have a grounding path. Without a proper ground, a person who touches the switch is in danger of receiving an electrical shock. Lack of a grounding path to the switch can result in excessive emissions.

AC power specifications




The following table describes the AC power specifications for the ERS 3500 Series.

Model	Input current	Input voltage (rms)	Power consumption	Thermal rating
3510GT	Maximum 0.18 A	100–240 VAC at 50–60 Hz	Maximum 18 W	61Btu/h maximum
3510GT-PWR+	Maximum 2.1 A	100–240 VAC at 50–60 Hz	Maximum 210 W	156 Btu/h maximum
3524GT	Maximum 0.28 A	100–240 VAC at 50–60 Hz	Maximum 28.5 W	95 Btu/h maximum
3524GT-PWR+	Maximum 5.0 A	100–240 VAC at 50–60 Hz	Maximum 475 W	357 Btu/h maximum
3526T	Maximum 0.28 A	100–240 VAC at 50–60 Hz	Maximum 28.5 W	95 Btu/h maximum
3526T-PWR+	Maximum 5.0 A	100–240 VAC at 50–60 Hz	Maximum 473 W	350 Btu/h maximum
3549GTS	Maximum 0.71 A	100–240 VAC at 50–60 Hz	Maximum 65 W	223 Btu/h maximum
3549GTS-PWR+	Maximum 4.91 A	100–240 VAC at 50–60 Hz	Maximum 484 W	424 Btu/h maximum
3550T	Maximum 0.83 A	100–240 VAC at 50–60 Hz	Maximum 35 W	118 Btu/h maximum
3550T-PWR+	Maximum 6.8 A	100–240 VAC at 50–60 Hz	Maximum 504 W	456 Btu/h maximum

AC power cord specifications

To connect AC power to the switch, you need an appropriate AC power cord as described in the following table, also see the following table for plug specifications.

Table 6: International power cord specifications

Country and plug description	Specifications	Typical plug
Continental Europe <ul style="list-style-type: none"> • CEE7 standard VII male plug • Harmonized cord (HAR marking on the outside of the cord jacket to comply with the CENELEC Harmonized Document HD-21) 	220 or 230 VAC 50 Hz Single phase	 228FA
U.S./Canada/Japan <ul style="list-style-type: none"> • NEMA5-15P male plug • UL-recognized (UL stamped on cord jacket) • CSA-certified (CSA label secured to the cord) 	100 or 120 VAC 50-60 Hz Single phase	 227FA
United Kingdom <ul style="list-style-type: none"> • BS1363 male plug with fuse • Harmonized cord 	240 VAC 50 Hz Single phase	 229FA
Australia AS3112-1981 male plug	240 VAC 50 Hz Single phase	 230FA

Supported power cords

The switch supports power cords with Power Cords with C13 Power Supply Side Connector.

AC power cords are not packaged with the switch. Ensure you order the correct power cord for your region.

Order Code	Description	Region
AA0020062E6	POWER CORD 3.05M IEC C13 TO NEMA 5-15P	North America
AA0020063E6	POWER CORD 2.5M IEC C13 TO BS1363	United Kingdom
AA0020064E6	POWER CORD 2.5M IEC C13 TO CEE 7/7	European Union

Table continues...


Order Code	Description	Region
AA0020065E6	POWER CORD 2.5M IEC C13 TO CEI 23-16	Italy
AA0020066E6	POWER CORD 2.5M IEC C13 TO GB 2099.1-1996	China
AA0020067E6	POWER CORD 2.5M IEC C13 TO BS-546/SANS164-1	India and South Africa
AA0020068E6	POWER CORD 2.5M IEC C13 TO AS 3112	Australia
AA0020069E6	POWER CORD 2.5M IEC C13 TO JIS 8303	Japan
AA0020101-E6	POWER CORD 2.5M IEC C13 TO NBR 14136 (IEC 60906-1)	Brazil
AA0020104-E6	POWER CORD 2.5M IEC C13 TO SEV 1011	Switzerland
AA0020107-E6	POWER CORD 2.5M IEC C13 TO SI-32	Israel

Console port pin assignments

Console port establishes a management terminal connection to the switch.

You can use an RJ-45 to DB-9 cable to connect the switch console port to your management terminal. Extreme Networks recommends you use the RJ-45. Alternatively a DB-9 to RJ-45 adapter or other suitable console cables can be used - the maximum length of a console cable is 25 feet (8.3 meters). The following table describes the RJ-45 console port pin-out information. You can use the pin-out information to verify or create a console cable for use with your maintenance terminal.

Table 7: Console port pin assignments

Connector	Pin Number	Signal
	1	Ready to send (RTS) — optional, can swap or link with pin 8
	2	Data terminal ready (DTR) — optional, can swap or link with pin
	3	Transmit data (TXD) — mandatory
	4	Carrier detect (DCD) — optional
	5	Ground (GND) — mandatory
	6	Receive data (RXD) — mandatory
	7	Data set ready (DSR) — optional, can swap or link with pin 1
	8	Clear to send (CTS) — optional, can swap or link with pin 1

LED state definitions

The figures and tables in the following sections describe the LEDs on the Ethernet Routing Switch 3500 Series. The tables describe LED operation for a switch that finishes the power-on self-test.

Warning:

Fiber optic equipment can emit laser or infrared light that can injure your eyes. Never look into an optical fiber or connector port. Always assume that fiber-optic cables are connected to a light source.

Switch front panel LED views

The front-panel PWR LEDs are lit when the device powers on.

The following figures illustrate the switch series front panel LED indicators.




Figure 9: ERS 3510GT/3510GT-PWR+ Series Front Panel LEDs




Figure 10: ERS 3524 Front Panel LEDs

Front Panel 3526T & 3526T-PWR+




Figure 11: ERS 3526 Front Panel LEDs




Figure 12: ERS 3549GTS/GTS-PWR+ Front Panel LEDs




Figure 13: ERS 3550T/T-PWR+ Front Panel LEDs

Status LEDs

The System Status LEDs are located on the left side of the unit and include PWR, Status, UP, Down, and Base. The following table defines the operation of the Status LEDs.

LED	State	Definition
PWR	Off	The unit power is off.
	Green (Solid)	Normal operation.
	Green (Blinking)	The system is in reset.

Table continues...

LED	State	Definition
Status	Off	System cannot work properly (like temperature is too high).
	Amber (Solid)	Non-critical warning (the system can still work)
	Amber (Blinking)	The system failed self-test
	Green (Solid)	Everything is OK
	Green (Blinking)	TBD
UP/Down	Off	No Stack-up or Stack-down connection is detected.
	Amber (Solid)	A Stack-up or Stack-down cable is detected, but adjacency has not been completed.
	Green (Solid)	The unit has formed a neighbor with an adjacent unit over the Stack-up or Stack-down cables.
Base	Off	The unit is operating in a standalone mode, or not the stack base unit.
	Amber (Solid)	The unit is operating as the Temporary Base Unit.
	Green (Solid)	The unit is operating as the Base Unit for the designated stack.
	Green (Blinking)	There is a stack configuration error. Either multiple base units or no base unit is configured in the stack.