



Extreme Platform ONE Networking v25.4.0 User Guide

Comprehensive Management and Usage Instructions

9039329-00 Rev AC
August 2025



Copyright © 2025 Extreme Networks, Inc. All rights reserved.

Legal Notice

Extreme Networks, Inc. reserves the right to make changes in specifications and other information contained in this document and its website without prior notice. The reader should in all cases consult representatives of Extreme Networks to determine whether any such changes have been made.

The hardware, firmware, software or any specifications described or referred to in this document are subject to change without notice.

Trademarks

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries.

All other names (including any product names) mentioned in this document are the property of their respective owners and may be trademarks or registered trademarks of their respective companies/owners.

For additional information on Extreme Networks trademarks, see: <https://www.extremenetworks.com/about-extreme-networks/company/legal/trademarks>

Open Source Declarations

Some software files have been licensed under certain open source or third-party licenses.

End-user license agreements and open source declarations can be found at: <https://www.extremenetworks.com/support/policies/open-source-declaration/>




Table of Contents

Abstract.....	viii
Preface.....	ix
Text Conventions.....	ix
Documentation and Training.....	x
Open Source Declarations.....	xi
Training.....	xi
Help and Support.....	xi
Subscribe to Product Announcements.....	xii
Send Feedback.....	xii
Introduction to Extreme Platform ONE Networking.....	13
Navigation Pane.....	14
Content Pane.....	15
Common Functionality.....	18
Administration and Settings.....	21
Pagination.....	22
Supported Applications.....	23
Log In To Extreme Platform ONE Networking	23
Create an Extreme Platform ONE Networking Account.....	24
Forgot Password.....	25
Change Password.....	26
Choose a Theme.....	26
Unified Login Page.....	26
Workspace Overview.....	27
Static Insights.....	27
AI Insights Widgets.....	27
Add AI Insight Widget.....	28
Role-Based Access.....	28
Inventory Status Widget.....	30
Extreme AI Expert.....	31
Extreme AI Expert Icons.....	32
Impersonation.....	32
AI Expert Interaction Modes.....	33
Overview.....	33
Conversational Mode.....	33
Interactive Mode.....	33
Security and Permissions.....	34
AI Canvas.....	34
Key Features.....	34
Canvas States.....	34
Enablement Prompts.....	35


AI Canvas Management.....	35
Select an Existing Canvas.....	35
Delete an Existing Canvas.....	35
Add a New Canvas.....	35
Edit Title of a Canvas.....	35
Delete All Canvases.....	35
Publish a Canvas.....	35
Unpublish a Canvas.....	36
Monitoring.....	37
Dashboard.....	37
Visualize.....	38
Customize the Visualize View.....	39
Visualize Topology Maps.....	41
Geographic Layer View.....	46
Physical Layer.....	46
Radio Frequency Maps.....	49
Access View.....	67
Fabric Layer.....	67
Service Layer.....	70
Reassign Licenses Visualize.....	74
Device Discovery.....	75
View Inspector Panel.....	76
View the Device Inspector Panel.....	77
View Device 360°.....	78
AutoSave Device Layout and Density.....	79
Search an Element.....	79
Settings.....	79
User Roles Supported in Visualize View.....	86
Alerts.....	86
Manage Alerts.....	86
Network Devices.....	88
Device Status.....	88
Device Health.....	125
Usage & Capacity.....	126
Onboard Network Devices.....	127
Update Network Device Firmware.....	128
Device View.....	128
Clients.....	140
Overview.....	140
Client Trail.....	141
Troubleshooting.....	142
Client Actions.....	142
Configuration Sites.....	143
Sites.....	143
Import a Site Tree.....	145
Add a Site.....	145
Add a Site group.....	145
Add a Building.....	146

Add a Floor.....	146
Upload a Floor Plan.....	146
Edit a Site.....	147
Move a Site.....	147
Export a Floor Plan.....	147
Clone a Building.....	148
Delete a Site.....	148
Delete a Building or a Floor.....	148
Configuration Network Policies.....	150
Add a Network Policy.....	151
Configure Policy Settings.....	152
Configure DNS Server Policy Settings.....	153
Configure NTP Server Policy Settings.....	154
Configure SNMP Server Policy Settings.....	156
Configure Syslog Server Policy Settings.....	158
Configure Device Credentials Policy Settings.....	160
Configure the Device Time Zone.....	160
Configure HIVE Policy Settings.....	161
Configure Management and Native VLAN Policy Settings.....	165
Configure IP Tracking Policy Settings.....	167
Configure LLDP/CDP Policy Settings.....	169
Configure Management Options.....	170
Configure Traffic Filters Policy Settings.....	180
Configure MGT IP Filter Policy.....	181
Deploy a Network Policy.....	182
Configure the SSID for a Standard Wireless Network.....	183
Cloud User Group Settings.....	187
Local User Group Settings.....	189
Add a User Profile.....	192
SSIDs.....	193
SSID Usage in Standard Wireless Networks.....	193
Configure a Client Mode AP Profile using a Wired Connection and a Device Template.....	207
Captive Web Portals.....	207
RADIUS Authentication.....	217
Configure VLAN Settings.....	231
Apply Different User Profiles to Clients and User Groups.....	245
Customize Advanced Access Security Controls.....	245
Customize Wireless Network Optional Settings.....	248
Configure Device Templates.....	257
Configure AP Templates.....	257
Configure Switch Templates.....	287
Configure Port Types.....	303
Aggregate LAG and LACP Ports.....	304
Configure Supplemental CLI.....	304
Configure Classification Rules for a Device Template.....	305
Add a Cloud Config Group.....	308
Fabric Attach.....	308
Configure Fabric Attach.....	309

Configure Device Data Collection and Monitoring Options.....	309
Configure the BLE Service.....	311
Configure Presence Analytics.....	314
Configure WIPS.....	314
WIPS Policy Settings.....	315
Configure a Location Server.....	318
Install CA Certificates.....	319
Configure a Layer 2 IPsec VPN Service.....	319
Layer 2 VPN Services Settings.....	320
Subscriptions & Services.....	322
Subscriptions Terminology.....	323
Subscriptions.....	323
Go to the Subscriptions Page.....	324
Subscription Activation and Account Linking.....	324
Link Your Extreme Portal Account to Extreme Platform ONE Networking.....	325
Subscriptions & Licensing User Interface Descriptions.....	326
Search, Group, and Filter.....	327
Examples of Subscriptions & Licensing Detail.....	328
Trial Subscriptions.....	330
Subscription Management.....	331
What to Expect When Licenses Are Upgraded.....	331
Unlocking Full Features.....	332
Should I Add a Subscription or Request a Trial License?.....	333
Request a Trial Subscription.....	334
Purchase a Subscription or Add Additional Licenses.....	334
Create a Subscription Request.....	335
Synchronize Subscriptions.....	335
General License Management.....	336
View License Pool.....	336
View Device State and Subscription Type.....	337
Manage NAC Allocations.....	337
Activate a License.....	338
Pre-provisioning and License Assignment.....	338
View Subscription History.....	339
Renew a Subscription.....	339
Contracts.....	339
Go to the Contracts Page.....	340
Contracts User Interface Descriptions.....	340
View Contract Information.....	341
Quick-Filter Contracts by a Pending Expiration Interval.....	341
Filter Contracts by Specified Date Range.....	341
Filter Contracts by Multiple Criteria.....	342
Renew a Contract.....	343
Contact Sales.....	343
Inventory.....	343
Manage Inventory.....	344
Onboard Devices.....	346
Upgrade Device Firmware.....	347


Administration & Settings.....348

- Access Management.....348
 - Role-Based Access.....348
 - Users & Roles.....353
 - Identity Providers.....357
- Alert Policies.....364
 - Global Policy.....364
 - Site Policy.....365
- External Notifications.....365
- Backup & Restore.....366
 - VIQ Management.....367
 - Set Default Device Password.....368
- Integrations.....368
 - Create a New API Key.....369
- Logs.....369



Abstract

The user guide for Extreme Platform ONE Networking version 25.4.0 provides detailed management and operational instructions for the platform. It covers technical features such as a centralized management interface, real-time alerts and notifications, contextual AI support, and single sign-on (SSO) capabilities. The guide includes specific instructions on navigating the platform, configuring settings, managing subscriptions and licenses, and monitoring network devices. It outlines usage scenarios for monitoring network performance, visualizing topology maps, and troubleshooting connectivity issues. Designed for technical readers, it includes step-by-step procedures, troubleshooting tips, and FAQs to ensure effective use of the platform. New features in this version include enhanced device discovery using LLDP and IS-IS protocols, improved visualization tools for physical, fabric, and service layers, and updated support for various network applications such as ExtremeCloud IQ, ExtremeCloud SD-WAN, and Universal ZTNA.



Preface

Read the following topics to learn about:

- The meanings of text formats used in this document.
- Where you can find additional information and help.
- How to reach us with questions and comments.

Text Conventions

Unless otherwise noted, information in this document applies to all supported environments for the products in question. Exceptions, like command keywords associated with a specific software version, are identified in the text.

When a feature, function, or operation pertains to a specific hardware product, the product name is used. When features, functions, and operations are the same across an entire product family, such as Extreme Networks switches or routers, the product is referred to as *the switch* or *the router*.

Table 1: Notes and warnings






Icon	Notice type	Alerts you to...
	Tip	Helpful tips and notices for using the product
	Note	Useful information or instructions
	Important	Important features or instructions
	Caution	Risk of personal injury, system damage, or loss of data
	Warning	Risk of severe personal injury

Table 2: Text

Convention	Description
screen displays	This typeface indicates command syntax, or represents information as it is displayed on the screen.
The words <i>enter</i> and <i>type</i>	When you see the word <i>enter</i> in this guide, you must type something, and then press the Return or Enter key. Do not press the Return or Enter key when an instruction simply says <i>type</i> .
Key names	Key names are written in boldface, for example Ctrl or Esc . If you must press two or more keys simultaneously, the key names are linked with a plus sign (+). Example: Press Ctrl+Alt+Del
<i>Words in italicized type</i>	Italics emphasize a point or denote new terms at the place where they are defined in the text. Italics are also used when referring to publication titles.
NEW!	New information. In a PDF, this is searchable text.

Table 3: Command syntax

Convention	Description
bold text	Bold text indicates command names, keywords, and command options.
<i>italic</i> text	Italic text indicates variable content.
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x y z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, such as passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	In command examples, the backslash indicates a “soft” line break. When a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

Documentation and Training

Find Extreme Networks product information at the following locations:

[Current Product Documentation](#)

[Release Notes](#)

[Hardware and Software Compatibility](#) for Extreme Networks products

[Extreme Optics Compatibility](#)

[Other Resources](#) such as articles, white papers, and case studies

Open Source Declarations

Some software files have been licensed under certain open source licenses. Information is available on the [Open Source Declaration](#) page.

Training

Extreme Networks offers product training courses, both online and in person, as well as specialized certifications. For details, visit the [Extreme Networks Training](#) page.

Help and Support

If you require assistance, contact Extreme Networks using one of the following methods:

[Extreme Portal](#)

Search the GTAC (Global Technical Assistance Center) knowledge base; manage support cases and service contracts; download software; and obtain product licensing, training, and certifications.

[The Hub](#)

A forum for Extreme Networks customers to connect with one another, answer questions, and share ideas and feedback. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.

[Call GTAC](#)

For immediate support: (800) 998 2408 (toll-free in U.S. and Canada) or 1 (408) 579 2800. For the support phone number in your country, visit www.extremenetworks.com/support/contact.

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number, or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any actions already taken to resolve the problem
- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- Any related RMA (Return Material Authorization) numbers

Subscribe to Product Announcements

You can subscribe to email notifications for product and software release announcements, Field Notices, and Vulnerability Notices.

1. Go to [The Hub](#).
2. In the list of categories, expand the **Product Announcements** list.
3. Select a product for which you would like to receive notifications.
4. Select **Subscribe**.
5. To select additional products, return to the **Product Announcements** list and repeat steps 3 and 4.

You can modify your product selections or unsubscribe at any time.


Send Feedback

The User Enablement team at Extreme Networks has made every effort to ensure that this document is accurate, complete, and easy to use. We strive to improve our documentation to help you in your work, so we want to hear from you. We welcome all feedback, but we especially want to know about:

- Content errors, or confusing or conflicting information.
- Improvements that would help you find relevant information.
- Broken links or usability issues.

To send feedback, email us at Product-Documentation@extremenetworks.com.

Provide as much detail as possible including the publication title, topic heading, and page number (if applicable), along with your comments and suggestions for improvement.



Introduction to Extreme Platform ONE Networking

[Pagination](#) on page 22

[Supported Applications](#) on page 23

[Log In To Extreme Platform ONE Networking](#) on page 23

[Choose a Theme](#) on page 26

[Unified Login Page](#) on page 26

Welcome to Extreme Platform ONE Networking, a productivity platform.

Extreme Platform ONE Networking is a central management platform that simplifies the user experience and provides automation at scale.

This guide helps you find your way around and introduces you to features and tools that enhance productivity and efficiency.


The following are a few key features:

- Comprehensive UI: Provides access to alerts, licensing details, inventory, and firmware updates
- Alerts and Notifications: Find and fix problems quickly. Real-time notifications ensure you are always aware of system updates or security notices
- Contextual AI Support: Meet your AI Expert-your contextual helper. Powered by the latest in AI technology, AI Expert provides instant support and guidance, ensuring you have the answers you need, when you need them
- Single Sign-On (SSO): Access Extreme Platform ONE Networking applications with a single sign-on, removing the need for multiple credentials


Extreme Platform ONE Networking consists of the following major sections:

- The navigation pane
- The content pane

Navigation Pane



Note

Select  to toggle the navigation pane on and off.


Use the navigation pane to access the following work benches and content:

- **Workspace**

- **Monitoring**
 - Dashboard
 - Visualize
 - Alerts
 - Network Devices
 - Clients
- **Configuration**
 - Sites
- **Subscriptions & Services**
 - Subscriptions & Licensing
 - Contracts
 - Inventory
- **Administration and Settings**
 - Access Management
 - Alerts
 - External Notifications
 - Backup and Restore
 - Integrations
 - Logs

Content Pane

The Extreme Platform ONE Networking content pane displays information related to your navigation pane selection.

Extreme Applications: Select  to access the following applications:

- ExtremeCloud IQ (Classic)
- Universal ZTNA



Note

As part of the Extreme Platform ONE rollout, Universal ZTNA is now accessible under the label **Extreme Platform ONE Security** in both ExtremeCloud IQ (New) and Extreme Platform ONE Networking. The nine-dot menu label has changed accordingly.

Once you have selected this option, the Universal ZTNA experience remains unchanged and delivers the same capabilities as expected.

- ExtremeCloud SD-WAN
- Extreme Intuitive Insights



Note

The applications that appear on the nine-dot menu depend on your entitlements. The nine-dot menu also includes links to begin trials for applications for which you do not have entitlements.

Table 4 through Table 7 on page 19 describe fields and columns available in the content pane.

Table 4: Standard Icons












Icon	Description
  Extreme AI Expert Canvas	<p>AI-driven help, advice, and more. Use Extreme AI Expert to get answers. AI Expert offers faster learning, troubleshooting, and purchasing with greater confidence and less risk.</p>
Notification Bell 	<p>Receive notifications for device, security, performance, and operational activities.</p> <p>When you select the bell icon, a panel displays the following:</p> <ul style="list-style-type: none"> • Go to Notification Center button • Sound On toggle  : to hear notification alerts • The following tabs: <ul style="list-style-type: none"> ◦ All: displays all notifications ◦ Critical: displays critical notifications ◦ Non-Critical: displays non-critical notifications ◦ Information: displays relevant information • Eye Icon  : displays the total number of unread notifications <p>Select Go to Notification Center to do the following:</p> <ul style="list-style-type: none"> • View notifications from the last 24 hours, last week, last month and last quarter • Select Generate Report to download a list of notifications in .csv format • Use the Search field to quickly find notifications • Select a particular notification to view the following details about that notification: <ul style="list-style-type: none"> ◦ Site ◦ Device ◦ Severity ◦ Category ◦ Description ◦ Aggregation count, if applicable ◦ Time stamp

Table 4: Standard Icons (continued)

Icon	Description
Profile Icon 	<p>Select your initials at the top right corner of the screen to view the following:</p> <ul style="list-style-type: none"> • Name and email address • Profile icon • About Extreme Platform ONE Networking displays the release version for each software component • Sign Out <p>The Profile icon displays your name, login details, and multi-factor authentication (MFA). You can modify your name and password from this menu.</p> <p>Note: To show passwords on the screen, select .</p> <p>You can choose a light or dark theme for your administrative environment.</p>
Extreme Applications 	<p>Displays all applications available in Extreme Platform ONE Networking for trial.</p> <ul style="list-style-type: none"> • ExtremeCloud™ IQ • Universal ZTNA <p>Note:</p> <p>As part of the Extreme Platform ONE rollout, Universal ZTNA is now accessible under the label Extreme Platform ONE Security in both ExtremeCloud IQ and Extreme Platform ONE. The nine-dot menu label has changed accordingly.</p> <p>Once you have selected this option, the Universal ZTNA experience remains unchanged and delivers the same capabilities as expected.</p> <ul style="list-style-type: none"> • ExtremeCloud SD-WAN • Extreme Intuitive Insights
Resource Center icon 	<p>The Resource Center icon expands to show the following menu options:</p> <ul style="list-style-type: none"> • Share Your Feedback • Product Tours • User Guide • Release Notes • Legal Summary • Contact Sales Team <p>Each selection opens an external site, from which you can add feedback or obtain product-related information.</p>
 Download	<p>You can download data and export in .csv format. Use the Filter option to tailor your content to specific views.</p>
 Refresh icon	<p>Refreshes the screen and displays the latest information</p>

Common Functionality

The Extreme Platform ONE Networking user interface offers the following common functions across the platform:

- Select the information icon for more information.
- Use the **Search** field to find and display information based on the criteria that you enter.
- **Tables:**
 - Select and drag the left or right border of the column header to adjust the column width.
 - Select and drag the column headers to change the order of the columns.¹
 - Select a column header to sort column data in ascending or descending order.²
 - Select **Columns** to add, remove, and reorder the columns.¹
 - Select **Filters** to narrow your search. You can filter by column or by selecting the **Filter** button and using check boxes.²
 - **Filters Applied:** indicates that the data is filtered. To remove filtered data, select **X**.²
 - **Page Size:** Specify the number of rows to display per page.

¹ You cannot move the primary column.

² Unavailable for the **Dashboard > Sites** table.

Table 5: Monitoring View

Left Navigator Menu	Description
Dashboard	The Dashboard provides an overview of the network.
Visualize	For a description of all icons on the Visualize screen see, Visualize Icons .
Alerts	<p>The Alerts screen consists of the following features icons and details:</p> <ul style="list-style-type: none"> • Date and Time Picker: Displays alerts for up to 30 days • Refresh Alert: Displays the most recent alerts • Export to CSV: Downloads alerts in a CSV file • Acknowledge: Indicates that the alert was read and understood <p>Alerts detect, record, and report details of a specific event.</p>

Table 5: Monitoring View (continued)

Left Navigator Menu	Description
Network Devices	The Network Devices page displays all devices for selected locations. You can manage the devices from this page.
Client & Users	The Client & Users screen provides an overview of clients and users.

Table 6: Configuration


Navigation pane	Description
Sites	<p>The Sites page consists of the following features icons and details:</p> <ul style="list-style-type: none"> • Import Site Tree: Drag & Drop or browse files in xml format. • Add Site Group: Add a site group to manage multiple sites. To add a site group see, Add a Site Group. • Add Site: Add a site and connect site groups to the site. To add a site see, Add a Site. • Select  for the corresponding row and choose one of the following actions: <ul style="list-style-type: none"> ◦ Add a building. ◦ Move a site. ◦ Export the plan in .xml or .tar format. ◦ Edit a site. ◦ Delete a site.


Table 7: Subscriptions & Services

Navigation pane	Description
Subscriptions	<p>The Subscriptions & Licenses page includes the following features icons and details:</p> <ul style="list-style-type: none"> • Customer Unique Identifier (CUID): Use your CUID to purchase licenses and get access to your license pool. • Linked to Extreme Portal: A green status means you are connected to the Extreme Portal where you can access training, knowledge articles, forums, log support cases, and access to information about owned assets. • Not Linked to Extreme Portal: A red status indicates that you have lost connection. • Unlink my Extreme Portal Account: Removes the link to your Extreme Portal Account from Extreme Platform ONE Networking.


Table 7: Subscriptions & Services (continued)


Navigation pane	Description
	<p>Caution: Do not Unlink your account without specific direction from Extreme Network Support personnel.</p> <ul style="list-style-type: none"> • Synchronize Subscriptions: Synchronizes information from the license management server. <p>Note: It can take up to 5 minutes to synchronize the license data.</p> <ul style="list-style-type: none"> • Search: Search by description, entitlement status, and product. • Group By: Displays subscriptions by product (application) or None • Status: <ul style="list-style-type: none"> ◦ Green: Everything is good ◦ Yellow: A non-urgent issue ◦ Red: Requires immediate action • Description: Indicates the total number of subscriptions associated with a license. This number includes all active, inactive, and expired subscriptions. To view details about individual subscriptions, select the number next to the subscription. • Entitlement: Displays product entitlement. • Product Displays the product name. • Total: Total number of licenses the customer can use today. • Active: Total number of consumed licenses. • Available: The total number of licenses minus active licenses.
Contracts	<p>The Contracts page include the following features icons and details:</p> <ul style="list-style-type: none"> • Renew: Renews expired contracts or contracts that are about to expire. • Subscription Request: Add subscriptions to your cart.
Inventory	<p>The Inventory page consists of the following:</p> <ul style="list-style-type: none"> • A list of devices that you manage, such as wireless devices, switches, routers, appliances, SD-WAN, and other devices. Select each asset to view firmware status and hardware life cycle. • Search: Use the search feature to show devices on the screen. • Sorting: All fields are sortable.

Table 7: Subscriptions & Services (continued)

Navigation pane	Description
	<ul style="list-style-type: none"> Status: Indicates when the device is connected or disconnected. <ul style="list-style-type: none"> Green = connected Red = disconnected In the column heading, select  to search contents in the column.

Administration and Settings

Navigation pane	Description
Access Management	<p>The Access Management page provides the following functionality to create and view user access:</p> <ul style="list-style-type: none"> Internal Users External Users Single Sign-On Credential Groups <p>Select each section to view additional details.</p> <p>Icons and buttons:</p> <ul style="list-style-type: none"> Create New User: Add an internal or external user to your account. To create a new user see, Create a New User. Search: Do searches based on column data. Select  for the corresponding row and choose one of the following actions: <ul style="list-style-type: none"> Edit Disable Delete <p>Single Sign-On:</p> <p>Note: Only an Administrator can enable SSO.</p> <p>To add an IdP profile on the Single Sign On Identity Provider (IdP) Profile page, select Add IdP Profile. Follow the steps to create the IdP profile and configure it with an IdP provider.</p>
Alert Policies	<p>The Alert Policies screen provides the following functions:</p> <ul style="list-style-type: none"> Configure a Global policy that impacts the full network. Configure a Site policy that impacts a specific network site.

Navigation pane	Description
External Notifications	<p>The Notification Configuration screen and the Alert Notifications tab consists of the following sections:</p> <ul style="list-style-type: none"> • Email Recipients • Webhooks • ServiceNow Accounts <p>Icons and buttons:</p> <ul style="list-style-type: none"> • Search Recipients: Search based on column data • Add Email Recipients: Add new email recipients. • Refresh icon: Refreshes the screen and displays the latest notifications . • Filters: Filter notifications by the following: <ul style="list-style-type: none"> ◦ All ◦ Verified ◦ Not Verified • Add Webhooks: Add a new webhook for automatic alert notifications. • Select  for the corresponding row, and choose one of the following actions: <ul style="list-style-type: none"> ◦ Edit ◦ Delete • Add ServiceNow Accounts: Add a new ServiceNow Account for automatic alert notifications.
Backup & Restore	<p>Backup & Restore provides the following functions:</p> <ul style="list-style-type: none"> • VIQ management • Default device passwords <p>In addition, you can perform the following actions:</p> <ul style="list-style-type: none"> • View backup history • Export VIQ settings • Import VIQ settings
Integration	<p>Integration provides the ability to use APIs to customize Extreme Platform ONE Networking.</p>
Logs	<p>Audit logs contains all changes made by users and applications.</p> <p>The Audit Logs screen consists of the following icons and buttons:</p> <ul style="list-style-type: none"> • Search: Search based on column data. • Date and Time Picker: Displays activities for up to 30 days.

Pagination

Extreme Platform ONE Networking supports pagination in all pages that show detailed data.

Select the required **Page Size (20, 50, 100)** to specify the number of entries in a table.

- The default page size is 20.
- Use the **Previous** (<) and **Next** (>) icons to scroll through the list.

Limitation:

The user interface shows incorrect data on the previous page when you scroll through list pages after applying filters.

Supported Applications

Extreme Platform ONE Networking eliminates the need to log in separately to the Extreme Networks multi-domain network management solutions by unifying them within a single user interface.

For example, if you subscribe to ExtremeCloud IQ, and have a site, you can view all connected sites and onboarded devices from ExtremeCloud IQ.



Note

The applications visible when you log on are specific to the subscription licenses purchased by your organization. Access to applications might also be defined by the role assigned if your organization implements Single Sign-On.

Extreme Platform ONE Networking supports the following applications:

- **ExtremeCloud IQ:** Provides centralized configuration and network monitoring, reporting, alarms, and statistics for cloud-enabled Extreme Networks devices.
- **ExtremeCloud SD-WAN:** Provides unified wired and wireless management through fabric services. You can enable a secure network, automate application performance management, and create a centralized management of applications with intuitive user experiences.
- **Universal ZTNA:** Provides network, application, and device access security within a single solution.



Note

As part of the Extreme Platform ONE rollout, Universal ZTNA is now accessible under the label **Extreme Platform ONE Security** in both ExtremeCloud IQ and Extreme Platform ONE. The nine-dot menu label has changed accordingly.

Once you have selected this option, the Universal ZTNA experience remains unchanged and delivers the same capabilities as expected.

- **Extreme Intuitive Insights:** Provides cloud-based deployment and monitoring of Zebra hand-held devices.

Log In To Extreme Platform ONE Networking

Choose one of the following ways to log in to Extreme Platform ONE Networking:

- Use your existing ExtremeCloud IQ account credentials if they include the Extreme Platform ONE Networking entitlement.

- Use your existing Extreme Platform ONE Networking account credentials.
- [Create an Extreme Platform ONE Networking Account](#) on page 24.

**Note**

Visible widgets, menu selections, and action permissions differ, depending on your role. For more information, see [Role-Based Feature Access](#).

Use this task to log in to Extreme Platform ONE Networking.

Go to [Extreme Platform ONE Networking](#), and use one of the following methods to log in.

- a. Type your ExtremeCloud IQ credentials when prompted, and then select **Log In**.
- b. Type your Extreme Platform ONE Networking credentials when prompted, and then select **Log In**.

Alternatively, if you have an SSO-logon account, select **Log in with SSO** and complete the login process.

**Note**

If you are an ExtremeCloud IQ customer and you have only ExtremeCloud IQ Pilot licenses, ExtremeCloud IQ (New) opens. If you have a mix of Pilot and Extreme Platform ONE Standard Networking subscriptions, or all Platform ONE Standard Networking subscriptions, Extreme Platform ONE Networking opens.

Create an Extreme Platform ONE Networking Account

If you are an Extreme Platform ONE Networking customer, you can use your credentials to log in to Extreme Platform ONE Networking.

Use this task to create an Extreme Platform ONE Networking account.

1. Near the bottom of the **Log In** dialog, select **Create Account**.
2. In the **Create an Account** dialog, type your **Business Email**, and then select **Continue**.
3. Select **Continue**.
4. Type the information for steps 1 through 3, as follows:
 - Step 1, enter information about you and select **Continue**.
 - Step 2, enter information about your company and select **Continue**.
 - Step 3, review and accept account notices.

5. Select **Create Account**.

**Note**

With an Extreme Platform ONE Networking account, you have access to ExtremeCloud IQ account also. The newly created Extreme Platform ONE Networking administrator account is also an ExtremeCloud IQ administrator account.

A registration email goes to the email address you used to create your account. Follow the link in the email to set up your password and complete the registration process.

Creating a new Extreme Platform ONE Networking account automatically starts the process of creating an Extreme Portal account. If you do not already have an Extreme Portal account, you will receive an email with instructions to set a password for your new Extreme Portal account.

Forgot Password

When logging in to Extreme Platform ONE Networking, if you forget your password, select the **Forgot Password** text link to get a new password.


Use this task to get a new password.

1. In the **Log In** dialog, select **Forgot Password?**
2. In the **Forgot Password** dialog, type your **Business Email**, type the email address for your account.

Extreme networks

Forgot Password?

We'll email instructions to reset your password.

 Business Email

Send Password Reset Link

3. Select **Send Password Reset Link**.
4. Open your email and select the reset password link.
5. Follow the instructions to reset your password.

Change Password

Use this task to change your password.

1. In the upper-right of the page, select **<your initials>** > **Profile**, and then select **Change Password** from the **Profile** area.
2. Populate the dialog as follows:
 - a. In the **Current Password** field, type your current password.
 - b. In the **New Password** field, type the new password.
 - c. In the **Confirm Password** field, retype the new password.
 - d. Select **Save**.

Choose a Theme

Use this task to choose a light or dark theme for your administrative environment. This task requires you to be logged in to your account.


1. Select your **Profile** (initials), and then select **Theme**.
2. Depending on your preference, select either **Light** or **Dark**.

You can repeat these steps to switch between light and dark themes.

Unified Login Page

Extreme Networks provides a unified login page that grants access to the applications based on your entitlements. Customers having only Extreme Platform ONE Standard Networking licensed devices or a mix of Platform ONE Standard Networking and ExtremeCloud IQ Pilot licensed devices are directed to Extreme Platform ONE Networking. From there, you can navigate to ExtremeCloud IQ (Classic) from the nine-dot application menu, ensuring access all features in ExtremeCloud IQ (Classic).

Extreme Platform ONE Networking licenses do not provide access to ExtremeCloud IQ (New). ExtremeCloud IQ (New) is available for customers having only ExtremeCloud IQ Pilot licenses and provides a limited subset of Extreme Platform ONE Networking features. ExtremeCloud IQ (New) customers can open ExtremeCloud IQ (Classic) from the nine-dot menu.



Workspace Overview


[Static Insights](#) on page 27

[AI Insights Widgets](#) on page 27

[Role-Based Access](#) on page 28

[Inventory Status Widget](#) on page 30

The Extreme Platform ONE Networking **Workspace** serves as the central landing page upon login, offering a unified view of network, security, and subscription insights. It is designed to help users quickly identify critical issues and prioritize actions. To return to the **Workspace**, select the Extreme Platform ONE Networking banner. The **Workspace** is divided into two primary sections: Static Insights and AI Insights.



Static Insights

This section provides high-level, static widgets that summarize the current state of the network and subscriptions. These widgets include:

- Alerts - number of Critical Alerts in the Last 24 Hours
- Licenses - number of active subscriptions
- Inventory status
- Site Health

AI Insights Widgets

This section includes customizable widgets powered by AI to provide security-related insights. These widgets might include:


- Unique User Access Types

- Top Identities by Activity

Add AI Insight Widget

1. While displaying the Workspace, select **AI Expert**.
2. Construct your AI Expert query.
3. Select **Add Widget**

The **AI widget** is added to the **AI Insights** area of **Workspace**.



Role-Based Access

Access to Extreme Platform ONE Networking features is governed by user roles. Depending on the assigned role, access to and visibility of some features may be limited regarding features such as dashboard widgets, Extreme AI Expert, and the Navigation menu.



Note

Extreme Platform ONE Networking user roles cannot be configured in ExtremeCloud IQ (Classic).

Use the following descriptions to determine role assignments.

Administrator

Best for users who need the following:

- Full system-configuration access
- User and access-management capabilities
- Integration and backup management
- Complete administrative control

As an Administrator, I have insight into the following Workspace widgets:

- Alerts
- Licenses
- Inventory Status
- Site Health

NetSecOps

Ideal for users who need the following:

- Network device management
- Security policy configuration
- Monitoring and alerting capabilities
- Operational control without user management

As a user with the NetSecOps role, I have insight into the following Workspace widgets:

- Alerts (can manage alert policies and acknowledge permissions)
 - Severity
 - Category
 - Top 3 Alerts
 - Application
- Licenses
- Inventory Status
- Site Health

Observer

Appropriate for users who need the following:

- Read-only access to monitoring data
- Dashboard and visualization viewing
- No configuration or administrative access

As an Observer, I have insight into the following Workspace widgets:

- Alerts (no alert policies, no acknowledge permissions)
 - Severity
 - Category
 - Top 3 Alerts
 - Application
- Site Health

BizOps

Designed for users who need the following:

- Business-focused access to inventory and contracts
- AI Canvas and Agent access for business insights
- Limited operational visibility

Subscription and licensing management

As an administrator, I have insight into the following Workspace widgets:

- Licenses
- Inventory Status
- Site Health

Related Links


[Security-Specific Roles and Features | Extreme Platform ONE Networking](#) on page 352

[Role-Based Feature Access | Extreme Platform ONE Networking](#) on page 352

Inventory Status Widget

A dedicated widget on the Extreme Platform ONE Networking landing page provides a focused view of inventory health. It displays data from the last 24 hours based on the user's last login.

Select this widget to redirect to the **Inventory** page for further exploration.



Extreme AI Expert

[Extreme AI Expert Icons](#) on page 32

[Impersonation](#) on page 32

[AI Expert Interaction Modes](#) on page 33

[AI Canvas](#) on page 34



Note

Extreme AI Expert queries the Extreme Networks documentation set. Extreme AI Expert supports questions about the network such as locations, devices, clients, applications, alerts, and CoPilot. Results from Extreme AI Expert are dependent on the user role scope.

Extreme AI Expert is your intelligent assistant for navigating the Extreme Networks documentation and gaining insights into your network. It can answer questions about a wide range of topics, including network locations, devices, clients, applications, alerts, and CoPilot.








Extreme AI Expert delivers context-aware, conversational responses - no need for complex commands. Simply ask your question, and you'll receive tailored, relevant answers.

To get the most accurate and helpful responses, provide as much detail as possible in your queries. Extreme AI Expert is designed to evolve and improve over time, and your feedback plays a key role in that process. Use the built-in feedback tools to rate responses and help enhance future interactions.

Extreme AI Expert is also self-aware - it can answer questions about its own capabilities and features. Just ask to learn more.


Your privacy and data security are top priorities. Extreme AI Expert operates within a secure framework that adheres to Extreme Networks' policies and industry best practices, ensuring your data is handled with confidentiality and integrity.

Extreme AI Expert Icons

Icon	Description
 Extreme AI Expert	Provides context-aware responses using a conversational interface.
 Dock	Docks the Extreme AI Expert panel to the Extreme AI Expert icon. This is the default setting.
 Overlay	Separates the Extreme AI Expert panel from the Extreme AI Expert icon.
 New Chat	Initiates a new chat.
 Conversations	Provides access to previous conversations with the Extreme AI Expert.
 Canvases	Displays the selected network dashboard and provides the following options: <ul style="list-style-type: none"> Update the existing dashboard using Replace Widget option. Add a new widget to the Canvas using Add to Canvas option.
 Extreme AI Expert Settings	Provides access to the following Extreme AI Expert settings: <ul style="list-style-type: none"> Impersonation Developer Info

Impersonation

With Impersonation, you can assume the role of another user within the system for effective diagnosis. Use this task to enable the Impersonation feature.

1. Select Extreme AI Expert Settings .
2. Enable the **Impersonate User** button.
3. Update the following fields:
 - API Gateway URL
 - Product Name
 - Version
 - Token
4. Select **Submit**.

AI Expert Interaction Modes

Overview

Extreme AI Expert supports distinct interaction modes designed to enhance user productivity and network intelligence within Extreme Platform ONE Networking:

- Conversational Mode
- Interactive Mode

Conversational Mode

Conversational mode lets users interact with **Extreme AI Expert** using natural language. This includes:

Talk to Knowledge

- Access to product documentation, including documentation across the Extreme Networks product suite.
- GTAC Knowledge Base
- Extreme Networks website articles
- **AI Expert** Self-aware content

Talk to Network

- Queries real-time network data
- Uses **ExtremeCloud IQ** and Common Services APIs
- Provides multimodal responses (charts, tables, widgets)
- Displays customizable visualizations

Multilingual support ensures responses are returned in the language of the query.

Interactive Mode

Interactive mode introduces the **AI Canvas**, a visual workspace that allows users to:

- Convert conversations into dashboards with a single click
- Add up to 10 widgets per canvas
- Create up to 13 canvases, (3 published, 10 draft)
- Continue conversations and dynamically add new widgets
- Customize widget visualizations (e.g., chart types, tables)

Canvas Types:

- **Draft Canvas:**
 - Manual refresh of widgets
 - Up to 10 widgets per canvas
 - Up to 10 draft canvases per user
 - Cannot be shared

- **Published Canvas:**
 - Widgets auto-refresh every 10 minutes
 - Up to 3 published canvases per user

Security and Permissions

AI Expert enforces strict role-based access control when making API calls on behalf of users. Each query is executed using the user's own credentials, ensuring that:

- Users can only access data permitted by their assigned role (e.g., Admin, NetSecOps, Observer).
- Unauthorized data access attempts are blocked, and users are notified accordingly.

This design ensures that **AI Expert** adheres to the same security model as the rest of the **Extreme Platform ONE** platform.

AI Opt-Out Process

Extreme AI is enabled by default for all **Extreme Platform ONE** customers. However, organizations with specific compliance or privacy concerns can request to opt out.

This process must be initiated by contacting GTAC or the sales team. Only users with appropriate administrative roles (Enterprise Admin or MSP Admin) can authorize the opt-out.

AI Canvas

AI Canvas is an interactive workspace within **Extreme Platform ONE** that allows users to build and visualize real-time network insights using AI-generated widgets. It extends the capabilities of **AI Expert** by enabling users to organize and monitor key metrics in a customizable dashboard format.

Key Features

Widget-Based Visualization: Users can create widgets from AI queries that return structured data (e.g., tables, charts, graphs). These widgets can be added to a canvas for ongoing visibility.

Canvas States

- **Draft:** A work-in-progress canvas where users can experiment with different widgets. There is a limit of 10 draft canvases, with up to 10 widgets per canvas.
- **Published:** A live canvas that auto-refreshes every 10 minutes. There is a limit of 3 published canvases, with up to 10 widgets per canvas.
- **Always-On Workspace Canvas:** A new default canvas is now embedded directly into the **Extreme Platform ONE Networking** workspace landing page. This canvas is:
 - Always published and live.
 - Not counted against user limits.

Enablement Prompts

To help users get started, **AI Canvas** includes enablement prompts - suggested questions that demonstrate how to interact with **AI Expert** and build useful widgets. These prompts are currently available in English and are designed to accelerate onboarding and discovery.

AI Canvas Management

From the **AI Canvas** you can:

- Select an existing canvas
- Delete an existing canvas
- Add a new canvas
- Edit the title of a canvas
- Delete all canvases
- Publish a canvas
- Unpublish a canvas

Select an Existing Canvas

To select a canvas, from **AI Canvas** select the canvas from the list of canvases shown.

Delete an Existing Canvas

To delete a canvas, from **AI Canvas** select the delete icon associated with the canvas.

Add a New Canvas

To add a new canvas, from **AI Canvas** select **Add New**. You can have a maximum 10 draft and 3 published canvases.

Edit Title of a Canvas

To edit a canvas title, from **AI Canvas** select the edit icon associated with the canvas. Change the title as required, then select the confirm icon.

Delete All Canvases


To delete all canvases, from **AI Canvas** select **Delete All**. Confirm the deletion to delete.

Publish a Canvas

To publish a canvas, select the canvas, then select **Publish**.

Unpublish a Canvas

To unpublish a canvas, select the canvas, then select **Unpublish**.



Monitoring

[Dashboard](#) on page 37

[Visualize](#) on page 38

[Alerts](#) on page 86

[Network Devices](#) on page 88

[Clients](#) on page 140

In the navigation pane, expand **Monitoring** and select one of the following options:

- **Dashboard:** Provides an overview of the network performance.
- **Visualize:** Presents a summary view of traffic on your network and the number of access points, routers, and switches. It also indicates the number of unique wired and wireless devices on your network and supports router attributes.
- **Alerts:** View and manage alerts.
- **Network Devices:** View managed and unmanaged devices.
- **Clients:** View and manage clients and users.

Dashboard

Dashboard uses the following widgets to provide an overview of the network performance for selected sites:



- Alerts
- Usage & Capacity
- Device Status
- Client Health
- Device Health


Use the **Sites** filter to select sites and filter the view.



Note

If you have access to only one site, the **Sites** field is not present.

To display the timestamp for the last update, hover over . To refresh the data, select .



To display the **Sites** information in table view, select . You can choose which columns to display, the column order, and the number of results per page.

To return to the widgets view, select .

Visualize

Visualize provides a comprehensive overview of network performance and geographical location. For information about geographical location support, see [Geographic Layer View](#) on page 46.



Note

The available features and views depend on your subscriptions. For more information, see [What to Expect When Licenses Are Upgraded](#) on page 331.



Customize the Visualize View

Use **Quick Navigation** to navigate to different levels of the network hierarchy. The following table lists and describes the **Quick Navigation** icons and other options for customizing the view.

Table 8: Visualize icons

Icon	Name	Description
Quick Navigation		
	Quick Navigation	Displays the different levels of the network hierarchy and shows the device count for each location. Use Quick Navigation to customize your display by location, building, and floor. To highlight the devices on the topology map for the selected location, hover over the devices in Quick Navigation .
	Group	Indicates a group of sites. Expand this element to see the sites.
	Site	Indicates a site.

Table 8: Visualize icons (continued)




















Icon	Name	Description
	Building	Indicates a building.
	Floor	Indicates a floor.
	Floor plan	Indicates that a floor plan exists for the corresponding floor.
	Search	Indicates the search field for the Quick Navigation . To begin, start typing in the search field.
	3-dot menu	<p>Provides the following options for the topology map:</p> <ul style="list-style-type: none"> • Collapse All • Expand All • Hide All Borders • Show All Borders • Floor Layouts: <ul style="list-style-type: none"> ◦ U-Shaped ◦ Grid • Device Layouts: <ul style="list-style-type: none"> ◦ Stacked ◦ Spread ◦ Grid ◦ Hierarchical • Density <ul style="list-style-type: none"> ◦ Very Sparse ◦ Sparse ◦ Dense ◦ Very Dense • Initiate Discovery • Show Masked Devices and Links <p>The 3-dot menu options vary for different levels of the network hierarchy.</p>
General Visualization Options		
	Topology Locked	Indicates that the topology map is locked. Select to unlock the topology map.
	Topology Unlocked	Indicates the topology map is unlocked. When the map is unlocked, you can toggle Autosave . Select to lock the topology map.
	Zoom In	Zooms in the topology map.
	Zoom Out	Zooms out the topology map.

Table 8: Visualize icons (continued)

Icon	Name	Description
	Legend	Opens the legends used to describe the symbols used in topology maps.
	Open Minimap	Opens the minimap.
	Close Minimap	Closes the minimap.
	Fit View	Adjusts the magnification for the topology map view to display the entire map.
	Geographic/Physical	Provides options to change between the Geographic view and the following topology map layers: <ul style="list-style-type: none"> • Physical or Access • Fabric • Service
	Refresh Topology	Refreshes the topology map.
	Search	Searches for devices, services, and VLANs. <ul style="list-style-type: none"> • Search for Devices by name, IP, MAC, host name, or serial number. • Search for Services by ID and name. • Search for VLANs by ID and name.
	Filter	Filters the topology map view based on tags. Note: Filter settings and view are persistent.
	Settings	Opens the following topology map settings: <ul style="list-style-type: none"> • Display options • Manage
	Inspector Panel Control Button	Displays the Inspector panel for more information about selected elements and services.

Visualize Topology Maps

Visualize supports the following topology maps:

- Geographic view
- Physical layer
- Access view
- Fabric layer
- Service layer


Use  to select or change the topology map view.

Visualize can display two layers simultaneously, one on top of the other, enabling network tracing between layers. The Access view for the Physical layer provides a per-floor view of edge devices, such as access points, phones, and cameras.



Note

Access view does not support split view.



Topology Legends

Figure 1 through Figure 5 on page 45 show symbols used in topology maps. Use these images to understand the layout and design of the network in the Geographical layer, Physical layer, Fabric layer, and Service layer.




Figure 1: Service layer topology legend




Figure 2: Fabric layer topology legend




Figure 3: Physical layer topology legend




Figure 4: Access view topology legend




Figure 5: Geographic layer topology legend

Geographic Layer View

The Geographic layer view is the default view in Visualize. The Geographic layer view supports the following functions:

- View sites
- Zoom-in up to the building level
- Zoom-out collapses the building level into sites
- Show links between buildings and sites



Note

- When you select a floor, the Geographic layer view shows the building location and filters devices to the selected floor.
- Hover your cursor over a site on the geographic map to view details such as number of sites/building, number of sites and building with alerts, and number of critical alerts.
- The current release supports alerts only from wireless devices in Geographic layer view.

Physical Layer



Note

Access to the Physical layer and split view feature requires Extreme Platform ONE Standard Networking subscriptions. If you have a mix of Platform ONE Standard Networking and ExtremeCloud IQ Pilot subscriptions, this feature is limited to sites, buildings, or fabrics that do not have any ExtremeCloud IQ Pilot-licensed devices.

The Physical Layer topology map shows all managed devices in the network. You can view physical characteristics and the connection between devices in the physical topology map.

The Physical layer supports the following functions:

- Search for devices.
- Expand or collapse device groups for a focused view.
- View ExtremeCloud IQ and Extreme Platform ONE Networking managed networks with attached network devices, such as APs, Phones, switches, and routers.
- View device port information.
- Access network alerts and error statistics to assist in debugging link or port issues.
- Tag network elements and apply filters for a focused view.
- Mask and unmask devices and links.
- Show or hide borders.
- Highlight devices.
- Drag and drop devices, sites, and floors.
- Auto save: Save device or frame position changes automatically.

- View LAGs:
 - Hover over: Displays Name and Status.
 - Single-click: Displays info from the inspector panel.
 - Double-click: Displays member ports.
- Aggregate LLDP discovered devices of the same type.

Physical Topology Map Elements

Hover over a node or a link in the physical topology map to view the details. Select an element or location in the topology map to view the inspector window with more information.

Table 9: Physical topology map elements


Topology Map Element	Description
Device Icons	Each device type has a unique icon. Device types include firewalls, routers, switches, access points, and phones.
Summary	Includes the following device details: <ul style="list-style-type: none"> • Nodename or System Name • IP Address • Model • Sys Up Time • OS Version • OS Type • Location • System Mac • Serial Number • System Description
Tags	Create and manage Default and Manual tags.
Alerts	View and acknowledge selected alerts.
Services/VLANs	View VLANs, L2 Services, and L3 services.
Port and Link Details	
Ports	Port Numbers and Link Names Includes the following information: <ul style="list-style-type: none"> • Switch Name • Port • Name • Media Type (RJ45/Transceiver) • Mode: <access/trunk> (untagged or tagged VLAN) • Operational Status: <Up/Down> • Admin Status: <Enabled/Disabled> • Transmission Mode: <Duplex> • Speed: <xyz Mbps> • LLDP Neighbor: <name/hyperlink>

Table 9: Physical topology map elements (continued)

Topology Map Element	Description
Link Stats	Link details such as Link Speed and In/Out Statistics.
SD-WAN View	Displays SD-WAN devices.

Mask a Device

An asterisk symbol (*) marks locations with masked devices in both **Quick Navigation** and the topology map.

**Figure 6: Quick Navigation Masked Device Locations**

Only the physical layer supports device masking. However, the device masking changes apply to the fabric layer as well.

Use this task to mask a device.

1. Go to **Monitoring > Visualize**.
2. Right-click a device on the topology map and select **Mask Device**.
3. To proceed, select **Yes**.

View Masked Devices

An asterisk symbol (*) marks locations with masked devices in both **Quick Navigation** and the topology map. To highlight devices on the topology map, hover over them in **Quick Navigation**.

Use this task to view masked devices.

1. Go to **Monitoring > Visualize**.
2. In **Quick Navigation** select , and then select **Show Masked Devices and Links**.




Figure 7: Quick Navigation - Show Masked Devices and Links

The masked devices are highlighted on the topology map.

3. (Optional) Right-click a masked device and select **Unmask Device** to unmask it.
4. Select **Exit View** to exit the masked devices and links view.

Aggregate LLDP Devices

When you select a floor, all LLDP devices of the same type are grouped as one LLDP device marked with the total number of LLDP devices. You can select the LLDP device to expand it and view all grouped LLDP devices.

Radio Frequency Maps

Radio Frequency (RF) network heat maps use a color spectrum, ranging from warm to cool, to illustrate real-time device signal strength throughout a building floor plan. Warm colors represent a stronger signal strength. Cool colors represent a weaker signal strength.

Extreme Platform ONE Networking supports the following map type views:

- [Wi-Fi Map](#)

- IoT Map



**Note**

Maps generated within the **Manage > Planning** section in ExtremeCloud IQ are visible in RF Maps.

With Extreme Platform ONE Networking RF Maps, you can:

- [Rotate the heat map.](#)
- [View device details or perform actions on a selected device](#) (including uploading installation photos).
- [View the summary details of clients connected to an AP](#) (including Client 360° details, roaming paths, and authenticating).
- [View the heat map in 3D.](#)
- [Filter devices by client connection type.](#)
- [Adjust thresholds.](#)
- [Change color schemes.](#)

Use this task to view real-time network data coverage.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.

**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. From the floor plan view pane, select **Map Type**.
4. To view the heat map for Wi-Fi devices, select **Wi-Fi**, configure the following Wi-Fi map type settings.

Table 10: Wi-Fi Map Types

Map Type	Radio Frequency
RSSI	2.4 GHz, 5 GHz, or 6 GHz
Coverage Overlap	2.4 GHz, 5 GHz, or 6 GHz
SNR	2.4 GHz, 5 GHz, or 6 GHz
Channel	All frequencies: 2.4 GHz, 5GHz, and 6 GHz
Interference	2.4 GHz, 5 GHz, or 6 GHz
Co-channel Interference	2.4 GHz, 5 GHz, or 6 GHz

- To view the heat map for IoT devices, select **IoT**, configure the following IoT map settings.

Table 11: IoT Map Settings

Map Type	Radio Frequency
RSSI	2.4 GHz



Note

IoT heat maps support **2.4 GHz** radio frequencies only.

- To rotate the map, from the top right corner, select and drag the slider.



Note

Select the arrow icon to reset the map rotation.



- To [view device details or perform actions](#), select a device on the map.
- To view asset details for the clients connected to an AP, select the purple halo above the AP.
 - The purple halo shows the number of connected clients.
 - From the **Asset** pop-up window, select a **Hostname** to view client **Summary** and **Actions**:
 - The **Summary** tab displays the Host Name, OS, Uptime, IP Address, MAC Address, Connected to, VLAN, SSID, Captive Web Portal, User, User Profile, Radio, and Channel information for the selected client.
 - From the **Actions** tab:
 - To access Client 360° details, select **Client 360° View**. This opens a new pop-up window displaying the Client 360° information. To return to the client summary, close the pop-up window.
 - To view the roaming trail of the client, select **Client Roaming**. For more information, see [View Client Roaming Trail](#) on page 60.
 - Select **Deauthenticate** to disconnect the client from the access point.
- Right-click an AP to:
 - Show Coverage**: Updates the heat map to show the coverage from the single AP. To reset and see coverage from all APs, select **Show Coverage** again.
 - Hide Device**: Hides the device from the heat map without removing it from the network. To show the device, see [View Device Inventory](#) on page 61.



Note

Hiding a device from the RF Map requires administrator privileges.

- For Channel Wi-Fi map types:





- To view the number of connected clients per AP, select .
- To view the number of clients per radio frequency for each AP, select .

- Select **3D** to view a three-dimensional representation of the heat map.

This view allows users to visualize how signals propagate through different areas, including floors and walls, offering a more comprehensive understanding of network

coverage and potential dead zones. This helps to optimize placement of access points and improve overall network performance.

When viewing a heat map in 3D, you can:




- Select  to stop the rotation. Select  to start the rotation.
- Select  and  to zoom in and out.
- Select and drag the slider to adjust the angle of the map.



Note

Select **2D** to return to the default map view.

12. To filter devices on the map by their connection type, select one of the following icons:

- : All
- : Wi-Fi
- : Thread

13. To set Wi-Fi coverage thresholds, configure the threshold values, select , and then select **Apply**.

Thresholds provide a visual to see where coverage is optimal, acceptable, and where improvements are needed.

Table 12: Wi-Fi Coverage Threshold Settings

Threshold	Description
Excellent	Above the set threshold, for example -30 dBm, the signal is considered excellent.
Good	Near the set threshold, for example -67 dBm, the signal is considered good.
Medium	Near the set threshold, for example 72 dBm, the signal is considered medium.
Poor	Below the set threshold, for example -90 dBm, the signal is considered poor.

14. To change the color scheme, select  and then select a new color scheme.



Note

The **Select Color Map** icon might display different colors, depending on the last color scheme selected.

15. To zoom in and out, select **+** and **-**, or scroll the mouse wheel. Select and drag the map to move within the window.



Note

When you zoom in or out, the scale of the RF Map changes in real time below the zoom icons. The scale represents the relationship between the displayed area on the RF Map and the original map scale.

Related Links

[Import a Third-Party RF Map](#) on page 62

[Edit an RF Map](#) on page 64

[Device Summary and Actions Menu](#) on page 53

[View Device Inventory](#) on page 61

[View Antenna Patterns](#) on page 64

Device Summary and Actions Menu

In a Radio Frequency (RF) Map, select a device to display device summary information and a list of available actions.

AP Device Summary

The **Summary** tab displays the following information for a selected AP device:

- Connected status: Offering the number of Days, Hours, Minutes, and Seconds a device has been connected.
- AP Name
- Model, and OS Version
- Network Policy associated with the device
- SSIDs: Network SSIDs associated with the device
- AP Orientation: AP Installation Height, Elevation, and Azimuth
- Wi-Fi 0, Wi-Fi 1, and Wi-Fi 2 details:
 - Radio Mode
 - Power
 - Channel
 - Channel Width
 - Frequency
 - Number of Clients
 - Mode
- Installation Photos: Upload photos or videos of the device installation. For better performance, limit the image file (.png, .jpg) to less than 500 KB and limit the video file (.mp4, .mov.) to less than 5MB.

Switch Device Summary

The **Summary** tab displays the following information for a selected switch device:

- Connected status: Offering the number of Days, Hours, Minutes, and Seconds a device has been connected.
- Hostname/SysName: Select to view device details.
- Model
- Network Policy associated with the device
- IP Address, System MAC Address, OS Version, and Make of the device
- Installation Photos: Upload photos or videos of the device installation. For better performance, limit the image file (.png, .jpg) to less than 500 KB and limit the video file (.mp4, .mov.) to less than 5MB.

Actions

From the **Actions** tab, you can perform the following actions on a selected device:

- [Locate a Device](#).
- [Reboot a Device](#).
- [Perform a VLAN Probe](#).
- [Reset a Device to Factory Defaults](#).
- [Upgrade Device Firmware](#).
- [Configure AP Radio and Power Settings](#).



Related Links

[Radio Frequency Maps](#) on page 49

Locate a Device

Using a visual cue helps you quickly identify the exact position of a selected device within the mapped area. By triggering the blinking function, you can efficiently manage and troubleshoot your network, ensuring optimal performance and coverage.

Use this task to locate the physical location of a selected device.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions**.

4. Select **Locate AP (blinking lights)** or **Locate Switch**, and then configure the Locate Device settings.

Table 13: Locate Device Settings

Device Type	Field	Description
AP	LED Color	Select one of the following blinking light colors to set the color that the locator light flashes to help you find the AP: <ul style="list-style-type: none"> • Amber • White • Off
AP	Blink Mode	Select one of the following blinking modes to set the speed at which the locator light flashes to help you find the AP: <ul style="list-style-type: none"> • Fast • Slow • Steady
Switch	LED Timeout	Select a number of seconds between 0 (until disabled) and 604800 (one week).



Note

To stop the blinking lights used for locating the device, select **Return to Standard LED operations**, and then select **Submit**.

5. Select **Submit**.

Related Links

[Radio Frequency Maps](#) on page 49

[Device Summary and Actions Menu](#) on page 53

Reboot the Selected Device


Use this task to restart the selected device.



Important

The current configuration is not automatically saved. Restarting momentarily disconnects any connected clients.

1. Go to **Monitoring > Visualize**, and then select .

2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.

**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions > Reboot**.
4. Select **Yes** to confirm.

Related Links

[Radio Frequency Maps](#) on page 49

[Device Summary and Actions Menu](#) on page 53



VLAN Probe from RF Maps

The VLAN probe action locates available VLANs for the selected device. When the VLAN probe is complete, a table shows the host name, MAC address, available VLANs, unavailable VLANs, and their status.

**Note**

The VLAN Probe Utility is also available from the **Device List** for a connected device.

Use this task to verify the VLAN probe results and status of VLAN for selected device.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.

**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions**.

4. Select **VLAN Probe**, and then configure the VLAN Probe settings.

Table 14: VLAN Probe Settings

Field	Description
VLAN Range	The start and end VLAN Range to probe. You can enter up to five ranges separated by commas, up to a total range of 12. However, range numbers cannot overlap. For example, 1, 2-7, 8, 8-12.
Probe Retries	The number of attempts made to send a probe to verify the status of a VLAN.
Timeout	The timeout from 5 to 60 seconds to specify how long to wait for a reply from each probe.

5. Select **Start** to start a probe.
6. Select **Stop** to stop a probe before it is complete.

Related Links

[Radio Frequency Maps](#) on page 49

[Device Summary and Actions Menu](#) on page 53



Reset a Device to Factory Defaults

Use this task to reset the selected device to the default configuration. If you select **Yes** to acknowledge the warning message, the operation restores factory settings and reboots the device.



Important

This operation removes all existing settings from the selected device and resets the device to a factory default configuration state. The device reconnects to Extreme Platform ONE Networking as a new device.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions > Reset to factory defaults**.
4. Select **Yes** to confirm.

Related Links

[Radio Frequency Maps](#) on page 49

[Device Summary and Actions Menu](#) on page 53



Upgrade Device Firmware

Use this task to manually upgrade firmware for a selected device from an RF Map.



Note

LLDP is on by default in Extreme Platform ONE Networking. With IQ Engine Release 10.7.5 and later, LLDP is on by default. If LLDP is disabled in the network policy, upgrading to 10.7.5 or later enables LLDP until after you perform a configuration update.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions > Upgrade firmware**.
4. In the **Device Update** dialog box, select an update type.

Table 15: Update AP Device Settings

Field	Description
Update Network Policy and Configuration:	
Delta Configuration Update	To update only the configuration changes for the selected device, select Delta Configuration Update . Extreme Platform ONE Networking only updates the device deltas. This action avoids a device reboot.
Complete Configuration Update	If a full update is required, select Complete Configuration Update . Used to reset the selected AP to Extreme Platform ONE Networking configuration settings. Note: Only supported on devices running HOS or IQE Firmware.
Upgrade IQ Engine and Extreme Network Switch Images:	
Upgrade to the latest version	Upgrade to the latest firmware version.

Table 15: Update AP Device Settings (continued)

Field	Description
Upgrade to the specific version	<p>Select a Model to upgrade, and then select the Version to upgrade.</p> <p>To add a new version (local image), select Add/Remove:</p> <ul style="list-style-type: none"> To add a new local image, select +, and then select Choose to upload an image file from your computer. <p>Note: The format for an image file name must be *.stk, *.xos, *.voss *.tgz, *.img, or *.img.S. The file name cannot contain spaces and must not exceed 64 characters.</p> <ul style="list-style-type: none"> To delete an existing local image, select an image, and then select -. Select Close. <p>Select View Release Notes to access the Online Help system and see the latest release notes.</p>
(Optional) Upgrade even if the versions are the same	Force an upgrade to the same version as the current version.
Activation Time for Extreme Networks Devices Running Images:	
Activate at next reboot (requires rebooting manually)	Activation takes affect the next time the AP reboots.
Activate after xx seconds	The delay before activation, in seconds.
Activate/reboot on this schedule based on your local system time	Schedule a Date and Time to activate.

Table 16: Update Switch Device Settings

Field	
Update Network Policy and Configuration:	
Reboot and revert Extreme Networks switch configuration if IQAgent is unresponsive after configuration update.	Note: Not supported on Dell/SR.
Perform delta configuration update and resolve local device configuration which is out of sync with Extreme Platform ONE Networking.	
Upgrade IQ Engine and Extreme Network Switch Images	

5. To update the selected device immediately, select **Perform Update**.

6. To save the settings for future use, select **Save as Defaults**.



Related Links

[Import a Third-Party RF Map](#) on page 62

[Edit an RF Map](#) on page 64

Configure AP Radio and Power Settings

Use this task to configure AP radio and power settings.

1. Go to **Monitoring** > **Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select a connected device from the floor plan, and then select **Actions** > **Radio and Power configuration**.
4. Select a Wi-Fi interface, configure the radio and power settings, and then select **Apply**.

Table 17: Radio and Power Configuration Settings

Field	Description
Radio Status	Toggle the Radio Status .
Channel	Select a specific channel. Select Auto to have Extreme Platform ONE Networking select the channel.
Transmission Power	Set the transmission power for the selected device (1 to 20 dBm). Select Auto to have Extreme Platform ONE Networking select the transmission power.

Related Links

[Radio Frequency Maps](#) on page 49

[Device Summary and Actions Menu](#) on page 53


View Client Roaming Trail

Viewing the client roaming trail to an access point (AP) on a real-time map has the following benefits:

- **Troubleshoot Connectivity Issues:** Identify areas where the client might be experiencing weak signals or frequent disconnections.
- **Optimize Network Performance:** Understand the movement patterns to adjust the placement of APs to ensure better coverage and reduce dead zones.
- **Monitor Security:** Detect any unusual or unauthorized movements within the network, which could indicate potential security threats.

Use this task to view the roaming trail of a selected AP client from a real-time map.

1. Go to **Monitoring** > **Visualize**, and then select .

2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.

**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select the purple halo above a device.
The purple halo shows the number of connected clients on the device.
4. From the **Inventory** list, select an available **Hostname**, and then select **Actions** > **Client Roaming**.
A split window opens:
 - **Left Pane:** This pane displays the map and shows how the client roamed.
 - **Right Pane:** This pane displays the roaming view details, including the Client Name, Roaming Time, and surrounding APs.
5. To view the roaming trail, from the right pane, select **Play**.

**Note**

By default, the roaming view displays client roaming details for the previous hour.

The roaming trail plays within the top map pane, showing where the client roamed and how long it took:

- A **green** roaming trail signifies a good roam (less than one second).
 - A **red** roaming trail signifies a slow roam (longer than one second).
6. To narrow the roaming time frame, from the right pane, select the **Date & Time Range**.
 - a. Select a **Start Date** and **End Date**.
 - b. Select a **Start Time** and **End Time**.
 - c. Select **Done**.

To reset to the default time frame, select **Reset to Default**.

7. To exit the roaming view and return to the real-time map, select **X**.

Related Links

[Radio Frequency Maps](#) on page 49

View Device Inventory

Inventory displays a list of **Access Points**, **Switches**, or **Clients** currently being monitored on an RF Map.



The **Access Points** and **Switches** asset lists provide the following details about each device:

- **Hostname:** The name assigned to the device
- **Status:** The current operational state of the device
- **IP Address:** The unique network address assigned to the device
- **Show/Hide:** An option to toggle the visibility of the device on the heat map, allowing for a more customized and focused view of the real-time status of your network

The **Clients** asset list provides the following details about each device:

- **Hostname:** The name assigned to the device
- **MAC Address:** The unique identifier assigned to the device
- **IP Address:** The unique network address assigned to the device
- **Type:** Filter by different client types

Use this task to toggle the visibility of **Access Points** and **Switches** and filter **Client** types on a selected heat map.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select .

**Note**

Use the **Search** field to find a specific device.

4. Select an Asset type:
 - Access Points
 - Switches
 - Clients
5. Select a **Hostname** to view device summary and available actions. For more information, see [Device Summary and Actions Menu](#) on page 53.
6. To hide an **Access Point** or **Switch**, deselect the corresponding  checkbox.
7. To show a hidden **Access Point** or **Switch**, select the corresponding  checkbox.



Import a Third-Party RF Map

Extreme Platform ONE Networking supports the following third-party RF Maps:

- Ekahau

- Hamina

Use this task to import a third-party RF Map.


1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .

**Note**

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.

**Note**

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select .
4. To import a floor map from Ekahau, select **Import Ekahau**:
 - a. Select **Choose**, then browse to your local folder, select a .esx floor plan, and then select **Open**.

**Note**

Use the **serialNumber** tag to import devices with your floor plan.

- b. Select **Next**.
- c. From **Import floors**, select a **Building** from the drop down list.

**Note**

With RF Maps you can only import building floors. To import a site, site folder, or a building, go to **Configuration > Sites**.

- d. If the configuration is custom, select the **Import Custom AP Configuration** checkbox.
 - e. Select one or more floor plans.
 - f. To move a single floor plan, double-click the selected plan.
 - g. To move more than one plan, select the applicable arrow.
 - h. Select **Import**.
5. To import a floor map from Hamina, select **Import Hamina**:
 - a. Log in to your active Hamina account and select **Export**.
 - b. Select **Extreme Networks** and follow the instructions.
 - c. Select **Export**.

Your floor map now displays APs in the correct building on the correct floor.

Related Links

[Radio Frequency Maps](#) on page 49

[Edit an RF Map](#) on page 64

View Antenna Patterns



Antenna Patterns allow users to visualize the coverage and performance of devices on the heat map. This visualization is essential for optimizing network design and troubleshooting connectivity issues.

The antenna patterns display how the antenna radiates energy in different directions and frequencies, including:

- **Azimuth Plane:** A top-down view of the radiation pattern, illustrating how the signal spreads out horizontally. It helps in understanding the coverage area and signal strength in different directions around the device.
- **Elevation Plane:** A side view of the radiation pattern, illustrating how the signal spreads out vertically. It helps in understanding the coverage area and signal strength above and below the device.
- **Frequency Band:** Along with Azimuth and Elevation planes, displays the radiation pattern for the 2.4 GHz, 5 GHz, and 6 GHz frequency bands for wireless devices.

These patterns help network administrators visualize and optimize device placement to ensure even and effective coverage.

Use this task to view antenna patterns.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.

3. Select .



Note

Use the **Search** field to find a specific device.

4. Select a device tab.

Edit an RF Map



An RF Map provides a visual representation of device signal strength across a floor plan. By editing the RF Map, you can identify areas with weak coverage, interference, and dead zones. This information helps network administrators optimize device placement and improve overall network performance.

Extreme Platform ONE Networking supports the following RF Map editing functions:

- [Draw Inner Walls](#)
- [Add a Device to a Floor Plan](#)

- [Move a Device to a New Location on a Floor Plan](#)
- [Remove a Device from a Floor Plan](#)
- [Adjust Layer Opacity](#)
- [Resize the Heat Map](#)

Use this task to edit an RF Map.

1. Go to **Monitoring > Visualize**, and then select .
2. From **Quick Sites Navigation**, select a floor, and then select .



Note

Use **Search** to find a specific location in a large network. Type the first few characters to see a list of locations. The more characters you type, the more precise the search results are.



Note

The selected floor must include a floor plan. For more information, see [Upload a Floor Plan](#) on page 146.


3. Select .
4. To draw inner walls:
 - a. Select **Walls**.
 - b. Select a wall type.

Table 18: Floor Plan Wall Types






Wall Color	Description
	Bookshelf 5dB
	Cubicle 2dB
	Dry Wall 3dB
	Brick Wall 5dB
	Concrete 15dB
	Elevator Shaft 10dB
	Thin Door 4dB
	Thick Door 10dB
	Thin Window 1dB
	Thick Window 6dB

Table 18: Floor Plan Wall Types (continued)

Wall Color	Description
Draw Perimeter	<p>Draw the outside boundary of the building.</p> <p>Note: When importing a new map, a perimeter is automatically established around the entire image unless the map already has a predefined perimeter. To adjust the perimeter, select Draw Perimeter, and then double-click the perimeter and drag to the desired location.</p>
Add Custom Material	<p>Create a new custom material by entering a Name, specifying the Attenuation (in dB), and selecting a Color. Select Apply to use this new material type.</p> <p>Delete an existing custom material by selecting the material and pressing the Delete key on your keyboard.</p> <p>Note: Custom materials can only be deleted after all associated references to the them have been removed.</p>

- c. Select each corner of an inner wall on the floor plan to draw a wall boundary.
- d. When you reach the end of the wall boundary, double-click the last corner to complete the wall.

**Note**

Right-click on a wall to change its type or delete it.

- e. To disable the pen tool, press the **ESC** key on your keyboard.
5. To add a device to the floor plan, select **Devices**:
 - a. Select a device, or use the **Search** field to find a device.
 - b. Hover over the floor map and select the desired location to add the device to the floor plan.

**Note**

Only devices that are not associated with the floor plan are displayed.

6. To move a device to a new location on the floor plan, select **Devices**, and then select a device and drag it to the desired location.
7. To remove a device from the floor plan, select **Devices**, right-click the device, and then select **Remove Device**.

**Note**

The removed device displays in the **Devices** list.

8. To adjust the opacity of the heat map layers, select **Layers** and adjust the opacity slider bar to make a layer more or less transparent.

**Note**

As you adjust the slider bar, the layer opacity changes on the map in real time.

9. To resize the heat map, follow these steps:
 - a. Select **Recalibrate**.
 - b. Select your starting point on the map.
 - c. Select again to close the line.
 - d. Add a measurement (in feet) for the line distance, and then press **Enter**.
10. To return to the heat map, select **Exit**.

Related Links

[Radio Frequency Maps](#) on page 49

[Import a Third-Party RF Map](#) on page 62

Access View

The **Access** view shows per floor view of edge devices such as access points, phones, and cameras connected to a device in a building. The view in the content pane depends on your selection in the navigation pane, as follows:

- If you select a site or group of sites, the content pane displays the first building belonging to the selected site or group of sites.
- If you select a building, the content pane displays the edge devices and connections for that building.
- If you select a floor, the content pane displays the edge devices and connections for that building, and focus is set to the selected floor.

The content pane displays the following devices (expanded) for the **Access** view:

- APs assigned to the selected floor or building
- If the LLDP Neighbors feature is enabled:
 - LLDP-discovered devices connected to switches on the selected floor or in the selected building
 - Cameras connected to switches on the selected floor or building
 - Phones connected to switches on the selected floor or building
 - Other devices connected to switches on the selected floor or building
- Existing links between switches that appear in the content pane

You can hover over an edge device or select it to view the details.

Fabric Layer



Note

Access to the Fabric layer feature requires Extreme Platform ONE Standard Networking subscriptions. If you have a mix of Platform ONE Standard Networking and ExtremeCloud IQ Pilot subscriptions, this feature is limited to sites, buildings, or fabrics that do not have any ExtremeCloud IQ Pilot-licensed devices.

The Fabric layer topology map shows fabric network connections. **Visualize** supports multiple fabric network views. You can navigate to any fabric network for visualization and orchestration.

The fabric layer topology map shows the boundary of the fabric network, which helps classify devices as fabric and non-fabric entities. You can divide a fabric network into multiple areas. The boundary nodes show information such as own home area and remote area. Visualize assigns default colors to home and remote areas.

Select  to configure the topology map [Display Options](#).

Fabric SD-WAN

Visualize shows SD-WAN devices that are connected through LLDP and IS-IS interconnections as Jump Link, connecting the two fabric nodes over the SD-WAN infrastructure.

VLAN Topology Map

For non-fabric devices, you can view both physical and service (VLAN) topology maps.

The physical topology map is based on the physical connections received from LLDP interconnections. If VLANs are added to a switch and provisioned on each port across each switch, the VLAN topology map shows the spread of a given VLAN in the topology.



Note

- Extreme Platform ONE Networking does not support Spanning Tree Protocol (STP) in a VLAN topology map.
- Device drag and drop options are not supported in the fabric layer.

Fabric Topology Map Elements

Hover over a node or link in the fabric topology map or select it to view the details in the **Inspector** panel. Select a fabric link to show the IS-IS area ID, differentiating between the home and remote area IDs.

Table 19: Fabric topology map elements

Elements	Description
Fabric Details	Includes the following details: <ul style="list-style-type: none"> • SysID • BVIDs • Nick Name • IS-IS Area (Home) • IS-IS Area (Remote)
Network-to-Network Interface (NNI)	At the fabric layer, fabric links are represented as NNIs. Fabric NNIs are classified as follows: <ul style="list-style-type: none"> • Fabric NNI (Link between fabric devices) • Fabric Attach NNI (Link to Fabric Attach) • Fabric SD-WAN NNI (Link to SD-WAN) NNI indicates whether the elements are configured explicitly or auto-sensed.
NNI States	Operational and administrative states are derived from IS-IS interconnections.
User Network Interface (UNI)	User links are represented as Switched, Transparent, or Private UNIs.
Auto Sense	Auto-sense ports support the following states: <ul style="list-style-type: none"> • Fabric NNI • Fabric Attach NNI • SD-WAN interconnect NNI • User access port with Network Access Control (NAC) • User access port w/o NAC • Onboarding
Fabric Attach	Displays devices that are running the following: <ul style="list-style-type: none"> • Fabric Attach Proxy Code: <ul style="list-style-type: none"> ◦ EXOS/Switch Engine ◦ ISW-Series Managed Industrial Ethernet Switch ◦ Ethernet Routing Switch (ERS) ◦ Third-party devices • Devices that are running Fabric Attach Client: <ul style="list-style-type: none"> ◦ Extreme APs ◦ Third-Party devices
Fabric Aware Devices	Devices that are attached to the fabric using Fabric Attach (FA), FA Proxies.

Table 19: Fabric topology map elements (continued)

Elements	Description
Summary	Includes the following device details: <ul style="list-style-type: none"> • FA System ID • FA Type: Proxy or Standalone • FA Mgmt VLAN • FA Server ID • FA Server Name • Forward FA Mgmt VLAN State Off
Tags	Create and manage Default and Manual tags.
Alerts	View and acknowledge selected alerts.
Services/VLANs	View VLANs, L2 services, and L3 services.

Service Layer



Note

Access to the Service layer feature requires Extreme Platform ONE Standard Networking subscriptions. If you have a mix of Platform ONE Standard Networking and ExtremeCloud IQ Pilot subscriptions, this feature is limited to sites, buildings, or fabrics that do not have any ExtremeCloud IQ Pilot-licensed devices.

The Service Layer topology map shows VLANs, L2, and L3 services configured on devices in the network. You can trace a service from the Service Layer to either Physical Layer or Fabric Layer.

The Service Layer supports the following functions:

- Search configured VLANs, L2, and L3 services in the network.
- View active and inactive ports or links and identify port states.
- Tag and filter devices based on attached services.
- View global and device specific service information.
- View endpoint-to-endpoint service information.
- Websocket notifications for service CRUD operations.
- Debug a VLAN, L2 Service, or L3 service connectivity issues between devices.


Filter a Service

You can use the **OR** and **AND** filter options to create a combination of filters such as service and physical, service and location, service and tags.

Upon device discovery, **Visualize** assigns default tags to devices based on the attached services. You can create manual tags and attach them to services.

Use this task to filter a service.

1. Go to **Monitoring > Visualize**.

2. To filter the topology map view, select **Filters** .
3. Select **Add Filter** and begin typing a filter keyword.
As you type, the Search returns results. Tag names are case sensitive.
4. Select **+ Add Filter** to add an additional **OR** filter.
5. Select **+ Add Condition** to add an additional **AND** filter.
6. Select **Apply Filters**.

The devices with the filtered tag are highlighted on the topology map.




Figure 8: Filtered Devices

Clear the filters using **Clear All** to return to the global view.

Pop-up Notifications

When you update a service endpoint in the network, all users in the Service Layer receive a pop-up notification to refresh the topology map to view the changes.

The topology map updates dynamically after service updates.



Note

When a physical link between two devices is removed, the link in the topology turns red and shows as **Disconnected** in the details when you hover over it. The link color and status do not change in the topology when the devices are reconnected. However, the inspector window shows the **Operational State** as **UP** for both sides of the link.

View Endpoint-to-Endpoint Service Information

Use this task to view the configured path from the source device to the destination device in a campus fabric network.

**Note**

For non-fabric VLAN networks, the endpoint-to-endpoint view of the VLAN displays all participating devices.

1. Go to **Monitoring > Visualize**.
2. Select the **Physical** or **Fabric** layer as required.
3. Right-click a device in the topology map and select **Show Endpoint-to-Endpoint Service/VLAN**.
4. Select the second device from the list of devices to view the endpoint-to-endpoint service mapping.

5. Select **Select End Point**.

The lists of services available on the selected endpoints opens.




Figure 9: Endpoint Services

6. Select a service from each of the lists.

7. Select **Show**.




Figure 10: Endpoint to Endpoint Configuration Path

Extreme Platform ONE Networking displays the Endpoint to Endpoint configuration path for the selected device.

8. Select the highlighted service on the topology map to view the endpoint-to-endpoint summary in the inspector panel.
9. In the inspector panel, select **Close ETE Service View** to exit the endpoint-to-endpoint service view.

Reassign Licenses | Visualize

To reassign licenses, you must have write access to **Inventory** and subscriptions and you must have sufficient Extreme Platform ONE Standard Networking licenses.

Use this procedure to reassign Extreme Platform ONE Standard Networking licenses to a building or an outdoor site.

1. Go to **Monitoring > Visualize**.
2. Select one or more sites or buildings.

3. Select , and then choose **Unlock Full Features**.



Note

If there are one or more Fabric Engine devices, to enable the reassignment, you must select all buildings with Fabric Engine.

4. Select **Unlock**.

Device Discovery

Visualize supports managed APs, VOSS (Fabric Engine), and EXOS (Switch Engine) devices.

Use **Visualize** to view and manage all devices onboarded through common onboarding services, including switch stacks. **Visualize** view generates a topology map of all managed on-boarded devices by analyzing data from the LLDP protocols (physical) and Intermediate System to Intermediate System (IS-IS) logical tables.

Table 20: Device Discovery based on LLDP

Adjacency	Description
Physical	Extreme Platform ONE Networking uses physical network connections to generate LLDP Neighborship from the devices.
Logical	Extreme Platform ONE Networking uses logical network connections to generate LLDP Neighborship, ISIS tables, and SD-WAN data.
Third-Party Devices	Special LLDP TLVs discover third-party devices, such as cameras, IoT devices, and sensors, and show them as attached devices on the topology map.

Device Group



The **Visualize** view leverages site-group and site hierarchy in Extreme Platform ONE Networking for the auto-creation of groups during the device onboarding process. Sites and site groups appear in groups on topology maps.


The topology map is a persistent view. The following map characteristics persist after you log out and log back in:

- Layout changes
- Hierarchical level
- User-defined details

Initiate Device Discovery



Use this task to add devices onboarded through ExtremeCloud IQ or Extreme Platform ONE Networking to the Visualize topology map.

1. Go to **Monitoring > Visualize** and select .
2. Select , and then select **Expand All**.
3. Locate the required building.

4. Select  for the building, and then select **Initiate Discovery**.
After a successful device discovery, a notification message with a **Refresh** button opens.
5. To refresh the topology map, from the **Success** notification, select **Refresh**.

View Inspector Panel

Use this task to view the **Inspector** panel.

1. Go to **Monitoring > Visualize**.
2. To view the **Inspector** panel for the selected site, building, floor, or group of devices, select .
3. (Optional) To view service mapping using topology layers, do the following:
 - a. Use  to select the **Service Layer**.
 - b. Select the second layer as required to view the service mapping: **Physical** or **Fabric**
4. From the **Services/VLANs** tab in the **Inspector** panel, do the following:
 - a. Select the required VLANs, L2 Services, or L3 Services tab.
 - b. Select a service to view service information for all devices in the topology.




Figure 11: Inspector panel

5. Deselect the selected Services and VLANs to exit the topology view.

View and Acknowledge Alerts

You can use **Quick Navigation** to navigate to critical alerts by location on the topology map.

Use this task to view and acknowledge alerts.

1. Go to **Monitoring > Visualize**.
2. Use **Quick Navigation** to navigate to critical alerts by site, building, or floor.
3. Select a location with critical alerts.
4. To open the **Inspector** panel, select a device.
5. Select the **Alerts** tab in the **Inspector** panel to view alerts.





Figure 12: Alerts Tab

6. Select an alert from the **Top 3 Alerts** list to view and acknowledge.
7. Select **Acknowledge** to mark the alert as reviewed.

View the Device Inspector Panel

Use this task to view the **Device Inspector** panel.

1. Go to **Monitoring > Visualize**.
2. To view device-specific information, select a device in the topology map.
The device-specific inspector window opens. You can expand or collapse the device information for a focused view in each tab.
3. (Optional) To view service mapping using topology layers, do the following:
 - a. To select the **Service Layer**, select .
 - b. If required, select a second layer to view the service mapping: **Physical** or **Fabric**.
4. On the **Services/VLANs** tab in the Inspector panel, do the following:
 - a. Select the required VLANs, L2 Services, or L3 Services tab.
 - b. Select a service to view service information for the selected device.





Figure 13: Device Inspector Panel

View Device 360°

Use this task to open Device 360° from the **Visualize** view.

1. Go to **Monitoring > Visualize**.
2. To open the **Device Inspector** panel, select a managed device in the content pane.
3. In the **Device Inspector** panel, select .

Available information depends on the device selected and the connection type (wired or wireless). For more information, see the following topics:

Wired Devices

- [Overview](#) on page 129
- [Clients](#) on page 129
- [Port Stats](#) on page 130
- [Services/VLANs](#) on page 131
- [Routing](#) on page 132
- [Events](#) on page 132




Wireless Devices

- [Overview](#) on page 129
- [Wireless Interface](#) on page 137
- [Wired Interface](#) on page 138

- [Clients](#) on page 138
- [Alerts](#) on page 138

AutoSave Device Layout and Density

Use this task to enable the autosave feature for device layout and density in the Physical layer and Access views.

1. Select  to unlock device layout and density.
2. Enable the **AutoSave** option.
3. Go to , and select a floor.
4. Select  for the floor, and then choose the required **Device Layout** and **Density** options for the topology map:

Device Layout :

- Stacked
- Spread
- Grid
- Hierarchical


Density:

- Very Sparse
- Sparse
- Dense
- Very Dense

Search an Element

You can search the network for configured VLANs, L2, and L3 services. **Visualize** can display five global services on the topology map. You can select or switch between these global services to view the topology map.

Use this task to search an element in the network topology map.

1. Go to **Monitoring > Visualize**.
2. Select .
3. Select the required filter keyword for searching:
 - Devices
 - Services
 - VLANs
4. Type a **Service Name**, **VLAN ID**, or **Device Name** in the **Search** field.
All devices with the specified search value and the associated service open in the global view.

Settings

Select  to configure topology map settings in the **Visualize** view.


Configure the Display Options

Use this task to configure display options for Visualize topology maps.



Note

The display options are user-specific.

1. Go to **Monitoring** > **Visualize** and select .
2. Select **Display Options**.
3. Select features for the required topology map layers:
 - For the Physical layer, go to step 4 on page 80.
 - For the Access view, go to step 5 on page 80.
 - For the Fabric layer, go to step 6 on page 81.
 - For the Service layer, go to step 7 on page 81.
4. Select the required **Physical** layer options:
 - **Device Labels: Name, IP, or Type** (select any two options)
 - **Link Labels**
 - **SD-WAN Internet Uplinks**
 - **LLDP Neighbors** (devices with LLDP and Fabric Attach capabilities):

You can expand or collapse **Display LLDP Options** to view and edit the list of LLDP devices:

- Discovered APs
- Cameras
- Extreme SD-WAN
- Phones
- Discovered Routers
- Discovered Switches
- Repeaters
- Others (LLDP devices without any capabilities advertised)



Note

Select **Others** to include all types of devices without LLDP capabilities. This option is disabled by default.

- Third Party Appliances (Phones, APs, Cameras)
 - Non managed Extreme Devices (Switches/APs/Routers)
5. Select the **Access** layer options:
 - **Device Labels: Name, IP, or Type** (Select any two.)
 - **LLDP Neighbors** (devices with LLDP and Fabric Attach capabilities):

You can expand or collapse **Display LLDP Options** to view and edit the list of LLDP devices:

- Discovered APs
- Cameras
- Phones
- Others (LLDP devices without any capabilities set)

**Note**

To include all types of devices without LLDP capabilities, select **Others**. This option is disabled by default.

6. Select the **Fabric** layer options:

- **Device Labels: Name or Type**
- **IS-IS Areas**
- **Ports**
- **Link Labels**
- **FA Clients**

7. Select the **Service** layer options:

- **Mode: Verbose or Non-Verbose**
- **IP Interface**
- **VRRP**
- **RMSLT Interfaces**

8. Select **Apply Settings**.

Manage

The following capabilities are available on the **Manage** tab:

- Select **Save User Settings** to save display options, filters, expand/collapse state of quick navigation, topology focus, zoom level, border state, device types settings, and the breadcrumb path.
- Select **Restore Settings** to restore and apply the saved display options, filters, and border settings.
- Select **Manage Tags** to create and manage tags.

Tags

Apply **Tags** to managed resources in the **Visualize** view. The tags act as labels and help in easy filtering of the devices in maps.


Table 21: Tag types

Tag Type	Description
Default Tag	Default tags are auto assigned during device discovery based on predefined criteria. These tags are created based on switch type, location, model, VLAN, VRF, L2 service, and L3 service. The default tags are read-only and cannot be altered or deleted. The system automatically assigns Provisional tags to masked devices.
Manual Tag	Manual tags are labeled by the user. Types of manual tags: <ul style="list-style-type: none">• Policy based• Non-policy based

Add a Policy-Based Tag


You can select single or multiple devices and services from the topology map and apply manual tags. You can add an existing tag or add a new tag to the selected devices.

Use this procedure to create a policy-based tag.

1. Go to **Monitoring > Visualize** and select **Settings** .
2. Select **Manage > Tags**.
The **Manage Tags** page opens in the content pane.
3. Select **Add Tag**.
4. Select **Custom Tag Name** and type a name for the tag.
5. Select the element **Type**:
 - **Device**
 - **L2 Service**
 - **L3 Service**
 - **VLAN Service**
 - **VRF Service**
6. Use the **Create a Condition** section to create conditions for tags:
 - a. Select the **Identifier**: **Location**, **Model**, or **Device Type**.
 - b. Select the **Relative** value: **is** or **is not**.
 - c. Enter the required **Value** for the tag.

The screenshot shows the 'Add Tag' dialog box. At the top, there's a title bar with 'Add Tag' and a close button. Below it, there's a text input field for 'Custom Tag Name' with a placeholder 'Add a Custom Tag Name'. To the right of this is a dropdown menu for 'Select Type'. Below these fields is a section titled '1 Create a Condition' with a delete icon. This section contains three fields: 'Identifier' (a dropdown menu), 'Relative' (a dropdown menu with 'is' selected), and 'Value' (a text input field). Below these fields is a '+ Add Attribute' button. At the bottom of the dialog, there is a '+ Add Condition' button and two buttons labeled 'Cancel' and 'Save'.

Figure 14: Add Tag Settings

- Select **Delete**  to delete a condition.
 - Use **Add Attribute** to add more conditional attributes to the tag.
7. Select **Save**.
The new tag is added to the list of tags.
 8. (Optional) Select **Back to Visualize** to return to the **Visualize** view.

Add a Non-Policy Based Tag

Select single or multiple devices and services from the topology map and apply manual tags. You can add an existing tag or add a new tag to the selected devices.

Use this procedure to create a non-policy based tag.

1. Go to **Monitoring > Visualize**.
2. Select a device on the topology map.
The **Inspector** panel opens for the selected device.

3. In the **Manual Tags** section, select **Add Tag**.











Figure 15: Summary - Add Tag

4. In the **Add Manual Tags** window, type a name for the new tag.
5. Select **Done**.
- The new tag is added to the selected device and the list of **Manual Tags**.
6. (Optional) To modify a manual tag, select it and then select .
7. (Optional) To copy a manual tag, select it and then select .
8. (Optional) To delete a manual tag, select it and then select .
9. (Optional) To return to the **Visualize** view, select **Back to Visualize**.


Edit a Tag

You cannot edit default tags. Use this task to modify manual tags:

1. Go to **Monitoring > Visualize** and select .
2. Select **Manage > Tags**.
- The **Manual Tags** page opens.
3. Select  for the corresponding tag, and then select **Edit**.
4. On the **Tag Details** page, select .
- Alternatively, you can select  for the corresponding tag and choose **Tag Details**.
5. Edit the tag details as required.
- For more information, see [Add a Policy-Based Tag](#) on page 82.
6. Select **Save**.

View and Manage Assigned Entities

Use this task to view and manage assigned entities.

1. Go to **Monitoring > Visualize** and select .
2. Select **Manage > Tags**.
- The **Manual Tags** page opens.



3. From the corresponding **Overflow** menu of the required tag, select **Tag Details**.
 4. In the **Tag Details** window, select **View Assigned Entities**.
Alternatively, you can select **View Assigned Entities** from the associated **Overflow** menu for the tag.
 5. In the **Assigned Entities** window, select the required tab to view the entities:
 - Switch
 - L2 Service
 - L3 Service
 - VLAN Service
- Use the **Search** field to narrow the list of entities from which to choose.
6. To unassign an entity, select it from the list of entities and select **Unassign**.
 7. Select **Unassign** to confirm when prompted.
 8. (Optional) Select **Back to Visualize** to return to the Visualize view.

Filter Devices Using Tags

The **Manage Tags** page displays the following information:

- **Tag Name:** Name of the tag
- **Tag Type:** Type of the tag, Manual or Default
- **Tag Applied To:** Entities associated with the tag

Use this task to filter devices using tags.

1. Go to **Monitoring > Visualize** and select **Settings** .
2. Select **Manage > Tags**.
3. Perform the following steps to filter the devices based on **Tag Name** and **Tag Type**:
 - a. Select the column heading.
 - b. Select Filter .
 - c. Select the check boxes of the entities to filter the list of tags.

Use the **Search**  field to narrow the list of tags.

Delete a Tag

Use this task to delete a tag.

1. Go to **Monitoring > Visualize** and select .
2. **Manage > Tags**.

The **Manual Tags** page opens.

3. Select the required tags and then select **Delete**.

Alternatively, you can select **Delete** from the associated **Overflow** menu for the tag.

User Roles Supported in Visualize View

Visualize view supports the following user roles:

Table 22: Supported user roles

User Role	Description
Administrator	Administrators have read-write access to Visualize view. They can create and manage all administrator users and licenses through Visualize view.
BizSecOps	BizSecOps have read-write access, but cannot manage accounts and licensing.
BizOps	BizOps have no access to Visualize view.
Observer	Observers have read-only access to Visualize view.

For more information about roles, see [Role-Based Access](#) on page 28.

Alerts

The **Alerts** view provides a comprehensive overview of network alerts, allowing operators to detect, record, and report specific events. It evaluates performance metrics and reports occurrences where specific criteria are met. Alerts can be filtered by time range, severity, status, site, and source.

Users can receive alert notifications through email or Webhooks.

Manage Alerts

The **Alerts** view offers widgets such as **Severity**, **Category**, **Top 3 Alerts**, and **Application** to filter the list of alerts raised during the specified time range.

Go to **Monitoring > Alerts**.

You can use widgets to filter the list of alerts raised during the specified time range.

Select **Alert Policies** to view and manage global and site policies.






Note

Site policies take precedence over global policies.

Alert Details

By default, the **Alerts** page displays information about alerts raised at all sites for the last 24 hours. You can filter the **Alert Details** list using the following methods:

- Use the **Time Range** controls to specify a time range, within the last 30 days, for which you want to view alerts.
- Use the **Severity** filter to view alerts based on specific severity:
 - Critical - Red 
 - Major, Minor, and Warning - No color combination

- Info - Blue 
- Use the **Status** drop-down list to view **All** (default), **Acknowledged**, or **New** alerts.
- Use the **Sites** filter to view alerts associated with a specific site.
- Use the interactive device host name in the **Source** column for more information about the alert.
- Use the **Refresh Alerts** button to view the most recent alerts.
- Use the **Export to CSV**  button to download the alert data in .csv format.

**Note**

The column filter settings do not persist.

Use the Filter Side Bar

Use the filter sidebar to customize the information shown in the **Devices** list and other **Alerts** view tables. You can save and reuse custom-defined filters. Saved filters are displayed in the saved filters section.

The Filter icon changes depending on whether a filter is applied.

View and Acknowledge Alert

1. Go to **Monitoring > Alerts**.
2. Navigate to alerts by **Severity**, **Category**, **Top 3**, or **Application**.
3. Select an alert from the list to view and acknowledge.
4. Select **Acknowledge** to mark the alert as reviewed.




Add a Site Policy

Use this task to add a site policy.

1. Go to **Administration & Settings > Alert Policies**, and select **Site Policies**.
2. Select **Add Site Policy**.
3. Complete the following:
 - Provide the **Alert Policy Name**.
 - Select **Sites**.
4. Select **Next**.
5. Select an **Alert Rule** and optionally edit, enable, or disable the rule parameters.
6. Select **Apply Rules**.
7. To edit or delete the site policy, from the 3-dot menu, select **Edit** or **Delete**.

Network Devices


Network Devices is a centralized location for monitoring both wired and wireless network devices. It provides detailed insights into the performance, health, and usage of each device, helping you maintain optimal network functionality. From here, you can:

- **Device Status:** Check if devices are connected, disconnected, or encountering problems.
- **Device Health:** Evaluate performance metrics such as CPU Usage, Memory Usage, and PoE Usage.
- **Usage & Capacity:** Understand bandwidth consumption, data transfer rates, and storage utilization.
- **Sites:** If you have access to multiple sites, select **Sites** to filter the network devices associated with a specific site.
- **Onboard:** Devices can be onboarded to the network using a manual or bulk onboard method.
- **Update Firmware:** Manually update firmware for selected devices
- **Firmware Update History:** Select  to view **Firmware Update History**.
- **Update Device Data:** Select  to refresh and update device data.
- **Download:** Select  to download the table data as a CSV file.

Device Status

The **Monitoring > Network Devices > Device Status** window provides resources to facilitate device management. These resources include:

- **Show Summary:** Displays Total Device, Disconnected, and Connected status widgets.
- **Show Additional Data:** Displays **Clients** data. Select status icon to view **Clients** details.
- **Device Status Indicators:** Under the **Status** column in the device list, icons appear that are designed to provide useful device status information. Multiple status icons can be associated with a device. Hover over any icon to view a label indicating what the icon represents. For a description of each icon that can appear in the device list, see [Device Status Icons](#).
- **All:** Displays all devices.
- **Wired:** Displays only wired devices.

- **Wireless:** Displays only wireless devices.
- **Device Management:** Select  at the end of a row in the device list to perform actions on a device.



Note

To perform actions on multiple devices, select the devices to configure, and then select **Actions**.



Note

To download the table data as a CSV file, select .

Wired

Select **Wired** to filter a list of wired devices.

The Wired table displays the following information:

- | | |
|-----------------|-------------------|
| • Status | • Default Gateway |
| • Device * | • FW Upgrade On |
| • Location | • Firmware |
| • Uptime | • Model |
| • MAC * | • IPv6 |
| • Serial Number | |
| • Management IP | |

* Select to view additional details.

Wireless

Select **Wireless** to filter a list of wireless devices.

The Wireless table displays the following information:

- | | |
|-------------------|----------------|
| • Status | • Updated |
| • Device * | • Firmware |
| • Location | • Model |
| • Uptime | • IPv6 |
| • MAC * | • Country Code |
| • Serial Number | • Managed By |
| • Management IP | |
| • Default Gateway | |

* Select to view additional details.

Device Management Overview

From the **Monitoring > Network Devices > Device Status > 3-dot Menu** (⋮), you can perform a number of actions on a device. The available actions depend on the device type selected.



Note

- Not all actions are available for all device types. Most device options are unavailable for an unmanaged device. To change the management status of your device, select **Change Management Status > Manage**.
- To perform actions on multiple devices, select the devices to configure, and then select **Actions**.

- **Assign Location:** Assign a location to IQ Engine devices.
- **Assign Network Policy:** Assign an existing network policy to the device.



Note

This action replaces existing associated policies with the newly selected policy.

- **Change Management Status:** Indicates the management status of the selected devices. Select **Manage** or **Unmanage**.



Note

The **Change Management Status** menu option is now available for Site Engine and devices managed by Site Engine. If Site Engine status is **Unmanaged**, the status for both Site Engine and devices managed by Site Engine is **Unmanaged**.

- **Reboot:** Reboot devices after uploading a configuration. Rebooting momentarily disconnects any associated clients from the SSID, which could be disruptive.
- **Reset to Default:** Reset the device to factory defaults.




Important

This operation removes existing settings from the selected device and returns it to factory settings. It then reconnects to the cloud as a new device.

- **Upgrade Firmware:** Upgrade firmware to a selected version. Select **Upgrade Now** to upgrade immediately, or select **Upgrade Later** to upgrade at a specific date and time.
- **Utilities > Diagnosis**
- **Configure > Device:** Perform device-level configuration tasks and update devices. Settings made at this level apply only to the individual device and overrides the template settings configured for the network policy. For wired devices, see [Configure Wired Devices](#). For wireless devices, see [Configure Wireless Devices](#).
- **Configure > Fabric:** Configure the minimum required Global SPBM and Auto Sense settings to enable SPBM to operate on a wired device. See [Configure Fabric Settings](#).

Configure Wired Devices

After you select  at the end of a wired device row, and then select **Configure > Device**, you can create or modify the following:

- **Device Configuration:** Edit device details such as the host name, the description, the device function, IP addresses, and VLAN assignments.
- **Device Management Servers:** Edit management server settings for a device associated with a network policy.
- **Switch Port Configuration:** Edit switch ports, STP, Storm Control, PSE, and VLAN attributes.



Note

Fabric Engine devices support EAPoL, SLPP, and VLAN/ISID configuration with VLAN attributes.


- **Device Credentials:** Assign or change network administrator credentials and administrator assignments.
- **Interface Configuration:** Add, edit, or delete interface configurations.
- **Routing Configuration:** Configure IP4 Static Routes.

After you make changes to the configuration, you must [push the configuration changes to the device](#).

Wired Device Configuration

Making device configuration changes at the wired device level overrides the equivalent settings in the network policy assigned to the device, after you push the updated configuration to the device.

Use this task to make device configuration changes at the device level.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Device Configuration**.
4. Configure the **Device Details**:
 - **Host Name:** Enter a unique host name for the device. It can contain up to 32 characters and can include spaces.
 - **SNMP Location:** Enter a location name, for example `headquarters, building 1`.
5. Configure the **Network Details**:
 - **Network Policy:** Select a network policy from the drop-down list of existing policies.
 - **Device Template:** Select a device template from the drop-down list of existing templates, or clone an existing template.



Note

Fabric Engine devices do not support device templates.

6. Toggle **Management Interface Settings** to **On** or **Off**.

When enabled, management interface settings specified below are applied and override template-level management interface settings. If disabled, you can apply template settings, or the device will use manually configured management interface settings. Leave disabled when using **Out-Of-Band Management**.

- **VLAN Interface:** Select when the management interface is to be supplied by the management VLAN.
 - **Management VLAN:** Enter the VLAN to be used by the switch.
 - **Management IP Settings:** Select **Static Address** or **Dynamic Address Configuration (DHCP) Client** to enable DHCP on this interface.

7. (Optional) Configure **Supplemental CLI**:

- a. **Apply Supplement CLI from network policy switch template:** Include the supplemental CLI object in the network policy and append the selected CLI object from the list. If you select a supplemental CLI object from the list, or create a new one, it is appended to the end of the configuration list, after the supplemental CLI object in the network policy.
- b. **Override Supplement CLI from network policy Supplement CLI:** Enable the network policy to override supplemental CLI objects for the device. For more information, see [Override Supplemental CLI](#) on page 116.



Note

Fabric Engine only supports Supplemental CLI from device-level configuration.



Important

Before you can configure Supplemental CLI access on a device, you must first enable Supplemental CLI. Go to **Administration & Settings > Backup & Restore**, and then enable **Supplemental CLI**.

8. Select **Save Configuration**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Device Management Servers](#) on page 92

[Configure Wired Devices](#) on page 91

Device Management Servers

The **Device Management Servers** page does not appear until you apply a network policy to the device.


Use this task to override a network policy and make device-level changes to management server settings for a device. The changes affect only the specific device, not all devices associated with the network policy. You must **Unlock** before you can configure and save a device level management server configuration. You can use

Revert to restore the network policy configuration and overwrite any changes made at the device level.

**Note**

DNS Server, NTP Server, SNMP Server, and Syslog Server configurations can be managed at the device level for Switch Engine/EXOS and Fabric Engine/VOSS after unlock. Not all management server tabs are available for all device types. UZTNA RADIUS and UZTNA RADIUS Proxy Servers are supported only for Fabric Engine devices under device management servers.

For stacks, the unlock and revert action applies to all units/slots within the page. This enables the full stack to revert to the currently assigned network policy. Also, the **Device Management Servers** is not available until you apply the network policy to both single switches and stacks.

1. Go to **Monitoring > Network Devices > Device Status..**
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Device Management Servers**.
4. Select **Unlock** from the top banner.

Changes saved after you unlock the device override the associated network policy.

5. Select each server tab to make any necessary changes to the server settings, then select **SAVE CONFIGURATION**.

The changes only apply at the device level. for more information about management server configuration.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Configure Switch Ports and VLAN](#) on page 93

[Configure Wired Devices](#) on page 91


Configure Switch Ports and VLAN

You can configure switch port configuration details and settings at the device level. Switch-level settings always override any port configuration settings that were made in the device template for a network policy. You must first **Unlock** this page to change

the switch-specific port configuration. You can also return to the original template configuration with the **Revert** option.

**Note**

- Only the options available to the specific switch are displayed.
- For 5520/5720 Universal Switches, VIM and partition mode are configurable at the device level.
- LLDP/CDP, MAC locking, STP Priority, BPDU Restrict, BPDU Restrict Recovery, Forwarding Delay, VLAN Attributes, and Max Age are configurable at the device level.
- BPDU Restrict and BPDU Recovery settings are found within the STP tab.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Port / VLAN Configuration**.
4. Select **Unlock** to enable switch-level configuration changes.
5. Select each tab, and edit any accessible field.
6. Select **Save Port Configuration**.

**Note**

BPDU Restrict and BPDU Restrict Recovery Timeout settings are found within the STP settings.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

7. To revert back to the network policy switch template, select **Revert to Network Policy**.

Related Links

[Configure Wired Device Credentials](#) on page 94

[Configure Wired Devices](#) on page 91

Configure Wired Device Credentials


Use device credentials to set up log in information for root or read-only administrators, change the name and password of the root admin, or add a read-only admin to a switch. Device-level credentials offer access to devices through Telnet, SSH, or console connections.

**Note**

At this level, you are making changes to the selected device only. These changes always override the network policy configurations. To revert to the settings in the network policy, from the **Device List**, select the device host name, and use the **Actions** button.

A root admin has complete privileges, which include the ability to add, modify, and delete other administrators, and to reset the configuration. A read-only admin can view settings but cannot add, modify, or delete them. You can require that an admin be

prompted for a password before accessing high-level privileged CLI commands. To configure a root admin with full capability, follow these steps:

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Device Credentials**.
4. For an **Administrator Account**, enter the **Admin Name** and **Password**.
Passwords should contain at least 8 characters, including at least one number, one special character, and one uppercase character.
5. For a **Read Only Administrator**, enter the **Admin Name** and **Password**.
Passwords should contain at least 8 characters, including at least one number, one special character, and one uppercase character.
6. Select **Save Configuration**.
For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links




[Configure Wired Devices](#) on page 91

Interface Configuration

On the **Interface Configuration** page, you can add, edit, or delete Interface configurations. The table includes the following parameters:

- IP Address
- IPv4 Subnetwork Allocation Name
- VLAN Name
- VLAN ID
- DHCP Relay
- IPv4 Forwarding
- Routing Instance

Use this task to configure the device interface.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under **Network Allocation**, select **Interface Configuration**.
4. Select a port icon on the template graphic to view port details, if available.
5. Select  to add, or  to edit an Interface.

6. Enter the interface attributes according to the table below:

Table 23: Interface Configuration Attributes

Field	Description
Network Allocation	An IP subnetwork configuration.
VLAN Attribute	A VLAN attribute, which can be created from within the Network Policy Switching > VLAN Attribute Section.
IPv4 Address / Subnet Mask	The assigned device IP Address.
Routing Instance	The device routing instance.
IPv4 Forwarding	Toggle ON to enable IPv4 forwarding.
VLAN Loopback Enable	Select the check box to enable VLAN loopback.
DHCP Relay	To override DHCP Relay, toggle ON Enable DHCP Relay . If enabled, enter a Primary DHCP Server and an optional Secondary DHCP Server .

7. Select **Next**.

8. Confirm **Summary** details, and then select **Save**.

To go back and make changes, select **Previous**.

9. To delete Interfaces, select the Interface(s) and then select .

10. For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Routing Configuration](#) on page 96


[Configure Wired Devices](#) on page 91

Routing Configuration

The device must have an IPv4 interface configured. For more information, see [Interface Configuration](#) on page 95.

Use this task to configure IP4 Static Routes for the selected device.

1. Go to **Monitoring > Network Devices > Device Status**.

2. Select  at the end of a device row, and then select **Configure > Device**.

3. Under the **Network Allocation** menu, select **Routing Configuration**.




4. Select  to add or  to edit, and then configure the following settings:

Table 24: Static Route Settings

Field	Description
Static Route Name	The name of the Static Route.
Destination Subnet	The desired subnet, such as 10.1.0.0/16.
Next Hop IP	The desired IP Address for the next Hop, such as 123.321.132.312.

Table 24: Static Route Settings (continued)

Field	Description
Next Hop IP Ping Protection	<p>Enable or Disable Next Hop IP Ping Protection.</p> <p>Note: Enabling Ping Protection will generate a Ping Protection Status tool tip when viewing your device within Monitoring > Visualize > Wired > Routing</p> <p>Note: Not supported for Fabric Engine/VOSS.</p>
Metric	The desired metric value.
Routing Instance	Shows the Routing Instance.

5. Select **Save**.
6. To delete a static route, select the check box next to the Static Route Name and then select .
7. For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links


[Configure Wired Devices](#) on page 91

Configure Fabric Settings

Shortest Path Bridging MAC (SPBM) is a next generation virtualization technology that revolutionizes the design, deployment, and operations of carriers and service providers, along with enterprise campus core networks and the enterprise data center. SPBM provides massive scalability while at the same time reducing the complexity of the network.

Auto-sense is a port-based functionality that supports zero touch capabilities on the switch. Auto-sense dynamically configures the port to act as an IS-IS network-to-network interface (NNI), Fabric UNI (Flex-UNI), Fabric Attach (FA), Fabric Extend, or voice (IP phone) interface, based on the Link Layer Discovery Protocol (LLDP) events. Auto-sense provides global configuration options for IS-IS authentication, FA authentication, Fabric Extend tunnel creation, and voice configuration for IP phones on the switch.

Use task to configure fabric settings for devices running Fabric Engine.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Fabric**.
3. Configure the following fabric settings:
 - [Global SPBM Settings](#)

- [Auto Sense Settings](#)

**Note**

Toggle **Advanced** to **ON** to view advanced options.

4. To save device fabric settings, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Device Management Overview](#) on page 90

Global SPBM Settings

Table 25: Global SPBM Settings

Field	Description
SPBM	
Hostname	Specifies the SPBM system name. Enter a string length from 1 to 255.
System ID	Specifies the SPBM instance ID. Note: System ID and Nickname can only be changed together.
Nickname	Specifies a nickname for the SPBM instance globally. Valid value is 2.5 bytes in the format <x.xx.xx>. Note: System ID and Nickname can only be changed together.
ISIS Manual Area ID	Specifies the IS-IS manual area. Valid value is 1-26 bytes in the format <xx.xxxx.xxxx...xxxx>. Only one manual area is supported. Use the same manual area across the entire SPBM cloud. For IS-IS to operate, you must configure at least one manual area.
Primary BVLAN	Specifies the primary SPBM B-VLAN to add to the SPBM instance.
Secondary BVLAN	Specifies the secondary SPBM B-VLAN to add to the SPBM instance.
IP Shortcuts	Toggle IP Shortcuts to ON to enable the SPBM IP shortcut state. The default is disable. In IP Source Address , specify the CLIP interface to use as the source address for SBPM IP shortcuts.
Multicast	Toggle Multicast to ON to enable IP multicast over SPBM. The default is disabled.
Auto ISID Assignment	Toggle Auto ISID Assignment to ON to enable automatic allocation to assign and manage ISIDs. In L2 ISID Offset , specify the starting index for SID allocation for Level 2 IS-IS routers.

Table 25: Global SPBM Settings (continued)

Field	Description
Nickname Server (Advanced Option)	
Nickname Prefix	Specifies the nickname server allocation prefix. x.xx.xx uses the form X.X0.00 from 0.00.00 to F.F0.00. A group, X.X0.00 to X.XF.FF, can provide up to 4,096 nicknames. The default is A.00.00.

Related Links

[Auto Sense Settings](#) on page 99

[Configure Fabric Settings](#) on page 97

Auto Sense Settings

Table 26: Auto Sense Settings

Field	Description
General Assignments	
Data ISID	Specifies the data I-SID used by the auto-sense ports.
Wait Interval	Specifies the wait interval, in seconds, for Auto sense to wait for a Link Layer Discovery Protocol (LLDP) neighbor to be detected in the auto-sense wait state before transitioning to the auto sense onboarding state. This configuration is a global configuration that applies to all auto-sense ports. The default value is 35. Note: This is an Advanced option.
Onboarding ISID	Specifies the onboarding I-SID used by the auto-sense ports. Note: This is an Advanced option.
Voice ISID	Specifies the voice I-SID used by auto sense ports.
Voice CVID	Specifies the customer VLAN ID associated with the voice I-SID used by auto-sense ports. Voice C-Vid is configured for tagged voice traffic only. Important: You must configure the Auto-sense voice customer VLAN ID along with the auto sense voice I-SID.
EAPoL Voice LLDP Authentication Bypass	Select to enable the EAPoL LLDP authentication bypass for voice auto sense ports. Note: This is an Advanced option.
Fabric Attach Assignments	
Proxy Switch management CVID	Specifies the proxy switch management client-VLAN ID (C-VID) used by auto sense ports.

Table 26: Auto Sense Settings (continued)

Field	Description
FA Proxy Management ISID	Specifies the FA proxy management I-SID used by auto sense ports.
Proxy No Auth ISID	Specifies the proxy no-auth I-SID used by auto sense ports. Note: This is an Advanced option.
Switch Engine Management ISID	Specifies the Switch Engine management I-SID used by auto-sense ports.
FA WAP Type1 ISID	Specifies the FA WAP type-1 I-SID used by auto sense ports.
FA Camera ISID	Specifies the FA camera I-SID used by auto sense ports.
EAPoL FA WAP Type1 Authentication Bypass	Select to enable the FA EAPoL authentication bypass for Wap-type-1 I-SID used by auto sense ports.
EAPoL FA Camera Authentication Bypass	Select to enable the FA EAPoL authentication bypass for camera I-SID used by auto sense ports.
Message Authentication IS-IS (Advanced Options)	
ISIS Hello Auth Type	Select an IS-IS hello authentication type.
ISIS Hello Auth Key ID	Specifies the IS-IS authentication key ID for auto sense ports.
ISIS Hello Auth Key	Specifies the IS-IS authentication key for auto sense ports.
Message Authentication FA (Advanced Options)	
FA Message Authentication	Select to enable FA message authentication.
FA Auth Key	Specifies the FA authentication key for the auto sense ports.

Related Links

[Global SPBM Settings](#) on page 98

[Configure Fabric Settings](#) on page 97

Configure Wireless Devices

After you select a **Wireless** from the Device List, you can create or modify the following:

- [Wireless Device Configuration](#): Edit device details such as the host name, the description, the device function, IP addresses, and VLAN assignments.
- [Wireless Interface Settings](#): View the default template settings and control actions for the Wireless (Wi-Fi) and Wired (Ethernet) ports. You can edit any field that is selectable.
- [Wireless Device Credentials](#): Assign or change network administrator credentials and administrator assignments, and configure CAPWAP and Shared Key settings.
- [Configure Netdump](#): Enable an unresponsive AP to automatically save a core dump file to a TFTP server on the network the next time it boots.

- [DHCP Server and Relay](#): For a small network, configure and enable a DHCP server on a device to provide network settings dynamically to clients.
- [Neighboring Devices](#): Define a list of neighbor access points that will collaborate in the Layer 3 roam process.
- [Bonjour Gateway Settings](#): Choose the AP you want to act as your Bonjour Gateway Designated Device (BDD) at the device level.
- [Troubleshooting](#): Enable Client Monitor so devices can detect client issues, and report client connection activities and problems to Extreme Platform ONE Networking.

After you make changes to the configuration, you must [push the configuration changes to the device](#).

Wireless Device Configuration

It is a best practice to configure devices using a device template. However, you can override the device template settings for a specific device.

Use this task to configure the settings for a specific wireless device.


1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Device Configuration**.
4. Configure **Device Details** settings:

Table 27: Device Details Settings

Field	Description
Host Name	Type a unique host name for the device. It can contain up to 32 characters and can include spaces.
Description	Optional description for the device.
Mgt0 MAC Address	This is the Node ID and is listed on the printed label located on each device.
Device Model	The hardware model of the configured device.
Device Function	This describes the main function of the device. For example, AP.
IQ Engine	Lists the IQ Engine firmware version currently installed on the AP.
SNMP Location	The SNMP location name, for example <code>headquarters, building 1</code> .

5. Configure **Network Details** settings:
 - **Network Policy**: Select a network policy from the drop-down list of existing policies.
 - **Device Template**: Select a device template from the drop-down list of existing templates, or clone an existing template.

6. Configure **Management Interface (Mgt0)** settings:

- a. Select **Static Address** to enter a static address for this interface, and then configure the following settings:

Table 28: Static Address Settings

Field	Description
IPv4 Address	The IPv4 address you want the device to use for the mgt0 interface.
Subnet Mask	The appropriate netmask for the subnet to which the mgt0 interface connects.
Default Gateway	The address through which the device (and its connected hosts) can reach the Internet.

- b. Select **Dynamic Address Configuration (DHCP) Client** to have an address automatically assigned by DHCP, and then configure the following settings:

Table 29: Dynamic Address Configuration (DHCP) Settings

Field	Description
Use DHCP only to set IP Address (IPv4 only)	Enable or disable this function.
Advanced DHCP Options (IPv4 only)	<p>Select to display or hide this section. Configure the following settings:</p> <ul style="list-style-type: none"> • DHCP Timeout: Enter the amount of time (in seconds) that the device waits for a response from the DHCP server before assigning itself a static IP address. By default, the timeout for reverting to a static address is 20 seconds. You can change the timeout from 0 to 3600 seconds (1 hour). A timeout of 0 means that the device continues trying to obtain network settings through DHCP indefinitely. • Automatically Generate Interface IP Settings: <ul style="list-style-type: none"> ◦ IP Prefix: The Extreme Networks device automatically switches to this IP address if it cannot obtain settings through DHCP. You can also enter an IPv6 address. ◦ Subnet Mask: Enter the netmask for the subnet to which the mgt0 interface connects. • Static Fallback IP Settings: <ul style="list-style-type: none"> ◦ Static IP Address: Enter the IP address you want the device to use if it cannot contact the DHCP server. You can also enter an IPv6 address. ◦ Subnet Mask: Enter the appropriate netmask for the subnet to which the mgt0 interface connects. ◦ Default Gateway: The address through which the device (and its connected hosts) can reach the Internet.

- c. Enter the **Management VLAN** for this interface.
- d. Enter the **Native VLAN** for this interface.
- e. Select **Override MGT0 MTU** to manually enter an MTU, ranging from 100-1500 Bytes (the default value is 1500 Bytes).

7. (Optional) Configure **Supplemental CLI**:
 - a. **Apply Supplement CLI from network policy switch template**: Include the supplemental CLI object in the network policy and append the selected CLI object from the list. If you select a supplemental CLI object from the list, or create a new one, it is appended to the end of the configuration list, after the supplemental CLI object in the network policy.
 - b. **Override Supplement CLI from network policy Supplement CLI**: Enable the network policy to override supplemental CLI objects for the device. For more information, see [Override Supplemental CLI](#) on page 116.



Important

Before you can configure Supplemental CLI access on a device, you must first enable Supplemental CLI. Go to **Administration & Settings > Backup & Restore**, and then enable **Supplemental CLI**.

8. Select **Override Disable WebUI in the network policy** to disable the local web user interface on an IQ Engine device to improve system security, without disabling the associated captive web portal.
If you configured **WebUI** in the network policy, you can disable it for this device here.
9. For **Deployment Mode**, select **Pre-Provisioned** or **Production** to indicate whether the device has been pre-provisioned.
10. (AP5010 only) Enable **POE Profile Override**, select the override option from the dropdown, and hover over the **i** icon to view the corresponding override table.
11. Select **Save Device Configuration**.
For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Wireless Interface Settings](#) on page 103

[Configure Wireless Devices](#) on page 100

Wireless Interface Settings

Use this task to view **Device Template Default Settings** and control actions for Wireless (Wi-Fi) and Wired (Ethernet) ports.



Note

Changes made here are at the device level, which overrides the network policy template for the device only. The Network Policy remains unchanged.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select **i** at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Interface Settings**.
4. For **Wireless Interfaces**, select either the **WiFi0**, **WiFi1**, **WiFi2**, **BLE**, or **IoT0** tab.



Note

The **IoT0** tab is supported on AP5010/AP5020 models.

5. To configure **WiFi0**, **WiFi1**, **WiFi2**, or **IoT0**, see [Wi-Fi Settings](#) on page 104.
6. To configure **BLE**, go to **Configuration > Network > Network Policy > Wireless > Application Management > BLE Service**.
7. For **Wired Interfaces**, see [Configure Wired Interfaces Settings](#) on page 106.

**Note**

To enable LLDP/CDP for a port, ensure LLDP/CDP is enabled under both the policy level and port level configuration.

8. To configure **Electronic Shelf Label**, toggle **Enable ESL** to **ON**, and then [Configure Electronic Shelf Label Settings](#).
9. Select **Save Interface Settings**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Configure Wireless Device Credentials](#) on page 107

[Configure Wireless Devices](#) on page 100

Wi-Fi Settings

Table 30: Radio Status Settings

Field	Description
Radio Status	Set to On .
Radio Profile—or IoT Profile, if applicable	<p>Select a profile from the drop-down list. You can also add a new Radio Profile or IoT Profile here, or clone and modify an existing profile.</p> <p>Note: Only the AP510C, AP510CX, AP550, AP650, AP650X, AP305C, AP305CX, AP302W, AP4000, AP5010, AP3000/X, AP410C, AP460C, AP460S6C, and AP460S12C models support MU-MIMO on its Wi-Fi0 interface.</p>
Radio Usage	<p>Select the usage type:</p> <ul style="list-style-type: none"> • Client Mode: Select to configure a device for AP client mode radio usage, and to configure advanced features such as Port Forwarding Rules and DHCP Server settings. Select a Client Mode Profile. If required, you can configure a new Client Mode Profile, or edit an existing profile. • Client Access: Select for normal client operation. • Backhaul Mesh Link: Select for wireless portal and mesh backhaul operation. • Sensor: Select for presence operation.
Enable SDR (Software Defined Radio)	Enable and then select an SDR Profile from the drop-down list. You can also add a new profile here or modify an existing profile.
Channel	Select a channel. If you select Auto , Extreme Platform ONE Networking selects the channel for you.


Table 30: Radio Status Settings (continued)

Field	Description
Override channel exclusion setting in radio profile	Enable, and then select activated channels to manually exclude them from the radio profile.
Transmission Power	Activate to manually set the transmission power. Select Manual , and then use the slider to select a dBm setting.
Enable client transmission power control (802.11h)	Activate to manually enable client transmission power control (802.11h). Select Manual and use the slider to select a dBm setting.

Table 31: Enable Presence Analytics Settings

Field	Description
Enable Presence Analytics	Toggle to On to modify device presence analytics settings.
Name	Automatically populates with the name of the Network Policy.
Trap Interval	The interval (in seconds) that the presence sensor reports data to Extreme Platform ONE Networking.
Aggregate Time	The interval (in seconds) for the period during which aggregation occurs for the presence profile.
Aging Time	The aging time (in seconds) for a given presence profile.

Table 32: SSID Settings

Field	Description
SSID Name (Policy)	The current SSID name.
Status	Toggle the SSID status to On or Off .
Override SSID Broadcast Name	Change the SSID broadcast name for the device.
Override PSK Password	Change the PSK password for the device.
Reassign CWP	Select a new CWP from the drop-down list.
	Hover and select Revert to revert device-specific SSID settings to their default values.

Related Links

[Wireless Interface Settings](#) on page 103

Configure Wired Interfaces Settings

Table 33: Wired Interfaces Settings




Field	Description
Interface	The software representation of the physical port.
State	Indicates if the port is enabled or disabled.
Port Type	The interface port type. This field is read only.
Native VLAN	The native (untagged) VLAN assigned to frames that do not have any 802.1Q VLAN tags in their headers.
Allowed VLANs	<p>The VLANs, including the native VLAN, that you want the trunk port to permit.</p> <p>You can list the VLANs individually, separated by commas, or as a range of VLANs using a hyphen. Alternatively, you can enter the word a11 in this field to support all existing VLANs previously configured in the network policy (the default).</p>
Fabric Attach	<ol style="list-style-type: none"> 1. Select , and then enter a Name and Description for the Fabric Attach. 2. For each VLAN, select , and then enter the device's associated VLAN ID and I-SID. 3. Select a VLAN from the list, and then select  to remove the VLAN from the Fabric Attach. 4. Select Save.
Transmission Type	<p>Select one of the following options:</p> <ul style="list-style-type: none"> • Auto: The switch negotiates the best common duplex mode with the connected device. • Full-Duplex: Forces the switch to communicate with the connected device using full duplex communication. • Half-Duplex: Forces the switch to use half duplex communication.
Speed	The speed the Ethernet port uses to communicate with the connected device.
Green Ethernet (AP4020 and AP5020 Only)	Select for AP5020 devices to allow physical layer transmitters to consume less power when they are in a state of idleness or low data activity.
LLDP	<p>Select for devices to advertise identities, status, and capabilities to each other.</p> <p>Devices can transmit data about themselves and receive transmitted data from other devices, but they cannot solicit and retrieve data from other devices.</p>
CDP	Select for devices to advertise an IP address that can send and receive SNMP traps.

Table 33: Wired Interfaces Settings (continued)

Field	Description
MCast Filter	Select to enable Multicast Rate Limiting on the interface for multicast/ broadcast traffic.
Multicast Rate Limit	Set the maximum rate (in Kbs) for incoming multicast traffic for the interface.

Related Links

[Wireless Interface Settings](#) on page 103

Configure Electronic Shelf Label Settings

Table 34: Electronic Shelf Label Settings

Field	Description
Server	The name of the server that manages Electronic Shelf Label (ESL) communication and data updates.
State	The current operational status of the ELS device.
Port Type	The network port type used for communication.
Native VLAN	The assigned VLAN ID.

Related Links

[Wireless Interface Settings](#) on page 103

Configure Wireless Device Credentials


Use device credentials to set up log in information for root or read-only administrators, change the name and password of the root admin, or add a read-only admin to an AP. Device-level credentials offer access to APs through Telnet, SSH, or console connections.

**Note**

At this level, you are making changes to the selected AP only. These changes always override the network policy configurations.

A root admin has complete privileges, which include the ability to add, modify, and delete other administrators, and to reset the configuration. A read-only admin can view settings but cannot add, modify, or delete them. You can require that an admin be prompted for a password before accessing high-level privileged CLI commands.

Use this task to configure wireless device credentials.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Device Credentials**.

4. For an **Administrator Account**, enter the **Admin Name** and **Password**.
Passwords should contain at least 8 characters, including at least one number, one special character, and one uppercase character.
5. For a **Read Only Administrator**, enter the **Admin Name** and **Password**.
Passwords should contain at least 8 characters, including at least one number, one special character, and one uppercase character.
6. Configure the **Primary CAPWAP Server** and **Secondary CAPWAP Server** connections.
You can select an existing CAPWAP server from the drop-down list, or select the add icon to define a new server.
7. Configure a **Shared Key for Authentication Passphrase**.
8. Select **Save Device Credentials**.
For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Configure Netdump](#) on page 108

[Configure Wireless Devices](#) on page 100

Configure Netdump

You must perform a full configuration update for each device on which you want to enable netdump.

If an AP or switch becomes non-responsive, you can enable it to automatically save a core dump file to a TFTP server on the network the next time it boots. You can provide this file to Support to assist in diagnosing the issue. To configure a device to save a core dump file to a TFTP server, complete the following steps:


1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Configuration** menu, select **Configure Netdump**.
4. Select the check box to **Enable Netdump**.
5. Configure the **Update Settings**.

Table 35: Netdump Update Settings

Field	Description
TFTP server for saving netdump files	The IP address of the TFTP server where you want the device to send the core file.
Netdump filename to save	The name of the netdump file.
VLAN for reaching the TFTP server	The VLAN of the interface the device will use to send the netdump file to the TFTP server.
Native VLAN of the local Extreme Networks device	The native VLAN of the device.

6. Select **DHCP** to have the device bootloader use DHCP to obtain an IP address at startup.

7. Select **Static** to use a static IP and configure the following network settings that the bootloader must use to connect to the network:

Table 36: Update Static IP Settings

Field	Description
Address of local Extreme Networks device	The IP address of the reporting device.
Netmask of local Extreme Networks device	The netmask for the reporting device.
Gateway for reaching the TFTP server	The IP address of the TFTP server.

8. Select **SAVE NETDUMP CONFIGURATION**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

The device will send a core dump file to the TFTP server the next time it reboots.

Related Links

[Configure DHCP Server and Relay Settings](#) on page 109

[Configure Wireless Devices](#) on page 100

Configure DHCP Server and Relay Settings

For small networks that do not already have a DHCP server, you can configure and enable a DHCP server on an Extreme Networks device to provide network settings dynamically to clients. After you configure one hive member as a DHCP server, the other hive members forward the DHCPDISCOVERY and DHCPREQUEST messages to their neighbors. The device you use as the DHCP server must be a portal.

When all hive members are in the same subnet and all devices in that subnet are on a single VLAN, you only need to configure the DHCP server device with a pool of IP addresses it can draw from when responding to DHCP client requests. When some hive members are in a different subnet from the DHCP server, you must also configure those devices to forward DHCP traffic to the IP address of the DHCP server. In this case, the other devices act as DHCP relay agents.

Use this task to configure both DHCP servers and relay agents.




1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Additional Settings** menu, select **DHCP Server and Relay**.
4. Select  to add or  to edit, and then configure the following settings:

Table 37: DHCP Server and Relay Settings

Field	Description
Name	A unique identifier for the DHCP configuration profile.
Description	A brief summary for the configuration profile.

Table 37: DHCP Server and Relay Settings (continued)

Field	Description
Platform Supported	The device models or operating systems the configuration is compatible with.
Interface	The network interface through which DHCP services are provided or relayed.
Service	Defines whether the device acts as a DHCP Server or Relay Agent. The DHCP relay enhancement supports deployments when a centralized DHCP server (for example, at corporate headquarters) is used. When you enable DHCP Relay, the DHCP server feature on devices is disabled so that routers redirect DHCP service requests to the centralized DHCP server


5. Enable or disable **Set the DHCP server as authoritative**.

If this DHCP server is the only one on your network, it contains a record of the valid IP numbers on the network. If a client tries to register with an invalid IP address (for example, if a client device still has an active lease with another network), an authoritative DHCP server denies access to that client.


6. Enable **Use ARP to check for IP address conflicts** when this DHCP server uses ARP to check for IP address conflicts on the network before assigning an IP address to a DHCP client.

7. Select **Enable NAT Support** if this DHCP server uses NAT.

8. For **IP Pool**, define the IP address pool from which the DHCP server draws IP addresses when making assignments.

- Select  to add a new IP pool.
- Enter the **Start IP Address** and **End IP Address**.
- Select **Add**.

9. For **IP Binding**

- Select  to add a new IP Binding.
- Enter the **IP Address** and **MAC Address**.
- Select **Add**.

10. To configure each of the required parameters that the DHCP server returns to clients along with an IP address, configure the [DHCP Server Options Settings](#) on page 111.

11. To define custom DHCP options to provide additional network settings to connected clients, see [Configure Custom DHCP Options](#) on page 111.

12. Select **Save**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Configure Neighboring Devices](#) on page 112

[Configure Wireless Devices](#) on page 100

DHCP Server Options Settings

Table 38: DHCP Server Options Settings

Field	Description
Default Gateway	The IP address of the default gateway for the subnet to which the address in the IP pool belong.
DNS Server1 IP	The primary DNS server IP address for the clients to contact when resolving domain names to IP addresses.
DNS Server2 IP	The secondary DNS server IP address for clients to contact when resolving domain names to IP addresses.
DNS Server3 IP	The tertiary IP address for clients to contact when resolving domain names to IP addresses.
POP3 Server IP	The POP3 server IP address.
SMTP Server IP	The SMTP server IP address.
WINS Server1 IP	The primary WINS server IP address.
WINS Server2 IP	The secondary WINS server IP address
Lease Time	The length of time for the DHCP lease to last.
Netmask	The subnet to which the addresses in the IP pool belong.
Domain Name	The DNS name resolution domain name to assign to DHCP clients.
MTU	The path MTU aging timeout in seconds.
NTP Server1 IP	The primary NTP server IP address for DHCP client clock synchronization.
NTP Server2 IP	The secondary NTP server IP address for DHCP client clock synchronization.
Log Server IP	The log server IP address for DHCP clients.


Related Links

[Configure DHCP Server and Relay Settings](#) on page 109

Configure Custom DHCP Options

Create or modify **DHCP Server and Relay settings**.

Use this task to define custom DHCP options to provide additional network settings to connected clients.

1. Select .
2. Enter a custom **Number** from 2 to 5, 8 to 14, 16 to 25, 27 to 41, 43, 45 to 50, 52 to 57, 60 to 68, 71 to 224, 227, 228, or 232 to 254.

3. Select the **Type** of data that the option provides:
 - **Integer:** (0-2,147,483,547)
 - **IP Address:** (Four octets for an IP address or eight groups of two octets each for an IPv6 address.)
 - **String:** (1-255 characters)
 - **Hex:** (1-254 hexadecimal digits)
4. Enter the **Value** for the data.
5. Select **Add**.


Related Links

[Configure DHCP Server and Relay Settings](#) on page 109

Configure Neighboring Devices

Roaming Threshold helps control the number of tunnels an AP can accept during layer 3 roaming operations.

Manually add a **Neighbor** to define a Hive neighbor in the case where the APs cannot hear over the air and they are in different management subnets (which is how they ordinarily learn of each other.) Bonjour Gateway piggybacks on this functionality to learn of APs in other management subnets that cannot be heard over the air.


1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Additional Settings** menu, select **Neighboring Devices**.
4. Select a **Roaming Threshold** value from the drop-down list to set the volume of traffic that the selected neighbors will accept through GRE (Generic Routing Encapsulation) tunnels to support Layer 3 roaming.

This option gives hive members the ability to push tunnels to other members for better tunnel load balancing. For example, if one AP near an entrance gets overloaded with tunnels, you can lower its threshold to medium or low so that more tunnels terminate on other APs.



Note

This setting only takes effect when the APs function as portals and Layer 3 roaming is enabled.

5. Select  to manually add a Layer 3 roaming or Bonjour gateway neighboring Extreme Networks device.
6. Select an **Available Neighbor** device from the drop-down list and select **Add**.



Note

You can add any or all of the Layer 3 roaming and Bonjour gateway neighboring Extreme Networks devices by repeating the previous two steps.

7. To remove a manually configured neighboring device, select a device, and then select .

8. Select **Save Neighboring Devices**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links


[Configure Bonjour Gateway Settings](#) on page 113

[Configure Wireless Devices](#) on page 100

Configure Bonjour Gateway Settings

Define Bonjour Gateway settings in the network policy.

Use this task to choose the wireless device you want to act as your Bonjour Gateway Designated Device (BDD) at the device level. If possible, use the newest model device you have in a low traffic area.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Additional Settings** menu, select **Bonjour Gateway Settings**.
4. Set the **Priority** for the wireless device you want to use as your BDD to around 250.
By default, every AP is set an automatic priority level (10-20) for the Bonjour service. The AP with the highest priority setting acts as the Bonjour Gateway. The MAC address is used if the priority is the same on all APs.
5. To modify the realm name, select **Override the default real name** and set the **Realm Name**.



Note

A realm name is automatically generated by placing this device on a map (the auto-generated name is the building name). Modifying the realm name here overwrites the auto-generated realm name.

6. Select **Save Bonjour Gateway Settings**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Push a complete configuration to the BDD, followed by a **Delta** update to all other APs.


Related Links

[Troubleshooting](#) on page 113

[Configure Wireless Devices](#) on page 100

Troubleshooting


Use this task to enable Client Monitor so devices can detect client issues, and report client connection activities and problems to Extreme Platform ONE Networking.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Additional Settings** menu, select **Troubleshooting**.
4. Toggle **Enable Client Monitor** to **On**.

5. Select  to configure a new Client Monitor Policy, see [Client Monitor Profile Settings](#) on page 114, and then click **Save**.

**Note**

Select the client monitor profile name to edit the profile.

6. Select  to select an existing client monitor policy.
7. Select **X** to use the SSID client monitor policy.
8. For wireless devices that support Dynamic Packet Capture, toggle **Enable Packet Capture** to **On**.

**Note**

If the AP model supports Dynamic Packet Capture, a small packet capture of the event is appended to the client monitor record. Dynamic Packet Capture is supported on the following models:

- AP3000, AP3000X, or AP5010 running 10.6.7 or higher
- AP5020 running 10.7.1 or higher
- AP4020 running 10.8.1 or higher

9. Select **Save Troubleshooting**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.

Related Links

[Configure SSH](#) on page 115

[Configure Wireless Devices](#) on page 100

Client Monitor Profile Settings

Table 39: Client Monitor Profile Settings

Field	Description
Name	Type a name to identify the Client Monitor Profile policy.
Association Problem	
Trigger Times	Set the number of times an association problem can be triggered, between 1 and 10.
Report Interval	Set the interval between reporting an association problem, between 30 and 3600 seconds.
Authentication Problem	
Trigger Times	Set the number of times an authentication problem can be triggered, between 1 and 10.
Report Interval	Set the interval between reporting an authentication problem, between 30 and 3600 seconds.
Networking Problem	

Table 39: Client Monitor Profile Settings (continued)

Field	Description
Trigger Times	Set the number of times a network problem can be triggered, between 1 and 10.
Report Interval	Set the interval between reporting a network problem, between 30 and 3600 seconds.

Related Links

[Troubleshooting](#) on page 113

Configure SSH


Before you can configure SSH access on a device, you must first enable **SSH Availability**. To do this, go to **Administration & Settings > Backup & Restore > VIQ Management** and toggle **SSH Availability** to **ON**.

Extreme Platform ONE Networking provides a way to access devices remotely using the SSH protocol by using an SSH proxy server.

**Note**

It is important to remember that while SSH access is available, your device is exposed to public access through an SSH proxy. The device is protected only by the device administrator credentials, because SSH FTP assumes that it is run over a secure channel.

Use this task to enable SSH on a wireless device.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Under the **Additional Settings** menu, select **SSH**.
4. Under **Run Time**, select the length of time that you want SSH to be available for the device.

Extreme Platform ONE Networking creates an SSH session for the specified length of time between the SSH proxy server and the device.

5. Select **Enable SSH**.

Provide assisting technicians with the onscreen instructions and device log in credentials so they can open a session from their external SSH client to the specified IP address and port number of the proxy server.

6. When they are finished, select **Disable SSH**.

The SSH session remains active for another minute or so and then automatically closes. If more time is required, enable a new SSH session.

Related Links

[Configure Wireless Devices](#) on page 100




Override Supplemental CLI

Before you can configure Supplemental CLI access on a device, you must first enable Supplemental CLI. Go to **Administration & Settings > Backup & Restore**, and then enable **Supplemental CLI**.

You can save supplemental CLI objects that contain CLI commands and then automatically update devices each time you update the network policy. On the **Device** page, you can keep the supplemental CLI object in the network policy and append another supplemental CLI object to the end of the running configuration list. If the supplemental CLI is appended to the delta configuration and the supplemental CLI portion fails device update, only the supplemental CLI regenerates for subsequent device updates.

If you use CLI to manage features that are not configured in the user interface, you can choose to override the user interface (or to override the CLI), benefiting deployments that rely on overly complex CLI objects.

Use this task to override supplement CLI from network policy supplement CLI.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Select **Override Supplement CLI from network policy Supplement CLI**.
4. Select an existing supplemental CLI object, or select  to add, or  to edit a supplemental CLI object. For more information, see [Add a Supplemental CLI Object](#) on page 116.
5. Select **Save Configuration**.

For more information about how to push updated configuration to the device, see [Push Device-Level Configuration](#) on page 118.



Note

To avoid an unnecessary system reboot, select **Delta Configuration Update**. Extreme Platform ONE Networking attempts to update only the configuration deltas. If a full update is required, the system prompts you to select **Complete Configuration Update**. Examples of CLI commands that require a full configuration update are: **system antenna-type** and **system environment**.

Related Links

[Add a Supplemental CLI Object](#) on page 116

Add a Supplemental CLI Object

Before you can use the supplemental CLI tool, you must first enable Supplemental CLI. Go to **Administration & Settings > Backup & Restore**, and then enable **Supplemental CLI**.




You can save supplemental CLI objects containing CLI commands, and Extreme Platform ONE Networking can then automatically update them for devices, each time you update the network policy.



Note

- Limit CLI commands to configuration commands. Exclude **Show** or other commands used to display information.
- Do not use supplemental CLI commands to configure any settings set via the Extreme Platform ONE Networking GUI as that creates a configuration sync conflict that results in future **Device Update Failed** errors.
- These commands work as a delta mechanism. Every new supplemental CLI update must only include new commands that you want to run, not ALL commands that you want to have present on the device at start up. Re-running some commands after already applied can cause future **Device Update Failed** errors.

Use the following task to create CLI objects.

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Go to **Configure > Common Objects > Basic > Supplemental CLI Objects**.
4. Select **Override Supplement CLI from network policy Supplement CLI**.
5. To add a new supplemental CLI object, or select  to add, or  to edit.
6. Enter a **Name** and an optional **Description**.
7. Enter the CLI commands.
 - Enter multiple CLI commands, one command per line, not exceeding a maximum total of 8192 characters. Limit CLI commands to configuration commands. Exclude Show or other commands used to display information.
 - You can use CLI commands that contain IP and VLAN objects: **\$ {ip:ip_object_name}** and **\${vlan:vlan_object_name}**.
 - You must perform a complete configuration update each time commands are appended to device configurations.
 - If supplemental CLI is added to device-level configuration, then device-level supplemental CLI takes precedence.
8. Select **SAVE** and perform a configuration update each time you append commands to device configurations.



Note

To avoid an unnecessary system reboot, select **Delta Configuration Update**. Extreme Platform ONE Networking attempts to update only the configuration deltas. If a full update is required, the system prompts you to select **Complete Configuration Update**. Examples of CLI commands that require a full configuration update are: **system antenna-type** and **system environment**.

Related Links

[Override Supplemental CLI](#) on page 116

Push Device-Level Configuration

1. Go to **Monitoring > Network Devices > Device Status**.
2. Select  at the end of a device row, and then select **Configure > Device**.
3. Select **Update** and configure the **Device Update** settings for the selected device.

Table 40: Update Wired Device Settings

Field
Update Network Policy and Configuration
Reboot and revert Extreme Networks switch configuration if IQAgent is unresponsive after configuration update.
Perform delta configuration update and resolve local device configuration which is out of sync with Extreme Platform ONE Networking.

Table 41: Update Wireless Device Settings

Field	
Update Network Policy and Configuration	
Delta Configuration Update	Updates only the device delta configuration changes for the selected device. This action avoids a device reboot.
Complete Configuration Update	A full update for the selected device. This resets the selected device to Extreme Platform ONE Networking configuration settings. Note: Only supported on devices running HOS or IQE Firmware.
Activation Time for Extreme Networks Devices Running Images:	
Activate at next reboot (requires rebooting manually)	Activation takes affect the next time the AP is rebooted.
Activate after xx seconds	The delay before activation, in seconds.
Activate/reboot on this schedule based on your local system time	Schedule a Date and Time to activate.

4. To update the selected device immediately, select **Perform Update**, or select **Save as Defaults** to keep these settings for future use.

Device Status Icons

Table 42: Device Status Icons





Icon	Icon Name	Description
	AFC Status	Indicates an AFC issue with the selected device. Status options include Pending , Grace Period , and Spectrum Mismatch .
	Anchor AP	Device is set as an anchor.
	Configuration at Device Level	Device possesses a device-level configuration that is different from the configuration defined in the network policy. This is not an error condition, but this information can be useful when troubleshooting network behavior because device-level configurations supersede device templates and network policy configurations.
	Configuration Audit Match	<p>The network policy configuration matches the current running configuration.</p> <p>Select the icon to open a pop-up window detailing the configuration changes that occurred since the last Update Devices operation.</p> <ul style="list-style-type: none"> • Audit tab — lists any modifications made since the previous configuration update. • Delta tab — shows CLI commands that have changed since the previous update. • Complete tab — shows all CLI commands (including the CLI commands in the Delta tab) that form a configuration file. ExtremeCloud IQ uses this file for the next configuration update. After a successful configuration update, the configuration in the Complete tab matches the running configuration. <p>Note: Not applicable for locally managed switches.</p>

Table 42: Device Status Icons (continued)







Icon	Icon Name	Description
	Configuration Audit Mismatch	<p>The network policy configuration does not match the current running configuration.</p> <p>Cause: The Configuration Audit Mismatch icon is visible on devices between the time that network policy changes are saved and the time that the altered network policy is uploaded to the device.</p> <p>Action: Upload the network policy to the device.</p> <p>Select the icon to open a pop-up window detailing the configuration changes that occurred since the last Update Devices operation. See the Configuration Audit Match icon description for details.</p> <p>Note: Not applicable for locally managed switches.</p>
	Configured at Device Level	Device possesses a device-level configuration that is different from the configuration defined in the network policy. This is not an error condition, but this information can be useful when troubleshooting network behavior because device-level configurations supersede device templates and network policy configurations.
	Configuration Pending	Device is currently offline and will receive its latest assigned configuration once it reconnects to the network.
	Configuration Rollback	Device could not establish a connection to ExtremeCloud IQ after the configuration update. Device configuration rolled back to the last known good connection and the Updated status column displays <i>Device update failed</i> .
	Connected Device	Device is actively communicating with Extreme Platform ONE Networking.
	Device Update Unsuccessful	<p>Device did not accept the OS or configuration upload.</p> <p>Cause: There are many reasons for an unsuccessful update, but the most common include network connectivity or connection status changes, or the device rejected the command it received.</p> <p>Action: Hover over the update message in the Updated column to view the reason message describing the likely error condition. Ensure that the device is properly powered, that there is appropriate network connectivity, and that common causes listed here are not the issue.</p>

Table 42: Device Status Icons (continued)








Icon	Icon Name	Description
	Digital Twin	Device is a simulated device.
	Disconnected Device	<p>Device is not actively communicating with Extreme Platform ONE Networking.</p> <p>Cause: The device might be physically disconnected from the network or powered off. This condition also occurs if there are interruptions in the network between the device and Extreme Platform ONE Networking or when there are misconfigured firewalls or ACL rules.</p> <p>Action: Ensure the device is connected to the network and powered on and ensure that communication can occur through logical barriers such as firewalls.</p>
	ExtremeCloud Appliance Cluster (Closed)	Device is a logical cluster of appliances, but the cluster is collapsed visually to appear as a single device.
	ExtremeCloud Appliance Cluster (Open)	Device is a logical cluster of appliances, but the cluster is expanded visually to reveal the cluster members.
	Fabric Attach	Device is a member of the Fabric Attach Connect Automation environment and is functioning properly in that context.
	Fabric Attach Issue	<p>Device is Fabric Attach capable, but the Fabric Attach (FA) session to the FA server is not established.</p> <p>Cause: This can occur if the communication link between the FA device and server is disrupted or if FA is disabled on the peer switch.</p> <p>Action: Ensure that there is connectivity between FA device and server, and that FA server functionality is enabled on the peer switch.</p>
	Locally Managed (ExtremeCloud IQ)	Device is managed by a platform other than ExtremeCloud IQ, but it is monitored by ExtremeCloud IQ. For example, other platforms can include 3rd party, ExtremeCloud IQ Site Engine, or ExtremeCloud IQ Controller.

Table 42: Device Status Icons (continued)










Icon	Icon Name	Description
	Locally Managed (No ExtremeCloud IQ)	Device or its management platform are not visible in ExtremeCloud IQ. Cause: This is not always an error condition, but it can indicate a status communication problem. In this case, the device is functioning properly, so there is no disruption in network performance; instead, the status communication is disrupted so that ExtremeCloud IQ is unaware of the status. Action: First, ensure that the device is functioning properly to rule out problems with the device. Next, ensure that there are no logical barriers between the device and ExtremeCloud IQ. Afterward, ensure that any applications that lie in the communication path are receiving, processing, and sending data appropriately.
	Managed by ExtremeloT	Device is provisioned to function with ExtremeloT.
	Monitoring Unassociated Clients	Device is using presence analytics to monitor client devices that are not associated to the network, such as passersby.
	No Connection	This device has not yet made a connection with Extreme Platform ONE Networking. It can take up to 10 minutes for a device to appear after the initial onboarding process. If the device has not successfully connected after 10 minutes.
	Old OS Personality Inactive	Device formerly used another OS persona, which is no longer active. The information in this record pertains to the device when it ran using this OS persona.
	RadSec Proxy Server	Device is acting as a RadSec proxy server. This service optimizes some authentication functions, especially for cloud authentication, such as cloud PPSK and cloud RADIUS.
	Rogue AP Mitigation	Device is actively mitigating a rogue access point. Refer to the information provided by your security management platform.
	Sensor Mode - Interface Active	Device is functioning as a sensor and the monitoring interface is active and monitoring the RF environment.
	Sensor Mode - Interface Inactive	Device is functioning as a sensor, but the monitoring interface is not active and is not monitoring the RF environment.

Table 42: Device Status Icons (continued)








Icon	Icon Name	Description
	Simulated Device	Device is a simulated device, which possesses only simulated configurations, conditions, and traffic. By contrast, a real device has a physical presence on the network and consumes power and network resources.
	Spectrum Intelligence	Device is functioning as a Spectrum Intelligence monitor, which monitors the RF environment and provides frequency and time domain graphs and heat maps.
	Swap for Real Device	Device is a simulated device that you can exchange for a real device.
	Switch Stack	Device is a switch stack.
	Switch Stack Warning	<p>One or more stack member switches is not associated to the master stack node.</p> <p>Cause: One or more member switches within a stack has lost connectivity to the master stack node. This can happen if the member switch is powered off, physically disconnected from the stack, or if there is an issue with the switch itself.</p> <p>Action: Ensure that the switch slot has power and that the stacking cables are properly connected.</p>
	Thread Commissioner Running	The AP is designated Commissioner in the IoT Thread network.
	Undetermined	<p>Device status is undetermined.</p> <p>Cause: This condition can arise when the indicators are ambiguous, unknown, or appear contradictory due to other factors.</p> <p>Action: Begin general troubleshooting procedures to ensure that the device is powered, connected, and is responding to traffic and CLI commands. Ensure that the device is communicating appropriately with network services, such as NTP, DHCP, etc.</p>

Table 42: Device Status Icons (continued)







Icon	Icon Name	Description
	VPN Client Server Tunnels Down	<p>Device is functioning as a VPN client, but the VPN tunnel is down. If the tunnel is administratively down, then this is not an error condition.</p> <p>Cause: If not administratively down, issues on the server side can cause the tunnel to go down. Additionally, if the client- and server-side configuration do not agree, then a tunnel cannot be built.</p> <p>Action: Consult the VPN troubleshooting tools in Extreme Platform ONE Networking. You can also ensure that the server device is connected to the network and that the tunnel configurations agree on both ends of the tunnel.</p>
	VPN Client Server Tunnels Up	<p>Device is functioning as a VPN client and the VPN tunnel is up, healthy, and operating properly.</p>
	VPN Client Server Tunnels Up and Down	<p>Some of the VPN client tunnels are administratively up but operationally down.</p> <p>Cause: VPN server might be down, or unreachable.</p> <p>Action: Ensure that the VPN server is powered on, connected to the network, and communicating with Extreme Platform ONE Networking. In addition, ensure that there is connectivity and communication between the VPN server and client.</p>
	VPN Server Turned Down	<p>Device is functioning as a VPN server, but the VPN tunnel is down. If the tunnel is administratively down, then this is not an error condition.</p> <p>Cause: If not administratively down, issues on the client side can cause the tunnel to go down. Additionally, if the client- and server-side configuration do not agree, then a tunnel cannot be built.</p> <p>Action: Consult the VPN troubleshooting tools in Extreme Platform ONE Networking. You can also ensure that the client device is connected to the network and that the tunnel configurations agree on both ends of the tunnel.</p>

Table 42: Device Status Icons (continued)

Icon	Icon Name	Description
	VPN Server Turned Up	Device is functioning as a VPN server and the VPN tunnel is up, healthy, and operating properly.
	VPN Server Turned Up and Down	Some of the VPN server tunnels are administratively up but operationally down. Cause: VPN client might be down, or unreachable. Action: Ensure that the VPN clients are powered on, connected to the network, and communicating with Extreme Platform ONE Networking. In addition, ensure that there is connectivity and communication between the VPN server and clients.

Device Health

Go to **Monitoring > Network Devices > Device Health**.



Note

To download the table data as a CSV file, select .

Wired

Select **Wired** to filter a list of wired devices.

When **Show Summary** is enabled, health widgets display Summary, CPU Usage Issues, Memory Usage Issues, PoE Usage Issues, Temperature Issues, Fan Issues, and Power Supply Issues.

The Wired table displays the following information:

- Device *
- Location
- CPU Usage %
- Memory Usage %
- PoE Usage %
- Temperature°C
- Fan Status *
- Power Supply *

* Select to view additional details.

Wireless

Select **Wireless** to filter a list of wireless devices.

When **Show Summary** is enabled, health widgets display Summary, CPU Usage Issues, Memory Usage Issues, and PoE Usage Issues.

The Wireless table displays the following information:

- Device *
- Location
- CPU Usage %
- Memory Usage %
- PoE Usage
- Channel Change
- WiFi Reboots
- Unicast/Multicast/Broadcast
- Eth 0%
- Eth 1%

* Select to view additional details.

Usage & Capacity

Go to **Monitoring** > **Network Devices** > **Usage & Capacity**.



Note

To download the table data as a CSV file, select .

Wired

Select **Wired** to filter a list of wired devices.

When **Show Summary** is enabled, usage and capacity widgets display Usage Utilization, Wired Throughput, and Wire Congestion.

The Wired table displays the following information:

- Device *
- Location
- Clients
- Total Bandwidth Utilized (Bytes)
- Total Throughput (Rx Packets per Second)
- Total Throughput (Tx Packets per Second)
- Total Unicast (Packets %)
- Total Multicast (Packets %)
- Total Broadcast (Packets %)
- Total Queue Congestion (# of Packets)

* Select to view additional details.

Wireless

Select **Wireless** to filter a list of wireless devices.

When **Show Summary** is enabled, usage and capacity widgets display Excessive Channel Utilization, Excessive Retries, and Excessive Packet Loss.

The Wireless table displays the following information:

- Device *
- Location
- Clients
- MAC Address *
- Packet Loss %
- Channel Utilization %
- Retries
- Unicast/Multicast/Broadcast
- Noise (dBm)
- Interference %

* Select to view additional details.

Onboard Network Devices


Devices can be onboarded to the network using one of the following methods:

- **Manual:** Manually add up to 10 serial numbers from the same platform family.
- **Bulk:** Bulk onboard multiple devices using a CSV file that contains device serial numbers.

Use this task to onboard devices to your network.

1. Select **Onboard**.
2. Configure the applicable Onboard Device Settings.

Table 43: Onboard Device Settings

Field	Description
Manual	
Cloud or Locally	Select option.
Device OS	Select a device type.
License Level	Select the license level.
Network Policy (Optional)	Assign the device to an existing network policy.
Location (Optional)	Assign the device to an existing location.
Select Next .	
Serial No.	Enter a device serial number. Select  to add additional serial numbers. You can add up to 10 serial numbers from the same platform family.
Select Next .	
Generate a Formatted Hostname	Enable the toggle.
Bulk	
Network Policy (Optional)	Assign the device to an existing network policy.
Location (Optional)	Assign the device to an existing location.
Upload File	Select Browse Files or drag and drop a CSV file containing device serial numbers. Note: Supports .xlsx files only.

3. Select **Onboard**.

Update Network Device Firmware

Use this task to update firmware for selected devices.



Note

Select **1** to view **Firmware Update History**.

1. Select **Update Firmware**.
2. Select a **Device Type** and **Device Management**.



Note

You can filter the device list by using the **Search** field to quickly locate specific devices.

3. Select the devices for firmware update, and then select **Next**.
4. Select a **Firmware Version** for each device, and then select **Next**.
5. Confirm the **Review Summary**, and then select a **Firmware Update Schedule**:
 - To update immediately, select **Update Now**, and then select **Update Firmware**.

Device View

The device view provides a comprehensive overview of the selected device's specifications and current status.

Select a **Device** name from the table. The **Device Details** window displays detailed information for the [Wired](#) or [Wireless](#) device.

Select **Actions** to perform specific tasks on the selected device. For more information, see [Device Actions Menu](#) on page 139.

Wired Device View

The **Wired** device view provides a streamlined interface for reviewing device details. Allowing quick access to essential device-specific information, including:

- Connection Status
- Device Image
- Device Location
- [VLAN Probe](#)
- Installation Media Gallery: Select to upload an image (.png or .jpg less than 500KB) or video (.mp4 or .mov less than 5MB) file.
- Device Details
 - [Overview](#)
 - [Clients](#)
 - [Port Stats](#)
 - [Services/VLANs](#)

- [Routing](#)
- [Events](#)

**Note**

To narrow the time frame, select the **Date & Time Range**, select a **Start Date** and **End Date**, select a **Start Time** and **End Time**, and then select **Done**. Select **Reset to Default** to reset back to the default time frame.

Select **Actions** to perform specific tasks on the selected device.

Overview

Overview displays the following information about the selected device:

- **Device Health** widgets display CPU Usage, Memory Usage, Resource Utilization, and PoE Usage.
- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce
 - PoE Bounce
 - Cable Test
- From the interactive timeline graph:
 - View and filter **Total CPU Utilized** and **Total Memory Utilized**.
 - Select any point along the timeline in the graphic to display details only for that precise time. To customize the time period for graphs, drag inside the timeline. The chart lines are interactive—hover over a line to see more data.
 - Select ≡ to:
 - View in full screen
 - Print chart
 - Download PNG image
 - Download JPEG image
 - Download PDF document
 - Download SVG vector image
- Device widgets display **Usage Utilization**, **Client Health**, and **Wired Throughput**.

Clients


Clients displays the following information about the selected device:

- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce
 - PoE Bounce
- Device widgets display **IP Connectivity Issues**, **Port Congestion**, **Traffic Anomalies**, and **Port Errors**.

- The Client table displays the following information:
 - Port Number
 - Client
 - MAC
 - Operating System
 - IPv6
 - VLAN

Port Stats

Port Stats displays the following information about the selected device:

- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce
 - PoE Bounce
 - Cable Test
- From the interactive timeline graph:
 - View and filter **Total TX/RX Utilization Pkts, Total TX/RX Throughput Bbps, Total TX/RX Unicast Pkts, Total TX/RX Broadcast Pkts, Total TX/RX Multicast Pkts, and Total Errors.**
 - Narrow the time frame. Select the **Date & Time Range**, select a **Start Date** and **End Date**, select a **Start Time** and **End Time**, and then select **Done**. Select **Reset to Default** to reset back to the default time frame.
 - Select any point along the timeline in the graphic to display details only for that precise time. To customize the time period for graphs, drag inside the timeline. The chart lines are interactive—hover over a line to see more data.
 - Select  to:
 - View in full screen
 - Print chart
 - Download PNG image
 - Download JPEG image
 - Download PDF document
 - Download SVG vector image
- Device widgets display **Usage Utilization, Wired Throughput, and Wired Congestion.**
- The **Port Description** table lists the following details:



Note

You can use the **Search** field to filter the table view.

- The tables list the following details:

Ports Description:

- Port Number
- Operational Status
- LLDP Neighbor
- STP Port State

- MAC Locking
- Media Type
- Transmission Mode
- Link Speed

Port Stats Summary:

- **% Utilization**
 - Port Number
 - % Utilization Rx
 - % Utilization Tx
 - % Utilization MaxRx
 - % Utilization MaxTx
- **In/Out Statistics**
 - Port Number
 - InOctets
 - OutOctets
 - InUcastPkts
 - OutUcastPkts
 - InBroadcastPkts
 - OutBroadcastPkts
 - InMulticastPkts
 - OutMulticastPkts
 - Port Queue Congestion Count
- **Errors**
 - Port Label
 - Port Number
 - Port Name
 - Total Aggregated Port Errors Counter

Link PoE:

- Port Number
- Power Consumed per port, mW



Note

You can use the **Search** field to filter the table view.

Services/VLANs

Services/VLANs displays the following information about the selected device:

- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce
 - PoE Bounce
 - Cable Test
- A table lists the following details about the clients that are connected during the specified time range:
 - VLAN Id
 - VLAN Name
 - Total Active Access Ports

- Total Active Tagged Ports
- STP Instance




Note

You can use the **Search** field to filter the table view.

Routing

Routing displays the following information about the selected device:

- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce
 - PoE Bounce
 - Cable Test
- From the interactive timeline graph:
 - View and filter **Total Routes**, **Direct Routes**, **Static Routes**, and **OSPF Routes**.
 - Narrow the time frame. Select the **Date & Time Range**, select a **Start Date** and **End Date**, select a **Start Time** and **End Time**, and then select **Done**. Select **Reset to Default** to reset back to the default time frame.
 - Select any point along the timeline in the graphic to display details only for that precise time. To customize the time period for graphs, drag inside the timeline. The chart lines are interactive—hover over a line to see more data.
 - Select  to:
 - View in full screen
 - Print chart
 - Download PNG image
 - Download JPEG image
 - Download PDF document
 - Download SVG vector image
- A table lists the following details:

◦ Destination	◦ Route Origin
◦ Next Hop	◦ Status
◦ VLAN Name	◦ Metric
◦ VLAN Id	



Note

You can use the **Search** field to filter the table view.

Events

Events displays the following information about the selected device:


- From the Port Configuration diagram, select individual ports or enable **Select All Ports** to reveal the following options:
 - Port Bounce

- PoE Bounce
- Cable Test
- A table lists the following details:
 - Timestamp
 - Severity
 - Category
 - Description



Note

You can use the **Search** field to filter the table view.

- From the interactive timeline graph:
 - View and filter **Critical, Major, Minor, info,** and **Clear**.
 - Select any point along the timeline in the graphic to display details only for that precise time. To customize the time period for graphs, drag inside the timeline. The chart lines are interactive—hover over a line to see more data.
 - Select  to:
 - View in full screen
 - Print chart
 - Download PNG image
 - Download JPEG image
 - Download PDF document
 - Download SVG vector image

Wireless Device View

The **Wireless** device view provides a streamlined interface for reviewing device details. Allowing quick access to essential device-specific information, including:

- Connection Status
- Device Image
- Floor Map (if available)
- Device Location
- Installation Reports
- Installation Media Gallery: Select to upload an image (.png or .jpg less than 500KB) or video (.mp4 or .mov less than 5MB) file.
- [Actions](#) on page 134
- [Overview](#) on page 137
- [Wireless Interface](#) on page 137
- [Wired Interface](#) on page 138

- [Clients](#) on page 138
- [Alerts](#) on page 138



Note

To narrow the time frame, select the **Date & Time Range**, select a **Start Date** and **End Date**, select a **Start Time** and **End Time**, and then select **Done**. Select **Reset to Default** to reset back to the default time frame.

Select **Actions** to perform specific tasks on the selected device.

Actions

From the **Actions** menu you can perform the following actions for the selected device:

- [Reboot](#) on page 134
- [Reset Factory Settings](#) on page 134
- [Upgrade Firmware](#) on page 134
- [Locate](#) on page 135
- [VLAN Probe](#) on page 136

Reboot

To restart a connected device, select **Reboot**, and then select **Yes** to confirm. Restarting momentarily disconnects any connected clients.



Note

The current configuration will not be saved before the reboot.

Reset Factory Settings

To reset the selected device to their default configuration, select **Reset Factory Settings**, and then select **Yes** to confirm.



Important

This operation removes existing settings from the selected device and returns it to factory settings. It then reconnects to the cloud as a new device.

Upgrade Firmware



Use this task to manually upgrade firmware for a selected device.

1. Select **Upgrade firmware**.
2. In the **Device Update** dialog box, select an update type.

Table 44: Update AP Device Settings

Field	Description
Upgrade IQ Engine and Extreme Network Switch Images:	
Upgrade to the latest version	Upgrade to the latest firmware version.

Table 44: Update AP Device Settings (continued)

Field	Description
Upgrade to the specific version	<p>Select a Model to upgrade, and then select the Version to upgrade to from the drop-down list.</p> <p>To add a new version (local image), select Add/Remove:</p> <ul style="list-style-type: none">To add a new local image, select , and then select Choose to upload an image file from your computer. <p>Note: The format for an image file name must be *.stk, *.xos, *.voss *.tgz, *.img, or *.img.S. The file name cannot contain spaces and must not exceed 64 characters.</p> <ul style="list-style-type: none">To delete an existing local image, select an image, and then select .Select Close. <p>Select View Release Notes to access the Online Help system and see the latest release notes.</p>
(Optional) Upgrade even if the versions are the same	Enforce an upgrade to the same version as the current version.
(Optional) Enable distributed image upgrade (APs only)	Designate the AP as the server to download the firmware image. This AP then distributes the firmware to other APs in the network.
Activation Time for Extreme Networks Devices Running Images:	
Activate at next reboot (requires manual reboot)	Activation takes affect the next time the AP is rebooted.
Activate after xx seconds	The delay before activation, in seconds.

3. To update the select device immediately, select **Update**, or select **Save as Default** to keep these settings for future use.

Locate

Use this task to locate the physical location of a selected device.

1. Select **Locate**, and then configure the **Locate Device** settings.

Table 45: Locate Device Settings

Field	Description
LED Color	Select one of the following blinking light colors to set the color that the locator light will flash to help you find the AP: <ul style="list-style-type: none">• Amber• White• Off
Blink Mode	Select one of the following blinking modes to set the speed at which the locator light will flash to help you find the AP: <ul style="list-style-type: none">• Fast• Slow• Steady



Note

Select **Return to Standard LED operations**, and then select **Submit**, to stop the blinking lights used for locating the device.

2. Select **Submit**.

VLAN Probe

The VLAN probe action locates available VLANs for the selected device. When the VLAN probe is complete, a table shows the host name, MAC address, available VLANs, unavailable VLANs, and their status.



Note

The VLAN Probe Utility is also available from the **Device List** for a connected device.

Use this task to verify the VLAN probe results and status of VLAN for selected device.

1. Select **VLAN Probe**, and then configure the VLAN Probe settings.

Table 46: VLAN Probe Settings

Field	Description
VLAN Range	The start and end VLAN Range to probe. You can enter up to five ranges separated by commas, up to a total range of 12. However, range numbers cannot overlap. For example, 1, 2-7, 8, 8-12.
Timeout	The timeout from 5 to 60 seconds to specify how long to wait for a reply from each probe.
Probe Retries	The number of attempts made to send a probe to verify the status of a VLAN. Note: Probe retries is not supported for switch devices.

2. Select **Start** to start a probe.
3. Select **Stop** to stop a probe before it is complete.

Overview

Overview displays the following information about the selected device:

- At the top of the page, the **Connection Chain** diagram shows how the device connects to the internet and to Extreme Platform ONE Networking.
- The following widgets appear below the connection chain diagram:
 - Device Health
 - Connectivity Issues
 - Excessive Packet Loss



Note

The selected time period applies to the widgets as well as the connection chain diagram.

- System Information for the selected device.

Wireless Interface

Wireless Interface provides the following information about the selected wireless device:

- An interactive timeline graph displaying channel utilization and connected clients. Select a **Radio** (Wi-Fi 0, Wi-Fi 1, or Wi-Fi 2) and **Filter by** Channel Utilization % and Connected Client.
- Summary information tables for **Wi-Fi 0**, **Wi-Fi 1**, and **Wi-Fi 2**.
- **Channel Utilization Interface** widgets.
- The **Surrounding Access Points** table provides details about surrounding APs.

Wired Interface

Wired Interface provides the following interface details about the selected wireless device:

- Status
- Interface
- Port
- Speed
- Tx Bytes
- Rx Bytes
- Tx Errors
- Rx Errors
- Tx Drops
- Rx Drops

Clients

Clients provides the following information about the selected wireless device:

- An interactive timeline graph shows the number of clients connected to the current device, for the specified time frame. By default, the data capture time frame is 24 hours.

You can select any point along the timeline in the graphic to display details only for connected clients at that precise time. To customize the time period for graphs, drag inside the timeline. The chart lines are interactive—hover over a line to see more data.

- **Client Statics** displays the following widgets:
 - Total Clients within selected time range: Displays the number of clients.
 - Clients with poor health: Displays the number of clients.
 - Total Unique Clients: Displays
- A table lists the following details about the clients that are connected during the specified time range:
 - Connection Status
 - Client
 - Site
 - SNR
 - RSSI
 - Frequency
 - Channel Utilization %
 - Association Issues
 - Authentication Issues



Note

You can use the **Search** field to filter the table view.

Alerts

Alerts provides the following information about the selected wireless device:

- An interactive graph shows the number of alerts raised on the current device, for the specified time frame. By default, the data capture time frame is 24 hours.

To customize the graph, select any **Source** from the list (Critical Alerts, Warning Alerts, and Information Alerts).

- The **Alerts by Severity** widget displays the total number of **Alerts Raised** for the specified time range, with the colored bands of the arch and color-matched beads below it representing refinements on the basis of **Severity**, as follows:
 - Critical
 - Warning
 - Info
- A table lists the following alert details during the specified time range:
 - Alert Name
 - Category
 - Summary
 - Source
 - Severity
 - Timestamp
 - Status

**Note**

Select  to export filtered alerts.

**Note**

You can use the **Search** field to filter the table view.

Device Actions Menu

In **Network Devices > Device Status**, select a device to display a list of available actions.

From the **Actions** menu, you can perform the following tasks on a selected device:

- **Reboot:** Restart the selected device. Select **Yes** to confirm.
- **Reset to Default/Reset Factory Setting:** Reset the device to factory defaults. Select **Yes** to confirm.

**Important**

This operation removes existing settings from the selected device and returns it to factory settings. It then reconnects to the cloud as a new device.

- **Upgrade Firmware:** Upgrade device firmware. Select a **Firmware Version**, and then select **Upgrade Firmware**.
- **Locate:** Locate the physical location of the selected device. Set an **LED Timeout**, and then select **Submit**.

**Note**

To stop the blinking lights used for locating the device, select **Return to Standard LED operations**, and then select **Submit**.

- **VLAN Probe:** Locate available VLANs for the selected device. Configure the VLAN Probe settings, and then select **Start**. To stop a probe before it is complete, select **Stop**.
- **Assigned Location:** Assign a location to the selected device. Select a location, and then select **Submit**.
- **Configure Device:** Configure the selected device. See, [Device Management Overview](#) on page 90.

Clients

The **Overview** tab on **Clients** page provides an overview of wired and wireless clients and users. You can filter the client list for the selected site.

Overview

The **Overview** tab on **Clients** page provides an overview of wired and wireless clients and users. You can filter the client list for the selected site.

In the **Wired** section, enable **Show Summary** to display the following widgets:

- IP Connectivity Issues
- Port Congestion
- Traffic Anomalies
- Port Errors

The Wired table displays the following information:

- Connection Status
- Client
- Location
- IPv4
- Port Number
- VLAN
- Default Gateway
- Clients
- MAC
- Username
- Instant Port Profile
- Total Congestion
- Total Unicast
- Total Multicast
- Total Broadcast
- Total Port Errors
- IPv6

In the **Wireless** section, when **Show Summary** is enabled, widgets display Connectivity Issues, Roaming Issues, and Frequency Distribution.

The Wireless table displays the following information:

- Connection Status
- Client
- Location
- SNR
- RSSI

- Frequency
- Airtime %
- Association Issues
- Network Issues
- Roaming Issues
- IPv4
- Connected To
- SSID
- VLAN
- Last Session Start Time
- Operating System
- MAC
- Username
- Authentication
- Encryption
- User Profile
- Alias
- Category Assignment
- IPv6
- Client Retries
 - Tx Retries
 - Rx Retries

Client Trail

The **Client Trail** tab on the **Clients** page provides an view of the following:

- Roaming Trail
 - Timestamp
 - From
 - To
 - Roam Duration
 - Status
- Connectivity Experience
 - Timestamp
 - AP Name
 - SSID
 - Association
 - Authentication
 - DHCP

Troubleshooting

The **Troubleshooting** tab on the **Clients** page provides an view of the **Troubleshooting Sessions**. The table displays the Timestamp, Description, Initiated by, and Status.

Client Actions

From the Actions menu on the **Client Overview** tab, you can complete the following actions:

- [VLAN Probe](#) on page 136
- [Troubleshoot Connectivity](#) on page 142
- [Disconnect Client](#) on page 142

Troubleshoot Connectivity

Use this task to troubleshoot client connectivity.

1. Go to **Actions > Troubleshoot Connectivity** and configure the settings.


Field	Description
Selected Client	Shows selected client.
Description (Optional)	You can add a description.
Select APs from the list below	Search for a specific client or select a client from the list.

2. Select **Start**.

Disconnect Client

Use this task to disconnect a client.

1. Go to **Actions > Disconnect Client**.
2. To temporarily disconnect the select client, select **Yes**.



Configuration | Sites

[Sites](#) on page 143

Use **Sites** to plan your network by adding locations, buildings, and floors. Place simulated devices to determine where you might need to add or redistribute devices for the best wireless network capability.

Sites

The Visualize view leverages site groups and site hierarchy in Extreme Platform ONE Networking for creating groups during the device onboarding process. The site groups and sites appear as groups on the map.

Extreme Platform ONE Networking adds devices that are not mapped to a specific site or floor to the **Default Site** in Visualize view. You can map locations to these devices using Extreme Platform ONE Networking or keep them in the **Default Site**.

Select the **Default Site** to open the details panel. The **Summary** tab displays a list of devices that are not mapped to a specific site or floor.




Figure 16: Details panel for the Default Site

The Visualize view supports the following location hierarchy:

Site Group

Site groups are optional folders into which you can organize sites. Two levels of site groups are permitted. Site group names must be unique within the organization.


Site

Sites are a mandatory component of the location hierarchy. A site is the parent container for buildings and can include multiple buildings.

Sites are parent containers for buildings and serve the following purposes:

- Column picker
- Configuration applicability
- Monitoring unit
- Troubleshooting and health score unit

Site names must be unique within the organization. A site cannot belong to more than one site group.

Select  to open the Column Picker and select the table columns to include in the Device list view. The options available to choose from depends on the current view.

Building

Buildings are physical premises with addresses. A building is the parent container for floors and must be associated with a site.

Building names must be unique within the parent site.

Floor

Floors are physical subdivisions of buildings.

Floor names must be unique within the parent building.

Import a Site Tree

Use this task to import a site tree to your network plan.




Note

This feature is available only if the site tree is empty.

1. Go to **Configuration > Sites** and select **Import Site Tree**.
2. Select **Browse Files** or drag and drop the the site tree file.
The files must be in .xml format.
3. Select **Import**.


Add a Site

Use this task to add a new site to your network plan.

1. Go to **Configuration > Sites** and select **Add Site**.
Alternatively, to add a site to an existing site group, select  and choose **Add Site**.
2. Type a **Name** for the new site.
3. Select the **Country**.
4. To add the new site group to an existing group, select an existing parent site group from the **Association** list.
5. (Optional) Enter the address manually, use GPS coordinates, or select the location on the map.
6. Select **Save**.

Add a Site group


Use this task to add a new site group folder to your network plan.

1. Go to **Configuration > Sites** and select **Add Site Group**.
Alternatively, select  for the corresponding parent group, and then choose **Add Site Group**.
2. Type a **Name** for the new site group.
3. (Optional) Add the **Description** text.
4. To add the new site group to an existing group, select an existing parent site group from the **Association** list.
5. Select **Save**.

Add a Building

Your network hierarchy must contain at least one site with the country code defined, before you can add buildings and floors.

Use this task to add a new building to your network plan, and to upload building perimeters and floor plan images. Visualize view stores the images in the image library for future use.

1. Go to **Configuration > Sites**, and select the corresponding  button for a site.
2. Select **Add Building**.
3. Type a **Name** for the building.
4. Type the building **Address**.


Alternately, use Google Maps search to automatically populate the address. If you manually adjust the marker on the map, the address updates automatically.

While sites do not require addresses, buildings must have addresses.

5. Select **Save**.

Add a Floor

Use this task to add a floor to a building.

1. Go to **Configuration > Sites**, and select the corresponding  button for a building.
2. Select **Add Floor**.
3. Type a **Name** for the floor.
4. From the **Environment** menu, choose the environment type that most closely matches your installation.
5. From the Floor **Attenuation** menu, select the noise level of the floor.
6. Specify the installation height (distance from floor to ceiling) of the APs on the floor. If the height varies from AP to AP, enter the average height. This setting has a minimal effect on location estimates except for sites such as warehouses where the height of ceilings or high crossbeams is substantial.
7. Specify the dimensions of the floor plan.
8. Select **Upload Floor Plan** and choose an image from the Library, or upload a new image.

For more information, see [Upload a Floor Plan](#) on page 146.

9. Verify the name of the building in the **Association** list.
10. Select **Save**.


Related Links

[Upload a Floor Plan](#) on page 146

Upload a Floor Plan


Use this task to upload a floor plan to an existing floor, or while creating a new floor.

Extreme Platform ONE Networking supports the jpg and png image formats with an image resolution of 8K.

1. Go to **Configuration > Sites** and expand the **Site** and the **Building**, to which you want to add a floor plan.
2. For an existing floor, select .
3. Choose **Upload New**.
If you're adding a new floor, select **Upload Floor Plan**.
4. Alternatively, select **Choose from Library**, select an image, and then click **Select**.
5. Drag and drop image files into the window, or select **Browse Files** to locate and select the image files.
6. To overwrite files with duplicate names, select **Override floor plan images with same names**.
7. Select **Next**.
8. Select and drag the image border to crop the image.
9. Select **Next**.
10. Select Point A and drag to Point B to set the scale for the floor plan.
11. Select **Done**.


Edit a Site

Use this task to edit a site, site group, building, or floor in your network plan.

1. Go to **Configuration > Sites**.
2. Select  associated with the site to modify it.
3. Select **Edit** and modify the fields as needed.
4. Select **Save**.


Move a Site

Use this task to move a site to a new location.

1. Go to **Configuration > Sites**.
2. Select  associated with the site to move it.
3. Select **Move**.
4. To move the site to an existing group, select an existing parent site group from the Association list.
5. Select **Move**.

Export a Floor Plan

Use this task to export a floor plan.


1. Go to **Configuration > Sites**.
2. Select  associated with the floor to export it.
3. Select **Export**.

The floor plan is exported into .xml or .tar format.

4. Select **Export**.


Clone a Building

Use this task to clone a building.

1. Go to **Configuration > Sites**.
2. Select  associated with the building to clone it.
3. Select **Clone**.
4. Type a **Name** for the new building.
5. To add the new building an existing group, select an existing parent site group from the Association list.

Delete a Site

Use this task to delete a site.

1. Go to **Configuration > Sites**
2. Select  for the site.
3. Select **Delete**.

If an object is in use, a pop-up window asks you to delete the references first. The default response is **Cancel**. To delete the object anyway, provide the randomly generated code to delete the location object.



Warning


Deleting objects with references can result in orphaned objects and other issues.

Related Links

[Delete a Building or a Floor](#) on page 148

Delete a Building or a Floor

Use this task to delete a building or a floor.

1. Go to **Configuration > Sites**.
2. Expand the site for which you want to delete a building or floor.
3. Select  for the building or floor.
You can select multiple buildings or floors to delete at once.
- 4.

5. Select **Delete**.

If an object is in use, a pop-up window asks you to delete the references first. The default response is **Cancel**. To delete the object anyway, provide the randomly generated code to delete the location object.




Warning

Deleting objects with references can result in orphaned objects and other issues.

Related Links

[Delete a Site](#) on page 148



Configuration | Network Policies

- [Add a Network Policy](#) on page 151
- [Configure Policy Settings](#) on page 152
- [Deploy a Network Policy](#) on page 182
- [Configure the SSID for a Standard Wireless Network](#) on page 183
- [Configure Device Templates](#) on page 257
- [Configure Supplemental CLI](#) on page 304
- [Configure Classification Rules for a Device Template](#) on page 305
- [Fabric Attach](#) on page 308
- [Configure Device Data Collection and Monitoring Options](#) on page 309
- [Configure the BLE Service](#) on page 311
- [Configure Presence Analytics](#) on page 314
- [Configure WIPS](#) on page 314
- [Configure a Location Server](#) on page 318
- [Install CA Certificates](#) on page 319
- [Configure a Layer 2 IPsec VPN Service](#) on page 319

A network policy is a combination of configuration settings that can be applied to multiple APs, switches, and routers that share a common characteristic, such as being located at the same site or working together to connect multiple remote sites through VPN tunnels. The type of network policy depends on whether your deployment consists of only wireless AP devices, only switches, only routers, or any combination of these devices. One of the strengths of creating a single policy for multiple device types is that you might only need one unified policy for all your devices. The policy can include one or more SSIDs, device templates, and port types, as well as other configuration elements for networking, including management services such as QoS and VPN tunneling. The policy items are as follows:

- **Policy Details:** Select the policy type: **Wireless** (APs), **Switching** (Universal switches), or both. See [Configure Policy Settings](#) on page 152.
- **Standard Wireless Networks:** Define the wireless network (SSID) and the bands on which to broadcast each SSID, plus SSID usage (authentication, including RADIUS configuration), user access, and additional settings.

- [Device Templates](#): Configure Access Point and Switch device templates.
- [Deploy Policy](#): Push the configuration to your network devices.

**Note**

- The assigned **Access Scope** determines an administrator's access to **Common Objects**. Administrators not assigned global access can only see and work with policy objects created for the sites to which they are assigned.
- Only Switch Engine/EXOS devices support common switch settings, templates, and port types.

Related Links

[Add a Network Policy](#) on page 151

[Configure Policy Settings](#) on page 152

[Configure the SSID for a Standard Wireless Network](#) on page 183

[Configure Device Templates](#) on page 257




[Deploy a Network Policy](#) on page 182

Add a Network Policy

This topic guides you through the basic steps to provide clients with network access via Extreme Networks devices. This process assumes that APs and routers have been deployed and have established secure CAPWAP connections with Extreme Platform ONE Networking. Switches do not use CAPWAP connections. Extreme Networks routers and APs run IQ Engine and communicate with Extreme Platform ONE Networking using CAPWAP on UDP port 12222 or CAPWAP-over-HTTP on TCP port 80. This is true whether they communicate with Extreme Platform ONE Networking on premises or in the cloud. Other supported devices communicate with Extreme Platform ONE Networking using HTTPS on TCP port 443.

Sequential workflow tabs at the top of the page define the network policy configuration process. These tabs are: **1 Policy Details**, **2 Wireless**, **3 Switching/Routing**, and **4 Deploy Policy**. The selected tab is highlighted.

Use this task to add a new network policy.

1. Go to **Configuration > Network**.
You can display network policies in a list () or in a thumbnail () format.
2. Select  from the list view, or select **Add Network Policy** from the thumbnail view.
3. In the **New Policy** window, select a policy type: (Wireless, Switching/Routing, SR/Dell Switching, Branch Routing, or any combination, including all them).
4. Type a **Policy Name**.
5. (Optional) Type a **Description**.
6. Enable or disable **Presence Analytics**.
Enable this option to collect customer behavior data. After you enable it, go to the **2 Wireless** workflow step, and from the left navigation bar, under **Application Management**, select **Presence Analytics**. This is where you configure analytics settings, such as trap interval, aging time, and aggregate time.

7. Select **SAVE**.
8. [Configure Policy Settings](#) on page 152, as required.
9. Select **NEXT**.

The highlighted tab changes from **1 Policy Details** to **2 Wireless**, **3 Switching/Routing**, **4 SR/Dell Switching**, **5 Branch Routing** and **6 Deploy Policy**, depending on your configuration choices.

After you have configured the network policy, [Deploy a Network Policy](#) on page 182.

Related Links



[Configure Policy Settings](#) on page 152

[Deploy a Network Policy](#) on page 182

Configure Policy Settings

The network policy settings that you configure depend on your requirements. For example, determine which default routing instance to use for NTP, DNS, Syslog, and SNMP for a switch.

This task is part of the network policy configuration workflow. Use this task to configure policy settings.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select  to create a new policy.
3. Configure the **Policy Settings**.
 - a. [Configure DNS Server Policy Settings](#) on page 153.
 - b. [Configure NTP Server Policy Settings](#) on page 154.
 - c. [Configure SNMP Server Policy Settings](#) on page 156.
 - d. [Configure Syslog Server Policy Settings](#) on page 158.
 - e. [Configure Device Credentials Policy Settings](#) on page 160.
 - f. [Configure the Device Time Zone](#) on page 160.
 - g. [Configure HIVE Policy Settings](#) on page 161.
 - h. [Configure Management and Native VLAN Policy Settings](#) on page 165.
 - i. [Configure IP Tracking Policy Settings](#) on page 167.
 - j. [Configure LLDP/CDP Policy Settings](#) on page 169.



Note

To configure LLDP port configurations on SR22XX, 23XX, VOSS, and EXOS devices, go to the device template or device configuration page. Configuring LLDP from this page can affect APs, XR, and 20XX/21XX switches, along with certain EXOS, VOSS, SR22XX, and 23XX Global LLDP parameters.

4. Configure the **Management Settings**.
 - a. [Configure Management Options](#) on page 170.
 - b. [Configure Traffic Filters Policy Settings](#) on page 180.
 - c. [Configure MGT IP Filter Policy](#) on page 181.

5. Select **SAVE**.
6. Select **Policy**, and then select **NEXT**.

Related Links

[Configure Classification Rules for a Device Template](#) on page 305

Configure DNS Server Policy Settings

DNS is a critical service for ExtremeCloud managed devices and is required to permit each device to connect to and communicate with Extreme Platform ONE Networking and related services.

Out of the box, and by default, unconfigured APs and switches find the DNS server to use from your DHCP server.



Note

For APs — If your DHCP server does not advertise a DNS server, the AP will instead use the following DNS servers from OpenDNS:

- 208.67.222.222
- 208.67.220.220

The usability of OpenDNS servers can vary depending on the country. Consult OpenDNS documentation for information on excluded countries.

Either your DHCP-defined DNS server or the two default DNS servers must be reachable outbound on UDP port 53 by each device connecting to Extreme Platform ONE Networking.




The DNS server settings defined in this part of the network policy configuration workflow are written to the configuration of your managed device after initial connection.




Note

If enabled, these DNS server settings will override the default DNS behaviors of your managed device. The DNS servers defined here must be reachable from your managed devices on outbound UDP port 53.

This task is part of the network policy configuration workflow. Use this task to configure **DNS Server Policy Settings** for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select  to create a new policy.
3. From the **Policy Settings** menu, select **DNS Server**.
4. Toggle the **DNS Server** setting to **ON**.
5. (Optional) To use existing DNS server settings, choose a DNS object from the  menu.
6. Configure the [DNS Server Settings](#) on page 154.

7. To add a new DNS server, select 
 - a. Type the IP address of the new DNS server.
 - b. Select **ADD**.

You can add up to three servers. The first entry is the primary server. The secondary entry is the secondary server, and the third entry is the tertiary server. Use the arrows in the **Order** column to change the order.

8. If you want to use classification, select **Apply DNS servers to devices via classification**.
9. Select **SAVE DNS SERVER**.

Related Links

[DNS Server Settings](#) on page 154

[Configure Policy Settings](#) on page 152

DNS Server Settings

Table 47: Settings for DNS server profiles

Setting	Description
Name	(Required) Type a Name for the default DNS server.
Domain Name	Type a Domain Name for the default DNS server.
Description	Type a description for the default DNS server. Although optional, entering a description is helpful for troubleshooting and for identifying the DNS server.

Related Links

[Configure DNS Server Policy Settings](#) on page 153

Configure NTP Server Policy Settings

NTP is a critical service for ExtremeCloud managed devices and is required to permit each device to securely connect with Extreme Platform ONE Networking and related services and to ensure alerts and events have the correct timestamp.

Out of the box, and by default, Extreme Networks access points (APs) and switches try to contact the NTP server assigned by your DHCP server. If your DHCP server does not advertise an NTP server, the device will automatically attempt to resolve and connect to the NTP server at `0.aerohive.pool.ntp.org`. Device DNS must be functioning correctly to contact the NTP server.

Either your DHCP-defined NTP server or the default NTP server must be reachable outbound on UDP port 123 by each device connecting to Extreme Platform ONE Networking.

**Note**







If using a Windows server as your NTP server, your Windows server must synchronize with an upstream NTP server for Extreme APs to trust and accept responses from the Windows NTP server.

The NTP server settings defined in this part of the network policy configuration workflow for the configuration of your managed device after initial connection.

**Note**

If enabled, these NTP server settings override the default NTP behaviors of your managed device. The NTP servers defined here must be reachable from your managed devices on outbound UDP port 123.

This task is part of the network policy configuration workflow. Use this task to configure NTP Server policy settings.

1. Go to **Configuration > Network**
2. Select an existing network policy, and then select , or to add a new one, select .
3. For **Policy Settings**, select **NTP Server**.
4. Toggle **NTP Server** to **ON**.
5. To use existing NTP server settings, select , and choose an NTP object.
6. Configure [NTP Server Settings](#) on page 156.
7. To add a new NTP server to the list, select 
 - a. To use an existing NTP, select , and choose a server.
 - b. To add a new NTP server, select , and then select **IP Address** or **Host Name**.
 - c. Type a **Name** for the new object.
You can use the menu to change your previous selection (**IP Address** or **Host Name**).
 - d. Select **SAVE IP OBJECT**.
 - e. Select **ADD**.
Extreme Platform ONE Networking accesses NTP servers in order, from the top down. Use the arrows to rearrange them.
8. If you want to use classification, select **Apply NTP servers to devices via classification**.
9. Select **SAVE NTP SERVER**.

Related Links

[NTP Server Settings](#) on page 156

[Configure Policy Settings](#) on page 152

*NTP Server Settings***Table 48: Settings for NTP server profiles**





Setting	Description
Name	Type a Name for the NTP server.
Domain Name	(Optional) Type a Domain Name for the NTP server.
Synchronize the device clock with the NTP servers.	<ol style="list-style-type: none"> 1. Type the HiveOS Device Sync Interval value (in minutes). 2. From the Switch Sync Interval, select a value.

Related Links

[Configure NTP Server Policy Settings](#) on page 154

Configure SNMP Server Policy Settings

This task is part of the network policy configuration workflow. Use this task to configure **SNMP Server Policy Settings** for a network policy.

1. Go to **Configuration > Network**
2. Select an existing network policy, and then select , or to add a new one, select .
3. For **Policy Settings**, select **SNMP Server**.
4. Toggle **SNMP Server** to **ON**.
5. To use existing SNMP server settings, select , and choose an SNMP server.
6. Configure the [SNMP Server Settings](#) on page 157.
7. To add a new SNMP server, select , and then select **IP Address** or **Host Name**.
You can add up to three SNMP servers to the profile.
8. To use an existing SNMP server, select it from the menu.
9. Type a **Name** for the new IP object.
You can use the menu to change your previous selection (**IP Address** or **Host Name**).
10. Select **SAVE IP OBJECT**.
11. For **Version**, select the version of SNMP that is running on the management station you intend to use.
12. For **Operation**, select the type of activity to permit between the specified SNMP management station and the devices assigned to this profile in the network policy.
 - **None:** Disable all SNMP activity for the specified management station.
 - **Get:** Permit GET commands sent from the management station to a device to retrieve MIBs.
 - **Get and Trap:** Permit reception of GET commands from the management station and transmission of traps to the management station.
 - **Trap:** Permit devices to send messages notifying the management system about events of interest.

13. In the Community field (for SNMP V2C and V1), type a text string that must accompany queries from the management station.

The community string acts similarly to a password, in that devices accept queries only from the management stations that send the correct community string.

14. Select **ADD SNMP SERVER**.

15. If you want to use classification, select **Apply SNMP servers to devices via classification**.

16. Select **SAVE SNMP SERVER**.

Related Links

[SNMP Server Settings](#) on page 157

[Configure Policy Settings](#) on page 152

SNMP Server Settings

Table 49: Settings for SNMP servers

Setting	Description
Name	Type a Name for the server.
Description	(Optional) Type a brief Description for the server. Although optional, entering a description is helpful for troubleshooting and for identifying the server.
SNMP Contact	Type the SNMP Contact information for the SNMP server administrator, so they can be contacted if necessary. This can be an email address, telephone number, physical location, or a combination.
Disable to Send traps over CAPWAP	Clear the check box for Disable to Send traps over CAPWAP to enable devices to send trap information (events and alarms) to ExtremeCloud IQ over a CAPWAP connection, or leave the box checked to disable this action.
SNMP Server	Select an SNMP server from the drop-down list. Choose the IP address or host name object for the SNMP server or servers that will access the devices. To permit management access from a single SNMP server, choose an IP address or host name that defines only that server. To permit management access from an entire subnet, choose an IP address or host name that defines that subnet. If you do not see the IP address or host name that you need, select + and define one.
Version	From the drop-down list, select the version of SNMP that is running on the management station that you intend to use.

Table 49: Settings for SNMP servers (continued)





Setting	Description
Operation	<p>Select the type of activity to permit between the specified SNMP management station and the devices in the network policy to which you will assign this profile.</p> <p>Options include:</p> <ul style="list-style-type: none"> • None: Disable all SNMP activity for the specified management station. • Get: Permit GET commands sent from the management station to a device to retrieve MIBs. • Get and Trap: Permit the reception of GET commands from the management station and the transmission of traps to the management station. • Trap: Permit devices to send messages notifying the management system of events of interest.
Community	<p>For SNMP V2C and V1, enter a text string that must accompany queries from the management station. The community string acts similarly to a password, such that devices accept queries only from management stations that send the correct community string.</p>



Related Links

[Configure SNMP Server Policy Settings](#) on page 156

Configure Syslog Server Policy Settings

This task is part of the network policy configuration workflow. Use this task to configure the **Policy Settings** for a Syslog server.

1. Go to **Configuration > Network**
2. Select an existing network policy, and then select , or to add a new one, select .
3. For **Policy Settings**, select **Syslog Server**.
4. Toggle **Syslog Server** to **ON**.
5. To use existing syslog server settings, select , and choose a syslog server.
6. Configure the [Syslog Server Settings](#) on page 159.
7. To add a new syslog server to the table, select .

Use the up or down arrows to reorder the list of syslog servers in the table.
8. Select , and choose an existing syslog IP address or host name, or select .
9. For **Severity**, select the log level.
10. Type the **Port** number.
11. Select **ADD**.
12. Select **Assign Syslog servers via Classification**.
13. Select **SAVE SYSLOG SERVER**.

Related Links

[Syslog Server Settings](#) on page 159

[Configure Policy Settings](#) on page 152

*Syslog Server Settings***Table 50: Settings for Syslog servers**

Setting	Description
Name	Type a Name for the syslog server.
Description	(Optional) Type a Description for the syslog server. Although optional, entering a description is helpful for troubleshooting and for identifying the server.
Syslog Facility	
IQ Engine Syslog Facility	Select an IQ Engine Syslog Facility to categorize messages sent to syslog from IQ Engine devices. Because syslog servers can receive messages from many types of network devices, such as routers, firewalls, mail servers, you can designate one of the twelve syslog facilities reserved for local use—Auth, Authpriv, Security, User, and Local0 to Local7—to mark messages from all the devices to which you apply this management service set.
Non-IQ Syslog Facility	Select a Non-IQ Syslog Facility to categorize messages sent to syslog from non-IQ Engine devices.
Syslog Group	Select the arrow to expand the Syslog Group section, and use the menus to select the log level for each category. <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notification • Info • Debug <p>Syslog groups organize messages by category and limit the number of messages sent based on severity level. APs do not send messages that are below the assigned level to the syslog server.</p>
Syslog servers are on the same internal network as the reporting Extreme Networks devices (for PCI DSS compliance)	If you must make PCI DSS compliance reports, select the check box. If the servers are on an external network outside the firewall, clear the check box.
Enable hostname in syslog headers	To add the hostname to the headers for all syslog messages, select the check box.

Related Links

[Configure Syslog Server Policy Settings](#) on page 158

Configure Device Credentials Policy Settings

Extreme Platform ONE Networking uses device credentials for remote access to devices through Telnet, SSH, or console connections. If you do not configure the Administrator and Read Only Administrator accounts, global device management settings apply.

**Note**

If you configure a new administrator account, the new account replaces the default account.

This task is part of the network policy configuration workflow. Use this task to configure **NTP Server Policy Settings** for a network policy.



1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. For **Policy Settings**, select **Device Credentials**.
4. Configure the following settings:

Table 51: Device Credentials

Setting	Description
Administrator Account	
Admin Name	Type the name of the Administrator account.
Password	Type the password for the Administrator account.
Show Password	Select the check box to show the password.
Read Only Administrator	
Admin Name	Type the name of the Read Only Administrator account.
Password	Type the password for the Read Only Administrator account.
Show Password	Select the check box to show the password.



5. Select **SAVE**.

Related Links

[Configure Policy Settings](#) on page 152

Configure the Device Time Zone

This task is part of the network policy configuration workflow. Use this task to configure the **Device Time Zone** for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .




3. From the **Policy Settings** menu, select **Device Time Zone**.
4. From the **Time Zone** menu, select a time zone.
5. If you want to use classification, select the **Apply time zone to devices via classification** check box.
6. Select **SAVE**.

Related Links

[Configure Policy Settings](#) on page 152

Configure HIVE Policy Settings

This task is part of the network policy configuration workflow. Use this task to configure **HIVE** policy settings for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select  to create a new policy.
3. From the **Policy Settings** menu, select **HIVE**.
4. (Optional) To use existing HIVE settings, choose a HIVE object from the  menu.
5. Configure the [HIVE Profile Settings](#) on page 161.
6. Apply MAC filters to restrict devices that can join the hive.
You can select existing filters from the table or add new filters.
7. From the menu, choose the default action (**Permit** or **Deny**) for devices that have a MAC address or OUI that does not match the selected MAC filter.
8. Select **SAVE**.

Related Links

[Configure Policy Settings](#) on page 152

[HIVE Profile Settings](#) on page 161

HIVE Profile Settings

Table 52: HIVE profile settings

Setting	Description
Name	Type a Name for the new profile.
Hive Control Traffic Port	Type the port number for Hive traffic control. Hive communications operate at Layers 2 and 3. The default port number for Layer 3 hive communications and for roaming-related traffic is UDP 3000. If a different service on your network is already using port 3000, you can change this to any number from 1024 to 65535, as long as the new setting is at least 50 greater or less than the current setting. For example, if the current port number is 3000, you can set a new port number higher than 3050.

Table 52: HIVE profile settings (continued)

Setting	Description
Description	(Optional) Type a description for the new profile. Although optional, entering a description is helpful for troubleshooting and for identifying the profile.
Alarms	
CAPWAP Delay Alarms	Toggle the setting ON or OFF .
Security	
Encryption Protection	Toggle the setting ON or OFF . Disable Encryption Protection to have ExtremeCloud IQ derive a default password from the hive name.
Encryption Password	Choose between Auto Generate and Manual . Hive members use this password to authenticate to each other over the wireless backhaul link using WPA-PSK CCMP (AES). To see the password that you entered, clear the Shared Secret > Show Password check box.

Table 52: HIVE profile settings (continued)

Setting	Description
MAC-based DoS Prevention Rules	<p>Select Hive or Client, and modifying the settings in the dialog box.</p> <p>Extreme Networks devices ship with the default hive- and SSID-lever DoS detection settings for a number of frame types that are commonly used when launching DoS attacks. You can raise the thresholds to avoid receiving too many false alarms or lowering them to receive more alarms indicative of spikes in certain types of traffic.</p> <ul style="list-style-type: none"> • DoS prevention rules for hives apply to wireless traffic from all radios that might reach the backhaul or access channel from wireless clients or nearby access points broadcasting on the same channel. You can define settings to detect DoS attacks on the radio channels that a device uses for hive communications and for SSID access traffic. • DoS prevention rules for clients apply to traffic originating from a single neighboring radio. The source might be a neighbor member or a nearby device outside the network that is broadcasting on the same channel the Extreme Networks device is using for its wireless backhaul communications, or for SSID access traffic. <p>For both types of rules, you can change the alarm thresholds and enable or disable settings for each DoS Detection type: Probe Requests and Responses, (Re) Associations, Association and Disassociation Requests and Responses, Authentication and Deauthentication, and EAP over LAN (EAPoL). Wireless clients periodically send probe requests to see if any access points are within range. The threshold determines the number of messages per minute required to trigger an alarm about a possible DoS attack. The alarm interval determines the length between repeated alarms when the number of messages continues to exceed the threshold.</p>
Wireless Mesh Settings	
Request to Send Threshold	<p>Type a value in bytes.</p> <p>This is the maximum frame size in bytes that requires the device to first send an request to send (RTS (request to send) message before sending a large frame. The default setting is 2346 bytes.</p>
Fragment Threshold	<p>Type a value in bytes.</p> <p>This is the maximum IEEE 802.11 frame size in bytes that the device uses when sending control traffic over the wireless backhaul link to other members. If the device needs to send a frame that is larger, it first breaks it into smaller fragments. The default setting is 2346 bytes.</p>
Require minimum wireless signal strength for creating wireless mesh	<p>Select the check box to require a minimum wireless signal strength for creating wireless mesh, and configure the related settings.</p>

Table 52: HIVE profile settings (continued)







Setting	Description
Signal Strength Threshold	Use the slider to specify a signal strength between 90 dBm and - 55 dBm. This value is the minimum signal strength required to enable members to form a wireless backhaul link. The default is -80 dBm.
Polling Interval	Type a value for the time interval from 1 to 60 minutes for polling the signal strength of neighboring members. A lower interval increases traffic on the network slightly, especially in environments where there are lots of members, however it also increases the responsiveness of members to changes in signal strength. A higher interval reduces responsiveness to signal strength changes, which can be preferable in an environment where severe and frequent signal strength fluctuations would cause members to continually drop and re-establish connections. The default is every 60 seconds.
Client Roaming > Detect neighbor devices	
Devices send keepalive heartbeats every	Type a value and select a unit of time from the menu to set the interval between keepalive heartbeats. The default is 10 seconds, and the range is 5 to 360,000 seconds (100 hours). To calculate the length of time, multiply the keepalive interval by the number of missed keepalives. Using the default settings, 10 seconds (interval) x 5 (missed keepalives), a neighbor ages out after 50 seconds.
Remove neighbor if the number of missed keepalive heartbeats exceeds	Type the number of the number of missed heartbeats before ExtremeCloud IQ removes a neighbor.
Client Roaming > Share connected client information(Roaming cache)	
Devices send client information every	Type a value and select a unit of time from the menu to specify how often devices send client information. The default is 60 seconds.
Remove cached client information when absent from updates after	Type the number of missed updates, after which ExtremeCloud IQ deletes cached client information for the affected client.
Update all hive members within radio range, including Layer 3 neighbors	Select the check box to update all hive members within radio range, including Layer 3 neighbors.
Update hive members in the same subnet and VLAN.	Select the check box to update hive members in the same subnet and VLAN.
IP Address Preference	
Use IP address type first with	(Required) From the menu, select IPv4 or IPv6 .

Related Links

[Configure HIVE Policy Settings](#) on page 161

Configure Management and Native VLAN Policy Settings

This task is part of the network policy configuration workflow. Use this task to configure **Management and Native VLAN** policy settings for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. From the **Policy Settings** menu, select **Management and Native VLAN**.
4. Select an **MGT Interface VLAN**  and choose an existing object, or to add a new one, select .
5. For a new **MGT Interface VLAN**, configure the settings.
 - a. Type a **Name** for the new VLAN object.
 - b. Type a **VLAN ID** for the new VLAN object.
 - c. If you want to use classification, select **Apply VLANs to devices using classification**.
See [Configure Classification Rules](#) on page 165.
6. Select an **Native (Untagged) VLAN** *For IQ Engine devices only*  and choose an existing object, or to add a new one, select .
7. For a new **Native (Untagged) VLAN**, configure the settings.
 - a. Type a **Name** for the new VLAN object.
 - b. Type a **VLAN ID** for the new VLAN object.
 - c. If you want to use classification, select **Apply VLANs to devices using classification**.
See [Configure Classification Rules](#) on page 165.
8. Select **SAVE VLAN**.

Related Links

[Configure Classification Rules](#) on page 165

[Configure Policy Settings](#) on page 152

Configure Classification Rules




Before you can use classification rules, you must create a network location, along with cloud config groups, IP addresses, and IP subnets.

You can create classification rules as part of a network policy or as a common object.

- Configure **Device Location** rules to assign different DNS and RADIUS servers and different time zones to different physical locations.
- Configure **Cloud Config Groups** (CCGs) to create user passwords which restrict access to private and personal network devices.
- Configure **IP Address** classification rules to associate user groups so they can communicate using their own private networks.
- Configure **IP Subnet** classification rules to support multiple user-group private networks.
- Configure **IP Range** classification rules for multiple user-group private networks.

This task is part of the network policy configuration workflow. Use this task to create a classification rules object. Extreme Platform ONE Networking supports multiple

classification rules for DNS servers, VLANs, RADIUS servers, device templates, user groups, and private client groups (PCGs).

1. Go to **Configuration > Network**.
2. Select an existing rule, and then select , or to add a new one, select .
3. Enter a **Name** for the rule.
4. (Optional) Enter a **Description** for the rule.
5. Select , and then choose the rule type to configure.

Choose from the following rule types:

Table 53: Rule types









Selected rule type	Do this
Device Location	<ol style="list-style-type: none">a. Drill down until you reach the location level at which the device resides.b. Select Select. <p>The location appears in the Classification Rules table.</p>
Cloud Config Group	<ol style="list-style-type: none">a. Select the Match Type.b. Select  and choose an existing group, or select .c. Select CLOUD CONFIG GROUP.d. Select CONTINUE.
IP Address	<ol style="list-style-type: none">a. From the Match Type menu, select Contains or Does Not Contain.b. Select  and choose an existing IP address, or select . <p>If you do not see the IP address that you want, select New to create a new IP address.</p> <ol style="list-style-type: none">c. Select SAVE IP.d. Select CONTINUE.

Table 53: Rule types (continued)

Selected rule type	Do this
IP Subnet	<ol style="list-style-type: none"> From the Match Type menu, select Contains or Does Not Contain. Select  and choose an existing IP subnet, or select  menu. If you do not see the IP subnet that you want, select New to create a new IP subnet. Select SAVE SUBNET. Select CONTINUE.
IP Range	<ol style="list-style-type: none"> From the Match Type menu, select Contains or Does Not Contain. Select  and choose an existing IP range, or select . If you do not see the IP range that you want, select New to create a new IP range. Select SAVE IP. Select CONTINUE.



6. Select **SAVE RULE**.

Related Links

[Add a Cloud Config Group](#) on page 308

Configure IP Tracking Policy Settings

This task is part of the network policy configuration workflow. Use this task to configure **IP Tracking** policy settings for a network policy.

- Go to **Configuration > Network**.
- Select an existing network policy, and then select , or to add a new one, select  to create a new policy.
- From the **Policy Settings** menu, select **IP Tracking**.
- Toggle the **IP Tracking** setting to **ON**.
- Select a tracking group and use the single-arrow controls to move it from **Available IP Tracking Groups** to **Selected IP Tracking Groups**, or vice versa.
Use the double-arrow controls to move all of the tracking groups.
- To add a new IP tracking group, select **ADD ANOTHER IP TRACKING GROUP**, and then configure the [IP Tracking Group Settings](#) on page 168.
- Select **SAVE**.

Related Links

[IP Tracking Group Settings](#) on page 168

[Configure Policy Settings](#) on page 152

*IP Tracking Group Settings***Table 54: Settings for IP Tracking Groups**

Setting	Description
Name	Type a Name for the group.
Description	(Optional) Type a Description for the group. Although optional, entering a description is helpful for troubleshooting and for identifying the group.
Connectivity	Select either Backhaul Connectivity Tracking for APs or WAN Interface Connectivity Tracking for APs .
Enable IP Tracking	To activate this IP tracking group, select the check box. Clear the check box to exclude the group from Available IP Tracking Groups .
Track the Following Targets	
IP Addresses	Enter up to four IP addresses, separated by commas. If you are also tracking the default gateway, enter up to three IP addresses.
Default Gateway	If the IP addresses use the default gateway, select Default Gateway . Otherwise, clear the check box.
Take action when	From the menu, select a condition for which to take action. Choose between All targets become unresponsive and A single target becomes unresponsive .
Tracking Interval	(Required) Type the tracking interval for this group. Default: 6
Tracking Retries	(Required) Type the number of retries before taking action for an IP address failure. Default: 3
Actions to take when target becomes unresponsive	
Enable the virtual access console	Select the check box to take this action when the target is unresponsive.
Disable all active SSIDs	Select the check box to take this action when the target is unresponsive.
Start the backhaul (mesh) failover procedure	Select the check box to take this action when the target is unresponsive.

Related Links

[Configure IP Tracking Policy Settings](#) on page 167

Configure LLDP/CDP Policy Settings




This task is part of the network policy configuration workflow. Use this task to configure LLDP/CDP policy settings for a network policy.



Note

LLDP is on by default in Extreme Platform ONE Networking. In IQ Engine, LLDP was previously off by default. With IQ Engine Release 10.7.5 and later, LLDP is on by default. This is the new default behavior for all new devices running 10.7.5 and later.

If LLDP is disabled in the network policy, upgrading to 10.7.5 enables LLDP until after you perform a configuration update.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. For **Policy Settings**, select **LLDP/CDP**.
4. Toggle **LLDP/CDP** to **ON**.
5. To use existing LLDP/CDP settings, select , and choose an LLDP/CDP object.
6. Configure the [LLDP and CDP Settings](#) on page 169.

Related Links

[Configure Policy Settings](#) on page 152

[LLDP and CDP Settings](#) on page 169

LLDP and CDP Settings

Table 55: Settings for LLDP and CDP

Setting	Description
Name	Type a Name for the new LLDP/CDP object.
Description	(Optional) Type a Description for the new LLDP/CDP object. Although optional, entering a description is helpful for troubleshooting and for identifying the LLDP/CDP object.
Enable LLDP on access ports	Select the check box to permit LLDP on access ports. Note: LLDP is enabled on other port types by default.
Enable receive only mode.	Select the check box to permit devices to receive, cache, and display LLDP advertisements from other devices, but to not advertise their own data.
LLDP entries to cache	(IQ Engine Only) Type the maximum number of LLDP entries from neighboring network devices that a device can store in its cache.

Table 55: Settings for LLDP and CDP (continued)

Setting	Description
Neighbors keep Extreme Networks advertisements for	Type the number of seconds for which neighboring devices retain LLDP advertisements. Increase the time while troubleshooting a network issue and decrease it if you need to reduce overall network traffic.
Advertisements Interval	Type the number of seconds between LLDP advertisements sent to neighboring network devices.
Timer Hold	Type a multiple of the advertisements interval. (EXOS/Switch Engine, VOSS/Fabric Engine, SR22XX/23XX, Dell)
Max power for LLDP advertisements	Select Use the default max power in IQ Engine to use the maximum power level that devices can request in LLDP advertisements.
LLDP Initialization Delay Time	Type the length of time that you want the interface to wait before initializing LLDP.
Fast start repeat count	Type the number of advertisement LLDP frames to send when the connected device (such as an IP phone) starts up or is discovered.
CDP (Cisco Discovery Protocol)	<p>Toggle CDP ON to enable devices to receive and cache CDP advertisements.</p> <p>Note: You can enable LLDP and CDP concurrently.</p> <p>CDP is a proprietary Data Link Layer protocol developed by Cisco Systems.</p>
Enable CDP on access ports.	Select the check box to permit CDP on access ports. By default, CDP is enabled on other port types.
CDP entries to cache	Type the maximum number of CDP entries that a device can store in its cache.



Related Links

[Configure LLDP/CDP Policy Settings](#) on page 169

Configure Management Options

After you enable **Management Options** in the network policy, you can re-use an existing **Management Options** object, or configure the settings manually.

This task is part of the network policy configuration workflow. Use this task to configure **Management Options** for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select  to create a new policy.
3. From the **Management Settings** menu, select **Management Options**.
4. Toggle the **Management Options** setting to **ON**.

5. To reuse existing management options settings, select **Re-use MGT IP Filter**, and then select an existing **Management Option**.
6. Enter a **Name**.
7. (Optional) Enter a **Description**.
Although optional, entering a description is helpful for troubleshooting and for identifying the **Management Options** object.
8. Configure the settings for [Management Options](#) on page 171.
9. Select **SAVE**.

Related Links

[Management Options](#) on page 171

[Configure Policy Settings](#) on page 152

Management Options

Use these settings to control how administrators authenticate and how they access the devices they manage. You can configure global and device-level settings. For example, you can enable or disable the reset button and console port, enable or disable proxy ARP requests and replies, enable APs and routers to forward broadcasts and multicasts between SSIDs, and a variety of other options such as adjusting LED brightness, and setting temperature alarms.

Forwarding Engine Control Management Options

The forwarding engine controls the type of traffic being forwarded between interfaces, between GRE tunnels, and sets logging features.

Table 56: Forwarding Engine Control Settings

Setting	Description
Forwarding Engine Control	
GRE Tunneling Selective Multicast Forwarding	<p>Select one of the following options:</p> <ul style="list-style-type: none"> • Block All—Prohibits forwarding multicast and broadcast traffic through tunnels. • Allow All—Enables forwarding multicast and broadcast traffic through tunnels. <p>Extreme Platform ONE Networking devices can selectively block or permit broadcast and multicast traffic through GRE tunnels to reduce traffic congestion. You can filter using a blocked list that blocks the forwarding of all broadcast and multicast traffic through GRE tunnels (or blocks all except to a few select destinations) or using an allow list that permits all broadcast and multicast traffic through GRE tunnels (or allows all, except to a few destinations).</p>
Exception IP List	Add an entry (destination IP Address and Netmask) to the Exception IP List . Type the values, and then select ADD .
Service Control	

Table 56: Forwarding Engine Control Settings (continued)

Setting	Description
Limit MAC Sessions per Station	<p>Select Limit MAC Sessions per Station to enable the feature, and then type the maximum number of (Layer 2 sessions) that can be created to or from a station.</p> <p>By default, devices do not enforce MAC or IP session limits per station. By default, devices do not enforce IP session limits per station.</p>
Limit IP Sessions per Station	<p>Select Limit IP Sessions per Station to enable the feature, and type the maximum number of sessions per station.</p> <p>This feature enables a device to monitor the TCP MSS (maximum segment size) option in TCP SYN and SYN-ACK messages for traffic that the device is going to pass through GRE tunnels (for Layer 3 roaming and static identity-based tunnels) and GRE-over-IPsec tunnels (for IPsec VPN tunnels). The device can then notify the sender to adjust the TCP MSS value if it exceeds a maximum threshold.</p>
Enable TCP Maximum Segment Size	<p>Select Enable TCP Maximum Segment Size to enable the feature, and then type the maximum segment size.</p> <p>When establishing a TCP connection, neither end is aware of the packet processing done by network forwarding equipment in between. For example, if a device has to send traffic through an IPsec VPN tunnel, then it adds a GRE header, IPsec header, and possibly a UDP header for NAT-Traversal to each packet. Since the additional headers expand packet size, the device is forced to fragment them, which increases packet processing and slows down throughput. To avoid fragmentation, the device can adjust the MSS (maximum segment size) value inside the initial SYN packet to provide room for the additional headers.</p> <p>The default thresholds are 1414 bytes for GRE tunnels and 1336 bytes for GRE-over-IPsec tunnels and are based on encapsulation overhead of the corresponding tunnel type and the maximum transmission unit (MTU) for the mgt0 interface, which is 1500 bytes by default. If you change the MTU and use "auto" for the TCP MSS option, the device automatically readjusts the TCP MSS thresholds.)</p>
DHCP Option 82: Replace MAC Address with Hostname	<p>To switch between MAC address and Hostname for DHCP option 82,enable DHCP Option 82: Replace MAC Address with Hostname. The default is MAC address.</p>

Table 56: Forwarding Engine Control Settings (continued)

Setting	Description
ARP Shield	<p>Enable ARP Shield to prevent Man-In-the-Middle attacks by client devices attempting to impersonate critical network resources on the network such as a network gateway or DNS server through an ARP poisoning attack. ARP Shield should not be used if any clients on the network are assigned static IP addresses. ARP Shield is disabled by default and can only be enabled on access points running IQ Engine 6.8.1 and above. Enabling ARP Shield is not enforced on access points running IQ Engine 6.5, switches, routers, or Virtual Gateway appliances.</p>
DHCP Shield	<p>Disable DHCP Shield to turn off the built-in ability for IQ Engine to prevent attached clients from impersonating a DHCP server.</p> <p>In the default enabled state, connected clients are blocked from responding to DHCP server discovery or IP lease requests. When disabled, connected clients can respond to DHCP discovery or IP lease requests. DHCP Shield is enabled by default on access points running IQ Engine 6.8.1 and above.</p> <p>Disabling DHCP Shield results in no changes to access points running IQ Engine 6.5, switches, routers, or Virtual Gateway appliances.</p>
Proxy ARP	<p>Proxy ARP requests enable learning MAC addresses and proxy replies to ARP requests. Select one of the following slider bar options:</p> <ul style="list-style-type: none"> • Disabled: Not recommended. Disabling turns off all proxy ARP handling capabilities. It increases air time utilization by having to send ARPs to clients in the roaming cache. Use for troubleshooting only. When diagnosing a network issue, you might need to permit ARP requests and replies between wireless clients and network devices (such as the default gateway) to flow directly across the device without proxy. • Legacy: Not recommended, but is available for legacy Wi-Fi 4 APs. • Enhanced: Preferred and is the highest level of adoption. Supported on Wi-Fi 5 APs and newer. Does not support ARP suppression for devices not in the roaming cache. Wired clients can flood the air with ARPs. • ARP Suppression: Recommended, but support is limited to AP3000, AP5010, and AP5050. Protects airtime from overuse by unneeded ARP traffic.

Table 56: Forwarding Engine Control Settings (continued)

Setting	Description
Disable Inter SSID Flooding	<p>Select Disable Inter SSID Flooding to prohibit a device from forwarding traffic that it receives from clients in one SSID to clients associated with the same device in another SSID.</p> <p>Instead, such traffic must first cross the device from an interface in access mode to an interface in backhaul mode. From there, the traffic might pass through an internal firewall that performs deep-packet inspection, URL filtering, or antivirus checking, and other operations, before sending the traffic back across the device to reach the clients in the destination SSID.</p>
Disable WebUI Without Disabling CWP	Select Disable WebUI Without Disabling CWP to disable the local web user interface on a device to improve system security without disabling the associated captive web portal.
Enable legacy HTTP redirect	<p>Select Enable legacy HTTP redirect to enable redirects to legacy HTTP sites.</p> <p>Note: Extreme Networks recommends HTTPS for best security. This option is provided for legacy clients, for which HTTPS is not suitable.</p>
Global Logging Options for Firewall Policies	
Log	<p>Select the corresponding check boxes to enable the generation of logs for the following scenarios:</p> <ul style="list-style-type: none"> • Drop packets that are denied by IP or MAC firewall policies • The first packets of the session destined for the Extreme Networks device itself
Drop	<p>Select the corresponding check boxes to enable the generation of logs for the following scenarios:</p> <ul style="list-style-type: none"> • Fragmented IP Packets • All non-management traffic destined for the Extreme Networks device itself

System Settings Management Options

Use the settings in this section to adjust various device-level functions, including device health alarm thresholds, VoIP features, and client OS detection types. Miscellaneous settings cover reset, console, PoE, and data collection features.

Table 57: System Settings

Setting	Description
LED Brightness	Set the device status LED brightness level. Select an option from the menu: Bright , Soft , Dim , or Off .
Temperature Alarm Threshold	Specify the ambient celsius temperature threshold that triggers an alarm.

Table 57: System Settings (continued)

Setting	Description
Fans Underspeed Alarm Threshold	Specify the minimum RPM operating speed for fans. Speeds below this value trigger an alarm.
Call Admission Control	To enable Call Admission Control , toggle the setting to ON . If enabled, devices monitor VoIP traffic to determine if there is enough available airtime for new VoIP calls.
Airtime per Second	<p>Set the amount of airtime reserved for VoIP traffic. Decreasing the amount of reserved airtime for VoIP traffic frees more airtime for traffic other than VoIP. This can be useful if there are only a few VoIP users on the WLAN. For a high number of VoIP users, increase the amount of reserved airtime. Type a value in microseconds.</p> <p>By default, a device reserves 500 milliseconds of airtime per second for all VoIP calls. You can change the reserved airtime per second for VoIP from 100 to 1000 milliseconds per second.</p>
Guaranteed Airtime for Roaming Clients	<p>Set the percentage of airtime that a device reserves on the access interface for receiving VoIP calls from roaming clients. Type a value as a percentage (%).</p> <p>By default, a device guarantees 20% of the reserved VoIP airtime for VoIP calls from roaming clients. You can change the percent of guaranteed airtime for roaming clients from 0% to 100%. Consider lowering the percent if VoIP users rarely roam, and raising the setting if roaming often occurs. Because VoIP traffic from a roaming client belongs to an existing session, the device to which the client roams always accepts it. If there is not enough airtime available in the guaranteed roaming reserve, the device deducts available airtime from the relevant user profile.</p>
OS Detection	<p>Enable devices to detect the OS of client devices based on a combination of DHCP option 55 contents and the contents of the HTTP headers. To enable, set the toggle to ON.</p> <p>The following detection methods are available:</p> <ul style="list-style-type: none"> • Use DHCP option 55 contents: Select to use the DHCP option 55 parameter list. • Use HTTP user agent IDs: Select to use the contents of the HTTP user agent ID within the HTTP headers. • Use both detection methods (DHCP=primary method, HTTP=secondary method): Select to use both the DHCP option 55 parameter list and the HTTP user agent information to identify the client operating system. When you select this option, devices first check the contents of the DHCP option 55 parameter list. If it finds no match, then the device examines the HTTP header for the HTTP user agent ID to determine the operating system. If no match is found in either pass, then ExtremeCloud IQ displays unknown as the client OS.

Table 57: System Settings (continued)

Setting	Description
Disable Reset Button	Disable the reset button on the front panel of the chassis to prevent non-administrators from using it to reset the device to its default settings or to a bootstrap configuration. Select the check box.
Disable Console Port	<p>Disable the functionality of the console port on a device to block all administrative access through that port. Select the check box.</p> <p>Disabling the console port on a device that is deployed in a publicly accessible location is a good security precaution. Disabling the console port means that all administrative access must flow over the network, and if there are any connectivity issues with the network or if the device is configured to use only DHCP to get an IP address and cannot get its network settings from a DHCP server, attempts to log in to the device fail.</p> <p>Note: Disabling the console port means that all administrative access must flow over the network, and if there are any connectivity issues with the network or if the device—if configured to use only DHCP to get an IP address—cannot get its network settings from a DHCP server, you will not be able to log into the device.</p>

Table 57: System Settings (continued)

Setting	Description
Enable Smart PoE	<p>To enable Smart PoE, select the check box.</p> <p>Smart PoE lets an AP230, AP320 or AP340 adjust power consumption automatically based on the current power supply. The AP230 and AP320 support PoE on the ETH0 interface. The AP340 supports PoE on both its ETH0 or ETH1 interfaces, and can simultaneously draw power through either one or both.</p> <p>Using Smart PoE, an AP can detect if there are power injectors connected to one or both of its Ethernet ports and how many watts are available for each PoE channel. The AP uses this information to manage its internal use of power resources based on the currently available power level as follows:</p> <ul style="list-style-type: none"> • 20 W or higher: No adjustments are needed when the power level is 20 W or higher. • 18 - 20 W: The device disables the ETH1 interface. • 15 – 18 W: The device switches from 3x3 MIMO (Multiple In, Multiple Out) to 2x3. • 13.6 - 15 W: In rare cases when the power drops between 13.6 and 15 W and further power conservation is necessary, the device reduces the speed on its active Ethernet interface from 10/100/1000 Mbps to 10/100 Mbps. • 0 - 13.6 W: If there is a problem with the PoE switch or Ethernet cable and the power falls between 0 and 13.6 W, the device disables its wireless interfaces and returns its ETH0 and ETH1 interfaces to 10/100/1000 Mbps speeds. <p>Note: When using smart PoE, the maximum power consumption setting must be set to No limitation (the default). Manually setting the PoE maximum power consumption level to anything else overrides smart PoE and essentially disables it.</p>
Enable PCI Wireless Control Data Collection	<p>Enable this feature to collect data about MAC DoS, IP DoS, and MAC filter violations in PCI compliance reports. Select the check box.</p>
Accept ICMP Redirect Message	<p>Enable this feature to accept ICMP redirect messages from routers on their subnet. Select the check box.</p> <p>By default, devices reject ICMP redirects because crafted ICMP redirect messages can be maliciously used to cause a victim host to send traffic to an attacker's host or even back to the victim itself, which is what occurs during a WinFreeze attack. However, you can enable this feature if you believe that your network is safe from such threats and you want multiple routers on the local subnet to be able to update the routing table on devices.</p>

Table 57: System Settings (continued)

Setting	Description
Report client information gathered from captive web portals	Enable this feature to require devices to forward client information (such as name and email address) to Extreme Platform ONE Networking, where the information is logged as an event. Select the check box.
Hostname in Beacon	<p>Activate iBeacon for or APs that have internal iBeacon transmitters and that belong to a network policy. Slide the toggle to ON.</p> <p>To use this setting, you must first define the iBeacon service in the associated network policy and then turn it on via the Device Management page.</p>

Authentication Settings Management Options

Authentication settings specify the database location for storing administrator accounts, and control authentication for administrators.

Table 58: Authentication Settings

Setting	Description
Extreme Networks Device Admin Authentication	<p>Specify the location of the database storing administrator accounts with which the AP authenticates administrators when they log in. Choose one of the following options:</p> <ul style="list-style-type: none"> • Local—Stores admin accounts locally on the APs. • RADIUS—Stores admin accounts remotely on RADIUS authentication servers. • Both—Stores admin accounts both locally and remotely. <p>If one or more RADIUS servers are already in place, for convenience and security, you can keep all the accounts there and configure the AP to look up administrators on those servers.</p> <p>Note: Be careful about using the RADIUS option. If all the AP admin accounts are on a RADIUS server and the device cannot connect to it, attempts by administrators to log in to the device fail.</p> <p>If there is no central RADIUS server containing a user database, or if you prefer to keep the admin accounts locally on the AP, select Local. To use accounts located on an external RADIUS server and locally on the device, select Both. In this case, the device authenticates administrators by first checking accounts on the external RADIUS servers specified in the RADIUS profile, and then by checking accounts stored on the local database second.</p>
Private PSK Server Auto-Save Interval	<p>Type the length of time that a device acting as a private PSK server automatically saves its list of private PSK-to-client MAC address bindings to flash memory.</p> <p>Depending on how frequently the server is binding private PSKs to client MAC addresses, you can make the interval as short as 60 seconds or as long as 3600 seconds (1 hour).</p>
MAC Address Format	<p>Define the MAC Address Format:</p> <ul style="list-style-type: none"> • Delimiter—Choose the type of delimiter: Colon (:), Dash (-), or Dot (.). • Style—Choose No delimiters, Two delimiters, or Five delimiters. • Case Sensitivity—Choose between Lower Case and Upper Case. <p>Some servers only accept MAC addresses in a particular format. These parameters control MAC authentication for local users on an Extreme Networks RADIUS server. For</p>

Table 58: Authentication Settings (continued)

Setting	Description
	<p>example, if you set case sensitivity as lower case and store local users with upper case MAC addresses for their user names and passwords, MAC authentication checks fail.</p> <p>By default, a device formats MAC addresses using lower case without any delimiter; for example: 0016cF8d55bc. You can reformat this address by making the following selections:</p> <p>Colon, no delimiter, upper case: 0016CF8D55BC Colon, two-delimiter, upper case: 0016:CF8D:55BC Colon, five-delimiter, upper case: 00:16:CF:8D:55:BC Dash, five-delimiter, upper case: 00-16-CF-8D-55-BC Dot, five-delimiter, upper case: 00.16.CF.8D.55.BC</p>




Related Links

[Configure Management Options](#) on page 170

Configure Traffic Filters Policy Settings

After you enable **Traffic Filter** in the network policy, you can re-use an existing Traffic Filter object, or configure the settings manually.

This task is part of the network policy configuration workflow. Use this task to configure **Traffic Filter** policy settings for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. From the **Management Settings** menu, select **Traffic Filter**.
4. Toggle the **Traffic Filter** setting to **ON**, and configure the settings.
5. (Optional) To use an existing filter, select **Re-use Traffic Filter Settings**, , and then choose an existing filter.
6. Configure the [Traffic Filter Settings](#) on page 180.
7. Select **SAVE**.

Related Links

[Traffic Filter Settings](#) on page 180

[Configure Policy Settings](#) on page 152

Traffic Filter Settings

Table 59: Settings for Traffic Filters

Setting	Description
Name	Type a Name for the new Traffic Filters object.
Description	Type a Description for the new Traffic Filters object.

Table 59: Settings for Traffic Filters (continued)

Setting	Description
IQ Engine APs, Routers and Switches	
Control the following types of traffic to devices	<p>Select the corresponding check boxes to enable the selected types of traffic.</p> <ul style="list-style-type: none"> • Enable SSH: Permit an SSH connection to the mgt0 interface. By default, SSH is enabled. • Enable Telnet: Permit a Telnet connection to the mgt0 interface. By default, Telnet traffic is disabled. • Enable Ping: Permit ICMP echo requests (pings) to reach the mgt0 interface. By default, pinging mgt0 is allowed. • Enable SNMP: Permit an SNMP connection to the mgt0 interface. By default, SNMP is disabled. • Enable Inter-station Traffic: (Only for APs) Permit inter-station traffic between APs.
Non-IQ Engine Switches (Dell & Extreme Networks)	
Control the following types of traffic to devices	<p>Select the corresponding check boxes to enable the selected types of traffic.</p> <ul style="list-style-type: none"> • Enable Telnet: Permit a Telnet connection to the mgt0 interface. By default, Telnet traffic is disabled. • Enable Ping: Permit ICMP echo requests (pings) to reach the mgt0 interface. By default, pinging mgt0 is allowed. <p>Does not apply to N1100 series devices.</p>



Related Links

[Configure Traffic Filters Policy Settings](#) on page 180

Configure MGT IP Filter Policy

After you enable MGT IP Filter in the network policy, you can reuse an existing MGT IP Filter object, or configure the settings manually.

This task is part of the network policy configuration workflow. Use this task to configure **MGT IP Filter** policy settings for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. From the **Management Settings** menu, select **MGT IP Filter**.
4. Toggle the **MGT IP Filter** setting to **ON**.
5. To use an existing filter, select **Re-use MGT IP Filter** and then select an existing filter.
6. Configure the [MGT IP Filter Settings](#) on page 182.
7. To add a new IP Object, select **Add Another IP Object**, configure the settings, and then select **SAVE SUBNET**.

See [MGT IP Filter Settings](#) on page 182.

8. Select **SAVE MGT IP FILTER**.

Related Links

[MGT IP Filter Settings](#) on page 182

[Configure Policy Settings](#) on page 152

*MGT IP Filter Settings***Table 60: Settings for MGT IP Filters**

Setting	Description
Name	Type a Name for the filter.
Description	(Optional) Type a Description for the filter. Although optional, entering a description is helpful for troubleshooting and for identifying the filter.
Permitted Management Traffic Source	
Available IP Objects	IP objects in this list are preconfigured. To add to the list, select ADD ANOTHER IP OBJECT . See Table 61 on page 182. Select an IP address in the Available IP Objects column, and then select the single arrow (>) to move it to the Selected IP Objects column. Use the double arrow >> to move all available IP addresses.
Selected IP Objects	IP objects in this list are the IP addresses from which administrators can access the devices. Select an IP address in the Selected IP Object column, and then select the single arrow (>) to move it to the Available IP Objects column. Use the double arrow >> to move all available IP addresses.



Table 61: Settings for IP Objects

Setting	Description
Name	(Required) Type a Name for the new IP object.
Subnet	(Required) Type the new IP Address and Subnet .

Deploy a Network Policy

When you create a new network policy or make changes to an existing policy, the final step is to push the policy to the devices. Extreme Platform ONE Networking pushes all configuration uploads as complete uploads. This action requires devices to reboot and activate the new configurations. Network policies can only be pushed to real devices (not simulated devices).

This task is part of the network policy configuration workflow. Use this task to deploy a network policy.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you configure the network policy, select the devices to which you want to upload the policy.
 - To automatically select the check boxes for all of the devices, select the check box in the top left of the table header.
 - To upload your network policy to specific devices only, select the corresponding check boxes for those devices.

Use the **Assigned**, **Eligible**, and **Filtered** controls to customize your view of the devices that appear in the table.

4. Select **UPLOAD**.
5. In the **Device Update** window, select the type of update (**Delta** or **Complete**), whether to update IQ Engine and Extreme Networks switch images, and the activation times for the updated devices.
6. Select **Enable Distributed Image Upgrade** when WAN speed and traffic usage are concerns.

When Extreme Platform ONE Networking updates the IQ Engine firmware for multiple, same-model APs, it can send the first upgrade to one device and enable the other devices using the same firmware to get their image from that first updated (seed) device.

7. Select **PERFORM UPDATE**.





Related Links

[Configuration | Network Policies](#) on page 150

Configure the SSID for a Standard Wireless Network

A network policy can include one or more wireless networks, commonly referred to as SSIDs. A wireless network SSID is an alphanumeric string that identifies a wireless network, including the set of authentication and encryption services that wireless clients and access point devices use to communicate with each other over the network.

This task is part of the network policy configuration workflow. Use this task to configure an SSID for a standard wireless network.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. Select **2 Wireless**.
4. (Optional) Select **Assign SSIDs using Classification Rules**.
 - a. To add a classification rule, select .
 - b. To specify an existing classification rule, select .

For more information, see [Configure Classification Rules](#) on page 165

**Note**

If you have more than 16 SSIDs, the check box appears dimmed. To enable the check box, reduce the number of SSIDs to fewer than 16.

5. Select an existing SSID and then select ☒, or to add a new one, select ☐.
6. Type a **Name** for the wireless network SSID.

Extreme Platform ONE Networking and IQ Engine use this name to group all the settings related to this wireless network, such as required and optional data rates, DoS policies, MAC filters, and the broadcast SSID.

7. Type a **Broadcast Name** for this wireless network, or accept the one automatically derived from the SSID name.

Clients discover this broadcast name from beacons and probe responses.

8. Select SSID radio broadcast bands:
 - **Wi-Fi 0 Radio (2.4 GHz or 5 GHz):** Broadcast the SSID based on the configuration of the Wi-Fi 0 radio.
 - **Wi-Fi 1 Radio (5 GHz only):** Broadcast the SSID on the Wi-Fi 1 radio operating in the 5 GHz band. Most Extreme Networks devices have two radios: radio 1 is bound to Wi-Fi 0 and radio 2 is bound to Wi-Fi 1. Radio 1 generally operates in the 2.4 GHz band but can also operate in the 5 GHz band on some models. Radio 2 operates in the 5 GHz band.

**Note**

Mapping an SSID to both radio types is a good approach if the devices need to work with some wireless clients that only support 802.11n/b/g, and others that only support 802.11ac/n/a/ac/x. In this case, both Wi-Fi 0 and Wi-Fi 1 must be in access mode or dual mode. If hive members need to support wireless backhaul communications with each other and you want both interfaces to provide client access, then one of the wireless interfaces must be able to provide both access and backhaul links.

- **Wi-Fi 2 Radio (6 GHz only):** This option currently supports only Enterprise WPA3, Personal WPA3, and Open Enhanced. After you select this check box, a message reminds you that WiFi2 supports only 6Ghz band for client access. The configuration menu shows only options applicable to 6Ghz.

9. Select an authentication method and configure the settings.

Table 62: Authentication methods

Method	Configuration
SSID Authentication	<ul style="list-style-type: none"> Select Enterprise WPA/WPA2/WPA3 to require users to authenticate by using a certificate or entering a username and password, and validating against a RADIUS server. Only WPA3 is supported for 6 GHz devices. See Configure Enterprise SSID Authentication on page 196. Select Personal WPA/WPA2/WPA3 to require users to enter a shared passphrase to authenticate. Only Personal WPA3 is supported for 6 GHz devices. See Configure Personal SSID Authentication on page 202. Select Private Pre-Shared Key to allow the use of multiple passphrases on a single SSID. See Configure Private Pre-Shared Key SSID Authentication on page 205. Select Open (not available for 6 GHz) so users do not use any form of authentication, but can be directed to a captive web portal before they can access other network resources. Select Enhanced Open (available only for 6 GHz devices) to provide improved data privacy in open Wi-Fi networks, such as Wifi hotspots and guest WLANs. <p>Note: For security reasons, WEP configuration is no longer available in the UI. If you require WEP for business continuity purposes, you can enable it via Supplemental CLI.</p>
MAC Authentication	See Configure MAC Authentication on page 195.

10. For an Enterprise or Personal SSID, configure the **Protected Management Frames** settings.



Note

Available settings depend on the **Key Management** selection (WPA, WPA2, or WPA3).

Table 63: Protected Management Frames Settings

Setting	Description
802.11w	Toggle 802.11w to ON to prevent forgery and retransmission of management frames.
Use of 802.11w is	<p>If you select a WPA3 level of security, 802.11w is enabled by default at a Mandatory level. The menu and check box appear dimmed.</p> <p>If you select a WPA3 level of security with Transition Mode enabled, 802.11w will be enabled as Optional.</p>

Table 63: Protected Management Frames Settings (continued)

Setting	Description
Use 802.11w protection for broadcasts/multicasts	If you select WPA2 level of security, 802.11w is disabled by default, with option to enable.
Enable Beacon Protection	Enhances Wi-Fi security by safeguarding beacon frames against tampering. Note: Enable Beacon Protection is supported on AP4020/AP5020 only.

11. To create a captive web portal for open authentication, see:

- [Customize and Preview Cloud-based Captive Portal Settings](#) on page 215
- [Customize and Preview Device-based Captive Web Portal Settings](#) on page 208
- [Import Captive Web Portal HTML Files](#) on page 216

12. If you intend to authenticate via RADIUS servers, either select an existing **Default RADIUS Server Group** from the current list or select the plus sign to add a new group.

See [Configure RADIUS Server Settings](#) on page 219 to add a wireless network (SSID)-specific RADIUS object. See [Configure an External RADIUS Server](#) on page 221 to add an external RADIUS common object.

To use classification, select **Apply RADIUS server groups to devices via classification**.

13. If you intend to authenticate via user groups (Enterprise only), turn on **Authentication with ExtremeCloud IQ Authentication Service**.

14. If you intend to use Zero Trust Network Access (ZTNA), turn on **Authentication with ExtremeCloud Universal ZTNA**.




Note

Authentication with ExtremeCloud IQ Authentication Service and **Authentication with ExtremeCloud Universal ZTNA** are mutually exclusive settings.

15. Select an existing user group from the list, or select  and configure the settings.

See [Cloud User Group Settings](#) on page 187 and [Local User Group Settings](#) on page 189.

16. Use the existing **Default User Profile**, select a profile from the list, or select  and configure the settings..

See [Add a User Profile](#) on page 192.

17. (Optional) Under **User Access Settings**, select the **Apply a different user profile to various clients and user groups** check box.

See [Apply Different User Profiles to Clients and User Groups](#) on page 245.

18. To customize the **SSID Availability Schedule**, select the **Restrict the availability of this SSID to selected schedules** check box to enable SSID schedules.

19. Select **Customize**.

To create a new schedule, select , and see [Schedule Settings](#) on page 243.

20. To customize **Advanced Access Security Controls**, see [Customize Advanced Access Security Controls](#) on page 245.
21. To customize **Optional Settings** (not available for 6 GHz), see [Customize Wireless Network Optional Settings](#) on page 248.
22. Toggle **Client Monitor ON** (default) to enable a device to detect client issues, and report client connection activities and problems to Extreme Platform ONE Networking.
23. Toggle **Client Monitor ON** (default) to
24. Select **SAVE**.

Continue configuring the network policy.

Related Links

[Configure Classification Rules](#) on page 165
[Configure Enterprise SSID Authentication](#) on page 196
[Configure Personal SSID Authentication](#) on page 202
[Configure Private Pre-Shared Key SSID Authentication](#) on page 205
[Customize and Preview Cloud-based Captive Portal Settings](#) on page 215
[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208
[Import Captive Web Portal HTML Files](#) on page 216
[Configure MAC Authentication](#) on page 195
[Configure RADIUS Server Settings](#) on page 219
[Configure an External RADIUS Server](#) on page 221
[Cloud User Group Settings](#) on page 187
[Local User Group Settings](#) on page 189
[Apply Different User Profiles to Clients and User Groups](#) on page 245
[Schedule Settings](#) on page 243
[Customize Advanced Access Security Controls](#) on page 245
[Customize Wireless Network Optional Settings](#) on page 248

Cloud User Group Settings

When you configure a user group for an Enterprise 802.1X SSID, the password database always resides in the cloud. For a user group for a Private Pre-Shared Key (PPSK) SSID, the password database can reside in the cloud or on all SSID APs. The following settings are available when you configure a cloud-based user group.

Table 64: Settings for Cloud User Groups

Setting	Description
User Group Name	Type a name for the user group.
Password DB Location	Select Cloud for a cloud-resident password database.
Password Type	Select PPSK or RADIUS .
Description	Type an optional Description for the user group.

Table 64: Settings for Cloud User Groups (continued)

Setting	Description
Enable CWP Register	Select Enable CWP Register to require users in this user group to log in using a captive web portal. Available only if a captive web portal is enabled for this SSID.
PCG Use	(Optional) Available only for the PPSK password type. Select Enable use for Private Client Group .
Password Settings	
Generate Password Using	(Required) Select any combination of characters that you want to include in the password: Letters , Numbers , and Special Characters .
Enforce the use of	Select one of the password enforcement options from the menu: <ul style="list-style-type: none"> • All selected character types • Any selected character types • Only one character type
PSK Generation Method	Available only for the PPSK password type. Select Password Only or User String Password from the menu. With the User String Password option, you can include the user name and a string of characters in front of the generated Private PSKs. If the password generation method is Password Only , then the PPSK password can be between eight and 63 characters. If the generation method is User + String + Password , the maximum passphrase for the Private PSK can be between eight and 31 characters.
Generated Password Length	Select the length for automatically-generated passwords for this user group. Range: 8–63
Concatenating String	Available only for the User String Password PSK Generation Method. Range: 0–8 Use this string to generate PPSKs as User name + Character String + Password. For example, if you enter <code>Extreme</code> , as the string, then the generated PPSKs are <code><User name>Extreme<Password></code> .
Expiration Settings	

Table 64: Settings for Cloud User Groups (continued)

Setting	Description
Account Expiration	<p>Select one of the options from the menu:</p> <ul style="list-style-type: none"> • Never Expire • Valid During Dates <p>Use the calendar and time controls to specify the Start and End dates and times.</p> <ul style="list-style-type: none"> • Valid For Time Period <p>Specify the time period for which the password is valid after ID Creation or First Login. Type the number of hours, days, or weeks. Select the unit of time and the after-condition from the menus.</p> <p>Optionally, select Renew user credentials. To delete credentials after a specific time period, select Delete credentials after, type a value, and then select the unit of time from the menu.</p> <ul style="list-style-type: none"> • Daily <p>Use the Start and End controls to specify the daily time period.</p>
Action at Expiration	<p>Not available for accounts set to never expire.</p> <p>Select Access Rejected to have Extreme Platform ONE Networking block users from renewing their credentials.</p> <p>Select Show Expiration Message to have Extreme Platform ONE Networking present to users an on-screen prompt that they can use to renew their credentials.</p>
Delivery Settings	
Deliver Access Key by	<p>Select the methods for delivery of the access key. Select one or both:</p> <ul style="list-style-type: none"> • Text Messages (SMS) • Email <p>Use the menus to select an email template for each method.</p>

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Local User Group Settings

When you configure a user group for an Enterprise 802.1X SSID, the password database always resides in the cloud. For a user group for a Private Pre-Shared Key (PPSK) SSID,

the password database can reside in the cloud or local on all SSID APs. The following settings are available when you configure a cloud-based user group.

Table 65: Settings for Local User Groups

Setting	Description
User Group Name	Type a name for the user group.
Password DB Location	Select Local to store login credentials on all APs using this SSID. You must select Local to create a private client group in this user group.
Password Type	Select PPSK or RADIUS .
Description	Type an optional Description for the user group.
Set the maximum number of clients per private PSK	(Optional) Available only for the PPSK password type. Select Set the maximum number of clients per private PSK to set per-user PPSK limits for different users in the same wireless network (SSID). Because you can set per-user PPSK limits for different users in the same SSID, you no longer need to configure an SSID for each user group (for instance, with three devices per employee). You can set multiple per-user PPSK limits can be set in the same (SSID). Range: 0-15, 0 = no limit
PCG Use	(Optional) Available only for the PPSK password type. Select Enable use for Private Client Group .
PPSK Classification Use	(Optional) Available only for the PPSK password type. Select Enable user for PPSK Classification only to create a single SSID and distribute unique guest passwords for each location. Use this option with a Private Pre-Shared Key SSID Authentication network policy. See Configure Private Pre-Shared Key SSID Authentication on page 205 for more information.
Password Settings	
Generate Password Using	(Required) Select any combination of characters that you want to include in the password: Letters , Numbers , and Special Characters .
Enforce the use of	Select one of the password enforcement options from the menu: <ul style="list-style-type: none"> • All selected character types • Any selected character types • Only one character type

Table 65: Settings for Local User Groups (continued)

Setting	Description
PSK Generation Method	Available only for the PPSK password type. Select Password Only or User String Password from the menu. With the User String Password option, you can include the user name and a string of characters in front of the generated Private PSKs. If the password generation method is Password Only , then the PPSK password can be between eight and 63 characters. If the generation method is User + String + Password , the maximum passphrase for the Private PSK can be between eight and 31 characters.
Generated Password Length	Select the length for automatically-generated passwords for this user group. Range: 8–63
Concatenating String	Available only for the User String Password PSK Generation Method. Range: 0–8 Use this string to generate PPSKs as User name + Character String + Password. For example, if you enter <code>Extreme</code> , as the string, then the generated PPSKs are <code><User name>Extreme<Password></code> .
Expiration Settings	
Require Authentication After	To force re-authentication after a session is inactive for some time, select Require Authentication After and enter a time in the minutes field.
Account Expiration	Select an option from the menu: <ul style="list-style-type: none"> • Never Expire • Valid During Dates (Available only for PPSK.) Use the calendar and time controls to specify the Start and End dates and times.
Action at Expiration	Not available for accounts set to never expire. Select Access Rejected to have Extreme Platform ONE Networking block users from renewing their credentials. Select Show Expiration Message to have Extreme Platform ONE Networking present to users an on-screen prompt that they can use to renew their credentials.
Delivery Settings	
Deliver Access Key by	Select the methods for delivery of the access key. Select one or both: <ul style="list-style-type: none"> • Text Messages (SMS) • Email Use the menus to select an email template for each method.

Related Links




[Configure the SSID for a Standard Wireless Network](#) on page 183

Add a User Profile

Configure an SSID for a standard wireless network. See [Configure the SSID for a Standard Wireless Network](#) on page 183.

User profiles define user traffic settings on APs. After a user associates with a device, the device assigns the user to a user profile. The device can make this assignment dynamically from attributes returned by a RADIUS authentication server or statically by using the default user profile set.

This task is part of the SSID configuration workflow. Use this task to add a user profile for an SSID, as part of a network policy.

1. While configuring an SSID, go to **User Access Settings > Default User Profile**.
2. To add a new user profile, select .
3. Type a **Name** for the profile.
4. For **Connect to**, select **VLAN** or **VLAN Group**.
5. To select an existing VLAN or VLAN group, select  and choose an existing object, or to add a new one, select .

See [Configure VLAN Settings](#) on page 231 for more information.

6. On the **Security** tab, apply IP or MAC firewall rules.

For more information, see [Configure User Profile Security](#) on page 233.

7. On the **Traffic Tunneling** tab, enable generic routing encapsulation (GRE) traffic tunneling for a user profile.

For more information, see [Configure User Profile Traffic Tunneling](#) on page 237.

8. On the **QoS** tab, set rate limits and traffic forwarding rules for each traffic class.

For more information, see [Configure User Profile QoS](#) on page 241.

9. On the **Availability Schedule** tab, define user profile availability for specific dates, days, and times.

For more information, see [Configure an Availability Schedule](#) on page 242.

10. On the **Client SLA** tab, enable devices to monitor client throughput and take action if the actual throughput is below the targeted minimum level.

For more information, see [Configure User Profile Client SLA](#) on page 243.

11. On the **Date/Time Limit** tab, configure access restrictions for users based on the user's assigned profile.

For more information, see [Configure User Profile Access Restrictions](#) on page 244.

12. Select **Save User Profile**.

Related Links

[Configure VLAN Settings](#) on page 231

[Configure User Profile Security](#) on page 233

[Configure User Profile Traffic Tunneling](#) on page 237

[Configure User Profile QoS](#) on page 241

[Configure an Availability Schedule](#) on page 242

[Configure User Profile Client SLA](#) on page 243

[Configure User Profile Access Restrictions](#) on page 244

SSIDs

An SSID is an alphanumeric string that identifies a wireless or guest network. For information about adding wireless networks, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

To view the list of configured SSIDs, go to **Configuration > Network**, choose an existing network policy, and then select **2 Wireless**.

The SSID table displays the following information about your network SSIDs:

- **SSID Name:** The name assigned to an SSID when it was created. This is the name that APs advertise in beacons (unless the SSID is in stealth mode) and respond to during client probes.
- **SSID Broadcast Name:** This name can be the same as the SSID Name.
- **Access Security:** The method that the SSID uses to secure network access.
- **VLAN:** The VLAN to which this SSID is assigned.
- **Default User Profile:** The user profile that is assigned to this SSID.
- **Used By:** Displays the number of APs and network policies that use this SSID. Hover over any non-zero number to see details.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

SSID Usage in Standard Wireless Networks

As part of configuring a standard wireless network, you must determine how authentication takes place. You can choose SSID authentication or MAC authentication. MAC Authentication is typically used to support legacy clients.



Note

Client mode radios use only PSK or Open SSID authentication.

SSID Authentication

SSID Authentication offers the following types of access security methods:

- **Enterprise WPA/WPA2/WPA3** requires users to authenticate by entering a user name and password, validated against a RADIUS server. Only WPA3 is supported for 6 GHz devices. See [Configure Enterprise SSID Authentication](#) on page 196.
- **Personal WPA/WPA2/WPA3** requires users to enter a shared PPSK to authenticate. Only Personal WPA3 is supported for 6 GHz devices. See [Configure Personal SSID Authentication](#) on page 202.
- **Private Pre-Shared Key** requires users to authenticate by entering a PPSK unique to each user (not available for 6 GHz). See [Configure Private Pre-Shared Key SSID Authentication](#) on page 205.
- **OPEN** (not available for 6 GHz) or **Enhanced Open** does not require users to use any form of authentication, but can direct them to a captive web portal before they can access other network resources. **Enhanced Open** is available only for 6 GHz devices.

MAC Authentication

In Extreme Networks, MAC authentication works by checking a client MAC address against a RADIUS server. The RADIUS server, or an external database with which the RADIUS server communicates, must have an entry with the client MAC address as both user name and password. If the client MAC address matches the entry, it is authenticated, and the AP allows it to access the network as determined by the user profile.

MAC authentication can provide an additional or sole means of authentication. If an SSID employs MAC authentication with another type of access control—PPSK or a captive web portal—MAC authentication occurs first. If it is successful, the AP continues with the rest of the authentication procedure. Otherwise, the authentication process stops, the AP denies network access to the client, and the AP disassociates the client. If you enable MAC authentication and use an open SSID, then MAC authentication becomes the sole means of access control. See [Configure MAC Authentication](#) on page 195.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure Private Client Group Options

First, [Configure Private Pre-Shared Key SSID Authentication](#) on page 205.

This task is part of the network policy configuration workflow. Use this task to configure the options for Private Client Groups.

1. On the **2 Wireless** page for the policy, under **SSID Usage**, select **Private Pre-Shared Key**.
2. Select **Private Group Options**.
3. Select **AP-Based** or **Key-Based**.

AP-Based PCG mode requires a unique user and shared keys. This mode supports common shared devices within personal network spaces. It also requires room assignments for AP anchoring and traffic tunneling.

Key-Based PCG requires one password used by the entire device group. Key-based PCG does not require room assignments for AP anchoring and traffic tunneling.

4. If you selected **Key-Based**, select the following **Private Client Groups Traffic Filtering** options as required.
 - **Enable Broadcast Filtering:** When selected, broadcast frames are not propagated beyond the current PCG domain.
 - **Enable Multicast Filtering:** When selected, multicast frames are not propagated beyond the current PCG domain.
 - **Enable MDNS** (multicast DNS) Filtering—When applied, multicast DNS frames are not forwarded outside the PCG domain.
 - **Enable SSDP** (Simple Service Discovery Protocol)—When enabled, SSDP frames are not forwarded outside of the PCG domain.

When you select **Multicast Filtering**, both mDNS and SSDP filtering are auto-selected. If you do not select **Multicast Filtering**, you can independently select mDNS and SSDP filtering. This capability depends solely on site requirements.

Related Links

[Configure Private Pre-Shared Key SSID Authentication](#) on page 205

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure MAC Authentication

Create a standard wireless network (SSID).

MAC authentication checks a client MAC address against a RADIUS server, and can provide an additional, or sole means of authentication. If an SSID employs MAC authentication with another type of access control, such as PPSK, PSK, or a captive web portal, MAC authentication occurs first. If it is successful, the AP continues the authentication procedure. Otherwise, the authentication process stops, the AP denies network access to the client, and the AP disassociates the client. If you enable MAC authentication and use an OPEN SSID, then MAC authentication becomes the sole means of access control.

This task is part of creating or editing a network policy. Use this task to configure an MAC authentication.

1. Go to **Configuration > Network**.
2. Select **MAC Authentication**, and then toggle the setting to **On**.
3. Select an **Authentication Protocol** to determine how the AP forwards authentication requests from users to an external RADIUS or Active Directory server:



PAP: The AP sends an unencrypted password to the RADIUS server.



Note

When **Authentication with ExtremeCloud Universal ZTNA** is enabled in the SSID authentication settings, PAP is the only option. For more information, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

CHAP or MS CHAP V2: The AP sends the result of an operation it performs on the password, instead of the password itself, to the RADIUS or Active Directory authentication server. The authentication server performs the same operation, and then compares the results to see if they match.

4. Select , and choose an existing RADIUS Server Group, or to add a new one, select .

For more information, see [Configure an AAA Server Profile](#) on page 223

Continue configuring a standard wireless network.


Related Links

[Configure an AAA Server Profile](#) on page 223

Configure Enterprise SSID Authentication

First, create a standard wireless network policy. For more information, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

This task is part of the network policy configuration workflow. Use this task to configure the **SSID AUTHENTICATION** options for Enterprise SSID authentication.

1. On the **2 Wireless** page for the policy, select  to add a new one.
Alternatively, select an existing Enterprise SSID to edit.
2. Under **SSID Usage > SSID Authentication**, select **Enterprise**.
This option requires users to authenticate by entering a user name and password, which the system checks against a RADIUS authentication server.
3. (Optional) Enable Hotspot 2.0 support.
IQ Engine v10.7.4 is required. For more information, see [Configure a Hotspot](#) on page 197.
4. Select the required **Key Management** from the menu, or keep the default value.

Key Management options:

- **WPA3-802.1X** uses 128-bit encryption and automatically enables 802.11w Protected Management Frames, found in the **Advanced Access Security Settings** section of the Wireless Network configuration. If all wireless clients support WPA3, it is a better choice than WPA2.
- **WPA2-802.1X** supports PMK caching and preauthentication (WPA does not). If the wireless clients support WPA2, it is the better choice over WPA. If you have a lot of legacy clients connecting to the network, WPA2 is a good choice.
- **WPA-802.1X** does not support PMK caching or preauthentication. However, if you know that all the clients that are going to use this SSID were released before IEEE 802.11i was ratified in 2004 and only support WPA (not WPA2), this option allows the Extreme Networks devices to support them.

The **Encryption Method** is **CCMP (AES)**. Counter Mode-Cipher Block Chaining Message Authentication Code Protocol (CCMP) uses AES (Advanced Encryption Standard) encryption. CCMP provides message integrity by combining counter mode with CBC (cipher block chaining) to produce a MAC (message authentication code).

5. Toggle **Transition Mode if Applicable** on.

802.11w settings might have been changed. See [Customize Advanced Access Security Controls](#) on page 245 to confirm.

**Important**

Transmission mode with Auto Protected Frame Management across all radios (including 6 GHz) requires IQ Engine 10.7.3. If you push the Auto setting to an AP with IQ Engine below 10.7.3, the AP defaults to the best available 802.11w setting available, and Protected Management Frames is set to **Mandatory**.

For more information, see [Transition Mode Overview](#) on page 204.

6. Select **SAVE**.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure a Hotspot




IQ Engine v10.7.5 or later is required.

**Note**

AP3000, AP5010, and AP5050 models support Hotspot 2.0.

Hotspot 2.0, also called Wi-Fi Certified Passport, is a standard for public access Wi-Fi that provides seamless and secure roaming among Wi-Fi networks and between Wi-Fi and cellular networks.

This task is part of the network policy configuration workflow. Use this task to configure a hotspot for an Enterprise SSID.

1. On the **2 Wireless** page for the policy, select an existing **Enterprise** SSID, or select  to add a new one.
2. From the **Hotspot** list, select **Enabled**.
3. From the **Hotspot Profile** list, select an existing profile, or select  to add a new one.
4. On the **Hotspot Identification** tab, configure the settings to identify the hotspot.
For more information, see [Hotspot Identification](#) on page 198.
5. On the **SP Identification** tab, select an existing Service Provider Profile from the list, or select  and configure the settings.
For more information, see [Service Provider Identification](#) on page 199.
6. On the **Network Characteristics** tab, configure the settings.
For more information, see [Network Characteristics](#) on page 201.
7. On the **Online Signup** tab, configure the settings.
For more information, see [Online Signup](#) on page 202.
8. Select **SAVE**.

Related Links

[Hotspot Settings](#) on page 198


Hotspot Settings

- [Hotspot Identification](#) on page 198
- [Service Provider Identification](#) on page 199
- [Table 67](#) on page 199
- [Network Characteristics](#) on page 201
- [Online Signup](#) on page 202


Hotspot Identification

On the **Hotspot Identification** tab, configure the settings to uniquely identify the hotspot and specify the languages for the venue.

Table 66: Hotspot Identification settings

Setting	Description
Name	(Required) Type a name for the hotspot.
HESSID	(Required) Type the Homogenous Extended Service Set Identifier (HESSID) for the Hotspot 2.0 network. One SSID can be used across multiple WLANs (BSS). A Beacon with the same {HESSID, SSID} pair belongs to same WLAN. The {HESSID, SSID} pair must be unique for each WLAN. By default, the HESSID is the MAC address of the controller Ethernet port. Hotspots can have the same HESSID as long as the SSID is unique. If you configure the HESSID manually, we recommend using an AP BSSID as the HESSID. In a mobility domain, manually configure the HESSID to a unique value, to differentiate it from the value used in the WLAN of the controller.
Domain	(Required) Type the Fully-Qualified Domain Name (FQDN) for the Hotspot 2.0 network. (Default: empty string) Domain names in the domain name list might contain sub-domains. If the FQDN of the service provider is not in the domain name list but is in the realm list, mobile devices that use that service provider are considered to be roaming.
Venue Info	Describe the venue. From the lists of predefined values, first select the category of the venue, and then select the subtype. Example: Institutional, Hospital Select  , configure the settings, and then select ADD .
Operator Name	(Required) Type the name of the venue operator.
Venue Name	(Required) Type the name of the venue.
Language	(Required) Select a language from the list. You can configure up to four languages for each venue.

Service Provider Identification

On the **SP Identification** tab, configure the settings to identify the service provider and configure authentication. Select existing **Service Provider Profiles**, or select  to add a new Service Provider Profile.



Note

Keep your DNS server records up to date so that mobile devices can resolve the server domain names (FQDN).

Mobile devices with a SIM or USIM credential, can obtain a realm from the hotspot NAI Realm list. While hotspot access usually requires 3GPP credentials, a targeted NAI home query is an efficient alternative approach. The device connection manager compares the realm information from the list to the information stored on the device. The connection manager uses the preconfigured user preferences and policy from the mobile device to make a decision between a hotspot AP or a non-hotspot AP, if both are available.

Table 67: Service Provider Profile Settings




Setting	Description
<p>NAI Realm: The Network Access Identification (NAI) Realm list is a list of realms that can be successfully authenticated. Each realm may have up to four supported EAP methods.</p> <ul style="list-style-type: none"> • Add all realms that can authenticate the login credentials or certificate credentials of a mobile device, including the realms of all roaming partners that are accessible from the hotspot AP. Include the realm of the home service provider. • Add a realm for the PLMN ID. This is the cellular network identity based on public land mobile network (PLMN) information. <p>Select  and configure the settings.</p>	
Realm	<p>(Required) Type the Fully-Qualified Domain Name (FQDN) of the service provider.</p> <p>Wildcards are supported for realm. For example, you can enter *.extreme.area120.com, instead of entering specific realms.</p>
EAP Method	<p>From the list, select the Extensible Authentication Protocol (EAP) authentication type.</p> <p>Mobile devices provisioned to authenticate against the home service provider do not require the EAP methods configured for the NAI Realm List.</p>
Description	<p>Type a description for the realm.</p> <p>Although optional, descriptions can be helpful when you are troubleshooting your network.</p>
<p>Roaming Consortium: Use roaming consortium authentication when you do not know all the authenticated realms. Using identifiers unique to the organization in the beacon is a battery-efficient roaming method because ANQP queries are not required. Select , configure the settings for the Roaming Consortium, and then select ADD.</p>	

Table 67: Service Provider Profile Settings (continued)

Setting	Description
Consortium	(Required) Type the Roaming Consortium Organization Identifier (RCOI). Specify up to eight identifiers unique to the organization that are part of the MAC address.
Description	Type a description for the consortium. Although optional, descriptions can be helpful when you are troubleshooting your network.
3GPP CellularNetwork: Create a list of cellular network IDs in the form of mobile country code (MCC), mobile network code (MNC). This list establishes whether an AP has a roaming arrangement with the 3GPP service providers. Select  , configure the settings for a 3rd Generation Partnership Project (3GPP) mobile network, and then select ADD .	
MCC	(Required) Type the mobile country code (MCC).
MNC	(Required) Type the mobile network code (MNC).
Description	Type a description for the 3GPP mobile network. Although optional, descriptions can be helpful when you are troubleshooting your network.
Advanced Settings	<p>Select the arrow to expand this section and configure the following settings:</p> <ul style="list-style-type: none"> • NAI Realm • Roaming Consortium • 3GPP CellularNetwork <p>Note: Advanced Settings override the corresponding settings in the associated Service Provider profiles.</p>

Network Characteristics

On the **Network Characteristics** tab, configure network settings to specify the type of access network, IP address type availability, WLAN metrics, and connection capabilities.

Table 68: Network Characteristics settings


Setting	Description
Access Network: From the list, select the type of access network: <ul style="list-style-type: none"> • Private network—An enterprise network with user accounts. • Private network with guest access—An enterprise network providing guest access. • Chargeable public network—(Default) Open to anyone but access requires payment. • Free public network—An open network, free of charge but may still require acceptance of terms of use (and may involve OSU servers with a captive portal). 	
DGAF	Select DGAF to enable Downstream Group Addressed Forwarding for the access network. If enabled, the system forwards all downlink wireless broadcast ARP and multicast packets. (Default: disabled)
IP Address Type Availability: Mobile devices use information about IP address type availability to make network selection decisions. Select the level of restriction for each network type.	
IPv4	From the list, select the type of IPv4 address: <ul style="list-style-type: none"> • Not Available • Public • Port Restricted • Single NAT • Double NAT • Port Restricted Single NAT • Port Restricted Double NAT • Unknown
IPv6	From the list, select the type of IPv6 address: <ul style="list-style-type: none"> • Not Available • Available • Unknown
WLAN Metrics: Mobile devices use the WAN Metrics settings to make network selection decisions. The mobile device can determine whether necessary throughput is available from the hotspot before connecting. If the mobile device receives indication that the basic service set (BSS) is at capacity, the device will not associate with that AP.	
Link Status	From the list, select a status. (Up, Down, or Test)
Downlink Speed	Specify the download speed in kbps.
Uplink Speed	Specify the upload speed in kbps.
Connection Capability: Select  , configure the settings, and then select ADD . Mobile devices use connection capability information to make network selection decisions by determining which services are blocked or supported at the hotspot.	
Protocol	From the list, select the network protocol.

Table 68: Network Characteristics settings (continued)

Setting	Description
Port Number	Type the port number.
Status	From the list, select a status. (Open, Closed, or Unknown)

Online Signup

With Online Signup (OSU), users who are not part of the provider network can manually connect to the hotspot. This feature also provides added security for users who want to connect anonymously.

From the **Network Authentication Type** list, select an authentication method and configure the settings.

Table 69: Online Signup settings

Setting	Description
Acceptance of Terms and Conditions —Redirection occurs after the user accepts the Terms and Conditions.	
Online Sign up —Authentication supports online enrollment.	
OSU SSID	Type the SSID for the online signup service.
CWP (Captive Web Portal) —Redirection occurs after the CWP authenticates the user.	
Redirection URL	Type the HTTP or HTTPS address for automatic redirection after authentication.

Related Links

[Configure a Hotspot](#) on page 197

Configure Personal SSID Authentication

First, create a standard wireless network policy. For more information, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

This task is part of the network policy configuration workflow. Use this task to configure the **SSID AUTHENTICATION** options for Personal SSID authentication.

1. On the **2 Wireless** page for the policy, select **Personal** SSID Authentication.
This option requires all users to authenticate by entering the same pre-shared key.

2. Choose one of the following **Key Management** options:

- Select **WPA3 (SAE)** to negotiate using WPA3 with clients. If all the wireless clients support WPA3, it is a better choice than WPA2.
- Select **WPA2-(WPA2 Personal)-PSK** to use WPA2 for key management.
- Select **WPA-PSK** to use WPA for key management. WPA does not support PMK caching or pre-authentication, but if the clients were released before IEEE 802.11i was ratified and they support WPA (not WPA2), this option allows the Extreme Networks devices to support them.



Note

For more information, see [Transition Mode Overview](#) on page 204.

3. Choose one of the following **Method** options:

- **HNP/H2E** (default): Enable both Hunting and Pecking (HNP) and Hash to Element (H2E).
- **H2E**: Set the H2E method as the privacy method for the WLAN on all radios (2.4 GHz, 5 GHz and 6 GHz). This option applies only to 6E capable devices (AP4000, AP5010, AP5020, AP5050, AP3000, and 11ax portfolio).



Note

Ensure that networks defined with the option **H2E** are assigned to configuration Profiles of supported devices (AP4000, AP5010, AP5020, AP5050, AP3000, and 11ax portfolio).

- **HNP**: Set the HNP method as the privacy method for the WLAN on all radios (2.4 GHz, 5 GHz and 6 GHz).
- Select the **Enable AKM-24 (WiFi 7 Only)** checkbox to ensure compatibility and compliance with 802.11be.



Note

Applies only to AP4020 and AP5020 devices.

4. Select an **Encryption Method**.

The **Encryption Method** for WPA3 and WPA2 is **CCMP (AES)**. Counter Mode-Cipher Block Chaining Message Authentication Code Protocol (CCMP) uses AES (Advanced Encryption Standard) encryption. CCMP provides message integrity by combining counter mode with CBC (cipher block chaining) to produce a MAC (message authentication code).



Note

When the SSID is configured for WPA3 (SAE), the encryption method is always set to 128-bit encryption.

The **Encryption Method** for WPA-PSK is **TKIP**. Temporal Key Integrity Protocol (TKIP), uses RC4 as its cipher and provides a rekeying mechanism. TKIP ensures that every data packet is sent with a unique encryption key, which is a combination of an Interim Key/Temporal Key and a Packet Sequence Counter. TKIP provides more secure encryption than Wired Equivalent Privacy (WEP), and works on older or legacy WEP hardware with minor upgrades.



Note

ExtremeCloud IQ supports TKIP only for AP3000, AP3000X, AP4000, AP5010, AP5050D, AP5050U models.

5. For **Key Value**, enter the pre-shared key and **Confirm** it.

The **Key Type** is **ASCII Key**.

6. (Optional) To show the **Key Value**, select **Show Password**.

7. Select **SAVE**.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Transition Mode Overview

Transition Mode eases the transition from WPA2 to WPA3 Wi-Fi security by connecting newer client hardware with the latest security standards, and permitting legacy client devices to access the same SSID using older standards.



Important

Transmission mode with Auto Protected Frame Management across all radios (including 6 GHz) requires IQ Engine 10.7.3. If you push the Auto setting to an AP with IQ Engine below 10.7.3, the AP defaults to the best 802.11w setting available, and Protected Management Frames is set to **Mandatory**.

There are three distinct types of transition modes, each functioning in its own unique way:

- **Open to Enhanced Open (OWE)**: Supports both OWE and open standards. Newer devices can connect using OWE, while older client devices can connect without encryption. This is provided through two distinct SSIDs: a visible open network and a similarly-named hidden OWE network. All clients attempt to join the visible open network, but clients that support OWE receive an information element in the open network SSID probe response to join the hidden OWE network instead.

- **WPA2/WPA3 Personal** (PSK to SAE): Supports both WPA2 and WPA3 on a single passphrase protected SSID. Devices supporting WPA3 can connect using WPA3 with SAE, while older devices can still connect using WPA2 with PSK. 802.11w (Protected Frame Management, or PMF) is set to optional on these SSIDs, enabling newer clients to use Protected Frames, while older clients do not.
- **WPA2/WPA3 Enterprise**: Supports both WPA2-Enterprise and WPA3-Enterprise on the same SSID. While all clients use the same backwards-compatible encryption (AES 128), 802.11w is set to Optional on these SSIDs. Newer clients use PMF, while older clients do not.

Transition Mode is only supported on the legacy radio bands (2.4 and 5 GHz), while 6 GHz networks are required to use the newer security standards. To simplify the adoption and use of the same SSIDs across all radios, ExtremeCloud IQ intelligently applies PMF settings on an SSID within an Enterprise network, based on the selected security and radio settings.

Table 70: Transition Mode Security and Radio Settings

	Transition Mode	2.4/5 GHz Enabled	6 GHz Enabled	802.11w Setting
WPA2-Enterprise	N/A	Yes	N/A	Off
WPA3-Enterprise	No	Yes	No	Mandatory
WPA3-Enterprise	Yes	Yes	No	Optional
WPA3-Enterprise	No	Yes	Yes	Mandatory
WPA3-Enterprise	Yes	Yes	Yes	Auto*



Note

*Auto 802.11w requires IQ Engine 10.7.3 or newer.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

[Configure Enterprise SSID Authentication](#) on page 196

[Configure Personal SSID Authentication](#) on page 202

Configure Private Pre-Shared Key SSID Authentication

First, create a standard wireless network policy. For more information, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

A PPSK is a unique pre-shared key assigned to a user rather than to an SSID. With this approach, you can assign different PPSKs and user profiles to different users on the same SSID. If a user is no longer permitted to use the WLAN or a wireless client

becomes lost, stolen, or compromised, you can revoke just that user's PPSK without having to reconfigure the PPSKs on all the other clients.

**Note**

ExtremeCloud IQ Connect does not support Private Pre-Shared Keys.

This task is part of the network policy configuration workflow. Use this task to configure Private Pre-Shared Key SSID authentication options.

1. On the **2 Wireless** page for the policy, under **SSID Usage**, select **Private Pre-Shared Key**.

Private Pre-Shared Key SSID authentication uses WPA2-(WPA2 Personal)-PSK for **Key Management**.

The **Encryption Method** for WPA2-(WPA2 Personal)-PSK is **CCMP (AES)**. Counter Mode-Cipher Block Chaining Message Authentication Code Protocol (CCMP) uses AES (Advanced Encryption Standard) encryption. CCMP provides message integrity by combining counter mode with CBC (cipher block chaining) to produce a MAC (message authentication code).

2. Select **Set the maximum number of clients per private PSK**, and then type the maximum number of simultaneous clients allowed for each PPSK user. (Range: 1 through 15, or type 0 for an unlimited number.)

**Note**

Setting the maximum number of clients per PPSK in the user group to a custom (non-zero) value overrides this setting in the SSID.

3. Select **MAC binding**, and then select an Extreme Networks AP from the menu to define it as a PPSK server.

When you enable this option, an Extreme Networks AP functions as a PPSK server and automatically binds MAC addresses to PPSKs. When the first client authenticates with a PPSK, the PPSK server creates an internal MAC address-to-PPSK binding list for it. If a second client authenticates with the same PPSK, the server automatically binds its MAC address to the PPSK and adds it to the list—if allowed by the configuration. You can configure a PPSK server to bind up to five MAC addresses to one PPSK so users can submit the same PPSK for all their smart phones, tablets, PCs, and other clients.

**Note**

Only APs that you previously configured with static network settings appear in the PPSK server list.

A PPSK server stores PPSK users, binds multiple client MAC addresses to a PPSK, and automatically updates and tracks PPSK-to-MAC address bindings. The AP must be at the site location defined in the network policy. Extreme Networks APs (PPSK authenticators) at the same site contact this server when checking and requesting a user-submitted PPSK binding to the client MAC address.

4. To configure **Private Client Group Options**, see [Configure Private Client Group Options](#) on page 194.

5. Select **PPSK Classification Options** to use this network policy with associated local user groups.

Related Links

[Configure Private Client Group Options](#) on page 194




[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure a Client Mode AP Profile using a Wired Connection and a Device Template

There must be at least one client mode profile configured before you can define a LAN-side AP radio for client mode.

You can set a radio on some AP models to client mode, which enables the AP to connect to existing open and PSK wireless networks, including third-party networks as a generic BYOD client. The method described here is recommended because it is often the fastest way to perform this task.

This task is part of the network policy configuration workflow. Use this task to configure a Client Mode Profile as part of an SSID for a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Configure a client mode AP device template.
 - a. From the **Wireless > Configuration Settings** menu, select **AP Template**.
 - b. Select , and then select an AP model to use as the client mode AP.
 - c. Type a **Template Name**.
 - d. Configure the WAN-side backhaul (WiFi0 or WiFi1) radio for **Backhaul Mesh Link**.
 - e. Select **Client Mode** for the LAN-side client mode radio (WiFi0 or WiFi1).
 - f. Select an existing client mode **Radio Profile** for the LAN-side client mode radio.
 - g. Select **SAVE TEMPLATE**.
5. Add an Open, or PSK SSID, without a captive web portal.

For more information, see [SSID Usage in Standard Wireless Networks](#) on page 193.

Related Links

[SSID Usage in Standard Wireless Networks](#) on page 193

Captive Web Portals

Extreme Networks supports two types of captive web portal (CWP):

- AP hosted portals on built-in web servers
- Extreme Networks hosted portals on cloud web servers

AP hosted portals support several user registration types (user authentication, self-registration to provide user data, use policy acceptance, self-registration to obtain a PPSK) plus an extensive set of configuration options. Cloud server hosted portals support two registration options: users can register by authenticating with their social

media credentials or by requesting and submitting a PIN. A cloud-based CWP also has a simpler set of configuration options.

After defining a CWP, you must take one of two actions for your changes to take effect:

- For an AP hosted CWP, upload the configuration, web page files, and certificates (for secure communications using HTTPS) to your devices.
- For a cloud-based CWP, upload the configuration to your devices. ExtremeCloud IQ automatically stores the web page files and certificates in the cloud.

**Note**

To remove an existing login button that has already been deployed, you must resave the CWP and the Network Policy, and then redeploy the respective network policy to the device.

ExtremeCloud IQ can include multiple CWPs.

Related Links

[Customize and Preview Cloud-based Captive Portal Settings](#) on page 215

[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208





[Import Captive Web Portal HTML Files](#) on page 216

Customize and Preview Device-based Captive Web Portal Settings

To configure a device-based captive web portal (CWP), you must first create a wireless network SSID with **Enterprise 802.1X** access security.

To join the SSID, users enter a user name and password, which are checked against a RADIUS server. When they open a web browser, the captive web portal opens to the **Use Policy Acceptance** (UPA) page. After the user agrees to the UPA, the AP allows them to access the rest of the network as determined by settings in the user profile applied to them.

This task is part of the network policy configuration workflow. Use this task to configure a device-based captive web portal.

1. Go to **Configuration > Network**.
2. Select an existing policy with open access security, and then select , or to add a new one, select .
3. On the **Wireless** tab, select an existing SSID, and then select , or to add a new one, select .
4. In the **SSID Usage** section, toggle **Enable Captive Web Portal** to **ON**.

5. Select **Captive Web Portal**, and then select the features.

Table 71: CWP features

Feature	Description
User Auth on Captive Web Portal	Authenticates users on the splash page.
Enable Self-Registration	Enables user registration on the splash page. Note: The First Name and Last Name fields cannot contain the following characters: \$, `, <, >, +, and #.
Return Aerohive Private PSK	Issues a Private PSK for the user.
Enable UPA	Enables the display of the Use Policy Acceptance page.
Choose Authentication Type:	(This setting is not available if Self-Registration is enabled.) Authenticate using either a Radius Server, or redirect to an external URL.

6. Select **SELECT** to use an existing CWP, or select **ADD**.
7. Enter a **Name** for the CWP.
8. If you selected **Return Aerohive Private PSK**, configure the **PPSK Settings**.

Table 72: PPSK settings

Setting	Description
Choose Access SSID (Private PSK)	Select an access SSID from the menu.
Choose a PPSK Server	Select a PPSK server from the menu.

9. Select **CUSTOMIZE AND PREVIEW > CUSTOMIZATION AND PREVIEW**.
Alternatively, you can import HTML files. See [Import Captive Web Portal HTML Files](#) on page 216.
10. [Preview and Customize the Landing Page](#) on page 214.
11. [Preview and Customize the Use Policy Acceptance Page](#) on page 214.
12. [Preview and Customize the Success Page](#) on page 214.
13. [Preview and Customize the Error Page](#) on page 215.
14. Enable or disable the **Success Page**.
15. Enable or disable **Redirect clients after a successful login attempt**.
When enabled, Extreme Platform ONE Networking sends successful clients to either the login page or to a specified URL.
16. Enable or disable the **Failure Page**, and choose the page to display the failure message.
When enabled, Extreme Platform ONE Networking displays the failure message on either the login page or the standard failure page. See [Preview and Customize the Error Page](#) on page 215.
17. Enable or disable **Redirect clients after a failed login attempt**.
When enabled, Extreme Platform ONE Networking sends unsuccessful clients to either the login page or to a specified URL.

18. Configure the default language, and additional languages.

Table 73: Supported languages

Setting	Description
Default Language	Select the Default Language from the menu.
Support Additional Languages	Select the additional languages you intend to support.

Extreme Platform ONE Networking adds the files required for the selected languages to the default CWP directory when you save the CWP.

19. Expand the **Advanced Configuration** section, and configure the settings.

Table 74: Advanced configuration settings


Setting	Description
Session Timer	Select Display session timer alert before session expires to display the session timer in the client browser. The timer shows the login status for the registered client, the time remaining in the session, and the elapsed time. You can choose to display the timer alert 5, 15, or 30 minutes before the session expires.
Network Settings	Select Use default settings to use the default IP address and netmask for the interface hosting the SSID with the captive web portal, or an admin-defined IP address and netmask. Select Customize to enter an IP address and netmask for each of the interfaces. You can use IPv4 or IPv6 addresses.
DHCP and DNS servers > Use external servers	
Use external servers	Select Use external servers to forward DHCP and DNS traffic from unregistered clients to external servers on the network. When enabled, unregistered and registered clients must be assigned to the same VLAN.
Override the VLAN ID used during registration	Select Override the VLAN ID used during registration and choose a previously defined VLAN ID from the drop-down list to assign to clients before and during the registration process. Select  to add a new VLAN ID.
DHCP and DNS servers > Use Extreme Network Devices	

Table 74: Advanced configuration settings (continued)

Setting	Description
Use Extreme Networks Devices	<p>Select Use Extreme Network Devices to forward DHCP and DNS traffic from unregistered clients to internal servers on the AP hosting the CWP. When enabled, unregistered and registered clients can be assigned to the same VLAN or to different VLANs, because unregistered clients use DHCP and DNS servers on the AP, and registered clients use servers on the network.</p> <p>Note: When the client of a previously unregistered guest first associates with the Guest Access SSID, the AP acts as a DHCP server, DNS server, and web server. Client network access is limited to the AP with which it is associated, and the client browser redirects to a registration page. After the guest registers, the AP stores the client MAC address as a registered client and allows the guest to access external servers.</p>
Lease Time	<p>Type the length of the DHCP lease assigned to the quarantined client of an unregistered guest, and choose the unit of time measure from the menu.</p> <p>DHCP clients typically renew at the midpoint of the lease. After the client successfully registers, the AP allows the next DHCP lease request to pass to an external DHCP server. Keeping the lease short allows the client to obtain new network settings soon after registering.</p>
Renewal Response	<p>From the menu, choose how you want the AP to respond to a DHCP lease renewal request for a nonexistent lease.</p> <ul style="list-style-type: none"> • Renew-NAK-Broadcast: By default, the AP responds by broadcasting DHCPNAK messages. Choosing either this option or the unicast DHCPNAK option can accelerate the transition to an external DHCP server on the network, or back to a quarantined address after the client logs out or the session times out. • Renew-NAK-Unicast: Choose to have the AP respond by sending unicast DHCPNAK messages. Sending unicast messages can reduce traffic on the network; however, broadcasting the DHCPNAK is safer in environments where there is a large and uncontrollable variety of clients. • Keep Silent: Choose to have the AP ignore the renewal request completely and enable the external DHCP server to respond. With this approach, the transition between DHCP servers can be slightly longer.
Web Servers	

Table 74: Advanced configuration settings (continued)


Setting	Description
Registration Period	Set the length of time that a registered client with an active session remains registered. Type a value and choose the unit of time measure from the menu. If the client closes one session and later starts a new one while the AP still has a roaming cache entry for that client (one hour by default), the client does not have to register with the captive web portal again. If the client closes a session and starts a new session after the roaming cache entry has been removed, the client must complete the registration process again, even if the new session begins within the registration period.
Domain Name	Type the same domain name as the CN (common name) value in the server certificate that the CWP uses for HTTPS. The domain name must be a valid domain name that a DNS server can resolve to the IP address of the interface hosting the CWP. This option allows you to use a server certificate from a CA that supports domain names as CNs, but not IP addresses. Note: If the CN has a wildcard domain name that can match multiple valid domain names, enter one of the valid domain names instead of selecting Override Web server domain name with CN value in the certificate . For example, if the CN is *.aerohive.com, then you can enter something like cwp.aerohive.com in the Web Server Domain Name field, and the clients' browsers will not show a security warning when they make an HTTPS connection to the captive web portal.
Security	
Enable HTTPs	Select Enable HTTPs to enable HTTPS on the CWP.
HTTPS certificate	Select Default-CWPCert.pem for preloaded CWPs. The AP hosting the CWP then uses HTTPS to secure traffic between the client and its CWP server. The certificate file must have the following properties: <ul style="list-style-type: none"> • The file format must be PEM (Privacy Enhanced Mail). • It must contain a server private key stored in an unencrypted format. • It must contain a server certificate concatenated to the private key.
Override Web server domain name with CN value in the certificate	Select to replace the Web server domain name with the common name value in the certificate.
Client Redirection	
Use HTTP 302	Select Use HTTP 302 to redirect code as the redirection method instead of JavaScript. This option is useful for clients accessing the network with mobile browsers.

Table 74: Advanced configuration settings (continued)

Setting	Description
Introduce a delay before redirecting after a successful login attempt	Specify how long the CWP displays the success page before initiating the redirection. Type a value in seconds.
Introduce a delay before redirecting after a failed login attempt	Specify how long the CWP displays the failure page before initiating the redirection. Type a value in seconds. Note: This redirection differs from that in the Captive Web Portal Failure Page Settings section, which the AP applies after a failed log in attempt.
Prevent the Apple CNA (Captive Network Assistant) application from requesting credentials	Select Prevent the Apple CNA (Captive Network Assistant) application from requesting credentials to bypass the Apple CNA application for redirect actions.

20.To create a walled garden, select , and configure the settings.

Table 75: Walled garden settings

Setting	Description
Service Type	Select one of the following options: <ul style="list-style-type: none"> • Web: Permit client access only to the World Wide Web. • All: Permit client access to the World Wide Web and all other servers. • Advanced: Permit client access only to the admin-defined IP object or host name. <p>If you selected Web or All, paste IP addresses or host names separated by commas into the Service Type text box. Then select ADD.</p> <p>If you selected Advanced, configure the settings, and then select ADD.</p>
IP Object/Host Name	Enter an IP object or host name of the external web server. Choose a previously-defined IP address or host name from the menu, enter a new IP address or domain name, or select  and define a new one.
Service	Select the service from the menu: Web, All, or Protocol.
Protocol Number	(Protocol service only) Type a protocol number (from 0 to 255).
Port	(Protocol service only) Type a port number to define the type of service you want to permit.

21. Select **SAVE CWP**.

Return to the **Wireless Network** page to complete the network policy configuration.

Related Links

[Import Captive Web Portal HTML Files](#) on page 216

[Configure the SSID for a Standard Wireless Network](#) on page 183

Preview and Customize the Landing Page

This task is part of [Customize and Preview Device-based Captive Web Portal Settings](#) on page 208. Use this task to preview and customize the landing page for a device-based captive web portal.

1. Select **LANDING PAGE** to preview the landing page.
2. Select **CUSTOMIZE** to modify the landing page colors, logo, language, and message text.
3. Select **SAVE CUSTOMIZATION**.
4. Select the corresponding check boxes to enable fields and to specify which fields are required.
5. Select **SAVE CONFIGURATION**, or select **USE POLICY ACCEPTANCE**.

Next, [Preview and Customize the Use Policy Acceptance Page](#) on page 214.

Related Links

[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208

[Preview and Customize the Use Policy Acceptance Page](#) on page 214

Preview and Customize the Use Policy Acceptance Page

This task is part of [Customize and Preview Device-based Captive Web Portal Settings](#) on page 208. Use this task to preview and customize the use policy acceptance page for a device-based captive web portal.

1. Select **USE POLICY ACCEPTANCE** to preview the page that displays the use policy.
2. Select **CUSTOMIZE** to modify the page colors, logo, language, and message text.
3. Select **SAVE CUSTOMIZATION**.
4. Select **SAVE CONFIGURATION**, or select **SUCCESS PAGE**.

Next, [Preview and Customize the Success Page](#) on page 214

Related Links

[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208

[Preview and Customize the Success Page](#) on page 214

Preview and Customize the Success Page

This task is part of [Customize and Preview Device-based Captive Web Portal Settings](#) on page 208. Use this task to preview and customize the success page for a device-based captive web portal.

1. Select **SUCCESS PAGE** to preview the page that appears after a successful login.
2. Select **CUSTOMIZE** to modify the page colors, logo, language, and message text.
3. Select **SAVE CUSTOMIZATION**.
4. Select **SAVE CONFIGURATION**, or select **ERROR PAGE**.

Next, [Preview and Customize the Error Page](#) on page 215.

Related Links

[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208

[Preview and Customize the Error Page](#) on page 215

Preview and Customize the Error Page

This task is part of [Customize and Preview Device-based Captive Web Portal Settings](#) on page 208. Use this task to preview and customize the error page for a device-based captive web portal.

1. Select **ERROR PAGE** to preview the page that appears after an unsuccessful login.
2. Select **CUSTOMIZE** to modify the page colors, logo, language, and message text.
3. Select **SAVE CUSTOMIZATION**.
4. Select **SAVE CONFIGURATION**.

Related Links





[Customize and Preview Device-based Captive Web Portal Settings](#) on page 208

Customize and Preview Cloud-based Captive Portal Settings

To configure a cloud-based captive web portal (CWP), you must first create a wireless network SSID with **Open** access security. For more information, see [Captive Web Portals](#) on page 207.

Extreme Networks provides two types of cloud-hosted CWPs. One controls network access by leveraging user credentials in social media services like Google and LinkedIn. The other type authenticates users by requiring them to enter a PIN, which is sent to them by email, to gain network access. Both CWP types are available in Extreme Platform ONE Networking.

This task is part of the network policy configuration workflow. Use this task to configure a cloud-based CWP.

1. Go to **Configuration > Network**.
2. Select an existing policy with open access security, and then select , or to add a new one, select .
3. On the **Wireless** tab, select an existing SSID, and then select , or to add a new one, select .
4. In the **SSID Usage** section, toggle the **Enable Captive Web Portal** setting **ON**.
5. Select **Cloud Captive Web Portal**.
6. To use social media services, select **Social Login**, or to require a PIN for logging in, select **Request a PIN**.

If you require a PIN, Extreme Platform ONE Networking sends a randomly generated PIN to authenticate the user.

7. Select an existing CWP or select **ADD**.
 - a. If you selected **ADD**, enter a new **Name** for the CWP.
 - b. Enter the length of time that the PIN remains valid.

The validity period begins when Extreme Platform ONE Networking receives the PIN request and can last from 1 to 24 hours.

- c. Enter an email address where you want Extreme Platform ONE Networking to send daily reports about successfully authenticated users on this CWP.
Each report is in CSV format and shows the login time (in UTC, or universal coordinated time) when the user submitted a PIN, the user name, and the MAC address of the client device used for the connection. Extreme Platform ONE Networking sends a separate email for when there are no entries to report.
- d. Set the hour and minute when Extreme Platform ONE Networking generates a daily report of successful user authentications.
Extreme Platform ONE Networking reports the time in UTC, and the report contains events for the previous 24 hours.
- e. Use the default CWP without customization, or toggle **Customize** to **ON** and select **PIN-Login-Example** to export the necessary files.
- f. Modify the files and import them in the **New Captive Web Portal** window.
- g. Select **Upload/Remove**, navigate to the files on your system and upload them.
- h. Select **Done**.
- i. Select the files you want to use for the **Login** and **Success** pages, and then select **SAVE CWP**.

The imported files are immediately saved to Extreme Platform ONE Networking.



Note

If you previously completed the configuration with default files and uploaded the network policy to your APs, you do not need to upload the configuration again.

If the customized files have the same name as the default files, the custom files overwrite the default files after import to Extreme Platform ONE Networking.

8. Select **Use a different captive web portal for various clients** to use other CWPs for different clients based on device classification and classification rules.
9. Select **Select a Classification Rule** to choose an existing rule, and then select **Link**.
To add a new classification rule, select **Add a Classification Rule** and complete the steps. For more information, see [Configure Classification Rules for a Device Template](#) on page 305.

Return to the Wireless Network page to complete the network policy configuration.

Related Links

[Configure Classification Rules for a Device Template](#) on page 305

[Configure the SSID for a Standard Wireless Network](#) on page 183





Import Captive Web Portal HTML Files

To import an HTML file for a captive web portal (CWP), you must first create a wireless network SSID and enable CWP.

This task is part of the network policy configuration workflow. Use this task to import an HTML file for your captive web portal configuration.

**Note**

Import HTML overrides the settings that are configured in **Customize and Preview**.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. On the **Wireless** tab, select an existing SSID, and then select , or to add a new one, select .
4. In the **SSID Usage** section, toggle the **Enable Captive Web Portal** setting **ON**.
5. Select **Captive Web Portal**.
6. On the **New Captive Web Portal** page, select **IMPORT HTML**.
7. Select **UPA-Example** to download a template that you can modify.
8. Select an existing **Web File Directory**, or select **Create** and type a new file directory name.
9. Select **Upload/Remove**, navigate to the files on your system and upload them.
10. Select **DONE**.
11. Select a file to use for the **Login Page**.
12. Select a file to use for the **Success Page**.
13. (Optional) Select **Redirect clients after a successful login attempt**.
14. Select the files you want to use for the **Login** and **Success** pages, and then select **SAVE CWP**.

There is no need for a failure page because error messages appear on the **Login** page rather than requiring navigation to a separate page. Extreme Platform ONE Networking immediately saves the imported files.

**Note**

If you previously completed the configuration with default files and uploaded the network policy to your APs, you do not need to upload the configuration again.

If the customized files have the same name as the default files, the custom files overwrite the default files after import to Extreme Platform ONE Networking.

Return to the **Wireless Network** page to complete the network policy configuration.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

RADIUS Authentication

RADIUS authentication is for use by Enterprise WPA/WPA2 802.1X and WEP 802.1X SSIDs, MAC authentication, and captive web portals that require user authentication. Extreme Networks devices use the wireless network (SSID) RADIUS server group for RADIUS lookups, unless there is a classification rule directing them to a different

group based on location or other parameters. The servers in the group can be external RADIUS servers, Extreme Networks RADIUS servers, Extreme Networks proxy servers, or a combination of these three types.

**Note**

The WEP protocol is no longer effective for securing wireless networks. For security reasons, WEP configuration is no longer available in the UI. If you require WEP for business continuity purposes, you can enable it via Supplemental CLI.

Related Links

- [Configure a RADIUS Server Group](#) on page 218
- [Configure RADIUS Server Settings](#) on page 219
- [Configure an External RADIUS Server](#) on page 221
- [Configure an Extreme Networks RADIUS Server](#) on page 222
- [Configure a RADIUS Proxy Server Realm](#) on page 229
- [Add an Active Directory Server](#) on page 225
- [Add an LDAP Server](#) on page 226

Configure a RADIUS Server Group

You must first create a wireless network SSID with **Enterprise 802.1X (WPA/WPA2/WPA3)** access security. This option requires users to authenticate themselves by entering a user name and password, which are checked against a RADIUS authentication server.



RADIUS servers offer two different types of services:

- Authentication for user credentials (usually on port 1812)
- Accounting (logging) (usually on port 1813)



Extreme Networks devices use the default wireless network (SSID) RADIUS server group, which can include up to four RADIUS servers, for RADIUS lookups, unless there is a device classification rule directing them to a different RADIUS server group. The servers in the group can be external RADIUS servers, Extreme Networks A3 RADIUS servers, Extreme Networks RADIUS servers, Extreme Networks proxy servers, or a combination of these four types.

Security for RADIUS servers uses simple passwords. Configure one password on the server, and the other on each of the clients.

This task is part of the network policy configuration workflow. Use this task to configure a RADIUS server group for an SSID, as part of a network policy.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. In the **Authentication Settings** section, toggle the **Authentication with ExtremeCloud IQ Authentication Service** setting **OFF**.

The **Authenticate via RADIUS Server** section becomes available.

5. To add an existing RADIUS server group, select  and choose an existing object, or to add a new one, select .
6. Type a **RADIUS Server Group Name**.
7. (Optional) Type a **RADIUS Server Group Description**.
Although optional, descriptions can be helpful when you are troubleshooting your network.
8. Configure the RADIUS server settings for IQ Engine devices.
See [Configure RADIUS Server Settings](#) on page 219.
9. Depending on the type of server that you want to add, select one of the following tabs:

Tab	Configuration task
EXTERNAL RADIUS SERVER	Configure an External RADIUS Server on page 221
EXTREME NETWORKS A3	Configure an Extreme Networks A3 Server on page 222
EXTREME NETWORKS RADIUS SERVER	Configure an Extreme Networks RADIUS Server on page 222
EXTREME NETWORKS RADIUS PROXY	Configure an Extreme Networks RADIUS Proxy on page 228

Select up to four existing servers to add to your wireless network (SSID) RADIUS server group.

10. Select **SAVE RADIUS**.



Note

In addition to those set by you, or by default, Extreme Networks APs report updated DHCP-snooped IP addresses of associated clients to the RADIUS server asynchronously, or as soon as the information is available.


Related Links

[Configure RADIUS Server Settings](#) on page 219

Configure RADIUS Server Settings

First begin configuring a RADIUS server group. See [Configure a RADIUS Server Group](#) on page 218.

This task is part of the network policy configuration workflow. Use this task to configure RADIUS server settings for IQ Engine devices for a RADIUS server group, as part of a network policy.

1. On the **Configure RADIUS Servers** page, select  and configure the following settings:

Setting	Description
Retry Interval	Specify the time between retries for an unresponsive primary RADIUS server Access-Request. The device retries the primary server after the interval elapses, even if the current backup server is responding. Range: 60–100000000 (seconds) Default: 600 Note: Do not enter commas in this field. Enter 100,000,000 as 100000000.
Accounting Interim Update Interval	Specify the interval for sending RADIUS accounting updates to report the client session status and cumulative length. Range: 10–100000000 (seconds) Default: 600 Note: Do not enter commas in this field. Enter 100,000,000 as 100000000.
Permit Dynamic Change Of Authorization Messages (RFC 3576)	Enable the RADIUS server to dynamically change the authorization for a user, or to disconnect a user per RFC 3576. When you enable this parameter, devices acting as RADIUS authenticators can accept unsolicited disconnect and Change of Authorization (CoA) messages from a RADIUS authentication server, such as GuestManager, per RFC 3576. Disconnect messages terminate a user session immediately, and CoA messages modify session authorization attributes such as VLANs and user profile IDs.
Inject Operator-Name attribute	Select to include the Operator-Name attribute in the Access-Request and Accounting-Request messages that the Extreme Networks RADIUS authenticators send to the RADIUS authentication server. The attribute value is the domain name suffix of the Extreme Networks authenticator, usually assigned by DHCP, and helps to identify the authentication requests source. Providing source information like this can aid in troubleshooting authentication problems.

Setting	Description
Message Authenticator attribute	The Message Authenticator attribute is an HMAC-MD5 checksum of the entire Access-Request packet, containing the Type, ID, Length, and Authenticator field, using the shared secret as the key. This ensures the authenticity and integrity of the packet. ExtremeCloud IQ uses this attribute to authenticate RADIUS server replies, and to encrypt passwords.
Override default failover settings	Select this option to override the default RADIUS server failover and retry interval. The retry interval is the number of seconds between RADIUS server requests. Select Aggressive or Custom (Range 1-5) . Set the First retry interval . (Default: 1) Set the Max-retries value, which is the maximum number of retries, before failing over to a configured backup RADIUS server. (Default: 3)

2. Select **SAVE RADIUS SETTINGS**.

Finish configuring the RADIUS server group.

Related Links


[Configure a RADIUS Server Group](#) on page 218


Configure an External RADIUS Server

First begin configuring a RADIUS server group. See [Configure a RADIUS Server Group](#) on page 218.

To add an external RADIUS server, you require the IP address, authentication port number, and the shared secret for the RADIUS server.

This task is part of the network policy configuration workflow. Use this task to configure a RADIUS server for a RADIUS server group, as part of a network policy.

1. On the **Configure RADIUS Servers** page, select **EXTERNAL RADIUS SERVER**.
2. Select an existing server, or select .
3. Type a **Name** for the server.
4. (Optional) Type a **Description** for the server.
5. Select the **IP/Host Name** for the server.

If you do not see the IP address that you need, select  to define a new one (IPv4 or IPv6).

If the address object is a host name, ensure that the devices can resolve it to an IP address. If you configure a domain name for the devices, or if the devices dynamically receive a domain name through DHCP, and the RADIUS server belongs to the same domain, the RADIUS server name can be just the host name without the domain name. If the RADIUS server belongs to a different domain, the address object must be the fully qualified domain name (FQDN): the host name + the domain name.

6. For **Server Type**, choose the RADIUS server role:
 - **Authentication:** As an authentication server, the RADIUS service requests that the client device demonstrate its identity.
 - **Port:** Set the RADIUS authentication port.
 - **Accounting:** As an accounting server, the RADIUS service tracks client-server session details.
 - **Port:** Set the RADIUS accounting port number.
7. Type the **Shared Secret** for authenticating communications with the RADIUS server.
8. (Optional) Select **Show Password**.
9. Select **SAVE EXTERNAL RADIUS**.

Finish configuring the RADIUS server group.

Related Links


[Configure a RADIUS Server Group](#) on page 218

Configure an Extreme Networks A3 Server

You must have existing A3 RADIUS server services.

First, begin configuring a RADIUS server group. See [Configure a RADIUS Server Group](#) on page 218.

This task is part of the network policy configuration workflow. Use this task to configure an A3 server for a RADIUS server group, as part of a network policy.

1. On the **Configure RADIUS Servers** page, select **EXTREME NETWORKS A3**.
2. Select an existing server, or select .
3. Type a **Name** for the server.
4. (Optional) Type a **Description**.
5. Enter the **IP/Hostname** of the server.
6. Accept the defaults or enter specific **Server Type** ports.
7. Type the **Shared Secret** for authenticating communications with the A3 server.
8. (Optional) Select **Show Password**.
9. Select **SAVE EXTREME NETWORKS A3**.

Finish configuring the RADIUS server group.

Related Links

[Configure a RADIUS Server Group](#) on page 218


Configure an Extreme Networks RADIUS Server

First begin configuring a RADIUS server group. See [Configure a RADIUS Server Group](#) on page 218.

Extreme Networks devices can serve as RADIUS authentication servers and respond to 802.1X requests from other Extreme Networks devices acting as RADIUS authenticators. The Extreme Networks RADIUS server can store user accounts locally, or check user

login credentials against user accounts stored externally on the following user database servers: Active Directory, or LDAP.

This task is part of the network policy configuration workflow. Use this task to configure an Extreme Networks RADIUS server for a RADIUS server group, as part of a network policy.

1. On the **Configure RADIUS Servers** page, select **EXTREME NETWORKS RADIUS SERVER**.
2. Select a **User Database Type** from the menu.
3. Select an existing server, or select .
4. Select the devices to configure.
5. Configure the AAA Server Profile.

See [Configure an AAA Server Profile](#) on page 223.

Related Links

[Configure an AAA Server Profile](#) on page 223

Configure an AAA Server Profile

First, configure an Extreme Networks RADIUS Server. See [Configure an Extreme Networks RADIUS Server](#) on page 222.


Extreme Networks devices can serve as RADIUS authentication servers and respond to 802.1X requests from other Extreme Networks RADIUS authenticators. The Extreme Networks RADIUS server can store user accounts locally or check user login credentials against user accounts stored externally on Active Directory or LDAP (lightweight directory access protocol) user database servers.

This task is part of the network policy configuration workflow. Use this task to configure an AAA server profile.

1. On the **Wireless** tab, select **Add Radius Server Group**.
2. Select **EXTREME NETWORKS RADIUS SERVER**.
3. Type a **RADIUS Server Group Name**.
4. Type an optional **RADIUS Server Group Description**.
5. Select the **User Database** type.
 - **Active Directory**: Select to enable an Extreme Networks RADIUS server to interoperate with an Active Directory server.
 - **LDAP Server**: Select to direct user account look-ups to one or more LDAP servers.
 - **Local Database**: Select to enable an Extreme Networks device to support authentication for local user groups.
6. Select the corresponding check boxes for the devices that you want to configure.
7. Select **CREATE NEW** to add a new AAA server profile.

Alternately, select **USE EXISTING**, and then select an AAA server profile from the list.
8. Type a **Profile Name**.
9. Type an optional **Profile Description**.
10. Select the **User Database** type: **Active Directory**, **LDAP Server**, or **Local Database**.

Available configuration options depend on the type of database that you select.

11. Type a **User Group Attribute**, and then select , and choose an existing user group.
12. Expand the **Additional Settings** section, and then enter the number of seconds for each response scenario.

The **Additional Settings** section is not available for local databases.

13. Select **Enable Caching of Credentials** to improve performance across WAN links.
14. Type the number of seconds to retain the credential cache.
15. Complete the database-specific configuration options as follows:

User database type	Configuration
Active Directory	See Add an Active Directory Server on page 225.
LDAP Server	See Add an LDAP Server on page 226.
Local Database	The Extreme Networks device that authenticates users directly, maintains the user database locally.

16. Select **Security Options**, and then [Configure AAA Server Security Options](#) on page 224.
17. Select **Approved RADIUS Clients**, and then [Add Approved RADIUS Clients](#) on page 230.
18. Select **SAVE RADIUS SERVER**.

Continue configuring the RADIUS server profile.

Related Links

[Configure an Extreme Networks RADIUS Server](#) on page 222

[Add an Active Directory Server](#) on page 225

[Add an LDAP Server](#) on page 226

[Configure AAA Server Security Options](#) on page 224

[Add Approved RADIUS Clients](#) on page 230

Configure AAA Server Security Options

Configure an Extreme Networks device as a RADIUS Server.

This task is part of the network policy configuration workflow. Use this task to add increased security to the AAA Server Profile. For more information, see [Configure an AAA Server Profile](#) on page 223.



Note

Default certificates are intended to be used for testing only.

1. Select an **Authentication Protocol** from the drop-down list.
 - **TLS** requires mutual authentication using client-side certificates. With a client-side certificate, a compromised password is not enough to break into TLS-enabled systems because the intruder still needs the client-side certificate. A password is only used to encrypt the client-side certificate for storage. Credentials

are used for a one-time certificate enrollment. The certificate is sent to the RADIUS server for authentication.

- **PEAP** encapsulates EAP within a potentially encrypted and authenticated TLS tunnel. The user must enter their credentials, which are sent to the RADIUS Server that verifies the credentials, and authenticates them for network access.
- **TTLS** extends TLS. The client can, but does not have to, be authenticated via a CA-signed PKI certificate to the server. This greatly simplifies the setup procedure since a certificate is not needed for every client.
- **LEAP** uses dynamic WEP keys and mutual authentication between the client and RADIUS server. Uses an authentication protocol in which user credentials are not strongly protected and are easily compromised. Users who absolutely must use LEAP should do so with sufficiently complex passwords.



Note

The WEP protocol is no longer effective for securing wireless networks. For security reasons, WEP configuration is no longer available in the UI. If you require WEP for business continuity purposes, you can enable it via Supplemental CLI.

- **MD5** offers minimal security, is vulnerable to dictionary attacks, and does not support key generation. This method is commonly used in a trusted network.
2. Select a **Default Authentication Protocol** from the drop-down list.
 3. Select the default certification authority digital certificate type.
 4. Select the default server digital certificate type.
 5. Select whether to verify the server certificate file.
 6. Enter the client key file password.
 7. Select whether to **Check common name in certificate against the user for TLS authentication**.
 8. Select the authentication that has been assigned to a user.
 9. If you **Enable Authentication**, the recommended value for the **Age Timeout for Active Session** is three times the value of the **Accounting Interim Update Interval** in the RADIUS Client.



For example, if the Accounting Interim Update Interval is set to 600 seconds, set the Age Timeout for Active Session to 1800 seconds.

Continue configuring the server.

Add an Active Directory Server

First, configure an AAA server profile. See [Configure an AAA Server Profile](#) on page 223.

This task is part of the network policy configuration workflow. Use this task to add an Active Directory (AD) database to an Extreme Networks device acting as a RADIUS Server.

1. For Step 3, on the **Configure RADIUS Servers** page, to add an existing AD server, select  and choose an existing object, or to add a new one, select .
2. Type a **Name** for the AD server.


3. Type the name of the **Domain**, to which the RADIUS authentication server and the AD server both belong.
(Range: 1–64 characters). Include parent domains, such as .com, .net, and .org.
4. Select **Auto** or **Manual**.

Setting	Description
Auto	Extreme Platform ONE Networking automatically populates the Active Directory Server and the base distinguished name (BaseDN) parameters. Go to Step 9 on page 226.
Manual	Go to Step 5.

5. From the drop-down list, choose a previously-defined IP object or host name for the **Active Directory Server** that contains the user accounts the RADIUS authentication server will authenticate.
If you do not see the one that you need listed, select **New** and enter an IP object or host name.
6. Type the **BaseDN**—The starting point for directory server searches, and the point in the directory tree structure where the server stores user accounts.
7. Type a **Short Domain Name**.
8. Type the **Realm** name that corresponds to the user account location, which is often the same as the domain name.
9. Set the organizational unit (OU) where the Extreme Networks RADIUS server has privileges to add itself as a computer in the domain or leave it blank.

**Note**

By default, the RADIUS server attempts to add itself into **Computers** unless you specify a computer-ou here. If you do not want to give a device access to the Computers container, you can create your own OU and give the device user permissions to create computers (that is, to add itself) to the specified OU. For example, the computer OU might be `wireless/APs`.

10. Select **Enable TLS Encryption** to encrypt the user look-up requests that the Extreme Networks RADIUS server sends to the Active Directory server.
11. Select **NEXT**.
12. Select an existing **DNS Server**, or select  to create a new one.
13. Select **NEXT**.

Continue configuring the RADIUS server.



Related Links

[Configure an AAA Server Profile](#) on page 223

Add an LDAP Server

First, configure an AAA server profile. See [Configure an AAA Server Profile](#) on page 223.

This task is part of the network policy configuration workflow. Use this task to add an Lightweight Directory Access Protocol (LDAP) database to an Extreme Networks device acting as a RADIUS Server.

1. On the **Configure RADIUS Servers** page, to use an existing LDAP server, select  and choose an existing object, or to add a new one, select .
2. Configure the settings.
See [LDAP Server Settings](#) on page 227

Continue configuring the RADIUS server.

Related Links

[LDAP Server Settings](#) on page 227

[Configure an AAA Server Profile](#) on page 223

LDAP Server Settings

Table 76: Settings for LDAP servers



Setting	Description
Name	Type a Name for the new or cloned server.
LDAP Server	Specify an IP Address or Host Name . Select  and choose an existing object, or to add a new one, select  .
Description	(Optional) Although optional, entering a description is helpful for troubleshooting and for identifying the server.
RADIUS User Base DN	Type the RADIUS user base distinguished name, or the starting point for directory server searches, such as cn=visitors, and the point in the directory tree structure under which the server stores user accounts in its database. Note: Extreme Platform ONE Networking supports up to 2000 users per user group. For more than 2000 users, you must separate the users into different user groups.
Bind DN Name	Type the LDAP client distinguished name used during the authentication part of an LDAP session, such as cn=users, cn=students, dc=southamerica, ou=student, and ou=school.
Bind DN Password	Type the password for the LDAP client distinguished name for use during the authentication part of an LDAP session.
Show Password	Select Show Password to see the password.
Communication	Select LDAP or LDAPS for the required communication protocol.
Optional Settings	
Filter Attribute	Enter required Filter Attribute for searching for elements below the baseObject.

Table 76: Settings for LDAP servers (continued)

Setting	Description
Strip realm name from filter	Select the check box to disable the realm, which is commonly appended to a user name and delimited with an @ sign, from the filter.
Destination Port	(Required) Enter the LDAP server Destination Port .
TLS Authentication/Encryption	Select the check box to enable Transport Layer Security authentication and encryption, and configure the settings.
TLS Authentication/Encryption	
CA Certificate File	(Required) Select the default certification authority digital certificate type from the list.
LDAP Client Certificate	(Required) Select the default LDAP client digital certificate type from the list.
Client Key File	(Required) Select the default client key digital certificate type from the list.
Key File Password	Type the client key file password.
Show Password	Select the check box to see the password.
Verify Server	Choose how often the Extreme Networks device checks the relationship between a certificate and its server: <ul style="list-style-type: none"> • Try (on first authorization or authentication) • Never • Demand (as required, on demand)

Configure an Extreme Networks RADIUS Proxy

First begin configuring a RADIUS server group. See [Configure a RADIUS Server Group](#) on page 218.

This task is part of the network policy configuration workflow. Use this task to to configure an Extreme Networks device as a RADIUS proxy server.

1. On the **Configure RADIUS Servers** page, select **EXTREME NETWORKS RADIUS PROXY**.
2. Select the device to configure as a proxy.
3. Type a **Name** for the proxy.
4. Type a **Description**.

Although optional, descriptions can be helpful when you are troubleshooting your network.

5. For the **Realms** section, see [Configure a RADIUS Proxy Server Realm](#) on page 229.
6. For the **Approved RADIUS Clients** section, see [Add Approved RADIUS Clients](#) on page 230.

7. For the **Realm Settings** section, see [Configure Realm Settings](#) on page 230.
8. Select **SAVE RADIUS PROXY**.

Related Links



[Configure a RADIUS Server Group](#) on page 218
[Configure a RADIUS Proxy Server Realm](#) on page 229
[Add Approved RADIUS Clients](#) on page 230
[Configure Realm Settings](#) on page 230

Configure a RADIUS Proxy Server Realm

First configure an Extreme Networks Device as a RADIUS proxy server. See [Configure an Extreme Networks RADIUS Proxy](#) on page 228.

You can add a postfix notation realm after a user name, separated by an "@" symbol, and the result resembles an email address domain name. Or you can add a prefix notation realm before a user name, with a backslash "\" separator. User names can also include multiple realms, for example `domain1.com\username@domain2.com` is a valid user name with two realms. Realms can be arbitrary text and do not need to contain real domain names, even though they can look like domains.

This task is part of the network policy configuration workflow. Use this task to configure realms for a RADIUS proxy.

1. On the **Configure RADIUS Servers** page, select **REALMS**.
2. Select **ADD A RADIUS SERVER GROUP** to display and configure the settings.
See [Configure a RADIUS Server Group](#) on page 218.
3. Configure **Required Realms**.
 - a. Select the **Default Realm** from the menu.
 - b. Select **Strip the realm name from the proxied access requests** to remove the realm name from proxied access requests.
 - c. Select the **RADIUS Server Group** from the menu.
4. To create a realm, select an existing realm and then select , or to add a new one, select .
 - a. Type the **Realm Name**.
 - b. Select a RADIUS server group from the menu.
 - c. Select **Strip the realm name from the proxied access requests** to remove the realm name from proxied access requests.
 - d. Select **ADD**.
5. Select **SAVE RADIUS PROXY**.

Continue configuring the proxy server.




Related Links

[Configure an Extreme Networks RADIUS Proxy](#) on page 228
[Configure a RADIUS Server Group](#) on page 218

Add Approved RADIUS Clients

Configure an Extreme Networks device as a RADIUS proxy server. See [Configure an Extreme Networks RADIUS Proxy](#) on page 228.

This task is part of the network policy configuration workflow. Use this task to add one or more approved RADIUS clients to each configured realm associated with a RADIUS proxy server.

1. On the **Configure RADIUS Servers** page, select **APPROVED RADIUS CLIENTS**.
2. Select .
3. To use an existing **IP/Host Name/Network** for a client, select  and choose an existing object, or to add a new one, select .
4. Type the associated **Shared Secret** (password).
5. To see the password, select **Show Password**.
6. (Optional) Type a **Description**.
Although optional, entering a description is helpful for troubleshooting and for identifying the approved RADIUS client list.
7. Select **ADD**.
8. Select **SAVE RADIUS PROXY**.

Next, see [Configure Realm Settings](#) on page 230.

Related Links

[Configure an Extreme Networks RADIUS Proxy](#) on page 228

[Configure Realm Settings](#) on page 230

Configure Realm Settings

Configure an Extreme Networks device as a RADIUS proxy server and create a realm.

- [Configure an Extreme Networks RADIUS Proxy](#) on page 228
- [Configure a RADIUS Proxy Server Realm](#) on page 229

This task is part of the network policy configuration workflow. Use this task to optimize the realm settings for a RADIUS proxy.

1. On the **Configure RADIUS Servers** page, select **REALM SETTINGS**.
2. Select a **User and Realm Name** format:
 - NAI (Network Access Identifier)—The standard syntax is `user@realm`.
 - Windows NT Domain—The standard syntax is `user1@example.com`.
 - SPN (service principal name)—The standard syntax is `serviceclass/host`.
 - AUTO—Extreme automatically applies a format.
3. Type the **Retry Delay**—The time interval between retries.
4. Type the **Retry Count**—The number of retries before declaring failure.
5. Type the **Dead Time**—The time elapse (in seconds) before declaring failure.
6. Select **Inject Operator-Name Attribute**.

If you do not want to inject an operator-named attribute, clear the check box.

7. Select **SAVE RADIUS PROXY**.

Finish configuring the RADIUS proxy.





Related Links

[Configure an Extreme Networks RADIUS Proxy](#) on page 228

[Configure a RADIUS Proxy Server Realm](#) on page 229

Configure VLAN Settings

This task is part of the SSID configuration workflow. Use this task to set the default user profile and configure the VLAN settings.

1. Go to **Configuration > Network**
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Select an existing SSID and then select , or select .
5. Scroll to **User Access Settings**, select the **Default User Profile**, and configure the settings.
 - To edit the selected **Default User Profile**, select the link and configure the settings.

Typically, the default VLAN is 1.



Note

The user profile **default-profile** cannot be edited directly. If this profile is assigned to your wireless network, you must either select a different profile or create a new one to configure the settings.



- To choose a new default user profile, select  menu.
- To create a new user profile, select .

Table 77: User profile settings




Setting	Description
User Profile Name	Type a User Profile Name .
Connect to	a. Select VLAN or VLAN Group . b. Select  and choose an existing object, or to add a new one, select  . For more information, see VLAN Object Settings on page 232 and VLAN Group Object Settings on page 233. To edit an existing VLAN object, select it and then select  .
SECURITY	See Configure User Profile Security on page 233.
TRAFFIC TUNNELING	See Configure User Profile Traffic Tunneling on page 237.
QOS	See Configure User Profile QoS on page 241.

Table 77: User profile settings (continued)

Setting	Description
AVAILABILITY SCHEDULE	See Configure an Availability Schedule on page 242.
CLIENT SLA	See Configure User Profile Client SLA on page 243.
DATA/TIME LIMIT	See Configure User Profile Access Restrictions on page 244.

6. Select **SAVE USER PROFILE**.

Continue the SSID configuration.

Related Links

[VLAN Group Object Settings](#) on page 233

[Configure Classification Rules for a Device Template](#) on page 305

VLAN Object Settings

Configure the following settings, and then select **SAVE VLAN**.

Table 78: Settings for VLANs

Setting	Definition
Name	(Required) Type a name for the new VLAN.
VLAN ID	(Required) Type an ID for the new VLAN.
Apply VLANs to devices using classification	Select Apply VLAN to devices for classification to create VLANs that you can apply to specific devices based on their location.

Related Links

[Configure VLAN Settings](#) on page 231

VLAN Group Object Settings

VLAN groups combine multiple VLANs as a single common object. Configure the following settings, and then select **SAVE**.

Table 79: Settings for VLAN group objects



Setting	Definition
Name	(Required) Type a name for the new VLAN group object.
VLANs	(Required) Specify individual VLANs or ranges. Indicate a range with a hyphen. Separate VLAN entries with commas, for example, 1-30, 100-200, 500. Range: 1-4094
Description	(Optional) Type a description to identify the VLAN group. Although optional, descriptions can be helpful when you are troubleshooting your network.

Related Links

[Configure VLAN Settings](#) on page 231

Configure User Profile Security

Use this task to apply IP or MAC firewall rules to a user policy.

- On the **SECURITY** tab, turn on **Firewall Rules**.
- To redirect a user device to an external web site, select **IP Firewall** and complete the following steps:
 - Select .
 - Type a **Name** for the firewall rule.
 - Select whether this firewall rule is for **Inbound Traffic** or **Outbound Traffic**.
 - Select whether this firewall rule is used to **Permit** or **Deny** traffic.
Permit enables traffic to traverse the firewall. **Deny** prevents the device from allowing traffic inside the firewall.
 - Select an existing IP firewall rule or select  to create a new rule.
See [Add IP Firewall Policies](#) on page 234.
- To determine how the device manages traffic based on source and destination IP addresses, select **MAC Firewall** and complete the following steps:
 - Enter a name for the firewall rule.
 - Select whether this firewall rule is for **Inbound Traffic** or **Outbound Traffic**.
 - Select whether this firewall rule is used to **Permit** or **Deny** traffic.
 - Select an existing MAC Firewall Rule or select the plus sign to create a new rule.
See [Add MAC Firewall Policies](#) on page 236.
- Continue configuring the user profile, or select **SAVE USER PROFILE**.

Related Links




[Add IP Firewall Policies](#) on page 234

[Add MAC Firewall Policies](#) on page 236

[Configure VLAN Settings](#) on page 231

Add IP Firewall Policies

Use this task to create IP firewall policy objects and rules that determine how the device manages traffic based on network or application services, and source and destination IP addresses.

1. Select an existing IP firewall policy rule, and then select , or to add a new one, select .
2. Enter a **Name** for the new policy.
3. Enter an optional **Description**.
4. Select  to add a new rule.
5. Select one or more network or application services.

Network Service objects identify Layer 4 traffic by protocol and port number.

Extreme Networks provides a number of predefined services. Select the add icon to create a new network service. For more information, see [Configure Network Services](#) on page 235.

- a. Choose either **Network Services** or **Application Services**.
You cannot select both.
 - b. Select up to 100 items.
 - c. Select **Add Service**.
6. Select a source IP address, host name, network, or **Any** from the drop-down list, or select **New** to add a new IP address, host name, or network.
 7. Select a destination IP address, host name, network, or **Any** from the drop-down list, or select **New** to add a new IP address, host name, or network.
 8. Select the action the device performs when it receives traffic matching the source address-destination address-service.

The firewall can perform the following actions:

- **Permit:** Allows traffic to traverse the firewall.
- **Deny:** Blocks traffic from traversing the firewall.
- **Drop traffic between stations:** Drops traffic between stations if both stations are associated with one or more members of the same hive. This setting applies to unicast, broadcast, and multicast traffic that the device receives on an interface in access mode.
- **NAT:** Translates the source IP address of a packet permitted to traverse the firewall to that of the mgt0 interface on the device.

9. Choose one of the following logging options from the drop-down list:
 - **Off:** Disables logging for packets and sessions that match the IP firewall policy rule.
 - **Session Initiation:** Log details about a session created after passing an IP firewall policy lookup.
 - **Session Termination:** Log details about a session matching an IP firewall policy termination.
 - **Both:** Log details after initiating and terminating a session.
10. Select **Save**.

As you continue to add rules to a policy, each subsequent rule is positioned at the bottom of the list. Use the up and down arrows in the rules table to rearrange the position of rules to determine their application order.

Related Links

[Configure Network Services](#) on page 235

Configure Network Services

Network service objects identify Layer 4 traffic by protocol and port number. Extreme Platform ONE Networking provides some predefined services and you can create custom network services to use when defining firewall policies, and QoS traffic classification and marking policies.


The Network Services table displays the following information about predefined and custom network service objects:

- **Name:** The name of the network service object.
- **Protocol Number:** The type of protocol (followed by its standard protocol number) that the service uses. Predefined services use the following protocols:
 - 1: ICMP (Internet Control Message Protocol)
 - 6: TCP (Transmission Control Protocol)
 - 17: UDP (User Datagram Protocol)
 - 89: OSPF (Open Shortest Path First)
 - 119: SVP (SpectraLink Voice Priority)
- **Port Number:** The standard destination port number of the service. The receiving device uses the port number to map the service to a particular processor.
- **Service Idle Timeout:** The amount of time (in seconds) after which the device terminates an inactive session using this service. (For IP firewall policies, this field is only supported by APs.)
- **ALG Type:** An ALG (application layer gateway) links certain port numbers to a service so that the device can apply the proper QoS (Quality of Service) and firewall policies. For example, the TFTP service has a control stream and data stream that each use different port numbers. The port number for the TFTP control stream is static (port 69 by default), but the port number for the TFTP data stream is dynamic and is negotiated within the control session. The TFTP ALG links these two streams together logically so that the device can apply the proper QoS and firewall policies to both TFTP streams. You can apply different QoS settings to the TFTP control and

data sessions, for example, to ensure high reliability but tolerate high latency, or to ensure accept a medium level of reliability but require low latency.

- **Description:** An optional description for the object. Descriptions can be very useful when troubleshooting or managing a complex network.
- **Virtual IQ :** The name of the Virtual IQ (virtual ExtremeCloud IQ) to which the service belongs. All predefined services are marked as global to indicate that they belong to all Virtual IQs. This column only appears when you are logged in to "All Virtual IQs" with super-user privileges.

Use this task to configure a network service:

1. Select .
2. Enter a name for the service.
3. Select a service idle timeout (for APs and routers only).
This is the amount of time (in seconds) after which the device terminates an inactive session using this service.
4. Select an IP Protocol number.
The number of the protocol the service will use. Predefined services appear in the drop-down list, or you can configure a custom protocol.
5. Enter the standard destination port number of the service.
For services that use TCP or UDP, you must set a destination port number, which the receiving device uses to map the service to a specific processor. When you use a custom protocol, a destination port number is not required because the receiving device can use the protocol to map the service to the appropriate processor.
6. Select an ALG type from the drop-down list.
ALG is supported for APs and routers only. If the service must use an ALG, select DNS, FTP, HTTP, SIP, or TFTP, from the drop-down list. Otherwise, leave this field empty.




Related Links

[Add IP Firewall Policies](#) on page 234

Add MAC Firewall Policies

MAC firewall policies determine how the device manages traffic based on source and destination IP addresses, and the actions (permit or deny) the device can take. When the policy contains multiple rules, the order of the rules affects how they are applied. Use this task to create a new rule.

Use this task to add MAC firewall policy objects and rules.

1. Select an existing IP firewall policy and then select , or to add a new one, select .
2. Enter a **Name** for the new policy.
3. Enter an optional **Description**.
4. Select  to add a new rule.

5. For **Source MAC**, select **Any**, an existing MAC OUI or the plus sign.
If you choose to add a new **Source MAC**, select **MAC Address** or **MAC OUI** and perform the following:
 - a. Enter a new name.
 - b. Enter the **MAC Address** or **MAC OUI**.
6. For **Destination MAC**, select **ANY**, an existing MAC OUI or the plus sign.
If you choose to add a new **Source MAC**, select **MAC Address** or **MA OUI** and do the following:
 - a. Enter a new name.
 - b. Enter the **MAC Address** or **MAC OUI**.
7. Select the action the device performs when it receives traffic matching the source address-destination address-service.
The firewall can perform the following actions:
 - **Permit**: Allows traffic to traverse its firewall.
 - **Deny**: Blocks traffic from traversing its firewall.
8. Choose one of the following logging options from the drop-down list:
 - **Off**: Disable logging for packets and sessions that match the MAC firewall policy rule.
 - **Session Initiation**: Log session details about a session created after passing a MAC firewall policy lookup.
 - **Session Termination**: Log session details about a session matching a MAC firewall policy termination.
 - **Both**: Log session details after initiating and terminating a session.
9. Select **Save**.

As you continue to add rules to a policy, each new rule is positioned at the bottom of the list. Use the up and down arrows in the rules table to rearrange the position of rules to determine their application order.

Related Links

[Configure User Profile Security](#) on page 233

Configure User Profile Traffic Tunneling

You can enable the following types of GRE traffic tunneling for new and existing user profiles:

Layer 3 Roaming

Adjusts roaming thresholds so that a device disassociates with a wireless client that has roamed to it from another subnet and has either been idle for a period of time, or for which traffic is below a specified threshold.

Identity-Based Traffic Tunneling

Tunnels guest traffic directly to the network.

Standard GRE Tunneling

Tunnels traffic to non-Extreme Networks tunnel endpoints.

Tunnel Concentrator

Tunnels traffic to Extreme Networks Tunnel Concentrator.

Use this task to configure traffic tunneling for a user profile.

1. On the **TRAFFIC TUNNELING** tab, turn on **Traffic Tunneling (GRE)**.
2. Select an existing profile from the **Re-use Tunnel Policy** menu, and then select the type of tunneling.
3. For **Layer 3 Roaming**:
 - a. Specify a time period between 10 and 600 seconds.
 - b. Specify a threshold number between 0 and 2147483647 packets per minute.
4. For **Identity-Based Traffic Tunneling**:
 - a. For the **Tunnel Source**, select a subnet from the drop-down list, or add a new subnet.
 - b. For **Tunnel Destination**, choose an IP address or host name from the drop-down list or add a new address or host name.
 - c. For **Tunnel Authentication**, type the password the AP uses to authenticate to the GRE termination point.
5. For **Standard GRE Tunneling**:
 - a. For **Tunnel Destination**, choose an IP address or host name from the drop-down list or add a new address or host name.
 - b. If you select **Tunnel Mode dot1q**, type, select, edit, or add the 802.1Q native VLAN ID.

To add a VLAN ID, see [Configure VLAN Settings](#) on page 231.
 - c. If you select **Tunnel Mode Access Mode**, type, select, edit, or add the VLAN ID.

To add a VLAN ID, see [Configure VLAN Settings](#) on page 231.
6. For **Tunnel Concentrator**, select the **Tunnel Destination**.

You can add a new Tunnel Concentrator service, or edit an existing instance. For more information, see [Single Tunnel Concentrator Services Settings](#) on page 239 and [Redundant Tunnel Concentrator Services Settings](#) on page 239.
7. Continue configuring the user profile, or select **SAVE USER PROFILE**.

Related Links

[Configure VLAN Settings](#) on page 231

[Single Tunnel Concentrator Services Settings](#) on page 239

[Redundant Tunnel Concentrator Services Settings](#) on page 239

Single Tunnel Concentrator Services Settings

Table 80: Single Tunnel Concentrator

Field	Description
Name	(Required) Type a name to identify the new Tunnel Concentrator service.
Description	(Optional) Provide a description that might be helpful when troubleshooting.
Single Tunnel Concentrator	(Required) Select this option to create a single Tunnel Concentrator without redundancy.
Tunnel IP Address/CIDR	(Required) Type the IP Address for the tunnel (CIDR).
Gateway	(Optional) Type the IP address of the gateway.
Native VLAN ID	(Required) Type the Native VLAN ID. The Native VLAN is untagged.
Device Tunnel Concentrator	(Required) Select a Tunnel Concentrator from the menu.
Tunnel Port	(Required) Select a port from the menu.
VLAN ID	(Required) Type the VLAN ID. (Optional) For an untagged VLAN, select the corresponding check box.
Bridge Port	(Required) Select a bridge port for the tunnel from the menu.

Related Links

[Configure User Profile Traffic Tunneling](#) on page 237

Redundant Tunnel Concentrator Services Settings

Table 81: Redundant (Primary and Backup) Tunnel Concentrators

Field	Description
Name	(Required) Type a name to identify the new Tunnel Concentrator service.
Description	(Optional) Provide a description that might be helpful when troubleshooting.

Table 81: Redundant (Primary and Backup) Tunnel Concentrators (continued)

Field	Description
Redundant Tunnel Concentrator	(Required) Select this option to create a redundant Tunnel Concentrator.
Tunnel IP Address/CIDR	(Required) Type the IP Address for the tunnel (CIDR).
Gateway	(Optional) Type the IP address of the gateway.
VRRP Router ID	(Required) Type the ID for the VRRP router. ExtremeCloud IQ configures the same VRRP Router ID for both the primary and backup Tunnel Concentrators (range 1-255). The VRRP Router ID must be different for each cluster of VRRP devices.
Native VLAN ID	(Required) Type the Native VLAN ID. The Native VLAN is untagged.
Device Tunnel Concentrator	(Required—Primary and Backup) Select a primary Tunnel Concentrator from the menu. Select a backup Tunnel Concentrator from the menu.
Tunnel Port	(Required—Primary and Backup) Select a port for the tunnel from the menu for the primary Tunnel Concentrator from the menu. Select a port for the tunnel from the menu for the backup Tunnel Concentrator from the menu.
VLAN ID	(Required—Primary and Backup) Type the VLAN ID for the primary and for the backup Tunnel Concentrators. (Optional) For an untagged VLAN, select the corresponding check box.
IP Address	(Required—Primary and Backup) Type the IP address for the primary and the backup Tunnel Concentrators.
Bridge Port	(Required—Primary and Backup) Select a bridge port for the tunnel from the menu for the primary Tunnel Concentrator. Select a bridge port for the tunnel from the menu for the backup Tunnel Concentrator.

Related Links

[Configure User Profile Traffic Tunneling](#) on page 237

Configure User Profile QoS

Extreme Networks devices can apply QoS to traffic originating from members of user profiles to prioritize traffic by category, set rate limits and traffic forwarding rules for each traffic class, and set the maximum traffic forwarding rate and scheduling weight at two levels: for individual users in a user profile and for all users to whom the user profile applies. Through the rate control and queuing profile, you define QoS policing rates and scheduling weights at the individual user level. In the **QoS** section in a user profile configuration, you define the rates and weights at the user profile level. Through the combined configuration of forwarding mechanisms and rate limits, you control how a device schedules traffic forwarding.

1. On the **QOS** tab, turn on **Quality of Service (QoS)**.
2. Configure the **Rate Limit per User Profile per AP** to set the aggregate rate limit for all the users in the user profile.
3. Select **Manage Rate Limit per Client**.
 - a. Set the **Rate Limit Per Client** from 0 to 2000 Mbps (0-2000000 Kbps).
 - b. Set a weight percentage for each of the seven traffic classes in **Traffic Queue Management Per User per AP**, and set other details as required.
 - c. Select **Save**.
4. Type the **Scheduling Weight**.



Note

Devices forward traffic of a higher class and greater weight faster than traffic of a lower class and lesser weight.

5. Select a QoS classification system from the **Mark outgoing traffic using** list.

Extreme Networks devices can apply priority and class mappings to outgoing traffic based on either of the standard QoS classification systems.
6. To add a marker map, see [Configure Marker Maps](#) on page 241.
7. Continue configuring the user profile, or select **SAVE USER PROFILE**.

Related Links

[Configure Marker Maps](#) on page 241

[Configure VLAN Settings](#) on page 231

Configure Marker Maps



For outgoing traffic, you can define marker maps to map classes to priority numbers in standard classification systems (802.11e, 802.1p, and DSCP). After you define classifier and marker maps, you then define classifier and marker profiles that enable one or more of the methods defined in the maps. Finally, you associate those profiles with SSIDs or interfaces to apply the mappings to traffic arriving at or exiting those interfaces.

Use the following procedures to configure marker maps for outgoing traffic. When you configure marker maps at the network policy level, you can reuse existing maps. Select

the list, and in the dialog box, select the check box of a map and choose **Select**. All fields are automatically populated with the information for the selected map.

**Note**

Deleting a marker map from the Location Server dialog box also deletes it from the Common Objects list. You can only delete a marker map if no other configuration object is using it. To see a list of configuration objects that reference a marker map, hover over the number in the **Used By** column for that map in the Marker Maps window in the Common Objects section.

1. Select an existing map, and then select , or to add a new one, select .
2. Enter a **Name** for the marker map.
3. Enter an optional **Description** for the map.
4. On the **802.1p Markers** tab, toggle **802.1p Markers** to **On**.

The QoS marking table shows the mapping of classes to WMM® (Wi-Fi Multimedia™) queues and the 802.1p classification system (marked in the L2 frame header in Ethernet frames). You can modify these mappings if necessary.

Extreme Network devices automatically include 802.1p priority marking in the L2 headers of wireless frames, so it is not included here as a configurable option.

Depending on the classification systems used in the surrounding network, select the appropriate check boxes to map classes to one or both systems for outgoing traffic. A network policy can reference just one marker map.

5. On the **Diffserv** tab, toggle **Diffserv** to **On**.

The QoS marking table shows the mapping of classes to WMM® (Wi-Fi Multimedia™) queues and the DiffServ codepoint marking system (marked in the L3 packet header) on outgoing packets. You can modify these mappings if necessary.

**Note**

If both 802.1p and DiffServ are enabled, only DiffServ takes effect.

Related Links

[Configure User Profile QoS](#) on page 241


Configure an Availability Schedule

Begin to [Configure VLAN Settings](#) on page 231.

You can make the user profile available for specific dates, days, and times by assigning defined availability schedules to the profile. Profile members can access the network through the device only during these scheduled times. When the user profile is inactive, the device blocks access to the network.

Use this task to enable the Availability Schedule feature and configure the settings when creating a user profile as part of a network policy.

1. On the **AVAILABILITY SCHEDULE** tab, turn on **Availability Schedule**.

2. Select  and configure the settings.
See [Schedule Settings](#) on page 243.
3. Continue configuring the user profile, or select **SAVE USER PROFILE**.

**Note**

To apply your SSID availability schedule to a wireless network, you must activate it in the **Additional Settings** section of the Standard Wireless Networks configuration page. See [Configure Enterprise SSID Authentication](#) on page 196.

Related Links

[Schedule Settings](#) on page 243

[Configure Enterprise SSID Authentication](#) on page 196

[Configure VLAN Settings](#) on page 231

Schedule Settings

Table 82: Settings for a One Time Schedule

Setting	Description
Name	Type a name for the schedule.
Description	(Optional) Type a description for the schedule.
One Time	Select to apply this schedule one time only.
Start Time	Use the Start and Time controls to specify the starting date and time for the schedule.
End Time	Use the End and Time controls to specify the end date and time for the schedule.

Table 83: Settings for a Recurring Schedule

Setting	Description
Name	Type a name for the schedule.
Description	(Optional) Type a description for the schedule.
Recurring	Select to apply this schedule on an ongoing basis.
Recurrence	Select Every Day , or select From and use the menus to select the day of the week to start, and the day to end the recurrence.
Limit recurrence between	Select the check box to apply the schedule to a specific date range. Use the controls to specify the start and end dates.

Related Links

[Configure an Availability Schedule](#) on page 242

Configure User Profile Client SLA

Service-level agreements (SLAs) are contracts that specify the performance parameters within which a network service is provided.

Extreme Networks devices monitor client throughput and take action if the actual throughput is below the defined target minimum level. Use this task to enable client SLA settings for the user profile.

1. On the **CLIENT SLA** tab, turn on **Client SLA**.
2. Use the **Targeted minimum throughput** slider bar to adjust the minimum throughput level.
3. Select **Log** to generate a log entry about the performance sentinel violation.
4. Select **Boost Airtime** to increase the airtime available to clients so they can reach their targeted minimum throughput level.
5. Select both **Log** and **Boost Airtime** to combine the previous two actions.

**Note**

Using just the Log option to see if wireless clients throughout the corporate network are SLA-compliant is useful even without the Boost Airtime option. When clients do not get the expected level of throughput, you can see the results in graphs in the Extreme Platform ONE Networking SLA reports. For Extreme Networks devices with non-compliant clients, you can drill down in the graph to see an SLA report for each client and determine why it is not meeting the SLA. If you conclude that the devices are oversubscribed, you can add more devices in that area to improve client throughput.

6. Continue configuring the user profile, or select **SAVE USER PROFILE**.

Related Links

[Configure VLAN Settings](#) on page 231

Configure User Profile Access Restrictions

Use this task to configure access restrictions (date and time limits) for users based on their assigned user profiles. This is particularly helpful when you manage non-employee guest users, such as visitors, VIPs, and contractors.

1. On the **DATA/TIME LIMIT** tab, turn on **Access Restrictions**.
2. Select **Time Limit**.
 - a. Select the limit in minutes, hours, days, or weeks (the number of minutes in a number of hours, or hours in days, or days in weeks).
 - b. Select how to define an hour (either a fixed or rolling time window).
3. Select **Data Usage Limit**.
 - a. Configure a data usage limit (in MB or GB).
 - b. Limit the duration to days, weeks, or months.
 - c. Select how a day is measured (either a fixed or rolling time window).
4. Continue configuring the user profile, or select **SAVE USER PROFILE**.

Related Links

[Configure VLAN Settings](#) on page 231








Apply Different User Profiles to Clients and User Groups

Before you can apply different user profiles, configure the SSID for the network. For more information, see [Configure the SSID for a Standard Wireless Network](#) on page 183.

With user-profile assignment rules, you can assign clients to user profiles that match all configured conditions. The available conditions are as follows:

- Advanced Guest Policy
- Client OS Type
- Client MAC Address
- Client Location
- Schedule
- Cloud Config Group

This task is part of the network policy configuration workflow. Use this task to apply different user profiles to clients and user groups as part of a network policy.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Under **User Access Settings**, select **Apply a different user profile to various clients and user groups**.
5. To choose an existing user profile, select  and choose an existing object, or to add a new one, select .
6. To add an existing user profile assignment rule, select 
 - a. Select one of the existing rules.
 - b. Select **Link**.
7. (Optional) To add a new user profile assignment rule, select 
 - a. Type a **Name** for the user profile assignment rule.
 - b. Type a **Description**.
 - c. Select , and choose a category.
 - d. Complete the configuration for the selected category.

See [Configure Classification Rules](#) on page 165.

You can add multiple assignment rules to create more granular control.

8. Select **SAVE**.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

[Configure Classification Rules](#) on page 165

Customize Advanced Access Security Controls

This task is part of the network policy configuration workflow. Use this task to configure and manage the cryptographic keys used to encrypt Wi-Fi traffic during the four-way

handshake authentication process between an AP and clients, and to manage and set up Pairwise Transient Keys.





1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Select an existing SSID, and then select , or to add a new one, select .
5. Expand the **Additional Settings** section.
6. For **Advanced Access Security Controls** (802.11w, Authentication timeout options), select **CUSTOMIZE**.
7. Configure the settings:

Table 84: Settings for Advanced Access Security Controls

Setting	Description
Advanced Authentication Options	
Generate new Group Master Key (GMK) after	Type the time interval, after which the system generates a new GMK. Select the unit of time (seconds, minutes, hours, or days) from the list. The GMK is a large random number that an Extreme Networks device chooses. From the GMK, the device derives a GTK (Group Temporal Key), which it then sends to all associated clients within EAPOL-key messages. The Extreme Networks device and clients use the GTK to encrypt and decrypt broadcast or multicast traffic transmitted between themselves.
Generate New Group Temporal Key (GTK) after	Type the time interval, after which the system generates a new GTK. Select the unit of time (seconds, minutes, hours, or days) from the list. The wireless client and Extreme Networks device use a GTK to encrypt to and decrypt broadcast and multicast traffic transmitted between themselves. A GTK is a temporal key that an Extreme Networks device derives from a GMK (Group Master Key) by performing a cryptographic hash on the concatenation of the GMK, a nonce, and the MAC address of the Extreme Networks device. The Extreme Networks device then sends the GTK to all associated clients within EAPOL-Key messages.
GTK Timeout Period	Type the time interval (in Milliseconds) that the device waits for client replies during the handshake process. To accommodate clients that have shorter or longer timeout values, you can change this to a value from 100 (the standard timeout value) to a maximum of 8000 milliseconds.
Number of GTK Retries	Type the maximum number of times the device will retry sending GTK messages.

Table 84: Settings for Advanced Access Security Controls (continued)

Setting	Description
Generate a new Pairwise Transient Key (PTK) after	<p>Select to enable PTK rekeying, and enter a value between 10 and 50,000,000 seconds (~231 days). If you enable PTK rekeying, an interval between 2 and 10 minutes (120 and 600 seconds) is the best practice recommendation, which is short enough to thwart the known TKIP exploit. Enable this option only if you know that the clients using the SSID support it. In addition, you might need to configure PTK rekeying on the clients.</p> <p>Note: There is a flaw in TKIP that allows an attacker to decrypt unicast packets sent from an access point to a wireless client, and then send the client-forged packets, possibly with the purpose of poisoning ARP or DNS caches. If you cannot transition to AES-CCMP—which is not susceptible to this attack—you can mitigate attacks against TKIP-encrypted data by setting the PTK (pairwise transient key) to rekey at short intervals.</p>
PTK timeout period	<p>Type the interval (in Milliseconds) that the device waits for client replies during the four-way handshake in which they derive a PTK for encrypting and decrypting unicast traffic.</p> <p>To accommodate clients that have shorter or longer timeout values, you can change the value from 100 milliseconds (the standard timeout value) to a maximum of 8000 milliseconds.</p>
Number of PTK retries	Type the maximum number of times the device will retry sending PTK messages.
Replay window	<p>Type a window size, within which the device accepts replies to previously sent messages during four-way handshakes.</p> <p>0 indicates that the device does not accept any messages other than a reply to the last message that it sent. You might want to accept replies to previously sent messages if there are clients that reply more slowly than the device retries sending it messages.</p>
Local TKIP Countermeasure	<p>(Available only when the encryption method is Auto-TKIP or CCMP (AES) or TKIP)</p> <p>Select to enable the deauthentication of all clients when the local device detects message integrity check failures during TKIP operations.</p> <p>If one key fails an integrity check, the discovery of such a failure suggests that other keys in current use might also be compromised. The cautious security stance is to deauthenticate all clients and stop using all existing keys immediately. When clients reauthenticate, they use newly generated pairwise and group primary and temporal keys. If this feature is disabled, the device continues to use existing keys and maintain currently connected clients after detecting MIC failures.</p>

Table 84: Settings for Advanced Access Security Controls (continued)

Setting	Description
Remote TKIP Countermeasure	(Available only when the encryption method is Auto-TKIP or CCMP (AES) or TKIP) Select to deauthenticate all previously authenticated clients when a client reports MIC failures during TKIP operations. The distinction between the local and remote countermeasure options is where the discovery occurs: <ul style="list-style-type: none"> Local—A device discovered the failure. Remote—A client discovered and reported the failure.
Enable to refresh the GTK only when the rekey period elapses.	To disable GTK refresh when either the rekey period elapses or a client disassociates from the SSID, clear the check box.



8. Select **SAVE**.

Customize Wireless Network Optional Settings

Complete the [Add a Network Policy](#) on page 151 task.

When configuring an SSID, you can configure and apply radio rates, DoS prevention settings, traffic filters, and other options.

Use this task to configure the **Optional Settings** for a standard wireless network.


1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. [Customize Radios and Rates Settings](#) on page 248.
6. [Customize DoS Prevention Settings](#) on page 249.
7. [Customize Traffic Filters](#) on page 250.
8. [Customize the User Profile Application Sequence](#) on page 251.
9. [Customize Voice Enterprise Options](#) on page 252.
10. [Customize Wi-Fi Multimedia™](#) on page 253.
11. [Customize Broadcast and Multicast Handling Settings](#) on page 254.
12. [Customize Client Related Network Settings](#) on page 255.
13. [Customize Other Options](#) on page 256.
14. Select **SAVE OPTIONAL SETTINGS**.

Customize Radios and Rates Settings

Complete the [Add a Network Policy](#) on page 151 task.

By default, Extreme Networks devices advertise support for all rates. By setting specific rates, you can restrict access to just those clients that can support them. Use these

controls to force clients to connect at higher data rates on an SSID, which can help increase average data transfer rates.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Radios and Rates** section.
6. Select a radio frequency and configure the basic (mandatory) and optional data rates per SSID.
7. Select **SAVE RATE SETTING**.
8. Repeat steps 6–7 for each radio frequency.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links


[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Customize DoS Prevention Settings

Complete the [Add a Network Policy](#) on page 151 task.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to customize settings for broadcast and multicast handling. Use this task to configure defensive settings to protect against Denial of Service (DoS) attacks, and configure SSID access filters based on MAC addresses.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **MAC-based Dos Prevention rules for** section.
6. Select an option and configure the settings.
 - **SSID**—Select to protect against DoS attacks at the MAC layer (Layer 2) on the radio channel that an AP uses for SSID access traffic. The settings for an SSID apply cumulatively to the total amount of Layer 2 traffic that an AP receives on the access channel for the SSID.
 - **Client**—Select to protect against DoS attacks at the MAC layer (Layer 2) on the radio channel that an AP uses for SSID access traffic. The settings in the MAC DoS configuration object apply to the total amount of Layer 2 traffic that an AP receives on the access channel for the SSID from a single MAC address.
7. Under **IP-based Dos Prevention rules for**, select **SSID** and configure the settings. This configuration protects against Denial of Service attacks at the IP layer (Layer 3) on the radio channel that an AP uses for SSID access traffic.




The settings in the IP DoS configuration object apply cumulatively to the total amount of Layer 3 traffic that an AP receives on the access channel for the SSID.

8. **Enable MAC-Based filters** and select an option for the **Default Action**.

- **Permit**—Enable traffic from clients that do not match one of the selected filters.
- **Deny**—Block traffic from clients that do not match any of the selected MAC filters.

This step makes the **Add MAC-Based Filters** section available.

9. Add Mac-based filters.

- a. Scroll to the **Add MAC-Based Filters** section, and then select .
- b. Specify a MAC or a MAC OUI.
 - Select  and choose an existing MAC or MAC OUI.
 - Select  to add a new **MAC Address**, or **MAC OUI**.
- c. Select an **Action** from the menu.
- d. Select **ADD**.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links

[Add a Network Policy](#) on page 151


[Customize Wireless Network Optional Settings](#) on page 248

Customize Traffic Filters

Complete the [Add a Network Policy](#) on page 151 task.

Select traffic filters to control which management and diagnostic services an AP may receive, and whether to allow traffic between clients connected to the AP.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to customize optional traffic filter settings.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Traffic Filters** section.
6. Select or clear the following check boxes to permit or deny specific types of management and diagnostic access to the mgt0 interface, or to enable traffic between clients connected to the AP.
 - **Enable SSH**
 - **Enable Telnet**
 - **Enable Ping**

- **Enable SNMP**
- **Enable Inter-station Traffic**

**Note**

When an Ethernet interface is in access mode, stations can communicate directly with each other without sending traffic through the AP. In this case, the AP cannot control their traffic. However, the AP can block traffic between stations connected to an Ethernet interface and stations connected to a wireless interface through an SSID.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links

[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Customize the User Profile Application Sequence

Complete the [Add a Network Policy](#) on page 151 task.

You can specify which profile you want to apply to user traffic. By default, an AP applies user profiles in the following order (the last one is the profile that the AP ultimately applies to user traffic):

- First, the AP applies the user profile indicated by attributes returned by a RADIUS server performing MAC authentication.
- Second, the AP applies the user profile specified in an SSID for traffic management. This overrides the first user profile.
- Third, the AP applies the user profile indicated by attributes returned from a RADIUS server when a captive web portal requires user authentication. This user profile overrides both the first and second profiles.

To give priority to a user profile by applying it later in the sequence, reorder the profiles.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task for configurations with different SSID components referencing different user profiles.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Choose User Profile Application Sequence** section, and then use the arrows to change the application sequence.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links

[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Customize Voice Enterprise Options


Complete the [Add a Network Policy](#) on page 151 task.

Navigate to **Optional Settings CUSTOMIZE** under **Additional Settings** in the **Configure Standard Wireless Networks** window.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to customize Voice Enterprise options.

**Note**

To enable Voice Enterprise or 802.11r, the SSID must be configured to use WPA2 key management.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Voice Enterprise** section.
6. Select an option.
 - **Enable Voice Enterprise**—Select to enable all options that are required for full voice enterprise support.
 - **Custom**—Select and choose one of the following options:
 - **Enable 802.11k**: (Radio Resource Measurement of Wireless LANs): Select to enable the devices to monitor the RF environment and network performance to help manage network usage and client roaming.
 - **Enable dualband neighbor list**: Select to enable APs to monitor 2.4 GHz, 5 GHz, and 6 GHz bands at the same time to widen the search for a less-loaded AP channel.
 - **Max. neighbor APs**: Set the maximum neighbor APs to send to the client to reduce the computational resources required for 802.11k handover.
 - **Enable 802.11v**: (IEEE 802.11 Wireless Network Management): Select to enable network devices and clients to share information such as location and neighbor information.
 - **Enable forced disassociation**: Select to enable APs to send disassociate or deauthenticate frames for a variety of reasons per 802.11v.
 - **Disassociate after**: (If forced disassociation is enabled.) Range: 0 to 5 seconds.
 - **SNR Checking**: (If forced disassociation is enabled.) Select to enable APs to consider signal-to-noise ratio to determine when to disassociate.
 - **Disassociate the Client**: (If forced disassociation and SNR checking are enabled.) Select to enable APs to send disassociation frames to client devices.
 - **BSSID Transition Request**: (If forced disassociation and SNR checking are enabled.) Select to enable APs to send BSSID transmission management request frames to client devices.

- **SLA Checking:** (If forced disassociation is enabled.) Select to enable Extreme Networks APs to consider service level agreement performance thresholds to determine when to disassociate.
 - **Disassociate the Client:** (If forced disassociation and SLA checking are enabled.) Select to enable APs to send disassociation frames to client devices.
 - **BSSID Transition Request:** (If forced disassociation and SLA checking are enabled.) Select to enable APs to send BSSID transmission management request frames to client devices.
- **Enable 802.11r:** (Fast BSS Transition): Select to optimize roaming by forcing stations to forward QoS state and encryption keys preemptively.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links

[Add a Network Policy](#) on page 151


[Customize Wireless Network Optional Settings](#) on page 248

Customize Wi-Fi Multimedia™

Complete the [Add a Network Policy](#) on page 151 task.

Enable Wi-Fi Multimedia™ (WMM) to prioritize network traffic according to the settings.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to enable WMM and customize the settings.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **WMM** section, and then select **Enable WMM**.
6. Select and clear the following check boxes as required:
 - **Voice**—Select to enable admission control algorithms for voice traffic.
 - **Video**—Select to enable admission control algorithms for video traffic.
 - **Enable Unscheduled Automatic Power Save Delivery**—Select to enable stations to request queued traffic at any time, rather than receiving queued traffic scheduled with the beacon.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links

[Add a Network Policy](#) on page 151


[Customize Wireless Network Optional Settings](#) on page 248

Customize Broadcast and Multicast Handling Settings

Complete the [Add a Network Policy](#) on page 151 task.

To reduce unnecessary airtime usage for multicast transmissions, a device can convert multicast frames to unicast frames under certain conditions or at all times, and can drop multicast frames when there are no group members present to receive them. Unicast traffic can increase the reliability of video delivery. If a wireless client does not receive a unicast frame and does not reply with an ACK, the AP will retransmit. Multicast traffic does not support wireless frame delivery confirmation.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to customize settings for broadcast and multicast handling.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Broadcast and Multicast Handling** section, and then select one of the following **Convert IP Multicast to Unicast** options:
 - **Auto**: The device is enabled to convert multicast frames to unicast when the channel utilization or membership count conditions are met.
 - **Always**: The device makes the conversion unconditionally.
 - **Disable**: The device does not use the multicast-to-unicast conversion feature, but instead follows the standard 802.11 behavior for sending multicast frames.
6. Set the **Channel Utilization Threshold** from 1 to 100%.
7. Set the **Membership Count Threshold** from 1 to 30.
8. Select **Enable Non-Essential Broadcast Filtering** to reduce unnecessary broadcast and multicast traffic forwarding (such as AMRP, HSRP, LLC, and STP) from APs with no registered listeners.
9. Select **Enable Multicast Drop** to drop multicast and broadcast traffic, excluding frames for any of the selected protocols. With the exception of **MDNS**, by default, all protocols are selected and are therefore included in multicast and broadcast traffic. To exclude protocols in multicast and broadcast traffic, proceed as follows:
 - **DHCPv4**: Clear the check-box to drop Dynamic Host Configuration Protocol version 4.
 - **DHCPv6**: Clear the check box to drop Dynamic Host Configuration Protocol version 6.
 - **ARP**: Clear the check box to drop Address Resolution Protocol.
 - **IGMP-query**: Clear the check box to drop Internet Group Management Protocol queries.
 - **IPv6-Discovery**: Clear the check box to drop Internet Control Message Protocol router discovery messages.
 - **MDNS**: This check box is not selected by default and is therefore preset to drop multicast DNS frames. Select this check box to **include** multicast DNS frames in multicast and broadcast traffic.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links


[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Customize Client Related Network Settings

Complete the [Add a Network Policy](#) on page 151 task.

Use this task to define client usage parameters that control how devices in the SSID transmit data, how neighboring devices exchange information with each other, and the maximum number of clients that the SSID supports.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Go to the **Client Related Network Settings** section, and then configure the settings:
 - **Maximum client limit:** Set the maximum number of clients that can associate with an SSID on a device.
 - **EAP Timeout** (Enterprise Security Mode Only): During the 802.1x authentication phase, in the event of an EAP retry due to packet loss or lack of response from the client, the AP can retry the EAP request. Some clients cannot properly handle fast retry timers, so this might need adjustment to facilitate fast recovery for bad RF environments.
 - **RTS threshold:** The RTS (request-to-send) threshold indicates the minimum packet size to trigger an RTS/CTS (request-to-send/clear-to-send) exchange. The purpose of this exchange is to reserve the medium and thereby reduce collision interference.
 - **Fragment threshold:** The fragment threshold indicates the minimum packet size to begin fragmenting packets before transmitting them. If there is a high level of interference, smaller packet sizes can reduce the need to retransmit packets and improve performance.
 - **DTIM settings:** Extreme Networks devices include delivery traffic indication messages (DTIM) in beacons at scheduled intervals. DTIMs are included in beacons according to the DTIM period that you set. Increase the DTIM setting to improve battery life or shorten it to deliver buffered broadcast and multicast traffic more frequently.
 - **Inactive client ageout:** Set the length of time to age out and automatically disassociate inactive clients.
 - **EAP Retries** (Enterprise Security Mode Only): After the EAP timeout, authentication fails and the client tries to reconnect per this value.
 - **Roaming cache update interval:** An Extreme Networks AP updates its neighbors about its currently associated clients. Neighboring APs use this information to

update their roaming caches—if necessary—with the most up-to-date client information from their neighboring APs.

- **Roaming cache ageout:** By default, an Extreme Networks device removes an entry from its roaming cache if it is absent from 60 consecutive updates from a neighbor. You can change the number of times an entry must be absent.

Continue customizing **Optional Settings** in the **Wireless Networks** configuration window. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Related Links


[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Customize Other Options

Complete the [Add a Network Policy](#) on page 151 task.

This task is part of a series for configuring the **Optional Settings** for a standard wireless network. Use this task to customize the **Other Options**.

1. Go to **Configuration > Network**
2. Select an existing policy, and then select .
3. Select **NEXT** to open the **Wireless Network** page.
4. Go to **Additional Settings > Optional Settings**, and then select **CUSTOMIZE**.
5. Select **Ignore broadcast probe request** to enable Extreme Networks devices hosting this SSID to ignore probe requests from wireless clients.
6. Select **Hide SSID (Stealth mode)** to enable a simple but ineffective method to secure a wireless network; it hides the SSID (Service Set Identifier).



Note

This method provides very little protection against anything but the most casual intrusion efforts.

7. Select **FTM(11mc) Responder Support** to enable client devices to determine their distance from the AP.

If the civic address, latitude, longitude, or altitude of the AP is configured, the AP advertises this information in the beacon.



Note

Enabling FTM (Fine Timing Measurement) 11mc causes a radio reset.

8. Select **Enable enhanced RNR** to enhance roaming for 6 GHz clients, or clear the check box to turn off this feature.

If you select **Broadcast SSID Using > 6 GHz radio**, Extreme Platform ONE Networking enables this feature by default. To disable the feature, turn off the 6 GHz radio.

9. Select **SAVE OPTIONAL SETTINGS** to save your changes.

Finish configuring the network policy.

Related Links

[Add a Network Policy](#) on page 151

[Customize Wireless Network Optional Settings](#) on page 248

Configure Device Templates

Create or configure an existing network policy.

Use a device template to configure default port settings and other device functions for a specific Extreme Networks model using a visual diagram of the physical ports. After you configure a device template, you can:

- Assign various port types to the device ports, then apply the device template configuration settings to large numbers of devices of the same type.
- Apply different device templates to other devices in the same network policy.

**Note**

Each network policy has only one template corresponding to each device model. To update devices with different configurations for the same model, you must create a new network policy or modify an existing policy and then configure a new template.

1. To add an AP template to the network policy, select **2 Wireless** in the workflow and proceed to [Configure AP Templates](#) on page 257.
2. To add a switch template to the network policy, select **3 Switching** in the workflow and proceed to [Configure Switch Templates](#) on page 287.
For legacy and Dell switch models, select **4 SR/Dell Switching** in the workflow.

Continue configuring the network policy.

Related Links

[Configure AP Templates](#) on page 257




[Configure Switch Templates](#) on page 287

Configure AP Templates

Create a network policy for the APs. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.

Create AP device templates with default settings for all APs, and settings that Extreme Platform ONE Networking applies when APs are onboarded. You can then modify the default AP settings individually, as required. AP templates enable quick AP deployment, with most of the port settings already applied by the associated template. Some devices have extra possible configuration options, depending on the device model.

Use this task to configure an AP device template as part of a network policy.

1. On the **2 Wireless** page, select **Configuration Settings > AP Template**.
2. Select an existing AP Template, and then select , or to add a new one, select .
To delete the selected template, select .

3. For a new template, type a **Name**, and for an existing template, edit as required.
4. Select the ports or interface icons on the template graphic.
 - a. To select all of the ports and interfaces, choose **Select All Ports**.
 - b. To deselect all of the ports and interfaces, select **Deselect All Ports**.
5. To **Assign** an Ethernet port profile, see [Assign an Ethernet Port Profile](#) on page 258.
6. To configure **Wireless Interfaces**, see [Configure Wireless Interfaces for an AP Template](#) on page 260.
7. To configure **Wired Interfaces**, see [Configure Wired Interfaces for an AP Template](#) on page 282.
8. To configure **SES-imagotag**, see [Electronic Shelf Labeling](#) on page 283.
9. To configure **Advanced Settings**, see [Configure AP Device Template Advanced Settings](#) on page 286.
10. Select **SAVE TEMPLATE**.

Continue configuring the network policy.



Related Links

[Configure Device Templates](#) on page 257

Assign an Ethernet Port Profile

An Ethernet port profile lets you manage a variety of features such as port status (on or off), port usage (bridge access, bridge 802.1Q, or uplink), wired connectivity, and MAC authentication.

This task is part of the network policy configuration workflow. Use this task to assign a port profile to device ports.

1. Select an existing AP Template, and then select , or to add a new one, select  to create a new template.
2. To assign an existing port profile, select one or more Ethernet ports on the AP template graphic.
 - a. Select **Assign**.
 - b. Select **Choose Existing**.
 - c. Choose any of the options from the **Port Type Assignment** list, and select **Save**.
3. To create a new port profile, select **Create New**.
 - a. Type a **Port Name** for the port type.
 - b. (Optional) Type a **Description** for the port profile.
 - c. Select the **Port Usage** type:
 - **Uplink Port**: Use to connect the AP to the WAN.
 - **Access Port**: Use for an AP in client access mode, connected to a forwarding device like a switch that supports multiple VLANs.
 - **Trunk Port**: Use to connect the AP in bridge mode to a forwarding device, such as a switch that supports multiple VLANs.
4. For **Wired Connectivity**, enable **User Authentication**.
5. See [Configure an External RADIUS Server](#) on page 221 if you are not selecting an existing RADIUS Server Group.

6. Enable **MAC Authentication**, see [Configure MAC Authentication](#) on page 195.
7. For **QoS Settings**, see [Configure Marker Maps](#) on page 241.
8. For **User Access Settings**, to add a new User Profile, see [Add a User Profile](#) on page 192.
9. For **Traffic Filter Management**, see [Configure Traffic Filters Policy Settings](#) on page 180.
10. For **Port Settings**, see [Configure LLDP/CDP Policy Settings](#) on page 169.
11. For **Storm Control Settings**, see [Configure Storm Control](#) on page 300.

Continue configuring the AP template.

Related Links

[Configure Port Types](#) on page 303



Enable STP—Device Configuration



Note

Switch templates are supported only for Switch Engine and Extreme XOS devices.

Use this task to enable STP and configure the settings for a switch template.

1. Go to **Configure > Common Objects > Policy > Switch Template**.
2. Select an existing template, and then select , or select .
3. From the **Configuration** menu, select **Device Configuration**.
4. Toggle **STP (Spanning Tree Protocol)** to **ON**.
5. Select the STP Mode:
 - **STP**—The initial version of this protocol uses a single tree without regard to VLAN. After convergence (30-50 seconds), only the root bridge sends configuration Bridge Protocol Data Units (BPDUs).
 - **RSTP (Rapid STP)**—Like STP, RSTP uses single tree without regard to VLAN. After convergence (a few millisecond to 6 seconds), all switches send BPDUs every 2 seconds.
 - **MSTP (Multiple STP)**—Multiple Spanning Tree Protocol (MSTP) can map a group of VLANs into a single Multiple Spanning Tree instance (MSTI). Configure the MSTP settings.
6. Select a **Priority** for STP from the drop-down list.
7. Configure the **STP Timers**:
 - **Forward Delay**—This is the time the switch spends in the listening and learning state. The default is 15 seconds, and the range is 4 to 30 seconds.
 - **Max Age**—This is the maximum time period before a bridge port saves configuration BPDUs information. The default is 20 seconds, the range is 6 and 40 seconds.
8. Select **SAVE**.

Continue configuring the Ethernet port.

Configure Wireless Interfaces for an AP Template

This task is part of the network policy configuration workflow. Use this task to Use this task to configure the Wi-Fi 0, Wi-Fi 1, Wi-Fi 2, and IoT0 ports for an AP template, as part of a network policy.

1. Select a **Device Model**, and then select an existing **Template**, or a default template.
2. Scroll down to the **Wireless Interfaces** section.
3. Select an **Operating Mode**.
 - Mode 1: 2.4 GHz / 5 GHz (Full) / 6 GHz — Tri-Radio
 - Mode 2: Tri-Radio / 5GHz (Full) / 6 GHz — Full Band with Scan
 - Mode 3: 5 GHz (Low) / 5 GHz (High) / 6 GHz — Dual 5 GHz with 6 GHz
 - Mode 4: Tri-Radio / 5 GHz (Full) / 2.4 GHz — DBDC
 - Mode 5: 5 GHz (Low) / 5 GHz (High) / 2.4 GHz — Dual 5 GHz with 2.4 GHz
 - Mode 6: 6 GHz (Low) / 5 GHz (Full) / 6 GHz (High) — Dual 6 GHz with 5 GHz
4. Select either the **WiFi0**, **WiFi1**, **WiFi2**, or **IoT0** tab.



Note

The **IoT0** tab applies only to AP5010/AP5020 models.

5. Set the **Radio Status** to **On**.
6. Select a **Radio Profile**—or an **IoT Profile** if applicable.

You can also add a new [Radio Profile](#) or [IoT Profile](#) here, or clone and modify an existing profile.
7. Select the **Radio Usage** type.
 - Select **Client Mode** to configure a device for AP client mode radio usage, and to configure advanced features such as **Port Forwarding Rules** and **DHCP Server** settings. Choose a **Client Mode Profile** from the drop-down list. If required, you can configure a new [Client Mode Profile](#) or edit an existing profile.
 - Select **Client Access** for normal client operation. Optionally, select **Backhaul Mesh Link** for wireless portal and mesh backhaul operation.
 - Select **Sensor** for presence operation.
8. Continue configuring the AP template, or select **Save Interface Settings**.

Related Links

[Configure AP Templates](#) on page 257
[Configure a Radio Profile](#) on page 262
[Configure IoT Profile Settings](#) on page 276
[Configure a Client Mode Profile](#) on page 261

Radio Profiles

A radio profile contains settings for the radios in APs. The radios generally operate in two frequency bands: radio 1 (WiFi0) operates at 2.4 GHz, and radio 2 (WiFi1) operates at 5 GHz. WiFi2 supports only the 6 GHz band for client access. The number of radios and frequency bands supported vary by AP model.

In the **Radio Profiles** window, you can view, add, modify, and delete radio profile settings. You can also modify radio profile settings when you configure a device template. See [Configure Device Templates](#) on page 257.

The **Radio Profiles** table displays the following information:

- **Radio Profile Name:** The name assigned to a profile when it was created. It is a convenient reference when assigning radio profiles to the WiFi0 and WiFi1 interfaces for an AP.
- **Applied to Radio:** 2.4 GHz, 5 GHz, or 6 GHz.
- **Radio Mode:** 802.11a, a/n, ac, b/g, g/n, ax, or be.
- **Used By:** Shows the number of devices associated with this radio profile. Hover over any non-zero number in this column to see the associated device templates.

Related Links



[Configure Device Templates](#) on page 257

[Configure a Radio Profile](#) on page 262

[Configure Wireless Interfaces for an AP Template](#) on page 260

Configure a Client Mode Profile

This task is part of the network policy configuration workflow. Use this task to configure a Client Mode Profile as part of a network policy.

1. While configuring **Radio Usage**, select an existing Client Mode Profile, and then select , or to add a new one, select .
2. Type a **Client Mode Profile Name**.
3. (Optional) Type a **Description**.

Although optional, descriptions can be helpful when you are troubleshooting your network.

4. The **Enable Local Web Page** option is enabled by default.

The client mode AP activates a local SSID portal web page, which includes choices to select and connect the client mode AP WAN-side radio to a WAN Wi-Fi network. Clear this check box to configure other options for this profile.

5. Choose one of the following DHCP server options:
 - In the **DHCP Server Scope** field, enter the first IP address of the DHCP server range. The first IP address in this range is the IP address used to display the client mode SSID portal web page. Make a note of this first IP address for later reference.
 - In the **DHCP Server Scope** field, enter a single IP address to reserve a specific client (MAC address) to an IP. A DHCP reservation is a permanent IP address assignment. It is a specific IP address within a DHCP scope that is permanently reserved for a specific DHCP client. DHCP reservations on the AP support security on the local side of the Network Address Translation (NAT) and ensure that the client IP address does not change.
 - Set the **Advanced DHCP Server** slider button to **On**, then choose a pre-configured **DHCP Server and Relay** agent.

6. Toggle **Enable Port Forwarding** to **ON**, and then configure **Port Forwarding Rules** as follows:
 - a. Select the plus sign to add a new port forwarding rule.
 - b. Enter a description of how this rule is to be used (optional).
 - c. Select a number for the outside port in the range of 1025-65535 (reserved ports cannot be used).
 - d. Select a number for the local port in the range of 1-65535.
 - e. Select **TCP**, **UDP**, or **Both** from the **Protocol** drop-down list.
 - f. Select a **Host IP Address** for the internal device from the drop-down list, or select the plus sign to add a new address.
 - g. Select **Add**.
7. Select **SAVE**.

Related Links

[Configure Wireless Interfaces for an AP Template](#) on page 260



Configure a Radio Profile

Use this task to create or edit a radio profile for 2.4 GHz, 5 GHz or 6 GHz device interfaces. For more information about radio profiles, see [Radio Profiles](#) on page 260.



Note

Extreme Networks provides defaults for each item in this section. The following steps are optional, except for the required radio profile **Name**.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing **Radio Profile**, and then select , or to add a new one, select .
4. Type the radio profile **Name**.
5. Type a **Description**.

Although optional, descriptions can be helpful when you are troubleshooting your network.
6. Select the desired 802 specification from the **Support Radio Modes** menu.
7. Select a **Supported Power Mode**.



Note

Only applicable to AP5020/AP4020 and future WiFi 7 APs.

8. To set the optimal maximum power level, enter a value for **Maximum Transmit Power**.
9. To set the minimum power level, enter a value for **Transmission Power Floor**.
10. To set the maximum value to which the radio power can drop below the current power level, type a value for **Transmission Power Drop**.

11. To set the maximum number of wireless clients that can use the radio, type a value for **Maximum Number of Clients**.

(Default: 100, Range: 1-255)

A lower value permits fewer concurrent connections to the AP and provides a higher quality of service. A high number of concurrent connections to a radio might affect the quality of service. While 100 might be a bit high for a classroom setting, higher values are suitable for larger public spaces, such as cafeterias or gymnasiums. A higher setting is appropriate for APs that serve dense outdoor areas with frequent connections that quickly roam to other areas.

12. Select **SAVE RADIO PROFILE**.

Now that you have completed the basic configuration, you can modify the advanced radio profile settings. Remember to select **SAVE RADIO PROFILE** after changing the **Advanced Settings**.

Related Links

[Radio Profiles](#) on page 260
[Configure Neighborhood Analysis](#) on page 263
[Channel Selection](#) on page 264
[Configure Dynamic Channel Switching](#) on page 267
[Optimize Radio Usage](#) on page 268
[Configure Radio Settings](#) on page 270
[Configure Backhaul Failover](#) on page 272
[Configure an Outdoor Deployment](#) on page 272
[Configure RF Interface Reports](#) on page 273
[Configure Client SLA Definitions](#) on page 274
[Configure WMM QoS Settings](#) on page 274
[Configure Sensor Mode Scan Settings](#) on page 275
[Configure IoT Profile Settings](#) on page 276

Configure Neighborhood Analysis



First, [Configure a Radio Profile](#) on page 262.

Using background scanning, an AP divides a full background channel scan into several shorter partial scans so they do not interfere with the beacons sent by the AP. The scan takes less time than the beacon interval (100 TU by default), and is spread out over multiple beacon intervals until the AP scans all available channels. Full scans occur at admin-defined intervals, with a default of 10 minutes.

This task is part of the Radio Profile configuration workflow. Use this task to configure neighborhood analysis (background scanning) settings.

**Note**

Extreme Networks provides defaults for each item in this section. The following steps are optional.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing **Radio Profile**, and then select , or to add a new one, select .
4. In the **Neighborhood Analysis** section, toggle **Background Scan** to **ON**.
Background scanning is necessary for WIPS and Layer 3 roaming to function.
5. Set the interval between background scans of all radio channels.
Perform Background Scan Every: The range is 1 to 1440 minutes (24 hours).
6. For **Skip Background Scan When**, specify when to skip background scans:
 - Select **Clients are connected** to enable an AP with connected clients to scan channels.
 - Select **Connected clients are in power save mode** to enable an AP to scan channels when connected clients are in power save mode.
 - Select **Network traffic with voice priority is detected** to prevent an AP from performing a background scan when voice traffic is detected.

Voice traffic takes priority and is the least forgiving of slow or degraded connections.

7. Select **SAVE RADIO PROFILE**.

Related Links

[Configure Channel Selection](#) on page 266

[Configure a Radio Profile](#) on page 262

Channel Selection**2.4 GHz Radio Settings**

The 2.4 GHz radio has between 11 and 14 channels, depending on the country code, but only three are completely non-overlapping (channels 1 - 6 - 11). Most wireless vendors recommend choosing one of the non-overlapping channels to avoid interference. However, in some cases, especially in very dense deployments, it can be better to use four channels, particularly in European countries where there are more channels available.

You can set the channel model as three or four channels, depending on the selected region (USA or Europe). When you select Europe, you can modify the channel choices and set a different combination of channels. If you disable limiting channel selection, the AP uses Advanced Channel Selection Protocol (ACSP) to determine the best among all available channels in its region, using data about channel utilization, interference, CRC errors, noise floor, and the number of neighbors and their signal strength. The AP then selects the best channel available.

5 GHz Radio Settings

The 5 GHz radio mode is 802.11a, 802.11n, or 802.11ac. One of the key features in the 802.11n and 802.11ac standards is channel bonding, in which the radio bonds two or four adjacent 20-MHz channels into one 40-MHz or 80-MHz channel to increase the transmit data bandwidth. Unlike the 2.4 GHz radio band, the 5 GHz band has enough space for channel bonding. When you enable channel bonding on an AP whose region code is **FCC** and choose **40 MHz** or **80 MHz**, ACSP automatically chooses the primary channel based on the current RF environment and optimizes channel usage.

You can also use channel bonding in the European Community in conjunction with Dynamic Frequency Selection (DFS), which makes channels 52-64 and 100-140 available in addition to channels non-DFS channels 36-48. Without DFS enabled, channel bonding is not recommended for client access in the European Community because only the Unlicensed National Information Infrastructure (U-NII) lower band would be available (5.15-5.25 GHz; bandwidth: 100 MHz; channels 36 - 40 - 44 - 48) and there would not be enough space for three non-overlapping 40-MHz channels.

**Note**

The DFS option only takes effect when the AP is configured with the country code of a country complying with European Telecommunications Standards Institute (ETSI) or Federal Communications Commission (FCC) regulations. All Extreme Networks APs are certified to use DFS channels in the ETSI region and all are certified for the FCC region.

The 5-GHz radio frequency spectrum is partitioned U-NII bands. Extreme Networks devices support the following:

- U-NII Low: 5.15-5.25 GHz (bandwidth: 100 MHz; available in the U.S. and E.C.)
- U-NII Upper: 5.725-5.85 GHz (bandwidth: 125 MHz; available in the U.S.)

**Note**

When a hive contains some APs that do not support channel bonding and others that do, the dynamic channel selection process works as follows:

- Channel selection for backhaul mode: The APs that support only 20-MHz channels converge on the control channel that the other members use as part of their 40-MHz channel.
- Channel selection for access mode: The APs that support only 20-MHz channels avoid choosing either the control channel or extension channel that the other members are using as part of their 40-MHz channels.

6 GHz Radio Settings

Wi-Fi 6 is the next generation of Wi-Fi based on 802.11ax HE (high efficiency) technology. Currently, AP3000, AP4000, AP4020 and AP5000 devices support Wi-Fi 6 on 160 MHz channels.

Wi-Fi 7 is a tri-radio based on 802.11be technology on 320 MHz channels. Currently, only AP5020 devices support Wi-Fi 7 across three bands - 2.4 GHz (4x4:4), 5 GHz (4x4:4), and 6 GHz (4x4:4).

Related Links

[Configure Channel Selection](#) on page 266

Configure Channel Selection



First, [Configure a Radio Profile](#) on page 262.

This task is part of the Radio Profile configuration workflow. Use this task to make changes to the device channel width. The available settings depend on the **Supported Radio Mode** that you selected in the basic configuration section.

**Note**

Extreme Networks provides defaults for each item in this section. The following steps are optional.

Channel selection is dimmed and set to **Auto**. Perform channel selection at the device level.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Specify the **Channel Width and Exclusions**.
 - a. To customize the display, select and clear the check boxes as desired:
 - **Show UNII Groups**
 - **Show Frequency Markers**
 - **Show Primary Channels**
 - **Show Preferred Scan Channels (PSC)**
5. To manually exclude channels, select a specific channel.
6. Enable **Dynamic Frequency Selection** to help maintain a balance between Wi-Fi performance and avoid interference with essential radio services.

**Note**

Dynamic Frequency Selection (DFS) settings do not apply to AP121, AP141, AP330, and AP350 access points that were shipped after 2 June 2016 and operate in the FCC domain.

- a. Select **Enable manual channel selection return** to return the affected radio to its original statically assigned DFS channel after a DFS event.
- b. Select **Enable ZeroWait DFS** to dedicate a single antenna chain to quickly identify a usable DFS channel. With ZeroWait DFS enabled, a 4x4 AP become a 3x3 AP.

**Note**

ZeroWait DFS is only available for 3- or 4-stream APs.

- c. Select **Enable Background Scan** to enable DFS to run background scans.
7. To manually set **Transmission Power**, select **Manual** and then use the slider to select a dBm setting.
 8. Enable **Enable client transmission power control (802.11h)**.

9. To manually enable client transmission power control (802.11h), use the slider to select a dBm setting.
10. Enable **Limit Channel Selection** to limit channel selection to non-overlapping channels.
 - a. Select the operating **Region** for the device from the drop-down list.
 - b. For **Channel Model**, select 3 channels for USA and 4 channels for Europe.
 - c. For **Limit Channel Selection**, USA defaults are 1, 6, and 11, and European defaults are 1, 5, 9.
11. Enable **Use the last known power and channel during the AP boot up process**.
12. Select **SAVE RADIO PROFILE**.

Related Links



[Channel Selection](#) on page 264

[Configure Dynamic Channel Switching](#) on page 267

[Configure a Radio Profile](#) on page 262

Configure Dynamic Channel Switching

This task is part of the Radio Profile configuration workflow. Use this task to enable Dynamic Channel Switching (DCS) to select and switch channels based on specified criteria.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Expand **Advanced Settings** and toggle **Dynamic Channel Switching** to **ON**.
5. Select **Automatically select and switch channels during specified time interval**.
 - a. In the **From** field, enter the start time for the interval.
 - b. In the **To** field, enter the end time for the interval.
 - c. In the **Do not switch channels if the number of connected clients exceeds** field, specify the number of connected clients.

If the number of associated clients is equal to or less than the specified value, and if the AP finds a better channel, it can switch to a new channel. Associated clients lose their connections and must reconnect. If the number of clients exceeds the value, the AP does not switch to a new channel. When a client de-authenticates during the scheduled time range, the AP checks the number of clients against the value. If the number of clients does not exceed the value, the AP switches channels. If the number of clients still exceeds the value, the AP does not change channels.
6. Select **Switch channels anytime if RF interference exceeds the threshold**.
 - a. In the **Interference Threshold** field, enter the value (%).
 - b. In the **CRC Error Threshold** field, enter the value (%).
 - c. Select **Do not switch channels if clients are connected**.
7. Select **SAVE RADIO PROFILE**.

Related Links

[Optimize Radio Usage](#) on page 268

[Configure Dynamic Channel Switching](#) on page 267

Optimize Radio Usage

First, [Configure a Radio Profile](#) on page 262.



Management frames such as beacons, and probe and association requests and responses, consume airtime that might otherwise be used to transmit user data.

This task is part of the Radio Profile configuration workflow. Use this task to minimize management traffic by using higher data rates, and suppressing and reducing probe and association responses under certain circumstances.



Note

Use caution when configuring radio optimization settings. When device configuration limits specific clients, there is a risk that end user clients will deny access to the WLAN. Extreme Networks provides default values for each setting. Modifying the radio configuration is optional and should be done with caution.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Choose **High data rates** to transmit management frames at the highest basic data rate specified in an SSID or **Low data rates** to use the lowest basic data rate.
5. Select **Suppress successive requests within the same beacon interval** to enable APs to suppress responses to repeated probe requests from the same client received within a single beacon interval.
6. Select **Suppress response to broadcast probes by** to reduce responses to broadcast probe requests by enabling only one of several SSIDs to respond, in rotation, or reduce responses from specific client device types.

With this feature enabled, select a suppression method:

- a. Select **Allowing only one SSID to respond at a time** to enable a single SSID to respond at a time.
- b. For **Reducing responses to certain client device types** add a new MAC OUI.

See [Configure a MAC Object and MAC OUI](#) on page 269.



Note

When high-density WLAN optimization is enabled, the suppression setting is disabled by default.

7. Enable **Band Steering** and select a mode from the menu.
8. Use the slider to set the **Allowed percentage distribution of 2.4 and 5.0 GHz clients**.

9. Enable **Client Load Balancing** and configure the threshold settings.

Table 85: Load balance clients based on

Airtime	Number of clients
Ignore probe and association requests per device when threshold exceeds: <ul style="list-style-type: none"> CRC Error Rate RF Interference Average Airtime Per Client 	Ignore probe and association requests from clients associated with other Extreme Networks devices until: <ul style="list-style-type: none"> Anchor Period Elapses Query neighbors about client load every
Ignore probe and association requests from clients associated with other Extreme Networks devices until: <ul style="list-style-type: none"> Anchor Period Elapses Query neighbors about client load every 	

10. Enable **Radio Load Balancing** and specify the **Number of Connection Attempts**.
11. Enable **Weak Signal Probe Request Suppression** and specify the **Signal-to-Noise Threshold** in dB.
12. Enable **Safety Net** and specify the time elapse, in seconds or minutes, before a device responds again to association requests after an overload incident.
13. Configure [Configure Radio Settings](#) on page 270.
14. Select **SAVE RADIO PROFILE**.

Related Links

[Configure a MAC Object and MAC OUI](#) on page 269



[Configure Radio Settings](#) on page 270

[Configure a Radio Profile](#) on page 262

Configure a MAC Object and MAC OUI

A MAC address is a 48-bit number typically written in hexadecimal notation that provides a unique address for each client device. An OUI is the first 24 bits of a MAC address. After a MAC object is assigned to a device, it can be grouped to a specific hive. In a MAC firewall policy rule, you can determine which traffic to permit or deny based on the source or destination MAC address. In QoS traffic classification and marking policies, you can prioritize traffic based on the OUI.

Use this task to configure a MAC object and MAC OUI.

1. Select .
2. Select **MAC Address**.
3. Type a **Name**.
4. Type the **MAC Address**.
5. Select **SAVE**.
6. Select .
7. Select **MAC OUI**.
8. Type a **Name**.

9. Type the first six digits of the Mac address, for the **MAC OUI**.
10. Select **SAVE**.

Related Links

[Optimize Radio Usage](#) on page 268

Configure Radio Settings

First, [Configure a Radio Profile](#) on page 262.



You can configure whether you want to use long or short preambles, adjust the beacon period (or interval), and enable the detection of spoofed BSSIDs. For more information about radio settings, see [Radio Settings](#) on page 271.

This task is part of the Radio Profile configuration workflow. Use this task to configure the radio settings.



Note

Extreme Networks provides defaults for each item in this section. The following steps are optional.

1. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
2. Select an existing radio profile, and then select , or to add a new one, select .
3. Expand the **Advanced Settings** section.
4. Select **Auto (Short/Long)** to enable support for short preambles or **Long** to disable short preamble support.
5. Set the period during which APs send beacons.
6. Set the Guard Interval to 800 nanoseconds by deselecting **Enable Short Guard Interval**.
7. To no longer combine data frames into larger frames before transmission, clear the check box for **Enable MAC Aggregate Protocol Data Units**.
8. Select **Enable Frame Burst** so a wireless client will transmit a burst sequence of up to three packets without releasing control of the transmission medium.
9. Select **Enable Transmit Beamforming** to improve data transfer rates for directional signal transmission processing.
10. Select **Enable MU-MIMO** to enable multiple users to receive data using different simultaneous spatial streams from an AP transmit radio chain.
11. If you selected **Enable MU-MIMO**, set **Station Receive Chain** to **Auto** or **1**, which is the chain the AP uses to receive data from the wireless client.
12. If you are using 802.11ax radios, enable **ODFMA**.
13. If you selected **Enable ODFMA**, select **Uplink** or **Downlink**.
14. If you are using 802.11ax radios, enable **BSS Coloring**.
15. If you selected **Enable BSS Coloring**, enter the numerical value of the new BSS color the AP will transmit after surpassing the beacon threshold.
16. Select **Enable Target Wake Time** to enable an AP to minimize medium contention between stations, and to reduce the required amount of **time** that a station in the power-save mode needs to be **awake**.
17. Select **SAVE RADIO PROFILE**.

Related Links

[Configure a Radio Profile](#) on page 262

Radio Settings

Preambles

When you enable short preambles, the AP broadcasts support of short preambles and attempts to negotiate using them with clients. If a client also supports short preambles, the client and AP agree to use them. If a client only supports long preambles, then the AP automatically adjusts to accommodate it, and they agree to use long preambles instead. When you select long preambles, the AP and client both agree to use long preambles. Although a short preamble saves time and improves throughput, a long preamble allows more time for the receiver to tune into and synchronize with the transmitting radio, providing additional decoding accuracy in noisier environments.

Beacon Periods

APs broadcast beacons to all clients within range, and by default, send beacons every 100 TUs (approximately 10 times per second). If APs are in an area with lots of background noise, you might want to add more time between beacon broadcasts, or set an interval from 40 to 3500 TUs (about 24 times per second to about every 3.5 seconds).

Guard Intervals

A guard interval is the amount of time between transmissions to ensure that they do not collide. The default is 800 nanoseconds, which is still suitable for large areas, such as warehouses or outdoors, where the distances between points of reflection are great. For smaller areas, such as office spaces, you can use a shorter interval of 400 nanoseconds. Enabling this option in the right environment can improve data rates.

Aggregate MAC Protocol Data Unit (AMPDU)

AMPDU transmissions reduce overhead when the transmission channel is busy. When AMPDU is enabled, the AP combines data frames into fewer, larger frames before transmission, and recognizes the format of larger frames when it receives them. Generally, enabling AMPDU increases performance.

Frame Bursts

Frame bursts enable a wireless client to transmit data at a higher throughput by using the inter-frame wait intervals to burst a sequence of up to three packets without releasing control of the transmission medium.

BSS Colors

A basic service set (BSS) is the cornerstone topology of any 802.11 network. The communicating devices that make up a BSS consist of one access point radio with one or more client stations. The BSS color is a numerical identifier of the BSS. 802.11ax radios are able to differentiate between BSSs using BSS color identifiers when other radios transmit on the same channel. If the color is the same, this is considered to be an intra-BSS frame transmission. In other words, the transmitting radio belongs to the

same BSS as the receiver. If the detected frame has a different BSS color from its own, then the station considers that frame as an inter-BSS frame from an overlapping BSS.

Related Links

[Configure Radio Settings](#) on page 270

Configure Backhaul Failover

First, [Configure a Radio Profile](#) on page 262.



When **Backhaul Failovers** are enabled, the AP forms a mesh link with other hive members and can failover backhaul communications from Eth0 to a wireless interface if the Ethernet link goes down.



Note

Extreme Networks provides defaults for each item in this section. The following steps are optional.

This task is part of the Radio Profile configuration workflow. Use this task to configure backhaul failover.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Enable **Backhaul Failover**.
5. Configure the following settings to define when to failover the backhaul link from Ethernet to wireless, and when to return the backhaul to Ethernet:
 - a. In **Switch to Wireless Backhaul**, set how long the Ethernet link must be down to trigger a failover to the wireless link.
 - b. In **Revert Back to Wired Backhaul**, set how long the Ethernet link must be up before the AP returns backhaul communications to Ethernet.
Use the menu to specify the time in seconds or minutes.
6. Select **SAVE RADIO PROFILE**.

Related Links

[Configure an Outdoor Deployment](#) on page 272

[Configure a Radio Profile](#) on page 262



Configure an Outdoor Deployment

First, [Configure a Radio Profile](#) on page 262.

You can configure outdoor APs to communicate wirelessly with each other across a great distance by using a directional antenna for the backhaul link, while continuing to use omnidirectional antennas for access. However, you must make some adjustments to the radios to accommodate the longer transmission intervals. A Wi-Fi radio expects to receive an ACK for every transmitted Unicast frame. If it does not receive an ACK, it retransmits the frame. If the distance between the transmitter and receiver is too great, the ACK timeout period elapses before the ACK from the receiver reaches the

transmitter, causing the transmitter to retransmit frames repeatedly until concluding that the frames are not reaching their target.

This task is part of the Radio Profile configuration workflow. Use this task to define the ACK timeout range between APs. By increasing the range, the radio increases the ACK timeout period accordingly.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Set a distance (between 300 and 10,000 meters) over which to support the radio.
5. Select **SAVE RADIO PROFILE**.

Related Links

[Configure RF Interface Reports](#) on page 273

[Configure a Radio Profile](#) on page 262

Configure RF Interface Reports

First, [Configure a Radio Profile](#) on page 262.



ExtremeCloud IQ can periodically poll APs and collect RF interface-related data. ExtremeCloud IQ forces APs to adopt a shorter polling interval if CRC error, channel interference, or short-term polling thresholds are exceeded.



Note

Extreme Networks provides defaults for each item in this section. The following steps are optional.

This task is part of the Radio Profile configuration workflow. Use this task to configure RF interference reports.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. Set the level of CRC errors for polling.
The default threshold is 20% for 802.11g/n, and 35% for 802.11a and 802.11ac. The range is from 15 to 60%.
5. Set the level of channel interference for polling.
The default threshold is 20% for 802.11g/n, and 35% for 802.11a and 802.11ac. The range is from 15 to 60%.
6. Set the short-term average for polling.
The range is 5 to 30 minutes.
7. Select **SAVE RADIO PROFILE**.

Related Links

[Configure Client SLA Definitions](#) on page 274

[Configure a Radio Profile](#) on page 262

Configure Client SLA Definitions

First, [Configure a Radio Profile](#) on page 262.

For each radio mode (or phymode)—11a, 11b, 11g, 11n, 11ac, 11ax—there are default settings for bit rate, success rate, and usage.

In most cases, the AP and client use several different rates to transmit and receive packets, changing rates as factors such as RSSI and packet loss change. To determine a common mid point to which various client scores can be compared, ExtremeCloud IQ provides three settings for each phymode:

Rate: This setting defines the transmission bit rated used by clients with healthy connectivity. For 802.11a/b/g, rates are Mbps. For 802.11n, the rates are Mbps and modulation coding scheme (MCS).

Success: This setting defines the percentage of packets that you expect clients with healthy connectivity to transmit successfully (without retries) at the defined rate.



Usage: This setting defines the percentage of time that clients with healthy connectivity will transmit at the defined rate. The aggregated usage for the two bit rates must be equal to or less than 100%.



Note

To counter traffic congestion from clients with otherwise healthy Tx/Rx bit rates, APs can monitor client throughput and report SLA status to ExtremeCloud IQ. APs can also dynamically increase the amount of airtime for clients with a significant backlog of queued packets and improved throughput.

This task is part of the Radio Profile configuration workflow. Use this task to configure the client SLA definitions.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. To use the default settings, select one of the three options: **High Density (performance-oriented)**, **Normal Density**, or **Low Density (coverage-oriented)**.
Alternately, to customize the settings for each option, select **CUSTOMIZE** and configure the settings on each tab.
5. Select **SAVE RADIO PROFILE**.

Related Links

[Configure WMM QoS Settings](#) on page 274



[Configure a Radio Profile](#) on page 262

Configure WMM QoS Settings

First, [Configure a Radio Profile](#) on page 262.

Wi-Fi Multimedia (WMM) classifies traffic into Voice, Video, Best-effort, and Background access categories, and provides mechanisms to prioritize each category at differing levels. **Contention Window Minimum**, **Contention Window Maximum**, and **AIFS** work together to determine the back-off time for each category. The first two define the minimum and maximum contention window parameters. When there is contention for access to the wireless medium, the AP calculates a random value between these two parameters. The higher the values, the longer the AP will back off during periods of access contention, resulting in longer delays for that traffic category. The lower the values, the shorter the back-off period, with shorter delays for traffic delivery. The AP adds the fixed arbitration interframe space (AIFS) back-off value to the first two values. The higher the setting, the longer the AP backs off, and the longer traffic is delayed during times of contention. The smaller the setting, the less time the AP backs off, resulting in shorter delays.

This task is part of the Radio Profile configuration workflow. Use this task to configure Wi-Fi Multimedia.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces..**
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. If necessary, modify the default settings in the **Contention Window Minimum**, **Contention Window Maximum**, and **AIFS** columns.
5. If necessary, modify the default setting in the **TXOP Limit** column to determine how long bursts of traffic last before relinquishing the medium.
6. Set the **No ACK** flag to inform the recipient not to send ACKs of the frames it receives, which is useful for the video category where lost packets in streaming video go unnoticed, and retransmissions are unnecessary.
7. Select **SAVE RADIO PROFILE**.

Related Links

[Configure Sensor Mode Scan Settings](#) on page 275

[Configure a Radio Profile](#) on page 262

Configure Sensor Mode Scan Settings

First, [Configure a Radio Profile](#) on page 262.



These settings determine how your APs behave during the scanning process. You can specify how long a device scans each channel and which channels to scan.



Note

Dwell time defines how long the radio transmits on a specific channel frequency to scan client probe requests before moving to the next channel in the sequence. For presence data collection, setting the dwell time above the default value raises the throughput of data collected on each channel. Setting the minimum dwell time below the default value reduces latency but also reduces the throughput of data collected on each channel.

This task is part of the Radio Profile configuration workflow. Use this task to configure scan settings for sensor mode.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the radio (2.4 GHz, 5 GHz, or 6 GHz).
3. Select an existing radio profile, and then select , or to add a new one, select .
4. If necessary, modify the **Dwell Time**.
5. Deselect **Scan All Channels** and set individual channel numbers to collect client probe request data.
6. Select **SAVE RADIO PROFILE**.

Related Links

[Configure a Radio Profile](#) on page 262

IoT Profiles

The IoT (Internet of Things) is a network of interconnected smart devices. Smart devices are embedded with software, sensors, and network connectivity that enables them to collect and share data. The smart devices communicate with each other and with other internet-enabled devices, like smartphones and gateways, creating a vast network of interconnected devices that can exchange data and perform a variety of tasks autonomously.

Extreme Platform ONE Networking uses IoT profiles to support IoT applications.

Related Links



[Configure IoT Profile Settings](#) on page 276

[Configure the Thread Commissioner](#) on page 280

Configure IoT Profile Settings

First, [Configure a Radio Profile](#) on page 262.

This task is part of the Radio Profile configuration workflow. Use this task to configure an AP5010/AP5020 to function as a backbone border router in a thread network, as part of a network policy.

1. In the device template, select **Device Configuration** and expand **Wireless Interfaces**.
2. Select the **IoT0** tab.
3. Toggle **Radio Status** to **ON**.
4. Select an existing profile, and then select , or to add a new one, select .
5. Configure the settings as described in [Table 86](#) on page 277 or [Table 87](#) on page 278.
6. Select **Save**.
7. (Optional) Select **Customize** to [Configure the Thread Commissioner](#) on page 280.

Related Links

[IoT Profile Settings](#) on page 277

[Configure the Thread Commissioner](#) on page 280

IoT Profile Settings

- [Thread Profile Settings \(Single IoT Application\)](#)
- [Thread Profile Settings \(Multiple IoT Applications\)](#)

Table 86: Thread Profile Settings (Single IoT Application)

Setting	Description
Name	Enter a Name for the profile.
IoT Application(s) Supported	Select Single from the menu.
Function	The default is Thread .
Application	The default is Thread Gateway .
Network Name	Enter a Network Name for the Thread network of an AP. Each AP participates in a Thread network identified with the PAN ID and EXT PAN ID configured for the Thread Profile.
Network Key	Enter the Network Key used to encrypt communication between devices in a Thread network.
PAN ID	The PAN ID (Personal Area Network Identifier) identifies the Thread network of the AP. Enter a 16-bit value for use in RF data transmissions between devices in a Thread network.
EXT PAN ID	Enter a 64-bit value for use in RF data transmissions between devices in a Thread network. The EXT PAN ID must be unique. It is used for a more specific network identification.
Channel	Choose an IEEE 802.15.4 AP Channel number from the drop-down list (11-26). The default is channel 15. Note: Thread channel 25 is only supported if the country supports IEEE 802.11 channels 12, 13, or 14. Thread channel 26 is only supported if the country supports IEEE 802.11 channels 13 or 14.
Default User Profile	Set the default VLAN user profile. Select an existing user profile to associate with this VLAN or create a new profile. To create a new user profile, see Add a User Profile on page 192. Note: Currently, only the VLAN of the associated User Profile is configured by the IoT profile.

Table 86: Thread Profile Settings (Single IoT Application) (continued)

Setting	Description
Enable NAT64	Enable NAT64 allows an AP to perform IPv6 to IPv4 translations between the Thread and backbone networks. This option is selected by default.
Add domain to upstream DNS queries	To append the domain name to the host name before forwarding the DNS query, select Add domain to upstream DNS queries .

Table 87: Thread Profile Settings (Multiple IoT Applications)

Setting	Description
Name	Enter a Name for the profile.
IoT Application(s) Supported	Select Multiple from the menu.
BLE Beacon	
Application	Select the corresponding check boxes for the applications that you want to configure: iBeacon , and Eddystone-url .
iBeacon	Edit the settings as required and select SAVE .
Eddystone-url Beacon	Edit the settings as required and select SAVE .
BLE Scan	
Application	Select the corresponding check boxes for the applications that you want to configure: iBeacon , Eddystone-url , and Generic .
Destination	Select Cloud Reporting , Batch Reporting , or both. Specify the interval in seconds. For Batch Reporting , specify the destination URL. To remove duplicate entries reported for the Batch Reporting interval, keeping only the latest entry for each BLE tag, toggle Remove Duplicates to ON . Note: ExtremeCloud IQ always removes duplicate entries for Cloud Reporting .
iBeacon Filter	Edit the settings as required and select SAVE .
Eddystone-url Beacon Filter	Edit the settings as required and select SAVE .
Generic Filter	Edit the settings as required and select SAVE . Note: If you select Custom for the Vendor , type the Company Name and the Company ID .

Related Links

[Configure IoT Profile Settings](#) on page 276

Thread Application

Thread is an IP-based, low-power wireless protocol designed to facilitate connecting to and controlling IoT devices. Thread uses a mesh architecture, which supports more efficient and robust networking.

Elements of a Thread network include the following:

- **Thread Router**
 - Manages communication between devices within the Thread network.
 - Maintains a routing table to promote the efficient routing of messages.
 - Generally has no ability to communicate with networks outside the Thread network.
- **Border Router**
 - Extends the capabilities of a Thread Router to allow communication with networks outside the Thread network.
 - Acts as a gateway to external networks.
 - Performs NAT (Network Address Translation) to facilitate communication between external networks and the Thread network.
- **Backbone Border Router**
 - Extends the capabilities of a Border Router to allow communication between the Thread network and backbone networks.
 - Supports fail-over mechanisms to ensure network resilience.
 - Generally supports higher capacity and greater speeds compared to regular routers for faster and more reliable communication with external networks.

With Extreme Platform ONE Networking, assign an IoT Thread profile to an AP5010/AP5020 wireless interface to have the device function as a BBR (Backbone Border Router).



Note

Extreme Platform ONE Networking IoT Thread application is supported on AP5010/AP5020 only.

IoT Thread is not supported on simulated devices.

With Extreme Platform ONE Networking, the BBRs in the network negotiate and together elect one PBBR (Primary Backbone Border Router). The PBBR routes traffic between the Thread network and the Backbone network.

Although there can be multiple BBRs in a Thread network, only one can be PBBR at any time. The others act as secondary BBRs. If the PBBR is unreachable, failover occurs to a negotiated secondary BBR, which then becomes the new PBBR.

The IoT Thread profile allows for:

- Specifying key properties of the Thread network, such as its name, network key, PAN ID, Extended PAN ID, channel, and whether or not to enable NAT64.
- Optionally, you can specify the behavior of the Commissioner for the Thread network, including its credentials, timeout, and list of allowed devices.

- Optionally, you can configure the Default User Profile to be associated with the IoT Thread profile by applying only the VLAN.

Consider the following:

- IoT Thread profile configuration automatically takes precedence over BLE configuration. If BLE is configured and deployed, and later IoT Thread is configured and deployed, BLE becomes disabled and IoT Thread is enabled. If BLE configuration exists but has yet to be deployed, and then later IoT configuration is done and deployed, only the IoT configuration is pushed to the AP.
- Only one Commissioner can be active at any given time in a Thread network.

Related Links

[IoT Profiles](#) on page 276

[Configure IoT Profile Settings](#) on page 276

[Configure the Thread Commissioner](#) on page 280

Configure the Thread Commissioner



First, [Configure IoT Profile Settings](#) on page 276.

Use this task to define the behavior of the Thread Commissioner role, which can later be assigned to an AP5010/AP5020. The Thread Commissioner securely screens endpoint devices attempting to join the Thread network. The Commissioner uses an Allow List to identify the IoT endpoint devices which have permission to join the Thread network.



Note

Only one Commissioner can be active at any given time in a Thread network.

1. Select an existing Thread Application profile, and then select , or to add a new one, select .
2. Scroll down to **Commissioner**, and select **CUSTOMIZE**.
3. (Optional) Type the **Commissioner Credential** consisting of 6 to 250 alphanumeric characters.
4. (Optional) Set the **Commissioner Timeout** to a value in the range of 1-2000000 seconds.

This value represents the ideal or known amount of time it takes for all the IoT endpoint devices defined in the Allow List to join the Thread network. The default is 120 seconds.



Note

If all of the IoT endpoint devices defined in the Allow List have joined the network but the Commissioner is still running because the Timeout value is set too high, you can force the Commissioner to stop running.

5. Under **Allow List of Thread-End Devices**, choose from the following actions:
 - Add devices to the Allow List either manually or in bulk, or using a combination of both methods.
 - To add devices manually, proceed to step 6 on page 281.
 - To add devices in bulk, proceed to step 7 on page 281.

**Note**

This method is available only after the Thread profile is saved.

- Edit a device entry in the Allow List. Select the target entry, then select .
 Edit the entry according to steps 6.b on page 281 and 6.c on page 281, then select **Save**. When editing is complete, proceed to step 8 on page 281.
 - Delete entries in the Allow List. Select one or more entries, then select . Proceed to step 8 on page 281.
 - Download the entries in the Allow List to a csv file. Select .
 - Search for an entry in the Allow List. Enter a Joiner ID or PSK ID in the search field, then select .
6. Optionally, add devices to the **Allow List** manually, as follows:
 - a. Select .
 - b. In the **Joiner ID** field, enter a value consisting of 16 hex digits (excluding 16 "F"s) representing the device's EUI-64 (64-bit Extended Unique Identifier). Alternatively, enter * to admit any joiner.
 - c. In the **Pre-Shared-Key for Device (PSKd)** field, enter a value for the shared password in the range of 6-32 alphanumeric characters (0-9, upper-case A-Y, excluding I, O, Q, and Z).
 - d. Select **Add**.
 - e. Repeat steps 6.a on page 281 through 6.d for each device added.
 - f. Proceed to step 8 on page 281.
 7. Optionally, add devices in bulk. Select **Import** to upload a csv file containing the device details. From the **Import Allow List of Thread End-Devices** window, choose from the following actions:
 - Deselect the **Delete all Allow List entries prior to import** check box to append the IoT device entries in a csv file to the existing Allow List. By default, this option is selected, resulting in the removal of existing Allow List entries before device entries in a csv file are imported.
 - Select **Download an example CSV import file** to view the required format of device entries to successfully import the list.
 - Drag to the **Choose File** field a csv file containing device entries to be imported, or select **Choose** to upload a locally stored csv file.
 - Select **Submit** to upload and add the device entries from the csv file to the Allow List, or select **Close** to exit the window.
 8. To save the settings, select **Save**, or select **Cancel** to close the window without saving settings.

To assign the Thread Commissioner role to an AP, go to **Manage > Devices** < *select an AP5010 or AP5020* > **Actions > Start Thread Commissioner**. If necessary, you can select **Stop Thread Commissioner** and reassign the Commissioner role to another AP.

Related Links

[Configure IoT Profile Settings](#) on page 276

Configure Wired Interfaces for an AP Template

Create or edit an AP template.

This task is part of the network policy configuration workflow. Use this task to configure wired interfaces on the AP.

1. Select a **Device Model**, and then select an existing **Template**, or a default template.
2. Scroll down to the **Wired Interfaces** section.
3. To activate an Ethernet port, toggle the **Interface State** to **ON**.
4. Select one of the following **Port Types**:
 - **Uplink Port**: Use when connecting the AP to the WAN. Use when dynamic trunk port configurations are desired. The Uplink Port automatically translates SSDI configurations as well as global native and Management ports to reduce the need for static trunk port configurations.
 - **Access Port**: Use when the AP is working in client access mode and is connected to a forwarding device, such as a switch that supports multiple VLANs.
 - **Trunk Port**: Use when connecting the AP in bridge mode to a forwarding device, such as a switch that supports multiple VLANs.
5. For **Native VLAN (read only)**: The native (untagged) VLAN assigned to frames that do not have any 802.1Q VLAN tags in their headers.

By default, Extreme Networks devices use VLAN 1 as the native VLAN. To apply VLANs to devices using classification (uplink port only; not trunk ports), highlight the Ethernet port icons and see [Configure Classification Rules for a Device Template](#) on page 305.
6. For **Allowed VLANs (read only)**: Enter the VLANs—including the native VLAN—that you want the trunk port to permit.

You can list the VLANs individually, separated by commas, or as a range of VLANs using a hyphen. Alternatively, you can enter the word `all` in this field to support all existing VLANs previously configured in the network policy (the default). To apply VLANs to devices using classification (uplink port only; not trunk ports), highlight the Ethernet port icons and see [Configure Classification Rules for a Device Template](#) on page 305.
7. For **Fabric Attach**: Select the add icon, enter the device's associated **VLAN ID** and select its **I-SID#** from the drop down.

Use this field to configure a device connected to an existing Fabric Connect network. The device must already be physically connected to the Fabric Connect switch.

8. For **Transmission Type**, select one of the following:
 - **Auto**: The switch negotiates the best common duplex mode with the connected device.
 - **Full-Duplex**: Forces the switch to communicate with the connected device using full duplex communication.
 - **Half-Duplex**: Forces the switch to use half duplex communication.
9. Select the **Speed** the Ethernet port uses to communicate with the connected device.
10. Select **Green Ethernet** for AP4020 and AP5020 devices to enable Energy-Efficient Ethernet (EEE).

The IEEE 802.3az standard, also known as EEE, introduces enhancements that enable physical layer transmitters to reduce power consumption during periods of idleness or low data activity. By enabling EEE, the network port can switch between active mode (during data transmission) and idle mode (when there is no Ethernet traffic), thereby consuming less power during idle or low activity states.
11. Select **LLDP** for devices to advertise their identities, status, and capabilities to each other.

Devices can transmit data about themselves and receive transmitted data from other devices, but they cannot solicit and retrieve data from other devices.
12. Select **CDP** for devices to advertise an IP address that can send and receive SNMP traps.
13. Select **MCast Filter** to enable Multicast Rate Limiting on the interface for multicast/broadcast traffic, and configure **Multicast Rate Limit** to set the maximum rate (in Kbs) for incoming multicast traffic for the interface.
14. Optionally, set **USBNET** to **On** to activate the USB Port, and configure the **VLAN**.

**Note**

By default, the USB port will provide power when the AP is powered by 802.3 at the power source. If USBNET is enabled, it will be configured as an access port. The USBNET interface can be configured only for IQ Engine version 10.2r4 and later.

Continue configuring the AP template.

Electronic Shelf Labeling

Electronic Shelf Labeling (ESL) consists of the following components:

- ESL tags, which are 2.4 GHz RF-based battery powered devices
- An ESL communicator used to communicate with the ESL tags
- A server that provides the configuration and updates to the ESL tags

The following access points support Electronic Shelf Labeling:

- AP305C
- AP410C
- AP4020

- AP5010
- AP5020

Configure ESL on a device template or as an individual AP override.

**Note**

Consider the following for the ESL support.

- An ESL Server behind a NAT (Network Address Translation) or firewall is not supported.
- Do not make configuration changes during ESL programming and setup.

Related Links

[Electronic Shelf Labeling Setup](#) on page 284

[Configure Electronic Shelf Labeling in a Device Template](#) on page 285

[Configure Electronic Shelf Labeling as a Device Override](#) on page 285

Electronic Shelf Labeling Setup

Use this task to enable Electronic Shelf Labeling (ESL).

1. Prepare the AP device:
 - a. Ensure that the access point is getting 3AT/3AT+ power.
 - b. Connect ESL communicator to access point USB port.
 - c. Ensure that the LED on the ESL communicator is red.
2. In Extreme Platform ONE Networking, [Configure Electronic Shelf Labeling in a Device Template](#) on page 285 or [Configure Electronic Shelf Labeling as a Device Override](#) on page 285 for a supported AP model.

The following access points support Electronic Shelf Labeling:

- AP305C
- AP410C
- AP4020
- AP5010
- AP5020

3. Ensure that the LED on the ESL communicator is amber.



Important Troubleshooting Tips:

No LED light on ESL communicator

Check the power supply. The AP requires 3AT/3AT+ power supply to work with a USB port.

The LED continues to be red

Check the AP logs to verify that ThinAP2 has started.

The LED continues to be Amber

Check the IP address of AP, the AP-ID, and the connectivity between the AP and the ESL server.

Related Links

[Electronic Shelf Labeling](#) on page 283

[Configure Electronic Shelf Labeling in a Device Template](#) on page 285

[Configure Electronic Shelf Labeling as a Device Override](#) on page 285

[Electronic Shelf Labeling Settings](#) on page 286

Configure Electronic Shelf Labeling in a Device Template

Use this task to configure Electronic Shelf Labeling (ESL) in the [device template](#).

1. Select an AP template for one of the supported AP models.
The following access points support Electronic Shelf Labeling:
 - AP305C
 - AP410C
 - AP4020
 - AP5010
 - AP5020
2. Scroll down to the **Electronic Shelf Labeling** section and select **Enable Imagotag**.
3. Configure the [Electronic Shelf Labeling Settings](#) on page 286.

Related Links

[Configure AP Templates](#) on page 257

[Electronic Shelf Labeling Settings](#) on page 286

Configure Electronic Shelf Labeling as a Device Override

Use this task to configure Electronic Shelf Labeling as a device override.

1. From **Network Devices**, select a supported AP model.
The following access points support Electronic Shelf Labeling:
 - AP305C
 - AP410C
 - AP4020

- AP5010
 - AP5020
2. From the left pane, expand **Action** and select **Configure Device**.
 3. In the **CONFIGURATION** section, select **Interface Settings**.
 4. Scroll down to the **Electronic Shelf Labeling** section and select **Enable ESL**.
 5. Configure the [Electronic Shelf Labeling Settings](#) on page 286.

Related Links

[Electronic Shelf Labeling Settings](#) on page 286

Electronic Shelf Labeling Settings

Configure the following settings for Electronic Shelf Labeling (ESL) support:

Server

The IP address of the ESL server.

Channel

The RF channel used for ESL communications. Set the channel to **Managed (Auto)** to have Extreme Platform ONE Networking select the communications channel.

Port

The port associated with the defined rule. To explicitly specify a port number, type the port number in this field. Traffic from this port is subject to the defined rule.

VLAN

The VLAN used to route ESL traffic.

Related Links

[Configure Electronic Shelf Labeling in a Device Template](#) on page 285

[Configure Electronic Shelf Labeling as a Device Override](#) on page 285

[Electronic Shelf Labeling](#) on page 283

Configure AP Device Template Advanced Settings

ExtremeCloud IQ can update device firmware and reboot the device during onboarding.

Use this task to configure **Advanced Settings** for an AP device template.

1. In the device template, select **Advanced Settings**.
2. To upgrade the device firmware when onboarding, toggle **Upload device firmware upon device authentication** to **ON**.

If you have activated device firmware upgrading, select one of two options:

- Update firmware to the latest version.
- Upgrade to a specific device firmware version.

If you choose this option, select the firmware version. To manage the list of firmware versions, select **ADD/REMOVE**.

3. To **Reboot after uploading**, toggle the setting **ON**.

**Note**

As a best practice, disable the reboot option when deploying devices in a meshed environment.

4. For **Antenna Location Type**, select a location.

**Note**

- You must have IQ Engine Version 10.2.2 or higher. The 6 GHz radio is supported Low Power Indoor (LPI) only.
- Antenna Location Type does not apply to AP5020.
- Because different radio tables are used, a full config push is required.

5. For **Supplemental CLI**, see [Configure Supplemental CLI](#) on page 304.

6. Select a **Country Code** from the menu.

**Note**

For Legacy World and EU SKU devices, the template country code assignment only takes place when a device is initially onboarded.

7. Enable **Override MGT0 MTU** to manually enter a maximum transmission unit (MTU) value, ranging from 100-1500 Bytes. Default value is 1500 Bytes.
8. Enable **POE Profile Override** (AP5010 only), and select the override option from the menu.
Hover over the **i** to view the corresponding override table.
9. Select **SAVE TEMPLATE**.

Related Links

[Configure Supplemental CLI](#) on page 304

[Configure AP Templates](#) on page 257

Configure Switch Templates

You can create a switch template during the network policy creation process, or at the device level after you have a network policy in place. Device-level changes to a switch template override settings in the network policy.


Create a network policy for the switch model. After you save the **Policy Details**, select **3 Switching/Routing**.

A switch template is a visual depiction of the physical ports on a switch. Configure how ports function by assigning port types and port usage settings to the template, and then applying the template to managed switches. The following steps describe how to create a switch template inside the network policy creation workflow.

Under **Device Configuration**, you can choose to override settings made under **Common Settings** in a network policy. The Switch Template Override feature allows you to create and manage switch templates based on common settings for SwitchEngine and ExtremeXOS. These common settings include STP, MAC Locking, IGMP, Extreme

Loop Recovery Protocol Settings (ELRP), MTU, PSE, and Management Interfaces (Switch Engine only). The default values for these settings are defined within the common switch settings for each platform type. When you create a new switch template and enable the override option, you can customize device configuration settings that will override the network policy switch common settings. If the override option is disabled, the network policy common settings inherit the device configuration.

This task is part of the network policy configuration workflow. Use this task to configure a switch template as part of a network policy.

1. On the **3 Switching/Routing** page, select **Configuration Settings > Switch Templates**.
2. To edit an existing switch template, select the corresponding link in the table, or to add a new template, select  and select the switch model.
3. Type a **Name** for the template.
4. To make changes to the device configuration, enable **Override Policy Common Settings**.
5. For STP Configuration, see [Configure Switch STP Settings](#) on page 289.
6. For **MAC Locking Settings**, select to control the forwarding database for learned MAC address entries on a port.

**Note**

MAC Locking must also be enabled on a per-port basis.

7. Enable **IGMP Snooping** and configure the settings.
 - **Enable immediate leave:** Instructs the switch to remove a multicast host from the multicast forwarding table immediately upon receipt of a leave-group-membership message.
 - **Suppress redundant IGMP membership reports to optimize traffic:** Suppresses redundant IGMP membership reports from multiple hosts on a subnet. The switch sends a single report to the IGMP router, reducing traffic.
8. For **Extreme Loop Recovery Protocol Settings**, select to configure ELRP client periodic packet transmission for VLANs assigned to a port type to detect and prevent loops.

This option enables an ELRP client and disables a port when a loop is detected on the applied access or trunk VLANs assigned to the port type.

**Note**

ELRP must also be enabled within the switch template.

9. Enable **DHCP Snooping**, and select **Enable drop rogue DHCP Packets action**
Ports configured as trusted do not apply the drop action. By default, port types configured as Trunk Port are trusted.
10. For **MTU Settings**, enter a maximum transmission unit value for Ethernet interfaces.
The MTU value determines the largest packet size that can be transmitted through your system.
11. For **PSE Settings**, toggle to **On** to configure maximum power thresholds to generate alerts to ExtremeCloud IQ about exceeding maximum power levels.

12. Select **Enable Flow Control** to manage the port data receive transmission rate.
13. For **Management Interface Settings**, select one of the following options:
 - **Infer from device** (Switch Engine/EXOS): Select when the switch supplies the management interface.
 - **VLAN Interface**: Select when the management interface is to be supplied by the management VLAN.
 - **Management VLAN**: Enter the VLAN to be used by the switch.
 - **Management IP Settings**: Select to enable DHCP on this interface.
14. For the **Port Configuration** section, see the following:
 - To configure **Instant Port Profile**, see [Configure an Instant Port Profile](#) on page 290.
 - To **Configure Ports in Bulk**, see [Create a New Port Type](#) on page 294
 - To **Configure Ports Individually**, see [Configure Individual Ports](#) on page 297
15. For **Supplemental CLI**, see [Configure Supplemental CLI](#) on page 304.
16. For **Advanced Settings**, see [Configure Switch Device Template Advanced Settings](#) on page 303.
17. Select **Save**.

Configure Switch STP Settings

Before you begin this task, create or modify a switch template.

By default, STP is disabled. Use this task to toggle it on and configure the settings. Extreme Networks recommends that you enable STP.

1. Toggle **STP (Spanning Tree Protocol)** to **ON**, and select one of the following modes:

STP: Uses a single spanning tree without regard to VLANs. After convergence, only the root bridge sends configuration BPDUs, and other switches only relay those BPDUs.

RSTP: Uses a single spanning tree without regard to VLANs. After convergence, all switches send BPDUs every two seconds in the event of a physical link failure.

MSTP: Can map a group of VLANs into a single multiple spanning tree instance (MSTI). MSTP uses BPDUs to exchange information between spanning-tree compatible devices, to prevent loops in each MSTI by selecting active and blocked paths.

2. Select the **STP Bridge Priority**.

Every switch taking part in spanning tree has a bridge priority. The switch with the lowest priority becomes the root bridge. If there's a tie, the switch with the lowest bridge ID number wins. The ID number is typically derived from a MAC address on the switch.

3. Set the following parameters for **STP Timers**:

Forward Delay: The time the switch spends in the listening and learning state.

Max Age: The maximum time before a bridge port saves its configuration BPDU information.

Instant Port Profiles

Configuring Instant Port Profiles (IPP) in Extreme Platform ONE Networking is an automated approach to configuring switch ports based on the connected devices. Instant Port Profiles streamline the management of network-connected devices, such as access points (AP), security cameras, and VoIP devices by dynamically provisioning the appropriate port configuration.

Instant Port Profile configuration comprises the following tasks:

- Create an Instant Port Profile
- Create Instant Port Device Type




Related Links

[Configure an Instant Port Profile](#) on page 290

[Configure an Instant Port Device Type Profile](#) on page 291

Configure an Instant Port Profile

Add or edit an IPP for a switch on the **Port Configuration** tab of the switch template.

1. On the switch template page, select **Port/VLAN Configuration** and then choose one of the following actions:
 - To add a new IPP, select .
 - To edit an existing IPP, select , choose the IPP object, and then select .
2. Configure the [Instant Port Profile Settings](#) on page 290.

Related Links

[Instant Port Profile Settings](#) on page 290

Instant Port Profile Settings

Configure the following IPP settings.

Table 88: IPP Configuration Settings

Field	Description
Name	Type a Name for the Instant Port Profile.
Description	Type a Description for the Instant Port Profile.
Non-Forwarding VLAN	From the menu, select a VLAN to detect attached devices; this VLAN does not forward traffic. The non-forwarding VLAN cannot be utilized within a port type assigned to the switch.

Table 88: IPP Configuration Settings (continued)

Field	Description
Default Port Type	<p>From the menu, select the default port type:</p> <ul style="list-style-type: none"> • Access Port—Use for a port connected to an individual host. • Trunk Port—Use for a port connected to a forwarding device such as an AP and switch that supports multiple VLANs. <p>Ports assigned to an Instant Port Profile inherit the selected port type settings, such as type, speed, STP, MAC locking, ELRP, and PSE port settings.</p>
Non-Match Action	<p>Select one of the options:</p> <ul style="list-style-type: none"> • Non-Forwarding VLAN—Does not forward traffic for devices that do not match an assignment rule. • Use Default Port Type VLAN—Assigns the VLANs associated with the port type. <p>Storm control settings are inherited when the non-match action is set to use the default port type and the device does not match a defined device type.</p>
Device Types	<p>Add a new Device Type, edit or delete an existing Device Type. Configure the IPP Device Type Settings on page 292.</p>

Related Links

[Instant Port Profiles](#) on page 290

[Configure an Instant Port Device Type Profile](#) on page 291


[IPP Device Type Settings](#) on page 292

[Configure an Instant Port Profile](#) on page 290

Configure an Instant Port Device Type Profile

Configure a Network Policy with a Switch Template and an Instant Port Profile.

The Port Device Type profile is part of the Instant Port Profile. When a device connects to a switch port, Extreme Platform ONE Networking uses the criteria defined in this task to determine whether the device port is eligible for application of the Instant Port Profile.

1. In the **Create Instant Port Profile** dialog, under **Device Types**, select .
2. Configure the **Instant Port Device Type** settings as described in [IPP Device Type Settings](#) on page 292.
3. Select **Save** to commit changes, or select **Cancel**.

Related Links

[Configure an Instant Port Profile](#) on page 290

IPP Device Type Settings

Configure the following Instant Port Profile Device Type settings.

Table 89: IPP Device Type Settings




Field	Description
Name	Type a Name for the Device Type profile.
Description	Optionally, type a Description of the Device Type profile.
Match Category	<p>Select a Match Category. Options are:</p> <ul style="list-style-type: none"> • MAC Learning—Matches the device based on the MAC address learned on the port from untagged traffic. The match criteria can be an exact MAC, OUI-based MAC, or custom MAC mask format. • LLDP Src MAC—Matches the device based on the source MAC of a LLDP PDU. The match criteria can be an exact MAC, OUI-based MAC, or custom MAC mask format. • LLDP Capability—Matches the device based on the LLDP capability from the source LLDP PDU. Options are: • LLDP Src MAC + LLDP Capability—Matches the device based on the source MAC of a LLDP PDU and the selected LLDP capability from the source LLDP PDU. <p>If you choose MAC Learning or LLDP Src MAC, configure the following fields:</p> <ul style="list-style-type: none"> • MAC Address/OUI <ul style="list-style-type: none"> ◦ Select  and choose a MAC address. ◦ Select  to add a custom MAC Address or MAC OUI. ◦ Select  to edit a custom MAC Address or MAC OUI. • MAC Mask <ul style="list-style-type: none"> ◦ Enter a custom MAC mask format. ◦ Select the Edit MAC Mask check box, then edit the entry in the MAC Mask field. <p>If you choose LLDP Capability, use the drop-down menu to choose one of the following options:</p> <ul style="list-style-type: none"> • Avaya Phone • Gen Tel Phone • Router • Bridge • Repeater • WLAN Access Pt • Docsis Cable Ser • Station Only • Other <p>If you choose LLDP Src MAC + LLDP Capability, configure the parameters as described above.</p>
PORT USAGE tab	

Table 89: IPP Device Type Settings (continued)













Field	Description
Port Usage	Select a Port Usage option, as follows: <ul style="list-style-type: none"> Access Port Trunk Port (802.1Q VLAN Tagging) Phone with a Data Port
VLAN tab	
VLAN	This field appears if Port Usage is configured as Access Port . Choose from the following actions: <ul style="list-style-type: none"> Select  and choose a VLAN. Select  to add a custom VLAN. Optionally, select the Apply VLANs to devices using classification check box. Select  to edit a custom VLAN.
Native VLAN	This field appears if Port Usage is configured as Trunk Port (802.1Q VLAN Tagging) . Choose from the following actions: <ul style="list-style-type: none"> Select  and choose a Native VLAN. Select  to add a custom Native VLAN. Optionally, select the Apply VLANs to devices using classification check box. Select  to edit a custom Native VLAN.
Allowed VLANs	This field appears if Port Usage is configured as Trunk Port (802.1Q VLAN Tagging) . Enter the VLAN names using comma delimiters (vlan1,vlan2,vlan3...).
Voice VLAN (tagged)	This field appears if Port Usage is configured as Phone with a Data Port . Choose from the following actions: <ul style="list-style-type: none"> Select  and choose a Voice VLAN. Select  to add a custom Voice VLAN. Optionally, select the Apply VLANs to devices using classification check box. Select  to edit a custom Voice VLAN.
Data VLAN (untagged)	This field appears if Port Usage is configured as Phone with a Data Port . Choose from the following actions: <ul style="list-style-type: none"> Select  and choose a Data VLAN. Select  to add a custom Data VLAN. Optionally, select the Apply VLANs to devices using classification check box. Select  to edit a custom Data VLAN.
STORM CONTROL tab	
Broadcast	Select Broadcast to include traffic that is forwarded to all destinations simultaneously.
Unknown Unicast	Select Unknown Unicast to include traffic whose destination address does not appear in the forwarding database.
Multicast	Select Multicast to include traffic whose destination is a multicast address.
Thresholds	The default is Packet Based .

Table 89: IPP Device Type Settings (continued)

Field	Description
Rate Limit Type	The default is PPS (packets per second).
Rate Limit Value	Enter (in packets per second) when the switch should discard traffic of the selected types.


Related Links

[Configure an Instant Port Device Type Profile](#) on page 291

Create a New Port Type

Create or modify a port type.

Use this task to create ports in bulk.

1. Either under **Create Ports in Bulk**, select one or more ports and select **Assign > Create New** or select  (next to **Port Type** under **Configure Ports Individually**).
2. If this template applies to a 5570 or 5520 switch, define the VIM Port Channelization ports.
 - a. Under **Configure Ports in Bulk**, select **Select VIM**.
 - b. For a 5570 switch, select **VIM-6YE** or **VIM-2CE**.
 - c. For a 5520 switch, select **VIM-4X**, **VIM-4XE**, or **VIM-4YE**.

**Note**

If different templates for the same switch SKU are required to be created with different VIMs, then a classification rule can be created to assign the same template SKU with different VIM options to different devices. See [Configure Classification Rules for a Device Template](#) on page 305 for more information about classification rules.

- d. Select one or more of these VIM ports and continue to Step 3.
3. Type a **Name**.
 4. (Optional) Edit the associated **Description**.
 5. Toggle the port **ON** or **OFF**.
 6. In the **Port Usage Settings** section, select one of the following port types:
 - **Access Port:** Ports connected to individual hosts such as printers, servers, and end-user computers.
 - **Phone with a data port:** Ports connected to IP phones, and optionally, to computers cabled to the phones.
 - **Trunk port:** Ports connected to network forwarding devices, such as switches and APs that support multiple VLANs on trunk ports.
 7. Select **Next**.
 8. Select an existing VLAN or select the add icon to add a new one.
To add a new VLAN, see [Configure VLAN Settings](#) on page 231.
 9. Select **Next**.

10. Set authentication options for switches with Instant Secure Port enabled. By default User Authentication (802.1x) and MAC authentication will set the reauthentication period to 3600 seconds. Instant Secure Port Profile must be enabled within the network policy and switch template. For **Instant Secure Port Authentication Settings**:

- **User Authentication:** Turn **On** for wired devices, such as printers, servers, and end-user computers.
- **MAC Authentication:** Turn **On** for legacy devices that use MAC addresses as the user name and password to authenticate clients.
 - **Authentication Protocol:** Select the authentication protocol that determines how the port forwards requests to the RADIUS or Active Directory server. Valid values are PAP, CHAP, and MS Chap V2.

With PAP, the port sends an unencrypted password to the RADIUS server. With CHAP or MS CHAP V2, instead of sending a password, the port and the authentication server perform the same operation on the password, the server compares the results to determine if the results match.

11. Select **Next**.
12. Add RADIUS Servers under **RADIUS Settings** to use this form of user authentication.

Either select an existing **RADIUS Server Group** or select the add icon to add a new one. See [Configure an External RADIUS Server](#) on page 221.

13. For **Authentication Method Priority**, use the up or down arrows to determine the authentication method use order.
14. For **QoS Settings**, toggle **On** to create custom settings.

Select the 802.1p classification system (marked in the L2 frame header in Ethernet frames) or the DiffServ codepoint marking system (marked in the L3 packet header) on outgoing packets from the drop-down list. See [Configure Marker Maps](#) on page 241.

15. Select **Next**.

16. For **Transmission Settings**, configure the following:

- **Transmission Type:** Select **Auto**, **Half-Duplex**, or **Full-Duplex**. Auto causes the switch to negotiate the best possible duplex mode possible with the connected device. Full-Duplex forces the switch to communicate with the connected device using full-duplex communication. Half-Duplex forces the switch to use half-duplex communication.
- **Transmission Speed:** Choose the speed the switch port uses to communicate with the connected device.
- **Debounce Timer:** Select the amount of time the switch does not register another input.
- **CDP Receive:** Enables the switch to receive and parse the information within Cisco CDP frames.
- **Auto MDIX:** Automatically detects the required cable connection type (straight through or crossover) and configures the connection appropriately.
- **LLDP Transmit:** Enables the switch to transmit LLDPDU frames.
- **LLDP Receive:** Enables the switch to receive LLDPDU frames.

17. Select **Next**.

18. For **STP**:

- **STP Enabled**: Toggle **ON** to enable STP for the port.
- **Edge Port**: Connects to a user terminal or server, instead of other switches or shared network segments. A port configured as an Edge port does not cause a loop upon network topology changes.
- **BPDU Protection**: Use the drop-down list to change BPDU protection to guard or filter status.
 - **Guard** - Controls whether a port explicitly configured as Edge disables itself upon reception of a BPDU. The port enters the error-disabled state, and is removed from the active topology.
 - **Filter** - Controls whether a port explicitly configured as Edge transmits and receive BPDUs. You must select this option for Fabric Engine switches.
 - **Disabled** - Turns off BPDU Protection.
- **Priority**: When this port is an STP edge port, select a port priority for STP from the drop-down list.

19. Select **Next**.

20. For **Storm Control**:

- **Broadcast**: Select to include traffic that is forwarded to all destinations simultaneously.
- **Unknown Unicast**: Select to include traffic whose destination address does not appear in the forwarding database.
- **Multicast**: Select to include traffic whose destination is a multicast address.
- **TCP-SYN**: Select to include TCP-SYN flood traffic.
- **Thresholds**: Select **Byte Based** or **Packet Based**.
- **Rate Limit Type**: Select **Kbps** (kilobytes per second) or **Percentage** if you selected **Byte Based** and **PPS** (packets per second) if you selected **Packet Based**.
- **Rate Limit Value**: Enter when the switch should discard traffic of the selected types.

21. For **MAC Locking**, enable the per port type with the option to specify **Maximum First Arrival Limit** and specify the **Link Down Action**.

By default, **Link Down Action** it is set to clear first arrival MACs, with the option to retain MAC's. We also have the option to take action when MACs are aged out.

22. Select general **ELRP Settings** and configure the settings:

- Toggle **Enable ELRP**.
- Select the **Enable ELRP for dynamically created VLAN(s)** check box.
- Toggle **Configure ELRP Port Duration** and enter the duration in seconds.

23. Select **SAVE**.

24. For device-level ELRP interface options, select the specific interface check box and toggle **ELRP Enabled** to enable ELRP per port or toggle **ELRP Exclude** to exclude ELRP.

25. For **PSE**, select an existing profile or select the plus sign to add a new one.

See [Configure PSE](#) on page 302.

26. Review all the port settings in the **Summary** section and select **Save** when complete.

Configure Individual Ports

Use this task to configure or modify settings for individual ports.

1. In the switch template, select **Port/VLAN Configuration**.
2. For **Port Name & Usage** and **VLAN**, see [Configure Port Details](#) on page 297.
3. For **Instant Secure Port Settings**, see [Configure Authentication](#) on page 298.
- 4.
5. For **Transmission Settings**, see [Configure Transmission Settings](#) on page 299.
6. For **STP**, see [Configure STP Settings](#) on page 299.
7. For **Storm Control**, see [Configure Storm Control](#) on page 300.
8. For **PSE**, see [Configure PSE](#) on page 302.
9. Review the settings on the **Summary** tab, and then select **SAVE**

Configure Port Details

Create or modify a switch template, and then open it for configuration. See [Configure Individual Ports](#) on page 297.

The **PORT DETAILS** tab of the **Configure Ports Individually** table displays the following information:



- **Interface:** The interfaces available for the switch, such as Eth1/0/1-Eth1/0/52.
- **Port Type:** Indicates the current port usage setting.
- **Enabled:** Indicates whether the port is currently activated.
- **LACP:** Indicates link aggregation control protocol for a member of a link aggregation port group. See [Aggregate LAG and LACP Ports](#) on page 304.
- **VLAN:** This column displays the VLAN assigned to the port. Change the VLAN number directly in the VLAN text box.
- **Description:** A brief description of the port.





Tip

These settings appear in the **Info & VLAN** section of the **Summary** tab.

Use this task to configure the settings for a new port, on the **Port Name & Usage** and **VLAN** tabs.

1. Under **Configure Ports Individually**, select the the **Port Details** tab.
2. For the interface that you want to configure:
 - To edit an existing port, select .
 - To configure a new port, select .
3. Configure the settings on the **Port Name & Usage** tab:
 - a. Type a **Name** for the new port.
 - b. Type a **Description** for the new port.

Although optional, descriptions can be helpful when you are troubleshooting your network.

- c. Toggle the **Status** to **ON** or **OFF**.
4. Select the **Port Usage** setting:
 - **Access Port:** Ports connected to individual hosts such as printers, servers, and end-user computers.
 - **Phone with a data port:** Ports connected to IP phones, and optionally, to computers cabled to the phones.
 - **Trunk port:** Ports connected to network forwarding devices, such as switches and APs that support multiple VLANs on trunk ports.
5. Select **NEXT** to open the **VLAN** tab.
6. For **VLAN**, select  and choose an existing object, or to add a new one, select  to create a new VLAN object.
7. Select **NEXT**, or select the **User Authentication** or **QoS** tab, and continue configuring the port.
8. Select the **Instant Secure Port Settings** tab, and continue configuring the port.

Related Links

[Configure Individual Ports](#) on page 297

[Configure Authentication](#) on page 298

Configure Authentication

First configure the **Port Name & Usage** and **VLAN** tabs. See [Configure Port Details](#) on page 297.



Tip

These settings appear in the **Authorization** section of the **Summary** tab.

Use this task to configure the authentication settings for a new port, on the **Instant Secure Port Settings** tab.



Note

The **User Authentication** tab is part of the taskflow for older Dell and SR-based devices.

1. Toggle **User Authentication** to **ON** or **OFF**.
2. Toggle **MAC Authentication** to **ON** or **OFF**.
3. Select **NEXT**, or select the **Transmission Settings** tab, and continue configuring the port.

See [Configure Transmission Settings](#) on page 299.

Related Links

[Configure Port Details](#) on page 297

[Configure Transmission Settings](#) on page 299

Configure Transmission Settings

First, [Configure Authentication](#) on page 298.



Tip

These settings appear in the **Port Settings** section of the **Summary** tab.

Use this task to configure the settings for a new port, on the **Transmission Settings** tab.

1. For **Transmission Type**, select **Auto**, **Half-Duplex**, or **Full-Duplex**.

Auto causes the switch to negotiate the best possible duplex mode possible with the connected device. **Full-Duplex** forces the switch to communicate with the connected device using full-duplex communication. **Half-Duplex** forces the switch to use half-duplex communication.

2. Select the **Transmission Speed** the switch port uses to communicate with the connected device.
3. To display learned switch port client MAC addresses on ExtremeCloud IQ monitoring screens, select **Client Reporting**.

When client reporting is disabled, client MAC addresses are not displayed. It is disabled when **CDP Receive** is turned off.

4. To enable Cisco Discovery Protocol (CDP), select **Enable CDP Transmit/Receive**.
5. To enable the switch to transmit LLDPDU frames, select **LLDP Transmit**.
6. To enable the switch to receive LLDPDU frames, select **LLDP Receive**.
7. To enable Link Layer Discovery Protocol-Media Endpoint Discovery, select **Enable LLDP MED Capabilities**.
8. Select **NEXT**, or select the **STP** tab, and continue configuring the port.

See [Configure STP Settings](#) on page 299.

Related Links

[Configure Authentication](#) on page 298

[Configure STP Settings](#) on page 299

Configure STP Settings

First [Configure Transmission Settings](#) on page 299.



Note

Extreme Networks recommends that you enable STP.

Extreme Networks switches can use Spanning Tree Protocol (STP) to activate links with the lowest cost (highest bandwidth), establish backup links where possible, and prevent Layer 2 network loops, which can result in duplicate unicast frames and broadcast storms. Bridge Protocol Data Unit (BPDU) protection is a security feature designed to protect the active STP topology by preventing spoofed BPDU packets from entering the STP domain. BPDU protection is applied to edge ports connected to end-user devices that do not run STP. If an STP BPDU protected port receives packets, this feature disables that port and alerts the network admin.

The BPDU Restrict feature disables the port as soon as a BPDU is received on the BPDU restrict port, blocking the loop. Specify a BPDU recovery timeout, enabling the port after the configured amount of time.

**Note**

You can enable BPDU Restrict only when Edge port is also enabled.

By default, STP is disabled. Use this task to enable STP and configure the settings for an individual port, on the **STP** tab.

1. Toggle **STP ON**.
2. Toggle **Edge Port ON** so the port connects to a user terminal or server, instead of other switches or shared network segments.

A port configured as an edge port will not cause a loop upon network topology changes.

3. For **BPDU Protection**, select **Guard** or **Disabled** status.
 - **Guard**: Controls whether a port explicitly configured as Edge disables itself upon reception of a BPDU. The port enters the error-disabled state, and is removed from the active topology.
 - **Disabled**: Turns off BPDU Protection.
4. Select the port **Priority**.

If Spanning Tree Mode is set to STP, set the port priority to either 0 or 16.

5. Select **NEXT**, or select the **Storm Control** tab, and continue configuring the port.
See [Configure Storm Control](#) on page 300.

Related Links

[Configure Transmission Settings](#) on page 299

[Configure Storm Control](#) on page 300

Configure Storm Control

First [Configure STP Settings](#) on page 299.

Extreme Networks switches can mitigate traffic storms by tracking the source and type of frames to determine whether they are legitimately required. Switches then discard frames that are determined to be the products of a traffic storm. You can apply storm control to broadcast, unknown unicast, and multicast traffic, and configure packet-based or byte-based rate limit thresholds for each interface.

**Tip**

These settings appear in the **Storm Control** section of the **Summary** tab.

Use the following procedure to configure traffic storm mitigation for an individual port.

1. Select the traffic to include:
 - Select **Broadcast** to include traffic that is forwarded to all destinations simultaneously.
 - Select **Unknown Unicast** to include traffic with a destination address does not appear in the forwarding database.
 - Select **Multicast** to include traffic with a multicast address as a destination.
2. Type the **Rate Limit Value** for discarding traffic of the selected types.
3. Select **NEXT**, or select the **MAC Locking** tab, and continue configuring the port.
See [Configure MAC Locking](#) on page 301.

Related Links

[Configure STP Settings](#) on page 299

[Configure MAC Locking](#) on page 301

Configure MAC Locking

First, configure [Configure Storm Control](#) on page 300.

Configure MAC locking security to control the forwarding database for learned MAC address entries on a port. You must also enable MAC locking in the switch template.

Use this task to configure the settings for MAC locking.

1. Toggle **MAC Locking Enable** to **ON**, and configure the settings.

Table 90: MAC Locking settings

Setting	Description
Maximum First Arrival	Specify the number of first-arrival MAC addresses allowed to communicate on the port. Range (0-600)
Disable Port	To disable the port when the maximum first arrival limit is exceeded, toggle Disable Port to ON .
Link Down Action	Select one of the following options: <ul style="list-style-type: none">• Clear first arrival MACs when port link goes down• Retain first arrival MACs when port link goes down
Remove Aged MACs	To remove learned MAC Addresses after they age out from the switch forwarding database, toggle Remove Aged MACs to ON .

2. Select **NEXT**, or select the **ELRP** tab, and continue configuring the port.
See [Configure ELRP](#) on page 301.

Related Links

[Configure Storm Control](#) on page 300

[Configure ELRP](#) on page 301

Configure ELRP

First, [Configure MAC Locking](#) on page 301.

Extreme Loop Recovery Protocol (ELRP) is a loop protection mechanism designed to detect and prevent loops. In Extreme Platform ONE Networking you can configure ELRP client periodic packet transmission for VLAN(s) assigned to a port type. You must also enable ELRP in the switch template.

Use this task to enable and configure ELRP.

1. Toggle **Enable ELRP client and disable port when a loop is detected on applied access or trunk VLANs assigned to the port type** to **ON**.
2. To prevent the ELRP client port from being disabled, toggle **ELRP Exclude** to **ON**.
3. Select **NEXT**, or select the **PSE** tab, and continue configuring the port.

Related Links

[Configure MAC Locking](#) on page 301

[Configure PSE](#) on page 302

Configure PSE



Create or modify a switch template.



Tip

These settings appear in the **PSE Settings** section of the **Summary** tab.

Use this task to configure PSE settings, which define how ports manage the power that they supply to devices.

1. Select an existing PSE profile from the  menu, or select .
2. Type a **Name**.
3. For **Power Mode**, select **802.3af** or **802.3at**.
802.3af (PoE) can deliver 15.4 watts over Cat5 cables. **802.3at (PoE+)** can deliver up to 30 watts over Cat 5 cables with 25.5 watts available to devices.
4. For **Power Limit**, limit the available PoE power to a level lower than the maximum allowed by the power mode.
5. Select a **Priority** from the drop-down list:
Low: If the total powered device (PD) power consumption exceeds the PSE power budget, power output is modified to bring the total consumption back to within the PSE power budget.
High: When the total PD power consumption exceeds the PSE power budget, power output is modified only after ports with low priority PSE profiles are regulated.
Critical: When the total PD power consumption exceeds the PSE power budget, power output is shut down last.
6. (Optional) Type a description.
Although optional, descriptions can be helpful when you are troubleshooting your network.
7. Select **SAVE**.
8. Toggle **POE Status** to **ON** or **OFF**.

9. Select **NEXT**, or select the **Summary** tab, and review the settings for the port.
10. Select **SAVE**.

Related Links

[Create a New Port Type](#) on page 294

Configure Switch Device Template Advanced Settings

Create or edit a switch template.

ExtremeCloud IQ can update device firmware and reboot the device during onboarding.

1. Select the **Advanced Settings** tab.
2. For **Upgrade device firmware upon device authentication**, select **On** to upgrade the device firmware upon onboarding.
If you have activated device firmware upgrading, select one of two options:
 - Update firmware to the latest version.
 - Upgrade to a specific device firmware version.
3. To reboot and roll back a device to a previous configuration if there are issues with the template configuration, select **On** for **Upload Configuration Automatically**, followed by the check box below.
4. To use **Supplemental CLI**, select **On**.
For more information, see [Configure Supplemental CLI](#) on page 304.

Complete configuring the device template.

Configure Port Types

After you select ports in a new device template, you must assign a port type. For AP ports, select **Choose Existing** or **Create New**. For switch ports, select from **Choose Existing**, **Create New**, or **Advanced Actions > Aggregate**.



Note

Only Switch Engine and Extreme XOS support port types.

For 1- and 2-port APs, there are three port types:

- **Bridge-Access ports** connect to individual hosts. You can configure captive web portal access, MAC authentication via a RADIUS server, change the user profile, and configure traffic management.
- **Bridge-802.1Q ports** provide network access through forwarding devices and support multiple VLANs. You can change the default user profile and manage incoming traffic.
- **Uplink Ports** act as WAN uplinks. You can change the default user profile and configure traffic control settings.

For 24- and 48-port switch templates there are three port types:



- **Access Ports** are connected to individual hosts such as printers, servers, and end user computers. A VLAN ID tag is added to the frame before it is forwarded using the

802.1Q tagging protocol. You can enable User Authentication or MAC Authentication, and configure QoS settings, Client Detection and VLAN ID.

- **Phone Data Ports** are used for voice transmission.
- **Trunk Port frames that are not VLAN-aware.** Frames are in a native VLAN (default) or Management VLAN.

You can also configure ports at the device level. Port settings that you configure there override any settings you make in the network policy device template.

Use this task to configure port types as part of a network policy.

1. Select an existing device template, and then select , or to add a new one, select .
2. To assign an existing port type, select the port and then select **Assign**.
3. To create a new port type and assign it to a port at the same time, select an interface port, then select **Assign > Create New**.
4. Type a **Name** for the port type.
5. (Optional) Type a brief **Description** for the port type.
6. Turn the port off or on.
7. Select **Save**.

Related Links

[Assign an Ethernet Port Profile](#) on page 258

Aggregate LAG and LACP Ports

Create or modify a switch template.

You can group individual ports into aggregate ports on 24- and 48-port switches by selecting two or more ports of the same type on the switch template.



Note

You can change the LAG port type after a port has been assigned to a LAG, without having to delete and recreate the LAG.

1. Select the ports you want to aggregate, and then select **AGGREGATE PORTS**.
Alternatively, select **Assign > Advanced Actions > Aggregate**.
2. Toggle **LACP (Link Aggregation Control Protocol)** to **ON**.
If LACP (Link Aggregation Control Protocol) is disabled, Extreme Platform ONE Networking creates a static LAG.
3. Use the arrows to add or remove ports from the LAG.
4. Select the **Master Port**.
5. Select a **Port Load Balancing** option.



Configure Supplemental CLI

First, enable Supplemental CLI in ExtremeCloud IQ. Go to **Global Settings > VIQ Management**, and toggle **Supplemental CLI** to **ON**.

After you save supplemental CLI objects containing CLI commands, you can update the commands for devices automatically, each time you update the network policy.

To avoid an unnecessary system reboot, select **Delta Configuration Update**. Extreme Platform ONE Networking attempts to update only the configuration deltas. If a full update is required, the system prompts you to select **Complete Configuration Update**. Examples of CLI commands that require a full configuration update are: **system antenna-type** and **system environment**.

Use this task to configure supplemental CLI (sCLI) objects.

1. Select an existing Supplemental CLI object, and then select , or to add a new one, select .
2. Type a **Name**.
3. (Optional) Type an optional **Description**.
Although optional, descriptions can be helpful when you are troubleshooting your network.
4. Type or paste the **CLI commands** into the field.
 - Enter multiple CLI commands, one command per line, not exceeding a maximum total of 8192 characters.
 - Use CLI Commands that contain IP and VLAN objects: `${ip:ip_object_name}` and `${vlan:vlan_object_name}`.
 - Perform a complete configuration update each time commands are appended to device configurations.
 - For Dell EMC switches, enter the CLI commands, `enable`, and `config` in the beginning of a sequence of CLI commands.
5. Select **SAVE TEMPLATE**.

Related Links

[Configure AP Device Template Advanced Settings](#) on page 286

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure Classification Rules for a Device Template




Before you can add classification rules to a network policy, you must add a default AP device template and a location for the target AP. Also, create cloud config groups, IP addresses, and IP subnets.

You can create classification rules as part of a network policy or as a common object. Use this task to create classification rules associated with a network policy. Extreme Platform ONE Networking supports multiple classification rules for DNS servers, VLANs, RADIUS servers, device templates, user groups, and private client groups (PCGs).


- Configure **Device Location** rules to assign different DNS and RADIUS servers, and different time zones to different physical locations.
- Configure **Cloud Config Groups** (CCGs) to create user passwords which restrict access to private and personal network devices.
- Configure **IP Address** classification rules to associate user groups so they can communicate using their own private networks.

- Configure **IP Subnet** classification rules to support multiple user-group private networks.
- Configure **IP Range** classification rules for multiple user-group private networks.

This task is part of the network policy configuration workflow. Use this task to configure classification rules for a device template, as part of a network policy.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Configuration Settings** menu, select **AP Template**.
5. Select  and choose the desired default template.



Default templates apply to all of the devices of the selected template type that do not have a matching classification rule.

6. Select , and then select the desired device template.

Classification rules templates apply only to the devices of the selected template type that match the rules.

7. Type the new **Template Name**.
8. Select **SAVE TEMPLATE**.

The new template appears in the table, in the main AP template window. The **Classification Rules** column for the template contains the controls for configuring classification rules.

9. To assign an existing classification rule, in the **Classification Rules** column, select .
 - a. Select an existing classification rule.
 - b. Select **Link**.
10. To create and assign a new classification rule, in the **Classification Rules** column, select .
 - a. Type a **Name** for the rule.
 - b. Type a **Description**.

Although optional, entering a description is helpful for troubleshooting and for identifying the rule.










- c. Select , and then select the rule category to configure.
Choose from the following rule categories:

Table 91: Rule categories

Selected rule category	Do this
Device Location	<ol style="list-style-type: none"> Drill down until you reach the location level at which the device resides. Select Select. <p>The location appears in the Classification Rules table.</p>
Cloud Config Group	<ol style="list-style-type: none"> Select the Match Type. To use an existing group, select  and choose an existing object, or to add a new one, select . <p>For more information, see Add a Cloud Config Group on page 308.</p> <ol style="list-style-type: none"> Select CLOUD CONFIG GROUP. Select CONTINUE.
IP Address	<ol style="list-style-type: none"> From the Match Type menu, select Contains or Does Not Contain. To use an existing IP address, select  and choose an existing object, or to add a new one, select  menu. Select SAVE IP. Select CONTINUE.
IP Subnet	<ol style="list-style-type: none"> From the Match Type menu, select Contains or Does Not Contain. To use an existing IP subnet, select  and choose an existing object, or to add a new one, select . Select SAVE SUBNET. Select CONTINUE.
IP Range	<ol style="list-style-type: none"> From the Match Type menu, select Contains or Does Not Contain. To use an existing IP range, select  and choose an existing object, or to add a new one, select . Select SAVE IP. Select CONTINUE.

11. Use the up and down arrows in the **Order** column to define the order in which the location, cloud config group, IP address, IP subnet, and IP range objects appear.
- Extreme Platform ONE Networking uses a top-down, first-match, stop-on-match processing method for these objects. Therefore, if a device is a member of more than one matching object for an element, only the first match applies.
12. Select **SAVE RULE**.

Related Links

[Add a Cloud Config Group](#) on page 308

Add a Cloud Config Group

Before you begin, configure devices to associate with the cloud configuration groups.

Use cloud configuration groups to create network-level policies that can be replicated for multiple network roll-out scenarios. Use this task to create a new cloud config group as part of a network policy.

1. Type a **Name** for the new group.
2. (Optional) Type a **Description** for the new group.
3. Select real and simulated devices to have their host names shown in the **Selected Devices** field.



Note

You can also import a comma-separated-values (CSV) file including the host names, serial numbers, and optional MAC addresses of other devices.

- a. Select **Import**.
 - b. Select the CSV file, or drag the CSV file to the **Import Cloud Config Group Members** window.
 - c. Select **Submit**.
4. Select **SAVE CLOUD CONFIG GROUP**.

Related Links

[Configure Classification Rules for a Device Template](#) on page 305

[Configure the SSID for a Standard Wireless Network](#) on page 183

Fabric Attach

Fabric Attach is a software-based feature that automates the connection to the Fabric Connect environment, enabling devices and their associated end-points to be quickly mapped to the appropriate virtualized Fabric Connect service.

Provisioning a non-fabric AP to the Fabric Connect network is as easy as taking the Fabric Attach-enabled AP out of the box and physically connecting it to a Fabric Connect-enabled switch. The Fabric Attach device then automatically configures itself with the appropriate management VLAN, preparing itself for the dynamic extension of virtualized fabric services on behalf of its connected end-point devices or users. This can speed the deployment of edge devices to the Fabric Connect environment since no manual configuration is required, and can be especially valuable at locations where networking skills are at a premium, such as remote offices.

Extreme Platform ONE Networking APs support the following functions:

- Discover the Fabric Attach Server upon start up.
- Receive management VLAN configuration from the Fabric Attach Server, if discovered.
- Configure received management VLAN on the Management interface and Ethernet interface of the AP.

- Establish the management plane communication path to Extreme Platform ONE Networking.
- Support Native VLAN Tagging on the Management interface.

ExtremeCloud IQ APs do not support the following functions:

- Get VLAN to I-SID Mapping from Extreme Platform ONE Networking as a management command.
- Configure the Fabric Attach Server port with VLAN to I-SID mapping.
- Establish data plane communication path for every configured VLAN.

Related Links







[Configure Fabric Attach](#) on page 309

Configure Fabric Attach

Before you begin, physically connect the device to a Fabric Connect-enabled switch. To perform the following task, you require the device VLAN ID and I-SID number.

For more information about Fabric Attach, see [Fabric Attach](#) on page 308.

This task is part of the network policy configuration workflow. Use this task to configure Fabric Attach for a device connected to an existing Fabric Connect network.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. Select an existing **Device Template** to edit, or select .
5. Scroll down to the **Wired Interfaces** section.
6. To use an existing **Fabric Attach** profile,  and choose an existing object, or to add a new one, select .
7. Type a **Name** for the new profile.
8. (Optional) Type a description for the new profile.
Although optional, descriptions can be helpful when you are troubleshooting your network.
9. Select  to add a VLAN.
10. Type the associated **VLAN ID** for the device.
11. Select the **I-SID#** for the device from the drop down.
12. Select **SAVE**.

Related Links

[Fabric Attach](#) on page 308



[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure Device Data Collection and Monitoring Options

First, create a network policy.

This task is part of the network policy configuration workflow. Use this task to set the following data collection and monitoring options:

- **Application Visibility and Control (AVC):** AVC gives you information that can help you manage network traffic and applications. AVC detects the application-layer contents of the frame to determine the application or protocol that is transmitting the data. Extreme Platform ONE Networking can then track the amount of data being transmitted by a particular application or protocol.
- **Device Wireless Activity Thresholds:** Set activity threshold limits above which event alarms are generated.
- **Client Wireless Activity Thresholds:** These alarms identify when violations occur that affect the wireless health of a client as reported in SLA reports for non-compliant clients. To trigger more alarms, lower thresholds. To reduce the number of alarms, increase thresholds.
- **Kernel Diagnostic Data Recorder (KDDR):** KDDR logs capture run-time statistical data about unexpected events for Extreme Networks devices. Extreme Networks Support analyzes the content of these binary log files for troubleshooting.
- **Automatic Synthetic Traffic Generation:** Some of the Client 360°, Device 360°, and Network 360° monitoring capabilities require synthetic traffic generation.

1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **Device Data Collection And Monitoring**.
5. Toggle the **Application Visibility and Control** setting **ON** to detect frame application-layer contents.
6. Toggle the **Statistics Collection** setting **ON** to record wireless activity statistics between the device and connected clients.
7. To change the data collection interval, select the number of minutes from the menu.
8. For **Device Wireless Activity Thresholds**, type values for the following fields:
 - **CRC error rate exceeds:** The point at which the percent of CRC errors in received wireless frames during the collection interval is considered to be excessive.
 - **Tx drop rate exceeds:** The point at which the percent of transmitted wireless unicast frames that a device drops during the collection interval is considered excessive. A transmitted wireless frame is dropped when the device tries to transmit the same unicast frame a maximum number of times without receiving an acknowledgment from the intended recipient.
 - **Rx drop rate exceeds:** The point at which the percent of dropped wireless frames during collection interval is considered excessive. A device might drop wireless frames on its ingress Wi-Fi interface for several reasons, such as the arrival of duplicate frames or frames that cannot be decrypted.
 - **Tx retry rate exceeds:** The point at which the percent of retransmitted wireless frames during the collection interval is considered excessive. A device tries to

resend a unicast frame if the first effort does not elicit an acknowledgment from its intended recipient.

- **Airtime Consumption exceeds:** The point at which the percent of transmitted and received airtime usage for a wireless interface during the collection interval exceeds the maximum airtime consumption threshold.

9. For **Client Wireless Activity Thresholds**, type values for the following fields:

Tx drop rate exceeds: Indicates the point at which the percent of wireless unicast frames that a device drops during transmission to the same client during the statistics collection interval is considered excessive.

Rx drop rate exceeds: Indicates the point at which the percent of dropped wireless frames received from the same client during the statistics collection interval is considered excessive.

Tx retry rate exceeds: Indicates the point at which the percent of retransmitted wireless frames to the same client during the collection interval is considered excessive.

Airtime Consumption exceeds: Indicates the point at which the percent of airtime that a device consumes while transmitting traffic to and receiving traffic from the same client during the collection interval is considered excessive.

10. Toggle the **Kernel Diagnostic Data Recorder** setting **ON** to capture run-time statistical data about unexpected events.

11. For **Automatic Synthetic Traffic Generation**:

- Enable **RADIUS Authentication** to create synthetic traffic.
- Toggle the **Check Radius service connectivity via Status-Server** setting **ON** to check RADIUS service connectivity.

Ensure that **Status-Server** is enabled on the RADIUS server.

- Adjust the check **Interval** if necessary.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure the BLE Service

First, configure a network policy.

Consider the following:

- The BLE Service settings configured in this task apply to the Device template associated with the network policy. You can override the settings configured here, and also configure device-level settings, by going to **Manage > Devices > Configure > Interface Settings > Wireless Interfaces > BLE Service**.
- IoT Thread profile configuration automatically takes precedence over BLE configuration. If BLE is configured and deployed, and later IoT Thread is configured and deployed, BLE becomes disabled and IoT Thread is enabled. If BLE configuration exists but has yet to be deployed, and then later IoT configuration is done and deployed, only the IoT configuration is pushed to the AP.

You can configure the embedded BLE transmitter in APs. As transmitters, these beacons broadcast numerical advertisements that trigger an action on Bluetooth-enabled devices that come within range. For example, an app running on a mobile device might react to a BLE signal by displaying welcome messages, sale announcements, or coupons.

This task is part of the network policy configuration workflow. Use this task to configure the iBeacon service for a network policy.



1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **BLE Service**.
5. Toggle the **BLE Services** setting **ON**.
6. Type a **Service Name**.
7. (Optional) Type a **Description**.
Although optional, entering a description is helpful for troubleshooting and identification.
8. For **BLE Scan**, select **iBeacon** or **Generic** or both, and then configure the **Destination** settings.

Table 92: Destination settings

Setting		Description
Cloud Reporting (iBeacon scan only)		Toggle ON to enable Cloud Reporting for the device. Deselect to disable Cloud Reporting for the device. Cloud Reporting provides real-time analytics and insights into the performance and usage of your BLE network. Use this feature to monitor key metrics, track user interactions, and optimize BLE for maximum efficiency.
	Interval	Specify an interval value between 10-1200 seconds to determine how often iBeacon transmits to Extreme Platform ONE Networking. The default value is 60 seconds.
Batch Reporting (Required for Generic BLE scan)		Toggle ON to submit iBeacon reports in batch files. Batch Reporting compiles and analyzes large sets of iBeacon interaction data at scheduled intervals. This feature is ideal for generating periodic reports and gaining insights into long-term trends and patterns.
	Interval	Specify an interval value between 10-60 seconds to determine how often iBeacon transmits batch file reports. The default is 10 seconds.
	URL	Type the destination URL to submit batch file reports.
Ignore Duplicates		Enable this feature to remove duplicate entries automatically, within the specified time interval.
Secure Connection		Toggle ON and specify the credentials to secure the data flow to your server.
Token renewal setting		

Table 92: Destination settings (continued)

Setting		Description
	Client ID	Specify the unique identifier assigned to the client application. (String, 10-255 characters)
	Client Secret	Specify the confidential key used to authenticate the client. (String, 10-255 characters)
	Show Password	Select the check box to show the password (Client Secret).
	Token URL	Specify the API URL where the client sends requests to obtain or refresh access tokens. (String, valid URL format, max 255 characters)

9. Configure the **iBeacon Filter** settings (iBeacon Filter only).

Table 93: iBeacon Filter settings

Setting		Description
	Min RSS(dBm)	The minimum Received Signal Strength (RSS) value used for filtering iBeacon signals. RSS is measured in dBm (decibels relative to 1 milliwatt).
	UUID	The iBeacon unique identifier. If your organization already has a UUID number, type it in the iBeacon UUID field. UUID format: 32 hexadecimal (base 16) digits, displayed in five groups separated by hyphens, in the form 8-4-4-4-12 for a total of 36 characters (32 alphanumeric and four hyphens). For example: 123e4567-e89b-12d3-a456-426655440000 You can also automatically create a UUID with an online UUID generator, such as the one at https://www.uuidgenerator.net/ .

10. Configure the **Generic Filter** settings (Generic Filter only).

Table 94: Generic Filter settings

Setting		Description
	Min RSS(dBm)	The minimum Received Signal Strength (RSS) value used for filtering generic signals. RSS is measured in dBm (decibels relative to 1 milliwatt).
	Vendor	Select Any , CHORUS , or Custom .
	Any	Select Any to capture all generic BLEs.
	Chorus	Select Chorus to auto-populate the settings for this vendor, and then select ADD .
	Custom	Select Custom , type the Name and Company Id of the vendor, and then select ADD . You can specify an ID for up to five vendors.

11. Select **Save**.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure Presence Analytics

First, configure a network policy.





Note

It is not necessary to change the default values if devices are connected over faster links.

Adjust these settings to accommodate situations where devices are connected over slower links and where the data must be aggregated at different rates.

This task is part of the network policy configuration workflow. Use this task to specify how frequently APs send data to Extreme Platform ONE Networking.



1. Go to **Configuration > Network**.
2. Select an existing policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **Presence Analytics**.
5. Toggle the **Enable Presence Analytics** setting **ON**.
6. Type a **Name**.
7. (Optional) Type a **Description**.
Although optional, entering a description is helpful for troubleshooting and for identification.
8. For **Trap Interval**, specify (in seconds) how often the presence sensor reports data to ExtremeCloud IQ.
Lowering this interval below 15 seconds pushes data faster but also increases network traffic. Raising this interval above 15 seconds pushes data at a slower rate and decreases network traffic.
9. Specify the **Aging Time** (in seconds) for a given presence profile.
10. Specify the **Aggregate Time** interval (in seconds) for the set period during which aggregation occurs for the presence profile.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure WIPS

This task is part of the network policy configuration workflow. Use this task to enable and configure the Extreme Networks Wireless Intrusion Prevention System (WIPS), as part of a wireless network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **WIPS**.
5. Toggle **WIPS** to **ON**, and configure the settings.

For more information, see [WIPS Policy Settings](#) on page 315.

To reuse WIPS settings, select  and choose a WIPS policy object.

6. Select **SAVE**.

Related Links

[WIPS Policy Settings](#) on page 315

[Configure the SSID for a Standard Wireless Network](#) on page 183

WIPS Policy Settings

Table 95: Settings for WIPS policy



Setting	Description
Name	Type a Name for the new policy.
Description	(Optional) Type a Description . Although optional, descriptions can be helpful when you are troubleshooting your network.
AirDefense Essentials	Toggle AirDefense Essentials to OFF to disable it, and then select Save . By default, AirDefense Essentials is ON (enabled). To Allow change of operating channel for air-termination , select the check box.
Rogue Access Point Detection	
Rogue Access Point Detection (Legacy)	Toggle Rogue Access Point Detection (Legacy) ON to enable the feature.
Determine if detected rogue APs are connected to your wired (backhaul) network	Use Determine if detected rogue APs are connected to your wired (backhaul) network in combination with other WIPS techniques to determine if a detected rogue AP is in the same network as compliant APs. An Extreme Networks AP builds a MAC learning table from source MAC addresses in the broadcast traffic it receives from devices in its Layer 2 broadcast domain. When an AP running XOS 5.0r2 or later detects a rogue AP through any of the rogue detection mechanisms in the WIPS policy, it checks the MAC learning table for an entry within a 64-address range above or below the BSSID of the invalid SSID. If there is a match, it assumes that both MAC addresses belong to the same device. Because one of its addresses is in the MAC learning table, the rogue is considered to be in the same backhaul network as the detecting AP, and In Net displays in the In Network column for that rogue in the list of rogue APs.
Detect rogue access points based on their MAC OUI	Select the check box to enable detection of rogue APs based on MAC OUI.
Select MAC OUIs of wireless devices that are permitted in the WLAN	Create an allow list of wireless devices allowed on the WLAN, according to MAC OUI. To use an existing MAC OUI, select  and choose an existing object, or to add a new one, select  . Select ADD .

Table 95: Settings for WIPS policy (continued)


Setting	Description
Detect rogue access points based on hosted SSIDs and encryption type	<p>Select the check box to enable detection of rogue APs based on hosted SSIDs and the encryption type. Select , and then choose one of the following:</p> <p>For example, if you have a network security policy that requires all SSIDs to use Enterprise 802.1x, any valid SSID using Enterprise 802.1x makes the access point hosting it valid. An access point is categorized as a rogue if it hosts an SSID using WEP or no encryption at all.</p> <ul style="list-style-type: none"> • Select an SSID—Select the SSID from the menu. • Enter an SSID Name—Type the SSID name. <p>Select Check the type of encryption used by this SSID, and then select the type of encryption from the list. Otherwise, clear the check box.</p> <p>Select ADD.</p>
Detect if wireless clients have formed an ad hoc network to identify rogue clients	<p>Toggle Detect if wireless clients have formed an ad hoc network to identify rogue clients ON to enable the feature.</p> <p>Select Enable rogue client reporting and type the number of seconds, after which disconnected rogue APs drop from the reports.</p>
Rogue Mitigation	
Mitigation Mode	<p>Select one of the following:</p> <ul style="list-style-type: none"> • Manual: Manually mitigate rogue APs and their clients. In manual mode, you must periodically check for rogue APs and their clients on the heat map pages in your network hierarchy. <p>Note: Use caution when mitigating a suspected rogue AP. If your WLAN is within range of other neighboring wireless networks, the access point that might initially be considered a rogue AP, along with its clients, might be valid in another WLAN.</p> <ul style="list-style-type: none"> • Automatic: APs automatically mitigate rogue APs and their clients, starting and stopping the mitigation process without any administrator involvement. <p>Note: Use only the automatic mode for rogue APs that are in-network (in the backhaul network of your organization). Otherwise, automatic mitigation can impact the normal operation of valid APs belonging to a nearby business by blocking their wireless clients from connecting to their APs. Reference the appropriate FCC regulations that prohibit Wi-Fi blocking in these cases.</p>

Table 95: Settings for WIPS policy (continued)

Setting	Description
Detect and Mitigate rogue clients every	<p>After you enable rogue detection on an AP, it scans detected rogue APs for clients during the period that you specify. If you manually start mitigation against a rogue, the AP not only continues scanning for clients during this period, it also sends deauthentication frames to the rogue AP and to any detected clients during the same period.</p> <p>For example, if you leave this at the default setting of 1 second, the AP checks for rogues and attacks them every second. Each time an AP checks if there are clients associated with a detected rogue, it must switch channels for about 80 milliseconds (unless it happens to be using the same channel as the rogue).</p> <p>To minimize channel switching, choose an AP that is on the same channel as the rogue to perform the mitigation. The Rogue AP list shows which channel the rogue is using. If none of the APs are using the same channel, choose the one with the fewest clients. Finally, if all the APs are busy and on different channels from the rogue, consider reducing the amount of channel switching by increasing the period so that the associated client check occurs less frequently. You can change the duration from 1 to 600 seconds (10 minutes).</p>
Repeat mitigation for detected rogue clients	<p>Specify how many consecutive periods to spend attacking a rogue AP and its clients before allowing client inactivity to stop and commence a countdown to end the mitigation. If you use the default settings for both the length of the mitigation period and the consecutive number of periods, an attack lasts for 60 seconds before stopping because of client inactivity. The range is from 0 to 2,592,000 seconds (30 days). A value of 0 means that mitigatory APs send deauthentication frames for the entire amount of time that a mitigation effort is in effect.</p>
Limit mitigation efforts per rogue AP to	<p>The maximum length of time that an attack against a rogue AP can last. If the length of client inactivity does not cause the attack to be suspended or if you do not manually stop the attack, the AP stops it after this time limit elapses. The default duration is 14,400 seconds (4 hours), which means that an AP continues checking for clients of a detected rogue for up to four hours and mitigates them if it finds them. The mitigation might stop sooner if the period of client inactivity lasts long enough to stop it. You can change the maximum time limit between 0 and 2,592,000 seconds (30 days).</p> <p>In cases where the response time to detect a rogue AP would be greater than the default duration of four hours, consider increasing the duration to enable more time to locate the AP before ending the mitigation process. A value of 0 means that the client detection and mitigation continues indefinitely, unless the client inactivity period elapses.</p>

Table 95: Settings for WIPS policy (continued)

Setting	Description
Stop mitigation if no client activity is detected in	Set the period of time to stop the mitigation process if the AP no longer detects that clients are associated with the rogue AP. During this time, the AP stops sending DoS attacks but continues checking if any clients form new associations with the targeted AP. If the AP detects any associated clients before this period elapses, it sends a deauthentication flood attack and resets the counter. If there are no more clients associated with the AP after this period, the AP stops the mitigation process even if there is still time remaining in the maximum time limit.
Max number of mitigator APs per rogue AP	(Applies only to automatic mode.) For automatic mitigation, hive members choose one AP to be the arbitrator, which is the one to which all the detector APs send reports. The arbitrator AP also determines which detector APs perform mitigation. When they start, they become mitigatory APs. Set the number of mitigatory APs that the arbitrator AP can automatically assign to attack a rogue AP and its clients. If you set the maximum as 0, all the detector APs can be assigned to perform rogue mitigation.

Related Links

[Configure WIPS](#) on page 314

Configure a Location Server

This task is part of the network policy configuration workflow. Use this task to enable and configure a location server as part of a network policy.




1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **Location Server**.
5. Toggle **Location Server** to **ON**, and configure the settings, or select  and choose an existing location server.

Table 96: Location server settings

Setting	Description
Name	(Required) Type a Name for the location server.
Description	Type a Description for the location server. Although optional, descriptions can be helpful when you are troubleshooting your network.

Table 96: Location server settings (continued)






Setting	Description
Client Location Tracking	Toggle the setting ON to enable tracking. Enable this setting to track the location of currently associated client, rogue APs, and devices carrying RFID (radio frequency identification) tags.
Track Client Location Using	Choose one of the options: <ul style="list-style-type: none"> • Extreme Networks Location Server • AeroScout Location Server • Tazmen Sniffer Protocol (Ekahau, etc...)

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Install CA Certificates

This task is part of the network policy configuration workflow. Use this task to install CA certificates as part of a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Application Management** menu, select **Certificates**.
5. Toggle **Install CA Certificates** to **ON**.
6. Select , and then choose a WIPS policy object from the  menu.
If the menu is empty, or does not contain the entry that you want, select  to open the **Certificate Management** page.

Related Links

[Configure the SSID for a Standard Wireless Network](#) on page 183

Configure a Layer 2 IPsec VPN Service

Layer 2 IPsec VPN is a logical extension of the Layer 2 broadcast domain across an IPsec VPN tunnel. After configuration, it is available for use in multiple network policies.

**Note**

A Layer 2 VPN server on an AP can terminate a maximum of 128 tunnels. A Layer 2 VPN Gateway Virtual Appliance can terminate up to 1024 tunnels.





Because the NAT mechanism on the device involves both the source IP address and source port number, wireless clients can only send TCP or UDP traffic. Note that the clients will be unable to ping local servers because ICMP does not use port numbers.

When a wireless client associates with a device, the device applies a user profile to traffic from that client. If the device is a VPN client with a user profile tunnel policy, the device tunnels that traffic back to a VPN server at the primary site. The clients receive

network settings from a DHCP server at the primary site, query DNS servers at the primary site for domain name resolution, and access other network servers through the tunnel to any site in the VPN network.

Layer 2 IPsec VPNs tunnel traffic between APs functioning as VPN clients at remote sites and a VPN Gateway Virtual Appliance or Extreme Networks APs functioning as VPN servers at the corporate site, providing Layer 2 extensions of the main network. You can define at least one VPN server or two for redundancy. Each VPN client must belong to the same management network as the VPN server and build a GRE (Generic Routing Encapsulation) tunnel between the client and server. DHCP traffic is also tunneled, so clients receive IP addresses from the DHCP server at the corporate site just as if they were on the primary network.

This task is part of the network policy configuration workflow. Use this task to configure a new Layer 2 IPsec VPN service as part of a network policy.

1. Go to **Configuration > Network**.
2. Select an existing network policy, and then select , or to add a new one, select .
3. After you save the **Policy Details**, select **NEXT** or **2 Wireless**.
4. From the **Network Services** menu, select **Layer2 IPsec VPN Services**.
5. Toggle **Layer 2 IPsec VPN Service** to **ON**.
6. To use an existing service, select  and choose an existing object, or to add a new one, select .
7. Configure the [Layer 2 VPN Services Settings](#) on page 320.

Related Links

[Layer 2 VPN Services Settings](#) on page 320


[Configure the SSID for a Standard Wireless Network](#) on page 183

Layer 2 VPN Services Settings

Table 97: Settings for Layer 2 VPN services


Setting	Description
Name	Type a name for the service.
Description	(Optional) Type a description. Although optional, descriptions can be helpful when you are troubleshooting your network.
Device VPN Server and Device VPN Client Settings	
Single Device VPN Server	Select Single Device VPN Server if you are not implementing redundant VPN servers.
Redundant Device VPN Servers	Select Redundant Device VPN Servers to configure a redundant VPN server. Configure the settings for Device VPN Server 1 and Device VPN Server 2 .
Device VPN Server	Select an AP with Layer 2 IPsec VPN services enabled.

Table 97: Settings for Layer 2 VPN services (continued)

Setting	Description
Server Public IP Address	<p>Auto-populated based on the selected VPN server settings. To change this setting, type the IP address of a VPN server that VPN clients can reach across the network.</p> <p>Note: If the VPN server is behind a NAT device, enter the address of the MIP address on the NAT device. If there is no NAT device in front of the VPN server, enter the mgt0 IP address of the server.</p>
Server MGT0 IP Address	Auto-populated and read-only.
Server MGT0 Default Gateway	Auto-populated and read-only.
Client Tunnel IP Address Pool Start	<p>Type the first IP address of the range of addresses that the VPN server assigns to tunnel interfaces on VPN clients during the Xauth phase of tunnel setup. As a best practice, put this address pool in the same subnet as the VPN server mgt0 interface, and the same subnet as the addresses that the DHCP server assigns to wireless clients through the tunnel. If the tunnel interfaces are in a different subnet, you must define a route the VPN server default gateway router uses to forward traffic destined for the tunnel interface, and traffic destined for the wireless clients to the VPN server mgt0 interface.</p>
Client Tunnel IP Address Pool End	Type the IP address at the end of the range of IP addresses in the address pool.
Client Tunnel IP Address Pool Netmask	Type the netmask that defines the subnet to which the tunnel interfaces belong.
Device VPN Client DNS Server	<p>Select the DNS server IP address or host name object that VPN clients use to resolve domain names, or select  to define a new one.</p>
User Profiles for Traffic Management ExtremeCloud IQ displays a list of available user profiles, for which traffic can be forwarded through the Layer 2 IPsec VPN tunnel or forwarded without tunneling.	
VPN Tunnel Mode	In the VPN Tunnel Mode column, select Enable to enable VPN clients to tunnel traffic for specific user profiles.
Tunnel All Traffic	To tunnel all client traffic, select Tunnel All Traffic .
Split Tunnel	To enable split mode tunneling, select Split Tunnel .

Related Links

[Configure a Layer 2 IPsec VPN Service](#) on page 319



Subscriptions & Services

[Subscriptions Terminology](#) on page 323

[Subscriptions](#) on page 323

[Subscription Management](#) on page 331

[General License Management](#) on page 336

[Contracts](#) on page 339

[Inventory](#) on page 343

Managing your network devices and network topologies with Extreme Platform ONE Networking is accomplished with applications. Licenses are required for the specialized applications that manage devices and network topologies, such as buildings and sites.

A *subscription* has a start and end date and gives you access to Extreme Platform ONE Networking application products. A subscription entitles you to an explicit allotment of Extreme Networks licenses for one or more applications to manage the devices, buildings, and outdoor sites in your network. Trial license periods are available to help you decide whether an application addresses your needs, within specific parameters. Such parameters might include dual subscriptions, but trial licenses are granted depending on your license and your eligibility.

It is important to understand the following information about the relationship of contracts, subscriptions, and licenses in Extreme Platform ONE Networking:

Contract

A contract is all-encompassing and can include multiple subscriptions and licenses.

Subscription

A subscription defines an explicit number of software-application licenses that enable robust features for managing and viewing devices.

- Licenses associated with the subscription are assigned to devices.
- Some features may require an entire building, outdoor site, or fabric to be covered by Platform ONE licenses only.

License

Licenses—defined and numbered according to subscription terms—are consumed by allocating them to devices within buildings or outdoor sites. Licenses unlock features specific to the application under license. Unlicensed devices are inventory-

only. Some management features specific to the subscribed application cannot be unlocked until one of the following occurs:

- You [request a trial subscription](#) or [purchase additional licenses](#) for your current subscription.
- You [reassign](#) existing licenses from other buildings or site to devices in a building or site where you want to implement full license features.

Subscriptions Terminology

The following table describes terms commonly used throughout this document.

Table 98: Terminology

Term	Description
Activate	Setting up new or active services for a user. You can activate or deactivate a service as part of your subscription.
License	Refers to how many individual seats you buy for each subscription. For example, you might have four subscriptions (bought at different times) that cover 5,000 licenses.
Purchase	Buy the product or service offered in the trial. For more information about purchasing products or services, contact an official Extreme Networks Partner.
Renew	Extend an existing contract.
Revoke	Return an activated license to the pool of available licenses.
Subscription	A specific type of purchase decision that entitles you to use Extreme Networks services to manage the products and licenses in your network or networks.

Subscriptions

You can manage subscriptions, licenses, and trials from the **Subscriptions** interface. The status of each license in your license pool is quickly identifiable, and you can search and use grouping and other filter criteria to view specific licenses and more detail about a license.



Note

The terms **License** and **Entitlements** appear throughout the Extreme Platform ONE Networking interface. These terms are interchangeable. For clarity, this document uses license, licenses, and licensing in all cases, unless the term **Entitlement** is part of a product name or label in the user interface.

Go to the Subscriptions Page

The **Subscriptions** page provides access to all subscription-related functions. You can access the **Subscriptions** page using a supported web browser. The interface pages vary, depending on the mode selected and your logged-in user role.

Use this task to go to the **Subscriptions** page.

1. Go to **Subscriptions & Services > Subscriptions & Licensing**.
2. On the **Subscriptions** page, select the **Global** tab.

Related Links

[Link Your Extreme Portal Account to Extreme Platform ONE Networking](#) on page 325

[Subscriptions & Licensing User Interface Descriptions](#) on page 326

[Examples of Subscriptions & Licensing Detail](#) on page 328

Subscription Activation and Account Linking

You can use Extreme Platform ONE Networking subscriptions for the following products:

- Extreme Platform ONE Networking
- ExtremeCloud IQ Controller
- ExtremeCloud IQ
- ExtremeCloud IQ Site Engine

Extreme Platform ONE Networking, ExtremeCloud IQ, ExtremeCloud IQ Controller, and ExtremeCloud IQ Site Engine.

You must link your account to use the Extreme Platform ONE Networking licenses that you purchased.



Note

For activation instructions specific to ExtremeCloud IQ Site Engine, see the [activation instructions for this product](#). For additional information for all Extreme Platform ONE Networking applications, see these [activation Instructions](#).

Your Extreme Portal account linking is only performed once. You can link your Extreme Portal account either in Extreme Platform ONE Networking or ExtremeCloud IQ. If either is already linked, new licenses are automatically available for both applications.

If you do not see your new licenses, you can request on-demand synchronization from either of the two following applications:

- In Extreme Platform ONE Networking:

See [Synchronize Subscriptions](#) on page 335 and follow the procedure steps.

- In ExtremeCloud IQ (New):

In ExtremeCloud IQ, hover over your profile name in the upper-right corner, and then select **Global Settings > Administration > License Management**, and click **Synchronize**.

Link Your Extreme Portal Account to Extreme Platform ONE Networking

When you log in to Extreme Platform ONE Networking, select **Link the Portal Account** at the prompt, type your Extreme Portal credentials, and then select **Link Extreme Portal Account**.

Use this task to link your Extreme Platform ONE Networking to the Extreme Portal from the **Subscriptions & Licensing** page.

1. Go to **Subscriptions & Services > Subscriptions & Licensing**.
2. Select the **Global** tab.
3. Select **Link Extreme Portal Account** and type your Extreme Portal credentials.



Note

If you are a partner or a distributor and are setting up an Extreme Portal account for a customer, type your Extreme Portal credentials when you link the customer account and the Customer Unique Identifier (CUID). The CUID is included in the customer Welcome Letter.

Subscriptions & Licensing User Interface Descriptions

Figure 17 shows the elements and features available in the Subscriptions interface. See Table 99 for descriptions of the numbered elements.

Figure 17: Subscriptions & Licensing interface, unfiltered




Table 99: Subscriptions & Licensing interface descriptions

Callout	Interface Area	Description
1	Navigation menu	Expand or collapse the Extreme Platform ONE Networking Navigation menu to provide access to all features of the interface or hide the navigation menu to view more data (image view is collapsed).
2	Page title	Name of your page location within Subscriptions & Services
3	Global tab	Display all license pools for all applications when unfiltered
4	Search field	Search all columns in the current data set (not case-sensitive) to filter for specific records, such as License Descriptions, License Type, or Status.
5	Subscriptions & licensing application tabs	Display subscription and licensing detail for each licensed application. The license pool status is indicated by the color dot on the tab, and line-item status is indicated by the same color scheme.
6	CUID	The unique ID associated with the license pool. The CUID is very important when communicating with support personnel.

Table 99: Subscriptions & Licensing interface descriptions (continued)

Callout	Interface Area	Description
7	Extreme Portal Link status	Indicates whether Extreme Platform ONE Networking is linked to your Portal account. The account must be linked to see content of the license pool
8	Link / Unlink	Toggle the link status between Extreme Platform ONE Networking and your Extreme Portal account. Caution: Use Unlink only for troubleshooting when directed by Support personnel.
9	'Group by' filter	Filter by None or Product
10	Synchronize Subscriptions	Synchronize all your Extreme Platform ONE Networking subscriptions
11	Download button	Download table data
12	3-dot menu	Displays action options: <ul style="list-style-type: none"> Request History Request button initiates the License Request process.
13	Refresh button	Refresh data for a current snapshot of table data
14	License counts groups	Shows total licenses, number active, and number still available columns for that license pool; numbers fluctuate as licenses are applied or removed from a device or devices. <ul style="list-style-type: none"> Total = sum of all licenses available to use today = sum all of the same license type with start date in the past and end date in the future = exclude expired and not yet valid Active = sum of all licenses the customer is using today Available = Total minus Active
15	Columns option	Customize the columns that you see on the page.
16	Filter	Filter the table by Entitlement (license), Application, or Status.
17	Pagination tools	Customize the number of results to show on one page.

Search, Group, and Filter

You can search for an item and organize lists in the **Subscriptions & Licensing** user interface.

You can group records based on the pre-defined criteria that vary for different windows.

Use the **Previous** (<) and **Next** (>) icons to scroll through the results lists.

**Note**

Search terms are not case-sensitive.


1. To search for records, start typing a search attribute such as product, license or license type, status, or a complete or phrase or words from a description in the **Search** field.
To clear the search, select **X** in the **Search** field.
2. To group records in a page, select **Group By** and choose an option.
The list is organized by the grouping option you selected. Some headings are collapsible, based on the chose option.
3. To filter records in a page, select **Filter** (▼) and choose the filter attribute.
To clear an individual filter, click **X** for the appropriate filter. To clear all the filters, select **Clear All Filters**.
The list is organized by the filtering attribute you selected.

Examples of Subscriptions & Licensing Detail

Information about licenses and license pools is immediately visible in the **Subscriptions & Licensing** interface, as shown in the following figures. Detail includes license or entitlement, product name, number of days until the license expires, status, and license total, active, and available licenses. Status for each subscription license is indicated by color:

- Green: no problems
- Amber: attention needed, for example:
 - One or more licenses expire in fewer than 60 days and the renewal is not yet in progress
 - Trial is in progress
- Red: immediate attention required, indicating but not limited to the following conditions:
 - The grace period is active
 - One or more licenses expire in fewer than 30 days and the renewal is not yet in progress


Status color indicates license expiration date: early warning (amber), critical upcoming expiration or already expired licenses (red).



The screenshot shows a dashboard with a sidebar on the left containing navigation links: Assets, Sites, Subscriptions & Services (selected), Subscriptions & Licensing, Contracts, Administration & Settings, Users & Roles, Alert Rules, Notifications, Single Sign On, and Audit Logs. The main area displays a table of subscriptions. The table has columns: Description, Entitlement, Product, Status, and Total. The status column uses colored icons to indicate expiration status: amber for early warning and red for critical/upcoming expiration. The table lists various subscriptions, including ExtremeCloud IQ Pilot SaaS, SD-WAN Enterprise XaaS, and ExtremeCloud IQ CoPilot SaaS. The bottom of the table shows pagination: Page Size: 20, 1 to 20 of 22, Page 1 of 2.

Description	Entitlement	Product	Status	Total
ExtremeCloud IQ Pilot SaaS Subscription	XIQ-PIL-S-C	Wired & Wireless	15 Devices Expire in 45 Days	200
SD-WAN Enterprise XaaS for Small Datacenter up to 250Mbps	XSW-DC-S-S	SD-WAN	Subscriptions Expire in 351 Days	200
ExtremeCloud IQ CoPilot SaaS Subscription	XIQ-COPILOT-S-C	Wired & Wireless	15 Devices Expire in 14 Days	200
SD-WAN Enterprise XaaS for Medium Branch up to 750Mbps	XSW-BR-M-S	SD-WAN	Subscriptions Expire in 351 Days	200
SD-WAN Enterprise XaaS for Medium Datacenter up to 250Mbps	XSW-DC-M-S	SD-WAN	Subscriptions Expire in 351 Days	200
SD-WAN Enterprise XaaS for Large DCLR 10GE up to 10Gbps High-Availability	XSW-DC-LR-HA-L-S	SD-WAN	Subscriptions Expire in 351 Days	200
SD-WAN Enterprise XaaS for Large DCLR 10GE up to 10Gbps	XSW-DC-LR-L-S	SD-WAN	Subscriptions Expire in 351 Days	200
SD-WAN Enterprise XaaS for Small Branch up to 500Mbps	XSW-BR-S-S	SD-WAN	Subscriptions Expire in 351 Days	200
Extreme Intuitive Insights for 10 IoT Devices	XII-IOT-S	Intuitive Insights	Subscriptions Expire in 351 Days	2000

The following figure shows detail about an early warning (amber) for upcoming license expiration.



The screenshot shows a modal titled "Subscription Details" for the "ExtremeCloud IQ Pilot SaaS Subscription" (XIQ-PIL-S-C). The modal displays a status indicator (amber) and a message "15 Devices Expire in 45 Days". Below this, there are three summary boxes: Total (200), Active (15), and Available (185). The modal also contains a table with columns: Contract Number, Status, Total, Start Date & Time, End Date & Time, and Notes (Optional). The table lists two contracts, both with a status of "Expiring in 45 Days".

Contract Number	Status	Total	Start Date & Time	End Date & Time	Notes (Optional)
5-01655943	Expiring in 45 Days	100	2024-07-23 18:00:00	2025-03-31 17:59:59	
5-01673526	Expiring in 45 Days	100	2024-07-23 18:00:00	2025-03-31 17:59:59	

Figure 18: Subscription detail, soon-to-expire status

In the next figure, the urgent status-symbol color (red) indicates an expired legacy entitlement or very soon-to-expire licenses. You can view details for each subscription.

In a similar figure, detail for an soon-to-expire or expired legacy entitlement is visible, indicated by the urgent status-indicator color (red). You can view details for each subscription.




Figure 19: Subscription detail, expired or imminent expiring status

Trial Subscriptions

If you do not have a valid subscription for one or more Extreme Platform ONE Networking applications, you can request a free trial subscription for 90 days. You must be an admin to request a trial from within Extreme Platform ONE.



Note
A trial subscription is a one-time only option, meaning you can request it only once. Only Extreme Platform ONE Networking (Wired & Wireless) , ExtremeCloud SD-WAN, and Universal ZTNA are supported as of this release.

Users with the following Extreme Platform ONE Networking roles and other product or application roles can request a trial subscription:



Note
A trial Subscription Request is not available for an MSP environment.

Extreme Platform ONE Networking

- Administrator
- BizOps

ExtremeCloud IQ (New)

- Administrator - excludes Workspace, Pilot features, and Universal ZTNA
- NetSecOps - excludes Workspace, Pilot features, and Universal ZTNA

ExtremeCloud IQ (Classic)

- Administrator

- Operator

ExtremeCloud SD-WAN

- Administrator

Extreme Intuitive Insights

- Administrator

The request trial must meet the following criteria to be valid:

- The account is linked to Extreme Portal.
- The request is initiated from the **Subscriptions & Licensing** page.
- An active subscription does not exist for the selected product.
- A previous trial was not granted.
- An expired subscription does not exist for the selected product.

After you request a trial subscription, it is either approved or rejected. If your request is rejected, you are notified and the next step is to contact the Sales team. In addition to not meeting the preceding criteria, a request can be rejected for the following reasons:

- Sanctioned country
- Sanctioned company
- Sanctioned individual
- Trial already expired

Related Links

[Request a Trial Subscription](#) on page 334

Subscription Management

You can view and manage subscriptions in the **Subscriptions & Licensing** interface.

What to Expect When Licenses Are Upgraded

When a subscription is upgraded from Extreme Platform ONE Networking, some features Extreme Platform ONE Networking may not be available. Depending on the mix of Pilot and licenses that you upgrade from Pilot to Extreme Platform ONE, visibility and management features for a building, outdoor site, or fabric are limited.

Some features in Extreme Platform ONE are mutually exclusive with use of ExtremeCloud IQ Pilot licenses. Areas where Pilot licenses are assigned may be limited in visibility and management features for a building, outdoor site, or fabric. [Comparison of features per license mode](#) lists features that are or are not available with combinations of Pilot and Extreme Platform ONE licenses.



Note

Buildings and sites with limited Extreme Platform ONE features are identified by the icon color in. Full-feature status icons are purple. Limited-feature status is indicated with a blue background.

Depending on your available license quantity, you can [unlock full features](#) to remove the limitation for the building, outdoor site or whole fabric.

Table 100: Comparison of features per license mode

Feature	New XIQ (Pilot-only)	Platform ONE mixed (Pilot & EP1-STD)	Platform ONE Standard (EP1-STD only)
Subscriptions All	No	Yes	Yes
Visualization – Physical layer	No	*	Yes
Visualization – Fabric layer	No	*	Yes
Visualization – Service layer	No	*	Yes
Visualization – Split view	No	*	Yes
Contracts	No	Yes	Yes
Inventory	No	Yes	Yes
Custom Roles	No	Yes	Yes
AI Expert	No	Yes	Yes
Agentic workflows	No	Yes	Yes
AI Expert actions	No	*	Yes
Fabric Configuration	No	*	Yes

Unlocking Full Features

If you have both ExtremeCloud IQ Pilot and Extreme Platform ONE Standard Networking licenses, you may encounter license conflicts (for more information, see [What to Expect When Licenses Are Upgraded](#) on page 331). You can unlock Platform ONE Standard Networking full features from the **Inventory**, **Sites**, and **Visualize** menus for one building, outdoor site, or multiple buildings, outdoor sites, or the whole fabric.

- [Purchase a Subscription or Add Additional Licenses](#) on page 334. Use this option to purchase a new subscription or to add more licenses to an existing subscription. (For more information, see [Should I Add a Subscription or Request a Trial License?](#) on page 333).
- [Reassign Licenses | Inventory](#) on page 333. Use this option when you want to use existing licenses from another site, building, or fabric to unlock full features in a different building.
- [Request a Trial Subscription](#) on page 334. Use this option to trial an application that you have not purchased or trialed previously or if you are a new customer, with the same caveats. (For more information, see [Should I Add a Subscription or Request a Trial License?](#) on page 333).

Related Links

[Reassign Licenses | Visualize](#) on page 74

Reassign Licenses | Inventory

To reassign licenses, you must have write access to **Inventory**, and you must have sufficient Extreme Platform ONE Networking licenses.

**Important**

This process is non-reversible.

Use this procedure to reassign Extreme Platform ONE Standard Networking licenses to a building or an outdoor site.

1. Go to **Subscriptions & Services > Inventory**.
2. Select all sites or filter sites.

If one or more associated devices use ExtremeCloud IQ Pilot licenses, Extreme Platform ONE Networking displays a widget that shows the number of buildings and the number of devices using Pilot licenses.

3. Use the widget to drill down to the devices for the filtered sites, and then select **Unlock Full Features**.

**Note**

If one or more devices are Fabric Engine, to allow the reassignment, you must select all buildings with Fabric Engine.

4. Select **Unlock**.

Related Links

[Unlocking Full Features](#) on page 332

Should I Add a Subscription or Request a Trial License?

Whether you should add a subscription or request a trial license is an administrative and business decision, but consider the following information as you make the decision.

- You can request a trial license only if you meet the following criteria:
 - You are a new Extreme Platform ONE Standard Networking customer.
 - You are an existing Extreme Platform ONE Standard Networking customer who has never purchased or requested a trial license for the application you are considering.

**Note**

If you requested and were granted a trial license in the past but never used it, you are disqualified from a new trial.

- You can add licenses incrementally to an existing subscription rather than purchase a larger number at one time. For more information, you can [contact sales](#) or complete the workflow steps to [add a subscription](#) and submit the form from within Extreme Platform ONE Standard Networking.

Request a Trial Subscription

Use this task to initiate a request for a 90-day trial subscription.

1. Go to **Subscriptions & Services > Subscriptions & Licensing**
2. On the **Subscriptions & Licensing** page, select **Start Trial**.



Note

On first request, a **Request Process** diagram shows. You can select Do not show this message again

- (Optional) Select **Do not show this message again**.
 - Select **OK**.
- a. Select the checkbox to Accept Terms and Conditions and acknowledge the policy.
 - b. Select the check box to agree to share contact information.
 - c. Select **Accept and Continue**.
3. In **Select Request**, select **Subscriptions**, and then select **Next**.
 4. Select the application that you want to trial, and select **Add** adding each one to the cart.
Each application that you add shows in the cart.
 5. When you finish adding applications to the cart, select **Next**.
 6. Type your phone number and fill out any optional information, then select **Next**.
 7. Review your request, and then select **Next** to download the request document.
 8. Submit the request document to your Extreme Networks partner or contact Sales to submit the request.

In standard situations the trial licenses appear in less than 10 minutes.

If the license does not appear in two business days, contact the Sales account team.

If the trial subscription request is rejected, contact the Sales team.



Note

Depending on the application and regulatory requirements, the trial license is available after a few minutes or up to five working days after verification. You are notified of request status through email and in the product license-request Extreme Platform ONE Networking pop-up.

Purchase a Subscription or Add Additional Licenses

Contact your Extreme Networks partner to purchase an Extreme Platform ONE Standard Networking subscription or add additional licenses to your current subscription. You can add additional licenses to your subscription as you need them or incrementally for budgetary reasons.

For more information, you can [contact sales](#) or complete the workflow to [create a subscription request](#) and print the form from within Extreme Platform ONE Networking to submit to your Extreme Networks partner.

Create a Subscription Request

Use this task to define, download, and send to your Extreme Networks partner for subscriptions you want to purchase.

You can initiate a subscription request from multiple Extreme Platform ONE Networking entry points.

1. Select an entry point to begin the request process.
 - Go to **Subscriptions & Services > Subscriptions & Licensing > Subscriptions**, and then select **Request**.
 - Go to **Subscriptions & Services > Contracts**, and then select **Subscription Request**.
 - From within **Inventory**, **Sites**, or **Visualize** area, follow the instructions to [unlock full features](#).

2. Read and choose **OK** on **Request Process**, select either **Subscription** or **Contract** to specify your request type, and then select **Next**.

3. In the **Select Subscriptions** area, select one or more applications and then select **Add**.

Each selection is added to the **Selected Subscriptions** pane, where you can select and make changes to **Duration** and **Quantity** for trial in the respective fields for each requested application.

4. Select **Next** and complete the optional information additional information as desired in the **Send a copy to**, **Preferred Partner**, and **Additional Comments** sections.
 - a. In **General information**, type your phone number, complete additional optional information as desired, and then select **Next**.
 - b. Review request details in **Review Request**, and then select **Next**.
 - c. Download the subscription request summary document, print or digitize it, and submit the request using one of the following methods.
 - Contact your Extreme Platform ONE Networking Preferred Partner and ask for the offer.
 - Use the [Partner Locator](#) to find and connect with a Preferred Partner and follow their submission instructions.

Synchronize Subscriptions

Subscription synchronization typically is automated and scheduled by the system, but you can initiate on-demand synchronization.

Synchronize Subscriptions to request out-of-the-schedule (on-demand) synchronization information. Subscriptions can be synchronized only once every 5 minutes.



Important

Do not use **Synchronize Subscription** just to refresh the information in Extreme Platform ONE Networking

Use this task if you do not see your new licenses.

1. Go to **Subscriptions & Licensing**.
2. Select **Synchronize Subscriptions**.

A 5-minute timer begins. After the timer expires, you can synchronize your subscriptions again.

General License Management

You can manage various aspects of licenses in the **Subscriptions & Licensing** interface, including but not limited to requesting more licenses for devices and NAC allocations.



Note

License counts for a pool fluctuate when license usage changes for a product, when a contract or a subscription expires, or when a new subscription order is processed.

View License Pool

A *license pool* is a set of licenses that are available to you. Licenses can have different start dates, end dates, and quantities. You can activate (assign) licenses in the pool when needed and return licenses to the Available pool when you remove them and they are not currently assigned (Active). You can view license expiration status; license type, term start and end date; and the number of licenses total, active, and available. The license counts from the applications appear on the **Subscriptions** page and in the subscription details when you select an individual subscription.



Note

When a license violation state is detected, devices are unmanaged automatically, the **Device License** type value changes to **Not Licensed**, and the lock is released

1. Go to **Subscriptions & Services** and select the desired application tab on the **Subscriptions & Licensing** page.

All licenses in the pool are available for you to view and page through, if you select the **Global** tab.

2. (Optional) Use the [search, group, and filter options](#) to refine the result set and view for a specific license pool or for multiple pools.

You can view details in the columns.

3. For more information, you can select a line item and view details about the selected subscription or license.

Related Links

[Pagination](#) on page 22

View Device State and Subscription Type



Note

When a license violation state is detected, devices are unmanaged automatically, the Subscription value changes to **Not Licensed**, and the lock is released

Table 101: State and Subscription Types

State	Subscription Type
Managed	Legacy (Legacy Entitlement Key)
Managed	Pilot
Managed	Standard Tier A
Managed	Standard Tier B
Managed	Standard Tier C
Managed	Standard Tier D

Use this task to view device details, including state and subscription type.

1. To view device and state subscription details, go to **Subscriptions & Services** and select **Inventory**.
2. (Optional) To view the most rows possible, select **Show Summary** to toggle closed the **Firmware Status** and **Hardware Lifecycle** summaries.
3. View device details, using [search, group, and filter options](#) options to refine your result set.

State and subscription type information is listed in the respective columns.

Related Links

[Manage Inventory](#) on page 344

Manage NAC Allocations

You can allocate NAC licenses to devices across a license pool according to your needs.



Note


ExtremeCloud IQ Site Engine must be onboarded before you can manage NAC allocations.

1. Go to **Subscriptions & Licensing** and select **Global**.
You can use the [search, group, and filter](#) functionality to find the subscription.



Note

The menu selection in this procedure does not appear unless you have one or more NAC subscriptions.

2. At the top right corner of the page, select , and then select **Manage NAC Allocations**.

3. In the **NAC Entitlements Allocation** window, specify the allocation percentage of the license pool to assign to which entity.
4. Select **Save Allocations**.

Activate a License

The following actions activate a license.

- Add a device as managed.
- Enable a licensed application. You may need to apply the license for some licenses (for example, MacSec).



Note

Use of some AI Expert agents activates AI Credits.

The following actions revoke a license.

- Unmanage or delete a device.
- Disable a licensed feature. You may need to revoke the license manually for some licenses (for example, MacSec) before you delete the device.



Note

Activated AI Credits are automatically revoked monthly.

Pre-provisioning and License Assignment

Extreme Platform ONE Networking does not assign a license to a device until the device connects to the cloud for the first time. Therefore, you can pre-provision new devices before decommissioning the old ones, even if you do not have enough licenses to cover all the devices. The following example explains how the process works.

Example

AP-A represents the old devices, and AP-B represents the new devices.

AP-A is operational, the **State** is **Managed**, and the device uses a license.

AP-B is not connected to the Internet.

1. Add the serial number for AP-B to Extreme Platform ONE Networking.
2. Assign policy and configure AP-B.

AP-B does not use a license, and the **State** is **New**.

3. In Extreme Platform ONE Networking, **Unmanage** AP-A.

AP-A is operational and provides service. Because the State is **Unmanaged**, Extreme Platform ONE Networking reports the device as **Disconnected**. The system does not collect statistics for the device, and you cannot change the configuration.

AP-A no longer uses a license.

4. Connect AP-B to the Internet.

The AP-B **State** changes from **New** to **Managed**, and AP-B uses a license.

View Subscription History


You can view the history for all your subscription and license purchases or trials and trial requests. Use this task to view that history.

1. Go to **Subscriptions & Services**, select , and then select **Request History**.

The **Subscriptions & Licensing / Request History** page lists all subscriptions and requests.

2. (Optional) Use the [search](#) box to refine the result set and view for a specific subset of subscriptions.

You can view details in the columns.

3. (Optional) To download summary information for a subscription or a subscription request, select , and then select **Download**.

To complete the download, save the file when prompted.

Renew a Subscription

Your Extreme Networks partner sends you a renewal quote. You can respond to that quote by renewing a subscription.



Note

Subscription renewal and license renewal are independent actions. Many licenses can be associated with one subscription, but renewing a license isn't linked to renewing the associated subscription.

Use this task to renew a subscription.

1. Send a completed purchase order to your Extreme Networks partner.
2. When the purchase order is processed, subscriptions are added to the license pool for your CUID.

Related Links

[Synchronize Subscriptions](#) on page 335

Contracts

You can view details for each contract in the Contracts interface, and you can renew a contract to avoid services disruption. Detail for each contract includes the following details:

- Contract number
- Start and end dates
- Partner
- Contract status
- Number of line items for the contract
- Site location where the contract is in use.

Go to the Contracts Page

The **Contracts** page provides access to information about individual contracts. You can access the **Contracts** page using the two most recent versions of Google Chrome web browser.

Use this task to go to the **Contracts** page.

1. In a web browser, open Extreme Platform ONE Networking with the fully qualified domain name (FQDN) and log on.
2. Go to **Subscriptions & Services > Contracts**.

Related Links

[Contracts User Interface Descriptions](#) on page 340

Contracts User Interface Descriptions

The **Contracts** page displays your contract details. [Table 102](#) on page 340, describes the elements on this page.


A [color dot on the tab](#) indicates the contract status:

- Green—license in good standing
- Amber—needs attention
- Red—canceled

Table 102: Contracts user interface descriptions

Interface area	Description
Navigation menu	Toggle to expand or collapse the Extreme Platform ONE Networking Navigation Pane to provide access to all features of the interface or hide the navigation menu to view more data (image view is collapsed).
Page title	Name of your page within Subscriptions.
Search field	Provides the ability to search all columns in the current data set (not case-sensitive) to filter for specific records.
Subscription Request	Opens the Subscriptions Request page, where you can initiate a request for one or more subscriptions.
Columns-shown choices (customizable)	Toggle to expand or collapse the column display choices (image view is expanded) where you can choose the columns that you want to show on the page.

Table 102: Contracts user interface descriptions (continued)

Interface area	Description
View/Renew Service Contract	Selecting  for the corresponding row expands a menu with choices to View Service Contract or Renew Service Contract .
Resource Center	Toggle expands and collapses the Resource Center menu: <ul style="list-style-type: none"> • Product Tours • Share Your Feedback • User Guide • Release Notes • Legal Summary

View Contract Information

The **Contracts** page provides information about each Extreme Platform ONE Networking contract, including details such as start and end date and contract status.

Use this task to view contract information.

1. Go to **Subscriptions & Services > Contracts**.
2. (Optional) To customize the columns view, use the following features:
 - a. Select **Columns** on the right page border to view available columns.
 - b. Select or clear check boxes to choose those columns you want to show.
 - c. Click and drag a column heading in the table to rearrange the order of the columns.

Quick-Filter Contracts by a Pending Expiration Interval

The quick-filtering options that delimit the result set in **Contracts** show above the contract columns.

Use this task to filter contracts by a pending expiration interval.

1. Go to **Subscriptions & Services > Contracts**
2. (Optional) Select **Clear All Filters** if previous filtering results persist.
3. Select an interval from the row above column table headings in **Contracts**.

You can view the filtered result set in the table columns. You can select a different interval filter to see other result sets.


Filter Contracts by Specified Date Range

You can filter contracts according to specific end dates. (To filter contracts by expiration date intervals or 30, 60, or 90 days, see [Quick-Filter Contracts by a Pending Expiration Interval](#) on page 341.)

Filter criteria include the following options:

- **Before or After** (choice 1 for the specified date or dates)
- **Date** in mm/dd/yyyy format
- **AND/OR** (Boolean choices)
- **Before or After** (choice 2 for the specified date or dates)

Use this task to filter contracts by a range of dates.

1. Go to **Subscriptions & Services > Contracts**.
2. (Optional) Select **Clear All Filters** if previous filtering results persist.
3. On the **Start Date** column heading, select .
 - a. In the dialog, specify your filter criteria.
 - b. Type the date in the correct format.
 - c. Select **Apply**.Your filtered results show in the **Contracts** area.
4. To redefine your criteria, select **Reset** to clear the previous criteria, and then repeat step 3.

Filter Contracts by Multiple Criteria

You can filter contracts by multiple options that help you narrow the result set criteria. (Alternatively, to filter contracts to see a list of contracts within a specified start and end date, see [Filter Contracts by Specified Date Range](#) on page 341.)

Filter criteria include the following options:

- Search box
- End Date
 - None
 - Expires in 30 days
 - Expires in 60 days
 - Expires in 90 days
- Partner
- Status
- Site

Use this task to filter contracts with multiple refining criteria options.

1. Go to **Subscriptions & Services > Contracts**.
2. (Optional) Select **Clear All Filters** if previous filtering results persist.
3. Select the **Filters** sidebar.
4. In the **Filters** pane, specify your filter criteria, and then select **Apply**.
Your results display in the **Contracts** area.
5. To redefine your criteria, select **Reset** to clear the previous criteria, and then repeat [step 4](#).

Renew a Contract

You can renew existing contracts from within Extreme Platform ONE Networking to ensure access to services without interruption. Use this task to renew a contract.

1. (Optional). Review your contracts and predetermine those that you want to renew.
2. Go to **Subscriptions & Services > Subscriptions & Licensing**
3. On the **Subscriptions & Licensing** page, select **Request**.
4. In **Select Request**, select **Contracts**, and then select **Next**.
5. Select the contracts that you want to renew and select **Add** to move them to the cart.
Each contract that you add shows in the cart.
6. When you finish adding contracts to the cart, select **Next**.
7. Type your phone number and fill out any optional information, then select **Next**.
8. Review your request, and then select **Next** to download the renewal document.
9. Submit the document to your Extreme Networks partner or contact Sales to submit the request.

Contact Sales

You can contact sales for information about contracts, subscriptions, and licenses, and for other needs you might have.

1. Go to **Subscriptions & Services > Contracts** and select **Contact Sales** to open the [Contact the Extreme Sales Team](#) web page.
2. Fill out and submit the form to receive a call from the sales team or alternatively, select another contact option from the **Other Ways to Get in Touch** section of the page.

Inventory

An asset is a physical device that you want to track. It could be a critical device essential for operations or an expensive item to replace if lost.

Use the **Inventory** view to locate a tracked asset within your site. This feature can raise alarms if the tracked asset is moved out of or into a restricted area or missing from the site over the configured threshold.



Note

Access to **Inventory** actions is role-based.

Assets are categorized by the following tabs:

- All
- Wireless
- Switches
- Routers
- Appliances

- SD-WAN
- Other Devices




Figure 20: Inventory

The **Firmware Status** widget on the **Inventory** page displays the device firmware status. To upgrade device firmware, see [Upgrade Device Firmware](#) on page 347.

The **Hardware Lifecycle** widget on the **Inventory** page displays the total number of devices, severities such as End of Sale, End of Software Maintenance, and End of Service Life. You can select a severity to filter the data.

The **Feature Limitations** widget lists the buildings/outdoor sites and devices. There is also a link to unlock full features.

Use the **Sites** filter to see all sites or only a select few.

A sample XLSX file template is available at [\[link\]](#) for download to create device definition files for bulk onboarding devices.

Manage Inventory

To view the list of managed assets, select **Inventory**.



Note

To view taken from **Inventory**, go to **Administration & Settings > Logs** and select **Audit Logs**.

The **All** tab is the default view for Inventory. The following information is available for managed assets:


Table 103: Inventory options

Field	Description
Status	Asset status: <ul style="list-style-type: none"> • Connected • Disconnected
State	Current device admin state: New, Managed, and Unmanaged.
Site	Location where device is managed


Table 103: Inventory options (continued)

Field	Description
Firmware	Operating System version
Managed By	Cloud or local device management information
Hostname	Hostname for the asset
MAC	MAC address
Service Contract	Service Contracts provide contract number and expiry date of a contract. A contract that has expired in the past 6 months is indicated by a warning symbol.
Model	Device model information: <ul style="list-style-type: none"> • Device End-of-Sale (EOS) • End-of-Service-Life (EOSL) • End-of-Software-Maintenance (EOSM) Hover over the device model name for more details if the date has passed the current date. A color is assigned to each device state - EOS (White), EOSL (Red), and EOSM (Orange). A warning symbol indicates a device that expired in the past six months.
Slot Unit Number	Slot unit number for the device.
Subscription	Subscription license type for the device.
Feature License	Feature license identifier.
Serial Number	Device serial number
MGT IP Address	Management IP address of the device.
Date Shipped	Date the device was shipped.
Date Available	Device availability date.
Country (Wireless devices only)	Licensing domain code for the device. Displays the country name.

Sort and Filter

To sort and filter the Assets list, select the field names. Alternatively you can select **Filters**  on the content pane on the right.

Columns

To configure the Assets list column display, select the **Columns**  icon and select or clear the columns for display.

Search

To search the Assets list by MAC address, Hostname, and Subscription type, use the **Search** field.

Download

To download the current Assets tab data in .XSLX format, select **Download** .

Onboard Devices

Devices can be onboarded to the inventory using one of the following methods:

- **Manual:** Manually add up to 10 serial numbers from the same platform family.
- **Bulk:** Bulk onboard multiple devices using a CSV file that contains device serial numbers.




Note

If you do not assign a device to a site when you onboard it, Extreme Platform ONE Networking assigns the device to the Default site. This assignment is visible in **Assets**, and you can reassign the device to another site.

Use this task to onboard devices to your inventory.

1. Select **Onboard**.
2. Configure the applicable Onboard Device Settings.

Table 104: Onboard Device Settings

Field	Description
Manual	
Cloud or Locally	Select option.
Device OS	Select a device type.
License Level	Select the license level.
Network Policy (Optional)	Assign the device to an existing network policy.
Location (Optional)	Assign the device to an existing location.
Select Next .	
Serial No.	Enter a device serial number. Select  to add additional serial numbers. You can add up to 10 serial numbers from the same platform family.
Select Next .	
Generate a Formatted Hostname	Enable the toggle.
Bulk	
Network Policy (Optional)	Assign the device to an existing network policy.
Location (Optional)	Assign the device to an existing location.
Upload File	Select Browse Files or drag and drop a CSV file containing device serial numbers. Note: Supports .xlsx files only.

3. Select **Onboard**.

Upgrade Device Firmware

Use this task to manually upgrade firmware for selected devices within Inventory.



Note

Select **History** to view **Firmware Upgrade History**.


1. Select **Update Firmware**.
2. Select a **Device Type** and **Device Management**.



Note

You can filter the device list by using the **Search** field to quickly locate specific devices.

3. Select the devices for firmware update, and then select **Next**.
4. Select a **Firmware Version** for each device, and then select **Next**.
5. Confirm the **Review Summary**, and then select a **Firmware Update Schedule**:
 - To update immediately, select **Update Now**, and then select **Update Firmware**.



Administration & Settings

[Access Management](#) on page 348

[Alert Policies](#) on page 364

[External Notifications](#) on page 365

[Backup & Restore](#) on page 366

[Integrations](#) on page 368

[Logs](#) on page 369

Use the **Administrations & Settings** menu to access the following sub-menu items:

- **Users & Roles:** Add external or internal users to your account.
- **Alert Rules:** Setup alert policies, custom metrics, triggers, severity levels and thresholds. Receive alerts for device, security, performance and operational activities.
- **Notifications:** Receive color-coded notification and alerts from all your applications.
- **Single Sign-On:** Set up single sign-on.
- **Audit Logs:** Record and show activities and violations such as administrative activities, data access and modification information, user denials, login failures, and system changes.

Access Management

Access Management enables administrators to add users, configure single sign-on for users, or integrate role-based access (RBAC) groups that you configure in an identity provider (IdP). From here you can:

- Create new users: Add new internal or external user accounts and assign roles to manage their access.
- Role-based access: Implement and assign RBAC groups and assign them to sites.
- Single Sign-On (SSO): Allow users to log in with SSO using credentials from an existing SAML-enabled identity provider (IdP).

Role-Based Access

Access to Extreme Platform ONE Networking features is governed by user roles. Depending on the assigned role, access to and visibility of some features may be

limited regarding features such as dashboard widgets, Extreme AI Expert, and the Navigation menu.

**Note**

Extreme Platform ONE Networking user roles cannot be configured in ExtremeCloud IQ (Classic).

Use the following descriptions to determine role assignments.

Administrator

Best for users who need the following:

- Full system-configuration access
- User and access-management capabilities
- Integration and backup management
- Complete administrative control

As an Administrator, I have insight into the following Workspace widgets:

- Alerts
- Licenses
- Inventory Status
- Site Health

NetSecOps

Ideal for users who need the following:

- Network device management
- Security policy configuration
- Monitoring and alerting capabilities
- Operational control without user management

As a user with the NetSecOps role, I have insight into the following Workspace widgets:

- Alerts (can manage alert policies and acknowledge permissions)
 - Severity
 - Category
 - Top 3 Alerts
 - Application
- Licenses
- Inventory Status
- Site Health

Observer

Appropriate for users who need the following:

- Read-only access to monitoring data
- Dashboard and visualization viewing
- No configuration or administrative access

As an Observer, I have insight into the following Workspace widgets:

- Alerts (no alert policies, no acknowledge permissions)
 - Severity
 - Category
 - Top 3 Alerts
 - Application
- Site Health

BizOps

Designed for users who need the following:

- Business-focused access to inventory and contracts
- AI Canvas and Agent access for business insights
- Limited operational visibility

Subscription and licensing management

As an administrator, I have insight into the following Workspace widgets:

- Licenses
- Inventory Status
- Site Health

Related Links

[Security-Specific Roles and Features | Extreme Platform ONE Networking](#) on page 352

[Role-Based Feature Access | Extreme Platform ONE Networking](#) on page 352

Role-Mapping Between Extreme Platform ONE Networking and Other Applications

[Table 105](#) and [Table 106](#) on page 351 show the mapping between Extreme Platform ONE Networking roles to those in other applications.

Table 105: Role-Mapping Between Extreme Platform ONE Networking and Other Applications

Extreme Platform ONE Networking	ExtremeCloud IQ (Classic)	ExtremeCloud IQ (New)	Extreme Intuitive Insights	ExtremeCloud SD-WAN
Administrator	Administrator	Administrator	Administrator	Administrator
NetSecOps	Operator	NetSecOps	NA	Operator

Table 105: Role-Mapping Between Extreme Platform ONE Networking and Other Applications (continued)

Extreme Platform ONE Networking	ExtremeCloud IQ (Classic)	ExtremeCloud IQ (New)	Extreme Intuitive Insights	ExtremeCloud SD-WAN
BizOps	Observer	Observer	NA	Observer
Observer	Monitor Help Desk Guest Management Application Operator Installer	Observer	NA	NA

**Note**

The following roles work better in ExtremeCloud IQ (Classic), and do not provide the same experience in Extreme Platform ONE Networking:

- Monitor
- Help Desk
- Guest Management
- Application Operator
- Installer

Table 106: Role-Mapping Between Extreme Platform ONE Networking and Other Applications

Extreme Platform ONE Networking	ExtremeCloud SD-WAN	Universal ZTNA*
Administrator	Administrator	Administrator
NetSecOps	Operator	Monitor
BizOps	NA	NA
Observer	Observer	Observer

**Note**

As part of the Extreme Platform ONE rollout, Universal ZTNA is now accessible under the label **Extreme Platform ONE Security** in both ExtremeCloud IQ and Extreme Platform ONE. The nine-dot menu label has changed accordingly. Once you have selected this option, the Universal ZTNA experience remains unchanged and delivers the same capabilities as expected.

Security-Specific Roles and Features | Extreme Platform ONE Networking

Extreme Platform ONE Networking security includes the following additional capabilities not available in networking-only deployments.

- Onboarding: Administrator and NetSecOps roles have full access. Observer and BizOps roles have no access.
- Troubleshooting: Administrator and NetSecOps roles have full access. Observer and BizOps roles have no access.
- Policy Management: Includes Security Policies, Users & Devices, Conditions, Network Services, and Applications
- Security Services: Administrator role has full access. NetSecOps role has read access only.

*Role-Based Feature Access | Extreme Platform ONE Networking***Table 107: Role-based feature access**

Feature	Administrator	NetSecOps	Observer	BizOps
Workspace (Extreme Platform ONE Networking only)	R/W	R/W	Read-only	Read-only
Monitoring				
Dashboard	R/W	R/W	Read-only	Read-only
Visualize	R/W	R/W	Read-only	No access
Alerts	R/W	R/W	Read-only	No access
Network Devices	R/W	R/W	Read-only	No access
Clients	R/W	R/W	Read-only	No access
Configuration				
Sites	R/W	R/W	No access	No access
Network	R/W	R/W	No access	No access
Subscriptions & Services				
Inventory (Extreme Platform ONE Networking only)	R/W	R/W	No access	Read-only
Subscriptions & Licensing	R/W	Read-only	No access	Read-only
Contracts	R/W	Read-only	No access	No access
Administration & Settings				
Access Management	R/W	No access	No access	No access

Table 107: Role-based feature access (continued)

Feature	Administrator	NetSecOps	Observer	BizOps
Alert Policies	R/W	R/W	No access	No access
External Notifications	R/W	R/W	No access	No access
Backup & Restore	R/W	R/W	No access	No access
Integrations	R/W	No access	No access	No access
Logs	R/W	R/W	No access	No access
Extreme AI (Extreme Platform ONE Networking only)				
AI Expert	R/W	R/W	Read-only	Read-only
AI Canvas	R/W	R/W	Read-only	Read-only

Users & Roles

You can add multiple users and roles of the following types to Extreme Platform ONE Networking. You can also implement single-sign-on via SAML-based identity providers.



Note

Roles for all applications can be assigned only in Extreme Platform ONE Networking. You cannot create or assign roles or custom roles that were previously assigned in individual applications.

- Internal users
- External users
- [Single Sign-On](#)

Related Links

[Role-Mapping Between Extreme Platform ONE Networking and Other Applications](#) on page 350

[Role-Based Access](#) on page 28

Create a New User

User access is controlled by the roles you assign. Use this task to add a new internal or external user account and assign roles to manage their site access.



Note

When user creation is complete, an email is sent instructing the user to create a password and then log in to Extreme Platform ONE Networking. If the user has logged in after a certain time elapses, user status remains **Inactive** and you have the option to resend the email. That option appears as a selection choice when you [edit, disable, or delete](#) a user account.

1. Go to **Administration & Settings > Access Management**.

2. In the **Users & Roles** area, select one of the following account-types:

- **Internal Users:** Select this tab to grant access to users within your organization.
- **External Users:** Select this tab to grant access to users outside of your organization; for example, resellers, distributors, technical support, and sales.



Caution

Depending on role assigned to an External User, that user may have full access or restricted access to all features and assets in Extreme Platform ONE Networking or ExtremeCloud IQ (New). Be cautious and evaluate role-based access options before assigning access to an External User. Provide access to the minimum necessary resources (the Principle of Least Privilege). You can add additional capabilities with other role options if needed.

Internal Users

- Select **Create New User**.
- Type the email address for the user and select **Next**.
- Configure the following settings.

Field	Description
Email	Email address, not more than 128 characters.
First Name	First name, not more than 63 characters.
Last Name	Last name, not more than 63 characters.
Primary Role	Specify access to Extreme Platform ONE Networking, ExtremeCloud IQ (New), and if applicable Security, SD-WAN, and other Platform ONE applications. The primary role is the platform role that is common across all accessible applications.
Classic Role	Specify access to ExtremeCloud IQ (Classic). Note: Options are limited by Primary Role selection for application access.
Sites	Specify access to sites. Administrators have access to all sites and locations if a site hierarchy is created. Note: It is imperative that you assign users to a site or sites.
Idle Session Timeout	Specify whether to enforce idle session timeout. If you do not specify a time, the user session will not timeout. Note: A non-expired timeout configuration overrides any admin-configured timeout. Otherwise, all admin-configured user timeout settings follow those that the admin configured.

- d. Type the first name and last name of the user in the Select **Create New User** and type the email address for that user.
- e. Configure roles for **Application Access** and **Classic Role**, respectively, for the internal user, selecting role from the menu for each role.
- f. Select **Save**.
- g. You can review the access and roles assigned to the new user by selecting **Internal Users** in the **Users & Roles** area.

External Users

- a. Select **Create New User**.
- b. Type the external email address and select **Next**.
- c. Configure the user's Application Access. Select the user role value for the Primary Role and the Classic Role.
- d. **Configure site access** from the role-specific menu choices.
- e. (Optional) Select the access duration:
 - **Time Dependent:** Select start and end dates (optional). Select the respective drop-down menus to assign workspace and application access, and roles to the external user.
 - **Indefinite:** Do not define start and end dates. This means site access is not time-limited until the value changes.
- f. Select **Save**.

You can review the access and roles assigned to the new user in the **Users & Roles** area by selecting **External Users** in the **Users & Roles** area.

Related Links

[Configure Idle Session Timeout for All](#) on page 357

View a List of Users

Use this topic to view a list of users.

1. Go to **Administration & Settings > Access Management**.
2. In the **Users & Roles** area, select one of the following account-types:
 - **Internal Users:** Select this tab to view users within your organization.
 - **External Users:** Select this tab to grant view users outside of your organization; for example, resellers, distributors, technical support, and sales.
3. Use the [search, group, and filter](#) features to refine your result set.

Related Links

[Create a New User](#) on page 353


[Edit, Disable, or Delete a User Account](#) on page 355

Edit, Disable, or Delete a User Account

The **Edit** option provides the ability to modify roles, site access, and idle session timeout.

Use this task to edit, disable (suspend), or delete a user account.

1. Go to **Administration & Settings > Access Management**.

2. In the **Users & Roles** area, select the **Internal Users** or **External Users** tab for the account type you want to change.
3. Use [search, group, and filter](#) to locate the account.
4. Select the account to change.
5. Select  for the account, and then select one of the following options:
 - **Edit.** Make changes to the account configuration.
 - **Disable.** Inactivate the account, with the ability to reactivate if desired.
 - **Delete.** Remove the account permanently from the system.
6. Follow the prompts to make your changes, and select **Save**.
7. Select **Save**.

Single Sign-On

Single Sign On (SSO) simplifies the login process, allowing users to log in using credentials from an existing SAML-enabled identity provider (IdP).

Key features of SSO:

- **Unified Access:** Log in once and gain access to integrated services without repeated logins.
- **Improved Security:** Use a single, strong password to reduce the risk of security breaches associated with weak or reused passwords, enforce multi-factor authentication based on your IdP policies, and deny administrative access to ExtremeCloud IQ by removing users from the IdP.
- **Role-Based Access Control (RBAC):** Assign users to groups and roles to define and control which assets can be viewed or managed by users.

Set Up Your Single Sign-On Credentials

Extreme Platform ONE Networking single sign-on (SSO) is self-service and available for you to configure when your account meets criteria defined by your Extreme Platform ONE administrator. Use this task to configure your SSO credentials.

1. In a web browser, open Extreme Platform ONE Networking.
2. In the logon dialog, select **Log in with SSO**.
3. In the **Log in with Single Sign-On** dialog, type your email address, and then select **Log in with SSO**.
4. Select your organization from the list, and then follow the prompts to complete configuring your account for SSO.



Note

If you encounter difficulty during configuration, contact your Extreme Platform ONE administrator to determine whether your account can be configured for SSO.

After you complete configuring SSO, select **Log in with SSO** in the log in dialog.

Configure Idle Session Timeout for All

Use this task to specify the idle session timeout for all users who are not assigned to a group. You can configure differing timeout intervals or a non-expiring timeout on a per-user basis.

**Note**

A non-expiring timeout configuration overrides any administrator-configured timeout. Otherwise, all administrator-configured user timeout settings follow those that the admin configured.

1. Go to **Administration & Settings > Access Management**, and then select the **Access Settings** tab.
2. Select **Timeout Duration**, and select the hour and minutes for duration from the **HH** and **MM** menus, respectively.
3. Select **Save**.

Related Links

[Edit, Disable, or Delete a User Account](#) on page 355

[Create a New User](#) on page 353

Identity Providers

You can configure one or more identity providers (IdPs) to implement role-based access (RBAC) and single sign-on (SSO) functionality.

**Note**

As a prerequisite to adding an IdP to Extreme Platform ONE Networking, you must configure your IdP before you begin.

Add an Identity Provider Profile

An Identity Provider (IdP) profile defines how Extreme Platform ONE Networking interacts with an external IdP for user authentication. By creating an IdP profile, you allow your system to authenticate users for the defined domain, governed by the role and site-assignment rules in the IdP profile.

The following IdPs are supported by Extreme Platform ONE Networking:

- Generic SAML Server
- Active Directory Federation Service (ADFS)
- Ping
- Okta
- Microsoft Entra ID
- OneLogin
- Auth0

You add an identity provider profile to begin the workflow that integrates an IdP with your application to enable single sign-on (SSO) authentication for your Extreme

Platform ONE users. SSO authentication can be used with both IdP- and SP-initiated SSO.

**Important**

The steps in this topic are a part of a workflow, meaning you should complete all steps to avoid having to repeat configuration steps.

Use this task to add an IdP profile to your network.

1. Go to **Administration & Settings > Access Management**, and then select the **Identity Providers** tab.
2. Select **+ Add IdP Profile**, and from **Provider**, select the IdP you want to integrate with Extreme Platform ONE Networking.
3. In the **Select An Identity Provider** area, select the provider that you want to integrate with Extreme Platform ONE Networking, then select **Next**.
4. In the **Add IdP Profile Information** area, add the following information:
 - a. In the **Domain** field, type a fully qualified domain name (FQDN) based on the identity provider you selected in the preceding step.
 - b. (*Optional*) In the **Description** field, type a description of up to 64 characters.
 - c. Select **Next** to [configure the IdP connection metadata](#).

Configure IdP Connection Metadata

Identity Provider (IdP) Metadata provides structured information that is used to configure and establish a connection between an IdP and a Service Provider (SP) in a SAML (Security Assertion Markup Language) environment. This metadata includes details such as the following:

- **IdP Entity ID:** A unique identifier for an IdP used to identify the IdP to an SP.
- **SSO URLs:** Endpoints where the SP sends authentication requests.
- **Binding Methods:** Methods for communication between the IdP and SP.
- **Certificates:** Used for signing and encrypting SAML assertions.

**Important**

The steps in this topic are a part of a workflow. Complete all steps to avoid having to repeat configuration steps.

You can import metadata through an XML file or a URL. As an alternative, you can enter the metadata manually. For more information, see [Table 108](#) on page 359.

Import Metadata

1. Select **Import From Metadata**.
2. Select **Browse Files**, then select the metadata file from your local folder.
3. Complete any missing information that displays, which is specific to the chosen IdP. For more information, see [Table 108](#) on page 359.
4. Click **Next**.

Import from URL

1. Select **Import From URL**.
2. Type or paste an **IdP Metadata URL**, and then select **Import**.
3. Complete any missing information that displays, which is specific to the chosen IdP.
For more information, see [Table 108](#) on page 359.
4. Click **Next**.

Enter Metadata Manually

1. Select **Manually Enter**.
2. Configure the IdP metadata settings that are described in [Table 108](#).
3. Click **Next**.

Table 108: IDP Metadata Settings Descriptions

Setting	Description
IdP Entity ID	The IdP unique identifier URL. URLs must begin with <code>https</code> .
SSO Binding	Select HTTP POST to send messages within the body of an HTTP POST request. Select HTTP Redirect to send encoded messages as query parameters in the URL of an HTTP GET request.
SSO URL	The endpoint where SSO authentication requests are sent. URLs must begin with <code>https</code> .
SSO Request	Select SSO Request to enhance SSO security. By signing the SSO request, you ensure its authenticity and integrity, confirming that it has not been tampered with.
SLO Binding	Single Logout (SLO) allows users to sign out from multiple applications or services with a single action. Select HTTP POST to send messages within the body of an HTTP POST request. Select HTTP Redirect to send encoded messages as query parameters in the URL of an HTTP GET request.
SLO URL	The endpoint where logout requests are sent to start the SLO process. This URL ensures that when a user logs out from one service, they are also logged out from all connected services. URLs must begin with <code>https</code> .
SLO Response URL	The endpoint where the Service Provider (SP) sends logout response messages after receiving a logout request from the IdP. This URL is used to confirm the completion of the SLO process. URLs must begin with <code>https</code> .
Verification Certificate	The digital certificate used to verify the authenticity and integrity of messages exchanged between the IdP and SPs. Choose an existing certificate from the drop-down list, or select Import a new Certificate .

Import Verification Certificates

1. Select **Import Certificates**.
2. Drag and drop the certificate or browse to upload it to the **Verification Certificates** area.
3. Click **Next** to [map user profile attributes](#).

Map User Profile Attributes

You must map the appropriate User Profile Attributes to the SAML Attributes sent from the IdP. These strings must be created and be in sync with both IdP and SP. The following attributes are required for Single Sign-On.

- **First Name.** The URL or endpoint where the IdP provides the user's given name.
- **Last Name.** The URL or endpoint where the IdP provides the user's family name or surname.
- **Email.** The URL or endpoint where the IdP provides the user's email address.
- **Group.** The URL or endpoint where the IdP provides the user's group memberships.



Important

The steps in this topic are a part of a workflow, meaning you should complete all steps to avoid having to repeat configuration steps.

Use this information to map user profile attributes to SAML profile attributes when you add a new IdP profile.

1. Go to **Administration & Settings > Access Management > Single Sign-On**.
2. Add the name, email, and group information in the respective boxes.
3. (Optional) To add a new group mapping, select **+ Add a Group Mapping** and complete the following information. Otherwise, go to step 4.
 - a. Type the **IdP Group Name**.

b.



Note

You can hover over the information tool-tip icon (i) for information about access and access limitations for each role type. The **Primary Role** selection populates the mapped **Classic Role** box. The Primary role determines the scope of access for the group.

Select the **Primary Role** for this group from the list.

The corresponding **Classic Role** populates according to the Primary role you choose.

- c. Toggle the **Sites** selector to assign site access for the group.

You can choose from the following actions:

- To give the group access to all sites, toggle the setting to **All**.

- To specify which site or sites the group can access, complete the following steps: and select unnamed menu that shows at the right of the **All** label, the continue to the next step.
 - i. Toggle the setting to the left (the off position).
 - ii. Select the unnamed menu at the right of the **All** label to open a list of sites.
 - iii. Scroll through the list or use the **Search** box to find and select one or more sites from the dialog.
 - iv. Click **Done**.

You can repeat this process to add as many new group mappings as desired.

4. (Option 2) Choose the following option **When there is no available group map** to specify the action to take.

**Note**

Using this option applies your chosen settings to the entire group.

5. Select the **Primary Role** for this group from the list.

**Note**

You can hover over the information tool-tip icon (i) for information about access and access limitations for each role type. The **Primary Role** selection populates the mapped **Classic Role** box. The Primary role determines the scope of access for the group.

6. Specify **Site** access following instructions in step 3C.
7. Select **Extreme Cloud(SP) Connection** to [export or import SP connections](#).

Export/Import SP Connections

Use this task to export or import SP connections.

After mapping user profile attributes, you export the SP metadata and import it to the IdP to complete the configuration.

**Important**

The steps in this topic are a part of a workflow, meaning you should complete all steps to avoid having to repeat configuration steps.

1. Select the option you desire to import or export SP metadata, and complete your chosen action.
2. Confirm the configuration is correct, and then download and save the .XML file to your local store.

*Manage IdP Profile Settings***Table 109: Profile Settings**

Setting	Description
Domain	The domain used by the IdP to manage and authenticate user identities.
Description	A brief summary of the IdP profile.

Table 110: IdP Connection Settings

Setting	Description
IdP Entity ID	The IdP unique identifier URL. URLs must begin with <code>https</code> .
SSO Binding	Select HTTP POST to send messages within the body of an HTTP POST request. Select HTTP Redirect to send encoded messages as query parameters in the URL of an HTTP GET request. Data is visible in the URL and is limited by the maximum URL length supported by browsers and servers.
SSO URL	The endpoint where SSO authentication requests are sent. URLs must begin with <code>https</code> .
SSO Sign Request	Select SSO Sign Request to enhance SSO security. By signing the SSO request, you ensure its authenticity and integrity, confirming that it has not been tampered with.
SLO Binding	Single Logout (SLO) allows users to sign out from multiple applications or services with a single action. Select HTTP POST to send messages within the body of an HTTP POST request. Select HTTP Redirect to send encoded messages as query parameters in the URL of an HTTP GET request.
SLO URL	The endpoint where logout requests are sent to start the SLO process. This URL ensures that when a user logs out from one service, they are also logged out from all connected services. URLs must begin with <code>https</code> .



Table 110: IdP Connection Settings (continued)

Setting	Description
SLO Response URL	The endpoint where the Service Provider (SP) sends logout response messages after receiving a logout request from the IdP. This URL is used to confirm the completion of the SLO process. URLs must begin with <code>https</code> .
Verification Certificate	<p>The digital certificate used to verify the authenticity and integrity of messages exchanged between the IdP and SPs.</p> <p>To update the verification certificate for this IdP profile, select X, and then choose an existing certificate from the drop-down list.</p>

Table 111: Attribute Mapping Settings

User Profile Attribute	SAML Attribute
First Name	The URL or endpoint where the IdP provides the user's given name.
Last Name	The URL or endpoint where the IdP provides the user's family name or surname.
Email	The URL or endpoint where the IdP provides the user's email address.

Table 111: Attribute Mapping Settings (continued)

User Profile Attribute	SAML Attribute
Group	The URL or endpoint where the IdP provides the user's group memberships.
Group Name Mapping	<p>Specifies how group names from the IdP are translated, or mapped, to the corresponding group names in ExtremeCloud IQ:</p> <ul style="list-style-type: none"> • Select the IdP Group, ExtremeCloud IQ Group, and Site(s) for each group name map. • Select Add a group name mapping to add a new group map row. • Select  to delete a group map. • Select  and drag the row to reorder the group mappings. The first group that the user matches the rule, in the order, the process stops. Rules are enforced top down, once a user is in the first group in a rule, the <p>Determine what action ExtremeCloud IQ should take for users that do not match a defined group name mapping:</p> <ul style="list-style-type: none"> • Deny user login. • Allow user login and assign a default user group (select a default group). <p>Note: When defining Group Mappings for the Operator, Monitor, Help Desk, Observer, and Installer roles you must define sites to view managed devices. Administrators have global oversight, so site-specific group mappings are ignored. Sites are ignored for Guest Management accounts. However, Guest Management accounts must be added to a Credential Distribution group to view and create guest accounts.</p>

Alert Policies

The **Alert Policies** screen consists of the following sections:

- Global Policy
- Site Policies




Note

The Observer role does not have access to Alert Policies.

Global Policy

Use the **Global Policy** screen to enable or disable **Alert Rules**, and edit alert rule parameters.

The alert rule categories are **ExtremeCloudIQ**, **Extreme Vendor Specific**, **Universal ZTNA**, and **ExtremeCloud SD-WAN**. Select a rule category to see alert rules for that type. Alert rule parameters can be enabled or disabled by selecting the alert rule, then toggle the enable/disable radio button for the event or metric. To edit alert rule parameters, select  for the rule.

Site Policy

Site policies are applied to particular sites. They over-ride global policies for the sites they apply to.

Add a Site Policy

Use this task to add a site policy.

1. Go to **Administration & Settings > Alert Policies**, and select **Site Policies**.
2. Select **Add Site Policy**.
3. Complete the following:
 - Provide the **Alert Policy Name**.
 - Select **Sites**.
4. Select **Next**.
5. Select an **Alert Rule** and optionally edit, enable, or disable the rule parameters.
6. Select **Apply Rules**.
7. To edit or delete the site policy, from the 3-dot menu, select **Edit** or **Delete**.

External Notifications

The **Alert Notifications** screen consists of the following major sections:

- Email Recipients
- Webhooks
- ServiceNow

Select  to refresh the screen.

Use this task to add email recipients, webhook, and ServiceNow alerts.

1. Go to **Administration and Settings > Notifications**.

Email Recipients

2. Type in the **Search** field to view specific email recipients.
3. Apply the following filters for email recipients:
 - All
 - Verified
 - Not Verified
4. To add a new email recipient:
 - a. Select **Add Email Recipient**.

By default, **Select All** is selected for severity, application, sites and policy drop down values.

- b. If a site-specific policy is available and a user selects **Global Policy** to generate an email notification, the system does not send a notification.

The system only uses the site-specific policy to send notifications.

- c. If there is no site-specific policy, and a user selects **Global Policy** to generate an email notification, the system sends a notification.

Webhook Alerts

5. Type in the **Search** field to view specific Webhook alerts.
6. To add a webhook alert, select **Add Webhook** and use this table to populate the **Add Webhook** screen:

Table 112: Add Webhook Alerts

Field	Enter
POST URL	Enter a valid URL
Access Token (optional)	Provide access token details.
Sites	Select at least one site or all sites.
Applications	Select at least one application or all applications.
Severity	Select at least one severity or all severity levels.
Alert Policy	Select at least one alert policy or all alert policies.

- a. Select the **Enable Notifications** toggle.
- b. Select **Save**.

ServiceNow

7. Type in the **Search** field to view specific ServiceNow alerts.
8. To add a ServiceNow alert, select **Add Account** and use this table to populate the **Add Account** screen:

Table 113: Add ServiceNow Alerts

Field	Enter
ServiceNow Email	Enter a valid email address
Sites	Select at least one site or all sites.
Applications	Select at least one application or all applications.
Severity	Select at least one severity or all severity levels.
Alert Policy	Select at least one alert policy or all alert policies.

- a. Select the **Enable Notifications** toggle.
- b. Select **Save**.

Backup & Restore

The **Backup & Restore** screen consists of the following major sections:

- VIQ Management
- Default Device Password

VIQ Management

The **VIQ Management** screen supports the following functions:

- Manually back up and restore Virtual IQ account data.
- Delete data to reset the Virtual IQ database.
- Enable Copilot feature for the VIQ.
- SSH Availability.
- Supplemental CLI.
- AP Out-of-the-box Wireless Onboarding.
- Import and Export VIQ data.


Use this task to manage the Virtual IQ.

1. Go to **Administration & Settings > Backup & Restore > VIQ Management**.

2. To perform a manual backup, select , and then select **Backup VIQ**.

To ensure data integrity, activities are suspended in the VIQ during both the backup and the restore process. When a backup is complete, the backup event is added to the Backup History table at the bottom of the page.

3. To restore a backup, choose a backup file from the **Backup History** table, and then select **Restore**.

4. To delete the VIQ database, select , and then select **Reset VIQ**.

This step resets the VIQ to its initial state before configuration and the addition of inventory.

5. Toggle **Enable CoPilot feature for this VIQ** to **ON**.

6. Toggle **SSH Availability** to **ON**.

Enabling SSH availability potentially gives others direct access to your devices while SSH access is available. While active, SSH Availability exposes your device to the public Internet through an SSH proxy, protected only by the device administrator credentials, as SSH FTP assumes that it is run over a secure channel.

7. Toggle **Supplemental CLI** to **ON**.

Use the Supplemental CLI tool to append CLI commands to a network policy when you upload the configuration to managed devices.

8. To enable the VIQ to permit APs to respond to mesh-join requests, slide the **AP Out-of-the-box Wireless Onboarding** toggle to **ON**.

This setting permits or prohibits AP responses to mesh-join requests. When this setting is off, the Virtual IQ prohibits managed APs from responding even if the serial number of the requesting AP is listed in the Virtual IQ.

9. To export VIQ data:

- a. Select **Export VIQ**.
- b. (Optional) Provide **Export Timeout (in minutes)**.
- c. Select **Export**.

10. To import VIQ data:

- a. Select **Import VIQ**.
- b. Select **Import VIQ from ExtremeCloud IQ**.

- c. Either drag the .tar.gz file or select **Browse Files** to navigate to the location of the file and select it.
- d. Complete the following Optional Settings:
 - Enable or disable **Resend Cloud PPSK/RADIUS password via Email/SMS**
 - Provide **Import Timeout** (in minutes)
 - Instructions on handling errors during VIQ import: **Abort the import operation** or **Continue the import Operation**.
 - Select **Import**.

Set Default Device Password

The device default password is applied to devices when their network policies are uploaded. Use this task to set the default device password.

1. Log into Extreme Platform ONE Networking.
2. Go to **Backup & Restore > Default Device Password**.
3. For **Default Password**, enter the password the administrator uses to log in to a new device.

The password must be an alphanumeric string containing at least one number and one uppercase character, and cannot be the same as the user name or a previously used password.

4. For EXOS and VOSS switches, select **Enable device management settings for Switch Engine (EXOS)/Fabric Engine (VOSS) switches**.


Enable this setting to set device credentials at the device level for these switch series.

5. (Optional) Select **Change Password**.

Integrations

Integrations provides administrators with tools to create and manage API keys. The **Integrations** table displays the following information for the API keys that have been added to Extreme Platform ONE Networking:

- **Name:** The name of the API key.
- **Expire At:** The expiration date of the API key.
- **Key Hash:** A partial representation of the API key used for reference without exposing the full key.
- **Description:** A short description of the API key.

To [Create a New API Key](#) on page 369, select **Create New API Key**. To edit an existing API key, select  at the end of the corresponding row, and then select **Edit Key**. To delete an API key, select **Delete Key**.



Note

Once a key is generated it cannot be modified.

Create a New API Key

Use this task to create a new API key.

1. Go to **Administration & Settings > Integrations > Create New API Key**.
2. Configure the following settings:

Table 114: API Key Settings

Field	Description
Name	A descriptive label to identify the API key.
Description	A short description of the API key.
Expiration Date	The date the API key automatically becomes inactive.

3. Select **Generate Key**.
4. Select **Copy API Key**, and then select **Close**.



Important

Make sure to copy your API key now. For security reasons, you won't be able to see it again once you close the window.

Related Links

[Integrations](#) on page 368

Logs


Use logs to detect anomalies in the system and track past activity.

Logs capture the following activities:

- **Audit Logs**
 - Administrative activity: For example, creating or deleting a user account or changing, suspending, or deleting role-based user access.
 - Data access and modification: When a user views, creates, or modifies data
 - User denials or login failures: Captures when a user is unable to login to a system due to invalid credentials or is denied access to resources such as a specific URL
 - System changes: Captures system activity. Audit logs must be compliant with all Extreme Network standards, for example, HIPPA, PCI, NIST.

Use this task to work with logs.

1. Log into Extreme Platform ONE Networking.
2. Go to **Administration and Settings > Logs**.
3. Select the **Log** and **Date** and **Time** pickers to do the following:
 - View logs for up to 30 days.
 - View logs for last week, last month or last quarter.
 - Select an end time.
 - Reset to default.

- Use arrows to select a specific month.
 - To view a logs for a specific date, select the date directly from the calendar.
4. You can also search and filter by column heading.
 5. Select the **Date/Time** column to sort in ascending or descending order.
 6. Select **Column** to add, hide, and reposition columns on the screen.
 7. To refresh the screen and get the latest audit logs, select .