



5520 Series Installation Guide

Setup, Configuration, and Best Practices

9036817-00 Rev. AW
September 2025



Copyright © 2025 Extreme Networks, Inc. All rights reserved.

Legal Notice

Extreme Networks, Inc. reserves the right to make changes in specifications and other information contained in this document and its website without prior notice. The reader should in all cases consult representatives of Extreme Networks to determine whether any such changes have been made.

The hardware, firmware, software or any specifications described or referred to in this document are subject to change without notice.

Trademarks

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries.

All other names (including any product names) mentioned in this document are the property of their respective owners and may be trademarks or registered trademarks of their respective companies/owners.

For additional information on Extreme Networks trademarks, see: <https://www.extremenetworks.com/about-extreme-networks/company/legal/trademarks>

Open Source Declarations

Some software files have been licensed under certain open source or third-party licenses.

End-user license agreements and open source declarations can be found at: <https://www.extremenetworks.com/support/policies/open-source-declaration/>



Table of Contents

Introduction to the 5520 Series Installation Guide.....	ix
Text Conventions.....	ix
Documentation and Training.....	xi
Open Source Declarations.....	xi
Training.....	xi
Help and Support.....	xi
Subscribe to Product Announcements.....	xii
Send Feedback.....	xii
New in this Guide.....	14
August 2025.....	14
Overview.....	15
Universal Hardware.....	15
Management.....	15
Instant Onboarding.....	16
Cooling.....	16
Power Supplies.....	16
Expansion Modules.....	17
Stacking Ports.....	17
Instant Stack.....	17
Instant Port.....	18
Instant Secure Port.....	18
Secure Boot.....	18
Operating Temperatures.....	19
Feature Licensing.....	19
5520-24T, 5520-24T-BASE, and 5520-24T-ACDC Switch Features.....	19
5520-24W Switch Features.....	20
5520-24X, 5520-24X-BASE, and 5520-24X-ACDC Switch Features.....	21
5520-12MW-36W Switch Features.....	22
5520-48T, 5520-48T-BASE, and 5520-48T-ACDC Switch Features.....	23
5520-48W Switch Features.....	24
5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC Switch Features.....	25
Port Subdivisions.....	27
Manage Your Switch.....	28
Connect to Your Switch.....	28
Configure and Operate Your Switch.....	29
Universal Ethernet Ports.....	30
Secure Boot.....	31
Switch Engine.....	31
Fabric Engine.....	31

Secure Boot Troubleshooting	32
Fan Modules for Use with Your Switch.....	33
Precautions Specific to Fan Modules.....	33
Fan Modules.....	34
Power Supplies for Use with Your Switch.....	35
Precautions Specific to Power Supply Modules.....	35
350 W AC Power Supplies.....	36
550 W AC and DC Power Supplies.....	36
550 W AC Power Supplies.....	37
550 W DC Power Supplies.....	37
715 W AC Power Supplies.....	38
1100 W AC Power Supplies.....	38
2000 W AC Power Supply.....	39
Expansion Modules for Use with Your Switch.....	41
V300 Virtual Port Extender.....	42
V300-8P-2X Model.....	42
V300-8T-2X Model.....	43
V300-8P-2T-W Model.....	44
V300HT-8P-2X Model.....	45
V300HT-8T-2X Model.....	46
V300 Virtual Port Extender LEDs.....	47
V400 Virtual Port Extender.....	48
Versatile Interface Modules for the 5520 Series Switches.....	49
5520-VIM-4X Versatile Interface Module.....	50
5520-VIM-4XE Versatile Interface Module.....	51
5520-VIM-4YE Versatile Interface Module.....	52
Build Stacks.....	53
Introduction to Stacking.....	53
Build Basic Stacks.....	54
SummitStack Topologies.....	56
SummitStack Terms.....	60
Plan to Create Your Stack.....	63
Enable and Disable the Stacking Support Option.....	63
Recommendations for Placing Switches for Stacked Operation.....	64
Recommendations for Configuring Stacks.....	64
Combine Switches from Different Series.....	65
Select Stacking Cables.....	66
Use the Extreme Stacking Tool.....	66
Set up the Physical Stack.....	68
Connect the Switches to Form the Stack Ring.....	68
Connect Your Stack to the Management Network.....	71
Site Preparation.....	72
Plan Your Site.....	72
Operating Environment Requirements.....	73
Meet Building and Electrical Codes.....	73
Set Up the Wiring Closet.....	74
Control the Temperature.....	75

Control the Humidity Level.....	76
Protect Your System from ESD (Electrostatic Discharge).....	76
Rack Specifications and Recommendations.....	76
Mechanical Recommendations for the Rack.....	77
Ground the Rack.....	77
Provide Adequate Space for the Rack.....	77
Secure the Rack.....	78
Evaluate and Meet Cable Requirements.....	78
Label Cables and Keep Accurate Records.....	79
Install Cable.....	79
Use RJ45 Connector Jackets.....	81
Prevent Radio Frequency Interference (RFI).....	82
Meet Power Requirements.....	82
Requirements for PoE Devices.....	82
Power Supply Requirements.....	82
Power Cord Requirements.....	83
UPS (Uninterruptible Power Supply) Requirements.....	83
Follow Applicable Industry Standards.....	85
Install Your Switch.....	86
Safety Considerations for Installation.....	87
What You Will Need for the Installation.....	87
Attach the Switch to a Rack or Cabinet.....	88
Two-Post Rack Mount.....	88
Four-Post Rack Mount.....	90
Install Expansion Modules.....	91
Install Optional Components.....	91
Pluggable Transceiver Modules.....	91
Optical Cables.....	91
Install Internal Power Supplies.....	91
Connect Network Interface Cables.....	92
Turn on the Switch.....	92
Connect AC Power.....	92
Connect DC Power.....	93
Activate and Verify the Switch.....	94
Connect to a Management Console.....	94
Log In for the First Time on Switch Engine	94
Configure the Switch's IP Address for the Management VLAN.....	96
Change the Switch OS via the Bootloader Menu.....	96
Change the Switch OS via the Startup Menu.....	97
Log In for the First Time on Fabric Engine.....	97
Remove and Replace Components.....	99
Remove a Switch from a Rack.....	99
Remove a Switch from a Four-Post Rack.....	99
Remove a Switch from a Two-Post Rack.....	100
Replace Power Supplies.....	100
Power Supply Airflow Direction Requirements.....	100
Replace a Power Supply.....	101
Replace Fan Modules.....	105

Fan Airflow Direction Requirements.....	105
Replace a Fan Module.....	106
Replace Expansion Modules.....	107
Replace Versatile Interface Modules.....	107
Replace Virtual Port Extenders.....	109
Monitor the Switch.....	135
System Status LEDs.....	135
Port LEDs in Default (SYS) Mode.....	136
Port LEDs in SPD Mode.....	136
Port LEDs in STK Mode.....	137
Locator LED.....	137
Versatile Interface Modules (VIM) Port LEDs.....	138
5520-VIM Port LEDs in Default (SYS) Mode.....	138
5520-VIM Port LEDs in SPD Mode.....	138
Technical Specifications.....	139
5520 Series Technical Specifications.....	140
External Interfaces.....	140
Weights and Dimensions.....	142
Acoustic Noise and Fan Speed.....	144
Fan & Acoustic Noise.....	144
Memory.....	150
Mean Time Between Failures.....	150
Power Specifications.....	152
Power Supply Specifications (cont.).....	153
Power Supply Specifications (cont.).....	153
PoE Power Budget.....	154
Minimum/Maximum Power Consumption and Heat Dissipation.....	154
V300 Virtual Port Extender Specifications.....	155
Power Specifications.....	156
Standards and Environmental Data.....	157
V400 Virtual Port Extender Technical Specifications.....	158
Power Specifications.....	159
Fan and Acoustic Sound.....	160
Standards and Environmental Data.....	160
Half-Duplex to Full-Duplex Converter Technical Specifications.....	161
Half-Duplex to Full-Duplex Converter Power Specifications.....	162
Half-Duplex to Full-Duplex Converter Environmental Data and Standards.....	162
Environmental.....	163
Environmental Specifications.....	163
Environmental Compliance.....	163
Environmental Operating Conditions.....	163
Packaging and Storage Specifications.....	164
Standards.....	164
North American ITE.....	164
European ITE.....	164
International ITE.....	164
IEEE 802.3 Media Access Standards.....	164
EMI/EMC Standards.....	165

North American EMC for ITE.....	165
European EMC Standards.....	165
International EMC Certifications.....	165
Country Specific.....	165
Power Cord Requirements for AC-Powered Switches and AC Power Supplies.....	166
Console Connector Pinouts.....	166
Safety and Regulatory Information.....	169
Considerations Before Installing.....	169
General Safety Precautions.....	170
Maintenance Safety.....	171
Fiber Optic Ports and Optical Safety.....	171
GBIC, SFP (Mini-GBIC), QSFP+, XENPAK, and XFP Regulatory Compliance.....	172
Cable Routing for LAN Systems.....	172
Install Power Supply Units and Connect Power.....	173
Select Power Supply Cords.....	174
EMC Warnings.....	174
Taiwan BSMI Warning.....	174
China CQC Warning.....	175
Battery Notice.....	175
Battery Warning - Taiwan.....	175
Japan (VCCI Class A).....	175
Korea EMC Statement.....	176
Index.....	177



Abstract

This hardware installation guide for 5520 Series covers procedures for setting up the switches, including site preparation, rack installation, and power supply specifications. It details various models, describing port configurations, cooling systems, and power options. The guide outlines management interfaces, including RJ45 and USB ports, and discusses stack configuration, secure boot processes, and operating environment requirements. It also includes instructions for handling power supplies, fan modules, and versatile interface modules (VIMs). The document is intended for network administrators familiar with LANs, Ethernet, and SNMP protocols.



Introduction to the 5520 Series Installation Guide

This guide is intended for use by network administrators responsible for installing and setting up network equipment. It assumes a basic working knowledge of:

- Local area networks (LANs)
- Ethernet concepts
- Ethernet switching and bridging concepts
- Routing concepts
- Simple Network Management Protocol (SNMP)
- Basic equipment installation procedures

See the *Switch Engine User Guide* and the *Switch Engine Command References* for your version of the *Switch Engine* operating system for information about configuring Extreme Networks switches.



Note

If the information in an installation note or release note shipped with your Extreme Networks equipment differs from the information in this guide, follow the installation or release note.

Read the following topics to learn about:

- The meanings of text formats used in this document.
- Where you can find additional information and help.
- How to reach us with questions and comments.

Text Conventions

Unless otherwise noted, information in this document applies to all supported environments for the products in question. Exceptions, like command keywords associated with a specific software version, are identified in the text.

When a feature, function, or operation pertains to a specific hardware product, the product name is used. When features, functions, and operations are the same across an entire product family, such as Extreme Networks switches or routers, the product is referred to as *the switch* or *the router*.

Table 1: Notes and warnings






Icon	Notice type	Alerts you to...
	Tip	Helpful tips and notices for using the product
	Note	Useful information or instructions
	Important	Important features or instructions
	Caution	Risk of personal injury, system damage, or loss of data
	Warning	Risk of severe personal injury

Table 2: Text

Convention	Description
screen displays	This typeface indicates command syntax, or represents information as it is displayed on the screen.
The words <i>enter</i> and <i>type</i>	When you see the word <i>enter</i> in this guide, you must type something, and then press the Return or Enter key. Do not press the Return or Enter key when an instruction simply says <i>type</i> .
Key names	Key names are written in boldface, for example Ctrl or Esc . If you must press two or more keys simultaneously, the key names are linked with a plus sign (+). Example: Press Ctrl+Alt+Del
<i>Words in italicized type</i>	Italics emphasize a point or denote new terms at the place where they are defined in the text. Italics are also used when referring to publication titles.
NEW!	New information. In a PDF, this is searchable text.

Table 3: Command syntax

Convention	Description
bold text	Bold text indicates command names, keywords, and command options.
<i>italic text</i>	Italic text indicates variable content.

Table 3: Command syntax (continued)

Convention	Description
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x y z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, such as passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	In command examples, the backslash indicates a “soft” line break. When a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

Documentation and Training

Find Extreme Networks product information at the following locations:

[Current Product Documentation](#)

[Release Notes](#)

[Hardware and Software Compatibility](#) for Extreme Networks products

[Extreme Optics Compatibility](#)

[Other Resources](#) such as articles, white papers, and case studies

Open Source Declarations

Some software files have been licensed under certain open source licenses. Information is available on the [Open Source Declaration](#) page.

Training

Extreme Networks offers product training courses, both online and in person, as well as specialized certifications. For details, visit the [Extreme Networks Training](#) page.

Help and Support

If you require assistance, contact Extreme Networks using one of the following methods:

[Extreme Portal](#)

Search the GTAC (Global Technical Assistance Center) knowledge base; manage support cases and service contracts; download software; and obtain product licensing, training, and certifications.

The Hub

A forum for Extreme Networks customers to connect with one another, answer questions, and share ideas and feedback. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.

Call GTAC

For immediate support: (800) 998 2408 (toll-free in U.S. and Canada) or 1 (408) 579 2800. For the support phone number in your country, visit www.extremenetworks.com/support/contact.

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number, or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any actions already taken to resolve the problem
- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- Any related RMA (Return Material Authorization) numbers

Subscribe to Product Announcements

You can subscribe to email notifications for product and software release announcements, Field Notices, and Vulnerability Notices.

1. Go to [The Hub](#).
2. In the list of categories, expand the **Product Announcements** list.
3. Select a product for which you would like to receive notifications.
4. Select **Subscribe**.
5. To select additional products, return to the **Product Announcements** list and repeat steps 3 and 4.

You can modify your product selections or unsubscribe at any time.

Send Feedback


The User Enablement team at Extreme Networks has made every effort to ensure that this document is accurate, complete, and easy to use. We strive to improve our documentation to help you in your work, so we want to hear from you. We welcome all feedback, but we especially want to know about:

- Content errors, or confusing or conflicting information.

- Improvements that would help you find relevant information.
- Broken links or usability issues.

To send feedback, email us at Product-Documentation@extremenetworks.com.

Provide as much detail as possible including the publication title, topic heading, and page number (if applicable), along with your comments and suggestions for improvement.



New in this Guide

The following sections describe the recent documentation revisions for this guide. Use this information to locate the latest updates.

August 2025

The following table lists the documentation updates for August, 2025.

Description	Section
Update for mixing AC and DC power supplies has been added.	Power Supplies for Use with Your Switch on page 35 Replace Power Supplies on page 100
Update for the mixed speeds table entry for the 5520-VIM-4YE has been added.	Versatile Interface Modules for the 5520 Series Switches on page 49



Overview

[5520-24T, 5520-24T-BASE, and 5520-24T-ACDC Switch Features](#) on page 19

[5520-24W Switch Features](#) on page 20

[5520-24X, 5520-24X-BASE, and 5520-24X-ACDC Switch Features](#) on page 21

[5520-12MW-36W Switch Features](#) on page 22

[5520-48T, 5520-48T-BASE, and 5520-48T-ACDC Switch Features](#) on page 23

[5520-48W Switch Features](#) on page 24

[5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC Switch Features](#) on page 25

The 5520 Series is a family of high-performance aggregation switches. The 5520 Series universal hardware provides end-to-end secure network segmentation, in addition to advanced policy capabilities, and offers a user-selectable choice of Extreme's flagship switch operating systems.

The 5520 Series includes 24- and 48-port 1 Gigabit models, 1/2.5/5 Gigabit multi-rate models, as well as a 24-port 10 Gigabit model. The family also offers 30/60/90W PoE, and supports 10G and 25G modular uplinks for flexible linkage to other switches or devices over a range of media.

The 10/100/1000Base-T ports on the 5520-24W/12MW-36W/48T/48W models can operate in half-duplex mode when operating at 10Mbps or 100Mbps. Half-duplex is not supported on these ports when operating at 1Gbps.

Universal Hardware

The switch comes with a dual-persona capability, allowing you to choose your Operating System (OS). Either the Switch Engine (EXOS) or Fabric Engine (VOSS) OS can be selected at switch start-up or changed at a later time. The switch assumes the features and capabilities of the OS that is selected. Switch OS selection can also be automated with ExtremeCloud IQ so that the desired OS can be automatically loaded at switch start-up, which facilitates remote OS enablement.

Management

The switch supports connections using the RJ45 serial console port, the Ethernet management port, or the Micro-USB Type B port to view and manage the switch configuration. For more information on switch connection methods, see [Manage Your](#)

Switch. For switch connection details, see [Connect to a Management Console](#) on page 94.

After connecting to your switch, it can be flexibly configured and operated through the cloud, the network, or the command-line interface (CLI), either remotely or locally. You can access management functions on the switch using ExtremeCloud™ IQ or ExtremeCloud IQ Site Engine, or manually through a web-based GUI or generic command-line interface (CLI) client. For more information on switch configuration and operation methods, see [Manage Your Switch](#).

**Note**

There are also two USB 2.0 Type A ports labeled USB 1 and USB 2. USB 1 is located on the front panel, while USB 2 is located on the rear panel. The USB ports can interface with USB storage devices.

The first USB storage device inserted is mounted and can be used under the Switch Engine operating system as `/usr/local/ext`, or under the Fabric Engine operating system as `/usb`. A second inserted USB storage device is not used until the first one is removed.

Instant Onboarding

Switch onboarding to the cloud is a hands-off operation using zero touch provisioning. Unpack the switch and connect it to the network. It automatically finds a connection to the cloud and is ready to be provisioned. The ExtremeCloud Companion mobile app makes onboarding even easier with on-site cloud set-up and switch troubleshooting capabilities.

Cooling

Each switch is cooled by hot-swappable internal fan modules. Most 5520 Series models have fan modules that provide front-to back airflow. Models 5520-24T-BASE, 5520-24X-BASE, 5520-48T-BASE, and 5520-48SE-BASE require fan modules that provide back-to-front airflow. Models 5520-24T-ACDC, 5520-24X-ACDC, 5520-48T-ACDC, and 5520-48SE-ACDC support fan modules with either front-to-back airflow or back-to-front airflow. Switch fans are not responsible for cooling the power supplies; power supplies have integrated cooling fans that operate independently of the switch fan. Fan modules are ordered separately for models 5520-24T-BASE, 5520-24T-ACDC, 5520-24X-BASE, 5520-24X-ACDC, 5520-48T-BASE, 5520-48T-ACDC, 5520-48SE-BASE, and 5520-48SE-ACDC. Fan modules are included with other models.

For more information about the fan modules used in the switch, see [Fan Modules for Use with Your Switch](#) on page 33.

Power Supplies

Most 5520 Series models use up to two hot-swappable internal AC power supplies to provide enough power for the needs of the switch. Power supplies have integrated cooling fans that operate independently of the switch fans for power supply cooling and are not responsible for cooling the switch. Models 5520-24T-ACDC, 5520-24X-ACDC,

5520-48T-ACDC, and 5520-48SE-ACDC support AC and DC power supplies. Power supplies are ordered separately.

For more information about the power supplies used in the switch, see [Power Supplies for Use with Your Switch](#) on page 35.

Expansion Modules

The switch supports hardware accessories that expand the capabilities of the switch. Collectively, they are referred to as *expansion modules*. The following expansion modules are compatible with the switch:

Versatile Interface Modules (VIMs)

A VIM is a plug-in expansion card used to add specific types of network ports and features. A VIM can be installed in the switch to provide dedicated high speed ports and flexible uplink capabilities with a single VIM slot.

Virtual Port Extenders

A virtual port extender can be installed in the switch. Bridge port extenders (BPEs) receive packets from extended ports and forward packets toward the upstream controlling bridge (a Switch Engine-based switch) for L2/L3 processing. They do not fully process packets or make forwarding or filtering decisions.

For more information, see [Expansion Modules for Use with Your Switch](#) on page 41.

Stacking Ports

Each switch comes equipped with two stacking ports, also referred to as Universal Ethernet ports. When running Switch Engine, these ports can be used in either stacking mode or Ethernet mode. When in stacking mode, up to eight systems can be stacked using qualified direct attach cables or optical transceivers. Fabric Engine does not support stacking; the stacking ports can be used as Ethernet ports if Fabric Engine is in non-fabric mode.



Note

The 5520 Series can stack with themselves and with other switches. See [Combine Switches from Different Series](#) on page 65 for more information.

- Stacking cables are ordered separately.
- For more information about stacking ports, see [Universal Ethernet Ports](#) on page 30.
- For information about optical modules, see the [Extreme Optics](#) website.
- For more information about stacking, see [Build Stacks](#) on page 53.

Instant Stack

Instant Stack simplifies cloud-based stack provisioning, enabling the entire switch stack to be set-up through a single push-button operation. Real-world stack information,

including each switch model and their stack order, is captured and replicated in the cloud. Once set up, the entire stack is then ready to be cloud-provisioned

**Note**

This feature is only supported on Switch Engine.

Instant Port

Instant Port automates the adds, moves or changes across switch ports, which eliminates the need for manual port configuration. The switch automatically detects the connected device type and applies the correct port parameters. The result is significant time savings when adding or moving devices across the wired network. There is a simple cloud interface which allows Instant Port definitions of customer designated device types that can then be applied across a single switch, a stack, or even all switches in the network.

**Note**

This feature is only supported on Switch Engine.

Instant Secure Port

Instant Secure Port utilizes ExtremeCloud Universal ZTNA for authentication and zero-trust policy enforcement across switch ports, while providing the same add, move, and change automation features of Instant Port. It simplifies switch security by using Universal ZTNA's cloud-based security capabilities, including Radius authentication, unified visibility and reporting, as well as policy enforced locally on switch ports. Instant Secure Port delivers a consistent and frictionless security experience for any user or device connecting through the switch.

**Note**

ExtremeCloud Universal ZTNA requires a separate license.
This feature is only supported on Switch Engine.

Secure Boot

Secure boot establishes a chain-of-trust relationship in the boot process. The chain-of-trust is established by cryptographic checks at each stage of the boot process to validate the integrity and authenticity of the next stage before it can execute. The current implementation validates boot images. It cannot be disabled after it has been programmed on the device. There is no command-line interface or commands to enable or disable secure boot. The status of the boot image verification can be monitored in the operating system.

For more information, see [Secure Boot](#) on page 31.

Operating Temperatures

All 5520 Series switches using front-to-back airflow support an operating range from 0°C (32°F) to 50°C (122°F). All 5520 Series switches using back-to-front airflow support an operating range from 0°C (32°F) to 45°C (113°F).

Temperature restrictions apply for some models at high altitudes.

Feature Licensing

5520 Series switches support Unified Licensing, so that you can use them with multiple operating systems. There are two methods of acquiring feature licenses: manual or through ExtremeCloud IQ™ (XIQ).

For Switch Engine licensing, see the *Feature License Requirements* for your version of the Switch Engine operating system.

For Fabric Engine licensing, see the Licensing chapter in the *Fabric Engine User Guide* for your version of the Fabric Engine operating system.

For XIQ licensing, see [ExtremeCloud IQ](#).

5520-24T, 5520-24T-BASE, and 5520-24T-ACDC Switch Features

The front panel of the 5520-24T, 5520-24T-BASE, and 5520-24T-ACDC switch includes:

1 = 24 x 10/100/1000Mb full/half duplex MACsec capable ports



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

2 = USB Type-A port for management or external USB flash

3 = USB Micro-B console port

4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)

5 = VIM slot (unpopulated, covered)




Figure 1: 5520-24T, 5520-24T-BASE, and 5520-24T-ACDC Front Panel

The rear panel of the switch includes:



Note

Power supplies and fans are not included with the 5520-24T-BASE and 5520-24T-ACDC models. They must be ordered separately. The 5520-24T-BASE and 5520-24T-ACDC models support fan modules and power supply units with either front-to-back or back-to-front airflow.

- 1 = 2 x Fan module slots (3 fan module slots for model 5520-24T-ACDC)
- 2 = Grounding lug
- 3 = Serial console port
- 4 = Out-of-band management port (RJ-45)
- 5 = USB Type-A port for management or external USB flash
- 6 = Locator LED
- 7 = 2 x Power supply slots (unpopulated)




Figure 2: 5520-24T, 5520-24T-BASE, and 5520-24T-ACDC Rear Panel

5520-24W Switch Features

The front panel of the 5520-24W switch includes:

- 1 = 24 x 10/100/1000Mb full/half duplex MACsec capable ports with 802.3bt Type 4 PoE (90W)



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

- 2 = USB Type-A port for management or external USB flash
- 3 = USB Micro-B console port
- 4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)
- 5 = VIM slot (unpopulated, covered)




Figure 3: 5520-24W Front Panel

The rear panel of the switch includes:

- 1 = 3 x Fan module slots
- 2 = Grounding lug
- 3 = Serial console port
- 4 = Out-of-band management port (RJ-45)
- 5 = USB Type-A port for management or external USB flash
- 6 = Locator LED
- 7 = 2 x Power supply slots (unpopulated)




Figure 4: 5520-24W Rear Panel

5520-24X, 5520-24X-BASE, and 5520-24X-ACDC Switch Features

The front panel of the 5520-24X, 5520-24X-BASE, and 5520-24X-ACDC switch includes:

- 1 = 24 x 100Mb/1Gb/10Gb SFP+ ports
- 2 = USB Type-A port for management or external USB flash
- 3 = USB Micro-B console port
- 4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)
- 5 = VIM slot (unpopulated, covered)



Note

5520-24X, 5520-24X-BASE, and 5520-24X-ACDC switches do not support 10G LRM and ZR optics.




Figure 5: 5520-24X, 5520-24X-BASE, and 5520-24X-ACDC Front Panel

The rear panel of the switch includes:



Note

Power supplies and fans are not included with the 5520-24X-BASE and 5520-24X-ACDC models. They must be ordered separately. The 5520-24X-BASE and 5520-24X-ACDC models support fan modules and power supply units with either front-to-back or back-to-front airflow.

- 1 = 2 x Fan module slots (3 fan module slots for model 5520-24X-ACDC)
- 2 = Grounding lug
- 3 = Serial console port
- 4 = Out-of-band management port (RJ-45)
- 5 = USB Type-A port for management or external USB flash
- 6 = Locator LED
- 7 = 2 x Power supply slots (unpopulated)




Figure 6: 5520-24X, 5520-24X-BASE, and 5520-24X-ACDC Rear Panel

5520-12MW-36W Switch Features

The front panel of the 5520-12MW-36W switch includes:

1 = 36 x 10/100/1000Mb full/half duplex MACsec capable ports with 802.3bt Type 4 PoE (90W)



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

2 = USB Type-A port for management or external USB flash

3 = USB Micro-B console port

4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)

5 = VIM slot (unpopulated, covered)

6 = 12 x 100Mb/1/2.5/5Gb multi-rate MACsec capable ports



Figure 7: 5520-12MW-36W Front Panel

The rear panel of the switch includes:

1 = 3 x Fan module slots

2 = Grounding lug

3 = Serial console port

4 = Out-of-band management port (RJ-45)

5 = USB Type-A port for management or external USB flash

6 = Locator LED

7 = 2 x Power supply slots (unpopulated)




Figure 8: 5520-12MW-36W Rear Panel

5520-48T, 5520-48T-BASE, and 5520-48T-ACDC Switch Features

The front panel of the 5520-48T, 5520-48T-BASE, and 5520-48T-ACDC switch includes:

1 = 48 x 10/100/1000Mb full/half duplex MACsec capable ports



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

2 = USB Type-A port for management or external USB flash

3 = USB Micro-B console port

4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)

5 = VIM slot (unpopulated, covered)




Figure 9: 5520-48T, 5520-48T-BASE, and 5520-48T-ACDC Front Panel

The rear panel of the switch includes:



Note

Power supplies and fans are not included with the 5520-48T-BASE and 5520-48T-ACDC models. They must be ordered separately. The 5520-48T-BASE and 5520-48T-ACDC models support fan modules and power supply units with either front-to-back or back-to-front airflow.

1 = 3 x Fan module slots

2 = Grounding lug

3 = Serial console port

4 = Out-of-band management port (RJ-45)

5 = USB Type-A port for management or external USB flash

6 = Locator LED

7 = 2 x Power supply slots (unpopulated)




Figure 10: 5520-48T, 5520-48T-BASE, and 5520-48T-ACDC Rear Panel

5520-48W Switch Features

The front panel of the 5520-48W switch includes:

1 = 48 x 10/100/1000Mb full/half duplex MACsec capable ports with 802.3bt Type 4 PoE (90W)



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

2 = USB Type-A port for management or external USB flash

3 = USB Micro-B console port

4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)

5 = VIM slot (unpopulated, covered)




Figure 11: 5520-48W Front Panel

The rear panel of the switch includes:

1 = 3 x Fan module slots

2 = Grounding lug

3 = Serial console port

4 = Out-of-band management port (RJ-45)

5 = USB Type-A port for management or external USB flash

6 = Locator LED

7 = 2 x Power supply slots (unpopulated)




Figure 12: 5520-48W Rear Panel

5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC Switch Features

The front panel of the 5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC switch includes:

1 = 48 100/1000BASE-X MACsec capable SFP ports



Note

Half-duplex is not supported on these ports when operating at 1Gbps or higher.

2 = USB Type-A port for management or external USB flash

3 = USB Micro-B console port

4 = 2 x QSFP28 Universal Ports/stacking ports (unpopulated)

5 = VIM slot (unpopulated, covered)




Figure 13: 5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC Front Panel

The rear panel of the switch includes:



Note

Power supplies and fans are not included with the 5520-48SE-BASE and 5520-48SE-ACDC models. They must be ordered separately. The 5520-48SE-BASE and 5520-48SE-ACDC models support fan modules and power supply units with either front-to-back or back-to-front airflow.

1 = 3 x Fan module slots

2 = Grounding lug

3 = Serial console port

4 = Out-of-band management port (RJ-45)

5 = USB Type-A port for management or external USB flash

6 = Locator LED

7 = 2 x Power supply slots (unpopulated)




Figure 14: 5520-48SE, 5520-48SE-BASE, and 5520-48SE-ACDC Rear Panel



Port Subdivisions

On some Extreme Networks switch models, you can configure QSFP28 ports either as single ports or as multiple, partitioned ports in Switch Engine, or channelized ports in Fabric Engine. In a partitioned or channelized port, with appropriate cabling, the original physical port can accommodate multiple data lanes at lower bandwidths. Ports are not partitioned by default.

The following options are available:

Table 4: Port Partitioning

Device	Port Bandwidth	Port Partitions
5520 (all models) QSFP28	100 Gb	One QSFP28 port with one of the following: <ul style="list-style-type: none">• Two 50 Gb ports (Switch Engine only)• One 40 Gb port (default)• Four 25 Gb ports• Four 10 Gb ports Note: These ports do not support 1x100Gb

For information about configuring partitioned ports, see the *Switch Engine Command References* for your version of the Switch Engine operating system, or the *Fabric Engine Command References* for your version of the Fabric Engine operating system.



Manage Your Switch

Each switch can be flexibly managed through the cloud, the network, or the command-line interface (CLI), either remotely or locally.

Connect to Your Switch

You can use the following methods to connect to the switch.

RJ45 serial console port

Attach an RJ45 to DB9 adapter cable to the RJ45 serial console port on the switch to connect a terminal to manage the switch locally. The RJ45 serial console port is located on the rear panel of the switch.

Ethernet management port

Attach an Ethernet cable to the Ethernet management port to connect the system to an out-of-band management network to manage the switch. An Ethernet management port provides dedicated remote access to the switch using TCP/IP. The switch uses an Ethernet management port only for host operation, not for switching or routing.

Alternatively, attach an Ethernet cable directly to the Ethernet management port and a laptop to view and locally manage the switch configuration.

The Ethernet management port is located on the rear panel of the switch. It supports 10/100/1000 Mbps speeds.

Micro-USB Type B port

Attach the Micro-USB Type B end of a Micro-USB Type B to USB Type A cable to the Micro-USB Type B port on the switch, and the USB Type A end to a PC or laptop to view and locally manage the switch configuration. The Micro-USB Type B port is located on the front panel of the switch.

If the Micro-B USB console port is connected, it is selected over the RJ45 serial console port. The Micro-B USB console port disconnects when the switch is rebooted. You can re-connect the port if needed. When the Micro-B USB console is active, any messages from the switch to the client terminal are echoed to both the USB console and the RJ45 serial console port; however, no user input is accepted from the RJ45 serial console port.

For switch connection details, see [Connect to a Management Console](#) on page 94.

Configure and Operate Your Switch

The switch supports flexible configuration and operation through the following methods.

ExtremeCloud IQ or ExtremeCloud IQ Site Engine


ExtremeCloud IQ is a cloud-based enterprise network management application. It provides centralized management, monitoring, and control of network devices from the cloud. It is entirely cloud-hosted, meaning it does not require on-premises infrastructure for management.

ExtremeCloud IQ - Site Engine is an on-premises solution that extends the capabilities of ExtremeCloud IQ to manage a broader range of devices and provides additional features for comprehensive network management. ExtremeCloud IQ - Site Engine provides end-to-end network management, task automation, real-time analytics, and service assurance.

For more information, see [ExtremeCloud IQ](#).

Web-based GUI or generic command-line interface (CLI)

The command line interface (CLI) is a powerful tool for managing and configuring switches and network settings. The CLI interface can be accessed through the web-based GUI, or through Telnet, Secure Shell (SSH2), or SNMP using an SNMP manager. The web server must be enabled in the operating system on the switch in order to use the web-based GUI.



Universal Ethernet Ports

The Universal Ethernet ports, or stacking ports, are located on the front panel of the switch and are labeled U1 and U2. These ports can be used with Switch Engine as stacking ports, or as Ethernet ports with Switch Engine and Fabric Engine in non-fabric mode (Fabric Engine does not support stacking).

The Universal Ethernet ports operate as stacking ports by default. Use the `disable stacking-support` command to set the U1 and U2 ports in Ethernet mode.

When used as Ethernet ports, the U1 and U2 ports can support data rates of 100Gb, 2 x 50Gb, 1 x 40Gb, 4 x 25Gb, or 4 x 10Gb using QSFP optics.

When running Fabric Engine, the stacking ports are reserved for use by advanced features on the switch by default. For more information, see the `advanced-feature-bandwidth-reservation` Boot Flag documentation in the *Fabric Engine User Guide* for your version of the Fabric Engine operating system.

For information on switch stacking, see [Build Stacks](#) on page 53.



Secure Boot

The status of the boot image verification can be monitored in the operating system.

Switch Engine

The Trusted Delivery field in the output of the `show switch` and `show system` commands in Switch Engine displays the status of the boot image verification. For example:

```
5520-24X-EXOS.2 # sh switch
SysName:          5520-24X-EXOS
SysLocation:
SysContact:        https://www.extremenetworks.com/support/
System MAC:        00:04:96:F2:F8:00
System Type:       5520-24X-EXOS
SysHealth check:   Enabled (Normal)
Recovery Mode:     All
System Watchdog:   Enabled
Trusted Delivery:  Boot Image Verified
Current Time:      Mon Jul 27 19:35:03 2020
Timezone:          [Auto DST Disabled] GMT Offset: 0 minutes, name is UTC.
Boot Time:         Mon Jul 27 19:31:50 2020
```

Trusted delivery can only be in one of two states:

- Boot Image Verified
- Boot Image Verification Failed

Fabric Engine

The Trusted Delivery Status field in the `show sys-info` command in Fabric Engine displays the status of the boot image verification. For example:

```
U-Boot Info :
```

```
-----
Default Version      : 2.2.1.3
Alternate Version    : 2.2.1.3
Boot Version Used    : Default
Trusted Delivery Status : Boot Image Verified
```

Trusted delivery status can only be in one of two states:

- Boot Image Verified
- Boot Image Verification Failed

Secure Boot Troubleshooting

When there is a secure boot validation failure, the switch is booted to a recovery stage or halts. Contact GTAC for assistance with recovering the switch.



Fan Modules for Use with Your Switch

[Fan Modules](#) on page 34

The 5520 Series switch is designed to operate with hot-swappable internal fan modules that provide the cooling needed for the switch to operate. The switch models can include up to two redundant, hot-swappable fan modules. The fan modules in the switch chassis can be removed and replaced without special tools. The switch can continue operating while a fan is being replaced (hot-swap)

Switch fans are not responsible for cooling the power supplies; power supplies have integrated cooling fans that operate independently of the switch fan. All installed fan modules must blow air in the same direction and must match the airflow direction of the installed power supplies. Fan module slots are located on the rear panel of the switch.

Precautions Specific to Fan Modules



Warning

Be careful not to accidentally insert your fingers into the fan tray while removing it from the chassis. The fan may still be spinning at a high speed.



Caution

Disassembling any part of the power supply and fan assembly voids the warranty and regulatory certifications. There are no user-serviceable parts inside the power supply and fan assembly.



Caution

Ensure that the airflow direction of the power supply unit matches that of the installed fan tray. The power supplies and fan trays are clearly labeled with either a green arrow with an "E", or an orange arrow with an "I."



Caution

If you do not install a fan module or a power supply in a slot, you must keep the slot filler panel in place. If you run the chassis with an uncovered slot, the system will overheat.

Fan Modules

Three fan module options, with front-to-back or back-to-front airflow, are supported on the switch.

- Part number 17115 provides front-to-back airflow for switch cooling.
- Part numbers X870-FANBF and 17116 provide back-to-front airflow for switch cooling.

Fan modules are ordered separately for models 5520-24T-BASE, 5520-24T-ACDC, 5520-24X- BASE, 5520-24X-ACDC, 5520-48T-BASE, 5520-48T-ACDC, 5520-48SE-BASE, and 5520-48SE-ACDC. Fan modules are included with other models.

For information on installing or replacing a fan module, see [Replace Fan Modules](#) on page 105.

LEDs on the front panel of the switch provide information on the unit's operational status. See [Monitor the Switch](#) on page 135 for details.



Power Supplies for Use with Your Switch

[350 W AC Power Supplies](#) on page 36

[550 W AC and DC Power Supplies](#) on page 36

[715 W AC Power Supplies](#) on page 38

[1100 W AC Power Supplies](#) on page 38

[2000 W AC Power Supply](#) on page 39

The 5520 Series switch is designed to operate with hot-swappable internal power supply modules that provide all of the power needed for the switch to operate. You can remove one power supply module without interrupting the switch's operation (hot-swap). Installed power supplies can be AC, DC, or a combination of AC and DC for the 5520-24T-ACDC, 5520-24X-ACDC, 5520-48T-ACDC, and 5520-48SE-ACDC switches.

Power supplies have integrated cooling fans that operate independently of the switch fans for power supply cooling and are not responsible for cooling the switch. All installed power supplies must blow air in the same direction and must match the airflow direction of the installed fan modules. Power supply slots are located on the rear panel of the switch.

Precautions Specific to Power Supply Modules



Warning

Make sure you use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the device.



Warning

If the installation requires a different power cord than the one supplied with the device, make sure you use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the device.



Caution

Disassembling any part of the power supply and fan assembly voids the warranty and regulatory certifications. There are no user-serviceable parts inside the power supply and fan assembly.

**Caution**

Ensure that the airflow direction of the power supply unit matches that of the installed fan tray. The power supplies and fan trays are clearly labeled with either a green arrow with an "E", or an orange arrow with an "I."

**Caution**

If you do not install a fan module or a power supply in a slot, you must keep the slot filler panel in place. If you run the chassis with an uncovered slot, the system will overheat.

350 W AC Power Supplies

The 350 W AC power supplies (part numbers XN-ACPWR-350W-FB and 10953) provide front-to-back airflow and are compatible with 5520-24T, 5520-24T-BASE, 5520-24X, 5520-24X-BASE, 5520-48T, 5520-48T-BASE, 5520-48SE, and 5520-48SE-BASE switches.

The 350 W AC power supplies (part numbers XN-ACPWR-350W-BF and DPS350AB-42 A) provide back-to-front airflow and are compatible with 5520-24T-BASE, 5520-24X-BASE, 5520-48T-BASE, and 5520-48SE-BASE switches.

The 350 W AC power supply has a (C14) power inlet that requires a (C13) power cord.

**Note**

AC power input cords are not provided with AC power supplies. You can order an appropriate cord from Extreme Networks or from your local supplier. The power cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 350 W AC power supply has the status LEDs listed in [Table 5](#).

Table 5: 350 W AC Power Supply LED Status Indications

IN_OK (Green)	OUT_OK (Green or Red)	Description
Off	Off	No AC input power connection or low AC voltage
On	Off	AC input good; output disabled
On	(Red) On	AC input good; output fault
On	(Green) On	AC input good; output good

550 W AC and DC Power Supplies

The 550 W AC power supplies (part numbers XN-ACPWR-550W-FB which provide front-to-back airflow, and XN-ACPWR-550W-BF which provide back-to-front airflow) and the 550 W DC power supplies (part numbers XN-DCPWR-550W-FB which provide front-to-back airflow, and XN-DCPWR-550W-BF which provide back-to-front airflow) are

compatible with the 5520-24T-ACDC, 5520-24X-ACDC, 5520-48T-ACDC, and 5520-48SE-ACDC switches .

550 W AC Power Supplies

The 550 W AC power supply has a (C14) power inlet that requires a (C13) power cord.



Note

AC power input cords are not provided with AC power supplies. You can order an appropriate cord from Extreme Networks or from your local supplier. The power cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 550 W AC power supply has the status LEDs listed in [550 W AC and DC Power Supplies](#) on page 36.

Table 6: 550 W AC Power Supply LED Status Indications

LED	Description
Green	Output on and OK
Blinking Green	Only 12 Vsb on or PSU in cold redundant state
Amber	AC cord unplugged or AC power lost with a second power supply in parallel still with AC input power and 12 Vsb must be connected together in parallel
Blinking amber	Power supply warning events where the power supply continues to operate high temp, high power, high current, or slow fan
Amber	Power supply critical event causing a shutdown; failure, OCP, OVP, or fan fail

550 W DC Power Supplies

The 550 W DC power supply accepts the positronic plug PLAH03M400A1/AA-E1A.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 550 W DC power supply has the status LEDs listed in [550 W AC and DC Power Supplies](#) on page 36.

Table 7: 550 W DC Power Supply LED Status Indications

LED	Description
Green	Output on and OK
Off	No DC input power to all power supplies

Table 7: 550 W DC Power Supply LED Status Indications (continued)

LED	Description
Blinking Green	DC input present; only 12 Vsb on (PSU off) or PSU in cold redundant state
Amber	DC input cord unplugged or DC input power lost with a second power supply in parallel still with DC input power
Blinking amber	Power supply warning events where the power supply continues to operate high temp, high power, high current, or slow fan
Amber	Power supply critical event causing a shutdown; failure, OCP, OVP, or fan fail

715 W AC Power Supplies

The 715 W AC PSU-FB (part numbers XN-ACPWR-715W-FB and 10951) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.

The 715 W AC power supply has a (C16) power inlet that requires a (C15) power cord.



Note

AC power input cords are not provided with AC power supplies. You can order an appropriate cord from Extreme Networks or from your local supplier. The power cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 715 W AC power supply has the status LEDs listed in [Table 8](#).

Table 8: 715 W AC Power Supply LED Status Indications

IN_OK (Green)	OUT_OK (Green or Red)	Description
Off	Off	No AC input power connection or low AC voltage.
On	Off	AC input good, 54V output disabled.
On	(Red) On	AC input good, output (54V) fault.
On	(Green) On	AC input good, DC outputs in spec.

1100 W AC Power Supplies

The 1100 W AC PSU-FB (part numbers XN-ACPWR-1100W-FB and 10941) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.

The 1100 W AC power supply has a (C16) power inlet that requires a (C15) power cord.

**Note**

AC power input cords are not provided with AC power supplies. You can order an appropriate cord from Extreme Networks or from your local supplier. The power cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 1100 W AC power supply has the status LEDs listed in [Table 9](#):

Table 9: 1100 W AC Power Supply LED Status Indications

IN_OK (Green)	OUT_OK (Green or Red)	Description
Off	Off	No AC input power connection or low AC voltage.
On	Off	AC input good, 54V output disabled.
On	(Red) On	AC input good, output (54V) fault.
On	(Green) On	AC input good, DC outputs in spec.

2000 W AC Power Supply

The 2000 W AC PSU-FB (part numbers XN-ACPWR-2000W-FB and XN-ACPWR-2000W-F) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.

**Note**

In order to obtain 2000W output from this power supply, the PSU must be connected to a 200-240VAC source.

The 2000 W AC power supply has a (C16) power inlet that requires a (C15) power cord.

**Note**

AC power input cords are not provided with AC power supplies. You can order an appropriate cord from Extreme Networks or from your local supplier. The power cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

For information on installing or replacing a power supply, see [Replace Power Supplies](#) on page 100.

The 2000 W AC power supply has the status LEDs listed in [Table 10](#):

Table 10: 2000 W AC Power Supply LED Status Indications

IN_OK (Green)	OUT_OK (Green or Red)	Description
Off	Off	No AC input power connection or low AC voltage.
On	Off	AC input good, 54V output disabled.
On	(Red) On	AC input good, output (54V) fault.
On	(Green) On	AC input good, DC outputs in spec.



Expansion Modules for Use with Your Switch

[V300 Virtual Port Extender](#) on page 42

[V400 Virtual Port Extender](#) on page 48

[Versatile Interface Modules for the 5520 Series Switches](#) on page 49

The switch supports hardware accessories that expand the capabilities of the switch. Collectively, they are referred to as *expansion modules*.

- You can install a versatile interface module (VIM) in the dedicated slot in the front panel of the switch. If no module is installed, the option slot is covered by a blank panel. The VIM provides dedicated 10/25/40G high speed ports.
- You can install a virtual port extender to receive packets from extended ports and forward packets toward the upstream controlling bridge for L2/L3 processing without fully processing packets or making forwarding or filtering decisions.

Table 11: Compatibility of Expansion Modules

Module Type	Name	No. of Ports	Type of Ports
Bridge Port Extender	V300 Virtual Port Extender	up to 8	8 10/100/1000BASE-T ports and: <ul style="list-style-type: none">• 2 1000BASE-T 802.3bt Type 4 uplink ports for PoE model• 2 10Gb SFP+ uplink ports for non- PoE models
Bridge Port Extender	V400 Virtual Port Extender	up to 48	48 10/100/1000BASE-T ports and: <ul style="list-style-type: none">• 2 10Gb SFP+ uplink ports for V400-24 port models• 4 10Gb SFP+ uplink ports for V400-48 port models

Table 11: Compatibility of Expansion Modules (continued)

Module Type	Name	No. of Ports	Type of Ports
5520-VIM	5520-VIM-4X	4	10GbE SFP+ optical ports
	5520-VIM-4XE	4	10GbE SFP+ MACsec capable optical ports
	5520-VIM-4YE	4	25GbE SFP28 MACsec capable optical ports

V300 Virtual Port Extender

Bridge port extenders (BPEs) are devices that do not fully process packets, nor make forwarding or filtering decisions. Instead, they simply receive packets from extended ports and forward packets toward the upstream controlling bridge (an Switch Engine-based switch) for L2/L3 processing. This scheme, based on the IEEE 802.1BR specification, is known as extended edge switching.

The V300 Virtual Port Extender offers the following models:

- [V300-8P-2X Model](#) on page 42
- [V300-8T-2X Model](#) on page 43
- [V300-8P-2T-W Model](#) on page 44
- [V300HT-8P-2X Model](#) on page 45
- [V300HT-8T-2X Model](#) on page 46

In general, the V300 Virtual Port Extender offers the following features:

- Eight 10/100/1000BASE-T half/full duplex ports or 10/100/1000BASE-T half/full duplex PoE+ ports
- Two 10Gb SFP+ uplinks
- PoE+ power on some models
- Fixed internal power-supply (non-PoE models), fanless

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

V300-8P-2X Model

The Virtual Port Extender V300-8P-2X model offers the following features:

- Eight 10/100/1000BASE-T half/full duplex PoE+ ports
- Two 10Gb SFP+ ports
- One USB port

- One console/management port
- One DC input port

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

- 1 = DC input
- 2 = 10/100/1000BASE-T PoE+ ports
- 3 = 10Gb SFP+ ports
- 4 = USB port
- 5 = Console/Management port

The V300-8P-2X model is shipped with one 40W AC PS FRU (Model XN-ACPWR-280W).




Figure 15: V300-8P-2X Front Panel




Figure 16: V300 Virtual Port Extender Rear Panel

V300-8T-2X Model

The Virtual Port Extender V300-8T-2X model offers the following features:

- Eight 10/100/1000BASE-T half/full duplex ports
- Two 10Gb SFP+ ports
- One USB port
- One console/management port
- One DC input jack

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

The V300-8T-2X model is shipped with one 40W AC PS FRU (Model XN-ACPWR-40W).

- 1 = DC input
- 2 = 10/100/1000BASE-T ports

- 3 = 10Gb SFP+ ports
- 4 = USB port
- 5 = Console/Management port




Figure 17: V300-8T-2X Front Panel




Figure 18: V300 Virtual Port Extender Rear Panel

V300-8P-2T-W Model

The Virtual Port Extender V300-8P-2T-W model offers the following features:

- 8 10/100/1000BASE-T half duplex PoE+ ports
- 2 1000/BASE-T 802.3bt Type 4 ports
- PoE power
- Fanless

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

- 1 = 10/100/1000BASE-T PoE ports
- 2 = 1000/BASE-T 802.3bt PD up-link



Figure 19: V300-8P-2T-W Front Panel




Figure 20: V300-8P-2T-W Rear Panel

V300HT-8P-2X Model

The Virtual Port Extender V300HT-8P-2X model is a high-temperature model that offers the following features:

- Eight 10/100/1000BASE-T half/full duplex PoE+ ports
- Two 10Gb SFP+ ports
- One USB port
- One console/management port
- Two DC input ports

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

The V300HT-8P-2X model is compatible with the following power supplies: 40W AC PS FRU (Model XN-ACPWR-40W).

- Model XN-ACPWR-320W-HT - a 320W AC power supply high temperature
- Model 16807 - an IS AC-DC power supply with 240W output and DIN rail compatible



Important

The high temperature power supplies for the V300HT models require field wiring. Power supplies must be installed in accordance with local electrical codes by a licensed electrician.



Note

Power supplies for this model are sold separately.

- 1 = DC input
- 2 = 10/100/1000BASE-T PoE+ ports
- 3 = 10Gb SFP+ ports
- 4 = USB port
- 5 = Console/Management port




Figure 21: V300HT-8P-2X Front Panel



Figure 22: V300 Virtual Port Extender Rear Panel

V300HT-8T-2X Model

The Virtual Port Extender V300HT-8T-2X model is a high-temperature model that offers the following features:

- Eight 10/100/1000BASE-T half/full duplex ports
- Two 10Gb SFP+ ports
- One USB port
- One console/management port
- Two DC input ports

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

The V300HT-8T-2X model is compatible with the following power supplies:

- Model XN-ACPWR-40W-HT - a 40W AC power supply high temperature
- Model XN-ACPWR-60W-HT-DIN - a 60W AC power supply high temperature DIN rail compatible



Important

The high temperature power supplies for the V300HT models require field wiring. Power supplies must be installed in accordance with local electrical codes by a licensed electrician.



Note

Power supplies for this model are sold separately.

1 = DC input

2 = 10/100/1000BASE-T ports

- 3 = 10Gb SFP+ ports
- 4 = USB port
- 5 = Console/Management port




Figure 23: V300HT-8T-2X Front Panel




Figure 24: V300 Virtual Port Extender Rear Panel

V300 Virtual Port Extender LEDs

The V300 Virtual Port Extender front panel LEDs observe the following behavior:

Table 12: V300 Virtual Port Extender LEDs

Location	LED Indicative	Color	Status	Description
LED Per device	PWR LED (Top)	Green	Off	Power off
			Solid	Power on
		Amber	Solid	External PSU 2 fail (For non-PD model)
			Flash	External PSU 1 fail (For non-PD model)
	System LED (Bottom)	Green	Off	System off
			Solid	System on and ready
			Flash	Bootng
		Amber	Flash	Fail (Controlled by MPP)

Table 12: V300 Virtual Port Extender LEDs (continued)

Location	LED Indicative	Color	Status	Description
LED Per RJ45 Port 1-8 (PSE)	Link/Act (left)	Green	Off	No Link
			Solid	Link is established
			Flash	Link activity
	PoE (right)	Amber	Off	No PD detected
			Solid	PD is detected
LED Per RJ45 Port 9-10 (PD)	Link/Act (left)	Green	Off	No link
			Solid	Link is established
			Flash	Link activity
	PoE (right) PoE model	Amber	Off	No PSE power is provided
			Solid	PSE power is supplied

V400 Virtual Port Extender

Bridge port extenders (BPEs) are devices that do not fully process packets, nor make forwarding or filtering decisions. Instead, they simply receive packets from extended ports and forward packets toward the upstream controlling bridge (a Switch Engine-based switch) for L2/L3 processing. This scheme, based on the IEEE 802.1BR specification, is known as extended edge switching.

The V400 Virtual Port Extender offers the following features:

- 24 or 48 10/100/1000 Base-T ports that provide 10 Gbps copper connectivity.
- Two or four 1000/10G Base-X SFP+ ports that provide 10 Gbps high-density fiber connectivity.
- Serial console port.
- Front panel USB port.
- PoE+ power on some models.
- Fixed internal power-supply and fan modules.

All models include either two or four SFP+ ports on the faceplate of each base unit, which can be provisioned either as uplink or cascade ports. This gives administrators the option to create redundant links or downstream cascade ports to other V400 units. The SFP+ ports are the only ones that can be used as uplink ports in a cascading configuration.

For more information about configuring Switch Engine for use with this equipment, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

1 = 10/100/1000BASE-T ports

2 = Console/Management port

3 = 10Gb SFP+ ports

4 = USB port




Figure 25: V400 Virtual Port Extender Front Panel (48-port Model Shown)

- 1 = Grounding lug
- 2 = RPS connector (some models)
- 3 = AC power input connector




Figure 26: V400 Virtual Port Extender Rear Panel

Versatile Interface Modules for the 5520 Series Switches

You can install a versatile interface module (VIM) in a dedicated slot in the front panel of the 5520 Series switch to provide 10/25G dedicated high speed ports. The front panel of every 5520 Series switch provides one slot to install the following:

- 5520-VIM-4X versatile interface module that provides four 10-GbE (SFP+) ports.
- 5520-VIM-4XE versatile interface module that provides four 10-GbE (SFP+) ports, LRM/MACsec capable.
- 5520-VIM-4YE versatile interface module that provides four 25-GbE (SFP28) MACsec capable ports.

The 5520-VIM ports are 1-4 on the 5520-VIM faceplate.

In Fabric Engine, the 5520-VIM slot number is 2.

5520-VIMs are ordered separately. Each VIM label can be found on the bottom side of the device, as seen in the following figure:

- 1 = 5520-VIM label




Figure 27: 5520-VIM Label

Table 13: 5520-VIM Matrix

	5520-VIM-4X	5520-VIM-4XE	5520-VIM-4YE
Usable ports	4	4	4
Operational speeds	1Gbps & 10Gbps	1Gbps & 10Gbps	10Gbps & 25Gbps
PHY present	No	Yes	Yes
1000BASE-T & 10GBASE-T	10GBASE-T only	Both	10GBASE-T only
Mixed speeds	1Gbps & 10Gbps	1Gbps & 10Gbps	Mixed speeds not supported ¹
1G Auto-negotiation	Disabled	Enabled	
10G Auto-negotiation	Disabled	Disabled	Disabled
10G LRM & ZT optics	Not supported	Supported	Supported
25G Auto-negotiation			Enabled for DAC Disabled for Fiber
FEC	Not supported	Not supported	Auto-FEC enabled for DAC and Fiber ²
MACsec	Not supported	128/256bit	128/256bit

¹ - In Fabric Engine, you must set `sys vim-speed` to 10G or 25G for 5520-VIM-4YE. The default is 25G. A reboot is not necessary after setting the speed. In Switch Engine, use the `configure ports partition` command with 4x25 or 4x10 on the first VIM port.

² - FEC is enabled by default only with `autonegotiation` set to ON.

See [Versatile Interface Modules \(VIM\) Port LEDs](#) on page 138 for VIM LED details.

5520-VIM-4X Versatile Interface Module

The 5520-VIM-4X versatile interface module provides four 10-GbE (SFP+) ports.

For information about the supported optical modules, refer to the most recent version of the [Extreme Optics](#) website.




Figure 28: 5520-VIM-4X Versatile Interface Module

Table 14: Port Numbers for Ports on the 5520-VIM-4X Module

5520 Series 24-port models	5520 Series 48-port models	Fabric Engine (all models)
33-36 (Switch Engine)	57-60 on 48-port models (Switch Engine)	VIM slot number=2 Interface names=2/1-2/4

5520-VIM-4XE Versatile Interface Module

The 5520-VIM-4XE versatile interface module provides four 10-GbE (SFP+) ports, MACsec capable.

For information about the supported optical modules, refer to the most recent version of the [Extreme Optics](#) website.




Figure 29: 5520-VIM-4XE Versatile Interface Module

Table 15: Port Numbers for Ports on the 5520-VIM-4XE Module

5520 Series 24-port models	5520 Series 48-port models	Fabric Engine (all models)
33-36 (Switch Engine)	57-60 on 48-port models (Switch Engine)	VIM slot number=2 Interface names=2/1-2/4

5520-VIM-4YE Versatile Interface Module

The 5520-VIM-4YE versatile interface module provides four 25-GbE (SFP28) MACsec capable ports.



Note

In Fabric Engine, you must use the `sys vim-speed` command to set the speed to 10G or 25G for 5520-VIM-4YE. The default is 25G. A reboot is not necessary after setting the speed.

In Switch Engine, use the `configure ports partition` command with 4x25 or 4x10.

For information about the supported optical modules, refer to the most recent version of the [Extreme Optics](#) website.




Figure 30: 5520-VIM-4YE Versatile Interface Module

Table 16: Port Numbers for Ports on the 5520-VIM-4YE Module

5520 Series 24-port models	5520 Series 48-port models	Fabric Engine (all models)
33-36 (Switch Engine)	57-60 on 48-port models (Switch Engine)	VIM slot number=2 Interface names=2/1-2/4



Build Stacks

[Introduction to Stacking](#) on page 53

[Plan to Create Your Stack](#) on page 63

[Set up the Physical Stack](#) on page 68

A stack consists of a group of up to eight switches that are connected to form a ring. The stack offers the combined port capacity of the individual switches; it operates as if it were a single switch, making network administration easier.

Stacking is facilitated by the SummitStack Native-V feature – part of the Switch Engine Basic License features.

This topic describes the supported configurations for stacking switches, the considerations for planning a stack, and the steps for setting up the hardware. Read this chapter before installing the switches that will make up the stack.

Refer to the "Stacking" chapter in the *Switch Engine User Guide* for your version of the Switch Engine operating system for information about configuring a stack, maintaining the stack configuration, and troubleshooting.

Introduction to Stacking

When stacking switches, the stack operates as if it were a single switch with a single IP address and a single point of authentication. One switch – called the primary switch – is responsible for running network protocols and managing the stack. The primary runs Switch Engine software and maintains all the software tables for all the switches in the stack.

All switches in the stack, including the primary switch, are called nodes. [Figure 31](#) shows four nodes in a stack, connected to each other by SummitStack cables.

All connections between stack ports must be directly between switches. A stacking connection cannot pass through a third device, for example a Virtual Port Extender or an LRM/MACsec Adapter.




Figure 31: Switches Connected to Form a Stack

Using the SummitStack feature—part of the Switch Engine Edge/Base license—a stack can combine switches from different series, provided that every switch in the stack:

- Runs in the same partition (primary or secondary).
- Runs the same version of Switch Engine.
- Includes support for stacking.

See [Combine Switches from Different Series](#) on page 65 for information about which switch series can be combined to form a stack.

The following topics introduce you to the basic principles of stacking and provide recommendations for creating stacks.

More information to answer your questions about stacking and help you plan your configuration is available on the [Extreme Networks GTAC Knowledge Base](#).

Build Basic Stacks

A stack can be created in either of two ways:

- In *native stacking* mode, switches are connected using either designated Ethernet data ports or dedicated stacking connectors.
- In *alternate stacking* mode, switches are connected using Ethernet data ports that have been configured for stacking. These ports are located either on the switch itself or on option cards installed on either the front or the rear of the switch. Not all switches support alternate stacking mod.

The 5520 Series supports native stacking in Native-V160 stacking mode. The switch also supports Native-V200 stacking mode. The 5520 Series supports alternate stacking. See [Combine Switches from Different Series](#) on page 65 for more information about cross-stacking 5520 Series switches with other switches.

When planning and building your stack, be sure to follow port compatibility and cabling recommendations as described in this chapter.

Slot Numbers in Stacks

A switch stack can be thought of as a virtual chassis. Each switch (node) operates as if it were occupying a slot in a chassis and is controlled by the primary. The high-speed stacking links function like the backplane links of a chassis.

Each switch in the stack is assigned a “slot number” during the initial software configuration of the stack. Starting at the switch with the console connection, numbers are assigned in numerical order following the physical path of the connected stacking cables. For example, if you follow the cabling recommendations presented in [Connect the Switches to Form the Stack Ring](#) on page 68 and configure a vertical stack from the console on the switch at the top of the physical stack, the switches will be assigned slot numbers 1 through 8 from the top down.

The top half of the number blinks if the switch is the primary, and the bottom half blinks if it is the backup. If the LED is steadily lit, the switch is a standby. If the LED is off the switch is not configured as a member of a stack.

The Mode button is used to cycle through three display modes for the port LEDs. After two presses of the Mode button, the port LEDs will enter the STK Display Mode, indicated by the STK LED. STK mode is used to indicate slot presence and slot number via the first eight port LEDs.




Figure 32: Mode Button with STK LED Example

The LED is steady green if the link is OK, blinking green if traffic is present, and off if no signal is present.

A quick way to verify that the cable connections match the software configuration is to check the stack number indicator on each switch. If the slot numbers do not line up in the order you arranged the switches, this might indicate that the stacking cable setup differs from what you intended when you configured the software. In this case, reconnect the cables in the correct order and perform the software configuration again.

Primary/Backup Switch Redundancy

When your stack is operational, one switch is the primary switch, responsible for running network protocols and managing the stack.

To provide recovery in case of a break in the stack connections, you can configure redundancy by designating a backup switch to take over as primary if the primary switch fails. When you perform the initial software configuration of the stack, the “easy setup” configuration option automatically configures redundancy, with slot 1 as the primary and slot 2 as the backup. You can also configure additional switches as “primary-capable,” meaning they can become a stack primary in case the initial backup switch fails.

When assigning the primary and backup roles in mixed stacks, consider the feature scalability and the speed of each switch model. The easy setup configuration process selects primary and backup switches based on capability and speed. The following list shows the capabilities based on the ability to cross stack with other switch families. The most capable switches are shown at the top of each list:

5520 Series switches can be stacked with themselves, or with 5320 Series or 5420 Series switches.

1. 5520 Series
2. 5420 Series
3. 5320 Series

5520 Series switches can also be stacked with 5720 Series switches. When creating a mixed stack of 5520 Series and 5720 Series switches, the Primary and Backup nodes must be 5720 Series switches and they must be configured for the Native V200 stacking method.

1. 5720 Series
2. 5520 Series

When easy setup compares two switches that have the same capability, the lower slot number takes precedence. Follow the same ranking hierarchy when you plan the physical placement of the switches in the stack.

SummitStack Topologies

[Figure 33](#) presents a graphical representation of a stack and some of the terms that describe stack conditions.




Figure 33: Example of a Stack, Showing the Active Topology and the Stack Topology

A stack is the collection of all switches, or nodes, that are cabled together to form one virtual switch using the Switch Engine SummitStack feature.

The maximum cable length supported between switches depends on the types of switches in your stack, the installed option cards, and the configured stacking ports.

A stack topology is the set of contiguous nodes that are powered up and communicating with each other. In the example shown, Switch 8 is not part of the stack topology because it is not powered up.

An active topology is the set of contiguous nodes that are active. An active node is powered up, is configured for stack operation, and is communicating with the other active nodes.

Switch 5 in the example has failed, stacking is disabled on Switches 6 and 7, and Switch 8 has no power. As a result, the active topology includes Switches 1 through 4 only.

For more information about SummitStack terminology, see [SummitStack Terms](#) on page 60.

Ring Topology: Recommended for Stacking

SummitStack nodes should be connected to each other in a ring topology. In a ring topology, one link is used to connect to a node and the other link is used to connect to another node. The result forms a physical ring connection. This topology is highly recommended for normal operation.

[Figure 34](#) represents a maximal ring topology of eight active nodes.




Figure 34: Graphical Representation of a Ring Topology

Figure 35 shows what the same ring topology would look in actual practice. Each switch in the rack is connected to the switch above it and the switch below it. To complete the ring, a longer cable connects Switch 1 with Switch 8.




Figure 35: Switches Connected to Each Other in a Ring Topology

Note that, while a physical ring connection may be present, a ring active topology exists only when all nodes in the stack are active.

Daisy Chain Topology: Not Recommended for Stacking

Stackable switches can be connected in a daisy-chain topology. This is a [ring topology](#) with one of the links disconnected, inoperative, or disabled. A daisy chain can be created when a link fails or a node reboots in a ring topology, but the daisy chain topology is not recommended for normal operation.

Connect your stack nodes in a ring topology, not a daisy-chain topology, for normal operation.

In [Figure 36](#), the nodes delineated as the active topology are operating in a daisy-chain configuration, even though there is physically a ring connection in the stack.




Figure 36: Daisy Chain Topology

You might need to use a daisy chain topology while adding a new node, removing a node, or joining two stacks.

If you are using a daisy chain topology, the possibility of a dual primary condition increases. Before you create a daisy chain topology, read "Managing a Dual Primary Situation" in the *Switch Engine User Guide* for your version of the Switch Engine operating system.

SummitStack Terms

Table 17 describes the terms used for the SummitStack feature. These terms are listed in the recommended reading sequence.

Table 17: List of Stacking Terms

Term	Description
Stackable switch	An Extreme Networks switch that provides two stacking ports and can participate in a stack.
Stacking port	A physical interface of a stackable switch that is used to allow the connection of a stacking link. Stacking ports are point-to-point links that are dedicated for the purpose of forming a stack.
Native stacking	A stacking configuration in which stack members are connected using either designated Ethernet data ports or dedicated stacking connectors.
Alternate stacking	A stacking configuration in which stack members are connected using 10-Gbps Ethernet data ports that have been configured for stacking. These ports are located either on the switch itself or on option cards installed on the rear of the switch.
Stacking link	A cable that connects a stacking port of one stackable switch to a stacking port of another stackable switch, plus the stacking ports themselves.
Node	A switch that runs the Switch Engine operating system and is part of a stack. Synonymous with <i>stackable switch</i> .
Stack	A set of stackable switches and their connected stacking links made with the intentions that: (1) all switches are reachable through their common connections; (2) a single stackable switch can manage the entire stack; and (3) configurable entities such as VLANs and link trunk groups can have members on multiple stackable switches. A stack consists of all connected nodes regardless of the state of the nodes.
Stack topology	A contiguously connected set of nodes in a stack that are currently communicating with one another. All nodes that appear in the <code>show stacking</code> command display are present in the stack topology.
Stack path	A data path that is formed over the stacking links for the purpose of determining the set of nodes that are present in the stack topology and their locations in the stack. Every node is always present in a stack path whether or not stacking is enabled on the node.
Control path	A data path that is formed over the stacking links that is dedicated to carrying control traffic, such as commands to program hardware or software image data for software upgrade. A node must join the control path to fully operate in the stack. A node that is disabled for stacking does not join the control path, but does communicate over the stack path.

Table 17: List of Stacking Terms (continued)

Term	Description
Active node	A node that has joined the control path. The active node can forward the control path messages or can process them. It can also forward data traffic. Only an active node can appear as a card inserted into a slot when the <code>show slot {slot} {detail} detail</code> command is executed on the primary node of the stack.
Active topology	A contiguous set of active nodes in a stack topology plus the set of stacking links that connect them. When an active topology consists of more than one node, each node in the active topology is directly and physically connected to at least one other node in the active topology. Thus, the active topology is a set of physically contiguous active nodes within a stack topology.
Candidate node	A node that is a potential member of an active topology, or an active node that is already a member of an active topology. A candidate node may or may not be an active mode – that is, it may or may not have joined the control path.
Node role	The role that each active node plays in the stack – either primary, backup, or standby.
Primary node	The node that is elected as the primary node in the stack. The primary node runs all of the configured control protocols such as OSPF (Open Shortest Path First), RIP (Routing Information Protocol), Spanning Tree, and EAPS (Extreme Automatic Protection Switching). The primary node controls all of its own data ports as well as all data ports on the backup and standby nodes. To accomplish this, the primary node issues specific programming commands over the control path to the backup and standby nodes.
Backup node	The node assigned to take over the role of primary if the primary node fails. The primary node keeps the backup node's databases synchronized with its own databases in preparation for such an event. If and when the primary node fails, the backup node becomes the primary node and begins operating with the databases it has previously received. In this way, all other nodes in the stack can continue operating.
Standby node	A node that is prepared to become a backup node in the event that the backup node becomes the primary node. When a backup node becomes a primary node, the new primary node synchronizes all of its databases to the new backup node. When a node operates in a standby role, most databases are not synchronized – except those few that directly relate to hardware programming.

Table 17: List of Stacking Terms (continued)

Term	Description
Acquired node	<p>A standby or backup node that is acquired by a primary node. This means that the primary node has used its databases to program the hardware of the standby or backup node. The standby or backup node has acted as a hardware programming proxy, accepting the instructions of the primary node to do so.</p> <p>An acquired backup node maintains the databases needed to reflect why the hardware is programmed as it is. However, a standby node does not. An acquired node can be re-acquired (without a reboot) by the backup node only when the backup node becomes the primary node, and only when both the backup and standby nodes were already acquired by the same primary node at the time of its failure.</p>
Data ports	The set of ports on a stackable switch that are available for connection to your data networks. Such ports can be members of a user-configured VLAN or trunk group. They can be used for Layer 2 and 3 forwarding of user data traffic, for mirroring, or other features you can configure. Data ports are different from stacking ports.
Failover	<p>The process of changing the backup node to the primary node when the original primary node has failed.</p> <p>When a primary node fails, if a backup node is present, and if that node has completed its initial synchronization with the primary node, then the backup node assumes the role of primary node. The standby nodes continue their operation and their data ports do not fail.</p>
Hitless failover	A failover in which all data ports in the stack, except those of the failing primary node, continue normal operation when the primary node fails.
Node address	The unique MAC address that is factory-assigned to each node.
Node role election	The process that determines the role for each node. The election takes place during initial stack startup and elects one primary node and one backup node. An election also takes place after a primary node failover, when a new backup node is elected from the remaining standby nodes.
Node role election priority	A priority assigned to each node, to be used in node role election. The node with the highest node role election priority during a role election becomes the primary node. The node with the second highest node role election priority becomes the backup.
Operational node	A node that has achieved operational state as a card in a slot. The operational state can be displayed using the <code>show slot {slot} {detail} detail</code> command.
System uptime	The amount of time that has passed since the last node role election. You can display the system uptime by entering the <code>show switch {detail}</code> command on the primary node.

Table 17: List of Stacking Terms (continued)

Term	Description
Stack segment	A collection of nodes that form a stack topology. The term is useful when a stack is severed. Each severed portion of the stack is referred to as a stack segment.
Stack state	A state assigned by the stack to a node. You can display the stack state by entering the <code>show stacking</code> command.
Easy Setup	A procedure that automatically configures the essential stacking parameters on every node for initial stack deployment, and then automatically reboots the stack to put the parameters into effect. The choice to run Easy Setup is offered when you run the <code>enable stacking {node-address node-address}</code> command and the essential stacking parameters are unconfigured or inconsistent. It can also be invoked directly by running the <code>configure stacking easy-setup</code> command.

Plan to Create Your Stack

Use the information in the following topics to plan the physical makeup of your stack – switches, versatile interface modules (VIMs), and cables – and the stacking protocols you will use. Included are:

- Guidelines and other information for each switch model in your stack
- Considerations for combining different switch models in a stack
- Information about stacking cables

Enable and Disable the Stacking Support Option

The stacking-support option is enabled by default. To disable stacking support, configure the switch data ports to use the Ethernet protocol instead of the stacking protocol. Use the following command:

```
disable stacking-support
```

To enable stacking-support, use the following command:

```
enable stacking-support
```

You must enable stacking-support individually for every switch in the stack that does not have stacking support enabled. The default stacking mode is Native-V160.

Recommendations for Placing Switches for Stacked Operation

For best results in a SummitStack configuration, follow these recommendations for physically situating your equipment:

- Use the shortest possible stacking cables to connect the switches in the stack. This reduces the likelihood that the stacking cables might accidentally be damaged or disconnected.
- When possible, place all switches for the stack in the same rack or in adjacent racks. This facilitates using shorter stacking cables.
- The primary switch, or node, is the switch through which you will perform the initial stack configuration, using the console port. For simplicity and ease of connecting the stacking cables, plan to designate the top switch in a vertical physical stack as the primary switch. If switches are installed in several adjacent racks, place the primary switch at one end of the row.
- Physically locate the intended primary and backup nodes adjacent to each other, and plan to connect these nodes to each other directly so that Switch Engine application synchronization traffic is localized to a single stack link.
- On the primary node, connect the Ethernet management port to your management network.
- To provide management access to the stack in case of a failure in the primary switch, connect all switches that will participate in redundancy to your management network using the Ethernet management port on each switch.
- Use stacking cables to interconnect the stack nodes into a ring topology (see [Ring Topology: Recommended for Stacking](#) on page 57). Include only the nodes that you expect to be active in the stack.

Follow the recommendations in [Recommendations for Configuring Stacks](#) on page 64 to configure the software for your stack.

The recommended procedures for installing and interconnecting a stack are found in [Set up the Physical Stack](#) on page 68.

Recommendations for Configuring Stacks

When deploying a new stack, follow these recommendations for configuring the software:

- Plan to use the stack as if it were a single multi-slot switch. You need to decide the number and type of stackable switches in the stack and how the stack ports will be connected to the network.
- You can physically connect the stack to your networks before the nodes are configured. However, the default configuration on a switch in non-stacking mode assumes a default untagged VLAN that contains all switch ports. When first powered on, the switch acts as a Layer 2 switch, possibly resulting in network loops.
- Make sure all nodes support the SummitStack feature and are running the same Switch Engine software version. (See the *Licensing Guide* for your version of the Switch Engine operating system.) To view the Switch Engine software version on a node, restart the node and run the command:


```
show version {detail | process name | images {partition partition}
{slot slot_number} } .
```

If any node does not have the right version, install the correct version on that node. Use the same image partition on all nodes. After stacking is enabled, images can be upgraded from the stack only if the same image is selected on all nodes.

- If you intend to deploy new units that might be part of a stack in the future, turn on stacking mode during initial deployment to avoid the need for a future restart. The only disadvantages of stacking mode are the loss of QoS (quality of service) profile QP7 and the reservation of some of the packet buffer space for stacking control traffic.
- You can configure the stack by logging into the primary node or any of the other nodes.
- If the primary-capable stackable switches have different purchased license levels, you might need to configure license level restrictions on some nodes before those nodes can join the stack. See the *Switch Engine User Guide* for your version of the Switch Engine operating system for more information about managing licenses.
- If the stack supports any feature pack license (such as MPLS or Direct Attach), that feature pack license must be installed on all primary-capable nodes to support that feature and to prevent traffic interruption if a failover event occurs.
- Most stacking specific configurations are effective only after a restart. However, most non-stacking configuration commands take effect immediately and require no restart.
- A basic stack configuration can be achieved by using the Easy Setup procedure, as described in the *Switch Engine User Guide* for your version of the Switch Engine operating system.
- If EAPS, Spanning Tree, or any Layer 2 redundancy protocol is not running on the network, make sure that your network connections do not form a network loop.

Follow the recommendations in [Recommendations for Placing Switches for Stacked Operation](#) on page 64 for physically situating your equipment.

Combine Switches from Different Series

5520 Series switches can stack with themselves and support data rates of 40Gbps on ports U1 and U2 using the Native-V160 stacking mode with QSFP+ cables. High-speed 200Gb stacking is available on 5520 Series starting with Switch Engine 31.6 while using Native-V200. The two QSFP ports on the 5520 Series each provide 50Gb in both directions, resulting in 4x50Gb, or 200Gb total.

The 5520 Series can also stack with 5320 Series, 5420 Series, and 5720 Series switches.

- When stacking with 5320 Series and 5420 Series switches (beginning with Switch Engine 31.6), the 5520 Series supports data rates of 10Gbps utilizing the 5520-VIM-4X installed on the 5520 Series. Either the Native-V40 stacking mode (10G link running at HG) with SFP+ cables can be used, or the Native-V stacking mode with SFP+ cables and alternate stacking ports (10G link running at HG) can be used.

Alternate stacking ports are 35 and 36 for models 5520-24T, 5520-24W, 5520-24X, 5520-24T-ACDC-BASE, and 5520-24X-ACDC-BASE. Alternate stacking ports are 59 and 60 for models 5520-48T, 5520-48W, 5520-12MW-36W, 5520-48SE, 5520-48T-ACDC-BASE, and 5520-48SE-ACDC-BASE.

- When stacking with 5420 Series switches (beginning with Switch Engine 31.5), the 5520 Series supports data rates of 20Gbps on ports U1 and U2 using the Native-V80 stacking mode with QSFP+ to SFP-DD cables.
- When stacking with 5720 Series switches, the 5520 Series supports data rates of 50Gbps on ports U1 and U2 using the Native-V200 stacking mode with QSFP28 cables.
- 5520 Series switches cannot stack with 5320 Series Extended Temperature switches and the 5320-16P-2MXT-2X switch.

Select Stacking Cables

Stacking connections using the native stacking ports require stacking cables that are specific to the type of stacking port. These cables are available from Extreme Networks in lengths from 0.5 meter to 40 kilometers.



Note

For the most recent information about available cables, contact your Extreme Networks sales representative or refer to the [Extreme Optics](#) website.



Caution

Use of non-recommended cables or optics could cause stack instability.

Use the Extreme Stacking Tool

The Extreme Stacking Tool provides an easy way to plan your stack. As you select various switches and stacking modes, the tool shows you:

- What switch models can be stacked together and which cannot.
- Statistics showing the routing options that are available with every stack combination.
- Recommendations about which switches should be the primary and backup nodes.
- Information about the supported versions of Switch Engine for every combination.

To use the Stacking Tool, follow these steps.

1. Open the Stacking Tool (<https://stackingtool.extremenetworks.com/StackingTool/>) in a web browser.



Note

The Stacking Tool is also available in the Support Tools section of the Extreme Portal.

2. Find a switch model in the **Switches** column.

Each switch model is represented by a rectangle, as shown in the example in the following figure. Each switch model is represented by a rectangle, as shown in the

example in the following figure. In this example, stacking ports are represented by U1 and U2 on the right side.




Figure 37: 5520 Switches Shown in the Stacking Tool



Tip

Select a rectangle to display more information about the switch model and the VIMs (if any) that it can use for stacking.

3. Drag the rectangle to the first slot in the Stack column in the middle of the page.

To the right of the Stack column, the tool displays statistics about available routes, supported software versions, and primary/backup recommendations.



Tip

If you do not see statistics and other information, select the arrow (> symbol) to the immediate right of the Stack column.

4. Use the tool in any of the following ways:
 - Select other switches and drag them to the slots in the stacking column.
 - For any switch in the stack, select the U1 and U2 symbols to choose stacking modes – for example, Native-V and Native-V80.
 - To remove a switch from the stack, drag it away from the stacking column.

Whenever you add or remove a switch from the stack, the statistics and recommendations update automatically.

In addition to statistics and recommendations, colors in the display show whether the selected switches and stacking modes are compatible.

Table 18: Colors in the Stacking Tool Display

Color	Meaning
Green	Compatible and preferred
Blue	Compatible
Yellow	Incompatible with the selected primary node
Red	Incompatible

Set up the Physical Stack

After you have installed the individual switches (see [Install Your Switch](#) on page 86), follow these steps to create the physical stack.

1. Connect the switches that will form the stack. See [Connect the Switches to Form the Stack Ring](#) on page 68.
2. Connect the switches to your management network. See [Connect Your Stack to the Management Network](#) on page 71.

After setting up and connecting the switches, perform software configuration for the stack. See "Configuring a New Stack" in the *Switch Engine User Guide* for your version of the Switch Engine operating system.

Connect the Switches to Form the Stack Ring

After you have installed the individual switches, connect them together using the stacking cables.

The examples in this section show cable connections and the recommended order for connecting ports to facilitate the easy setup configuration.

In general, it is best to connect Stack Port 2 on one switch to Stack Port 1 on the switch with the next higher slot number. Although you can connect the switches in any order, connecting them as shown in these examples will produce better predictability and easier software configuration.

All connections between stack ports must be directly between switches. A stacking connection cannot pass through a third device, for example a Virtual Port Extender or an LRM/MACsec Adapter.

It is essential to create an unbroken data path through all the switches in the stack.

Examples of Valid Stacking Configurations

The examples in the following sections show various physical stacking arrangements: all switches in a single rack, switches in two adjacent racks, and switches at the tops of several racks in a row.

Example: Basic Stack with Four Switches

This example shows a stack of four switches in a single rack.

The slot numbers presume a console connection to the switch at the top of the physical stack.

Figure 38 shows cable connections for a 4-node stack using SummitStack 40G cables to connect switches with integrated SummitStack ports.




Figure 38: SummitStack Cable Connections Using Four Switches with Integrated SummitStack Ports

Table 19 lists the recommended order for connecting the stacking ports in this example.

Table 19: Basic Stack with Four Switches: Connections

Connect this slot and port To this slot and port	
Slot 1	Stack Port 2	Slot 2	Stack Port 1
Slot 2	Stack Port 2	Slot 3	Stack Port 1
Slot 3	Stack Port 2	Slot 4	Stack Port 1
Slot 4	Stack Port 2	Slot 1	Stack Port 1

Example: Basic Stack with Eight Switches

Figure 39 shows cable connections for an 8-node stack using SummitStack 40G cables to connect switches with integrated SummitStack ports.




Figure 39: SummitStack Cable Connections Using Eight Switches with Integrated SummitStack Ports

Table 20 lists the recommended order for connecting the stacking ports in this example.

Table 20: Basic Stack with Eight Switches: Connections

Connect this slot and port To this slot and port	
Slot 1	Stack Port 2	Slot 2	Stack Port 1
Slot 2	Stack Port 2	Slot 3	Stack Port 1
Slot 3	Stack Port 2	Slot 4	Stack Port 1
Slot 4	Stack Port 2	Slot 5	Stack Port 1
Slot 5	Stack Port 2	Slot 6	Stack Port 1
Slot 6	Stack Port 2	Slot 7	Stack Port 1
Slot 7	Stack Port 2	Slot 8	Stack Port 1
Slot 8	Stack Port 2	Slot 1	Stack Port 1

Example: Stacked Switches across Several Racks

Figure 40 shows five switches installed at the tops of five adjacent racks. To accommodate the shortest possible cables, immediately adjacent switches are not always connected together. Port 2 on one switch is connected to Port 1 on the next connected switch. If the easy setup feature is used to configure the stack parameters, the assigned slot numbers will be as shown in the figure.




Figure 40: Top-of-Rack Stack Installation

Table 21 lists the recommended order for connecting the stacking ports in this example.

Table 21: Stacked Switches across Several Racks: Connections

Connect this slot and port To this slot and port		
Slot 1	Rack A	Port 2	Slot 2	Rack B	Port 1
Slot 2	Rack B	Port 2	Slot 3	Rack D	Port 1
Slot 3	Rack D	Port 2	Slot 4	Rack E	Port 1
Slot 4	Rack E	Port 2	Slot 5	Rack C	Port 1
Slot 5	Rack C	Port 2	Slot 1	(Rack A	Port 1

Connect Your Stack to the Management Network

Before you can configure Switch Engine for a new stack, your management console must be connected to at least one switch in the stack.

Connect your management console to a serial console port or the Ethernet management console port on the switch that will become the stack primary node. If you plan to configure redundancy, connect to the console ports of all switches in the stack that will be primary-capable.

If you followed the cabling examples in [Connect the Switches to Form the Stack Ring](#) on page 68, and if you use the Easy Setup configuration procedure, only slots 1 and 2 can become the primary node. However, you can connect all switch management ports in the stack if you choose to do so. There is an alternate IP address configuration that will enable you to log in directly to each switch in the stack through its Ethernet management port.

See the *Switch Engine User's Guide* for your version of Switch Engine for instructions to perform the software configuration for your stack.



Site Preparation

[Plan Your Site](#) on page 72

[Operating Environment Requirements](#) on page 73

[Rack Specifications and Recommendations](#) on page 76

[Evaluate and Meet Cable Requirements](#) on page 78

[Meet Power Requirements](#) on page 82

By carefully planning your site, you can maximize the performance of your existing network and ensure that it is ready to migrate to future networking technologies.

The information in this chapter is intended for the system administrator, network equipment technician, network manager, or facilities manager responsible for installing and managing the network hardware. The chapter assumes a working knowledge of local area network (LAN) operations, and a familiarity with communications protocols that are used on interconnected LANs.

Only qualified service personnel should install, maintain, or remove a switch, chassis, or its components. Qualified service personnel have had appropriate technical training and experience that is necessary to be aware of the hazards to which they are exposed when performing a task and of measures to minimize the danger to themselves or other people.



Note

Before installing or removing any components of the system, and before carrying out any maintenance procedures, read the safety information in the [Technical Specifications](#) on page 139 topic.

Plan Your Site

To install your equipment successfully, you should plan the site carefully. The site planning process has three major parts:

1. Meeting site requirements.

The physical installation site must meet the following requirements for a safe and successful installation:

- Building and electrical code requirements
- Environmental, safety, and thermal requirements for the equipment you plan to install
- Equipment rack requirements

2. Evaluating and meeting cable requirements.

After examining your physical site and verifying that all environment requirements are met, evaluate and compare your existing cable plant with the requirements of the Extreme Networks equipment to determine if you need to install new cables.

3. Meeting power requirements.

To run your equipment safely, you must meet the specific power requirements for each switch and external power supply unit installed in the system.

For power specifications of the switches, see the specific switch listings in [Technical Specifications](#) on page 139.

Operating Environment Requirements

Verify that your site meets all environmental and safety requirements.

Virtually all areas of the United States are regulated by building codes and standards. During the early planning stages of installing or modifying your network, it is important that you develop a thorough understanding of the regulations that pertain to your location and industry.

Meet Building and Electrical Codes

Building and electrical codes vary depending on your location. Comply with all code specifications when planning your site and installing cable. This section lists resources for obtaining additional information.

For information about major building codes, consult the following organization:

International Code Council (ICC)
5203 Leesburg Pike
Falls Church, VA 22041 USA
www.iccsafe.org

The organizations listed in [Table 22](#) are authorities on electrical codes.

Table 22: Authorities on Electrical Codes

Organization	Address	Web Site URL
National Electrical Code (NEC) Classification (USA only) Recognized authority on safe electrical wiring. Federal, state, and local governments use NEC standards to establish their own laws, ordinances, and codes on wiring specifications. The NEC classification is published by the National Fire Protection Association (NFPA).	NFPA 1 Batterymarch Park Quincy, MA 02169 USA	www.nfpa.org/
Underwriters' Laboratory (UL) Independent research and testing laboratory. UL evaluates the performance and capability of electrical wiring and equipment to determine whether they meet certain safety standards when properly used. Acceptance is usually indicated by the words "UL Approved" or "UL Listed."	UL 333 Pfingsten Road Northbrook, IL 60062 USA	www.ul.com
National Electrical Manufacturing Association (NEMA) (USA only) Organization of electrical product manufacturers. Members develop consensus standards for cables, wiring, and electrical components.	NEMA 1300 N. 17th Street Rosslyn, VA 22209 USA	www.nema.org
Electronic Components Industry Association (ECIA) Trade association that develops technical standards, disseminates marketing data, and maintains contact with government agencies in matters relating to the electronics industry.	ECIA 111 Alderman Drive Suite 400 Alpharetta, GA 30005 USA	www.ecianow.org
Federal Communications Commission (FCC) (USA only) Commission that regulates all interstate and foreign electrical communication systems that originate in the United States according to the Communications Act of 1934. The FCC regulates all U.S. telephone and cable systems.	FCC 445 12th Street S.W. Washington, DC 20554 USA	www.fcc.gov

Set Up the Wiring Closet

Be aware of the following recommendations for your wiring closet:

- Make sure that your system is easily accessible for installation and service. See [Rack Specifications and Recommendations](#) on page 76 for more information.
- Use appropriate AC or DC power, power distribution, and grounding for your specific installation.

- Use a vinyl floor covering in your wiring closet. (Concrete floors accumulate dust, and carpets can cause static electricity.)
- Prevent unauthorized access to wiring closets by providing door locks. Install the equipment in a secured, enclosed, and restricted access location, ensuring that only qualified service personnel have access to the equipment.
- Provide adequate overhead lighting for easy maintenance.
- Be sure that each wiring closet has a suitable ground. All equipment racks and equipment installed in the closet should be grounded.
- Be sure that all system environmental requirements are met, such as ambient temperature and humidity.

**Note**

Consult an electrical contractor for commercial building and wiring specifications.

Control the Temperature

Extreme Networks equipment generates a significant amount of heat. It is essential that you provide a temperature-controlled environment for both performance and safety.

Install the equipment only in a temperature- and humidity-controlled indoor area that is free of airborne materials that can conduct electricity. Too much humidity can cause a fire. Too little humidity can produce electrical shock and fire.

Observe these additional thermal recommendations for the location where you plan to install your equipment:

- Ensure that the ventilation in the wiring closet is adequate to maintain a temperature below the maximum operating temperature for the equipment.
- Install a reliable air conditioning and ventilation system.
- Keep the ventilation in the wiring closet running during non-business hours; otherwise, the equipment can overheat.
- Maintain a storage temperature between -40°C (-40°F) and 70°C (158°F).

[Table 23](#) summarizes the behavior of Extreme Networks switches when they experience high operating temperatures.

Safeguards are built into all Extreme Networks switches and power supply units to minimize the risk of fire.

Table 23: Thermal Shutdown and Restart Behavior

Switch Model(s)	Behavior
All switches	<p>When internal system temperatures exceed the thermal shutdown temperature limit (typically about 20°C higher than normal system operating temperatures), the system's power supplies are turned off and the switch shuts down. The system remains in the OFF state until the system has sufficient time to cool and the internal thermal sensor measures a temperature lower than the maximum specified ambient temperature, at which time the system restarts automatically.</p> <p>Alternately, you can restart the system by removing and then restoring all line power to the system. The internal sensor must still measure a system temperature that is lower than the maximum specified ambient temperature, so recovery might not be immediate.</p>

Control the Humidity Level

To maximize equipment life, keep operating humidity between 50% and 70% relative humidity (non-condensing) during typical operation.

The equipment can operate between 5% and 95% relative humidity (non-condensing) for short intervals.

Protect Your System from ESD (Electrostatic Discharge)

Your system must be protected from static electricity or ESD. Take the following measures to ensure optimum system performance:

- Remove materials that can cause electrostatic generation (such as synthetic resins) from the wiring closet.

Check the appropriateness of floor mats and flooring.

- Connect metal chassis, conduit, and other metals to ground using dedicated grounding lines.
- Use electrostatically safe equipment.

If you are working with pluggable interface modules, wear an ESD-preventive wrist strap and connect the metal end to a grounded equipment rack or other source of ground.

Rack Specifications and Recommendations

Racks should conform to conventional standards.

In the United States, use EIA Standard RS-310C: Racks, Panels, and Associated Equipment. In countries other than the United States, use IEC Standard 297. In addition,

verify that your rack meets the basic mechanical, space, and earthquake requirements that are described in this section.

Mechanical Recommendations for the Rack

Use equipment racks that meet the following mechanical recommendations:

- Use an open style, 19-inch rack to facilitate easy maintenance and to provide proper ventilation.
- Use a rack made of steel or aluminum.
- The rack should use the universal mounting rail hole pattern that is identified in IEC Standard 297.
- The rack should have designated earth grounding connections (typically on the base).
- The rack must meet earthquake safety requirements equal to that of the installed chassis.
- The mounting holes should be flush with the rails to accommodate the chassis.
- The rack should support approximately 270 kg (600 lb).

Ground the Rack

The rack must be properly grounded.

Use a rack grounding kit and a ground conductor that is carried back to earth or to another suitable building ground.

At a minimum, follow these guidelines to ground equipment racks to the earth ground:

- CAD weld appropriate wire terminals to building I-beams or earth ground rods.
- For a DC-powered switch, use a minimum 6 AWG stranded copper wire for grounding.

AC-powered switches do not need separate chassis grounding.

- Position the earth ground as close to the equipment rack as possible to maintain the shortest wiring distance possible.
- Use a ground impedance tester or micro-ohm meter to test the quality of earth ground connection at the chassis. This will ensure good grounding between the chassis, rack, and earth ground.



Note

Because building codes vary worldwide, consult an electrical contractor to ensure proper equipment grounding for your specific installation.

Provide Adequate Space for the Rack

Provide enough space in front of and behind the switch so that you can service it easily.

Allow a minimum of 48 inches (122 cm) in front of the rack and 30 inches (76 cm) behind the rack. When using a relay (two-post) rack, provide a minimum of 24 inches (61 cm) of space behind the mounted equipment. Extra room on each side is optional.

**Warning**

Extreme Networks switches do not have a switch for turning power to the unit on and off. For systems using an AC power supply, power to the switch is disconnected by removing the wall plug from the electrical outlet.

Be sure that cables and other equipment do not block the switch's air intake or outflow.

Depending on other conditions in the equipment room, it may be possible to install the switches closer to each other; consult your Extreme Networks Customer Support representative for guidance.

Secure the Rack

The rack should be attached to the wiring closet floor with 9.5 mm (3/8 in) lag screws or equivalent hardware. The floor under the rack should be level within 5 mm (3/16 in). Use a floor-leveling cement compound if necessary or bolt the racks to the floor as shown.




Figure 41: Properly Secured Rack

Brace open equipment racks if the channel thickness is less than 6.4 mm (1/4 in).

Evaluate and Meet Cable Requirements

Use professional consultants for site planning and cabling.

The Building Industry Consulting Service International (BICSI) Registered Communications Distribution Designer (RCDD), which is globally recognized as a standard in site planning and cabling, can be used.

For information, visit www.bicsi.org.

Label Cables and Keep Accurate Records

A reliable cable labeling system is essential when planning and installing a network.

Keeping accurate records helps you to:

- Relocate devices easily.
- Make changes quickly.
- Isolate faults in the distribution system.
- Locate the opposite end of any cable.
- Know the types of network devices that your cabling infrastructure can support.

Follow these guidelines when setting up a cable labeling system suitable for your installation:

- Identify cables by securely attaching labels to all cable ends.
- Assign a unique block of sequential numbers to the group of cables that run between each pair of wiring closets.
- Assign a unique identification number to each equipment rack.
- Identify all wiring closets by labeling the front panel of your Extreme Networks equipment and other hardware.
- Keep accurate and current cable identification records.
- Post records near each equipment rack. For each cable drop, include information about the cable source, destination, and jumper location.

Install Cable

When you connect cable to your network equipment, keep the following things in mind.

- Examine cable for cuts, bends, and nicks.
- Support cable using a cable manager that is mounted above connectors to avoid unnecessary weight on the cable bundles.
- Use cable managers to route cable bundles to the left and right of the network equipment to maximize accessibility to the connectors.
- Provide enough slack, approximately 5 to 7.5 cm (2 to 3 in), to provide proper strain relief as shown in [Figure 42](#) on page 80.
- Bundle cable using hook-and-loop straps to avoid injuring cables.
- If you build your own cable, be sure that connectors are properly crimped.
- When installing a patch panel using twisted pair wiring, untwist no more than 2.5 cm (1 in) of the cable to avoid radio frequency (RF) interference.
- Discharge the RJ45 Ethernet cable before plugging it into a port on the switch.



Caution

Unshielded twisted pair (UTP) cable can build up electrostatic charges when being pulled into a new installation. Before connecting any category 5 UTP cable to the switch, discharge ESD from the cable by plugging the RJ45 connector into a LAN static discharge device or use an equivalent method.

- Use plenum-rated cable when it is necessary for safety and fire rating requirements. Consult your local building codes to determine when it is appropriate to use plenum-rated cable, or refer to IEC standard 850.
- Keep all ports and connectors free of dust.




Figure 42: Properly Installed and Bundled Cable

1 = Ensure adequate slack and bend radius

Handle Fiber Optic Cable

Fiber optic cable must be handled carefully during installation.

Every cable has a minimum bend radius, and fibers will be damaged if the cables are bent too sharply. It is also important not to stretch the cable during installation. Ensure that the bend radius for fiber optic cables is equal to at least 5 cm (2 in) for each 90-degree turn as shown in [Figure 43](#).



Note

Kinks and sharp bends can destroy or impair the cable's ability to convey light pulses accurately from one end of the cable to the other. Use care in dressing the optical fiber cables: provide satisfactory strain relief to support the cable and maintain an adequate bend radius at all cable turns, particularly where the cable connects to the I/O module.




Figure 43: Bend Radius for Fiber Optic Cable

1 = Minimum 5 cm (2 in) radius in 90° bend

Cable Distances and Types

Refer to the [Extreme Optics](#) website for descriptions of optics and cables, as well as a complete list of supported cable lengths, and a list of the cable types that are compatible with your equipment.


Use RJ45 Connector Jackets

Use RJ45 cable with connector jackets that are flush with the connector or that have connectors with a no-snag feature.

Using cable with jackets that are wider than the connectors can cause:

- Connectors that are not properly aligned with the port.
- Crowded cable installation, which can cause connectors to pop out of the port.

[Figure 44](#) shows examples of recommended and non-recommended connector jacket types.



SPQ_001

Figure 44: RJ45 Connector Jacket Types

Prevent Radio Frequency Interference (RFI)

If you use UTP cabling in an installation, take precautions to avoid radio frequency (RF) interference.

RF interference can cause degradation of signal quality, and, in an Ethernet network environment, can cause excessive collisions, loss of link status, or other physical layer problems that can lead to poor performance or loss of communication.

To prevent RF interference, avoid the following situations:

- Attaching UTP cable to AC power cables
- Routing UTP cable near antennas, such as a ham radio antenna
- Routing UTP cable near equipment that could exhibit RF interference, such as ARC welding equipment
- Routing UTP cable near electrical motors that contain coils
- Routing UTP cable near air conditioner units
- Routing UTP cable near electrical transformers

In areas or applications where these situations cannot be avoided, use fiber optic cabling or shielded twisted pair cabling.

Meet Power Requirements

Observe the following requirements and precautions for powering your hardware.

Requirements for PoE Devices

When connecting PoE devices to a PoE switch, all connections between the PoE device and the switch must remain within the same building and use a low-voltage power distribution system per IEEE 802.3af.

Power Supply Requirements

Follow these recommendations when you plan power supply connections for your equipment:

- Place the equipment in an area that accommodates the power consumption and component heat dissipation specifications.
- Be sure that your power supply meets the site DC power or AC power requirements of the network equipment.
- When you connect power to installed equipment, do not make this connection through an extension cord or power strip.
- If your switch includes more than one power supply, connect each power supply to a different, independent power source.

If a power source fails, it will affect only the switch power supply to which it is connected. If all switch power supplies are connected to a single power source, the entire switch is vulnerable to a power source failure.

- In regions that are susceptible to electrical storms, the best practice is to plug your system into a surge suppressor.

For detailed power specifications for your equipment, see [Technical Specifications](#) on page 139.

Power Cord Requirements

Most Extreme Networks switches do not ship with power cords. Visit www.extremenetworks.com/product/powercords/ for information on selecting and purchasing the correct power cords for use with specific Extreme Networks equipment. The web page provides specifications for power cords in each country so that you can purchase cords locally.

AC power cords must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

UPS (Uninterruptible Power Supply) Requirements

A UPS (uninterruptible power supply) is a device that sits between a power supply (such as a wall outlet) and a device (such as a switch) to prevent outages, sags, surges, and bad harmonics from adversely affecting the performance of the device.

A UPS traditionally can perform the following functions:

- Absorb relatively small power surges.
- Smooth out noisy power sources.
- Continue to provide power to equipment during line sags.
- Provide power for a period of time after a blackout has occurred.

In addition, some UPS devices or UPS-plus-software combinations provide the following functions:

- Automatically shut down equipment during long power outages.
- Monitor and log power supply status.
- Display the voltage (current draw) of the equipment.
- Restart equipment after a long power outage.
- Display the voltage currently on the line.
- Provide alarms on certain error conditions.
- Provide short-circuit protection.

Select a UPS

To determine UPS requirements for your switch, answer these questions:

- What are the amperage requirements?
- What is the longest potential time period that the UPS would be required to supply backup power?
- Where will the UPS be installed?
- What is the maximum transition time that the installation will allow? (See [Provide a Suitable UPS Transition Time](#) on page 84.)

**Note**

Use a UPS that provides online protection.

Calculate Volt-Amperage Requirements

To determine the size of UPS that you need:

1. Locate the voltage and amperage requirements for each piece of equipment.

These numbers are usually found on a sticker on the back or bottom of your equipment.

2. Multiply the numbers together to get Volt-Amperes (VA):

$$\text{VA} = \text{Volts} \times \text{Amperes}$$

3. Add the VA from all the pieces of equipment together to find the total VA requirement.

To determine the minimum volt-amperage requirements for your UPS, add 30% to the total.

Provide a Suitable UPS Transition Time

UPS transition time is the time required for the UPS to change from providing AC power derived from the utility (or mains) supply to providing AC power derived from the battery backup. UPS transition time is sometimes called *UPS transfer time*.

UPS transition times vary between UPS models and implementations, but shorter transition times are preferred. For Extreme Networks stacking products, a UPS transition time of 20 milliseconds or less ensures optimum performance and minimizes service interruptions.

For high-availability and fault-tolerant installations in which the switches use redundant power supply units (PSUs), ensure that each PSU in a switch is connected to a different UPS and that each UPS is powered by an independent AC supply. This will prevent service interruptions when a power source is lost, or when a UPS unit fails. (Note that a single, appropriately sized UPS can power PSUs in multiple switches. The recommendation is simply that for any given switch, the two PSUs should be connected to different UPS units.)

Follow Applicable Industry Standards

Always follow applicable industry standards.

For more information, see the following ANSI/TIA/EIA standards:

- ANSI/TIA/EIA-568-A—the six subsystems of a structured cabling system
- ANSI/TIA/EIA-569-A—design considerations
- ANSI/TIA/EIA-606—cabling system administration
- ANSI/TIA/EIA-607—commercial building grounding and bonding requirements

You can access these standards at: or .



Install Your Switch

[Safety Considerations for Installation](#) on page 87
[What You Will Need for the Installation](#) on page 87
[Attach the Switch to a Rack or Cabinet](#) on page 88
[Install Expansion Modules](#) on page 91
[Install Optional Components](#) on page 91
[Install Internal Power Supplies](#) on page 91
[Connect Network Interface Cables](#) on page 92
[Turn on the Switch](#) on page 92

Before you attempt to install or remove an Extreme Networks switch, read the precautions in [Safety Considerations for Installation](#) on page 87.

Extreme Networks switches fit into standard 19-inch equipment racks.

A four-post rack-mounting kit is provided with the switch. A two-post kit can be ordered separately.

The installation process includes the following tasks:

1. Prepare to install the switch. See [What You Will Need for the Installation](#) on page 87.
2. Install the switch in the rack. See [Attach the Switch to a Rack or Cabinet](#) on page 88.
3. Install expansion modules. See [Install Expansion Modules](#) on page 91.
4. Install optional components: optical transceivers and cables. See the instructions in [Install Optional Components](#) on page 91.
5. Install one or two power supplies. See [Install Internal Power Supplies](#) on page 91.



Note

Be aware of whether the power supply you are installing is AC-powered or a DC-powered. The installation instructions are different depending upon what type of power is used.

6. Connect network interface cables. See [Connect Network Interface Cables](#) on page 92.
7. Power up the switch. See [Turn on the Switch](#) on page 92.
8. Perform initial network connection and configuration. See [Activate and Verify the Switch](#) on page 94.

Safety Considerations for Installation

Read the information in this chapter thoroughly before you attempt to install or remove an Extreme Networks switch.

Ensure that proper ESD (electrostatic discharge) controls are in use before switch maintenance is performed. This includes but is not limited to wrist straps that are grounded to the switch housing and earth grounds.



Warning

Connect the chassis ground wire **before** you connect any power cables. Disconnect the ground wire **after** you disconnect all power cables.

Take care to load the equipment rack so that it is not top-heavy. Start installing equipment at the bottom of the rack and work up.

Do not cover vents that would restrict airflow.



Note

See [Safety and Regulatory Information](#) for additional safety and regulatory information. See [Technical Specifications](#) on page 139 for additional information regarding regulatory compliance certifications.

What You Will Need for the Installation

Ensure that you have followed the guidance in [Site Preparation](#) on page 72, and ensure that you have the appropriate people and tools on hand.

Installing Extreme Networks switches is easiest when there are two people to maneuver the switch and attach mounting hardware.

Provide enough space in front of and behind the switch so that you can service it easily. Ensure that a minimum of 122 cm (48 in) in front of the rack and 76 cm (30 in) behind the rack.

If your switch has internal power supplies, make sure they have the same airflow direction as the fans in the switch.

Check the *Quick Reference Guide* for your switch to see what hardware is provided in the switch packaging. Most Extreme Networks switches come with the following hardware:

- Two rack mounting brackets (ears) adaptable for either a front-mount or mid-mount installation.
- Two long mounting brackets (rails) or slider kits for mounting in a four-post installation.
- Screws for attaching mounting hardware to the switch housing.

You need the following additional tools and equipment. These are not provided with your switch:

- Rack mounting screws: eight for a four-post installation; four for other installations. The size of the screws will vary based on the rack system you are using.
- Screwdriver for securing the rack mounting screws.
- #2 Phillips magnetic screwdriver to attach bracket screws that are provided with the switch.
- AC power cord. For switches with removable AC power supplies, a separate power cord is needed for each installed power supply. The cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.
- ESD-preventive wrist strap for installing optional ports at the back of the switch.

Attach the Switch to a Rack or Cabinet

The 5520 Series switch can be attached to a standard 19-inch equipment rack in either of the following ways:

- Four-post rack, using the mounting kit provided (part number XN-4P-RMKIT-005).
- Two-post rack, using mounting brackets (part number XN-2PRMKIT-005) to attach the front or the middle of the switch to the posts (not provided). The two-post rack mounting kit can be ordered separately.



Note

Take care to load the rack so that it is not top-heavy. Start installing equipment at the bottom and work up.

Two-Post Rack Mount

You can attach the switch to a two-post rack in either of two configurations:

- Flush-mount
- Mid-mount

Use the following instructions to install the switch in a two-post rack.

1. Set a mounting bracket against the switch housing on one side of the switch.

Set the flange (ear) flush with the front of the switch, facing the front, for a flush-mount.

Set the flange (ear) toward the back of the switch, facing the rear, for a mid-mount.

The following figures illustrate how to attach the brackets for two common mounting options.

- [Figure 45](#) shows a flush-mount configuration using a short mounting bracket.
- [Figure 46](#) shows a mid-mount configuration using a short mounting bracket.




Figure 45: Flush-Mount: Attaching Short Mounting Brackets




Figure 46: Mid-Mount: Attaching Short Mounting Brackets

2. Use the small bracket-mounting screws (provided) to secure the bracket to the switch housing.

If you are using screws other than the screws that are provided, ensure that the threaded length of the screws is within 4 to 5 cm.

3. Repeat step 1 and step 2 to attach the other bracket to the other side of the switch.
4. Secure the mounting bracket flanges to the rack, using screws that are appropriate for the rack. (Rack-mounting screws are not provided.)
5. Ground the switch if a grounding lug is present.
 - a. At one end of the wire, strip the insulation to expose 1/2 inch (12 mm) of bare wire.
 - b. Identify the grounding lug on the back of the switch.
 - c. Insert the stripped wire into the grounding lug.

- d. Tighten the retaining screw with a straight-tip torque screwdriver to 20 in-lb (2.25 N m).
- e. Connect the other end of the wire to a known reliable earth ground point at your site.

After the switch is secured to the rack or cabinet, install optional components using the instructions in [Install Optional Components](#) on page 91.

Install one or two power supplies using the instructions in [Install Internal Power Supplies](#) on page 91.

Four-Post Rack Mount

1. Attach the rack rails to both sides of the switch using the provided rack screws.
2. Attach the rack ears to the front rack posts, using the screws (rack post screws not provided).
3. Slide the rack rails into the rack ears on both sides, and adjust them to the appropriate rack depth.




Figure 47: Attaching the Side Rails

4. Attach the rack rails to the rear rack posts, using the screws (rack post screws not provided).
5. If a grounding lug is present, ground the switch.
 - a. At one end of the wire, strip the insulation to expose 1/2 inch (12 mm) of bare wire.
 - b. Identify the grounding lug on the back of the switch.
 - c. Insert the stripped wire into the grounding lug.

- d. Tighten the retaining screw with a straight-tip torque screwdriver to 20 in-lb (2.25 N m).
- e. Connect the other end of the wire to a known reliable earth ground point at your site.

After the switch is secured to the rack or cabinet, install optional components using the instructions in [Install Optional Components](#) on page 91.

Install one or two power supplies using the instructions in [Install Internal Power Supplies](#) on page 91.

Install Expansion Modules

The switch supports hardware accessories that expand the capabilities of the switch. Collectively, they are referred to as *expansion modules*. The 5520 Series supports versatile interface modules (VIMs) and virtual port extenders. For installation instructions, see [Replace Expansion Modules](#) on page 107.

Install Optional Components

After the switch is secured to the rack, install optional components.

Extreme Networks switches support the use of pluggable transceivers and cables in the SFP, SFP+, SFP28, QSFP-DD, QSFP+, and QSFP28 formats.

For a list of the optical components supported with Extreme Networks devices, see the [Extreme Optics](#) website.

Pluggable Transceiver Modules

Extreme Networks offers several optical transceiver modules for transmitting and receiving data over optical fiber rather than through electrical wires.

Optical Cables

Direct-attach copper and fiber cables provide connections between populated SFP, SFP+, SFP28, QSFP-DD, QSFP+, and QSFP28 ports.

Install Internal Power Supplies

If your switch does not come with an installed power supply, you can install one or two power supplies. All installed power supplies must blow air in the same direction and must match the airflow direction of the installed fan modules.

- Power supplies with a **red** tab provide front-to-back airflow.
- Power supplies with a **blue** tab provide back-to-front airflow.

For installation instructions, see [Replace Power Supplies](#) on page 100.

Connect Network Interface Cables

Use the appropriate type of cable to connect the ports of your switch to another switch or router.

Cable Type	Maximum Distance
CAT5E	55 meters
CAT6	55 meters
CAT6A	100 meters

Working carefully, one port at a time, do the following:

1. Verify that you have identified the correct cable for the port.
2. Use an alcohol wipe or other appropriate cleaning agent to clean the cable connectors; make sure they are free of dust, oil, and other contaminants.
3. If you are using optical fiber cable, align the transmit (Tx) and receive (Rx) connectors with the correct corresponding connectors on the switch or the I/O module.
4. Press the cable connectors into their mating connectors on the switch or I/O module until the cable connector is firmly seated.
5. Repeat the preceding steps for the remaining cables on this or other switches or I/O modules.
6. Dress and secure the cable bundle to provide appropriate strain relief and protection against bends and kinks.

Turn on the Switch

Use the following instructions to turn on the switch

**Note**

The switch does not have a power button, so connecting the power cable at both ends turns the switch on.

Connect AC Power

An AC power cord is not included with the AC power supply. You can purchase AC power cords for use in the US and Canada from Extreme Networks or from your local supplier. The cord must meet the requirements listed in [Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166.

To turn on the switch, connect one end of the power cord to the AC power input socket on the device and connect the other end to an AC power outlet.

**Note**

The grounding connection in the power receptacle and in the power cord properly ground the power supply and extend that grounding to the switch.

If the power supply LEDs do not turn green, refer to [System Status LEDs](#) on page 135 for troubleshooting information.

When the power supply LED has turned green, follow the instructions in [Activate and Verify the Switch](#) on page 94.

Connect DC Power

Use the following instructions to connect the device to a DC power source.

1. Verify that the DC circuit is de-energized.
2. Verify that the ground wire is connected to the grounding lug on the rear of the switch.

The grounding lug is identified by the international symbol for earth ground:



3. Verify that the DC power input cables are properly connected to the DC power supplies at the rear of the switch.
4. Energize the circuit.

If the power supply LEDs do not turn green, refer to [System Status LEDs](#) on page 135 for troubleshooting information.

When the power supply LED has turned green, follow the instructions in [Activate and Verify the Switch](#) on page 94.



Activate and Verify the Switch

[Connect to a Management Console](#) on page 94

[Log In for the First Time on Switch Engine](#) on page 94

[Configure the Switch's IP Address for the Management VLAN](#) on page 96

[Change the Switch OS via the Bootloader Menu](#) on page 96

[Change the Switch OS via the Startup Menu](#) on page 97

[Log In for the First Time on Fabric Engine](#) on page 97

Operating system selection and activation can be done via the following:

1. XIQ - automatically by pre-selecting the preferred switch OS
2. Bootloader menu - option to change the switch OS on initial activation only
3. Startup menu in Switch Engine CLI - post-Bootloader menu prompt

Refer to *Read Me First - Switch OS Selection for Universal Hardware* shipped with your switch, or visit <https://www.extremenetworks.com/support/switch-os-selection/> for information on changing your switch OS after initial activation.

Otherwise, use the instructions in the following topics to configure the software on the switch and prepare it for use.

Connect to a Management Console

Connect each switch's serial console interface (an RJ45 jack) to a PC or terminal. The PC or terminal serves as the *management console*, used to monitor and configure the switch.

The default communication protocol settings for the serial console interface are:

- Baud rate: 115200
- Data bits: 8
- Stop bit: 1
- Parity: None

Log In for the First Time on Switch Engine

Onboard your switch with ExtremeCloud™. Log in or create your XIQ administrator account in order to select your switch operating system with XIQ at <https://extremecloudiq.com>

Switch Engine is the default operating system. If you want to run Fabric Engine, see [Change the Switch OS via the Bootloader Menu](#) on page 96 or [Change the Switch OS via the Startup Menu](#) on page 97.

Before logging in, verify that the switch LEDs are on (solid green or blinking green) and that it is connected to a management console as described in [Connect to a Management Console](#) on page 94.

To perform the initial login and complete initial configuration tasks, follow these steps.

1. Use a terminal emulator such as PuTTY or TeraTerm, connect to the switch using the serial port connection. You can also connect to the switch via telnet or SSH.

Be sure that your serial connection is set properly:

- Baud rate: Baud rate: 115200
 - Data bits: 8
 - Stop bit: 1
2. At the management console, press **[Enter]** one or more times until you see the login prompt.
 3. At the login prompt, log in using the default user name admin.

For example:

```
login: admin
```

**Note**

For the initial password, simply press **[Enter]**.

When you have successfully logged on to the system, the command line prompt displays the system name (for example, 5520-24T-SwitchEngine#) in its prompt. You are logged in with administrator privileges, which gives you access to all switch functions.

4. Respond to the screen prompts to configure the level of security you need.

**Note**

For more information about logging in to the switch and configuring switch management access, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

5. Enter `show version`.

The switch serial number is displayed, as highlighted in the following example. Make a note of this number for future reference.

```
Transit.3 # show version
Switch : 800444-00-05 0723G-01234 Rev 5.0 BootROM:
```

Configure the switch's IP address for the management virtual LAN (VLAN) by following the steps in the [Configure the Switch's IP Address for the Management VLAN](#) on page 96.

Configure the Switch's IP Address for the Management VLAN

You can configure the switch's IP address for the management virtual LAN (VLAN).



Note

The management port is part of the mgmt VLAN. This VLAN membership cannot be changed.

Log in to the management console, connect to the switch, and follow these steps.

1. Assign a name, IP address, and default subnet mask for the VLAN as shown in the following example:

```
configure vlan vlan_name ipaddress nn.nn.nn.nn 255.255.255.0
```

Your changes take effect immediately.

2. Enter `save` to save your configuration changes so that they will be in effect after the next system reboot.



Note

For more information about saving configuration changes, see the *Switch Engine User Guide* for your version of the Switch Engine operating system.

The configuration is saved to the configuration database of the switch.

Change the Switch OS via the Bootloader Menu

Onboard your switch with ExtremeCloud™. Log in or create your XIQ administrator account in order to select your switch operating system with XIQ at <https://extremecloudiq.com>

Switch Engine is the default operating system for the Universal Hardware switch. If you take no action during the initial bootup, you can change the switch OS from the Bootloader menu on initial activation only by completing the following steps:

1. Using a terminal emulator such as PuTTY or TeraTerm, connect to the switch using the serial port connection.

Be sure that your serial connection is set properly:
 - Baud rate: Baud rate: 115200
 - Data bits: 8
 - Stop bit: 1
2. Once the switch is powered on, after seeing the "Boot Menu" screen, press the **[spacebar]** key within 30 seconds.
3. Use the **down-arrow** key to select Change the switch OS to Fabric Engine, then select **Enter**.

The switch installs Fabric Engine, then resets. Once the NOS is selected, the "Boot Menu" only waits for 3 seconds before continuing.

To change the switch OS if you take no action during the initial boot, see [Change the Switch OS via the Startup Menu](#) on page 97.

Change the Switch OS via the Startup Menu

Onboard your switch with ExtremeCloud™. Log in or create your XIQ administrator account in order to select your switch operating system with XIQ at <https://extremecloudiq.com>

Switch Engine is the default operating system for the Universal Hardware switch. If you take no action during the initial bootup, you can change the switch OS from the Startup menu on initial activation only by completing the following steps:

1. Connect to the switch via telnet, SSH, or console with a baud rate of 115200.
2. At the login prompt, log in using the default user name `admin`.

For example:

```
login: admin
```



Note

For the initial password, simply press **[Enter]**.

3. The switch prompts you to choose which switch personality you want to use:

```
This switch can alternatively run the Fabric Engine Network Operating System.
If you answer yes, all data including configurations, logs and debugs will be
cleared, except for the license activation status, Fabric Engine
will be installed, and Switch Engine will be removed.
Would you like to change the switch OS to Fabric Engine? [y/N/q]:
```

The switch installs Fabric Engine, then resets.

After resetting, your switch boots with Fabric Engine. See [Log In for the First Time on Fabric Engine](#) on page 97.

Log In for the First Time on Fabric Engine

Onboard your switch with ExtremeCloud™. Log in or create your XIQ administrator account in order to select your switch operating system with XIQ at <https://extremecloudiq.com>

Before logging in, verify that the switch LEDs are on (solid green or blinking green) and that it is connected to a management console as described in [Connect to a Management Console](#) on page 94.

To perform the initial login and complete initial configuration tasks, follow these steps.

1. Using a terminal emulator such as PuTTY or TeraTerm, connect to the switch using the serial port connection.

Be sure that your serial connection is set properly:

- Baud rate: 115200
- Data bits: 8

- Stop bit: 1
- 2. Press **[Enter]** one or more times until you see the login prompt.
- 3. At the login prompt, log in using the default user name `rwa`.

For example:

```
login: rwa
```

When prompted for the password, enter `rwa`.

When you are logged in with the role-based authentication level of `rwa`, you can configure the login and password values for the other role-based authentication levels.



Remove and Replace Components

[Remove a Switch from a Rack](#) on page 99

[Replace Power Supplies](#) on page 100

[Replace Fan Modules](#) on page 105

[Replace Expansion Modules](#) on page 107

Use the information in the following topics to remove or replace components.

Remove a Switch from a Rack

These procedures assume that you have attached the switch to the rack as described in [Attach the Switch to a Rack or Cabinet](#) on page 88.



Note

Read all of the information in this chapter thoroughly before attempting to remove a switch from a rack.

Remove a Switch from a Four-Post Rack

Use the following instructions to remove a switch from a four-post rack.

1. Disconnect the device from its power source or sources.
2. Remove all cables and transceivers.
3. To remove a device from a four-post rack, do the following:
 - a. Unsecure the device from the rack by unscrewing the thumb screws on the mounting ears.
 - b. Fully extend the device on the rails and push the disconnect latch to release the device.
 - c. Carefully slide the device out of the slider assembly and place it on a flat surface.

You can leave the slider assemblies in place. If you want to remove them, continue with the next step.

- d. On one of the slider assemblies, remove the outer rail (bracket) from the rack by removing the M5 screws.
- e. Repeat step [3.d](#) to remove the second slider assembly.

If you plan to use the device again later, store it with the mounting brackets attached.

Remove a Switch from a Two-Post Rack

Use the following instructions to remove a switch from a two-post rack.

1. Disconnect the device from its power source or sources, then disconnect the ground, if there is a ground.
2. Remove all cables and transceivers.
3. Unscrew the mounting brackets from the rack while carefully supporting the weight of the device.
4. Tilt the device so that the brackets are clear of the rack posts, and carefully lift it out of the rack.

If the device cannot be tilted (because other equipment is mounted directly above and below), remove one or two mounting brackets from the device and then slide the device out.

If you plan to use the device again later, store it with the mounting brackets attached.

Replace Power Supplies

For switches with replaceable power supplies, refer to the following information to replace the power supplies. The switches have two power supply slots. In a switch with a redundant power configuration, you can replace one power supply without powering down the switch ("hot swapping"). Most 5520 Series switches support up to two AC power supplies, but the 5520-24T-ACDC, 5520-24X-ACDC, 5520-48T-ACDC, and 5520-48SE-ACDC switches support AC, DC, or a combination of AC and DC power supplies. Power supply slots are located on the rear panel of the switch.



Caution

Power supplies that support PoE cannot be installed in switches that do not support PoE. The switch operating system prevents PoE power contribution from a power supply that is not listed for use with that particular switch model.

Images in this topic might show switches that are not identical to the ones you are using. However, the procedure for replacing a power supply is the same for all Extreme Networks switches.



Note

Read all of the information in this chapter thoroughly before attempting to replace a power supply.

Power Supply Airflow Direction Requirements

All installed power supplies must blow air in the same direction and must match the airflow direction of the installed fan modules.

- A power supply with a **red** tab provides front-to-back airflow for power supply cooling. All 5520 Series switches are available with front-to-back airflow.
- A power supply with a **blue** tab provides back-to-front airflow for power supply cooling. 5520-24T-BASE, 5520-24T-ACDC, 5520-24X-BASE, 5520-24X-ACDC,

5520-48T-BASE, 5520-48T-ACDC, 5520-48SE-BASE, and 5520-48SE-ACDC switches are available with back-to-front or front-to-back airflow.

Replace a Power Supply

5520 Series switches support the following power supplies:

- The 350 W AC power supplies (part numbers XN-ACPWR-350W-FB and 10953) provide front-to-back airflow and are compatible with 5520-24T, 5520-24T-BASE, 5520-24X, 5520-24X-BASE, 5520-48T, 5520-48T-BASE, 5520-48SE, and 5520-48SE-BASE switches.

The 350 W AC power supplies (part numbers XN-ACPWR-350W-BF and DPS350AB-42 A) provide back-to-front airflow and are compatible with 5520-24T-BASE, 5520-24X-BASE, 5520-48T-BASE, and 5520-48SE-BASE switches.

- The 550 W AC power supplies (part numbers XN-ACPWR-550W-FB which provide front-to-back airflow, and XN-ACPWR-550W-BF which provide back-to-front airflow) and the 550 W DC power supplies (part numbers XN-DCPWR-550W-FB which provide front-to-back airflow, and XN-DCPWR-550W-BF which provide back-to-front airflow) are compatible with the 5520-24T-ACDC, 5520-24X-ACDC, 5520-48T-ACDC, and 5520-48SE-ACDC switches .
- The 715 W AC PSU-FB (part numbers XN-ACPWR-715W-FB and 10951) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.
- The 1100 W AC PSU-FB (part numbers XN-ACPWR-1100W-FB and 10941) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.
- The 2000 W AC PSU-FB (part numbers XN-ACPWR-2000W-FB and XN-ACPWR-2000W-F) provide front-to-back airflow and are compatible with 5520-24W, 5520-12MW-36W, and 5520-48W switches.

Pre-Installation Requirements

You need the following tools and materials to replace a power supply:

- Thermal protective gloves
- AC power cord, if you are not re-using the cord from the removed power supply

Remove a Power Supply



Caution

Disconnect the AC power cord from the wall outlet and from the power supply before removing an AC power supply. Ensure that the DC circuit is de-energized before removing a DC power supply.

Use the following instructions to remove a power supply.

1. Attach an ESD-preventive wrist strap to your bare wrist and connect the metal end to an appropriate ground point on the rack.

**Caution**

Power supplies can become very hot during operation. Wear thermal protective gloves when you remove a power supply from an operating switch.

2. Note the orientation and the airflow direction of the installed power supply, and the location of the latching tab on the power supply.
3. Push the latching tab toward the power supply handle and pull outward on the handle to disengage the power supply internal connectors.




Figure 48: Remove a Power Supply

**Note**

If you are not installing a replacement power supply, install a cover over the unoccupied power supply bay. Unoccupied bays must always be covered to maintain proper system ventilation and EMI levels.

Replace or Install a Power Supply

Use the following instructions to replace or install a power supply.

1. Attach an ESD-preventive wrist strap to your bare wrist and connect the metal end to an appropriate ground point on the rack.
2. If necessary, remove a blank panel from the back of the switch.
3. Ensure that the orientation of the power supply is correct, and that the new power supply's airflow direction (front-to-back or back-to-front) is compatible with the installed fan modules and any other installed power supplies.
4. Carefully slide the power supply all the way into the power supply slot.




Figure 49: Install a Power Supply

5. Push the power supply in until the latch snaps into place.

Do not slam the power supply into the switch.



Note

Be sure to install a cover over any unoccupied power supply slots. Unoccupied power supply slots must always be covered to maintain proper system ventilation and EMI levels.

To install or replace a second power supply repeat this procedure.

After installing a power supply, connect the power cord to the power supply.

- If the power supply was an AC power supply, connect it to a grounded AC power outlet.



Warning

Always make sure that the source outlet is properly grounded before plugging the AC power cord into the AC power supply.

- If the power supply was a DC power supply, use the provided 2 meter DC power input cable for the DC power supply to ground the power supply and connect the power supply to the power source.



Warning

Connect the chassis ground wire before you connect any power cables.

Connect a DC Power Supply to the Source Voltage

The DC power connection at your facility must be made by a qualified electrician, following these instructions.



Warning

Always make sure that the DC circuit is de-energized before connecting or disconnecting the DC power cables on the DC power supply

**Caution**

Provide proper connection and strain relief on the DC power cables in accordance with all local and national electrical codes.

1. Verify that the DC circuit is de-energized.
2. Attach an ESD-preventive wrist strap to your bare wrist and connect the metal end to an appropriate ground point on the rack.
3. Position the DC power cable connector so that the wide, flat side is closest to the fan, as shown in [#unique_124/unique_124_Connect_42_FIG_MYK_D4L_NZB](#). The DC power cable connector can only connect to the power supply one way.




Figure 50: Connecting the DC Power Cord

4. Tighten the two thumb screws to secure the DC power connector in place.
5. The installation electrician connects the other end of the power cord to the building power system.

**Warning**

Before installing, be sure to connect the chassis ground wire before you connect any power cables.

**Warning**

Before removing, be sure to disconnect the ground wire after you disconnect all power cables

- a. Connect the ring terminal of the yellow and green ground wire to a known reliable earth ground point at your site.




Figure 51: DC Power Cable

Use the following for building the wire harness:

Cable Connector	Wire Color	
Pin 1	Yellow/Green	GRD
Pin 2	Black	-48V
Pin 3	Red	RTN

- b. Connect the ring terminal of the red RTN power cable to the positive terminal of the DC power source, and connect the ring terminal of the black -48V power cable to the negative terminal of the DC power source.
6. Repeat these steps for each power supply.

Leave the ESD strap permanently connected to the rack, so that the strap is always available when you need to handle ESD-sensitive components.

Replace Fan Modules

For switches with replaceable fan modules, refer to the following information to replace the fan modules. You can replace fan modules as needed while the switch is operating ("hot swapping"). Fan module slots are located on the rear panel of the switch.

Do not operate a chassis for more than a few minutes with a missing fan module. To ensure internal chassis air pressure is maintained and to avoid loss of traffic due to modules overheating and shutting down, leave a failed fan module installed until you have a replacement.

Images in this topic might show switches that are not identical to the ones you are using. However, the procedure for replacing a fan module is the same for all Extreme Networks switches.



Note

Read all of the information in this chapter thoroughly before attempting to replace a fan module.

Fan Airflow Direction Requirements

All installed fan modules must blow air in the same direction and must match the airflow direction of the installed power supplies. Before you begin, have the replacement fan module on hand so that you can complete the replacement promptly. The switch can overheat if left without adequate cooling for an extended time.

- A fan labeled **Air Out** provides front-to-back airflow for switch cooling. All 5520 Series switches are available with front-to-back airflow.
- A fan labeled **Air In** provides back-to-front airflow for switch cooling. 5520-24T-BASE, 5520-24T-ACDC, 5520-24X-BASE, 5520-24X-ACDC, 5520-48T-BASE, 5520-48T-ACDC, 5520-48SE-BASE, and 5520-48SE-ACDC switches are available with back-to-front or front-to-back airflow.

Replace a Fan Module

Use the following instructions to remove and replace a fan module in the switch.

Pre-Installation Requirements

You need a 1/4-inch flat-blade screwdriver to replace a fan module.



Caution

Be sure to finish the replacement procedure promptly. The switch could overheat if left without cooling for an extended period.

Remove a Fan Module

Use the following instructions to remove a fan module.

1. Completely loosen the captive retaining screws on the fan module.

On most switch models, the fan module has two retaining screws at the bottom corners of the module, as shown in [Figure 52](#).

On some switch models, the fan module has a single retaining screw at the top right corner of the module.

2. Slide the fan module out of the switch and set it aside.




Figure 52: Removing a Fan Module

Replace or Install a Fan Module

Use the following instructions to install a fan module.

1. Verify that the airflow direction on the fan module matches that of the installed power supplies and any installed fan modules.

Fan modules labeled **Air Out** provide front-to-back airflow.

Fan modules labeled **Air In** provide back-to-front airflow.

2. Carefully slide the replacement fan module into the switch.




Figure 53: Installing a Fan Module

3. Align and fully tighten the captive retaining screws.

Replace Expansion Modules

The switch supports hardware accessories that expand the capabilities of the switch. Collectively, they are referred to as *expansion modules*. The 5520 Series supports versatile interface modules (VIMs) and virtual port extenders.



Note

Read the information in this chapter thoroughly before trying to install or remove an expansion module.

Replace Versatile Interface Modules

5520 Series switches support the following versatile interface modules (VIMs):

- 5520-VIM-4X versatile interface module that provides four 10-GbE (SFP+) ports.
- 5520-VIM-4XE versatile interface module that provides four 10-GbE (SFP+) ports, LRM/MACsec capable.
- 5520-VIM-4YE versatile interface module that provides four 25-GbE (SFP28) MACsec capable ports.

You need the following tools and materials to install a VIM module:

- ESD-preventive wrist strap
- Phillips head screwdriver

Remove a VIM module

Use the following instructions to remove a VIM module.

1. Attach the ESD wrist strap to your wrist and connect the metal end to an appropriate ground point on the rack.
2. Ensure that the switch is completely powered down.

3. Remove the screws that secure the VIM module in the VIM slot using the Phillips head screwdriver.




Figure 54: VIM Module Inserted in Slot

1 = VIM module retaining screw locations

4. Slide the VIM module out of the VIM slot and set it aside.

Replace a VIM module

Use the following instructions to replace a VIM module.

1. Attach the ESD wrist strap to your wrist and connect the metal end to an appropriate ground point on the rack.
2. Ensure that the switch is completely powered down.
3. Remove the VIM cover (if necessary) by removing the screws that hold the cover plate over VIM slot, using the Phillips head screwdriver.




Figure 55: Removing a slot Cover Plate (VIM slot cover shown)

1 = VIM module retaining screw locations

4. Remove the new VIM module from its anti-static packaging.
5. Install the VIM module in the switch:
 - a. Carefully slide the VIM module into the switch.
 - b. Insert and tighten the retaining screws you previously removed, using the Phillips head screwdriver.




Figure 56: VIM Module Inserted in Slot

1 = VIM module retaining screw locations

Replace Virtual Port Extenders

5520 Series switches support the following virtual port extenders:

- V300 Virtual Port Extender
 - V300-8P-2T-W (PoE)
 - V300-8P-2X (non-PoE)
 - V300-8T-2X (non-PoE)
 - V300HT-8P-2X (non-PoE)
 - V300HT-8T-2X (non-PoE)
- V400 Virtual Port Extender
- Half-Duplex to Full-Duplex Converter (HDX/FDX Converter)

Remove a Virtual Port Extender

Use the following instructions to remove a virtual port extender.

1. Disconnect the port extender from its power source and, if applicable, from its redundant power supply.
2. Support the port extender while you remove the rack-mounting screws that hold the front mounting brackets in place against the rack posts.
3. Carefully slide the port extender out of the rack.
4. Place the port extender on a secure, flat surface. Optionally, remove the mounting brackets from the sides.
5. Optionally, install a new virtual port extender.

Remove a Half-Duplex to Full-Duplex Converter

Use the following instructions to remove a Half-Duplex to Full-Duplex converter

1. Disconnect the half-duplex ports (HD1 - HD4) from your half-duplex devices.
2. Disconnect the full-duplex ports (FD1 - FD4) from the switch.
3. Disconnect the converter from its power adapter.
 - a. Disconnect the power adapter from its AC power source.

- b. Disconnect the DC power cable from the power adapter and from the DC input socket on the side of the converter.
 - c. Remove the grounding wire from the converter.
4. If the converter is attached to a 3-slot modular shelf, loosen the cable ties and remove it from the shelf.
5. Optionally, install a new converter.

Install a V300 Virtual Port Extender

The following installation instructions are applicable to the V300-8P-2T-W (PoE) model. The V300-8P-2X, V300-8T-2X, V300HT-8P-2X, and V300HT-8T-2X models will be referred to as non-PoE models from this point on.

You need the following tools and materials to install a V300 Virtual Port Extender:

- ESD-preventive wrist strap
- M3.5 or M4 #2 Phillips screwdriver (magnetic screwdriver recommended)

The V300 Virtual Port Extender comes with two mounting brackets and screws for attaching them. Mount the equipment in a standard equipment rack, in either a front-mount or mid-mount configuration, in the same way you would mount a switch.

To install a V300 Virtual Port Extender, follow these steps:

1. Attach the mounting brackets to the sides of the port extender using four screws (included) for each bracket.
2. Align the holes in the brackets with the rack post holes.
3. Secure the port extender to each post with rack-mounting screws (not provided).
4. Connect an AC power cord to the AC power input socket on the port extender and to an AC power outlet.
5. When power is connected, verify that the SYS LED on the port extender turns green.
If the SYS LED does not turn green, verify that the power source is on and the connection was made properly.
6. Optionally, connect the port extender to a redundant power source, depending on the model.

The following mounting kits are available for non-PoE V300 models:

Table 24: V300 Mounting Kits

Kit part number	Description
XN-2P-RMTKIT-1CS-001	Single rack mount kit
XN-2P-RMTKIT-2CS-001	Dual rack mount kit
XN-DIN-MT-001	DIN Rail mount kit
XN-MTKIT-CS-001	Replacement surface mount kit
XN-PS-MT-001	PSU mount kit

For additional installation options, including non-PoE V300 Mounting Kit installation, see the following topics:

- [Install a V300 Virtual Port Extender on a Wall](#) on page 111
- [Install a V300 Virtual Port Extender Under or on a Table Surface](#) on page 114
- [Install a V300 Virtual Port Extender in a VESA Mount](#) on page 116
- [Install a V300 in a Single Rack Mount](#) on page 118
- [Install a V300 in a Dual Rack Mount](#) on page 121
- [Install a V300 in a DIN Rail Mount](#) on page 124
- [Install a V300-8P-2T-W Model in a Single or Dual Rack Mount](#) on page 127
- [Install a V300-8P-2T-W Model in a DIN Rail Mount](#) on page 128

Install a V300 Virtual Port Extender on a Wall

The following tools and materials are required to install a V300 Virtual Port Extender to a wall:

- ESD-preventive wrist strap
- M3.5 #2 Phillips screwdriver (magnetic screwdriver recommended)
- M4 #2 Phillips screwdriver (magnetic screwdriver recommended) for non-PoE models



Note

The mounting surface, item, and hardware must be able to support the extender in all environmental conditions. The mounting surface must also be flat.

Typical installation for the V300-8P-2T-W model include wall or table installations, in addition to VESA mounting.

There are several orientations for installation on a wall. To install the V300-8P-2T-W model on a wall:

1. Attach the short brackets to both sides of the extender

The orientation for wall mounting should be front panel facing down.

Two short brackets attached to the extender by 4 wood screws and 4 anchors, provided in the accessory kit.




Figure 57: V300-8P-2T-W Wall Mounting

2. Use the optional short bracket as a template and mark the holes to be used. Extreme recommends using 2 holes per short rack ear.

3. For non-PoE models, after attaching the short brackets, attach the PSUs to the PSU mounting brackets using two cable ties.






Figure 58: V300-8P/8T-2X Wall Mount with PSU

V300HT-8P-2X



V300HT-8T-2X

**Figure 59: V300HT-8P/8T-2X Wall Mount with PSU**

4. Drill the holes and attach the bracket using the provided woodscrews and anchors.
5. Connect the LAN/Ethernet cables to the extender.
6. When power is connected, verify that the SYS LED on the port extender turns green.

Install a V300 Virtual Port Extender Under or on a Table Surface

The following tools and materials are required to install a V300 Virtual Port Extender under a table:

- ESD-preventive wrist strap
- M3.5 #2 Phillips screwdriver (magnetic screwdriver recommended) for PoE model
- M4 #2 Phillips screwdriver (magnetic screwdriver recommended) for non-PoE models

Typical installation for the V300-8P-2T-W model include wall or table installations, in addition to VESA mounting.

For table surface or other flat surface installation, attach the rubber feet to the underside of the virtual port extender, then place the device to the table or flat surface:




Figure 60: Table Surface Mounting

There are several orientations for installation under a table. To install a V300-8P-2T-W model under a table:

1. Attach the short mounting brackets (included in kit) to the sides of the port extender using four screws (included) for each bracket.




Figure 61: Under Table Mounting

- For non-PoE models, after attaching short brackets and PSU bracket to the V300, attach the PSU(s) to the PSU mounting bracket using two cable ties:




Figure 62: V300-8P/8T-2X Under Table Mounting with PSU




Figure 63: V300HT-8P/8T-2X Under Table Mounting with PSU

- Secure the port extender to the underside of the table using the provided 4 wood screws and 4 anchors.
- When power is connected, verify that the SYS LED on the port extender turns green.

Install a V300 Virtual Port Extender in a VESA Mount

The following tools and materials are required to install a V300 Virtual Port Extender with a VESA mount:

- ESD-preventive wrist strap

- M4 #2 Phillips screwdriver (magnetic screwdriver recommended)

The VESA mount comes with 4 screws and should be used when mounting the V300 Virtual Port Extender to a VESA mount for 75mm x 75mm or 35mm x 75mm mounting dimensions. To install a V300 Virtual Port Extender in a VESA Mount:

1. Attach the VESA mount to the underside of the port extender using four screws (included):





Figure 64: VESA Mounting

2. For non-PoE models, after attaching the PSU bracket to the V300, attach the PSU(s) to the PSU mounting brackets using two cable ties:

V300-8P-2X



V300-8T-2X




Figure 65: V300-8P/8T-2X VESA Mounting with PSU

3. Connect the LAN/Ethernet cables to the extender.
4. When power is connected, verify that the SYS LED on the port extender turns green.

Install a V300 in a Single Rack Mount

The following tools and materials are required to install a non-PoE V300 Virtual Port Extender to a single rack mount:

- ESD-preventive wrist strap
 - M4 #2 Phillips screwdriver (magnetic screwdriver recommended)
 - XN-2P-RMTKIT-1CS-001 - Single rack mount kit
1. Remove all contents of the single rack mount kit (XN-2P-RMTKIT-1CS-001).
 2. Attach the short and long ear brackets to the V300 using the screws provided.
 3. Secure the bracket flanges to the rack using the customer-provided screws appropriate for the rack you are using.

4. After attaching the PSU bracket to the V300, attach the PSU to the PSU mounting brackets using two or four cable ties:




Figure 66: V300-8P-2X Single Rack Mounting with PSU




Figure 67: V300HT-8P/8T-2X Single Rack Mounting with PSUs

5. For a more secure attachment, attach the two PSU mounting brackets to the rack using customer-provided screws:




Figure 68: V300HT-8P/8T-2X Single Rack Mounting with DIN Rail and PSUs

6. Alternatively, the PSU can be mounted to the long rack ear using cable ties.

Install a V300 in a Dual Rack Mount

The following tools and materials are required to install a non-PoE V300 Virtual Port Extender to a dual rack mount:

- ESD-preventive wrist strap
 - M4 #2 Phillips screwdriver (magnetic screwdriver recommended)
 - XN-2P-RMTKIT-2CS-001 - Dual rack mount kit
1. Remove all contents of the dual rack mount kit (XN-2P-RMTKIT-2CS-001).
 2. Attach one short ear bracket to the outer side of each V300 using the screws provided.
 3. Attach the joint brackets to the inward side of each V300 (one with tapped screw holes facing forward, one facing rearward, using the screws provided).
 4. Attach the two joint brackets together using the screws provided.

5. After attaching the PSU bracket to the V300 using the provided screws, attach the PSU to the PSU mounting brackets using two, four, or eight cable ties:




Figure 69: V300-8T-2X Dual Rack Mounting with PSU




Figure 70: V300HT-8P/8T Dual Rack Mounting with PSUs

6. For a more secure attachment, attach the PSU mounting brackets to the rack using customer-provided screws:




Figure 71: V300HT-8P/8T Dual Rack Mounting with DIN Rail and PSUs

Install a V300 in a DIN Rail Mount

The following tools and materials are required to install a non-PoE V300 Virtual Port Extender to a DIN Rail mount:

- ESD-preventive wrist strap
- M4 #2 Phillips screwdriver (magnetic screwdriver recommended)
- XN-DIN-MT-001 - DIN Rail mount kit

For PSU XN-ACPWR-320W-HT or XN-ACPWR-40W-HT:

1. Remove all contents of the DIN Rail mount kit (XN-DIN-MT-001).
2. Attach the port extender to the DIN Rail using one DIN bracket and the screws provided.

3. Attach the PSUs to the DIN bracket using cable ties, and then attach the bracket to the DIN Rail:




Figure 72: V300HT-8P-2X DIN Rail Mount with dual XN-ACPWR-320W-HT PSUs

4. For PSU 16807, attach the port extender to the DIN Rail using one DIN bracket and the screws provided.

5. Attach the PSUs directly to the DIN rail:




Figure 73: V300HT-8P-2X DIN Rail Mount with dual 16807 PSUs

6. For XN-ACPWR-60W-HT-DIN, attach the port extender to the DIN Rail using one DIN bracket and the screws provided.

7. Attach the PSUs directly to the DIN rail:




Figure 74: V300HT-8T-2X DIN Rail Mount with dual XN-ACPWR-60W-HT-DIN PSUs

Install a V300-8P-2T-W Model in a Single or Dual Rack Mount

You need the following tools and materials to install a V300-8P-2T-W model to a rack mount:

- ESD-preventive wrist strap
- M4 #2 Phillips screwdriver (magnetic screwdriver recommended)

Typical installation for the V300-8P-2T-W model include wall or table installations, in addition to VESA mounting. In order to rack-mount this model, an accessory mounting kit is required.

To install the V300-8P-2T-W model in a single or dual rack mount kit:

1. Remove all contents of the single rack mount kit (XN-1S-RKMT-V300) or dual rack mount kit (XN-2S-RKMT-V300).
2. Attach the short mounting brackets (included) to the sides of the port extender using the four screws (included) for each bracket.




Figure 75: Single Rack Mounting




Figure 76: Dual Rack Mounting

3. Align the holes in the brackets with the rack post holes.
4. Secure the port extender to each post with rack-mounting screws (not provided).
5. Connect the LAN/Ethernet cables to the extender.
6. When power is connected, verify that the SYS LED on the port extender turns green.

Install a V300-8P-2T-W Model in a DIN Rail Mount

You need the following tools and materials to install a V300 Virtual Port Extender to a DIN Rail mount:

- ESD-preventive wrist strap
- M4 #2 Phillips screwdriver (magnetic screwdriver recommended)

There are two DIN Rail mounting options. To install a V300-8P-2T-W model in a DIN Rail Mount:

1. Remove all contents of the DIN Rail Mount Kit (XN-DIN-MT-V300).
2. For option 1, attach the DIN mounting bracket to the rear of the port extender using the two screws (included) for each bracket:




Figure 77: DIN Rail Mounting Option 1: Attach the Bracket

3. Align the DIN bracket with the DIN rail and attach the port extender:




Figure 78: DIN Rail Mounting Option 1: Secure the Port Extender

4. For option 2, attach the DIN mounting bracket to the side panel of the port extender:




Figure 79: Din Rail Mounting Option 2: Attach the Bracket

5. Align the DIN bracket with the DIN rail and attach the port extender:




Figure 80: DIN Rail Mounting Option 2: Secure the Port Extender

6. When power is connected, verify that the SYS LED on the port extender turns green.

Connect the V300 Virtual Port Extender to Power

V300-8P-2W and V300-8T-2W models run on AC power with included power supply unit(s).

V300HT-8P-2W and V300HT-8T-2W models can run on redundant power supplies (RPS). HT model power supplies are sold separately.

See the following topics to connect non-PoE V300 models to power:

- [Connect the V300 to a Primary Power Source](#) on page 130
- [Connect the V300 to a Redundant Power Source](#) on page 131

Connect the V300 to a Primary Power Source



Note

Installing the system as described in this guide meets the protective earth grounding requirements of the National Electrical Code (NEC) UL 60950 and IEC 60950 standards. However, in some cases, it may be necessary to use an alternative grounding method. In these cases, a 14 AWG wire can be connected between the grounding lug on the chassis and a nearby building ground point.

To attach the V300 switch to a power source, do the following:

1. Connect the PSU to the V300 with the integrated power cable.
2. Connect the AC power cord to the AC power input socket on the power supply and plug the other end into an AC power outlet.

To attach the V300HT model to a primary power source, do the following:

3. Connect the PSU to the included screw terminal connector (use adequate AWG wire for DIN PSUs).
4. Plug the screw terminal connector into the port extender DC input (PSU1 recommended).
5. Connect the:
 - AC power cord to the AC power input socket on the PSU and plug the other end into an AC power outlet for non-DIN PSUs; or
 - PSU to an AC power source using the instructions included with the PSU for DIN PSUs.

When power is connected, verify that the PWR LED on the switch turns green. If the PWR LED does not turn green, verify that the power source is powered on and the connection was made properly.

Connect the V300 to a Redundant Power Source



Note

Installing the system as described in this guide meets the protective earth grounding requirements of the National Electrical Code (NEC) UL 60950 and IEC 60950 standards. However, in some cases, it may be necessary to use an alternative grounding method. In these cases, a 14 AWG wire can be connected between the grounding lug on the chassis and a nearby building ground point.

To attach the V300 switch to a redundant power source (HT models only), do the following:

1. Connect the RPS to the included screw terminal connector (use adequate AWG wire for DIN PSUs).
2. Plug the screw terminal connector into the port extender DC input (PSU2 recommended).
3. Connect the:
 - AC power cord to the AC power input socket on the PSU and plug the other end into an AC power outlet for non-DIN PSUs; or
 - PSU to an AC power source using the instructions included with the PSU for DIN PSUs.

When power is connected, verify that the PWR LED on the switch turns green. If the PWR LED does not turn green, verify that the power source is powered on and the connection was made properly.

Install a V400 Virtual Port Extender

You need the following tools and materials to install a V400 Virtual Port Extender:

- ESD-preventive wrist strap
- #1 Phillips screwdriver (for clock module) or flat-bladed screwdriver (for all other VIM modules)

Your V400 Virtual Port Extender comes with two mounting brackets and screws for attaching them. Mount the equipment in a standard equipment rack, in either a front or mid-mount configuration, in the same way you would mount a switch.

To install a V400 Virtual Port Extender, follow these steps:

1. Attach the mounting brackets to the sides of the port extender using four screws (included) for each bracket.
2. Align the holes in the brackets with the rack post holes.
3. Secure the port extender to each post with rack-mounting screws (not provided).
4. Connect an AC power cord to the AC power input socket on the port extender and to an AC power outlet.
5. When power is connected, verify that the SYS LED on the port extender turns green. If the SYS LED does not turn green, verify that the power source is powered on and the connection was made properly.

Install a Half-Duplex to Full-Duplex Converter

The following options are available for installing the Half-Duplex to Full-Duplex Converter:

1. On a shelf that is mounted in an equipment rack. (The shelf can accommodate up to three converters.)

See [Install Half-Duplex to Full-Duplex Converters in a 3-Slot Modular Shelf](#) on page 132.

2. On a flat surface.

See [Mount a Half-Duplex to Full-Duplex Converter on a Flat Surface](#) on page 132.

3. On a wall.

See [Mount a Half-Duplex to Full-Duplex Converter on a Wall](#) on page 133.

Install Half-Duplex to Full-Duplex Converters in a 3-Slot Modular Shelf

Refer to [Install a Half-Duplex to Full-Duplex Converter](#) on page 132 for installation options for the Half-Duplex to Full-Duplex Converter.

Before installing the converter in the 3-slot modular shelf (part no. STK-RPS-1005CH3), mount the shelf in the rack. Follow the steps in the [3-Slot Modular Shelf Quick Reference Guide](#).

To install up to three Half-Duplex to Full-Duplex Converter units in the 3-slot modular shelf, follow these steps:

1. Attach the four rubber feet (included) to the bottom of the converter, one at each corner.
2. Set the converter on the shelf.
3. Connect the converter to its power adapter, following the instructions in [Connect a Half-Duplex to Full-Duplex Converter to its Power Adapter](#) on page 133.
4. Secure the converter to the shelf using cable ties (included with the shelf).
Pass the ties through the holes in the shelf and secure them firmly around the converter.
5. Connect the full-duplex ports (FD1 - FD4) to the switch.
6. Connect the half-duplex ports (HD1 - HD4) to your half-duplex devices.
7. Install one or two additional Half-Duplex to Full-Duplex Converter units in the shelf, as described in steps [Install Half-Duplex to Full-Duplex Converters in a 3-Slot Modular Shelf](#) on page 132 through [Install Half-Duplex to Full-Duplex Converters in a 3-Slot Modular Shelf](#) on page 132.

Mount a Half-Duplex to Full-Duplex Converter on a Flat Surface

Refer to [Install a Half-Duplex to Full-Duplex Converter](#) on page 132 for installation options for the Half-Duplex to Full-Duplex Converter.

To install a Half-Duplex to Full-Duplex Converter unit on a flat surface, follow these steps:

1. Attach the four rubber feet (included) to the bottom of the converter, one at each corner.
2. Set the converter on a flat, stable surface.
3. Connect the converter to its power adapter, following the instructions in [Connect a Half-Duplex to Full-Duplex Converter to its Power Adapter](#) on page 133.
4. Connect the full-duplex ports (FD1 - FD4) to the switch.
5. Connect the half-duplex ports (HD1 - HD4) to your half-duplex devices.

Mount a Half-Duplex to Full-Duplex Converter on a Wall

Refer to [Install a Half-Duplex to Full-Duplex Converter](#) on page 132 for installation options for the Half-Duplex to Full-Duplex Converter.

To mount a Half-Duplex to Full-Duplex Converter unit on a wall, follow these steps:

1. Drill two holes in the wall, each 4 mm (0.16 in.) in diameter.
The holes should be 10.5 cm (4.13 in.) apart so that they correspond to the locations of the holes in the bottom of the converter.
2. Insert an anchor bolt (not provided) into each hole in the wall.
3. Place a screw (not provided) into each anchor bolt and tighten so that the screw head protrudes slightly from the wall.
4. Place the converter onto the screws and gently lower it so that it locks into place.
5. Connect the converter to its power adapter, following the instructions in [Connect a Half-Duplex to Full-Duplex Converter to its Power Adapter](#) on page 133.
6. Connect the full-duplex ports (FD1 - FD4) to the switch.
7. Connect the half-duplex ports (HD1 - HD4) to your half-duplex devices.

Connect a Half-Duplex to Full-Duplex Converter to its Power Adapter

Before connecting the Half-Duplex to Full-Duplex Converter to power, install it using one of the options described in [Install a Half-Duplex to Full-Duplex Converter](#) on page 132.

The Half-Duplex to Full-Duplex Converter operates on DC power, which it receives from its power adapter.

Connection points to the power adapter are located on the sides of the converter, as shown in [Connect a Half-Duplex to Full-Duplex Converter to its Power Adapter](#) on page 133.

- 1 = Kensington lock point
- 2 = Grounding point
- 3 = DC power connector




Figure 81: Half-Duplex to Full-Duplex Converter: Side Panels

To connect your Half-Duplex to Full-Duplex Converter to power, follow these steps:

1. Attach a grounding wire to the grounding point on the side of the converter.
2. Connect a DC power cable to the DC input socket on the same side of the converter.
3. Connect the other end of the DC power cable to the power adapter.
4. Connect the power adapter to an AC power source.
5. When power is connected, verify that the converter's power LED turns green.

If the power LED does not turn on, recheck the connections from the connector to the power source.



Monitor the Switch

[System Status LEDs](#) on page 135

[Versatile Interface Modules \(VIM\) Port LEDs](#) on page 138

The following topics help you monitor the status of the switch as it is running.

System Status LEDs

System status LEDs are located on the front of the switch. The following table describes the colors and the states for the LEDs.

LED	Color/State	Port State
SYStem status LED (Legacy MGMT function) Note: The system status LED is solid green to indicate normal operation when the switch is running Fabric Engine.	Green flash slowly	POST Passed, normal operation, blinks on standalone switch, stack master, and backup nodes in a stack; off for standby nodes in a stack
	Green blinking	POST in progress
	Amber blinking	POST failed or overheat
PSU status LEDs P1/P2	Green	Power On
	Off	Power off and no power attached
	Amber blinking	Power supply failures
Fan status LEDS (F1, F2 and F3)	Green	Normal operation
	Amber blinking	Fan failure
	Amber	Fan absent
Bluetooth Status LED (BT)	Green blinking	Bluetooth pairing in progress
	Green	Bluetooth connected
Locator LED (LOC)	Blue blinking	Locator function

The following figure shows the two alternate mode LEDs for 5520 Series switches: SPD and STK. The Mode button is used to cycle through three display modes for the port LEDs. In the default mode, SPD and STK are off. SPD and STK display modes expire after 30 seconds, at which time the port LEDs revert to the default SYS mode.




Figure 82: 5520 Series Mode and System Status LEDs

 **Note**

Front-panel PoE ports use Amber to indicate PoE states.

Port LEDs in Default (SYS) Mode

In the default SYS mode, SPD is OFF, and the port status displays behavior for link, traffic, and PoE as described in the following table:

Table 25: Port LEDs in SYS Mode (default)

Color/State	Meaning
Green	Link is OK; port is not powered
Amber	Link is OK; port is powered; no traffic
Blinking green	Link is OK and transmitting packets; port is not powered
Blinking amber	Link is OK and transmitting packets; port is powered
Slow blinking amber	No link, or disabled port; port is powered
Alternating amber and green	Port has a power fault
Off	Port is not powered, has no link, or is disabled

Port LEDs in SPD Mode

After one press of the Mode button, the port LEDs enter the SPD (speed) Display Mode, indicated by the SPD LED. SPD mode is used to help determine the operational speed of a port.

There are two LEDs per QSFP28 port on 5520 models. In stack mode, the first LED represents the link state and traffic of the stack port with solid or blinking green. When a QSFP28 port is used for Ethernet and partitioned to 4x10 or 4x25, one LED is shared for two ports. The first LED indicates state for the first two ports and the second LED indicates state for the second two ports. The LED is on or blinking green to indicate link and traffic when any of the 2 ports are up. It is off when both ports are down. In partitioned 2x50, each LED represents link and traffic for one 50G port. In aggregate

1x40 mode, the first LED indicates the port state and traffic and the second LED is off. Color and blink patterns indicate speeds, as referenced by the following table:

Table 26: Port LEDs in SPD Mode

Color/State	Speed
Slow blinking green	10Mbps
Fast blinking green	100Mbps
Solid green	1000Mbps
Slow blinking amber	2.5Gbps
Fast blinking green	5Gbps
Slow blinking green	10Gbps
Fast blinking green	25Gbps
Fast blinking green	40Gbps
Fast blinking green	50Gbps

Port LEDs in STK Mode

After two presses of the Mode button, the port LEDs enter the STK Display Mode, indicated by the STK LED. STK mode is used to indicate slot presence and slot number via the first eight port LED, as referenced by the following table:

Table 27: Port LEDs in STK Mode

Color/State	Speed
Green	Slot corresponding to the port number of the LED is present
Blinking green	This slot has slot number corresponding to the port number of the blinking LED

Table 28: Management Port LEDs

Right side LED		State
Link	Green	Link up
	Off	No link up or port disable
Left side LED		State
Act	Blinking green	Packet transmitting or receiving
	Off	No packet transmitting or receiving

Locator LED

The blue LED labeled LOC on the front panel is the locator LED, which is controlled by using the CLI commands

```
[enable | disable] led locator.
```

Versatile Interface Modules (VIM) Port LEDs

There are two supported modes for ExtremeSwitching 5520-VIM port LEDs:

- SYS - default, use normal port LED behavior for link, traffic, and PoE
- SPD – use the port LEDs to indicate operational speed

5520-VIM Port LEDs in Default (SYS) Mode

In the default SYS mode, SPD is OFF, and the port status displays behavior for link, traffic, and PoE as described in the following table:

Table 29: 5520-VIM Port LEDs in SYS Mode (default)

Color/State	Meaning
Solid green	Link is OK; port is not powered
Blinking green	Link is OK and transmitting packets; port is not powered
Slow blinking green	Port is admin disabled
Off	Port is not powered, has no link

5520-VIM Port LEDs in SPD Mode

SPD mode is used to help determine the operational speed of a port. Color and blink pattern indicate speeds, as referenced by the following table:

Table 30: 5520-VIM Port LEDs in SPD Mode

Color/State	Speed
Slow blinking green	10Gbps
Solid green	1Gbps
Fast blinking green	25Gbps



Technical Specifications

[5520 Series Technical Specifications](#) on page 140
[Acoustic Noise and Fan Speed](#) on page 144
[Memory](#) on page 150
[Mean Time Between Failures](#) on page 150
[Power Specifications](#) on page 152
[V300 Virtual Port Extender Specifications](#) on page 155
[V400 Virtual Port Extender Technical Specifications](#) on page 158
[Half-Duplex to Full-Duplex Converter Technical Specifications](#) on page 161
[Environmental](#) on page 163
[Standards](#) on page 164
[EMI/EMC Standards](#) on page 165
[Power Cord Requirements for AC-Powered Switches and AC Power Supplies](#) on page 166
[Console Connector Pinouts](#) on page 166

The following topics contain technical specifications for the hardware products described in this document.

5520 Series Technical Specifications

External Interfaces

Switch Model	Interfaces
5520-24T	<ul style="list-style-type: none"> • 24 x 10/100/1000BASE-T ports <ul style="list-style-type: none"> ◦ Full / Half-Duplex (autosensing) ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-24W	<ul style="list-style-type: none"> • 24 x 10/100/1000BASE-T 802.3bt (90W) ports <ul style="list-style-type: none"> ◦ Full / Half-Duplex (autosensing) ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-48T	<ul style="list-style-type: none"> • 48 x 10/100/1000BASE-T ports <ul style="list-style-type: none"> ◦ Full / Half-Duplex (autosensing) ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-48W	<ul style="list-style-type: none"> • 48 x 10/100/1000BASE-T 802.3bt (90W) ports <ul style="list-style-type: none"> ◦ Full / Half-Duplex (autosensing) ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot

Switch Model	Interfaces
5520-12MW-36W	<ul style="list-style-type: none"> • 12 x 100M/1/2.5/5GBASE-T 802.3bt (90W) PoE ports • 36 x 10/100/1000BASE-T 802.3bt (90W) PoE ports <ul style="list-style-type: none"> ◦ Full-Duplex ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-48SE	<ul style="list-style-type: none"> • 48 x 100/1000BASE-X (SFP) ports (unpopulated) <ul style="list-style-type: none"> ◦ MACsec-capable • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-24X	<ul style="list-style-type: none"> • 24 x 100M/1G/10GBASE-X (SFP+) ports** (unpopulated) • 2 x Stacking/QSFP28 ports* (unpopulated) • 1 x Serial console port (RJ-45) • 1 x 10/100/1000BASE-T out-of-band management port • 2 x USB A ports for management or external USB flash • 1 x USB Micro-B console port • 1 x VIM slot
5520-24T-ACDC	<ul style="list-style-type: none"> • 24 x 10/100/1000BASE-T FDX/HDX MACsec capable ports • 2 stacking/QSFP28 ports • 1 unpopulated VIM slot • 3 unpopulated modular fan slots • 2 unpopulated modular PSU slots • AC or DC PSU capable
5520-48T-ACDC	<ul style="list-style-type: none"> • 48 x 10/100/1000BASE-T FDX/HDX MACsec capable ports • 2 stacking/QSFP28 ports • 1 unpopulated VIM slot • 3 unpopulated modular fan slots • 2 unpopulated modular PSU slots • AC or DC PSU capable

Switch Model	Interfaces
5520-24X-ACDC	<ul style="list-style-type: none"> • 24 x 100M/1Gb/10Gb SFP+ ports** (unpopulated) • 2 stacking/QSFP28 ports (unpopulated) • 1 unpopulated VIM slot • 3 unpopulated modular fan slots • 2 unpopulated modular PSU slots • AC or DC PSU capable
5520-48SE-ACDC	<ul style="list-style-type: none"> • 48 x 100/1000BASE-X SFP MACsec capable ports (unpopulated) • 2 stacking/QSFP28 ports (unpopulated) • 1 unpopulated VIM slot • 3 unpopulated modular fan slots • 2 unpopulated modular PSU slots • AC or DC PSU capable
5520-VIM-4X	<ul style="list-style-type: none"> • 4 x 1/10GBASE-X SFP+ ports (unpopulated)
5520-VIM-4XE	<ul style="list-style-type: none"> • 4 x 1/10GBASE-X SFP+ ports (unpopulated) <ul style="list-style-type: none"> ◦ LRM-capable ◦ MACsec-capable
5520-VIM-4YE	<ul style="list-style-type: none"> • 4 x 10/25GBASE-X SFP28 ports (unpopulated) <ul style="list-style-type: none"> ◦ MACsec-capable

* Notes on use of the 2 x Stacking/QSFP28 ports

1. With Switch Engine, the 2 x QSFP28 ports can be used for stacking or as Ethernet uplink ports (when not stacking); stacking data rate is 40Gb or 50Gb per port.
2. With Fabric Engine, the 2 x QSFP28 ports can be used as Ethernet uplink ports if in non-Fabric mode or if no VIM is present as of the VOSS 8.4.2 release.
3. Ethernet uplink QSFP28 data rate options per port, with channelization: 4 x 10Gb SFP+, 4 x 25Gb SFP28, 1 x 40Gb QSFP+ (supported with Switch Engine and Fabric Engine); 2 x 50Gb (Switch Engine only)

** 100M on 5520-24x and 5520-24x-ACDC access ports supported with Switch Engine and with Fabric Engine. Refer to the Extreme Optics Compatibility Tool.

Weights and Dimensions

Switches

Switch Model	Weight*	Physical Dimensions	
		Chassis Only	With PSU
5520-24T	5.54 kg (12.21 lb.)	Height: 44 mm (1.73 in.) Width: 441 mm (17.36 in.) Depth: 442 mm (17.42 in.)	Height: 44 mm (1.73 in.) Width: 441 mm (17.36 in.) Depth: 449 mm (17.68 in.)
5520-24W	6.25 kg (13.78 lb.)		

Switch Model	Weight*	Physical Dimensions	
		Chassis Only	With PSU
5520-48T	5.76 kg (12.70 lb.)		
5520-48W	6.06 kg (13.36 lb.)		
5520-12MW-36W	6.33 kg (13.96 lb.)		
5520-48SE	5.70 kg (12.57 lb.)		
5520-24X	6.25 kg (13.78 lb.)		
5520-24T-ACDC	5.15 kg (11.35 lb.)	Height: 43 mm (1.71 in.) Width: 431 mm (16.98 in.) Depth: 442 mm (17.42 in.)	Not applicable
5520-48T-ACDC	5.95 kg (13.12 lb.)		
5520-24X-ACDC	5.68 kg (12.52 lb.)		
5520-48SE-ACDC	5.91 kg (13.03 lb.)		

* Switch weights include fans but no PSUs

VIM Modules

Model	Weight	Physical Dimensions
5520-VIM-4X	0.17 kg (0.37 lb.)	Height: 40.8 mm (1.61 in.) Width: 48.8 mm (1.92 in.) Depth: 146.3 mm (5.76 in.)
5520-VIM-4XE	0.20 kg (0.44 lb.)	
5520-VIM-4YE	0.21 kg (0.46 lb.)	

Power Supplies

Model	Weight*	Physical Dimensions
10953 (350W AC)	1.08 kg (2.38 lb.)	Height: 82.5 mm (3.25 in.) Width: 40 mm (1.57 in.) Depth: 287 mm (11.30 in.)
10951 (715W AC)	1.16 kg (2.56 lb.)	
10941 (1100W AC)	1.16 kg (2.56 lb.)	
XN-ACPWR-2000W-F (2000W AC)	1.16 kg (2.56 lb.)	Height: 75 mm (2.95 in.) Width: 40 mm (1.57 in.) Depth: 292 mm (11.50 in.)
XN-ACPWR-550W-FB	0.81 kg (1.79 lb.)	Height: 40 mm (1.58 in.) Width: 73.7 mm (2.90 in.) Depth: 185.2 mm (7.29 in.)
XN-ACPWR-550W-BF	0.81 kg (1.79 lb.)	
XN-DCPWR-550W-FB	0.81 kg (1.79 lb.)	
XN-DCPWR-550W-BF	0.81 kg (1.79 lb.)	

Acoustic Noise and Fan Speed

Fan & Acoustic Noise

Switch Model	Acoustic Information	
5520-24T	Typical: Single 350W AC PSU, no VIM Maximum: Dual 350W AC PSU, 5520-VIM-4YE	
	Bystander Sound Pressure 39.6 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 77.5 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 5.1 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 8.46 B, 50 °C (122 °F) (Maximum)
5520-24W	Typical: Single 715W AC PSU, no VIM Maximum: Dual 1100W AC PSU, 5520-VIM-4YE	
	Bystander Sound Pressure 50.4 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 67.1 dB(A), 25 °C (77 °F) (Maximum) 78.9 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 6 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 7.61 B, 25 °C (77 °F) (Maximum) 8.6 B, 50 °C (122 °F) (Maximum)
5520-48T	Typical: Single 350W AC PSU, no VIM Maximum: Dual 350W AC PSU, 5520-VIM-4YE	
	Bystander Sound Pressure 39.0 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 79.0 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 4.9 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 8.52 B, 50 °C (122 °F) (Maximum)
5520-48W	Typical: Single 1100W AC PSU, no VIM Maximum: Dual 2000W AC PSU (240VAC), 5520-VIM-4YE	
	Bystander Sound Pressure 64.3 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 69.1 dB(A), 25 °C (77 °F) (Maximum) 79.4 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 7.24 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 7.65 B, 25 °C (77 °F) (Maximum) 8.6 B, 50 °C (122 °F) (Maximum)

Switch Model	Acoustic Information	
5520-12MW-36W	Typical: Single 1100W AC PSU, no VIM Maximum: Dual 2000W AC PSU (240VAC), 5520-VIM-4YE	
	Bystander Sound Pressure 62.7 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 69.2 dB(A), 25 °C (77 °F) (Maximum) 78.8 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 7.25 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 7.64 B, 25 °C (77 °F) (Maximum) 8.6 B, 50 °C (122 °F) (Maximum)
5520-48SE	Typical: Single 350W AC PSU, no VIM Maximum: Dual 350W AC PSU, 5520-VIM-4YE	
	Bystander Sound Pressure 41.4 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 77.9 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 5.14 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 8.53 B, 50 °C (122 °F) (Maximum)
5520-24X	Typical: Single 350W AC PSU, no VIM Maximum: Dual 350W AC PSU, 5520-VIM-4YE	
	Bystander Sound Pressure 40.6 dB(A), 0 °C to 35 °C (32 °F to 95 °F) (Typical) 76.9 dB(A), 50 °C (122 °F) (Maximum)	Sound Power 5.05 B, 0 °C to 35 °C (32 °F to 95 °F) (Typical) 8.52 B, 50 °C (122 °F) (Maximum)

Switch Model	Acoustic Information	
5520-24T-ACDC	Typical: F2B Airflow; Single 550W AC PSU, no VIM Maximum: F2B Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.6 dB(A), 0 °C to 40 °C (Typical) 76.5 dB(A), 50 °C (Maximum)	Sound Power 4.94 B, 0 °C to 40 °C (Typical) 8.60 B, 50 °C (Maximum)
	Typical: F2B Airflow; Single 550W DC PSU, no VIM Maximum: F2B Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.2 dB(A), 0 °C to 40 °C (Typical) 77.0 dB(A), 50 °C (Maximum)	Sound Power 4.89 B, 0 °C to 40 °C (Typical) 8.56 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W AC PSU, no VIM Maximum: B2F Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.46dB(A), 0 °C to 40 °C (Typical) 76.6 dB(A), 50 °C (Maximum)	Sound Power 4.99 B, 0 °C to 40 °C (Typical) 8.61 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W DC PSU, no VIM Maximum: B2F Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 39.8 dB(A), 0 °C to 40 °C (Typical) 79.0 dB(A), 50 °C (Maximum)	Sound Power 5.03 B, 0 °C to 40 °C (Typical) 8.69 B, 50 °C (Maximum)

Switch Model	Acoustic Information	
5520-48T-ACDC	Typical: F2B Airflow; Single 550W AC PSU, no VIM Maximum: F2B Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.2 dB(A), 0 °C to 40 °C (Typical) 76.4 dB(A), 50 °C (Maximum)	Sound Power 4.91 B, 0 °C to 40 °C (Typical) 8.58 B, 50 °C (Maximum)
	Typical: F2B Airflow; Single 550W DC PSU, no VIM Maximum: F2B Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.1 dB(A), 0 °C to 40 °C (Typical) 77.1 dB(A), 50 °C (Maximum)	Sound Power 4.88 B, 0 °C to 40 °C (Typical) 8.55 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W AC PSU, no VIM Maximum: B2F Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.5 dB(A), 0 °C to 40 °C (Typical) 76.7 dB(A), 50 °C (Maximum)	Sound Power 4.94 B, 0 °C to 40 °C (Typical) 8.54 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W DC PSU, no VIM Maximum: B2F Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 39.6 dB(A), 0 °C to 40 °C (Typical) 79.0 dB(A), 50 °C (Maximum)	Sound Power 5.00 B, 0 °C to 40 °C (Typical) 8.70 B, 50 °C (Maximum)

Switch Model	Acoustic Information	
5520-48SE-ACDC	Typical: F2B Airflow; Single 550W AC PSU, no VIM Maximum: F2B Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 39.0 dB(A), 0 °C to 40 °C (Typical) 76.6 dB(A), 50 °C (Maximum)	Sound Power 4.98 B, 0 °C to 40 °C (Typical) 8.65 B, 50 °C (Maximum)
	Typical: F2B Airflow; Single 550W DC PSU, no VIM Maximum: F2B Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.7 dB(A), 0 °C to 40 °C (Typical) 77.2 dB(A), 50 °C (Maximum)	Sound Power 4.96 B, 0 °C to 40 °C (Typical) 8.64 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W AC PSU, no VIM Maximum: B2F Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.9 dB(A), 0 °C to 40 °C (Typical) 77.4 dB(A), 50 °C (Maximum)	Sound Power 4.95 B, 0 °C to 40 °C (Typical) 8.65 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W DC PSU, no VIM Maximum: B2F Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 40.2 dB(A), 0 °C to 40 °C (Typical) 79.5 dB(A), 50 °C (Maximum)	Sound Power 5.04 B, 0 °C to 40 °C (Typical) 8.75 B, 50 °C (Maximum)

Switch Model	Acoustic Information	
5520-24X-ACDC	Typical: F2B Airflow; Single 550W AC PSU, no VIM Maximum: F2B Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.1 dB(A), 0 °C to 40 °C (Typical) 75.8 dB(A), 50 °C (Maximum)	Sound Power 4.90 B, 0 °C to 40 °C (Typical) 8.59 B, 50 °C (Maximum)
	Typical: F2B Airflow; Single 550W DC PSU, no VIM Maximum: F2B Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.0 dB(A), 0 °C to 40 °C (Typical) 76.6 dB(A), 50 °C (Maximum)	Sound Power 4.88 B, 0 °C to 40 °C (Typical) 8.53 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W AC PSU, no VIM Maximum: B2F Airflow; Dual 550W AC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 38.3 dB(A), 0 °C to 40 °C (Typical) 77.3 dB(A), 50 °C (Maximum)	Sound Power 4.94 B, 0 °C to 40 °C (Typical) 8.64 B, 50 °C (Maximum)
	Typical: B2F Airflow; Single 550W DC PSU, no VIM Maximum: B2F Airflow; Dual 550W DC PSU, with 5520-VIM-4YE	
	Bystander Sound Pressure 40.1 dB(A), 0 °C to 40 °C (Typical) 79.3 dB(A), 50 °C (Maximum)	Sound Power 4.94 B, 0 °C to 40 °C (Typical) 8.73 B, 50 °C (Maximum)

Table 31: 5520 Fan Speed and Power Consumption

Fan Speed	Fan Module RPM (typical)		Power
	Inlet Fan	Outlet Fan	Typical
Full (100%)	21000	19000	12V*1.7A = 20.4W per module*
Low (20%)	4200	3800	2W (per module)

* Some units are equipped with (2) fan module, while others are equipped with 3. Total fan power is equal to the number of installed fan modules multiplied by the fan power for each module.

Fan Speed and Temperature Variation

The speed of the fan increases only when the temperature of the device increases. Fan speed is not dependent on any fan failures.

Memory

Memory
2 GB DDR4 ECC memory
2 GB SLC NAND Flash Memory
8MB packet buffer per chip

Mean Time Between Failures

Table 32: 5520 MTBF (front-to-back airflow)

Ambient Temp = 25°C	5520-24T	5520-24W	5520-24X	5520-12M W-36W	5520-48T	5520-48W	5520-48SE
System base (all boards, modules excluded)	545,928	480,404	633,004	392,662	506,767	417,304	531,218
Complete system - A (system base+full fans+1 PSU)							
One 2000W PSU		185,080		174,532		179,138	
One 1100W PSU		212,906		199,067		205,081	
One 715W PSU		218,879		204,272		210,617	
One 350W PSU	270,711		193,198		236,070		169,687
Complete system - B (system base+ full fans+2 PSUs)							
Two 2000W PSU		123,936		119,115		121,243	
Two 1100W PSU		150,232		143,607		146,293	

Table 32: 5520 MTBF (front-to-back airflow) (continued)

Ambient Temp = 25°C	5520-24T	5520-24W	5520-24X	5520-12M W-36W	5520-48T	5520-48W	5520-48SE
Two 715W PSU		156,248		148,663		151,992	
Two 350W PSU	184,380		193,198		167,627		169,687

**Note**

5520-24X and 5520-24T models have 2 fan slots; All other models have 3.

Table 33: 5520 MTBF (back-to-front airflow)

Ambient Temp = 25°C	5520-48T-BASE	5520-24T-BASE	5520-24X-BASE	5520-48SE-BASE
System base (without PSU and fans)	506,767	545,928	633,004	531,218
(system base+3 fans+1 PSU)				
One 350W PSU	334,974			343,304
(system base+3 fans+2 PSUs)				
Two 350W PSU	353,898			363,209
(system base+2 fans+1 PSU)				
One 350W PSU		409,290	455,433	
(system base+2 fans+2 PSUs)				
Two 350W PSU		437,901	491,140	

Table 34: 5520 MTBF (AC and DC power supplies)

Ambient Temp = 25°C	5520-48T-ACDC	5520-24T-ACDC	5520-24X-ACDC	5520-48SE-ACDC
System base (without PSU and fans)	634,091	697,627	717,424	618,066
(system base+3 f-b fans+1 PSU)				
One 550W AC PSU	317,110	331,806	335,188	313,314
One 550W DC PSU	303,810	317,273	320,363	300,323
(system base+3 b-f fans+1 PSU)				

Table 34: 5520 MTBF (AC and DC power supplies) (continued)

Ambient Temp = 25°C	5520-48T-ACDC	5520-24T-ACDC	5520-24X-ACDC	5520-48SE-ACDC
One 550W AC PSU	297,612	310,520	313,480	294,266
One 550W DC PSU	317,057	331,749	335,128	313,262
(system base+3 f-b fans+2 PSUs)				
Two 550W AC PSUs	355,926	374,545	378,860	351,150
Two 550W DC PSUs	344,636	362,064	366,094	340,156
(system base+3 b-f fans+2 PSUs)				
Two 550W AC PSUs	339,289	356,168	360,067	334,947
Two 550W DC PSUs	355,877	374,492	378,805	351,103

Table 35: 5520 MTBF (AC and DC power supplies cont.)

Ambient Temp = 50°C	5520-48T-ACDC	5520-24T-ACDC	5520-24X-ACDC	5520-48SE-ACDC
System base (without PSU and fans)	251,134		286,740	

Power Specifications

	10953	10951	10941	XN-ACPWR-2000-F*
Voltage Input Range (Nominal)	100VAC-127VAC/ 200VAC-240VAC	100VAC-127VAC/ 200VAC-240VAC	100VAC-127VAC/ 200VAC-240VAC	100VAC-127VAC/ 200VAC-240VAC
Line Frequency Range	50Hz to 60Hz	50Hz to 60Hz	50Hz to 60Hz	50Hz to 60Hz
Power Supply Input Socket	IEC/EN 60320 C14	IEC/EN 60320 C16	IEC/EN 60320 C16	IEC/EN 60320 C16
Power Cord Input Plug	IEC/EN 60320 C13	IEC/EN 60320 C15	IEC/EN 60320 C15	IEC/EN 60320 C15
Operating Temperature	0°C to 55°C (32°F to 131°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 55°C (32°F to 131°F) Normal Operation

* 200VAC-240VAC is required to achieve full 2000W output. If run at 100VAC-120VAC, output is limited to 1100W.

Power Supply Specifications (cont.)

	XN-ACPWR-350W-FB	XN-ACPWR-350W-BF	XN-ACPWR-715W-FB	XN-ACPWR-1100W-FB	XN-ACPWR-2000W-FB*
Voltage Input Range (Nominal)	100VAC-240VAC	100VAC-240VAC	100VAC-240VAC	100VAC-240VAC	100VAC-240VAC
Line Frequency Range	50Hz to 60Hz	50Hz to 60Hz	50Hz to 60Hz	50Hz to 60Hz	50Hz to 60Hz
Power Supply Input Socket	IEC/EN 60320 C14	IEC/EN 60320 C14	IEC/EN 60320 C16	IEC/EN 60320 C16	IEC/EN 60320 C16
Power Cord Input Plug	IEC/EN 60320 C13	IEC/EN 60320 C13	IEC/EN 60320 C15	IEC/EN 60320 C15	IEC/EN 60320 C15
Operating Temperature	0°C to 55°C (32°F to 131°F) Normal Operation	0°C to 55°C (32°F to 131°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation

* 200VAC-240VAC is required to achieve full 2000W output. If run at 100VAC-120VAC, output is limited to 1100W.

Power Supply Specifications (cont.)

	XN-ACPWR-550W-FB	XN-ACPWR-550W-BF	XN-DCPWR-550W-FB	XN-DCPWR-550W-BF
Voltage Input Range (Nominal)	100VAC-240VAC	100VAC-240VAC	-48VDC (-36VDC to -72VDC)	-48VDC (-36VDC to -72VDC)
Line Frequency Range	50Hz to 60Hz	50Hz to 60Hz	N/A	N/A
Power Supply Input Socket	IEC 320 - C14	IEC 320 - C14	POSITRONIC PN# PLAH03M400A1/ AA-E1A	POSITRONIC PN# PLAH03M400A1/ AA-E1A

	XN-ACPWR-550W-FB	XN-ACPWR-550W-BF	XN-DCPWR-550W-FB	XN-DCPWR-550W-BF
Power Cord Input Plug	IEC 320 - C13	IEC 320 - C13	POSITRONIC PN# PLAH03M400A1/ AA-E1A	POSITRONIC PN# PLAH03M400A1/ AA-E1A
Operating Temperature	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation	0°C to 50°C (32°F to 122°F) Normal Operation

PoE Power Budget

Switch Model	1 x 715W	2x 715W	1 x 1100W	2 x 1100W	1 x 2000W @ 100-120VAC	1 x 2000W @ 200-240VAC	2 x 2000W @ 100-120VAC	2 x 2000W @ 200-240VAC
5520-24W	494W	1079W	879W	1781W	879W	1779W	1869W	2160W
5520-48W	483W	1068W	868W	1770W	868W	1768W	1858W	3568W
5520-12MW-36W	464W	1049W	849W	1751W	849W	1749W	1839W	3549W

Note: It is recommended that primary and secondary power supply units (PSUs) be of the same type to support optimal PoE operation.

Minimum/Maximum Power Consumption and Heat Dissipation

Switch Model	Minimum Power Consumption (W)	Minimum Heat Dissipation (BTU/hr)	Maximum Power Consumption (W)*	Maximum Heat Dissipation (BTU/hr)**
5520-24T	52	176	142	483
5520-24W	54	182	2480	1092
5520-48T	60	205	171	584
5520-48W	59	203	4100	1817
5520-12MW-36W	66	224	4095	1862
5520-48SE	61	209	255	872
5520-24X	48	165	171	585
5520-24T-ACDC	41	140	135	459
5520-48T-ACDC	46	156	141	481
5520-24X-ACDC	39	132	169	575
5520-48SE-ACDC	45	154	223	760

* Includes maximum PoE load (W) through the switch

** Does not include PoE load heat dissipated through external electronic load

V300 Virtual Port Extender Specifications

The following V300 Virtual Port Extender models are available:

- V300-8P-2X
- V300-8T-2X
- V300-8P-2T-W
- V300HT-8P-2X
- V300HT-8T-2X

Table 36: V300 Unpackaged Dimensions

V300-8P-2X V300-8T-2X V300HT-8P-2X V300HT-8T-2X	Height: 1.73 in (4.4 cm) Width: 7.76 in (19.71 cm) Length: 212 in (538.48 cm)
V300-8P-2T-W	Height: 1.73 in (4.4 cm) Width: 8.26 in (21 cm) Length: 7.48 in (19 cm)

Table 37: V300 Unpackaged Weight

V300-8P-2X V300-8T-2X V300HT-8P-2X V300HT-8T-2X	3.31 lb (1.5 kg)
V300-8P-2T-W	3.22 lb (1.46 kg)

Table 38: V300 Packaged Dimensions

V300-8P-2X	Height: 3.07 in (7.79 cm) Width: 11.52 in (29.26 cm) Length: 19.98 in (50.74 cm)
V300-8T-2X	Height: 3.07 in (7.79 cm) Width: 10.15 in (25.78 cm) Length: 17.61 in (44.72 cm)

Table 38: V300 Packaged Dimensions (continued)

V300-8P-2T-W	Height: 3.08 in (7.82 cm) Width: 10.85 in (27.56 cm) Length: 11.52 in (29.26 cm)
V300HT-8P-2X V300HT-8T-2X	Height: 3.07 in (7.79 cm) Width: 10.15 in (25.78 cm) Length: 14.46 in (36.72 cm)

Table 39: V300 Packaged Weight

V300-8P-2X with 280W PSU	7.94 (3.6 kg)
V300-8T-2X with 40W PSU	5.73 lb (2.6 kg)
V300-8P-2T-W	4.1 lb (1.86 kg)
V300HT-8P-2X V300HT-8T-2X	3.97 (1.8kg)

Power Specifications



Note

When you use a redundant power supply (RPS), only redundant power – not additive power – is supported. Thus, the PoE ports load does not increase when an RPS is added.

Table 40: V300 Power Options

V300-8P-2X	DC Input: 54VDC, 4.5A max
V300-8T-2X	DC Input: 12VDC, 1.5A max
V300-8P-2T-W	<p>The PoE PSE Budget is dynamically determined by the 802.3bt Type 4 PD input power applied to its uplinks as follows:</p> <ul style="list-style-type: none"> • 2 x 90W = PoE ports load to 105W • 1 x 90W = PoE ports load to 50W • 2 x 60W = PoE ports load to 75W • 1 x 60W = PoE ports load to 30W • 2 x 30W = PoE ports load to 30W • 1 x 30W = PoE ports load to 0W
V300HT-8P-2X	DC Input: 54VDC, 4.5A max
V300HT-8T-2X	DC Input: 12VDC, 1.5A max

Table 41: Power Specifications

	Minimum ¹ Heat Dissipation (BTU/hr)	Minimum ¹ Power Consumption (Watts)	Maximum ¹ Heat Dissipation (BTU/hr)	Maximum ¹ Power Consumption (Watts)
V300-8P-2X	25.9	7.6W	118.2	214.6W
V300-8T-2X	11.6	3.3W	23.8	7.0W
V300-8P-2T-W	24.57	7.2W	82.1	129.1W
V300HT-8P-2X	25.8	7.6W	113.7	213.3W
V300HT-8T-2X	16.6	4.9W	7.4	25.2W

¹ Minimum is defined as idle, with no ports linked. Maximum is defined as fans high, all ports 100% traffic.

Standards and Environmental Data

Table 42: Safety Standards

North American Safety of ITE	UL 60950-1 2nd Ed., A2:2014, Listed Device (US) CSA 22.2 #60950-1-07 2nd Ed., 2014-10 Canada) Complies with FCC 21CFR 1040.10 (US Laser Safety) CDRH Letter of Approval (US FDA Approval)
European Safety of ITE	EN 60950-1:2006 +A1+A1+A2+A2 EN 60825-1:2007 (Lasers Safety) IEC 60950-1:2005 2nd+A1:2009+A2:2013 2014/35/EU Low Voltage Directive
International Safety of ITE	CB Report & Certificate per IEC 60950-1:2005 2nd Ed. + National Differences AS/NZX 60950-1 (Australia /New Zealand)

Table 43: Environmental Data

Operating conditions	Temperature: 0°C to 60°C (32°F to 140°F) for V300 8P-2T-W and V300-8P/8T-2X models Temperature: -40°C to 70°C (-40°F to 158°F) for V300HT-8P/8T-2X models Storage and transportation temperature: -40°C to 70°C (-40°F to 158°F) Humidity: 5% to 95% relative humidity, non-condensing Altitude: 0 to 3,000 meters (9,850 feet)
----------------------	---

V400 Virtual Port Extender Technical Specifications

The following V400 Virtual Port Extender models are available:

- V400-24t-10GE2 (part no. 18101)
- V400-24p-10GE2 (part no. 18102)
- V400-48t-10GE4 (part no. 18103)
- V400-48p-10GE4 (part no. 18104)

Table 44: V400 Unpackaged Dimensions

V400-24t-10GE2	Height: 1.70 in (4.32 cm) Width: 9.97 in (25.3 cm) Length: 17.34 in (44.0 cm)
V400-24p-10GE2	Height: 1.70 in (4.32 cm) Width: 9.97 in (25.3 cm) Length: 17.34 in (44.0 cm)
V400-48t-10GE4	Height: 1.70 in (4.32 cm) Width: 9.97 in (25.3 cm) Length: 17.34 in (44.0 cm)
V400-48p-10GE4	Height: 1.70 in (4.32 cm) Width: 15.25 in (38.7 cm) Length: 17.34 in (44.0 cm)

Table 45: V400 Unpackaged Weight

V400-24t-10GE2	6.62 lb (3.00 kg)
V400-24p-10GE2	9.08 lb (4.12 kg)
V400-48t-10GE4	7.14 lb (3.26 kg)
V400-48p-10GE4	14.06 lb (6.38 kg)

Table 46: V400 Packaged Dimensions

V400-24t-10GE2	Height: 4.49 in (11.4 cm) Width: 14.66 in (37.2 cm) Length: 22.02 in (55.9 cm)
V400-24p-10GE2	Height: 4.49 in (11.4 cm) Width: 14.66 in (37.2 cm) Length: 22.02 in (55.9 cm)

Table 46: V400 Packaged Dimensions (continued)

V400-48t-10GE4	Height: 4.49 in (11.4 cm) Width: 14.66 in (37.2 cm) Length: 22.02 in (55.9 cm)
V400-48p-10GE4	Height: 4.49 in (11.4 cm) Width: 19.86 in (50.4 cm) Length: 22.02 in (55.9 cm)

Table 47: V400 Packaged Weight

V400-24t-10GE2	9.00 lb (4.08 kg)
V400-24p-10GE2	11.44 lb (5.19 kg)
V400-48t-10GE4	9.69 lb (4.39 kg)
V400-48p-10GE4	16.56 lb (7.50 kg)

Power Specifications



Note

When you use a redundant power supply (RPS), only redundant power – not additive power – is supported. Thus, the PoE ports load does not increase when an RPS is added.

Table 48: V400 Power Options

V400-24t-10GE2	AC Input: 100-240 VAC, 50/60 Hz, 0.6 A max
V400-24p-10GE2	AC Input: 100-240 VAC, 50/60 Hz, 2.2 A max DC RPS input: 54 VDC, 18.52 A max <ul style="list-style-type: none"> • PoE ports load to 382 W for AC input only. • PoE ports load to 720 W for DC input only. • PoE ports load to 720 W for AC+DC input.
V400-48t-10GE4	AC Input: 100-240 VAC, 50/60 Hz, 1.0 A max
V400-48p-10GE4	AC Input: 100-240 VAC, 50/60 Hz, 12.0 - 6.0 A max DC RPS input: 54 VDC, 18.52 A max <ul style="list-style-type: none"> • PoE ports load to 740 W for AC input only. • PoE ports load to 900 W for DC input only. • PoE ports load to 1440 W for AC+DC input.

Table 49: Power Specifications

	Minimum ² Heat Dissipation (BTU/hr)	Minimum ² Power Consumption (Watts)	Maximum ² Heat Dissipation (BTU/hr)	Maximum Power Consumption (Watts)
V400-24t-10GE2	36.1	10.6	75.2	22.1
V400-24p-10GE2	109.8	32.2	336.8	478.7
V400-48t-10GE4	66.0	19.3	134.8	39.5
V400-48p-10GE4	168.9	49.5	583.2	910.9
VX-RPS-1000	141.3	41.4	3152.8	924

² Minimum is defined as idle, with no ports linked. Maximum is defined as fans high, all ports 100% traffic.

Fan and Acoustic Sound

Table 50: Fan and Acoustic Sound

	Bystander Sound Pressure ³ in dB(A)	Declared Sound Power (LWAd) ³ in bels
V400-24t-10GE2	41.6 (Duty 30%) / 59.4 (max.)	4.4 (Duty 30%) / 6.2 (max.)
V400-24p-10GE2	47.5 (Duty 30%) / 64.0 (max.)	5.0 (Duty 30%) / 6.7 (max.)
V400-48t-10GE4	43.4 (Duty 30%) / 61.1 (max.)	4.6 (Duty 30%) / 6.4 (max.)
V400-48p-10GE4	48.5 (Duty 30%) / 65.5 (max.)	5.1 (Duty 30%) / 6.8 (max.)

³ At 25°C and 50% PoE load where applicable

Standards and Environmental Data

Table 51: Safety Standards

North American Safety of ITE	UL 60950-1 2nd Ed., A2:2014, Listed Device (US) CSA 22.2 #60950-1-07 2nd Ed., 2014-10 Canada) Complies with FCC 21CFR 1040.10 (US Laser Safety) CDRH Letter of Approval (US FDA Approval)
European Safety of ITE	EN 60950-1:2006 +A11+A1+A2+A2 EN 60825-1:2007 (Lasers Safety) IEC 60950-1:2005 2nd+A1:2009+A2:2013 2014/35/EU Low Voltage Directive
International Safety of ITE	CB Report & Certificate per IEC 60950-1:2005 2nd Ed. + National Differences AS/NZX 60950-1 (Australia /New Zealand)

Table 52: V400 Environmental Data

Operating conditions	Temperature: 0°C to 50°C (32°F to 122°F) for non-PoE models Temperature: 0°C to 45°C (32°F to 113°F) for PoE models Storage and transportation temperature: -40°C to 70°C (-40°F to 158°F) Humidity: 5% to 95% relative humidity, non-condensing Altitude: 0 to 3,000 meters (9,850 feet)
----------------------	--

Half-Duplex to Full-Duplex Converter Technical Specifications

The Half-Duplex to Full-Duplex Converter can be attached to switch ports to enable communication over half-duplex connections with older Ethernet devices.

Order the converter using one of the following part numbers:

- 10958: HDX to FDX Converter, Rest of World
- 10959: HDX to FDX Converter: North America

Other specifications:

- 8.8 Gbps switching capacity
- 4 priority queues
- 192Kb packet buffer

Table 53: Half-Duplex to Full-Duplex Converter Packaged Dimensions

Height	2.69 cm (1.06 in)
Width	12.9 cm (5.08 in)
Depth	6.91 cm (2.72 in)
Weight	200 g (0.44 lb)

Half-Duplex to Full-Duplex Converter Power Specifications

Table 54: Rest of the World External Power Pack (10958-CEE 7/1)

Voltage input range	200-240 VAC
Line frequency range	50 to 60 Hz
Operating temperature	0°C to 40°C (32°F to 104°F) normal operation

Table 55: North American External Power Pack (10959-NEMA 1-15P)

Voltage input range	100-120 VAC
Line frequency range	50 to 60 Hz
Operating temperature	0°C to 40°C (32°F to 104°F) normal operation

Half-Duplex to Full-Duplex Converter Environmental Data and Standards

Table 56: Environmental Data

Environmental conditions	<p>Operating temperature: 0°C to 40°C (32°F to 104°F) Storage temperature: -40°C to 70°C (-40°F to 158°F) Humidity: 10% to 95% relative humidity, non-condensing Altitude: 0 to 2,000 meters (6,562 feet) Packaged shock (half sine): 180 m/s² (18 G), 6 ms, 600 shocks Packaged vibration: 5 to 62 Hz at velocity 5 mm/s, 62 to 500 Hz at 0.2 G Packaged random vibration: 5 to 20 Hz at 1.0 ASD w/-3 dB/oct. from 20 to 200 Hz Packaged drop height: 14 drops minimum on sides and corners at 42 inches (<15 kg box)</p>
--------------------------	---

Table 57: Safety Standards

North American ITE	<p>UL 60950-1 2nd Ed., Listed Device (U.S.) CSA 22.2 #60950-1-03 2nd Ed. (Canada) Complies with FCC 21CFR 1040.10 (U.S. Laser Safety)</p>
European/International ITE	<p>EN 60950-1:2007 2nd Ed. CB Report & Certificate per IEC 60950-1 2nd Ed. + National Differences AS/NZS 60950-1 (Australia /New Zealand)</p>
EMI/EMC Standards	<p>FCC CFR 47 part 15 Class A (USA) ICES-003 Class A (Canada) EN 55022: Class A EN 55024:A2 Class A includes IEC 61000-4-2, 3, 4, 5, 6, 11 EN 61000-3-2,8 (Harmonics) EN 61000-3-3 (Flicker) 2014/30/EU EMC Directive</p>

Table 57: Safety Standards (continued)

International EMC Certifications	CISPR 22: Ed 5.2, Class A (International Emissions) CISPR 24:A2: Class A (International Immunity) IEC 61000-4-2: EN 61000-4-2:2009 Electrostatic Discharge, 8kV Contact, 15 kV Air, Criteria A IEC 61000-4-3: EN 61000-4-3:2006+A1:2008 Radiated Immunity 10V/m, Criteria A IEC 61000-4-4: am1 ed.2./EN 61000-4-4:2004/A1:2010 Transient Burst, 1 kV, Criteria A IEC 61000-4-5: EN 61000-4-5:2006 Surge, 2 kV L-L, 2 kV L-G, Level 3, Criteria A IEC 61000-4-6: EN 61000-4-6:2009 Conducted Immunity, 0.15-80 MHz, 10V/m unmod. RMS, Criteria A IEC/EN 61000-4-11: Power Dips & Interruptions, >30%, 25 periods, Criteria C
IEEE 802.3 Media Access Standards	IEEE 802.3ab 1000BASE-T IEEE 802.3az EEE
Environmental specifications	EN/ETSI 300 019-2-1 v2.1.2 - Class 1.2 Storage EN/ETSI 300 019-2-2 v2.1.2 - Class 2.3 Transportation EN/ETSI 300 019-2-3 v2.1.2 - Class 3.1e Operational ASTM D3580 Random Vibration Unpackaged 1.5 G

Environmental

Environmental Specifications

EN/ETSI 300 019-2-1 v2.1.2 - Class 1.2 Storage
 EN/ETSI 300 019-2-2 v2.1.2 - Class 2.3 Transportation
 EN/ETSI 300 019-2-3 v2.1.2 - Class 3.1e Operational
 EN/ETSI 300 753 (1997-10) - Acoustic Noise
 ASTM D3580 Random Vibration Unpackaged 1.5 G

Environmental Compliance

EU RoHS - 2011/65/EU
 EU WEEE - 2012/19/EU
 EU REACH - Regulation (EC) No 1907/2006 - Reporting
 China RoHS - SJ/T 11363-2006
 Taiwan RoHS - CNS 15663 (2013.7)

Environmental Operating Conditions

Temp: 0°C to 50°C (32°F to 122°F) for Front-Back cooling
 Temp: 0°C to 45°C (32°F to 113°F) for Back-Front cooling (5520-24T, 5520-24x, 5520-48T, 5520-48SE)

Humidity: 5% to 95% relative humidity, non-condensing

Altitude: 0 to 3,000 meters (9,850 feet)

Shock (half sine): 98m/s² (10G), 11ms, 18 shocks

Random vibration: 3Hz to 500Hz at 1.5 G rms

Packaging and Storage Specifications

Temp: -40°C to 70°C (-40°F to 158°F)

Humidity: 5% to 95% relative humidity, non-condensing

Packaged Shock (half sine): 180 m/s² (18 G), 6 ms, 600 shocks

Packaged Vibration: 5Hz to 62Hz at velocity 5 mm/s, 62Hz to 500Hz at 0.2 G

Packaged Random Vibration: 5Hz to 20Hz at 1.0 ASD w/-3 dB/oct. from 20Hz to 200Hz

Packaged Drop Height: 14 drops minimum on sides and corners at 42 inches (<15 kg box)

Standards

North American ITE

UL 60950-1

UL/CuL 62368-1 Listed

Complies with FCC 21CFR 1040.10 (U.S. Laser Safety)

CDRH Letter of Approval (US FDA Approval)

CAN/CSA 22.2 No. 60950-1

European ITE

EN 60950-1, EN 62368-1

EN 60825-1 Class 1 (Lasers Safety)

2014/35/EU Low Voltage Directive

International ITE

CB Report and Certificate per IEC 60950-1

IEC 62368-1

IEEE 802.3 Media Access Standards

IEEE 802.3ab 1000BASE-T

IEEE 802.3bz 2.5G/5GBASE-T

IEEE 802.3bt Type4 PoE

IEEE 802.3ae 10GBASE-X

IEEE 802.3aq 10GBASE-LRM

IEEE 802.3by 25GBASE-X
IEEE 802.3ba/802.3bm 40GBASE-X and 100GBASE-X
IEEE 802.3az Energy Efficient Ethernet

EMI/EMC Standards

North American EMC for ITE

FCC CFR 47 Part 15 Class A (USA)
CB Report and Certificate IEC 62368-1
RoHS Directive 2011/65/EU
AS/NZS 60950-1 (Australia /New Zealand)

European EMC Standards

EN 55035
EN 55032 Class A
EN 55024
EN 55011
EN 61000-3-2,2014 (Harmonics)
EN 61000-3-3 2013 (Flicker)
EN 300 386 (EMC Telecommunications)
2014/30/EU EMC Directive

International EMC Certifications

CISPR 32, Class A (International Emissions)
AS/NZS CISPR32
CISPR 24 Class A (International Immunity)
IEC 61000-4-2/EN 61000-4-2 Electrostatic Discharge, 8kV Contact, 15 kV Air, Criteria B
IEC 61000-4-3 /EN 61000-4-3 Radiated Immunity 10V/m, Criteria A
IEC 61000-4-4/EN 61000-4-4 Transient Burst, 1 kV, Criteria AB
IEC 61000-4-5 /EN 61000-4-5 Surge, 2 kV L-L, 2 kV L-G, Level 3, Criteria B
IEC 61000-4-6 Conducted Immunity, 0.15-80 MHz, 10V/m unmod. RMS, Criteria A
IEC/EN 61000-4-11 Power Dips & Interruptions, >30%, 25 periods, Criteria C

Country Specific

VCCI Class A (Japan Emissions)
ACMA RCM (Australia Emissions)
CCC Mark (China)
KCC Mark, EMC Approval (Korea)
EAC Mark (Custom Union)
NRCS Mark (South Africa)

BSMI Mark (Taiwan)
Anatel (Brazil)
NoM (Mexico)

Power Cord Requirements for AC-Powered Switches and AC Power Supplies

An AC power cord is not included with the AC power supply.

Power cords used with AC-powered switches or AC power supplies must meet the following requirements:

- The power cord must be agency-certified for the country of use.
- The power cord must have an appropriate AC connector for connection to the switch or power supply. See the power supply documentation for the appropriate power cord.
- The power cord must have an appropriately rated and approved wall plug applicable to the country of installation.
- For cords up to 14.76 feet (4.5m) long, the wire size must be 15 AWG (2 mm²) minimum wire length up to 4.92ft (1.5m).

For details about obtaining AC power cords for use in your country, refer to <http://www.extremenetworks.com/product/powercords/>.

Console Connector Pinouts

Table 58 describes the pinouts for a DB-9 console plug connector.

Table 58: Pinouts for the DB-9 Console Connector

Function	Pin Number	Direction
DCD (data carrier detect)	1	In
RXD (receive data)	2	In
TXD (transmit data)	3	Out
DTR (data terminal ready)	4	Out
GND (ground)	5	-
DSR (data set ready)	6	In
RTS (request to send)	7	Out
CTS (clear to send)	8	In

Figure 83 shows the pinouts for a 9-pin to 25-pin (RS-232) null-modem cable.


**Figure 83: Null-Modem Cable Pinouts**

Figure 84 shows the pinouts for a 9-pin to 9-pin (PC-AT) null-modem serial cable.


**Figure 84: PC-AT Serial Null-modem Cable Pinouts**

Table 59 shows the pinouts for the RJ45 console port on the ExtremeSwitching switches.

Table 59: RJ45 Console Port on Switch

Function	Pin Number	Direction
RTS (request to send)	1	Out
DTR (data carrier detect)	2	Out
TXD (transmit data)	3	Out
GND (ground)	4	—
GND (ground)	5	—
RXD (receive data)	6	In

Table 59: RJ45 Console Port on Switch (continued)

Function	Pin Number	Direction
DSR (data set ready)	7	In
CTS (clear to send)	8	In

Table 60 shows the pinouts for an RJ45-to-DB-9 adapter.

Table 60: Pinouts for an RJ45 to DB-9 Adapter

Signal	RJ45 Pin	DB-9 Pin
CTS (clear to send)	1	8
DTR (data carrier detect)	2	6
TXD (transmit data)	3	2
GND (ground)	4	5
GND (ground)	5	5
RXD (receive data)	6	3
DSR (data set ready)	7	4
RTS (request to send)	8	7



Safety and Regulatory Information

[Considerations Before Installing](#) on page 169
[General Safety Precautions](#) on page 170
[Maintenance Safety](#) on page 171
[Fiber Optic Ports and Optical Safety](#) on page 171
[Cable Routing for LAN Systems](#) on page 172
[Install Power Supply Units and Connect Power](#) on page 173
[Select Power Supply Cords](#) on page 174
[EMC Warnings](#) on page 174
[Battery Notice](#) on page 175
[Battery Warning - Taiwan](#) on page 175
[Japan \(VCCI Class A\)](#) on page 175
[Korea EMC Statement](#) on page 176



Warning

Read the following safety information thoroughly before installing Extreme Networks products. Failure to follow this safety information can lead to personal injury or damage to the equipment.

Only trained and qualified service personnel (as defined in IEC 60950-1 and AS/NZS 3260) should install, replace, or perform service to Extreme Networks and their components. Qualified personnel have read all related installation manuals, have the technical training and experience necessary to be aware of the hazards to which they are exposed in performing a task, and are aware of measures to minimize the danger to themselves or other persons.

If you are located in the United States, install the system in accordance with the U.S. National Electrical Code (NEC).

Considerations Before Installing

Consider the following items before you install equipment.

- For equipment designed to operate in a typical Telco environment that is environmentally controlled, choose a site that has the following characteristics:
 - Temperature-controlled and humidity-controlled, such that the maximum ambient room temperature shall not exceed 50°C (122°F).
 - Clean and free from airborne materials that can conduct electricity.
 - Well ventilated and away from sources of heat including direct sunlight.

- Away from sources of vibration or physical shock.
- Isolated from strong electromagnetic fields produced by electrical devices.
- For equipment designed to be installed in environments that are not environmentally controlled, such as outdoor enclosures, see the product data sheet or for environmental conditions, temperature, and humidity.
- Establish at least 3 inches clearance on all sides for effective ventilation. Do not obstruct the air intake vent on the front, side, or rear ventilation grills. Locate the system away from heat sources.
- Make sure that your equipment is placed in an area that accommodates the power consumption and component heat dissipation specifications.
- Make sure that your power supplies meet the site DC power or AC power requirements of all the network equipment.
- Racks for Extreme Networks equipment must be permanently attached to the floor. Failure to stabilize the rack can cause the rack to tip over when the equipment is removed for servicing.
- Do not operate the system unless all modules, faceplates, front covers, and rear covers are in place. Blank faceplates and cover panels are required for the following functions:
 - Preventing exposure to hazardous voltages and currents inside the equipment
 - Containing electromagnetic interference (EMI) that might disrupt other equipment
 - Directing the flow of cooling air through the equipment
- Ultimate disposal of this product should be handled according to all national laws and regulations.

General Safety Precautions

Follow these guidelines:

- Do not try to lift objects that you think are too heavy for you.
- When you install equipment in a rack, load heavier devices in the lower half of the rack first to avoid making the rack top-heavy.
- Use only tools and equipment that are in perfect condition. Do not use equipment with visible damage.
- Route cables in a manner that prevents possible damage to the cables and avoids causing accidents, such as tripping.
- Do not place a monitor or other objects on top of the equipment. The chassis cover is not designed to support weight.
- To reduce the risk of fire, use only #26 AWG or larger telecommunications line cord. Use only copper conductors.
- Do not work on the system or connect or disconnect cables during periods of lightning activity.
- This equipment must be grounded. Never defeat the ground conductor or operate the equipment in the absence of a suitably installed ground conductor.

Maintenance Safety

When you perform maintenance procedures on Extreme Networks equipment, follow these recommendations:

- Use only authorized accessories or components approved for use with this system. Failure to follow these instructions may damage the equipment or violate required safety and EMC regulations.
- This system contains no customer serviceable components. Do not attempt to repair a chassis, power supply, module, or other component. In the event of failure, return the defective unit to Extreme Networks for repair or replacement, unless otherwise instructed by an Extreme Networks representative.
- To remove power from the system, you must unplug all power cords from wall outlets. The power cord is the disconnect device to the main power source.
- Disconnect all power cords before working near power supplies, unless otherwise instructed by a product-specific maintenance procedure.
- Replace a power cord immediately if it shows any signs of damage.
- When you work with optical devices, power supplies, or other modular accessories, put on an ESD-preventive wrist strap to reduce the risk of electronic damage to the equipment. Connect the other end of the strap to an appropriate grounding point on the equipment rack or to an ESD jack on the chassis if one is provided. Leave the ESD-preventive wrist strap permanently attached to the equipment rack or chassis so that it is always available when you need to handle components that are sensitive to ESD.
- Install all cables in a manner that avoids strain. Use tie wraps or other strain relief devices.

Fiber Optic Ports and Optical Safety

The following safety warnings apply to all optical devices used in Extreme Networks equipment that are removable or directly installed in an I/O module or chassis system.

Such devices include but are not limited to gigabit interface converters (GBICs), small form factor pluggable (SFP) modules (or mini-GBICs), QSFP+ modules, XENPAK transceivers, and XFP laser optic modules.



Warning

Laser optic modules become very hot after prolonged use. Take care when removing a laser optic module from the module or option card. If the laser optic module is too hot to touch, disengage the laser optic module and allow it to cool before removing it completely.

When working with laser optic modules, always take the precautions listed below to avoid exposure to hazardous radiation.

- Never look at the transmit LED/laser through a magnifying device while the transmit LED is powered on.
- Never look directly at a fiber port on the switch or at the ends of a fiber cable when they are powered on.

- Invisible laser radiation can occur when the connectors are open. Avoid direct eye exposure to the beam when optical connections are unplugged.
- Never alter, modify, or change an optical device in any way other than suggested in this document.

GBIC, SFP (Mini-GBIC), QSFP+, XENPAK, and XFP Regulatory Compliance

Extreme Networks pluggable optical modules and direct-attach cables meet the following regulatory requirements:

- Class 1 or Class 1M Laser Product
- EN60825-1:2007 2nd Ed. or later, European standard
- FCC 21 CFR Chapter 1, Subchapter J in accordance with FDA & CDRH requirements
- Application of CE Mark in accordance with 2014/30/EU EMC Directive and the 2014/35/EU Low Voltage Directives
- UL and/or CSA registered component for North America
- 47 CFR Part 15, Class A when installed into Extreme products

Cable Routing for LAN Systems

Extreme Networks equipment meets the requirements for LAN system equipment.

LAN systems are designed for intra-building installations; that is, cable runs between devices must be in the same building as the connected units, except under the conditions listed in the next paragraph.

As allowed in the USA by the National Electrical Code (NEC), this equipment can be connected between buildings if any one of the following conditions is true:

- Cable runs between buildings are less than 140 feet long.
- Cable runs between buildings are directly buried.
- Cable runs between buildings are in an underground conduit, where a continuous metallic cable shield or a continuous metallic conduit containing the cable is bonded to each building grounding electrode system.



Caution

Failure to follow these requirements for cable routing conditions may expose the user to electrical shock and expose the unit to damage that can cause errors.

**Warning**

The Ethernet ports of the equipment and its sub-assemblies are suitable only for intra-building connections (within the same building) or for connections to unexposed wiring or cabling. (See the conditions listed above.) The Ethernet ports of this equipment or its sub-assemblies must not be metallically connected to interfaces that connect to the outside plant (OSP) or its wiring. Ethernet interfaces are designed for use only as intra-building interfaces (described as Type 2 or Type 4 ports in GR-1089-CORE, Issue 6) and require isolation from the exposed OSP wiring. The addition of Primary Protectors is not sufficient protection to connect these interfaces metallically to OSP wiring.

Install Power Supply Units and Connect Power

For the ratings and power input requirements of each power supply unit, see [Technical Specifications](#) on page 139 or the data sheet for the power supply at www.extremenetworks.com.

**Warning**

Be sure to satisfy the requirements listed in this section when you install Extreme Networks power supplies or connect power.

When you install any power supply:

- Do not use excessive force when you insert a power supply into the bay.
- Do not attempt to open the power supply enclosure for any reason; the power supply does not contain user-serviceable parts. In the event of failure, return the defective power supply to Extreme Networks for repair or replacement.
- Do not put your hand into an open power supply bay when a power supply is not present.
- Before you work on equipment that is connected to power lines, remove all jewelry, including watches. Metal objects heat up when they are connected to power and ground and can cause serious burns or weld the metal object to the terminals.
- An electrical arc can occur when you connect or disconnect the power with power applied. This could cause an explosion in hazardous area installations. Be sure that power is removed from the device.
- When you install or replace equipment, always make the ground connection first and disconnect the ground connection last.

When you install DC power supplies or connect DC power:

- Extreme Networks DC power supplies do not have switches for turning the unit on and off. Make sure that the DC circuit is de-energized before connecting or disconnecting the DC power cord at the DC input power socket.

- Connect the system or power supply only to a DC power source that complies with the safety extra-low voltage (SELV) requirements in IEC 60950-based safety standards.

**Note**

Because building codes vary worldwide, consult an electrical contractor to ensure proper equipment grounding and power distribution for your specific installation and country.

**Warning**

Extreme Networks power supplies do not have switches for turning the unit on and off. Disconnect all power cords to remove power from the device. Make sure that these connections are easily accessible.

Extreme Networks alimentations n'ont pas de contact pour mettre l'appareil sous et hors tension. Débranchez tous les cordons d'alimentation pour couper l'alimentation de l'appareil. Assurez-vous que ces connexions sont facilement accessibles.

Select Power Supply Cords

You can purchase a power cord for your product and for your specific country from your local Extreme Networks Channel Account Manager or Sales Manager, or you can purchase a cord from your local supplier. Requirements for the power cord are listed in the Technical Specifications for your product.

To locate a Sales Manager or Partner in your region, visit www.extremenetworks.com/partners/where-to-buy.

**Note**

This equipment is not intended to be directly powered by power distribution systems where phase-phase voltages exceed 240 VAC (2P+PE), such as those used in Norway, France, and other countries. For these applications, use a transformer to step down the voltage to < 240 VAC from phase-phase, or make a connection to a (P+N+PE) power distribution where voltages do not exceed 240 VAC.

All installations should confirm that the product is reliably grounded according to the country's local electrical codes.

EMC Warnings

Taiwan BSMI Warning

**警告: 為避免電磁干擾, 本產品不應安裝
或使用於住宅環境。**

China CQC Warning

警告:在居住环境中，运行此设备可能会造成无线电干扰。

Battery Notice



Warning: This product contains a battery used to maintain product information. If the battery should need replacement it must be replaced by Service Personnel. Please contact Technical Support for assistance.

Risk of explosion if battery is replaced by an incorrect type. Dispose of expended battery in accordance with local disposal regulations.



Attention: Ce produit renferme une pile servant à conserver les renseignements sur le produit. Le cas échéant, faites remplacer la pile par le personnel du service de réparation. Veuillez communiquer avec l'assistance technique pour du soutien.

Il y a risque d'explosion si la pile est remplacée par un type de pile incorrect. Éliminez les piles usées en conformité aux règlements locaux d'élimination des piles.

Battery Warning - Taiwan

警告

**如果更換不正確之電池型式會有爆炸的風險，
請依製造商說明書處理用過之電池。**

Japan (VCCI Class A)



Warning

This is a Class A product based on the standard of the VCCI Council. If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

この装置は、クラスA機器です。この装置を住宅環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

Korea EMC Statement

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.



Index

Numerics

- 1100 W AC power supply
 - features 38
- 2000 W AC power supply
 - features 39
- 3-slot modular shelf
 - and Half-Duplex to Full-Duplex Converter 132
- 350 W AC power supply
 - features 36
- 550 W AC power supply
 - features 36, 37
- 550 W DC power supply
 - features 36, 37
- 5520 series switches
 - features 15–19
 - specifications 140, 142
- 5520 Series switches
 - features 19
 - LEDs 135–137
- 5520-VIM-4X
 - module
 - features 50
- 5520-VIM-4XE
 - module
 - features 51
- 5520-VIM-4YE
 - module
 - features 52
- 715 W AC power supply
 - features 38
- 715 W DC power supply
 - features 38

A

- AC power
 - requirements for cords 166
- AC power supplies
 - install 91
- access 74
- acoustic noise
 - V400 Virtual Port Extender 160
- acquired node
 - definition 62
- active node 61
- active topology 61
- airflow 100, 105
- alert, power supply 36, 37
- alternate stacking 60

- announcements xi, xii
- ANSI standards 85

B

- backup node
 - definition 61
 - redundancy 55
- battery notice 175
- bend radius 80
- BICSI 78
- building codes 73
- Building Industry Consulting Service International,
see BICSI

C

- cabinet
 - attaching switch 88, 90
- cable
 - ANSI standards 85
 - bend radius 80
 - fiber optic 80
 - for stacking 66
 - installing 80
 - optical 91
 - RJ45 81
 - standards 78
 - types and distances 81
- candidate node 61
- combining
 - switches in a stack 65
- commercial building standards 85
- components
 - optional 91
- connecting
 - to management console 94
- connector jackets
 - RJ45 81
- connector pinouts
 - DB-9 console connector 166
 - null-modem cable 166
- console port
 - 5520 series 15–19
 - for stacked configurations 71
 - on switch 166
 - settings 94
- control path 60
- conventions

conventions (*continued*)

notice icons ix

text ix

cooling 100, 105

cords

requirements 166

selecting 174

D

daisy chain topology 59

data port 62

DB-9 console connector pinouts 166

DB-9 pinouts 166

design standards 85

distances

cables 81

documentation

feedback xii

location xi

dual primary condition 59

E

Easy-Setup 63

election

node role 62

priority 62

electrical codes 73

environmental requirements

building codes 73

electrical codes 73

humidity 76

temperature 75

wiring closet 74

equipment

tools needed to install 87

equipment rack

grounding 77

mechanical recommendations 77

mounting holes 77

securing 78

service access 77

space requirements 77

F

failover 62

fan

airflow 100, 105

replacing 105

feedback xii

fiber optic cable

bend radius 80

handling 80

installing 80

frequency, *see* radio frequency interference (RFI)

front-to-back cooling 100, 105

G

grounding

racks 77

requirements 85

wiring closet 74

H

Half-Duplex to Full-Duplex Converter

connecting to power 133

installing 132, 133

mounting in a rack 132

mounting on a flat surface 132

mounting on a shelf 132

mounting on a wall 133

specifications 161, 162

hitless failover 62

humidity 76

I

industry standards 85

install

AC power supplies 91

internal power supplies 91

power supplies 91

installing

fiber optic cable 80

Half-Duplex to Full-Duplex Converter 132, 133

optical transceivers 91

optional components 91

personnel 87

preparing 87

safety information 87

switches 87, 88, 90

tools 87

V300 Virtual Port Extender 110, 111, 114, 116, 118, 121, 124, 127, 128

V400 Virtual Port Extender 131

internal power supplies

install 91

J

jackets

RJ45 connector 81

L

LEDs

5520 Series 135–137

5520-VIM 138

stack number indicator 55

local management connection 94

M

MAC address 62

- management port
 - 5520 series 15–19
 - connecting to switch 94
 - for stacked configurations 71
 - settings 94
- multiple-rack stacking 70

N

- native stacking 60
- native stacking ports 54
- node address 62
- node role
 - definition 61
 - election 62
- notices ix
- null-modem cable pinouts 166

O

- operating environment requirements 75
- operational node 62
- optical cables
 - installing 91
- optical transceivers
 - installing 91
- optional components
 - installing 91

P

- partitioning
 - of ports 27
- pinouts
 - DB-9 console connector 166
 - null-modem cable 166
- planning
 - site 72
- pluggable transceivers, *see* optical transceivers
- ports
 - console port settings 94
 - for stacked configurations 71
 - management 94
 - native stacking 54
 - partitioning 27
- power
 - requirements for cords 166
- power cords
 - selecting 83, 174
- power over Ethernet (PoE)
 - power requirements 82
- power requirements
 - PoE devices 82
 - power supply 82
- power specifications
 - V300 Virtual Port Extender 156, 157
 - V400 Virtual Port Extender 159, 160
- power supplies
 - install 91

- power supply unit (PSU)
 - 1100 W AC 38
 - 2000 W AC 39
 - 350 W AC 36
 - 550 W AC 36, 37
 - 715 W AC 38
 - alert 36, 37
 - power requirements 82
- primary node
 - definition 61
 - redundancy 55
- primary switch 64
- priority
 - for node role election 62
- product announcements xi, xii

Q

- QSFP+ ports
 - partitioning 27
- QSFP28 ports
 - partitioning 27

R

- rack
 - attaching switch 88, 90
- rack specifications
 - grounding 77
 - securing to floor 78
 - space requirements 77
- radio frequency interference (RFI)
 - preventing 82
- redundancy
 - in a stack 55
- restricted 74
- restricted access 74
- RFI, *see* radio frequency interference (RFI)
- ring topology 57
- RJ45 cable 81

S

- safety
 - precautions when installing 87
- secure boot 31, 32
- service access to the rack 77
- settings
 - for management console 94
- signal quality 82
- single-rack stacking 69
- site planning 72
- site preparation 87
- slot number 55
- space requirements, rack 77
- specifications
 - 5520 switch 140, 142
 - equipment racks 77
 - Half-Duplex to Full-Duplex Converter 161, 162

specifications (*continued*)
 V300 virtual port extender 155–157
 V400 virtual port extender 158–161
 stack 60
 see also SummitStack
 stack number indicator 55
 stackable switch 60
 stacking
 backup 55
 cables 66
 combining switch models 65
 connecting cables 71
 connecting management port 71
 connection order 68
 daisy chain 59
 definition 54
 dual primary condition 59
 examples 69, 70
 guidelines 64
 LEDs 55
 multiple-rack 70
 native stacking ports 54
 primary 55
 priority 55
 recommendations 64
 redundancy 55
 ring topology 57
 single-rack 69
 slot number 55
 stack number indicator 55
 terminology 60
 troubleshooting 55
 stacking link 60
 stacking port 60
 standards
 cabling 78, 85
 commercial building 85
 design 85
 grounding 85
 standby node
 definition 61
 SummitStack
 path 60
 segment 63
 state 63
 topology 56, 60
 SummitStack configuration 53
 support
 technical support xi, xii
 switches
 attaching to cabinet 88, 90
 attaching to rack 88, 90
 installing optional components 91
 safety information 87
 tools needed to install 87

T

technical support

technical support (*continued*)
 contacting xi, xii
 temperature 75
 tools for installing equipment
 switches 87
 transceivers, *see* optical transceivers
 transition time
 UPS 84
 troubleshooting stack connections 55

U

UPS (uninterruptible power supply)
 requirements 83
 selecting 84
 transition time 84
 UTP cable
 preventing RFI 82

V

V300 virtual port extender
 specifications 155–157
 V300 Virtual Port Extender
 DIN rail mounting in a rack 124
 environmental data 157
 installing 110, 111, 114, 116, 118, 121, 124, 127, 128
 mounting in a rack 110, 111, 116, 118, 121, 127, 128
 power specifications 156, 157
 table 114
 V300 virtual port extender LEDs 47
 V300-8P-2T-W 44
 V300-8T-2X 43
 V400 virtual port extender
 specifications 158–161
 V400 Virtual Port Extender
 acoustic noise 160
 environmental data 160
 installing 131
 mounting in a rack 131
 power specifications 159, 160
 versatile interface module (VIM)
 5520-VIM-4X 50
 5520-VIM-4XE 51
 5520-VIM-4YE 52
 virtual port extender 42–48

W

warnings ix
 wiring closet
 floor coverings 74
 grounding 74
 humidity 76
 rack, securing 78
 temperature 75
 wiring terminals 77