

Software Release V2.0.1

Part No. 309976-B Rev 00
February 2000

4401 Great America Parkway
Santa Clara, CA 95054

Release Notes for the BayStack 450 10/100/1000 Series Switch



NORTEL
NETWORKS™

Copyright © 2000 Nortel Networks

All rights reserved. Printed in the USA. February 2000.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

Trademarks

NORTEL NETWORKS is a trademark of Nortel Networks.

Bay Networks and Optivity are registered trademarks and Accelar, BayStack, EZ LAN, Optivity Campus, Optivity Enterprise, StackProbe, and the Bay Networks logo are trademarks of Nortel Networks NA Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks NA Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks NA Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Nortel Networks NA Inc. Software License Agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as “Software” in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH NORTEL NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License Grant. Nortel Networks NA Inc. (“Nortel Networks”) grants the end user of the Software (“Licensee”) a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Nortel Networks Agent software or other Nortel Networks software products. Nortel Networks Agent software or other Nortel Networks software products are licensed for use under the terms of the applicable Nortel Networks NA Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Nortel Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Nortel Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Nortel Networks’ and its licensors’ confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Nortel Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee’s facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Nortel Networks warrants each item of Software, as delivered by Nortel Networks and properly installed and operated on Nortel Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Nortel Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Nortel Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Nortel Networks will replace defective media at no charge if it is returned to Nortel Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Nortel Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Nortel Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Nortel Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL NORTEL NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF NORTEL NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO NORTEL NETWORKS FOR THE SOFTWARE LICENSE.

5. Government Licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Nortel Networks of any such intended examination of the Software and may procure support and assistance from Nortel Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Nortel Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Nortel Networks copyright; those restrictions relating to use and disclosure of Nortel Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Nortel Networks the Software, user manuals, and all copies. Nortel Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and Re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Nortel Networks, 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN NORTEL NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST NORTEL NETWORKS UNLESS NORTEL NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Introduction

These release notes contain important information about software version V2.0.1 for the BayStack™ 450 switch that may not be included in the related user guide *Using the BayStack 450 10/100/1000 Series Switch* (Part number 309978-A Rev 00). The information in these release notes supersedes the applicable information in the user guide.

These release notes contain the following sections:

- “Upgrading the BayStack 450 Firmware” (page 1)
- “The Upgrade Process” (page 2)
- “Accessing the Firmware Images” (page 4)
- “Upgrade Restrictions” (page 4)
- “Nortel Networks Online Documentation” (page 5)
- “New Features” (page 6)
- “Bug Fixes” (page 6)
- “Known Restrictions” (page 8)
- “Known Problems” (page 12)
- “Connecting to Accelar Gigabit Ports” (page 13)
- “1000BASE-LX Connectors” (page 13)
- “Replacing MDAs” (page 14)
- “Network Management” (page 15)

Upgrading the BayStack 450 Firmware

The BayStack 450 switch firmware provides a code load facility that allows you to upgrade the firmware image over any switch port, including any MDA ports.

The BayStack 400-ST1 Cascade Module *will not operate* with BayStack 450 switches that are configured with BayStack 450 software versions *earlier than* version V1.1.0. You *must upgrade all units* with BayStack 450 software version V1.1.0 (or later) *before* installing the BayStack 400-ST1 Cascade Modules.

To access the firmware images, see “Accessing the Firmware Images” on page 4.

The Upgrade Process

Upgrading the BayStack 450 switch to software version V2.0.1 is a two-step process:

1. **Download the *boot code image*.**
2. **Download the *agent image*.**

To properly upgrade the BayStack 450 switch, the boot code image *must be downloaded first*, before you download the agent image. If the agent image (the operational firmware) is downloaded before the boot code image, the firmware may not be programmed into the BayStack 450 switch FLASH memory.

The switch indicates a failed image load as follows: An alternating LED pattern is displayed on the BayStack 450-24T 10/100 status LEDs (ports 13 to 24), on the BayStack 450-12T 10/100 status LEDs (ports 1 to 12), and on the BayStack 450-12F Link status LEDs (ports 1 to 12).

If this happens, cycle the switch power (power off the switch, then power it on). Use the Software Download screen to download the new boot code image. After the boot code image download completes, download the new agent image.

Important Considerations

When you upgrade your BayStack 450 switch:

- Download *two images* (the *boot code image* and the *agent image*). The new boot code image must be downloaded *before* the agent image is downloaded.
- After upgrading your units, verify the firmware and software versions in the sysDescr field of the System Characteristics screen.

The firmware version should be **FW:V1.44** and the software version should be **SW:V2.0.1**.



Note: When you upgrade to software version V2.0.1, you should also obtain a copy of *Using the BayStack 450 10/100/1000 Series Switch* (Part number 309978-A Rev 00). That user guide provides information about using the new software version V2.0 features. See “Nortel Networks Online Documentation” on page 5 to get the latest version of the user guide.

Recovering from a Failed Upgrade

The upgrade process is a fairly straightforward process when implemented correctly. However, if you do not follow the correct steps to upgrade your switch, the switch can become temporarily disabled.

- If you install a BayStack 400-ST1 Cascade Module before you upgrade the switch to software version V1.1.0 (or later), the code load facility may not function properly:
 - To correct this situation, remove the BayStack 400-ST1 Cascade Module and upgrade the firmware properly before reinstalling it.
- If you try to download the agent image *before* you download the boot code image, the upgrade may fail:
 - The agent firmware can detect an incompatible revision and will discontinue programming itself into FLASH memory. This condition is indicated by a steady pattern of alternating LEDs.
 - The switch will not automatically reset. To recover from this condition, you must cycle power to the switch, upgrade the boot firmware, and then upgrade the agent firmware.

Stack Installation Tips

When you install your stack:

- All switches must have the same software version before they are configured in a stack. Units with software versions that are different from the base unit will not join the stack. This condition is indicated by CAS Up and CAS Dwn LEDs blinking on those units.
- In a properly configured stack configuration, you can upgrade the entire stack as a single unit.
- Select only one unit, preferably the top unit or the bottom unit, as the base unit by setting the Unit Select Switch on the cascade module to the Base position (up = Base).

Accessing the Firmware Images

You can access the firmware image files directly from the Internet:



Note: When upgrading the firmware image, you must download *two images* (the *boot code image* and the *agent image*). You must download the boot code image *before* you download the agent image.

1. **Go to** *support.baynetworks.com/software*.
2. **Under the BayStack Workgroup Products heading, select BayStack_450x, then click the Go button.**
3. **Under the Operational Software heading, click on BayStack 450 Ethernet Switch boot code V2.0.1.**

Follow the prompts to download the BayStack 450 boot code image. The boot code image file name is *b4502011.img*.

4. **After the BayStack 450 boot code image is downloaded, click on BayStack 450 Ethernet Switch agent V2.0.1.**

Follow the prompts to download the BayStack 450 agent image. The agent image file name is *b4502012.img*.

For detailed information about downloading a new software image, see Chapter 3, “Using the Console Interface,” in *Using the BayStack 450 10/100/1000 Series Switch*.

Upgrade Restrictions

The following restrictions apply when you upgrade the switch firmware to software version V2.0.1:

- When you upgrade a stack configuration that uses a Gigabit distributed trunk for the uplink to the TFTP server, you must first disable the uplink trunk at both ends.
- When you upgrade a stack configuration that contains a BayStack 410-24T unit (which is configured with at least one distributed trunk member), and the distributed trunk is the uplink to the TFTP server, you must first disable the uplink trunk at both ends.

-
- The firmware cannot be upgraded to software version V2.0.1 through a port that is configured for *tagged* traffic; upgrade your switch firmware to software version V2.0.1 through a port that is configured as an *untagged* member of VLAN 1. (Software version V2.0.1 now supports upgrades to future versions over VLANs other than VLAN 1, with tagged or untagged ports.)
 - When the BayStack 450 switch is upgraded with the new boot code image, all existing entries in the Event Log are erased. This corrects a potential problem with an earlier software version. A new entry is written to the Event Log confirming the upgrade of the boot code image.
 - During the load process, the ports are configured as follows:
 - Twisted-pair ports: autonegotiation enabled
 - Fiber optic ports: 100 Mb/s, half-duplex
 - Gigabit MDA ports: autonegotiation disabled, Preferred Phy set to Right

Nortel Networks Online Documentation

To be sure you have the latest updates to your product documentation, including these release notes, visit the Nortel Networks™ Web site at the following location:

support.baynetworks.com/library/tpubs/

Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Using Adobe Acrobat Reader, you can open the manuals and release notes, search for the sections you need, and print them on most standard printers. You can download Acrobat Reader free from the Adobe Systems Web site, *www.adobe.com*.

You can purchase selected documentation sets, CDs, and technical publications through the collateral catalog. The catalog is located on the World Wide Web at *support.baynetworks.com/catalog.html* and is divided into sections arranged alphabetically:

- The “CD ROMs” section lists available CDs.
- The “Guides/Books” section lists books on technical topics.
- The “Technical Manuals” section lists available printed documentation sets.

New Features

Software version V2.0.1 provides the following new features:

- **Fast Aging:** When a link-down is detected on a port, all addresses learned on that port are aged out within 20 seconds.
- **Download Timeout:** The new boot code extends the timeout for downline loads from 2.5 minutes to 11 minutes. This change allows you to use slower links for downline loads.

The following features were provided with software version V2.0:

- Protocol-based VLANs
- RADIUS authentication support for TELNET and console access
- Support for upgrade over VLANs other than VLAN 1 (tagged or untagged)
- User-specified management VLAN
- IGMP multicast group display screen
- Link up/down traps configurable per port
- Enhanced SNMP support for network management tools
- Support for stack event traps (for example, if a unit leaves or joins the stack, or if a new base-unit is assigned)
- Support for Autotopology

Bug Fixes

The following problems are corrected with software version V2.0.1:

- You can use an SNMP network management tool to change or delete MultiLink Trunk members while the MultiLink Trunk is enabled.
- IGMP host reports will be sent out of mirrored gigabit ports.
- If you change a port from full-duplex mode to half-duplex mode, the s5ChasBrdLed MIB object will now properly reflect the change.
- If you change the switch or stack-wide autonegotiation setting, and then immediately reset your switch, the ports will be properly configured to autonegotiate after the restart.

-
- The MIB object rcPortAdminDuplex indicates the correct value for a gigabit port.
 - When a stack is configured with multiple Distributed MultiLink Trunks (DMLTs), and one or more members of a DMLT are disconnected, the DMLT will continue to pass traffic normally.
 - You can now configure a port mirroring monitor port on a standalone unit.
 - Conflicts between console configuration and simple network management protocol (SNMP) configuration of MultiLink Trunks have been corrected.
 - When using SNMP to get an alarm log, you do not need to connect to the stack through the base unit.
 - If you try to download a version of agent code into a stack that is configured with a nonsupported unit, the Software Download screen displays an error message that indicates the nonsupported unit within the stack.
 - When renumbering stack units, you can now set the unit number on more than one stack unit at a time to zero.
 - When a unit leaves a stack, autotopology packets now indicate the unit's standalone switch MAC address.
 - When you log into a stack configuration that has the console passwords enabled using the read-only password, you can now view any multiple gigabit MDA settings that are configured within your stack.
 - The current state of an inactive MultiLink Trunk is now correctly reported.
 - Your switch will no longer transmit extra Host Membership Queries when IGMP proxy is enabled.

Software version V2.0 corrected the following problem:

- When replacing an MDA with another type of MDA, you no longer have to cycle the switch power between the MDA removal and replacement procedures (see “Replacing MDAs” on page 14).

Known Restrictions

The following known restrictions apply to software version V2.0.1 (and earlier versions):

- You cannot assign a port to multiple protocol VLANs that have the same protocol ID (not applicable to gigabit ports or BayStack 410-24T ports).
- If you manually configure a port path cost, the path cost is not recalculated regardless of speed or trunk state changes.
- MultiLink Trunking

MultiLink Trunking allows you to group ports of varying speeds (for example, you can group 10 Mb/s, 100 Mb/s, and 1000 Mb/s ports in any combination). Although this is a valid configuration, Nortel Networks recommends that you only group ports of equivalent speeds when configuring a trunk. The MultiLink trunk algorithm distributes connections across all of the available links in the trunk, regardless of speed.

- System reset due to MultiLink Trunking reconfiguration

If you add a new unit, that is configured with at least one bounded trunk¹ (with no distributed trunks²), into a stack that is configured with one or more distributed trunks, the new unit automatically resets before entering the operational mode of the stack.

- MultiLink Trunking interoperability with AccelarTM

When a Distributed MultiLink trunk (DMLT) is connected to an Accelar switch, and you reset one of the stack units or change the spanning tree status of the DMLT, each unit sends out a (standalone) BPDU frame through the DMLT port. This can cause Accelar switches with software versions prior to V2.0.5 to disable the DMLT.

If this happens, reset the Accelar switch. If resetting the Accelar switch does not correct the problem, contact your Nortel Networks Technical Solutions Center (see “How to Get Help” in *Using the BayStack 450 10/100/1000 Series Switch*).

¹Bounded trunk: an active trunk with all trunk members configured on the same module.

²Distributed trunk: an active trunk with trunk members configured on at least two different units within a single stack.

-
- Monitoring outgoing frames on trunk member ports

When you monitor outgoing frames on a full-duplex port that is a MultiLink trunk member, Nortel Networks recommends that you use the address-based mirroring mode. If you use port-based mirroring with this type of configuration, some frames may not be displayed.

- IEEE 802.1D spanning tree parameters

Spanning tree parameters cannot be configured from the console interface (CI) menus and screens.

Configuration support is available through the Bridge MIB using Simple Network Management Protocol (SNMP). Refer to RFC 1493 for more information.

- Spanning tree port participation

The Fast Learning value (used with the Participation field in the Spanning Tree Port Configuration screen) is the same as the Normal Learning value, except that the state transition timer is shortened to 2 seconds.

Nortel Networks recommends using the Fast Learning value to optimize switch-to-endstation connections. When you connect one switch to another switch, the Normal Learning (default) value provides the best results.

- Spanning Tree Participation disabled for monitor port

When you use the Port Mirroring feature in a standalone switch configuration, the Spanning Tree Participation for the monitor port is automatically set to Disabled. If you then insert the same standalone switch into a stack, the Spanning Tree Participation for the previously configured monitor port *remains* Disabled. You must manually reset the Spanning Tree Participation to Normal Learning or Fast Learning using the Spanning Tree Port Configuration screen.

- The spanning tree configuration must be the same on both ends of a MultiLink trunk.

- Autonegotiation restriction with gigabit ports

The BayStack 450 switch gigabit MDA ports comply with IEEE 802.3z Draft 3.2 and IEEE 802.3z Draft 4.1; however, the following restriction applies to the autonegotiation feature:

-- Autonegotiation does not restart if an invalid code word is received from the link partner during the autonegotiation process. In cases where autonegotiation fails, disable and then enable autonegotiation.

- Redundant gigabit Phy

You cannot use the redundant gigabit Phy port (the backup Phy port) to create two different paths.

- RMON Alarms and Event entries

RMON Alarms and Event entries are *not* saved to nonvolatile random access memory (NVRAM). When a reset condition or power-down sequence occurs, the entries are not preserved. This conforms to the current RFC 1757 standard. All RMON Alarms and Events must be reentered.

- RMON Event Log table's secondary index

The RMON Event Log table's secondary index is not incremented when all of the table's entries have been used. In this case, the existing indexes are reused. Thus, the index number cannot be used to indicate the total number of log entries received.

- RMON History Control entries

A maximum of 85 RMON History Control entries per stack unit are supported. The entry exists on the unit containing the "ControlDataSource".

- Adding or removing stack units

When you add a new unit to the stack or remove an existing stack unit, you will not be able to perform IP management functions for approximately 30 seconds.

During this time period, the following can occur:

- Packets are lost when performance testing with SmartBits or any other traffic generator.
- IP Multicast streams stop receiving.
- TELNET sessions time out and users lose their TELNET connection without warning. Users must re-establish lost TELNET sessions.
- ICMP echo (PING) requests do not receive responses.
- All IP-related processes fail temporarily.

- Changing from a stack unit to a standalone switch

When you change a switch from a stack unit into a standalone switch, or vice versa, the IP address of the switch/stack changes. As a result, all existing management applications that use the previous IP address are lost until you reconnect using the new IP address.

-
- Console may display a blank screen

When you connect a console terminal to an operating switch through the Comm Port, the console may display a blank screen. This is a normal condition. Press [Ctrl]-C to refresh the screen or, to get beyond the Nortel Networks logo screen, press [Ctrl]-Y.

- Tagged bridge protocol data units (BPDUs)

Tagged BPDUs are not supported in this version.

- Network interface controllers (NICs)

The MultiLink Trunking feature supports only multiport NICs that are configured as a single MAC address, single IP address entity.

- Downgrading a switch or stack to a software version earlier than software version V2.0



Note: Software versions earlier than software version V2.0 do not support distributed trunking. You must remove any distributed trunks before you downgrade the switch to software versions earlier than software version V2.0 or problems will occur.

If you must downgrade a switch from software version V2.0 (or later) to an earlier version, you must first remove any existing distributed trunks using the MultiLink Trunk Configuration screen. You can remove the trunk by disabling the trunk and setting all the trunk members to none [blank field].

If you downgrade a switch with a bounded MultiLink trunk from software version V2.0 (or later) to an earlier version, some ports may become disabled. If this happens, you can enable the ports again using the Port Configuration screen.

- Configuring port mirroring monitor ports

Nortel Networks recommends that you configure the port mirroring monitor port to be on the same stack unit as the mirrored ports.

Known Problems

The following problems are known to exist in software version V2.0.1 (and earlier versions):

- When you remove a unit from a stack configuration, the value of rcVlanPortMembers MIB object does not update.
- When you enable RADIUS authentication support with a server IP address and a shared secret, be aware that if you then remove the RADIUS IP address or the shared secret you will be locked out of the console and TELNET. Before you remove the server IP address or the shared secret, first disable RADIUS authentication.
- The following MIB objects for Gigabit ports return the wrong value and cause some SNMP network management applications to incorrectly report the port speed/duplex mode:
 - rcPortAdminSpeed
 - rcPortOperDuplex
 - rcPortOperSpeed
- Gigabit MDA ports count oversized frames (larger than 1785 bytes) as both oversized frames *and* as lost frames.
- MDAs must be *firmly secured* in the chassis for proper operation. Be sure to secure the MDA in the chassis by *firmly* tightening the two thumbscrews on the MDA front panel.
- A link state cannot be established when you plug a cable that is 100 percent utilized into a BayStack 450 switch port. As soon as a break in the traffic occurs, the link state is established.
- When you connect the BayStack 450 switch to an Alteon network interface controller (NIC), the switch learns invalid MAC addresses whenever autonegotiation for a gigabit MDA port is enabled (the invalid MAC addresses eventually age out).

This problem occurs only when you reset the switch (via the console interface main menu or during a power cycle) and does not affect the correct operation of the BayStack 450 switch.
- Some SNMP commands fail if your base unit has a unit ID other than 1.

Connecting to Acclar Gigabit Ports

The BayStack 450 switch supports gigabit MDA port connections to the Nortel Networks Acclar switch gigabit ports, with the following restrictions:

- Autonegotiation *is not* supported on the Acclar 1000BaseSXWG (ASIC Version *GMAC 2*).

When connecting to this version, disable autonegotiation on the BayStack 450 switch gigabit MDA port.

- Autonegotiation *is* supported on the Acclar 1000BaseSXWG (ASIC Version *GMAC 4*).

When connecting to this version, set autonegotiation to enabled (or disabled) at both ends of the communications link. The autonegotiation setting must be identical at both ends of the communications link.

You can determine the ASIC version number for the 1000BaseSXWG gigabit card using the following command from the Acclar console port:

```
Acclar-1100# sh sys info
```

1000BASE-LX Connectors

The 1000BASE-LX (gigabit) MDAs use a longwave 1300 nm, fiber optic transceiver to connect devices over single-mode (5 km/16,405 ft) or multimode (550 m/1,805 ft) fiber optic cables.



Note: The transceiver must be mode conditioned externally via a special offset SMF/MMF patch cord for 1000BASE-LX multimode applications. The offset SMF/MMF patch cord allows the same transceiver to be used for both multimode and single-mode fiber. See your Nortel Networks sales representative for more information about the SMF/MMF patch cord.

The optical performance of this transceiver cannot be guaranteed when connected to a multimode fiber plant without the use of the special offset SMF/MMF (mode conditioning) patch cord.

The 1000BASE-LX MDA transceiver is designed to mechanically accommodate the *single-mode ferrules* used on one end of the special offset SMF/MMF patch cord. *Multimode ferrules* can bind and cause damage to the transceiver.



Caution: Do not connect multimode cables directly into the 1000BASE-LX MDA transceiver. Connect a special offset SMF/MMF patch cord into the transceiver, then connect the multimode cable into the SMF/MMF patch cord.

For more information about gigabit transmission over fiber optic cable and mode conditioning, refer to:

Reference Note: Gigabit Ethernet Physical Layer Considerations
(Part number 201540-B).

The publication is available on the World Wide Web at support.baynetworks.com/library/tpubs/. At the Web site, click on Accelar under the Routing Switches heading.

Replacing MDAs

When replacing an installed MDA with another type of MDA, complete the following steps to clear the NVRAM:

1. Power down the BayStack 450 switch.

Remove the AC power cord from the power source.

2. Remove the installed MDA.

Loosen the thumbscrews and remove the MDA.

3. Cycle the switch power¹.

Power up the switch and wait for the Nortel Networks logo screen to appear (approximately 10 seconds); then power down the switch.

4. Install the replacement MDA.

Be sure to *firmly* tighten the two thumbscrews on the MDA front panel (refer to the MDA installation documentation).

5. Power up the switch.

¹Not required for software version V2.0 and later.

Network Management

Table 1 lists the supported network management applications that are available for your BayStack 450 switch:

Table 1. Supported Network Management Applications

Application	BayStack 450 Software Version V1.2 (HW Rev B and D)	BayStack 450 Software Version V1.3.0/V1.3.1/V1.3.2 (HW Rev B and D)	BayStack 450 Software Version V2.0/V2.0.1 (HW Rev B, D, and L)
UNIX Optivity LAN 8.1.1	Standalone mode only	No	No
Windows Optivity Campus 7.0.2	Yes	No	No
Optivity 9.0	Partial support only (see Note)	Partial support only (see Note)	Partial support only (see Note)
Optivity Infocenter 9.0, with 9.0.0.2 patch ¹	Yes	Yes	Yes
Device Manager 2.0.3	No	Yes	No
Device Manager 3.0.3	No	Yes	Yes
Device Manager 3.0.4.1	No	Yes	Yes

¹ Requires installation of the Optivity Integration Toolkit (OIT) for the BayStack 450.



Note: Optivity 9.0 provides partial support only for these switch versions. For a list of Optivity modules or components that support the BayStack product, see *Release Notes for Optivity Network Management System 9.0 for Solaris and Windows NT* (Part number 205970-A). You can obtain a copy of the Optivity 9.0 release notes at: support.baynetworks.com/library/tpubs/nav/netman/nms.htm#OPTN90.
