

Part No. 215148-D
March 2004

4655 Great America Parkway
Santa Clara, CA 95054

Release Notes for BayStack Operating System Switching Software (BoSS) 3.1 for BayStack 460, 470, and BPS 2000

215148-D

NORTEL
NETWORKS™

Copyright © 2004 Nortel Networks

All rights reserved. March 2004.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks Inc.

Trademarks

Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, BayStack, BoSS, and Optivity are trademarks of Nortel Networks.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporated.

Java is a trademark of Sun Microsystems, Inc.

Macintosh is a trademark of Apple Computer, Inc.

Netscape Navigator is a trademark of Netscape Communications Corporation.

Restricted rights legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Contents

Introduction	7
New features for BoSS, software release 3.1	7
Hardware compatibility matrix	8
GBIC compatibility matrix	9
BayStack 450 support	10
Media Dependant Adapter (MDA) compatibility matrix	10
Software compatibility matrix	11
BoSS Software Version 3.1 for Policy switches compatibility matrix	11
BoSS software version 3.0 for Policy switches compatibility matrix	11
Known issues for BoSS, software version 3.1	11
Base unit for a mixed stack	14
Merging a switch into a stack	15
IGMP issues	18
Stack issues	18
DMLT issues	18
Nortel Networks Command Line Interface (NNCLI) issues	19
Device Manager (DM) issues	19
Web Interface issues	19
EAPoL issues	19
Spanning Tree Protocol (STP) issues	20
QoS issues	20
Resolved issues for BoSS, software version 3.1	20
Downloading BoSS 3.1 software	23
ASCII configuration generator	24
show running-config command	25
copy running-config command	25
configure network command	26
configure network load-on-boot command	29
802.3ad Link Aggregation	30

Enabling traffic separation	32
Defaulting to BootP-when-needed	33
Configuring with NNCLI	33
ip bootp server command	33
default ip bootp server command	35
Layer-2 restricted filters	35
Unrestricted meters	35
Layer-2 restricted QoS meters	35
Configuration	36
IP/BootP configuration retention on downgrade	37
Copper GBIC support	37
Using remote logging	37
Configuring with NNCLI	38
show logging	38
remote logging enable command	39
no logging remote enable command	40
logging remote address command	40
no logging remote address command	41
logging remote level command	41
no logging remote level command	42
default logging remote level command	42
Syslog content enhancements	42
Syslog enhancements for SSH	43
Stacking enhancement	44
Faulty unit and cable detection	44
Additional entries in volatile system log	45
.....	49
Additional entries in non-volatile system log	49
Displaying most recent log entry first	51
Configuring with NNCLI	51
show logging	51
Latch or overwrite volatile RAM log file	52
Enabling and disabling autosave	53
Configuring with NNCLI	53
show autosave command	53

autosave enable command	54
no autosave enable command	54
default autosave enable command	54
Downloading image without resetting	55
Configuring with NNCLI	55
Using SNTP	57
Configuring with NNCLI	57
show sntp command	58
show sys-info command	59
sntp enable command	60
no sntp enable command	61
sntp server primary address command	61
sntp server secondary address command	62
no sntp server command	62
sntp sync-now command	63
sntp sync-interval command	63
Using DNS to ping and telnet	64
Configuring with NNCLI	64
show ip dns command	65
ping command	65
ip name-server command	67
no ip name-server command	67
ip domain-name command	68
no ip domain-name command	69
default ip domain-name command	69
Sample commands	69
Changing HTTP port number	70
Configuring with NNCLI	70
show http-port command	70
http-port command	71
default http-port	71
Displaying MAC address table by port number	72
show mac-address-table command	72
Custom Autonegotiation Advertisements	73
Unit replacement	75

Replacing a unit in a stack	75
Command Line Interface (CLI) commands for unit replacement	77
RADIUS fallback enhancement	77
RADIUS access challenge	78
Enhanced autotopology display	78
show auto-topology nmm-table command	79
Display date of manufacture and HW deviation number in WEB/CLI/Console	80
50 addresses for IPMGR	80
Restricted SSH access with IP Manager list	81
Telnet client support	81
telnet command	81
Trap notification when configuration changes saved to NVRAM	82
Displaying the default interface	82
User-based policies	83
Configuring with NNCLI	83
eapol user-based-policies enable command	83
no eapol user-based-policies enable command	83
default eapol user-based-policies enable command	84
show eapol	84
Related publications	84
How to get help	85

Introduction

These release notes document the new features and known issues of BayStack Operating System Switching Software (BoSS), software release 3.1.

New features for BoSS, software release 3.1

These release notes contain information on the following new features for BoSS, software release 3.1:

- [“ASCII configuration generator” on page 24](#)
- [“802.3ad Link Aggregation” on page 30](#)
- [“Enabling traffic separation” on page 32](#)
- [“Defaulting to BootP-when-needed” on page 33](#)
- [“Layer-2 restricted filters” on page 35](#)
- [“Layer-2 restricted QoS meters” on page 35](#)
- [“IP/BootP configuration retention on downgrade” on page 37](#)
- [“Copper GBIC support” on page 37](#)
- [“Using remote logging” on page 37](#)
- [“Syslog content enhancements” on page 42](#)
- [“Syslog enhancements for SSH” on page 43](#)
- [“Stacking enhancement” on page 44](#)
- [“Displaying most recent log entry first” on page 51](#)
- [“Enabling and disabling autosave” on page 53](#)
- [“Downloading image without resetting” on page 55](#)
- [“Using SNTTP” on page 57](#)
- [“Using DNS to ping and telnet” on page 64](#)
- [“Changing HTTP port number” on page 70](#)
- [“Displaying MAC address table by port number” on page 72](#)
- [“Custom Autonegotiation Advertisements” on page 73](#)
- [“Unit replacement” on page 75](#)
- [“RADIUS fallback enhancement” on page 77](#)
- [“RADIUS access challenge” on page 78](#)

- “Enhanced autotopology display” on page 78
- “Telnet client support” on page 81
- “Display date of manufacture and HW deviation number in WEB/CLI/Console” on page 80
- “50 addresses for IPMGR” on page 80
- “Restricted SSH access with IP Manager list” on page 81
- “Trap notification when configuration changes saved to NVRAM” on page 82
- “Displaying the default interface” on page 82
- “User-based policies” on page 83

Hardware compatibility matrix

BoSS for Policy Switches Software Version 3.1 is compatible with the switches listed in [Table 1](#).

Table 1 Hardware platform and part numbers for BayStack switches

Hardware Platform	Part Number
BayStack 460-48T-PWR	AL2001?20
BayStack 470-24T	AL2012?37
BayStack 470-48T	AL2012?34
BayStack BPS	AL2001?15

The question mark(?) in the part numbers above may be replaced with the appropriate letter from the table below to identify a particular power cord option.

[Table 2](#) describes the power cord options and option codes for BayStack switches.

Table 2 Power cord options and option codes for BayStack switches

Power cord option description	Option Code
No power cord	A
European Union power cord	B
UK power cord	C
Japan power cord	D

Table 2 Power cord options and option codes for BayStack switches (continued)

Power cord option description	Option Code
North American power cord	E
Australia power cord	F

GBIC compatibility matrix

[Table 3](#) lists the Gigabit Interface Converters (GBICs) that are supported by the BoSS for Policy Switches Software Version 3.1.

Table 3 GBIC compatibility matrix

GBIC	Standard or SFP	Order number	Comment
1000Base-T Copper	Standard (RJ-45 connector)	AA1419042	BayStack 470 Only
1000Base-SX	Standard (SC connector)	AA1419001	
1000Base-LX	Standard (SC connector)	AA1419002	
1000Base-XD	Standard (SC connector)	AA1419003	Extended distance 50km
1000Base-ZX	Standard (SC connector)	AA1419004	Extended distance 70km
1000BaseWDM	Standard (SC connector)	From AA1419017 to AA1419024	1470nm-1610nm (in 20nm intervals)
1000Base-SX	SFP (LC connector)	AA1419013	
1000Base-SX	SFP (MT-RJ connector)	AA1419014	
1000Base-LX	SFP (LC connector)	AA1419015	
1000Base-CWDM (40km)	SFP (LC connector)	From AA1419025 to AA1419032	1470nm - 1610nm (in 20nm intervals)
1000Base-CWDM (70km)	SFP (LC connector)	From AA1419033 to AA1419040	1470nm - 1610nm (in 20nm intervals)

BayStack 450 support

BoSS Software Version 3.1 supports stacks that contain BayStack 450 switches.

- The BayStack 450 units must run BayStack 450 Software Version 4.4.0.6.
- The BayStack 450 units cannot be stacked with the BayStack 470-48T.

Media Dependant Adapter (MDA) compatibility matrix

[Table 4](#) lists the MDAs that are supported in the BayStack BPS and the BayStack 460-24T-PWR running BoSS Software Version 3.1.

Table 4 MDA compatibility matrix

MDA description	Order number
450-1SX 1-port 1000BASE-SX Single PHY MDA	AL2033005
450-1SR 1-port 1000BASE-SX Redundant PHY MDA	AL2033006
450-1LX 1-port 1000BASE-LX Single PHY MDA	AL2033007
450-1LR 1-port 1000BASE-LX Redundant PHY MDA	AL2033008
BayStack 450-1 GBIC MDA	AL2033009
BPS2000-4TX 4-port 10/100 MDA	AL2033011
BPS2000-4FX 4-port 100BASE-FX MDA w/mini MT-RJ-type connectors	AL2033012
BPS2000-2FX 2-port 100BASE-FX MDA w/SC-type connectors	AL2033013
BPS2000 1 port 1000BASE-T MDA	AL2033014
BPS2000 2port 1000BASE-T MDA	AL2033015
BPS2000 2 port SFP GBIC MDA	AL2033016

Software compatibility matrix

BoSS Software Version 3.1 for Policy switches compatibility matrix

The components for the BoSS Software Version 3.1 are:

- BoSS Standard Runtime Image Software Version 3.1.0.78 (boss31078.img)
- BoSS Secure Runtime Image Software Version 3.1.0.79 (boss31079s.img)
- BoSS Boot/Diagnostic Software Version 3.0.0.5 (boss3005_diag.bin)
- Java Device Manager software version 5.7.6.0 (jdm_5760)
- BoSS Management Information Base (MIB) definition files (bossmibs_3.1.0.52.zip)
- BayStack 450 Software Version 4.4.0.6
- BayStack 460-24T-PWR PoE Software v2.3.0 (bs4607013_002.poe.zip)

BoSS software version 3.0 for Policy switches compatibility matrix

The components for the BoSS Software Version 3.0 are:

- BoSS Standard Runtime Image Software Version 3.0.0.54 (boss30054.img)
- BoSS Secure Runtime Image Software Version 3.0.0.55 (boss30055ss.img)
- BoSS Boot/Diagnostic Software Version 3.0.0.4 (boss3004_diag.bin)
- Java Device Manager Version 5.5.6.0 (jdm_5560)
- BoSS Management Information Base (MIB) definition files (bossmibs_v3.0.0.38.zip)
- BayStack 450 Software Version 4.2.0.22
- BayStack 460-24T-PWR PoE Software v2.3.0 (bs4607013_002.poe.zip)

Known issues for BoSS, software version 3.1

BoSS, software version 3.1 has the following known issues:

- Device Manager and Web-based management do not include help information for the new 3.1 features.
- When in mixed stack mode, the user interface does not provide the ability to configure the BayStack 450 to filter unregistered frames. This feature is only available on the BayStack 450 when not stacked with the BayStack BPS, BayStack 470, and BayStack 460. (Q00707465)
- The software will allow you to remove the Management VLAN from all spanning tree groups, even though this configuration should be avoided. (Q00723332)
- Downloading the configuration file from the TFTP server may fail with an “Intra-stack communication” error. Simply re-attempt the configuration file download should this occur. (Q00725148)
- When a tagged port is part of multiple Spanning Tree Groups, that port should be configured to tag all traffic using the tagAll option. (Q00728620)
- If you have the Secure Shell (SSH) feature enabled and you upgrade your stack or switch to BoSS Software Version 3.1, the SSH feature will be disabled. (Q00838995)
- ASCII Configuration File download is not supported through an Secure Shell (SSH) session. (Q00840035)
- Downloading binary configuration files, ASCII configuration files, and software image files is not supported when a stack is in a temporary base-unit condition. (Q00840624)
- If you are managing the stack via a console cable connection, the download command with the no-reset option may only be executed from the base unit’s console port. (Q00841927)
- After you download an image file using the "download no-reset" option, you must reset the switch or stack before executing subsequent downloads. (Q00841945)
- You may not execute the lacp clear-stats against all ports in a stack simultaneously. You may execute the command against all the ports in a switch simultaneously, and then against each switch in a stack. (Q00844967)
- When you create an MLT group using the Menu Interface, you must identify a unit number/port number combination in the first field in order for the port configuration to be accepted by the Menu Interface, as shown. For example:

Trunk	Trunk Members	STP Learning	Trunk Mode	Trunk Status
1	[/1] [/ 2] [/ 3] [/]	[Normal]	Basic	[Disabled]
2	[2/6] [2/7] [/] [/]	[Normal]	Basic	[Disabled]
3	[3/10] [4/11] [4/12] [5/13]	[Normal]	Basic	[Disabled]
4	[/] [/] [/] [/]	[Normal]	Basic	[Disabled]
5	[/] [/] [/] [/]	[Normal]	Basic	[Disabled]
6	[/] [/] [/] [/]	[Normal]	Basic	[Disabled]

- Ensure you assign an IP address to the switch or stack before enabling RADIUS authentication. If you attempt to enable RADIUS authentication using the CLI, you will not receive an error message even if the switch or stack is not configured with an IP address. (Q00752827)
- You may delete the IP address of the device using the CLI even if RADIUS authentication is enabled and you will not receive an error message. (Q00752828)
- You may see the MAC address table refresh by itself every few seconds after another unit in the stack has been reset. This condition may persist for one or two minutes. (Q00761481)
- You may only change the VLAN port configuration for MLT or DMLT ports using the lowest numbered port in the MLT. (Q00761593)
- The switch continues to send BootP request even after BootP is disabled. (Q00763866)
- If the Spanning Tree Protocol (STP) is enabled on a Link Aggregation Group (LAG), then the LAG is subject to STP convergence, just like any other port. If Spanning Tree does reconverge, you should expect there to be a loss of data on the LAG link. (Q00769684, Q00804961)
- There is an error on page 258 of the document, “Using the BayStack 470-24T 10/100/1000 Switch, Software Version 3.0” regarding how GBIC ports relate to the various queues. The new text for the page is as follows:

The cascade port has a set of 2 queues that are serviced using an absolute priority discipline. Filters are installed only on cascade ports that are connected to BayStack 450 or BayStack 410 units in the stack.

BayStack 470-24T ports are associated with three types of queue sets:

- Queue set 1 has four queues. The first queue is serviced in an absolute priority fashion. The other three queues are serviced in a WRR fashion.
- Queue set 2 has two queues that are serviced in an absolute priority fashion.

- Queue set 3 has eight queues. The first queue is serviced in an absolute priority fashion. The other seven queues are serviced in a WRR fashion.

There are 3 sets of external ports that correspond to the queue sets. The first set of external ports contains the 10/100 Mb/s ports. These interfaces are associated with queue set 1. Each port in this set has a set of 4 queues. The first queue holds the highest priority and is serviced in an absolute priority fashion, meaning that this queue is serviced first until all the queued packets are transmitted. The other three queues are serviced using a WRR scheduler.

The second set of external ports contains the cascade ports. These interfaces are associated with queue set 2, which has 2 queues that are serviced in an absolute priority fashion.

The third set of external ports contains the GBIC ports; these interfaces are associated with queue set 3. Each port in this set has a set of 8 queues. The first queue holds the highest priority and is serviced in an absolute priority fashion, meaning that this queue is serviced first until all the queued packets are transmitted. The other seven queues are serviced using a WRR scheduler.

You cannot change the characteristics of these queue sets (such as the service discipline, packet or buffer thresholds, and queue weights for WRR scheduler). (Q00770815)

- In the Release Notes for the BayStack operating System Switching Software (BoSS) 3.0 for BayStack 460, 470, and BPS 2000, Part No. 215148-A, dated May 2003, page 20, the text should read:

The base unit in an allied stack cannot be a BPS 2000. Any of the other BayStack Policy Switches can function as a base unit in an allied stack, but if a BayStack 470-48T switch is in the stack, it must be the base unit.

- The "Base unit for a mixed stack" section in the Release Notes for the BayStack operating System Switching Software (BoSS) 3.0 for BayStack 460, 470, and BPS 2000, Part No. 215148-A, dated May 2003, page 22 should read as follows:

Base unit for a mixed stack

In order of preference, one of the following switches can function as a base unit in a mixed stack:

- If a BayStack 470-24T switch is in the stack, it should be the base unit.

-
- Otherwise, if a BayStack 460-24T PWR switch is in the stack, it should be the base unit.
 - Otherwise, the BPS 2000 should be the base unit.



Note: The BayStack 470-48T switch cannot join a mixed stack (or one containing the BayStack 450 switch). For information on stacking the BayStack 460, 470 or BPS 2000 with the BayStack 470-48T switch, refer to "Allied stacking" on page 21.



Note: The BayStack 450 switch can never be the base unit of a stack.



Note: The BayStack 460 and BayStack 470 switches are the preferred base units of a stack because these switches have more memory than the BPS 2000 switch.



Note: A mixed stack cannot contain both a BayStack 450 and a BayStack 470-48T unit. You also cannot have more than 8 units in a stack.

- The "Merging a switch into a stack" section in the Release Notes for the BayStack operating System Switching Software (BoSS) 3.0 for BayStack 460, 470, and BPS 2000, Part No. 215148-A, dated May 2003, page 24 should read as follows:

Merging a switch into a stack

Nortel Networks recommends that you start up the switch you are going to add to the stack initially in a standalone mode and perform preliminary IP configuration tasks before you add it to an existing stack. Adding a new unit does not change the designated base unit. If you want to change the designated base unit when you add a new unit to the stack, you must manually change the base unit:

- 7 Turn off power to all units in the stack by unplugging the power cords from each unit.

- a Add the new unit to the stack leaving the original base unit unchanged. Do not change the base unit switches on the back.
- b Power up the stack so that the new unit can learn the IP configuration and stack information. Verify the configuration of the stack.
- c Turn off power to all units in the stack by unplugging the power cords from each unit.
- d Change the base unit selector switch on the new unit so that it is now base unit.
- e Change the base unit selector switch on the original base unit so that it is not longer configured as the base unit.

8 Power-up the newly joined units by plugging in the power cords and verify the configuration. It may take a few minutes for the entire stack to display on the console. All units will display as their new numbers within the newly formed stack.

If you are running a pure stack that consists of only BPS2000s, and you add a BayStack 460, a BayStack 470-24T switch, or a BayStack 470- 8T switch to create an allied stack, you must manually change the base unit from a BPS 2000 switch. (Q00725300)

- The CLI command "default duplex" may not be executed against a GBIC port. If you execute this command against a GBIC port, you may see the following error:

```
% Cannot modify settings
% inconsistentValue <port_number>
```

(Q00779732)
- When using LAG, a maximum of one standby link is supported. (Q00783242)
- The ports on the BPS2000 2GT MDA may not be the target of the interface "flowcontrol" command. Changing the flow control of the ports on the BPS2000 2GT will result in autonegotiation being disabled on the port which is an unsupported configuration. (Q00787182)
- LAG / IGMP stream does not failover immediately when standby is present. (Q00804064)
- You must enable IGMP proxy when using IGMP in conjunction with LAG or MLT. (Q00805627)

-
- If you initiate a management session with the device through the console port, you may see the following message in your system log.
session opened from 127.0.0.1
127.0.0.1 is the loopback address and this message is appropriate since the connection was physically initiated from the console port on the device.
(Q00826743)
 - The CLI command "show running-config" will display the configuration parameters that are appropriate for the user that is logged into the device. A subset of the configuration parameters is displayed to the READ-ONLY (RO), while a more verbose set of parameters is available to the READ-WRITE (RW) user. (Q00827993)
 - Changes to the "cmd-interface" command will take effect when the user next logs into the device. (Q00829147)
 - When using TFTP Transfers and a file not found error occurs you may see the following error message on the console screen:
Error code 1: File not found
You may ignore this error message. (Q00726506)
 - Managing a LAG from a BayStack 450 in a mixed stack is not supported. (Q00750550)
 - BPS/460-Changing from 10MB to 100 MB may result in port remaining in a down condition (Q00630821)
 - MLT / LAG console menu screen may display more port members when moving cables. Refresh the screen should this occur. (Q00770784)
 - You may not configure the rate-limiting feature for a standalone unit through the CLI. Please configure this feature through the Web or the Menu Interface (Q00853102).
 - When configured in a BayStack 450, the speed and duplex setting on the BPS2000-4TX MDA, port 25 may change after soft reset (Q00585849)
 - No trap is sent after a BPS2000 unit which goes down and then comes back up (Q00691410)
 - You cannot use Device Manager to download a binary configuration file. Use the console, Web-based management, or Command Line interface. (Q00689710)
 - On the BayStack 450 in a mixed stack configuration, make sure that you re-enable Global Security when you make any changes to the security parameters to ensure that the changes take effect. (Q00620973)

- As part of your risk management protocol, please make sure you periodically backup your configuration file. Binary configuration files may be used in conjunction with the Unit Replacement Feature to increase network availability. (Q00593649), (Q00604762), (Q00518226)

IGMP issues

- IGMP reports may appear to be associated with several VLANs. This display issue does not affect IGMP functionality or performance. (Q00623137)
- When using BoSS 3.0, with IGMP enabled, in conjunction with the Passport 1200, make sure that the IGMP Proxy parameter is enabled on the BoSS 3.0 unit. This is due to an issue with the Passport 1200. (Q00591972)
- When displaying the number of IGMP hosts on a stack, the number of hosts displayed may be 20 to 25 percent of the actual count. You may determine the actual count of IGMP hosts in the stack by interrogating each of the units in the stack. (Q00626413)

Stack issues

- Managing a stack through the console port of a BayStack 450 is not supported in this release. Please use the console port of the base unit. (Q00605113, Q00615550)
- The Port IfIndex allocates resources for thirty-two ports per unit on a hybrid stack and sixty-four ports per unit on a non-hybrid stack. Therefore, on a hybrid stack IfIndex ports 1-32 are assigned to unit 1, ports 33-64 are assigned to unit 2, ports 65-96 are assigned to unit 3, and so one. On a non-hybrid stack, IfIndex ports 1-64 are assigned to unit 1, ports 65-128 are assigned to unit 2, ports 129-192 are assigned to unit 3, and so one. (Q00606591)
- Occasionally, in order for a stack to reform, the entire stack must reset. This may happen when BayStack 450 is power cycled while in the stack. (Q00607599)

DMLT issues

- Traffic flow will be interrupted on DMLT for around 30 seconds if a BayStack 450 contains one of the links that is reset when the switch loses power. (Q00606295)

Nortel Networks Command Line Interface (NNCLI) issues

- The "show stack-info uptime" command does not display the uptime for BayStack 450 Switches. (Q00587447)
- If you enable port mirroring on a port that has STP enabled, when you disable port mirroring, you must manually re-enable STP support for that port. (Q00617551)
- You cannot change STP bridge priority, port priority, or path cost using the console interface. Use the NNCLI, web-based management, or Device Manager. (Q00592138)

Device Manager (DM) issues

- When using Device Manager, the "UndersizePkts" count is not updated for the BPS2000 1000MB MDAs. This statistic may be obtained through the Console Interface menu system, the Nortel Networks Command Line Interface, or the Web Interface. (Q00608569)
- The MAC address security parameter "AuthCtlPartTime" is not supported through Device Manager. Use the NNCLI or the Web Interface to set this parameter. (Q00623812)
- Device Manager will not identify the ports that have STP disabled on the "STP->Ports" screen. Use the NNCLI or Web Interface to set this parameter. (Q00607218)
- When managing a BayStack 450 switch using Device Manager, it may take up to 20 seconds for the unit to become editable after the edit menu option is invoked. (Q00607328)

Web Interface issues

- When using the Web interface, the version number of the software shown in "Stack info > System Description" may be truncated. Use the NNCLI to query the software version number. (Q00597301)

EAPoL issues

- On BayStack 450 software version 4.2.0.22, the EAPoL Reauthentication parameter is not supported.

Spanning Tree Protocol (STP) issues

- In a stack with a large number of units (e.g. 6 to 8), a large number of VLANs AND a large number of Spanning Tree Groups (STGs), STG configurations may fail to be propagated to the most distant units in the stack. This issue only affects non-default STGs (i.e. STG IDs not equal to 1). When this issue is being experienced, ports on a unit in the stack will fail to send out BPDUs for any affected non-default STGs. Ports on other units in the stack which belong to this same STG may still correctly carry out the tasks of the STP.

A soft reset of an affected unit will cause the STG configuration information to be re-acquired from the base unit and will correct this problem.

QoS issues

- When specifying an IP filter to a particular destination, if there are two or more filters, the source address must specify a particular host. (Q00599978)

Resolved issues for BoSS, software version 3.1

The following issues were resolved in software version BoSS 3.1:

- When a port is administratively disabled, the port will no longer provide link pulses. (Q00776905)
- When configured in a BayStack BPS or BayStack 460, the speed and duplex setting on the BPS2000-4TX MDA, port 25 no longer changes after soft reset (Q00585849)
- When using the unit replacement feature, you may now change the Target Unit if you have 2 open telnet sessions. (Q00691669)
- When using the unit replacement feature, you may now clear the target unit on the renumber screen on all units, not just the base unit. (Q00696227)
- IP address on the ping field now displays on all units of the allied stack, not just the base unit. (Q00692114)
- Do not enter the following characters in the MAC Security Port list:
 - [+ , - or ,]

These characters might cause the switch to stop operating properly in the stack. (Q00637930)

-
- If you add MAC addresses to Security Lists that do not have ports associated with them, and then display the Security Lists, the lists will appear empty until a port is associated with the list. (Q00622842)
 - A mixed stack may reset twice after being booted or rebooted. This may cause a slight delay in booting the stack. (Q00617280)
 - If you disable all Link up and down traps on the front panel interfaces, you may still see link up traps reflecting the fact that cascade ports are initializing. (Q00628942)
 - A BPS 2000 hangs when it receives an EAP access reject from an ACS radius server. The problem appears very quickly if you retrieve a `show` command from the CLI. For example: `show int` or `show EAPoL`. (Q00666030)
 - The EAPoL configuration parameter "Maximum Requests" has no effect. The unit will only send out three EAP-Request/Identity frames before sending a Failure frame and restarting the authentication process. (Q00637063)
 - When you download the DSA Authorization key for the first time, the transfer may time out. Simply re-initiate the key download sequence. (Q00626440)
 - After rebooting the system, the Last key transfer result is not displayed correctly. The display shows "Other: Error 0.", but the DSA-Key works properly. (Q00597567)
 - It may take up to 10 minutes for the DSA key to be generated, and you will not receive a message when the generation is completed. You cannot authenticate an SSH session to a switch using the DSA key authentication until the key has been fully generated. (Q00627029)
 - For port mirroring, all packets are sent to the monitor port after SSH has been enabled and the stack has been rebooted. (Q00605912)
 - If the DSA public key download fails, the following message will be displayed if the action was initiated through the console port: "Cannot modify settings, Undo Failed 1." No message is displayed if the action was initiated through telnet, but the following message will appear in the last transfer results of the "show ssh download" command: "Other: Error 5." (Q00578979)
 - You cannot enable SSH while the DSA public key is being generated. If you attempt to enable SSH during the key generation period, you may see the following error: "cannot modify settings." (Q00626985)
 - If you have a DMLT configured, and one of the units that has a configured link fails, the NNCLI displays the link as belonging to port yy. For example: 2/yy. (Q00624397)

- Autotopology packets will not be transmitted on a link that is connected to a DMLT if the unit is reset. Autotopology packets will continue to be received from the units in the stack that were not reset. (Q00633687)
- If you enter an incorrect password while using RADIUS authentication to restrict management access to the device, the following error message appears: "no response from RADIUS servers". (Q00560496)
- In a hybrid stack, when the base unit fails and the temporary base units takes over management responsibilities for the stack, the MAC address table cannot be displayed through the NNCLI. The web interface will show the proper information. (Q00637611)
- In the NNCLI, changing the STP participation for all ports also changes the MLT STP settings. Use the console or web-based management interface instead of the NNCLI. (Q00598466)
- When adding a user with privacy, the NNCLI does not allow you to omit the write-view and specify the notify-view. The NNCLI requires that you enter a read-view, write-view, and notify-view. If you do not wish to enter a write-view for the user, you may use the web interface to create the user. (Q00636313)
- You cannot use the NNCLI to delete an SNMP v3 trap destination entry that was created using the web interface or Device Manager. (Q00622221)
- If you clear the log using the NNCLI "clear logging" command in a stack of 8 units, the entries related to unit 8 may not be removed. (Q00625617)
- When using Device Manager, and changing information on multiple ports, the Device Manager may display a message that the application is in "fetching mode." If this message appears for more than a few seconds, Device Manager application must be restarted. To avoid this error condition when using Device Manager, do not attempt to change the configuration of more than a few ports at a time. (Q00614887)
- In a stacked configuration, after creating a new Spanning Tree Group (STG) using Device Manager, the stgid may return a value of "0" when you attempt to add a VLAN to the STG. Refresh the view of the stack and the stgid parameter will return the correct value. (Q00584031)
- You may encounter problems using Internet Explorer to access help items in the right-hand frame of the online help screen. To avoid this problem, access the help items you want through the Table of Contents in the left-hand frame of the online help. (Q00561521)

- Using the Web Interface, you may only change the EAPoL Re-Authentication Field for individual ports. As a workaround, you may use the Console Interface menu system, or the NNCLI. (Q00636903)
- Using the Web interface, you cannot configure flow control for BS450 in a mixed stack. Use the NNCLI or console interface. (Q00628278)
- When using SNMP V3, you may only assign a notify-view address to one user. You may not use the same target IP address for multiple users. (Q00615644)
- During the download process, the console may appear to hang. You can verify that the download is in progress by the state of the LEDs. You may see the following error message:

```
% error accessing image file
```

but the download will continue. (Q00596530)
- You cannot disable port mirroring through the console interface. Use another interface. (Q00620633)
- If you default a unit and re-enter the same IP station addresses that were in the ARP table, you may not be able to manage the switch. Either manage the switch from another station, or reboot the stack. (Q00565566)
- The ShapingQDrops parameter is not supported in Device Manager for the BayStack 470 switches. (Q00647900)
- There may be STP convergence issues with Multilink Trunking when there is an STP priority/port path cost change, with uplink to the 8600. To correct this problem, disable and re-enable MLT. (Q00604730).

Downloading BoSS 3.1 software

To obtain the BoSS 3.1 software that *does not* contain SSH, download the following files from the Nortel Networks customer support web site at: <http://www.nortelnetworks.com/support>

- boss31078.img



Note: Ensure that you do not interrupt the download process; do not detach either the power cord or any of the network connections during download.

ASCII configuration generator

The ASCII Configuration Generator (ACG) allows the configuration settings of the switch to be displayed or saved to an external ASCII configuration file made up of a series of CLI commands. This editable ASCII configuration file can then be uploaded to a switch from an external file server.



Note: You must reset the switch to the factory default settings before uploading the ACG-generated ASCII configuration file. Resetting the switch to factory default settings will cause loss of connectivity and loss of the current configuration of the switch.

The ASCII configuration file contains configuration settings for the following network management applications:

- Core applications (system information, topology, etc.)
- Internet Protocol
- Multilink Trunking
- Port configuration
- Partial Spanning Tree configuration, including configuration of port priority and path cost
- VLAN configuration
- Quality of Service (QoS)
- RMON

The ACG is only available from the command line interface (CLI). This section discusses the following new or enhanced CLI commands used for the ASCII Configuration Generator:

- [“show running-config command,”](#) next
- [“copy running-config command”](#) on page 25
- [“configure network command”](#) on page 26
- [“configure network load-on-boot command”](#) on page 29

show running-config command

The `show running-config` command displays the current running configuration. The syntax for the `show running-config` command is:

```
show running-config
```

The `show running-config` command is in the `privExec` command mode.



Note: The `show running-config` command is available, but its use is restricted, when a user has read-only access.

The `show running-config` command has no parameters or variables.

[Figure 1](#) displays sample output from the `show running-config` command.

Figure 1 show running-config command output

```
BS470#show running-config
enable
config t
mac-address-table aging-time 300
autotopology
snmp-server authentication-trap enable
snmp-server contact "SysAdmin"
snmp-server name "BS470"
snmp-server location "Lab"
snmp-server community "public" ro
snmp-server community "private" rw
--More--
```

copy running-config command

The `copy running-config` command stores the current configuration as an ASCII file on the TFTP server. The syntax for the `copy running-config` command is:

```
copy running-config tftp [address <A.B.C.D>] filename <WORD>
```



Note: The `copy config` command will copy a binary configuration file to the TFTP server. To store the configuration as an ASCII file, you must use the `copy running-config` command.

The `copy running-config` command is in the `privExec` command mode.

[Table 5](#) describes the parameters and variables for the `copy running-config` command.

Table 5 `copy running-config` command parameters and variables

Parameters and variables	Description
address <A.B.C.D>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Specifies the name of the existing ASCII configuration file on the TFTP server. This file must be read/write enabled.

[Figure 2](#) displays sample output from the `copy running-config` command.

Figure 2 `copy running-config` command output

```
BS470#copy running-config tftp address 134.177.118.56 filename config.txt
%Contacting TFTP host: 134.177.118.56.
%ACG Configuration file successfully written.
BS470#
```

configure network command

The `configure network` command loads the ASCII configuration file from an external TFTP server. The syntax for the `configure network` command is:

```
configure network [address <A.B.C.D>] [filename <WORD>]
```

The `configure network` command is in the PrivExec mode, Global configuration mode, and Interface configuration mode.

[Table 6](#) describes the parameters and variables for the `configure network` command.

Table 6 `configure network` command parameters and variables

Parameters and variables	Description
address <A.B.C.D>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Enter the name of the ASCII configuration file you want to copy from the TFTP server.

[Figure 3](#) displays sample output from the `configure network` command.

Figure 3 configure network command output

```
BS470#configure network address 134.177.118.56 filename config.txt
Config File [[]]
BS470#enable
Downloaded file successfully, executing . . .
BS470#config t
Enter configuration commands, one per line. End with CNTL/Z.
BS470(config)#mac-address-table aging-time 300
BS470(config)#autotopology
BS470(config)#snmp-server authentication-trap enable
BS470(config)#snmp-server contact "HCS lab"
BS470(config)#snmp-server community "public" ro
BS470(config)#snmp-server community "private" rw
BS470(config)#ip bootp server disable
BS470(config)#ip default-gateway 134.177.150.1
BS470(config)#ip address 134.177.150.79
BS470(config)#ip address netmask 255.255.255.0
BS470(config)#no auto-paid
% AutoPVID already disabled.
BS470(config)#vlan mgmt 1
BS470(config)#vlan name 1 "VLAN #1"
BS470(config)#vlan members remove 1 ALL
BS470(config)#vlan members 1 ALL
BS470(config)#vlan members 2 1-12
BS470(config)#sed-frame disable filter-untagged-frame disable priority 0
BS470(config)#$ enable proxy enable robust-value 2 query-interval 125
BS470(config)#$ enable proxy enable robust-value 2 query-interval 125
BS470(config)#vlan mgmt 1
BS470(config)#spanning-tree priority 8000
BS470(config)#spanning-tree hello-time 2
BS470(config)#spanning-tree max-age 20
BS470(config)#spanning-tree forward-time 15
BS470(config)#interface FastEthernet ALL
BS470(config-if)#spanning-tree port 1-24 learning normal
BS470(config-if)#exit
BS470(config)#no mlt
BS470(config)#mlt 1 name "Trunk #1"
BS470(config)#mlt 2 name "Trunk #2"
BS470(config)#mlt 3 name "Trunk #3"
BS470(config)#mlt 4 name "Trunk #4"
BS470(config)#mlt 5 name "Trunk #5"
BS470(config)#mlt 6 name "Trunk #6"
BS470(config)#interface FastEthernet ALL
BS470(config-if)#no shutdown port 1-24
BS470(config-if)#snmp trap link-status port 1-24 enable
BS470(config-if)#speed port 1-24 auto
BS470(config-if)#duplex port 1-24 auto
BS470(config-if)#exit
```

configure network load-on-boot command

The `configure network load-on-boot` command is used to configure the switch to automatically download a configuration file when you reboot the switch. The syntax for the `configure network load-on-boot` command is:

```
configure network load-on-boot {disable|use-bootp|
use-config} [address <A.B.C.D>] filename <WORD>
```

The `configure network load-on-boot` command is in the PrivExec mode, Global configuration mode, and Interface configuration mode.

[Table 7](#) describes the parameters and variables for the `configure network load-on-boot` command.

Table 7 configure network load-on-boot command parameters and variables

Parameters and variables	Description
{disable use-bootp use-config}	Specifies the settings for automatically loading a configuration file when the system boots: <ul style="list-style-type: none"> • <code>disable</code>—disables the automatic loading of the configuration file • <code>use-bootp</code>—specifies using the BootP file as the automatically loaded configuration file • <code>use-config</code>—specifies using the ASCII configuration file as the automatically loaded configuration file
address <A.B.C.D>	Specifies the TFTP server IP address; enter in dotted-decimal notation.
filename <WORD>	Enter the name of the ASCII configuration file you want to copy from the TFTP server.

[Figure 4](#) displays sample output from the `configure network load-on-boot` command.

Figure 4 configure network load-on-boot command output

```
BS470#configure network load-on-boot use-config address 134.177.118.56 filename config.txt
BS470#
```

802.3ad Link Aggregation

Link Aggregation (LA) allows you to create and manage a trunk group. You can control and configure a trunk group automatically through the use of the Link Aggregation Control Protocol (LACP).

The LACP, defined by the IEEE 802.3ad standard, allows a switch to learn the presence and capabilities of a remote switch by exchanging information with the remote switch before a trunk group is formed. Either switch can accept or reject the aggregation request with the far end on a per port basis. A link that can not join a trunk group operates as an individual link.

802.3ad provides an industry standard method for bundling multiple links together to form a single trunk between two networking devices. Trunks that conform to the 802.3ad standard are Link Aggregation Groups (LAGs). BoSS 3.1 supports 2 types of trunks

- Dynamic LAG
- MLT

A trunk group that is formed by Link Aggregation is called a Link Aggregation group (LAG), and a trunk group that is formed by BayStack Multilink Trunking is called a Multilink trunk (MLT) group.

BayStack software supports both Link Aggregation groups and Multilink trunks. By default Link Aggregation is set to disabled on all ports. A Link Aggregation group or trunk group can be created or deleted automatically using Link Aggregation Control Protocol (LACP).

The maximum number of Link Aggregation and MLT groups is 6, and the maximum number of active links per group is 4. Link Aggregation allows more than 4 links to be configured in one Link Aggregation group (LAG).

The first four high priority links are active links and together they form a trunk group. The fifth low priority link remains in standby mode. When one of the active links goes down, the standby link becomes active and is added to the trunk group. LACP supports only one standby link.

The failover process is as follows:

- The down link is removed from the trunk group
- The highest priority standby link is added to the trunk group.

There may be a temporary delay in traffic flow due to the switching of links. If the active link goes down and there is no standby link, the traffic is re-routed to the remaining active links with a minimal delay in time.

Half duplex links are not allowed in LAG, and all links in a LAG must have the same speed.

802.3 Link Aggregation is available through the Nortel Networks Command Line Interface (CLI). The CLI supports the following commands:

To enable, disable, or default LACP on a port:

- `lacp aggregation [port <portlist>] enable`
- `no lacp aggregation [port <portlist>] enable`
- `default lacp aggregation [port <portlist>] enable`

To specify the LACP mode:

- `lacp mode [port <portlist>] {off | passive | active}`
- `default lacp mode [port <portlist>]`

To assign an administrative key value to a port:

- `lacp key [port <portlist>] <1-4095>`

To specify the port priority:

- `lacp priority [port <portlist>] <0-255>`
- `default lacp priority [port <portlist>]`

To set port timeout:

- `lacp timeout-time [port <portlist>] {short | long}`
- `default lacp timeout-time [port <portlist>]`

To set LACP system priority:

- `lacp system-priority [0-65535]`
- `default lacp system-priority`

CLI Show commands for LACP:

- `show lacp aggr`
- `show lacp port [<portList>]`
- `show lacp port aggregator`
- `show lacp debug member [portlist]`
- `show lacp system`
- `show lacp stats [port <portlist>]`
- `show lacp stats aggregator`
- `lacp clear-stats`

Enabling traffic separation

Traffic separation is a feature used to separate IP packets and PPPoE packets from an incoming port and forward them to different outgoing ports. IP packets and PPPoE packets separated using this feature go to different channels. Hence, this is packet-type based switching.

To enable this feature, use the following command:

```
config switch mode <l2|traffic-separation>
```



Note: Once this feature is enabled, port mirroring does not work. Also, QoS is different from regular BPS2000 behavior.

Defaulting to BootP-when-needed

The BootP default value is now BootP-when-needed. This allows you to boot your switch and the system will automatically seek a BootP server for the IP address.



Note: If an IP address is assigned to the device and the BootP process times out, the BootP mode remains the default mode of BootP-when-needed.

However, if the device does not have an assigned IP address and the BootP process times out, the BootP mode automatically changes to BootP disabled. But this change to BootP disabled is not stored, and the BootP reverts to the default value of BootP-when-needed after rebooting the device.

When you upgrade, the switch retains the previous BootP value. When you default the switch after the upgrade, the system moves to the default value of BootP-when-needed.

Configuring with NNCLI

This section covers the following topics:

- [“ip bootp server command,”](#) next
- [“default ip bootp server command” on page 35](#)

ip bootp server command

The `ip bootp server` command configures BootP on the current instance of the switch or server. You use this command if you want to change the value of BootP from the default value, which is BootP when needed. The syntax for the `ip bootp server` command is:

```
ip bootp server {always|disable|last|needed}
```

The `ip bootp server` command is in the config command mode.

[Table 8](#) describes the parameters and variables for the `ip bootp server` command.

Table 8 ip bootp server command parameters and variables

Parameters and variables	Description
last needed disable always	Specifies when to use BootP: <ul style="list-style-type: none">• always—Always use BootP• disable—never use BootP• last—use BootP or the last known address• needed—use BootP only when needed <p>NOTE: The default value is to use BootP when needed.</p>

default ip bootp server command

The `default ip bootp server` command resets the mode to BootP when needed, which is the default mode. The syntax for the `default ip bootp server` command is:

```
default ip bootp server
```

The `default ip bootp server` command is in the config command mode.

The `default ip bootp server` command has no parameters or values.

Layer-2 restricted filters

The Layer-2 restricted filters feature allows you to configure up to 23 metered policies. BoSS 3.1 supports both restricted and unrestricted meters.

Unrestricted meters

In BoSS Software versions prior to 3.1, only unrestricted meters were supported. When using unrestricted meters, you may configure a maximum of 12 Layer-2 metered policies. This is because each metered policy requires a filter for in-profile actions, and another filter for out-of-profile actions. With 24 layer-2 filters available, and two filter for each metered policy, you end up with 12 Layer-2 metered policies.

Unrestricted meters may be applied to any group of interfaces: Trusted, Untrusted, and Restricted.

Layer-2 restricted QoS meters

With restricted meters, you are allowed a maximum of 23 Layer-2 metered policies. All 23 metered policies may have a different in-profile-action, but they will all share the same out-of-profile action. The first policy created will consume two filters; one filter is consumed for the in-profile action, and another filter is

consumed for the out-of-profile action. Subsequent restricted Layer-2 metered policies will only use one filter for the in-profile-action and they will share the out-of-profile action defined by the first filter. Since only one filter is used for each policy, statistics will only count in-profile traffic.

Restricted meters can only be used when the Interface Class Restriction is set to Unrestricted Only.

Configuration

To configure the BoSS Software Version 3.1 device to use restricted meters, the following steps must be performed:

- 1 Ensure that the current Interface Class Restriction is set to Unrestricted Only by entering the following CLI command.

```
BPS2000(config)# show qos agent
```

- 2 If the current Interface Class Restriction is not set to Unrestricted Only, you may enable the Unrestricted Only mode by entering the following command:

```
BPS2000(config)# qosagent class-restrictions  
unrestricted-only
```

- 3 Reboot the switch for this mode to take effect

```
BPS2000(config)#boot  
Reboot the unit(s) (y/n) ? y
```

- 4 Assign a default action or use the default "Drop_Traffic"

```
BPS2000(config)# qosagent default-out-of-profile-action  
name no-flow
```

- 5 Create the restricted meter

```
qos meter 1 create name myMeter committed-rate 5000  
max-burst-rate 6000 restricted
```

Restricted meters are created when the "restricted" command argument is appended to the "qos meter <meter_id> create" command.

- 6 Apply the new restricted meter to a policy as you would an unrestricted meter.

IP/BootP configuration retention on downgrade

When downgrading a unit with BoSS Software for Policy Switches version 3.0.3 and later, the system will default all configuration, except for the following:

- Stack operation mode
- IP configuration
- BootP mode

Previous releases of Policy Switch software retained the Stack Operational Mode only on software downgrade. This change allows a remotely accessed switch to maintain its accessibility after downgrade and/or not require the user re-enter this basic information which should remain unchanged after a downgrade.

Copper GBIC support

A new full-sized GBIC is supported. This GBIC supports 1000BaseT and works only on BayStack 470 units. For more information, see [“GBIC compatibility matrix” on page 9](#).

Using remote logging

This feature provides an enhanced level of logging by replicating system messages onto a syslog server. System log messages from several switches can be collected at a central location, which alleviates the network manager querying each switch individually to interrogate the log files.

You must configure the remote syslog server and set up the unit to log informational messages to this remote server. The UDP packet is sent to port 514 of the configured remote syslog server,

Once the IP address is in the system, you can send the syslog messages to the remote syslog server. If a syslog message is generated prior to capturing the IP address of the server, the system stores up to 10 messages that are sent once the IP address of the remote server is on the system.

You configure this feature by enabling remote logging, specifying the IP address of the remote syslog server, and specifying the severity level of the messages you want sent to the remote server.

Configuring with NNCLI

You use the CLI to configure remote logging. This section discusses the following topics:

- [“show logging,”](#) next
- [“remote logging enable command”](#) on page 39
- [“no logging remote enable command”](#) on page 40
- [“logging remote address command”](#) on page 40
- [“no logging remote address command”](#) on page 41
- [“logging remote level command”](#) on page 41
- [“no logging remote level command”](#) on page 42
- [“default logging remote level command”](#) on page 42

show logging

The `show logging` command displays the configuration and the current contents of the system event log. The syntax for the `show logging` command is:

```
show logging [config] [critical] [informational] [serious]
[sort-reverse]
```

The `show logging` command is in the `privExec` command mode.

[Table 9](#) describes the parameters and variables for the `show logging` command.

Table 9 show logging command parameters and variables

Parameters and variables	Description
config	Displays the configuration of event logging.
critical	Displays critical log messages.
informational	Displays informational log messages.

Table 9 show logging command parameters and variables

Parameters and variables	Description
serious	Displays serious log messages.
sort-reverse	Displays log messages in reverse chronological order (beginning with most recent).

[Figure 5](#) shows the output of the `show logging config` command.

Figure 5 show logging config command output

```
BS470_48>enable
BS470_48#show logging config
Event Logging: Enabled
Volatile Logging Option: Latch
Event Types To Log: Critical, Serious, Informational
Event Types To Log To NV Storage: Critical, Serious
Remote Logging: Disabled
Remote Logging Address: 0.0.0.0
Event Types To Log Remotely: None
```

remote logging enable command



Note: The default value for remote logging is disabled

The `logging remote enable` command enables logging syslog messages to a remote server. The syntax for the `remote logging enable` command is:

```
remote logging enable
```

The `remote logging enable` command is in the config command mode.

The `remote logging enable` command has no parameters or variables.

no logging remote enable command

The `no logging remote enable` command disables sending syslog messages to a remote server. The syntax for the `no logging remote enable` command is:

```
no remote logging enable
```

The `no remote logging enable` command is in the config command mode.

The `no remote logging enable` command has no parameters or variables.

logging remote address command

The `logging remote address` command sets the remote server for receiving the syslog messages; you enter the IP address of the server you want. The syntax for the `logging remote address` command is:

```
logging remote address <A.B.C.D>
```

The `logging remote address` command is in the config command mode.

[Table 10](#) describes the parameters and variables for the `logging remote address` command.

Table 10 logging remote address command parameters and variables

Parameters and variables	Description
<A.B.C.D>	Specifies the IP address of the remote server in dotted-decimal notation.

The default address is 0.0.0.0.

no logging remote address command

The `no logging remote address` command clears the IP address of the remote server. The syntax for the `no logging remote address` command is:

```
no logging remote address
```

The `no logging remote address` command is in the config command mode.

The `no logging remote address` command has no parameters or variables.

logging remote level command

The `logging remote level` command sets the severity level of the logs you send to the remote server. The syntax for the `logging remote level` command is:

```
logging remote level {critical|informational|serious}
```

The `logging remote level` command is in the config command mode.

[Table 11](#) describes the parameters and variables for the `logging remote level` command.

Table 11 logging remote level command parameters and variables

Parameters and variables	Description
{critical serious informational}	Specifies the severity level of the log messages to be sent to the remote server: <ul style="list-style-type: none"> critical informational serious

There is no default value for this command.

no logging remote level command

The `no logging remote level` command removes any severity level of the log messages that you send to the remote server; it reverts to None. The syntax for the `no logging remote level` command is:

```
no logging remote level
```

The `no logging remote level` command is in the config command mode.

The `no logging remote level` command has no parameters or variables.

default logging remote level command

The `default logging remote level` command sets the severity level of the logs you send to the remote server to the default value, which is None. The syntax for the `default logging remote level` command is:

```
default logging remote level
```

The `default logging remote level` command is in the config command mode.

The `default logging remote level` command has no parameters or variables.

Syslog content enhancements

In addition to the syslog engine enhancements including in this release, several new syslog events are generated and some existing events are enhanced:

- The Link Up/Down traps events now include unit and port number information.
- The Stack Cascade port link up/down events now clearly indicate the link event is for a cascade port.
- Agent and Diagnostics code upgrades generate a serious event which is logged, by default, in the non-volatile syslog. The event text includes the version if successful and the failure reason if the download fails.

-
- SNTP sync events are logged on each sync attempt and pass/fail is indicated.
 - Telnet session open, close, and timeout (Inactivity logout) events are logged.
 - New event for the bsnConfigurationSavedToNvram trap. Generated when a config change written to NVRAM.

Syslog enhancements for SSH

The following event-triggered messages have been added to the system log to support SSH.

- Success Connection—Indicates that the client has successfully initiated an SSH session with the switch or stack
- Connection Logout—Indicates that the client has logged out of the device
- Inactivity Logout—Indicates that the client was logged out by the stack or switch due to inactivity
- Disallowed connection dues to host not allowed—Indicates that the client's connection request was not allowed due to the restrictions applied by the IP Manager Access Control List.
- Download DSA key completion—Indicates that the switch or stack has successfully downloaded the DSA key
- SSH Enabled in secure mode—Indicates that the “ssh secure” command was invoked to initiate the SSH feature. Telnet, SNMP, and Web management are all disabled as a result of this command.
- SSH Enabled in non-secure mode—Indicates that the “ssh” command was invoked to initiate the SSH feature
- SSH Disabled—Indicates that the SSH feature has been deactivated by the “no ssh” command

Stacking enhancement

Faulty unit and cable detection

When the operation mode is pure, the stack manager can detect the scenario whereby a unit appears good to its neighboring units (its up and downstream clocks are good) but the data packets it transmits or receives are corrupted or missing. In such a scenario, the stack falls apart and the ring check does not succeed.

This triggers the “Ring Discovery” algorithm whereby units are polled both downstream and upstream individually to isolate the point of failure. When the failure is isolated, the bad unit or cables are wrapped out.

In the case where a cable has bad data pins, the stack ports where the cable is connected are wrapped out. On a unit that has its IN port connected to the bad cable, the system log shows “IN stack port wrapped; check for bad cable or unit” and its downstream LED stays amber.

Similarly on the unit that has its OUT port connected to the bad cable, the system log shows “OUT stack port wrapped; check for bad cable or unit” and its upstream LED stays amber. When replacing a bad cable with a good one, at least one unit should be rebooted so that the stack manager on the base unit detects a unit coming in and re-runs the stack.

Additional entries in volatile system log

Table 12

Log Entry	Multiple Base Units Detected, Check Base Unit Switch
Explanation	More than one unit has its "base unit switch" in the on position.
Diagnostic Info	Check to make sure only one unit has its "base unit switch" in the on position.

Table 13

Log Entry	Multiple Base Units Detected in UNP Phase
Explanation	More than one unit has its "base unit switch" selected or there is a contention in 2 units trying to be the base unit.
Diagnostic Info	Check to make sure only one unit has its "base unit switch" in the on position

Table 14

Log Entry	Incompatible operational mode, module <physical id> failed to join stack
Explanation	module <physical id> operation mode is not the same as the base unit's.
Diagnostic Info	Change the operation mode on the module <physical id> so that it is the same as the operational mode of the base.

Table 15

Log Entry	Incompatible Software Revision, module <physical id> failed to join stack
Explanation	module <physical id> software revision is not the same as the base unit's software revision.
Diagnostic Info	Program the same agent image on all units. All units should have the same boss agent software revision and all Baystack 450 in the stack should have the same software revision.

Table 16

Log Entry	Incompatible interop value, module <physical id> failed to join stack
Explanation	module <physical id> type cannot interoperate with the base unit's interop value.
Diagnostic Info	Replace module <physical id> with another module type that is compatible with the base's interop value.

Table 17

Log Entry	Incompatible operational mode, module inactive, module <physical id> failed to join stack
Explanation	module <physical id> has transitioned to inactive state. When there is a configuration change, the base unit will re-transmit the "UNP" packet and a unit upon receiving it may find that it is no longer active or in the stack.
Diagnostic Info	Find out why module <physical id> became inactive.

Table 18

Log Entry	IN stack port wrapped; check for bad cable or unit.
Explanation	The unit did not receive any acknowledgment when it communicates with its upstream unit.
Diagnostic Info	<p>First, determine whether you have a bad cable or a bad upstream unit. If the cable connected to IN stack port is bad, the stack port on both ends of the cable should be wrapped out and the units attached to the cable should still be in stack. Also, the unit that is attached to the other end of the cable should have the entry "OUT stack port wrapped; check for bad cable or unit". Replace the cable with a good one, and reboot the units that were attached to this cable.</p> <p>On the other hand, if the upstream unit is bad, the downstream led on the upstream unit should be amber and the upstream unit will not be in stack. Replace the upstream unit.</p>

Table 19

Log Entry	OUT stack port wrapped; check for bad cable or unit.
------------------	--

Table 19

Explanation	The unit did not receive any acknowledgment when it communicates with its downstream unit.
Diagnostic Info	First, determine whether you have a bad cable or bad downstream unit. If the cable connecting to the OUT stack port is bad, the stack port on both ends of the cable should be wrapped out and the units attached to the cable should still be in stack. Also, the unit that is attached to the other end of the cable should have the following system log entry, "IN stack port wrapped; check for bad cable or unit". Replace the cable with a good one, and reboot the units that were attached to this cable. On the other hand, if the downstream unit is bad, the downstream led on the downstream unit should be amber and the downstream unit is not in stack. Replace the downstream stack module or downstream unit.

Table 20

Log Entry	Stack manager event MODULE INACTIVE (module id = <physical id>)
Explanation	Informational message declaring that the module < module mask> has become inactive because it did not receive the necessary heartbeat packets.
Diagnostic Info	You need to find out why heartbeats are not getting to this unit <physical id>. Make sure that the unit is connected to the stack properly and the cascading connectors are screwed in all the way. If you just powered off the module, then this log is expected to show up.

Table 21

Log Entry	Stack manager event BECOME TEMP BU (module id <physical id>)
Explanation	Informational message declaring the unit has become the base unit due to the heartbeat packets not being received from the former base unit.
Diagnostic Info	Make sure that the former base unit is still operational. Typically, when the base unit goes out for more than 30 seconds, a temporary base unit will take over.

Table 22

Log Entry	Stack manager detected a unit coming up
------------------	---

Table 22

Explanation	Informational message declaring that a unit in the stack is booting up.
Diagnostic Info	This is an informational message. A unit was just inserted or rebooted in the stack. Make sure that you are not rebooting units unnecessary.

Additional entries in non-volatile system log

Table 23

Log Entry	Stack manager event JOIN STACK (module id = <physical id>)
Explanation	Informational message declaring that the module has joined the stack
Diagnostic Info	N/A

Table 24

Log Entry	Stack manager event LEAVE STACK (module id = <physical id>)
Explanation	Informational message declaring that the module has just left the stack.
Diagnostic Info	This may or may not be a failure depending on the circumstances. If you just disconnected both cascading cables on the unit, then this is a normal behavior. Otherwise, you may need to investigate why the unit left the stack.

Table 25

Log Entry	Switch Reset, Ring Check Error, Global Reset Count
Explanation	A soft reset has occurred when the global reset counter value is <number>. The stack manager on the base unit reset because it did not receive back the ring any of the ring check packet that it transmitted and the ring discovery algorithm fails to form a ring.
Diagnostic Info	This event should not normally occur unless there have been multiple resets of the units on the stack which result in the communication path being broken repeatedly.

Table 26

Log Entry	Switch Reset, Ring Discovery Error, Global Reset Count
------------------	--

Table 26

Explanation	A switch soft reset has occurred when the global reset counter value is <number>. The stack manager issue this soft reset the ring discovery algorithm was not successful after 2 attempts.
Diagnostic Info	Check to make sure that there is no bad cable or unit. Make sure that you are not resetting or disconnecting units while the ring discovery algorithm is being executed.

Table 27

Log Entry	Switch Reset, UNP Error, Global Reset Count
Explanation	A switch soft reset has occurred at the specified global reset count. The stack manager issued the reset because the non-base unit has not received the upstream next neighbor packet after 2 UNP timer timeouts.
Diagnostic Info	The unit is not receiving any UNP packet. It may be that the units are being reset one after another during the boot up phase over an interval of more than one minute. If this is not the case, make sure that there is no bad cable or unit.

Table 28

Log Entry	Switch Reset, DbToken Not Received, Global Reset Count <value>
Explanation	A switch soft reset has occurred at the specified global reset count. The stack manager issued the soft reset because the unit did not receive the database token after 3 timer timeouts.
Diagnostic Info	This should not happen unless the user repeatedly reset units in the stack without giving it a chance to join over a period of time.

Table 29

Log Entry	Switch Reset, Db Xchg (got <hexadecimal value>, wanted = <hexadecimal value>) Global Reset Count <value>
Explanation	A switch soft reset has occurred at the global Reset Count. The stack manager issued the soft reset because database exchanges did not succeed for all applications. The missing bits in the got <hexadecimal value> from the wanted <hexadecimal value> indicates which applications were not successfully.
Diagnostic Info	N/A

Displaying most recent log entry first

This option allows you to view the system log with the most recent entry displayed first; the rest of the log entries are listed in reverse chronological order.

Configuring with NNCLI

You use the `show logging` command (with `sort-reverse` option) to sort the system log in reverse chronological order.

show logging

The `show logging` command displays the configuration and the current contents of the system event log. The default value displays all levels in chronological order. The syntax for the `show logging` command is:

```
show logging [config] [critical] [informational][serious]
[sort-reverse]
```

The `show logging` command is in the `privExec` command mode.

[Table 30](#) describes the parameters and variables for the `show logging` command.

Table 30 show logging command parameters and variables

Parameters and variables	Description
config	Displays the configuration of event logging.
critical	Displays critical log messages.
informational	Displays informational log messages.
serious	Displays serious log messages.
sort-reverse	Displays log messages in reverse chronological order (beginning with most recent).

[Figure 6](#) shows the output of the `show logging sort-reverse` command (with `SNTP` enabled).

Figure 6 show logging sort-reverse command output

```

BS470_48#show logging sort-reverse
Type Time                               Idx  Src Message
-----
I    2003-10-27 20:52:00 GMT 59      Successful connection from IP
address: 13
4.177.118.66, access mode: no security
I    2003-10-27 20:48:51 GMT 58      Inactivity logout, IP address:
134.177.11
8.66, access mode: no security
I    2003-10-27 20:26:03 GMT 57      Authentication Failure Trap
I    2003-10-27 20:25:03 GMT 56      Authentication Failure Trap
I    2003-10-27 20:24:03 GMT 55      Authentication Failure Trap
I    2003-10-27 20:23:03 GMT 54      Authentication Failure Trap
I    2003-10-27 20:16:00 GMT 53      Successful connection from IP
address: 13
4.177.118.66, access mode: no security
I    2003-10-27 19:32:06 GMT 52      SNMP: First synchronization
successful.
I    2003-10-27 19:29:29 GMT 51      Authentication Failure Trap
I    2003-10-27 19:29:25 GMT 50      Authentication Failure Trap
I    2003-10-27 19:29:22 GMT 49      Authentication Failure Trap

```

Latch or overwrite volatile RAM log file

BoSS 3.1 provides you with the ability to overwrite or latch (not overwrite) older log entries if log entry space in volatile storage should be filled to capacity. This feature is not available for those entries that are stored in non-volatile storage.

```
logging volatile {latch | overwrite}
```

To configure the device to allow a new log entry to overwrite the oldest entry in the volatile system log when the volatile system log is full, enter the following command:

```
BS470_24(config)# logging volatile overwrite
```

To configure the device to discard new log entries and to prohibit overwriting of any of the entries in the volatile system log, enter the following command:

```
BS470_24(config)# logging volatile latch
```

Enabling and disabling autosave

You can enable or disable the autosave feature of your unit. Autosave automatically saves your configuration information across reboots.

When autosave is disabled, the logging messages sent to non-volatile memory are not saved.



Note: You can use the CLI command `copy config nvram` to force a manual save of the configuration when autosave is disabled.

You must use CLI to enable or disable autosave; the default value is enabled. This setting is saved across resetting the unit.

Configuring with NNCLI

You use CLI to enable or disable autosave. This section discusses the following topics:

- [“show autosave command,”](#) next
- [“autosave enable command”](#) on page 54
- [“no autosave enable command”](#) on page 54
- [“default autosave enable command”](#) on page 54

show autosave command

The `show autosave` command displays the status of the autosave feature, either enabled or disabled. The syntax for the `show autosave` command is:

```
show autosave
```

The `show autosave` command is in the `privExec` command mode.

The `show autosave` command has no parameters or variables.

[Figure 7](#) displays sample output from the `show autosave` command.

Figure 7 show autosave command output

```
BS470_48#show autosave
Auto Save: Enabled
```

autosave enable command

The `autosave enable` command enables the autosave feature. The syntax for the `autosave enable` command is:

```
autosave enable
```

The `autosave enable` command is in the config command mode.

The `autosave enable` command has no parameters or variables.

no autosave enable command

The `no autosave enable` command disables the autosave feature. The syntax for the `no autosave enable` command is:

```
no autosave enable
```

The `no autosave enable` command is in the config command mode.

The `no autosave enable` command has no parameters or variables.

default autosave enable command

The `default autosave enable` command defaults the autosave feature to the default value of enabled. The syntax for the `default autosave enable` command is:

```
default autosave enable
```

The `default autosave enable` command is in the config command mode.

The `default autosave enable` command has no parameters or variables.

Downloading image without resetting

This feature allows you to upgrade the software without resetting the unit.



Note: This feature is not available on the BayStack BPS or on a stack containing a BayStack BPS.



Note: After using this feature, the Web interface will not be available until the switch or stack is rebooted.

Configuring with NNCLI

You use the `download` command to download the image without rebooting the switch using the CLI.

The `download` command upgrades the software for the BoSS 3.1 version. You can upgrade both the software image and the diagnostics image.



Note: The default of the downloading process, without this command, is that the unit resets after downloading.

The syntax for the `download` command is:

```
download [address <ip>] {image <image-name>|image-if-newer  
<image-name>|diag <filename>}[no-reset]
```

The `download` command is in the `privExec` command mode.

[Table 31](#) describes the parameters and variables for the `download` command.

Table 31 download command parameters and variables

Parameters and variables	Description
address <ip>	Specifies the TFTP server you want to use. Note: If this parameter is omitted, the system goes to the server specified by the <code>tftp-server</code> command.
image <image-name>	Enter the name of the software image you want to download.
image-if-newer <image-name>	Enter the name of the software image you want to download if newer than the current running image.
diag <filename>	Enter the name of the diagnostics image you want to download.
no-reset	Download the specified software without resetting the unit.

The software download process automatically completes without user intervention. The process erases the contents of flash memory and replaces it with a new software image. Take care not to interrupt the download process until after it runs to completion (the process can take up to 10 minutes, depending on network conditions).

When the download process is complete, the switch automatically resets (unless you specify `no-reset`) and the new software image initiates a self-test. The system returns a message after successfully downloading a new image. [Figure 8](#) displays a sample output of the download command.

Figure 8 download message

```
Download Image [ / ]
Saving Image [ - ]
Finishing Upgrading Image
```

During the download process, the unit is not operational. You can monitor the progress of the download process by observing the LED indicators.

Using SNTP

The Simple Network Time Protocol (SNTP) feature synchronizes the Universal Coordinated Time (UCT) to an accuracy within 1 second. This feature adheres to the IEEE RFC 2030 (MIB is the s5agent). With this feature, the system can obtain the time from any RFC 2030-compliant NTP/SNTP server.



Note: If you have trouble using this feature, try various NTP servers. Some NTP servers may be overloaded or currently inoperable.

The system retries connecting with the NTP server a maximum of 3 times, with 5 minutes between each retry. If the connection fails after the 3 attempts, the system waits for the next synchronization time (the default is 24 hours) and begins the process again.

Using SNTP provides a real-time timestamp for the software, shown as Greenwich Mean Time (GMT).

If SNTP is enabled (the default value is disabled), the system synchronizes with the configured NTP server at boot-up and at user-configurable periods thereafter (the default sync interval is 24 hours). The first synchronization is not performed until network connectivity is established.

SNTP supports primary and secondary NTP servers. The system tries the secondary NTP server only if the primary NTP server is unresponsive.

Configuring with NNCLI

You use the CLI to configure the SNTP feature, ensuring that you complete the following steps:

- 1 Set the primary and secondary NTP server.
- 2 Enable SNTP.
- 3 Display the UTC time.
- 4 Optionally, to ensure the synchronization happens immediately, force a synchronization.

This section discusses the following topics, which enable you to complete these steps:

- [“show sntp command,”](#) next
- [“show sys-info command”](#) on page 59
- [“sntp enable command”](#) on page 60
- [“no sntp enable command”](#) on page 61
- [“sntp server primary address command”](#) on page 61
- [“sntp server secondary address command”](#) on page 62
- [“no sntp server command”](#) on page 62
- [“sntp sync-now command”](#) on page 63
- [“sntp sync-interval command”](#) on page 63

show sntp command

The `show sntp` command displays the SNTP information, as well as the configured NTP servers. The syntax for the `show sntp` command is:

```
show sntp
```

The `show sntp` command is in the `privExec` command mode.

The `show sntp` command has no parameters or variables.

[Figure 9](#) displays sample output from the `show sntp` command.

Figure 9 show sntp command output

```
BS470_48#show sntp
SNTP Status:           Enabled
Primary server address: 47.82.2.10
Secondary server address: 47.81.2.10
Sync interval:         24 hours
Last sync source:      47.82.2.10
Primary server sync failures: 0
Secondary server sync failures: 0
Last sync time:        2003-10-27 19:32:17 GMT
Next sync time:        2003-10-28 19:32:17 GMT
Current time:          2003-10-27 19:47:35 GMT
```

show sys-info command

The `show sys-info` command displays the current system characteristics.



Note: You must have SNTP enabled and configured to display GMT time.

The syntax for the `show sys-info` command is:

```
show sys-info
```

The `show sys-info` command is in the `privExec` command mode.

The `show sys-info` command has no parameters or variables.

[Figure 10](#) displays sample output from the `show sys-info` command.

Figure 10 show sys-info command output

```
BS470_48#show sys-info
Operation Mode:      Switch
MAC Address:        00-04-38-D5-86-40
Reset Count:        0
Last Reset Type:    Power Cycle
Power Status:       Primary Power
Autotopology:       Enabled
GBIC Port 47:       None
GBIC Port 48:       None
sysDescr:           BayStack 470 - 48T
                    HW:#0D      FW:3.0.0.5   SW:v3.1.14  ISVN:2
sysObjectID:        1.3.6.1.4.1.45.3.46.1
sysUpTime:          2 days, 23:25:51
sysNtpTime:         2003-10-27 20:16:12 GMT
sysServices:        3
sysContact:
sysName:
sysLocation:
```

sntp enable command



Note: The default setting for SNTP is disabled.

The `sntp enable` command enables SNTP. The syntax for the `sntp enable` command is:

```
sntp enable
```

The `sntp enable` command is in the config command mode.

The `sntp enable` command has no parameters or variables.

no sntp enable command

The `no sntp enable` command disables SNTP. The syntax for the `no sntp enable` command is:

```
no sntp enable
```

The `no sntp enable` command is in the config command mode.

The `no sntp enable` command has no parameters or variables.

sntp server primary address command

The `sntp server primary address` command specifies the IP addresses of the primary NTP server. The syntax for the `sntp server primary address` command is:

```
sntp server primary address <A.B.C.D>
```

The `sntp server primary address` command is in the config command mode.

[Table 32](#) describes the parameters and variables for the `sntp server primary address` command.

Table 32 sntp server primary address command parameters and variables

Parameters and variables	Description
<A.B.C.D>	Enter the IP address of the primary NTP server.

The default is 0.0.0.0.

ntp server secondary address command

The `ntp server secondary address` command specifies the IP addresses of the secondary NTP server. The syntax for the `ntp server secondary address` command is:

```
ntp server secondary address <A.B.C.D>
```

The `ntp server secondary address` command is in the config command mode.

[Table 33](#) describes the parameters and variables for the `ntp server secondary address` command.

Table 33 ntp server secondary address command parameters and variables

Parameters and variables	Description
<A.B.C.D>	Enter the IP address of the secondary NTP server.

The default is 0.0.0.0.

no ntp server command

The `no ntp server` command clears the NTP server IP addresses. The syntax for the `no ntp server` command is:

```
no ntp server <primary|secondary>
```

The `no ntp server` command is in the config command mode.

Table 34 describes the parameters and variables for the `no sntp server` command.

Table 34 `no sntp server` command parameters and variables

Parameters and variables	Description
<primary secondary>	Enter the NTP server you want to clear: <ul style="list-style-type: none"> primary—clears the IP address for the primary NTP server secondary—clears the IP address for the secondary NTP server

sntp sync-now command

The `sntp sync-now` command forces a manual synchronization with the NTP server.



Note: You must have SNTP enabled before this command can take effect.

The syntax for the `sntp sync-now` command is:

```
sntp sync-now
```

The `sntp sync-now` command is in the config command mode.

The `no sntp sync-now` command has no parameters or variables.

sntp sync-interval command

The `sntp sync-interval` command specifies recurring synchronization with the NTP server in hours relative to initial synchronization. The syntax for the `sntp sync-interval` command is:

```
sntp sync-interval <0-168>
```

The `sntp sync-interval` command is in the config command mode.

[Table 35](#) describes the parameters and variables for the `sntp sync-interval` command.

Table 35 sntp sync-interval command parameters and variables

Parameters and variables	Description
<0-168>	Enter the number of hours you want for periodic synchronization with the NTP server. NOTE: 0 is boot-time only, and 168 is once a week; the default value is 24 hours.

Using DNS to ping and telnet

Using the DNS client, you can ping or telnet to a host server or to a host by name.

To use this feature, you must configure at least one domain name server; you may also configure a default domain name. If you configure a default domain name, that name is appended to hostnames that do not contain a dot. The default domain name and addresses are saved in NVRAM.

The hostnames for ping and telnet cannot be longer than 63 alphanumeric characters, and the default DNS domain name cannot be longer than 255 characters.

Configuring with NNCLI

You must use the CLI to configure the DNS client. This section discusses the following sections:

- [“show ip dns command,”](#) next
- [“ping command”](#) on page 65
- [“ip name-server command”](#) on page 67
- [“no ip name-server command”](#) on page 67
- [“ip domain-name command”](#) on page 68
- [“no ip domain-name command”](#) on page 69
- [“default ip domain-name command”](#) on page 69

- [“Sample commands” on page 69](#)

show ip dns command

The `show ip dns` command displays the DNS domain name, as well as any configured DNS servers. The syntax for the `show ip dns` command is:

```
show ip dns
```

The `show ip dns` command is in the exec command mode.

The `show ip dns` command has no parameters or variables.

[Figure 11](#) displays sample output from the `show ip dns` command.

Figure 11 show ip dns command output

```
BS470-48#show ip dns
DNS Default Domain name: us.nortel.com
DNS Servers
- - - - -
47.82.2.10
0.0.0.0
0.0.0.0
BS470-48#
```

ping command

The `ping` command tests the network connection to another network device. The command sends an Internet Control Message Protocol (ICMP) packet from the switch to the target device. The local IP address must be set before issuing the `ping` command.

You can ping a host using either its IP address or hostname.

The syntax for the `ping` command is:

```
ping <A.B.C.D or Hostname>
```

The ping command is in the exec command mode.

Table 36 describes the parameters and variables for the ping command.

Table 36 ping command parameters and variables

Parameters and variables	Description
<A.B.C.D or Hostname>	Specify: <ul style="list-style-type: none">• the IP address of the target device in dotted-decimal notation• the hostname of the device to ping (The hostname can be a simple name, such as fred; in this case the DNS domain name, if set, is appended. Or the hostname can be a full hostname, such as fred.ca.nortel.com.)

If the device receives the packet, it sends a ping reply. When the switch receives the reply, it displays a message indicating that the specified IP address is alive. If no reply is received, a message indicates that the address is not responding.

Figure 12 displays sample ping responses.

Figure 12 ping command responses

```
BS470_48#ping 10.10.40.29
Host is reachable
BPS2000#ping 10.10.41.29
Host is not reachable
```

There is no default value for this command.

ip name-server command

The `ip name-server` command adds one or more DNS servers' IP addresses. The syntax for the `ip name-server` command is:

```
ip name-server <A.B.C.D>
```

The `ip name-server` command is in the config command mode.



Note: You can add up to 3 servers; adding one at a time.

[Table 37](#) describes the parameters and variables for the `ip name-server` command.

Table 37 ip name-server command parameters and variables

Parameters and variables	Description
<A.B.C.D>	Enter the IP address of a DNS server.

The default value is 0.0.0.0.

no ip name-server command

The `no ip name-server` command removes one or more DNS servers' IP addresses. The syntax for the `no ip name-server` command is:

```
no ip name-server <A.B.C.D>
```

The `no ip name-server` command is in the config command mode.

[Table 38](#) describes the parameters and variables for the `no ip name-server` command.

Table 38 no ip name-server command parameters and variables

Parameters and variables	Description
<A.B.C.D>	Enter the IP address of a DNS server.

The default value is 0.0.0.0.

ip domain-name command

The `ip domain-name` command sets the system's DNS domain name. The syntax for the `ip domain-name` command is:

```
ip domain-name [<LINE>]
```

The `ip domain-name` command is in the `config` command mode.

[Table 39](#) describes the parameters and variables for the `ip domain-name` command.

Table 39 ip domain-name command parameters and variables

Parameters and variables	Description
<LINE>	Enter a DNS domain name.

The default value for this command is an empty string.

no ip domain-name command

The `no ip domain-name` command clears the system's DNS domain name (sets it to an empty string). The syntax for the `no ip domain-name` command is:

```
no ip domain-name
```

The `no ip domain-name` command is in the config command mode.

The `no ip domain-name` command has no parameters or variables.

default ip domain-name command

The `default ip domain-name` command clears the system's DNS domain name (set it to an empty string). The syntax for the `default ip domain-name` command is:

```
default ip domain-name
```

The `default ip domain-name` command is in the config command mode.

The `default ip domain-name` command has no parameters or variables.

Sample commands

```
BayStack470(config)#  
ip name-server 47.81.2.10  
ip domain-name us.nortel.com  
ping 47.80.225.27  
ping labcoat  
ping labcoat.us.nortel.com  
BayStack470(config)#
```

Changing HTTP port number

Beginning with software release 3.1, you can configure the HTTP port. This feature provides enhanced security and network access.

The default HTTP port typically used to communicate between the Web client and the server is the well-known port 80. With this feature, you can change the HTTP port.

You can modify the HTTP port while the switch is running. The HTTP port value is saved in NVRAM, and is saved across reboots of the switch.

Configuring with NNCLI

You configure the HTTP port number using the NNCLI. This sections discusses the following topics:

- [“show http-port command,”](#) next
- [“http-port command”](#) on page 71
- [“default http-port”](#) on page 71

show http-port command

The `show http-port` command displays the port number of the HTTP port. The syntax for the `show http-port` command is:

```
show http-port
```

The `show http-port` command is in the `privExec` command mode.

The `show http-port` command has no parameters or variables.

[Figure 13](#) displays sample output from the `show http-port` command.

Figure 13 show http-port command output

```
BS470_48#show http-port
HTTP Port: 80
```

http-port command

The `http-port` command sets the port number for the HTTP port. The syntax for the `http-port` command is:

```
http-port <1024-65535>
```

The `http-port` command is in the config command mode.

[Table 40](#) describes the parameters and variables for the `http-port` command.

Table 40 http-port command parameters and variables

Parameters and variables	Description
<1024-65535>	Enter the port number you want to be the HTTP port.



Note: To set the HTTP port to 80, use the default `http-port` command.

The default value for this parameter is port 80.

default http-port

The default `http-port` command sets the port number for the HTTP port to the default value of 80. The syntax for the `default http-port` command is:

```
default http-port
```

The `default http-port` command is in the config command mode.

The default `http-port` command has no parameters or variables.

Displaying MAC address table by port number

You can now filter the MAC Address table by port number. You must use the NNCLI for this feature.

show mac-address-table command

The `show mac-address-table` command displays the current contents of the MAC address forwarding database table. The syntax for the `show mac-address-table` command is:

```
show mac-address-table [vid <1-4094>] [aging-time] [address <H.H.H>] [port <portlist>]
```

The `show mac-address-table` command is in the `privExec` command mode.

[Table 41](#) describes the parameters and variables for the `show mac-address-table` command.

Table 41 show mac-address-table command parameters and variables

Parameters and variables	Description
vid <1-4094>	Enter the number of the VLAN you want to display the forwarding database of. Default is to display the management VLAN's database.
aging-time	Displays the time in seconds after which an unused entry is removed from the forwarding database.
address <H.H.H>	Displays a specific MAC address if it exists in the database. Enter the MAC address you want displayed.
port <portlist>	Enter the port number(s) you want to display the MAC address table for.

[Figure 14](#) displays sample output from the `show mac-address-table` command.

Figure 14 show mac-address-table command output

```
BS5510-24T#show mac-address-table
Mac Address Table Aging Time: 300
Number of addresses: 22
```

MAC Address	Source	MAC Address	Source
00-00-81-06-2B-A6	Port: 21	00-00-A2-ED-2A-63	Port: 21
00-04-38-D5-86-40		00-04-DC-92-8A-03	Port: 21
00-08-74-CC-78-55	Port: 21	00-60-FD-EB-47-F5	Port: 21
00-60-FD-EB-5D-95	Port: 21	00-C0-4F-61-2B-66	Port: 21
00-E0-16-53-28-82	Port: 21	00-E0-7B-46-1A-38	Port: 21
08-00-20-1F-E1-A2	Port: 21	08-00-20-7B-8E-3F	Port: 21
08-00-20-8D-5B-D4	Port: 21	08-00-20-8E-D5-DA	Port: 21
08-00-20-8E-E0-42	Port: 21	08-00-20-A2-39-48	Port: 21
08-00-20-A2-48-62	Port: 21	08-00-20-B5-8B-79	Port: 21
08-00-20-B5-92-EA	Port: 21	08-00-20-B5-94-E6	Port: 21
08-00-20-C6-7A-6B	Port: 21	08-00-20-EB-B5-A6	Port: 21
08-00-69-0F-3E-40	Port: 21		

There are no default values for this command.

Custom Autonegotiation Advertisements

Custom Autonegotiation Advertisements (CANA) allows you to customize the capabilities that you advertise. For example, if a port is capable of 10/100/1000 full duplex operation, the port can be configured to only advertise 10 half-duplex capabilities.

CANA allows you to control the capabilities that are advertised by the BayStack switch as part of the auto-negotiation process. In the current software releases, auto-negotiation can either be enabled or disabled.

When auto-negotiation is disabled, the hardware is configured for a single (fixed) speed and duplex value. When auto-negotiation is enabled, the advertisement made by the product is a constant value based upon all speed and duplex modes supported by the hardware.

When autonegotiating, the switch selects the highest common operating mode supported between it and its link partner.

In certain situations, it is useful to be able to auto-negotiate a specific speed and duplex value. In these situations, the switch can allow for attachment at an operating mode other than its highest supported value.

For example, if the switch only advertises a 100 Mbps full-duplex capability on a specific link, then the link only goes active if the neighboring device is also capable of auto-negotiating a 100 Mbps full-duplex capability. This prevents mismatched speed/duplex modes if customers disable auto-negotiation on the neighboring device.

CANA is available through the Command Line Interface (CLI). The CLI provides the following commands for CANA:

- `show auto-negotiation-advertisements [port <portlist>]`
- `no auto-negotiation-advertisements [port <portlist>]`

To show hardware advertisement capabilities (userExec mode):

- `show auto-negotiation-capabilities [port <portlist>]`

To configure advertisements (interface configuration mode):

- `auto-negotiation-advertisements [port <portlist>]
[10-full] [10-half] [100-full] [100-half]
[1000-full] [1000-half] [asymm-pause-frame] [none]
[pause-frame]`
- `default auto-negotiation-advertisements [port <portlist>]`



Note: This feature is available only for built-in 10/100 ethernet ports.

When custom autonegotiation advertisements is in use on a port, autonegotiation is displayed as “custom” in the console and web-based management interfaces.

Unit replacement

Unit replacement allows you to upgrade a standalone unit with the configuration of the inactive unit off-line, before adding it to the stack. This is also called a staging operation.

It also allows you to retrieve a single unit configuration from a stack's binary configuration file. The unit can then be inserted into the stack without requiring a reboot of the entire stack.

Replacing a unit in a stack



Note: You must use either the console interface (CI) menus, the NNCLI, or the Web-based management system to replace or insert units into a stack.

The following summary overview shows the major steps required to replace a failed unit in a stack configuration and preserve configuration information:

- 1 Ensure that you have uploaded the configuration file from the stack to the TFTP server.
- 2 Download the part of the configuration file corresponding to the unit you are replacing to standalone BayStack switch *before* inserting it into stack.
- 3 Assign the appropriate number to the new unit.
- 4 Turn off the new unit.
- 5 Insert new unit into stack.
- 6 Turn on the new unit.



Note: Replacing a unit in a stack is not available for mixed stacks.



Note: You must follow the steps of the procedure described below in the exact order or you will encounter problems.

To replace a failed unit in a stack configuration, and preserve configuration information:

- 1 Ensure that you have uploaded the stack configuration file to the TFTP server using the management system before a unit fails.
- 2 Obtain the new BayStack switch you want to insert into the stack to replace the unit that failed.
- 3 Ensure that the new switch you will be inserting is set to factory default values. You will be configuring this new unit in *standalone* mode, before inserting it into the stack.
- 4 Download the part of the configuration file corresponding to the unit you are replacing from the TFTP server to the standalone BayStack switch unit. (The standalone unit extracts the relevant configuration information.)

With the management system you are using (connected to the standalone replacement unit), you will specify the unit you are replacing. The standalone switch resets, and reboots with the correct configuration for the stack.
- 5 In the stack, using the management system, specify the unit number you want to replace.
- 6 Physically replace the failed unit in the stack with the newly configured switch and complete the cabling.
- 7 Turn on the replaced unit.



Note: The new unit must be running the identical software and firmware version as the unit you are replacing. You must replace a BayStack 470-48T switch with a BayStack 470-48T switch and replace a BayStack 470-24T switch with a BayStack 470-24T switch.

The new unit joins the stack as the replaced unit and it comes up appropriately, without resetting the stack.

If you are replacing the base unit, remember that the stack will have a temporary base unit. When you replace the unit, the newly replaced unit will not automatically resume as the base unit. You must configure the replaced unit as the base unit, using either the rear-panel Unit Select switch or the front-panel UI button. You may reset the stack to reactivate the new base unit.



Note: To insert a new unit into a stack, cable the units appropriately and the new unit will join the stack; you do not need to reset the stack.

Command Line Interface (CLI) commands for unit replacement



Note: The console and web-based management interfaces also support unit replacement.

Use the following CLI commands for unit replacement:

To download the configuration to a replacement unit (in standalone mode):

```
copy tftp config unit <unit #>
```

To prepare the stack to receive the replacement unit (in stack mode):

```
stack replace unit <1-8>
```

RADIUS fallback enhancement

The system can use the local password of the switch or stack if the RADIUS server is unavailable to authenticate the user for administrative access. This option is disabled by default.

RADIUS password fallback allows you to configure password fallback as an option when using RADIUS authentication for login and password.

When RADIUS password fallback is enabled and the RADIUS server is somehow unavailable or unreachable, you can use the local switch or stack password to login into the switch or stack.

When RADIUS password fallback is disabled, you need to specify the RADIUS username and password from the NetLogin screen and you will not be able to login to the switch or stack unless the RADIUS server is configured and reachable in order to authenticate the login and password.

The user can use the following CLI commands to enable and disable this feature:

- `radius-server password fallback`
- `no radius-server`

RADIUS access challenge

BoSS 3.1 provides support for RADIUS access challenge as specified in RFC 2138. No configuration on the switch is required.

RFC 2138 specifies that the RADIUS server can provide further security of authentication by challenging users with more levels of challenges and passwords.

Enhanced autotopology display

Enhanced autotopology display shows both local and remote units and ports using the CLI command `show autotopology nmm-table`.

show auto-topology nmm-table command

The `show autotopology nmm-table` command displays the network management module (NMM) table. The Network Management Module table shows the slot number and port number of the remote device used to send out the topology packet. For BayStack stackable switches, the slot number refers to the unit number of the switch in the stack. The syntax for the `show autotopology nmm-table` command is:

```
show autotopology nmm-table
```

The `show autotopology nmm-table` command is in the `privExec` command mode.

The `show autotopology nmm-table` command has no parameters or variables. [Figure 15](#) displays a sample output of the `show autotopology nmm-table` command.

Figure 15 show autotopology nmm-table command output

```
BS470-48T#show autotopology nmm-table

LSlot
LPort  IP Addr      Seg ID  MAC Addr      Chassis Type      BT LS  CS      RSlot
-----  -
0/ 0    10.30.31.234    0x000000 000438d4eade BayStack 470      12 Yes HTBT  NA
1/ 7    10.30.31.235    0x000301 0004dcfdc19e BayStack 450      12 Yes HTBT  3/ 1
2/47    10.30.31.231    0x000119 0009973d3ae1 System 5000      12 Yes HTBT  NA

BS470-48T#
```

[Table 42](#) describes the fields in the output of the `show autotopology nmm-table` command.

Table 42 show autotopology nmm-table command output fields

Field	Description
LSlot/LPort	Local Slot/Local Port—The local slot (unit number) and port that received the topology packet.
IP Addr	IP Address—The IP address of the device.
Seg ID	Segment ID—The segment ID of the device.

Table 42 show autotopology nmm-table command output fields (continued)

Field	Description
MAC Addr	MAC Address—The MAC address of the device.
Chassis Type	Chassis Type—A description of the type of device.
BT	Backplane Type—The backplane type of the device. BayStack devices always return a value of 12.
LS	Local Segment—Displays whether the device is on a local segment or not. Possible values are Yes or No.
CS	Current State—Possible values are NEW, HTBT (heartbeat), and TPCH (topology change).
RSlot/RPort	Remote Slot/Remote Port—The remote slot (unit number) and port used to send out the topology packet.

Display date of manufacture and HW deviation number in WEB/CLI/Console

The System Characteristics screen in the console interface, the show sys-info command in the CLI, and the Switch Information page of the web interface now display the following information: HW rev, FW rev, date of manufacture (DOM), and HW deviation number. In stack mode, this information is displayed in the stack information page for all stack units.

50 addresses for IPMGR

There are 50 addresses available for IP Manager. IP Manager is configured through the NNCLI using the ipmgr command. The ipmgr command is in the config command mode.

Use the following CLI commands for IP Manager list:

```
BPS2000(config)#ipmgr source-ip ?
```

```
<1-50>
```

Select the address/mask pair.

To remove an IP from the IPMGR list:

```
BPS2000(config)#no ipmgr source-ip ?
```

```
<1-50>
```

Select the address/mask pair

Restricted SSH access with IP Manager list

When telnet is enabled and use list is also enabled, the IP Manager list restricts SSH access.

Telnet client support

The telnet client allows you to telnet to a host or UNIX machine. One telnet client session at a time is supported.

telnet command

The `telnet` command allows you to establish a telnet session to a remote system using either its IP address or hostname.



Note: When establishing a telnet connection to a host, set the terminal type on the host to VT100. You may need to adjust the screen size parameter to ensure proper formatting.

This command is not available in configuration command modes. The `telnet-access` command overrides it.

The syntax for the `telnet` command is:

```
telnet <A.B.C.D or Hostname>
```

The `telnet` command is in the `exec` command mode.



Note: You use the `telnet` command in `config` mode to configure a telnet session to the switch, while you use the `telnet` command in `exec` command mode to establish a telnet session to a remote system.

Table 43 describes the parameters and variables for the `telnet` command.

Table 43 telnet command parameters and variables

Parameters and variables	Description
<A.B.C.D or Hostname>	Enter the IP address or the hostname of the device to connect to. The hostname can be a simple name, such as <code>fred</code> ; in this case the DNS domain name, if set, is appended. Or the hostname can be a full hostname, such as <code>fred.ca.nortel.com</code> .

There is no default value for this command.

Trap notification when configuration changes saved to NVRAM

When configuration changes are written to non-volatile memory, a trap (`bsnConfigurationSavedToNvram`) is sent to the trap receiver indicating that a change has occurred to the configuration of the device. This trap will also appear as an event in the volatile system log.

Displaying the default interface

To display the current default interface, execute the following command:

```
show cmd-interface
```

Below is an example of the output from the command:

```
BPS2000#show cmd-interface
```

Default interface: Menu

User-based policies

This feature allows user-specific QoS policy information to be manipulated based on the presence, or lack thereof, of a specific network user. User information is retrieved from the RADIUS Server during EAP authentication and passed to the QoS Agent. The QoS Agent, in turn, notifies OPS of the user's presence if the policy server is currently in-charge of policy configuration. OPS may then download policy components to the device that are associated with the user. The User Based Policies (UBP) components will automatically be deleted when the user logs off or is no longer authenticated.

This feature adds an ON/OFF attribute to the console interface to enable/disable UBP support. For SNMP support, an Enterprise-specific MIB is added. CLI support is similar to other EAP configuration. This attribute is presently not supported from the Web interface.

In a mixed stack including the 450, this attribute defaults to disabled and cannot be changed (i.e, this feature is disabled).

Configuring with NNCLI

eapol user-based-policies enable command

The `eapol user-based-policies enable` command enables user-based-policies. RADIUS must be configured prior to enabling user-based-policies. The syntax for user-based-policies is:

```
eapol user-based-policies enable
```

no eapol user-based-policies enable command

The `no eapol user-based-policies enable` command disables user-based-policies. The syntax for `no eapol user-based-policies enable` is:

```
no eapol user-based-policies enable
```

default eapol user-based-policies enable command

The `default eapol user-based-policies enable` command sets user-based-policies to the default setting. The default setting for user-based-policies is disabled. The syntax for the `default eapol user-based-policies enable` command is:

```
default eapol user-based-policies enable
```

show eapol

The `show eapol` command shows whether user-based-policies are enabled or disabled. The syntax for `show eapol` is:

```
show eapol
```

Related publications

For more information about using BoSS, refer to the following publications:

- BayStack 450 switch documentation set
- BayStack 460 switch documentation set
- BayStack 470 switch documentation set
- BayStack BPS documentation set

You can print selected technical manuals and release notes free, directly from the Internet. Go to the www.nortelnetworks.com/documentation URL. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe* Acrobat Reader* to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the www.adobe.com URL to download a free copy of the Adobe Acrobat Reader.

How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact Nortel Networks Technical Support. To obtain contact information online, go to the www.nortelnetworks.com/cgi-bin/comments/comments.cgi URL, then click on Technical Support.

From the Technical Support page, you can open a Customer Service Request online or find the telephone number for the nearest Technical Solutions Center. If you are not connected to the Internet, you can call 1-800-4NORTEL (1-800-466-7835) to learn the telephone number for the nearest Technical Solutions Center.

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the <http://www.nortelnetworks.com/help/contact/erc/index.html> URL.

