Infrastructure Management Supported Devices

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration — Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
Motorola	NX 9500	5.2.x	✔	✔					✔
	NX 9000	5.1	✔	✔					✔
		5.2	✔	✔					✔
		5.3	✔	✔					
	NX 6500	5.2.4	✔	✔	WiNG Only	✔	✔	✔	✔
	NX 4500	5.2.4	✔	✔	WiNG Only	✔	✔	✔	✔
	RFS7000	1.3.1.0-003R			✔				
		3.3.1.0-003			✔				
		4.1.0.0-042R	✔	✔	✔	✔	✔	✔	✔
		4.2.x	✔	✔	✔	✔	✔	✔	✔
		4.3.0.0-59R	✔	✔	✔	✔	✔	✔	✔
		4.3.2.0-12R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	RFS6000	1.3.1.0-003R							
		3.3.1.0-003	✔	✔	✔	✔	✔	✔	✔
		4.1.0.0-	✔	✔	✔	✔	✔	✔	✔

		042R							
		4.3.2.0-12R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration — Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
Motorola (cont)	RFS6000 (cont)	5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	RFS4000	4.1.0.0-042R	✔	✔	✔	✔	✔	✔	✔
		4.2.x	✔	✔	✔	✔	✔	✔	✔
		4.3.0.0-59R	✔	✔	✔	✔	✔	✔	✔
		4.3.2.0-12R	✔	✔	✔	✔	✔	✔	✔
		5.0.0.107R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	WS5100	2.1.x			* to 3.3.1.0-003R.v2 Only				
		2.1.4.0-001R	✔	✔					
		3.0.2.0-008R	✔	✔	✔	✔	✔	✔	✔
		3.3.1.0-003R	✔	✔	✔	✔	✔	✔	✔
		3.3.3.0-006R	✔	✔	✔	✔	✔	✔	✔
	WS2000	2.3.2.0			✔				
		2.4.1.0	✔	✔	✔	✔	✔	✔	✔

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration – Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
		2.4.3.0	✔	✔	✔	✔	✔	✔	✔
	AP7181	3.2.1	✔	✔	✔	✔	✔		✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP7161	5.2.0.0-069R	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP7131	3.2.0.0			✔				
		3.1.1.0			✔				
		3.2.1.0			✔				
		4.0.0.0	✔	✔	✔	✔	✔	✔	✔
		4.0.1.0	✔	✔	✔	✔	✔	✔	✔
		4.0.2.0	✔	✔	✔	✔	✔	✔	✔
Motorola (cont)	AP7131 (cont)	4.0.3.0	✔	✔	✔	✔	✔	✔	
		4.1.0.0	✔	✔	✔	✔	✔	✔	✔
		4.1.3.0-010R	✔	✔	✔	✔	✔	✔	✔
		4.1.4.0-002R	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔

	AP8132	5.2.6	✔	✔	✔	✔	✔	✔	✔
	AP650	5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP621/622	5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP6511	5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP6522	5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP6521/ AP6562/ AP6522M	5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP6532	5.2	✔	✔	✔	✔	✔		✔
		5.2.13	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔		✔
		5.4.0	✔	✔	✔	✔	✔	✔	✔
		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP6511	5.2	✔	✔	✔	✔	✔		✔
		5.3	✔	✔	✔	✔	✔		✔

		5.4.1	✔	✔	✔	✔	✔	✔	✔
	AP5131	2.1.1.0-001R			✔				
		2.2.0.0-023R	✔	✔	✔	✔	✔	✔	✔
		2.3.0.0-019R	✔	✔	✔	✔	✔	✔	✔
		2.3.2.0-001R	✔	✔	✔	✔	✔	✔	✔
		2.3.2.1-002R	✔	✔	✔	✔	✔	✔	✔
	AP5131 (ADP)	2.4.0.0-035R	✔	✔	✔	✔	✔	✔	✔
		2.4.1.0.10R	✔	✔	✔	✔	✔	✔	✔
		2.5.0.0-041R	✔	✔	✔	✔	✔	✔	✔
		2.5.1.0-016R	✔	✔	✔	✔	✔	✔	✔
	AP4131	3.7.0-68	✔	✔					✔
		3.95-04	✔	✔					✔
	ES3000	1.0.4.0-002R	✔						✔
	CB3000	1.3.0.0	✔		✔	✔			
		1.3.1.0	✔		✔	✔			
Cisco	WLC 4400, 2x00, 5500	4.2.207.0	✔	✔	✔				
		5.2.193.0	✔	✔	✔	✔	✔	✔	✔
		6.0.196.0	✔	✔	✔	✔	✔	✔	✔
		7.0.98.0	✔	✔	✔	✔	✔	✔	✔
	WLC 2x00	7.0.235.0	✔	✔	✔	✔	✔	✔	✔
		6.0.202.0	✔	✔	✔	✔	✔	✔	✔

		MD							
		5.2.193.0 ED	✔	✔	✔	✔	✔	✔	✔
		4.2.209.0 MD	✔	✔	✔	✔	✔	✔	✔

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration — Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
Cisco (cont)	1250	12.4.10b(JDA) (10)	✔	✔	✔	✔	✔	✔	✔
		12.4.21a-JA1	✔	✔	✔	✔	✔	✔	✔
		12.4.21a-JY(ED)	✔	✔	✔	✔	✔	✔	✔
		12.4.25d-JA1 ED	✔	✔	✔	✔	✔	✔	✔
	1230	12.2.x			✔				
		12.3.8-JEC2(ED)	✔	✔	✔	✔	✔	✔	✔
	1210	12.3(8)JA	✔	✔	✔	✔	✔	✔	✔
	1140	12.4-21aJY(ED)	✔	✔	✔	✔	✔	✔	✔
		12.4.25d-JA1 ED	✔	✔	✔	✔	✔	✔	✔
	1130	12.3.x			✔				
		12.4-10b(JDA)	✔	✔	✔	✔	✔	✔	✔
		12.4.21a-JA1(ED)	✔	✔	✔	✔	✔	✔	✔
		12.4.25d-JA1 ED	✔	✔	✔	✔	✔	✔	✔

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration – Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
Extreme	WM3700	4.2.1.0-008R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	WM3600	4.2.1.0-008R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	WM3400	4.2.1.0-008R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
		5.3	✔	✔	✔	✔	✔	✔	✔
	WM20	5.3	✔	✔		✔			
	WM200	5.3	✔	✔		✔			

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration – Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
Extreme (cont)	WM2000	5.3	✔	✔		✔			
	AP3510	2.4.1.0-008R	✔	✔	✔	✔	✔	✔	✔
	AP3550	2.4.1.0-008R	✔	✔	✔	✔	✔	✔	✔
	AP4710	4.1	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔

Manufacturer	Model	Version	Up/Down Status Monitoring	Statistics Data Collection	Upgrade/Downgrade	Configuration CLI Templates with User Defined Variables	Configuration – Extraction Variables	Configuration GUI Based Configuration	SNMP Trap Reception
	AP4750	5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	AP4610	4.2.1.0-008R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	AP4620	4.2.1.0-008R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	AP4532	5.2	✔	✔	✔	✔	✔	✔	✔
	AP4511	5.2	✔	✔	✔	✔	✔	✔	✔
Brocade	BR-RFS7000	4.3.1.0-016R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	BR-RFS6000	4.3.1.0-016R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	BR-RFS4000	4.3.1.0-016R	✔	✔	✔	✔	✔	✔	✔
		5.1	✔	✔	✔	✔	✔	✔	✔
Brocade (cont)	BR-RFS4000	5.2	✔	✔	✔	✔	✔	✔	✔
	BR7131	4.1.1.0-018R	✔	✔	✔	✔	✔	✔	✔

		5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	BR650	5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	BR6511	5.1	✔	✔	✔	✔	✔	✔	✔
		5.2	✔	✔	✔	✔	✔	✔	✔
	BR5181	2.4.1.0-006R	✔	✔	✔	✔	✔	✔	✔
Aruba	3000 Series Controller	6.0.1	✔	✔					
		6.1.3	✔	✔	✔	✔	✔	✔	✔
	600 Series Controller	6.0.1	✔	✔					
		6.1.3	✔	✔	✔	✔	✔	✔	✔