



ExtremeCloud IQ (New) v25.4.4-5 Release Notes

Enhancements, Fixes, and Supported Devices

9039375-06 Rev AA
September 2025



Copyright © 2025 Extreme Networks, Inc. All rights reserved.

Legal Notice

Extreme Networks, Inc. reserves the right to make changes in specifications and other information contained in this document and its website without prior notice. The reader should in all cases consult representatives of Extreme Networks to determine whether any such changes have been made.

The hardware, firmware, software or any specifications described or referred to in this document are subject to change without notice.

Trademarks

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries.

All other names (including any product names) mentioned in this document are the property of their respective owners and may be trademarks or registered trademarks of their respective companies/owners.

For additional information on Extreme Networks trademarks, see: <https://www.extremenetworks.com/about-extreme-networks/company/legal/trademarks>

Open Source Declarations

Some software files have been licensed under certain open source or third-party licenses.

End-user license agreements and open source declarations can be found at: <https://www.extremenetworks.com/support/policies/open-source-declaration/>



Table of Contents

Abstract.....	iv
Help and Support.....	v
General Release Information.....	6
Current Release: 25.4.4-5	6
Release: 25.4.4-5 Addressed Issues.....	6
Account Management.....	6
Alerts.....	6
API.....	7
Device Issues.....	7
Licensing.....	7
Logs.....	8
Onboarding.....	8
Roles.....	8
User Interface.....	8
Visualize.....	9
Release: 25.4.4-5 Known Issues.....	9
ExtremeCloud IQ (New) Public IP Address Blocks.....	11
Supported IQ Engine Software.....	12
New Features in 25.4.0.....	13
Device Support Information.....	15
Universal Compute Platform.....	15
Access Points.....	15
Universal Hardware.....	16
IQ Engine (Cloud Native).....	17
Switches.....	17
Universal Hardware.....	19
ExtremeXOS.....	38
VOSS.....	42
Supported Browsers and Display Settings.....	43
Desktop and Mobile Browser Support.....	43
Display Settings.....	44



Abstract

This release notes document for ExtremeCloud™ IQ (New) version 25.4.4-5 outlines enhancements, resolved issues, and expanded device support across the platform. It introduces new device-level configuration capabilities for Fabric Engine 7x20 and 4k/5k SKUs, extends Extreme Platform ONE functionality for both wired and wireless configurations, and maintains feature parity with previous versions. The release supports IQ Engine 10.8.3 and includes updates to the EXOS, VOSS, and Switch Engine support matrices. Key fixes address UI inconsistencies, role-based access issues, and API errors across ExtremeCloud IQ and Extreme Platform ONE Networking. The document provides detailed support matrices for controllers, access points, switches, routers, and third-party hardware, along with configuration prerequisites and known limitations. It also includes updated public IP address blocks for global data centers and browser compatibility guidelines. This technical document is intended for IT professionals managing enterprise network infrastructure and offers comprehensive guidance for deployment, configuration, and troubleshooting.



Help and Support

If you require assistance, contact Extreme Networks using one of the following methods:

Extreme Portal


Search the GTAC (Global Technical Assistance Center) knowledge base; manage support cases and service contracts; download software; and obtain product licensing, training, and certifications.

The Hub

A forum for Extreme Networks customers to connect with one another, answer questions, and share ideas and feedback. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.

Call GTAC

For immediate support: (800) 998 2408 (toll-free in U.S. and Canada) or 1 (408) 579 2800. For the support phone number in your country, visit www.extremenetworks.com/support/contact.



General Release Information

Current Release: 25.4.4-5

September 2025

Release: 25.4.4-5 Addressed Issues

The following tables list Addressed Issues for ExtremeCloud IQ 25.4-5.

Account Management

Issues related to user account creation, status, and account-level operations.

Issue ID	Description
XCP-11288	Addressed an issue where logout from one application does not terminate sessions in other open applications by implementing unified logout functionality across Extreme Platform ONE Networking, ExtremeCloud IQ, SD-WAN, EII, and Extreme Platform ONE Networking Security applications.
XCP-11301	Fixed an issue where Extreme Platform ONE Networking logout does not support a unified logout URL by implementing support for single logout URL functionality.
XIQ-44235	Fixed an issue where users with no active external accounts were not properly redirected to ExtremeCloud IQ (New) home page, bypassing VHM selection.

Alerts

Issues related to alerts.

Issue ID	Description
CFD-14520	Addressed an issue where when selecting a cluster of APs connected to a switch, the Alerts tab in the Device Inspector panel does not display the alert count for the associated switch. However, if the Device Inspector is closed and the switch is selected directly (outside the AP cluster view), the correct alert count is shown.

API

Issues related to Application Programming Interface (API) functionality and responses.

Issue ID	Description
WS-2718	Addressed an issue where when attempting to log out of Extreme Platform ONE Networking while using an Incognito browser window, the application automatically logs back in.
XIQ-44624	Fixed an issue by adding a stacked_view parameter to POST rm-devices-table API to return all devices including stack members when set to False.

Device Issues

Issues related to device visibility, device information display, and device management functionality.

Issue ID	Description
XCP-12330	Fixed an issue where SD-WAN devices were not getting synced after deletion from new scheduled jobs.

Licensing

Issues related to license management and contract handling.

Issue ID	Description
WS-3189	Addressed an issue where the CUID Banner experiences a noticeable delay in loading after a license is unlinked from Extreme Platform ONE Networking.
WS-3195	Fixed an issue where the "Application Tour" pop-up appears for new users even before a license is linked to their accounts.
WS-3204	Fixed an issue where Users with Legacy Entitlement Keys (LEK) are redirected to Extreme Platform ONE Networking instead of ExtremeCloud IQ Classic after login.
XCP-10232	Addressed an issue where the system allocates Extreme Platform ONE Networking licenses to devices even when sufficient licenses are not available, leading to license violation banner in ExtremeCloud IQ (Classic).
XCP-12241	Fixed an issue where device_license was incorrect and mismatched between ExtremeCloud IQ (New) and Extreme Platform ONE Networking platforms.
XCP-12280	Fixed an issue where license_status column showed incorrect values in assets database for devices with allocated licenses.

Logs

Issues related to audit logs, security logs, and logging functionality.

Issue ID	Description
XCP-10467	Addressed an issue where during onboarding failures, the Audit Log incorrectly records the status as "Success".

Onboarding

Issues related to device onboarding processes, location selection, and bulk device operations.

Issue ID	Description
CFD-14894	Fixed an issue where customers were unable to delete multiple serial numbers from ODI, preventing device onboarding.
XCP-10317, XCP-10324	Addressed an issue where Wired and Wireless AP serial numbers are not validated during onboarding, and the expected HTTP 400 error code is not returned.

Roles

Issues related to role-based access control and user permissions.

Issue ID	Description
XCP-10865	Addressed an issue where users with the NetSecOps Role scoped to specific sites are able to create new site groups successfully, but unable to view new groups after creating them.

User Interface

Issues related to general user interface components and interactions.

Issue ID	Description
CFD-14533	Addressed an issue where the statistics and the number of issues shown in the Connectivity Issues widget do not match the statistics and the number of issues shown in the filtered data grid.
WS-2894	Addressed an issue where the Terms & Conditions pop-up briefly appears after login but disappears without user interaction.
WS-3418	Addressed enhancements to Workspace Landing page including making widgets clickable and updating labels for consistency.
WS-2708, XCP-10793	Extreme Platform ONE Networking does not apply the selected language to the following elements: • Dashboard title and menu name • Sub text of the tiles • Table column header

Visualize

Issues related to network visualization, topology display, and visualization features.

Issue ID	Description
NVO-9916	Fixed an issue where websocket and telegraf events were not visible in RDC during production operations.

Release: 25.4.4-5 Known Issues

The following table lists Known Issues for ExtremeCloud IQ 25.4.4-5.

Table 1: Known Issues in release 25.4.4-5

Issue ID	Description
9-dot Menu	
XCP-3475, XCP-10803, XCP-11090	Accessing applications from the 9-dot menu fails with Internal Server Errors.
Account Management	
WS-775	The Verify Email option in the Account Lockout Notification email takes you to the ExtremeCloud IQ application.
WS-1916	Users with multiple accounts are unable to switch accounts or VIQs.
WS-3238	Restricted screen is visible to an External VIQ user when switching from an Internal VIQ screen.
API	
XIQ-39330	The packet loss metric is incorrectly reported as a raw packet count rather than a percentage in both the API response and the user interface.
Browser Issues	
NVO-1308	Unable to add or delete tags in Safari browser as pop-ups are not working.
NVO-6837	When using Firefox, the device icons are misaligned in the Physical View.
XCP-9905	When accessing the ExtremeCloud IQ URL (https://ws2.qa.xcloudiq.com/) or the SD-WAN URL (https://extremecloudiq.com/discovery-apps), users are redirected to the existing login pages instead of the Extreme Platform ONE Networking login page.
Contracts	
CFD-14518	Canceled contracts are displayed as active in the Contracts view.
Device Management	
NVO-6878	The Device Inspector does not display the Client tab for some devices.

Table 1: Known Issues in release 25.4.4-5 (continued)

Issue ID	Description
XCP-5227, XCP-5268	Incorrect "Managed_by" value for locally managed devices.
XCP-10812	Device managed by Site Engine cannot be changed from Managed to Unmanaged and Unmanaged to Managed in Extreme Platform ONE Networking. Use ExtremeCloud IQ to perform such actions.
XIQ-44031	The number of client issues displayed on the Client List page does not match the count shown on the C360 > Troubleshooting > Client Issues .
Licensing	
XCP-11193	Linking a portal account with Extreme Platform ONE Networking only licenses fails to redirect users from ExtremeCloud IQ to Extreme Platform ONE Networking.
XCP-11270	A user account with both Extreme Platform ONE Networking and ExtremeCloud IQ licenses is redirected to the ExtremeCloud IQ login page after login, instead of the expected Extreme Platform ONE Networking login page.
Logs	
XCP-11224	The Audit Log displays API denied error log entries, which are not relevant.
Onboarding	
XCP-6924	The general device onboarding failed toast messages must include reason for failure.
XCP-10371	Wired and Wireless onboarding processes onboard more than 10 devices, exceeding the intended limit.
XCP-10407	The DLCS service returns inconsistent schema structures for HTTP 400 errors across different onboarding interfaces.
Roles	
WS-3030	The eligibility banner ("Connect Eligible and Not Eligible") is displayed incorrectly when accessing the application using a role-based account.
XCP-10308	Manage or Unmanage actions are not performed for the NetSecOps Role.
SSO	
XCP-8507	The login button does not activate for certain SSO-enabled user login instances.
Troubleshooting	
XCP-11234	The number of client issues displayed on the Client List page does not match the count on the C360 > Troubleshooting > Client Issues .
User Interface	
WS-2809	After switching the language to English from another language, a browser refresh is required to display the page content in English.

Table 1: Known Issues in release 25.4.4-5 (continued)

Issue ID	Description
XCP-5065	Search and Filter does not filter the appliance cluster.
XCP-5043	UCP appliance is misaligned in the table under Asset > Appliance .
XCP-6945	Table alignment for the child devices is not aligned under All > Switch > Appliance .
Visualize	
NVO-7586	Fabric links may not appear in the Fabric Layer View when devices use the default ISIS area ID 1515.fee1.900d.1515.fee1.900d and are running Visualization version 24.5 or older.
NVO-8908	Node custom positions in topology are not retained on browser refresh.

ExtremeCloud IQ (New) Public IP Address Blocks

Data Center	IP Block	Addresses and Ports
Global Data Center (GDC)	44.234.22.92/30 18.194.95.0/28 34.253.190.192/26 3.234.248.0/27	
Australia (AUS)	13.210.3.192/28 18.98.198.80/28	Firewall Address and Port Information
Azure, Canada Central (ACA)	20.151.64.48/28	Firewall Address and Port Information
Azure, US East (AVA)	52.226.89.112/28	Firewall Address and Port Information
Brazil (BR)	18.228.70.16/28	Firewall Address and Port Information
Germany (FRA)	3.67.81.96/27 18.194.95.0/28	Firewall Address and Port Information
India (IN)	13.232.67.8/29 3.6.70.64/29	Firewall Address and Port Information
Ireland (IE)	34.253.190.192/26	Firewall Address and Port Information
Japan (JP)	18.176.203.112/29 13.231.6.232/29 57.181.58.0/28	Firewall Address and Port Information
Netherlands (NL-GCP)	34.91.82.64/27	Firewall Address and Port Information
Singapore (SG-GCP)	34.87.158.80/28	Firewall Address and Port Information
Spain (ES)	18.101.49.128/27	Firewall Address and Port Information

Data Center	IP Block	Addresses and Ports
Sweden (SE)	13.48.186.224/29 13.48.4.184/29 13.48.4.240/28	Firewall Address and Port Information
Switzerland (ACH)	51.107.1.192/28	Firewall Address and Port Information
United Arab Emirates (UAE)	3.28.159.128/28	Firewall Address and Port Information
United Kingdom (UK-AGB)	51.143.233.80/28	Firewall Address and Port Information
US East (VA)	34.202.197.0/26 44.192.245.0/26 3.234.248.0/27	Firewall Address and Port Information
US East 2 (VA2)	34.202.197.0/26 44.192.245.0/26 3.234.248.0/27	Firewall Address and Port Information
US-Iowa (IA-GCP)	34.67.130.64/27	Firewall Address and Port Information
US Ohio (OH)	3.145.235.64/26	Firewall Address and Port Information

Supported IQ Engine Software

See the [IQ Engine Release Notes](#) for information about IQ Engine version 10.8.3.



New Features in 25.4.0

A new option to request a trial subscription for Extreme Platform ONE Networking has been implemented. If your Trial expired unexpectedly, follow the new procedure to trial both ExtremeCloud IQ and Extreme Platform ONE Networking. For more information, see the [Extreme Platform ONE Networking](#) documentation web page.

Device OS Support

This release supports the following device operating systems.

Table 2: EXOS/Switch Engine Support Matrix

ExtremeCloud IQ Release 25.4.0	Version	Hardware/Model	ExtremeCloud IQ Onboard / Monitor / Config / Local Image Mgmt	Global Download Image
IQAgent Version	0.9.22/1.9.22 (0.9.22 for NOS versions <= 33.2 1.9.22 for NOS versions >= 33.2)			
	—	5120 Universal HW	✓	—
	—	5320-16P-2MXT-2X Universal HW	✓	—
Latest Supported GA Patch	32.7.2.19-patch1-32	—	✓	✓
Latest Supported GA Image	33.3 GA	X465	✓	✓
Previous Supported GA Patch	31.7.4.2 GA	—	—	✓
Previous Supported GA Image	33.3.1.12	—	✓	✓

Table 3: VOSS Fabric Engine Support Matrix

ExtremeCloud IQ Release 25.4.0	Version	Hardware Model	ExtremeCloud IQ Onboard / Monitor / Config / Local Image Mgmt	Global Download Image
IQAgent Version	9.2.25			
Latest Supported GA Patch	9.2.0	—	✓	✓
Previous Supported GA Patch	9.1.1	—	✓	✓
Previous Supported GA Image	8.10.7	—	✓	✓

IQ Engine


- IQ Engine 10.8.3

New Hardware Support

No new hardware in this release.

Table 4: New Features in 25.4.0

Feature ID	Description
NVO-6735	Implements device-level support for Fabric Engine 7x20 SKUs (7520-48YE-8CE, 7520-48XT-6C, 7520-48Y-8C, 7720-32C).
NVO-5567	Adds device-level configuration support for Fabric Engine 4k/5k SKUs including 4220, 5320-XT, 5520, and 5720 Series switches with comprehensive port and system configuration options.
NVO-4939	Delivers Extreme Platform ONE Networking Wired Networking Configuration Fabric Engine device-level functionality, providing feature parity and new configuration capabilities for VOSS/Fabric Engine devices.
NVO-4928	Completes Extreme Platform ONE Networking Wireless Configuration, maintaining all existing ExtremeCloud IQ wireless features including network policies, common objects, and PPSK management.
NVO-4917	Implements Wired Configuration L2/Static Routes, preserving all ExtremeCloud IQ switching functionality for EXOS/Switch Engine/Fabric Engine devices including network policies and common objects.



Device Support Information

[Universal Compute Platform](#) on page 15

[Access Points](#) on page 15

[Switches](#) on page 17

[Supported Browsers and Display Settings](#) on page 43

This section lists the devices that ExtremeCloud IQ supports and includes the latest version of the software that each device supports.



Note

Site-Engine managed devices that are connected to ExtremeCloud IQ are unsupported in ExtremeCloud IQ (New).

Universal Compute Platform

Device Model	Latest Supported Release	Comments
ExtremeCloud Edge	5.11.01	1130C 2130C 3150C 3160C 4120C

Access Points

Access Point information is provided in the following sections:

- [Universal Hardware](#) on page 16
- [IQ Engine \(Cloud Native\)](#) on page 17

Universal Hardware

Device Model	Latest Supported Release	Comments
AP302W	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.3.1
AP305C	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.1
AP305C-1	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.4.6
AP305CX	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.1
AP3000	IQ Engine 10.8.2 AP 10.14.1	Platform support introduced with IQ engine 10.6.1
AP3000X	IQ Engine 10.8.3	Platform support introduced with IQ Engine 10.6.1
AP4000	IQ Engine 10.8.3 AP 10.14.1	Platform support introduced with IQ Engine 10.4.1
AP4000-1	IQ Engine 10.8.3 AP 10.14.1	Platform support introduced with IQ Engine 10.4.2
AP4020	IQ Engine 10.8.2a	Platform support introduced with IQ Engine 10.8.1
AP410C	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.2
AP410C-1	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.4.6
AP460C	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.2
AP460S6C	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.2
AP460S12C	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.1.2

Device Model	Latest Supported Release	Comments
AP5010	IQ Engine 10.8.3 WiNG OS 7.9.6.1 AP 10.14.1	Platform support introduced with IQ Engine 10.5.1
AP5020	IQ Engine 10.8.3 AP 10.14.1	Platform support introduced with IQ Engine 10.7.2
AP5050U	IQ Engine 10.8.3 AP 10.14.1	Platform support introduced with IQ Engine 10.5.3
AP5050D	IQ Engine 10.8.3 AP 10.14.1	Platform support introduced with IQ Engine 10.5.3
AP510C/CX	IQ Engine 10.8.3	Platform support introduced with IQ Engine 10.0.8

IQ Engine (Cloud Native)

Device Model	Latest Supported Release	Comments
AP630	IQ Engine 10.8.3	Platform support introduced with IQ Engine 10.0.1. End of Life Information
AP650	IQ Engine 10.8.3	Platform support introduced with IQ Engine 10.0.1. End of Life Information
AP650X	IQ Engine 10.8.3	Platform support introduced with IQ Engine 10.0.1. End of Life Information
AP1130	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 8.2.1. End of Life Information
AP250	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 7.0.2.
AP230	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 8.2.1. End of Life Information
AP150W	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 8.1.1. End of Life Information
AP130	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 8.2.1. End of Life Information
AP122	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 7.0.4.
Atom AP30	IQ Engine 10.6.1a	Platform support introduced with IQ Engine 8.3.2. End of Life Information

Switches

Switch information is provided in the following sections:

- [Universal Hardware](#) on page 19

- [ExtremeXOS](#) on page 38
- [VOSS](#) on page 42

For the latest release notes for Fabric Engine and Switch Engine , see the [Extreme Networks Documentation Site](#).

Universal Hardware

Device Model	Latest Supported Release	Standalone Support	Stack Support
4120-24MW-4Y	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 200Gb stacking through two built-in QSFP28 ports Note: Can only stack with other 4120 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4120-48MW-4Y	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 200Gb stacking through two built-in QSFP28 ports Note: Can only stack with other 4120 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4120-Series-Stack	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 200Gb stacking through two built-in QSFP28 ports Note: Can only stack with other 4120 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-12P-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Monitor Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4220-12T-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Monitor Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-24P-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Monitor Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4220-24T-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-48P-4X	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4220-48T-4X	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-4MW-20P-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4220-4MW-8P-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-8MW-40P-4X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
4220-8X	Switch Engine 33.3	Switch Engine: - Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.
4220-Series-Stack	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking 40Gb stacking through two built-in SFP+ uplink ports Note: Can only stack with other 4220 devices. Cross stacking between 4120 and 4220 is not supported. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5120-24X-4Y	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking - Ability to toggle universal ports from stacking-support enabled to stacking-support disabled - Two QSFP28 uplink ports that can operate at 1x100G, 4x10G, or 4x25G Note: Can only stack with other 5120 devices. Cross stacking between 4000 and 5000 is not supported.
5120-24XT-4Y	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking - Ability to toggle universal ports from stacking-support enabled to stacking-support disabled - Two QSFP28 uplink ports that can operate at 1x100G, 4x10G, or 4x25G Note: Can only stack with other 5120 devices. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5120-44X-4Y-2C	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking - Ability to toggle universal ports from stacking-support enabled to stacking-support disabled - Two QSFP28 uplink ports that can operate at 1x100G, 4x10G, or 4x25G Note: Can only stack with other 5120 devices. Cross stacking between 4000 and 5000 is not supported.
5120-Series-Stack	Switch Engine 33.3	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Pilot license required to configure advanced features.	- Onboard - Monitor - Template- and device-level configuration - SSH Proxy* - Up to 8 unit stacking - Ability to toggle universal ports from stacking-support enabled to stacking-support disabled - Two QSFP28 uplink ports that can operate at 1x100G, 4x10G, or 4x25G Note: Can only stack with other 5120 devices. Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5320-16P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	- Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5320-16P-4XE-DC	Switch Engine 33.3 Fabric Engine 9.2.1.0	- Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5320-24T-8XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	- Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	- Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5320-24P-8XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	- Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	- Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5320-48T-8XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5320-48P-8XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-24T-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-24P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5420F-24S-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-48T-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-48P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-48P-4XL	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy

Device Model	Latest Supported Release	Standalone Support	Stack Support
5420F-8W-16P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-16W-32P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420F-16MW-32P-4XE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420M-24T-4YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5420M-24W-4YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420M-48T-4YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420M-48W-4YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5420M-16MW-32P-4YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5520-24W	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-24T	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-24T-ACDC	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-24X-ACDC	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5520-48W	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-48T	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-48T-ACDC	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-12MW-36W	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5520-48SE	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-48SE-ACDC	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	• Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5520-24X	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5720-24MW	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
5720-48MW	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5720-24MXW	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
5720-48MXW	Switch Engine 33.3 Fabric Engine 9.2.1.0	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Note: Fabric Engine only supports device-level configuration.	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
7520-48Y	Switch Engine 33.3 Fabric Engine 9.2.1.0	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI* Fabric Engine: Device-level Configuration	Switch Engine: • Monitor • Template- and device-level configuration • SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

Device Model	Latest Supported Release	Standalone Support	Stack Support
7520-48YE	Switch Engine 33.3 Fabric Engine 9.2.1.0	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
7520-48XT	Switch Engine 33.3 Fabric Engine 9.2.1.0	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.
7720-32c	Switch Engine 33.3 Fabric Engine 9.2.1.0	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy* - Supplemental CLI* Fabric Engine: Device-level Configuration	Switch Engine: - Monitor - Template- and device-level configuration - SSH Proxy Note: Cross stacking between 4000 and 5000 is not supported.

**Note**

* SSH Proxy and Supplemental CLI can be used for configuring additional parameters not currently available within template or device-level configurations.

ExtremeXOS

Device Model	Latest Supported Release	Standalone Support	Stack Support
X435-8P-2T-W	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	N/A
X435-24T-4S	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	N/A
X435-24P-4S	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	N/A
X435-8T-4S	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	N/A
X435-8P-4S	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	N/A
X440-G2-12p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*
X440-G2-12t-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*

Device Model	Latest Supported Release	Standalone Support	Stack Support
X440-G2-24p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*
X440-G2-24t-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*
X440-G2-48p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*
X440-G2-48t-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*
X450-G2-24p-GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X450-G2-24p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X450-G2-48p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor

Device Model	Latest Supported Release	Standalone Support	Stack Support
X460-G2-16mp-32p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • S	Monitor
X460-G2-24p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-24p-GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • S	Monitor
X460-G2-24p-24hp-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-24t-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-24t-GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-24t-24ht-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-24x-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor

Device Model	Latest Supported Release	Standalone Support	Stack Support
X460-G2-48p-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-48t-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-48t-GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X460-G2-48x-10GE4	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X465-24W	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X465-48W	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X465-24MU	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor

Device Model	Latest Supported Release	Standalone Support	Stack Support
X465-48P	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor
X465-24MU-24W	ExtremeXOS 33.3	• Monitor • Template- and device-level configuration • SSH Proxy* • Supplemental CLI*	Monitor

**Note**

* SSH Proxy and Supplemental CLI can be used for configuring additional parameters not currently available within template or device-level configurations.

VOSS

Device Model	Latest Supported Release	Standalone Support	Stack Support
VSP7432CQ	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported
VSP7400-48Y	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported
VSP4900-48P	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported
VSP4900-24XE	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported

Device Model	Latest Supported Release	Standalone Support	Stack Support
VSP4900-24S	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported
VSP4900-12MXU-12XE	VOSS 9.2.1.0	• Monitor • Device-level configuration • SSH Proxy* • Supplemental CLI*	Not supported

**Note**

* SSH Proxy and Supplemental CLI can be used for configuring additional parameters not currently available within template or device-level configurations.

Supported Browsers and Display Settings

Desktop and Mobile Browser Support

**Note**

ExtremeCloud IQ (New) does not support 32-bit browsers.

Table 5: Desktop Browsers

Desktop Browsers	Version Supported
Chrome	v116
Edge	v115
Firefox	v115
Internet Explorer	Not supported
Opera	v60
Safari	v13

Table 6: Mobile Browsers

Mobile Browsers	Version Supported
Android Webview	v73
Chrome for Android	v116
Edge	v79
Firefox for Android	v67
Opera for Android	v52

Table 6: Mobile Browsers (continued)

Mobile Browsers	Version Supported
Safari for iOS	v13
Samsung Internet	Not supported

Display Settings

ExtremeCloud IQ (New) supports display resolutions of 1280 x 1024 or higher.