



Avaya Fabric Orchestrator - Read Me First

Release 1.0
Issue 01.01
December 2015

NOTICE: Power cords are not included

! Important:

The Avaya Fabric Orchestrator (AFO) server does not ship with AC power cords. You can use any 100–240V IEC 60320 AC power cord with a C13 connector that meets the regulations for your geographic region and operating environment.

See support.avaya.com, and locate the AFO product notices for more information about power cords that you can purchase from Avaya for use with an AFO server.



1. On the Avaya support website, you can click **Support by Product > Documents**.
2. Enter `Fabric Orchestrator` in the product field.
3. From the **Content Type** list, click **Product Correction Notices**, and **Product Support Notices**.
4. Click **Enter**.