

## **Service Release Notes for WiNG 7.3.0.1-016R**

**Please Note:** Service releases are made available to fix specific customer reported issues in a timely manner. Service releases are not as extensively tested as main releases (such as 7.3.0.0-038R). The next maintenance or manufacturing release will incorporate all qualifying and preceding service releases.

*This document is an addendum to the release notes for the main release 7.3.0.0-038R.*

### **CONTENTS**

<b>1. Resolved Issues .....</b>	<b>1</b>
<b>2. Important Notes.....</b>	<b>1</b>
<b>3. Platforms Supported .....</b>	<b>1</b>
<b>4. Firmware Upgrade/Downgrade Procedure.....</b>	<b>1</b>

### **1. RESOLVED ISSUES**

This service release 7.3.0.1-016R is released with the XCA 4.76.01.0081.

Following is a list of SPRs/CRs fixed in this release:

CRID	Description
WING-42360	AP560 radios now operate in 2x2 when using low power mode.
WING-42346	Corrected Probe Suppression -> Force Disassociate on AP5xx.
WING-42508	Resolved Smart-RF not changing channel assignment.

### **2. IMPORTANT NOTES**

Please refer to XCA 4.76.01.0081 documentation for more information.

### **3. PLATFORMS SUPPORTED**

This release applies to all platforms released with WiNG 7.3.0.1-016R.

### **4. FIRMWARE UPGRADE/DOWNGRADE PROCEDURE**

The method described in this section uses the Command Line Interface (CLI) procedures. To log into the CLI, either SSH, Telnet or serial access can be used.

**For detailed upgrade procedure – please refer to WiNG 7.3.0 release notes.**

*Upgrade from WiNG v7x.x.x to WiNG v7.3.0.1*

1. Copy the controller image to your tftp/ftp server.
2. Use the **—upgrade ftp://<username>:<password>@<ip address of server>/<name of file>||**, or **—upgrade tftp://<ip address of server>/<name of file>** command from CLI or **Switch->Firmware->Update Firmware** option from the GUI. You may need to specify the username and password for your ftp server.
3. Restart the controller. From CLI the command is **—reload**.