

53-1003824-01  
18 August 2015

# Brocade NetIron

---

## Command Reference

Supporting Multi-Service Ironware Release 5.9.00

**BROCADE** 

**© 2015, Brocade Communications Systems, Inc. All Rights Reserved.**

ADX, Brocade, Brocade Assurance, the B-wing symbol, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, The Effortless Network, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision and vADX are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

# Contents

---

<b>Preface.....</b>	<b>15</b>
Document conventions.....	15
Text formatting conventions.....	15
Command syntax conventions.....	15
Notes, cautions, and warnings.....	16
Brocade resources.....	17
Contacting Brocade Technical Support.....	17
Document feedback.....	18
<b>About This Document.....</b>	<b>19</b>
What's new in this document.....	19
Supported hardware and software.....	21
<b>Using the NetIron Command-Line Interface.....</b>	<b>23</b>
Logging on through the CLI.....	23
On-line help.....	23
Command completion.....	24
Scroll control.....	24
Line editing commands.....	24
Command configuration modes.....	25
Configuration modes.....	26
Accessing the CLI .....	27
Single user in global configuration mode.....	28
Multi-user conflict during deletion of group configuration (or stanza).....	29
Navigating among command levels.....	29
CLI command structure.....	30
Required or optional fields.....	30
Optional fields.....	30
List of available options.....	30
Searching and filtering output.....	31
Searching and filtering output from show commands.....	31
Searching and filtering output at the --More-- prompt.....	32
Using special characters in regular expressions.....	33
Allowable characters for LAG names .....	35
CLI parsing enhancement.....	36
Syntax shortcuts.....	36
Saving configuration changes.....	36
Modifying startup and running configuration file manually.....	36
<b>Commands A - E.....</b>	<b>39</b>
access-list.....	39
access-list sequence.....	42
activate.....	45
adjustment-threshold .....	46
advertise backup.....	47
advertise-fec.....	48

area authentication	49
area nssa (OSPFv3)	51
area range (OSPFv2)	53
area range (OSPFv3)	54
area stub	55
area virtual-link (OSPFv3)	56
area virtual-link authentication (OSPFv3)	58
arp	60
arp-guard	62
arp-guard-access-list	63
arp-guard-syslog-timer	64
authentication	65
auto-bandwidth	66
autobw-threshold-table	67
auto-cost reference-bandwidth (OSPFv2)	68
auto-cost reference-bandwidth (OSPFv3)	69
auto-enroll	71
backup	72
backup-bw-best-effort	73
backup-hello-interval	74
bandwidth	75
bandwidth-ceiling	76
bandwidth-ceiling max threshold percentage	77
base vrf	78
bfd	79
bfd all-interfaces	81
bfd holdover-interval	83
bfd interval	85
bfd-enable	86
bfd mh-session-setup-delay	87
bfd sh-session-setup-delay	88
cam ifsr	89
cam-mode amod	90
clear access-list receive accounting	91
clear arp-guard-statistics	92
clear bm histogram	94
clear cpu histogram sequence	95
clear dot1x-mka statistics	96
clear ikev2 statistics	97
clear ikev2 sa	98
clear ip vrrp statistics	99
clear ip vrrp-extended statistics	100
clear ipsec error-count	101
clear ipsec sa	102
clear ipsec statistics	103
clear ipsec statistics tunnel	104
clear ipv6 vrrp statistics	105
clear ipv6 vrrp-extended statistics	106
clear macsec statistics	107
clear memory histogram	108
clear metro mp-ulp-queue	109
clear mpls auto-bandwidth-samples	110
clear mpls rsvp statistics session	111
clear mpls statistics	112
clear openflow	115
clear pki counters	116
clear pki crl	117
clear rate-limit counters bum-drop	118

clear rate-limit counters ip-option-pkt-to-cpu.....	119
clear rate-limit counters ipv6-hoplimit-expired-to-cpu.....	120
clear rate-limit counters ip-ttl-expired-to-cpu.....	121
clear statistics openflow .....	122
cluster-client-static-mac-move.....	123
copy.....	124
copy-received-cos.....	126
common-name.....	127
country-name.....	128
crl-query.....	129
crl-update-time.....	130
cspf-computation-mode.....	131
cspf-computation-mode (LSP level).....	132
database-overflow-interval (OSPFv3).....	133
dead-interval .....	134
default-link-metric.....	136
default-metric (OSPF).....	138
default-passive-interface .....	139
delete-certificate.....	140
disable authenticate md5.....	141
distance (OSPF).....	142
display-pkt-bit-rate.....	143
dot1ag-transparent.....	144
dot1x-key.....	145
dot1x-mka-enable.....	146
eckeypair.....	147
egress-truncate.....	148
egress-truncate-size.....	149
email.....	150
enable-mka.....	151
encryption.....	152
enrollment.....	153
esn-enable.....	154
exclude-interface.....	155
external-lsdb-limit (OSPFv3).....	156
ext-stats-mode slot.....	157

**Commands F - J..... 159**

fingerprint.....	159
fqdn.....	160
garp-ra-interval.....	161
gig-default.....	162
graceful-restart (OSPFv2).....	163
graceful-restart helper (OSPFv3).....	164
group-master interface.....	165
hello-interval (VRRP) .....	166
ike-profile.....	168
ikev2 auth-proposal.....	169
ikev2 cookie-challenge.....	170
ikev2 dhgroup.....	171
ikev2 exchange-max-time.....	172
ikev2 http-url-cert.....	173
ikev2 limit.....	174
ikev2 policy.....	175
ikev2 profile.....	176
ikev2 proposal.....	178
ikev2 retransmit-interval.....	179

ikev2 retry-count.....	180
ike-profile.....	181
ingress-tunnel-accounting.....	182
In-label .....	183
integrity.....	184
ip.....	185
ip allow-src-multicast.....	186
ip allow-src-multicast switched-traffic.....	187
ip arp-refresh-request-timer.....	188
ip http client connection timeout connect.....	189
ip http client connection timeout idle.....	190
ip http client source-interface.....	191
ip multicast-routing load-sharing .....	192
ip ospf bfd .....	193
ip rate-limit option-pkt-to-cpu policy-map.....	194
ip rate-limit ttl-expired-to-cpu policy-map.....	195
ip receive access-list .....	196
ip route bfd .....	198
ip route static-bfd .....	199
ip ssh encryption disable-aes-cbc.....	200
ip tcp adjust-mss.....	201
ip tcp redirect-gre-tcp-syn.....	203
ip vrrp auth-type.....	205
ip vrrp vrid.....	206
ip vrrp-extended auth-type.....	207
ip vrrp-extended vrid.....	209
ip-address.....	210
ipsec profile.....	211
ipsec proposal.....	212
ipv6 dhcp-relay include-options.....	213
ipv6 multicast-routing load-sharing rebalance .....	214
ipv6 nd proxy.....	215
ipv6 nd ra-dns-server .....	216
ipv6 nd ra-domain-name .....	217
ipv6 ospf active .....	218
ipv6 ospf area .....	219
ipv6 ospf authentication ipsec .....	220
ipv6 ospf authentication ipsec disable .....	221
ipv6 ospf authentication ipsec spi.....	222
ipv6 ospf bfd .....	224
ipv6 ospf cost .....	225
ipv6 ospf dead-interval .....	226
ipv6 ospf hello-interval .....	227
ipv6 ospf hello-jitter .....	228
ipv6 ospf instance .....	229
ipv6 ospf mtu-ignore .....	230
ipv6 ospf network .....	231
ipv6 ospf passive .....	232
ipv6 ospf priority .....	233
ipv6 ospf retransmit-interval .....	234
ipv6 ospf suppress-linklsa .....	235
ipv6 ospf transmit-delay .....	236
ipv6 rate-limit hoplimit-expired-to-cpu.....	237
ipv6 receive access-list .....	238
ipv6 receive deactivate-acl-all .....	240
ipv6 receive delete-acl-all .....	241
ipv6 receive rebind-acl-all .....	242
ipv6 route.....	243

ipv6 route bfd .....	245
ipv6 router ospf .....	247
ipv6 route static bfd .....	248
ipv6 router vrrp .....	249
ipv6 router vrrp-extended .....	250
ipv6 vrrp vrid.....	251
ipv6 vrrp-extended vrid.....	252
ipv6-address.....	253
isis bfd .....	255
isis reverse-metric.....	256
jitc enable.....	259

**Commands K - Sh..... 261**

key-add-remove-interval.....	261
key-rollover-interval.....	262
key-server-priority.....	263
I2 policy route-map.....	264
label-range static.....	265
label-withdrawal-delay .....	266
link-protection .....	267
local-as .....	268
load-balance mask ip.....	269
load-balance mask ipv6.....	270
local-certificate.....	271
location.....	272
log (OSPFv2).....	273
logging enable.....	275
log-status-change .....	277
logs-per-interval-per-mep-rmep.....	278
lsr-id .....	279
mac-age-time.....	280
mac-move-det-syslog.....	281
macsec cipher-suite.....	283
macsec confidentiality-offset.....	284
macsec frame-validation.....	285
macsec replay-protection.....	286
match identity.....	287
match I2acl.....	288
method.....	289
metric-type .....	290
mka-auth-fail-action.....	291
mka-cfg-group .....	292
neighbor bfd .....	293
neighbor fail-over .....	295
neighbor next-hop-self (BGP).....	296
non-preempt-mode .....	297
ocsp-url.....	298
openflow controller source-interface.....	299
openflow enable .....	300
openflow hello-reply disable.....	301
org-name.....	302
org-unit-name.....	303
owner.....	304
permit (arp-guard-access-list).....	305
pim neighbor-filter .....	306
ping mpls ldp .....	307
pki authenticate.....	309

pki cert validate.....	310
pki enroll.....	311
pki entity.....	312
pki export.....	313
pki export crl.....	314
pki export key.....	315
pki import.....	316
pki import key ec.....	317
pki profile-enrollment.....	318
pki trustpoint.....	320
pki-entity.....	321
pre-shared-key.....	322
prf.....	323
protected.....	324
rate-limit input.....	325
rd.....	326
remove-tagged-ports / remove-untagged-ports.....	327
remove-vlan.....	328
reverse-metric.....	329
revocation-check.....	332
rfc1583-compatibility (OSPF).....	333
router-interface.....	334
router vrrp .....	335
router vrrp-extended .....	336
rpf shortcut .....	337
rsvp-hello .....	338
rsvp-hello acknowledgments .....	340
rsvp-hello disable .....	341
sample-recording.....	344
scale-timer .....	345
sflow null0-sampling .....	346
shortcuts isis.....	347
short-path-forwarding .....	349

## **Show Commands.....351**

show access-list accounting.....	351
show access-list bindings .....	354
show access-list receive accounting .....	355
show arp.....	356
show arp-guard-access-list.....	358
show arp-guard port-bindings.....	359
show arp-guard statistics ethernet.....	360
show bfd.....	362
show bfd applications.....	364
show bfd mpls .....	365
show bfd neighbors.....	366
show bfd neighbors bgp.....	367
show bfd neighbors details.....	371
show bfd neighbors interface.....	374
show bfd neighbors isis.....	375
show bfd neighbors ospf.....	376
show bfd neighbors ospf6.....	377
show bfd neighbors static.....	378
show bfd neighbors static6.....	379
show bip slot.....	380
show cam-detail-eth.....	381
show cam-detail-ip.....	384



show cam ifl .....	386
show cam ipvpn .....	387
show cam uda.....	389
show configuration .....	390
show cpu histogram .....	391
show cpu histogram sequence .....	394
show dot1x-mka group.....	395
show dot1x-mka config.....	397
show dot1x-mka sessions brief.....	399
show dot1x-mka sessions ethernet.....	400
show dot1x-mka statistics.....	404
show egress-truncate.....	405
show ikev2 policy.....	406
show ikev2 profile.....	407
show ikev2 proposal.....	408
show ikev2 sa.....	409
show ikev2 session.....	410
show ikev2 statistics.....	411
show interface ethernet.....	412
show interfaces tunnel.....	413
show ip allow-src-multicast.....	415
show ip bgp neighbors .....	416
show ip bgp summary .....	418
show ip http client.....	421
show ip interface.....	423
show ip ospf.....	427
show ip route.....	428
show ip static-arp.....	430
show ip vrrp.....	431
show ip vrrp-extended.....	433
show ipsec egress-config.....	437
show ipsec egress-spi-table.....	438
show ipsec error-count.....	439
show ipsec ingress-config.....	440
show ipsec ingress-spi-table.....	441
show ipsec policy.....	442
show ipsec profile.....	443
show ipsec proposal.....	444
show ipsec sa.....	445
show ipsec statistics.....	447
show ip-tunnels.....	449
show ipv6 access-list bindings .....	450
show ipv6 access-list receive accounting .....	451
show ipv6 bgp neighbors.....	452
show ipv6 bgp summary.....	453
show ipv6 dhcp-relay interface.....	456
show ipv6 dhcp-relay options.....	457
show ipv6 interface tunnel.....	458
show ipv6 ospf interface .....	460
show ipv6 vrrp.....	465
show ipv6 vrrp-extended.....	469
show isis.....	472
show isis shortcut.....	476
show macsec ethernet.....	478
show macsec statistics ethernet.....	479
show memory histogram .....	482
show metro mp-ulp-queue.....	483
show mmp.....	485

show mmp attributes.....	486
show mmp config.....	487
show mmp statistics.....	488
show mpls autobw-threshold-table .....	489
show mpls bypass-lsp.....	490
show mpls config.....	493
show mpls forwarding.....	495
show mpls interface.....	497
show mpls label-range.....	499
show mpls ldp.....	501
show mpls ldp database.....	502
show mpls ldp fec.....	504
show mpls ldp interface.....	508
show mpls ldp neighbor.....	509
show mpls ldp path.....	511
show mpls ldp peer.....	512
show mpls ldp session .....	514
show mpls ldp statistics.....	516
show mpls ldp tunnel .....	518
show mpls lsp.....	520
show mpls lsp_p2mp_xc .....	528
show mpls path.....	529
show mpls policy .....	531
show mpls route .....	534
show mpls rsvp interface.....	536
show mpls rsvp neighbor .....	538
show mpls rsvp session.....	540
show mpls rsvp session backup.....	545
show mpls rsvp session brief.....	547
show mpls rsvp session bypass.....	549
show mpls rsvp session destination.....	551
show mpls rsvp session detail.....	553
show mpls rsvp session detour.....	555
show mpls rsvp session down.....	557
show mpls rsvp session extensive.....	559
show mpls rsvp session (ingress/egress).....	562
show mpls rsvp session (interface).....	563
show mpls rsvp session name.....	564
show mpls rsvp session p2mp.....	568
show mpls rsvp session p2p.....	571
show mpls rsvp session ppend.....	572
show mpls rsvp session transit.....	573
show mpls rsvp session up.....	575
show mpls rsvp session wide.....	577
show mpls rsvp statistics .....	579
show mpls static-lsp.....	581
show mpls statistics 6pe.....	584
show mpls statistics bypass-lsp.....	585
show mpls statistics label.....	586
show mpls statistics ldp transit.....	588
show mpls statistics ldp tunnel .....	589
show mpls statistics lsp.....	590
show mpls statistics oam.....	591
show mpls statistics vll.....	592
show mpls statistics vll-local.....	593
show mpls statistics vpls.....	595
show mpls statistics vrf.....	597
show mpls summary.....	598

show mpls ted database.....	599
show mpls ted path.....	600
show mpls vl.....	603
show mpls vl-local.....	607
show mpls vpls.....	609
show mstp .....	615
show mvrp.....	616
show mvrp attributes.....	617
show mvrp config.....	618
show mvrp statistics.....	619
show nht-table ipsec-based.....	620
show openflow.....	621
show openflow controller.....	623
show openflow flows.....	624
show openflow groups.....	626
show openflow interface.....	627
show openflow meters.....	628
show openflow queues.....	630
show pim interface .....	632
show pim multicast-filter.....	633
show pki certificates.....	634
show pki counters.....	636
show pki crls.....	637
show pki enrollment-profile.....	638
show pki entity.....	639
show pki key mypubkey.....	640
show pki trustpoint.....	641
show rate-limit counters bum-drop.....	643
show rate-limit detail.....	645
show rate-limit interface.....	646
show rate-limit ipv6 hoplimit-expired-to-cpu.....	647
show rate-limit option-pkt-to-cpu.....	648
show rate-limit ttl-expired-to-cpu.....	649
show rmon alarm.....	650
show rmon statistics.....	651
show route-map.....	654
show rstp .....	655
show running-config.....	657
show sflow statistics .....	659
show spanning-tree .....	660
show statistics .....	661
show sysmon config .....	665
show sysmon results brief.....	666
show sysmon results detail.....	668
show sysmon schedule.....	670
show telemetry.....	672
show terminal.....	673
show tm-voq-stat queue-drops.....	674
show vlan.....	675
show vlan tvf-lag-lb .....	677

**Commands Si - Z.....679**

slow-start.....	679
snmp-server community.....	680
snmp-server context .....	682
snmp-server enable mib.....	683
snmp-server enable traps.....	684

snmp-server enable traps bum-ri-traps.....	685
snmp-server host.....	686
snmp-server mib community-map.....	688
spanning-tree pvst-protect.....	689
state-name.....	691
static-lsp.....	692
static-mac-address.....	693
statistics-load-interval.....	694
subject-alt-name.....	695
summary-address (OSPFv3).....	696
suppress-acl-seq.....	697
sysmon fe link auto-tune.....	698
sysmon lp-high-cpu enable.....	699
sysmon lp-high-cpu threshold.....	700
sysmon np memory-errors.....	701
sysmon port port-crc-test.....	703
sysmon sfm walk auto.....	705
sysmon sfm walk polling-period.....	706
sysmon sfm walk redundancy-check.....	707
sysmon sfm walk start.....	708
sysmon sfm walk status.....	709
sysmon sfm walk stop.....	710
sysmon sfm walk threshold.....	711
sysmon tm link auto-tune.....	712
system np control-ram-threshold.....	713
system np lpm-ram-threshold.....	715
system-init.....	717
system-max ecmp-pram-block-size.....	719
system-max ip-arp.....	720
system-max ipv6-receive-cam.....	721
system-max ipv6-vrf-route.....	722
system-max ip-vrf-route.....	723
system-max rstp.....	724
system-max trunk-num.....	725
system-max tvf-lag-lb-fid-group.....	726
system-max tvf-lag-lb-fid-pool.....	727
te-metric.....	728
terminal enable timestamp.....	729
timers (OSPFv3).....	731
traceroute.....	732
traceroute mpls ldp.....	734
track-port.....	736
transparent-hw-flooding lag-load-balancing.....	737
tunnel destination.....	738
tunnel mode ipsec ipv4.....	739
tunnel mode ipsec ipv6.....	740
tunnel override-pkt-tos-ttl.....	741
tunnel protection ipsec profile.....	742
tunnel source.....	743
tunnel-interface.....	744
uda access-group.....	746
uda-offsets.....	748
underflow-limit.....	749
update-lag-name.....	750
use-v2-checksum.....	751
use-vrrp-path.....	752
version.....	753
virtual-mac.....	754

vll.....	755
vll-peer.....	756
vrf forwarding.....	758
write memory.....	759



# Preface

---

- Document conventions..... 15
- Brocade resources..... 17
- Contacting Brocade Technical Support..... 17
- Document feedback..... 18

## Document conventions

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Brocade technical documentation.

### Text formatting conventions

Text formatting conventions such as boldface, italic, or Courier font may be used in the flow of the text to highlight specific words or phrases.

Format	Description
<b>bold text</b>	Identifies command names Identifies keywords and operands Identifies the names of user-manipulated GUI elements Identifies text to enter at the GUI
<i>italic text</i>	Identifies emphasis Identifies variables Identifies document titles
Courier font	Identifies CLI output Identifies command syntax examples

### Command syntax conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
<b>bold text</b>	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example, <b>--show</b> WWN.

Convention	Description
[ ]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x   y   z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options. In Fibre Channel products, square brackets may be used instead for this purpose.
x   y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	Indicates a “soft” line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

## Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

---

### NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

---

---

### ATTENTION

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.

---



### CAUTION

**A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.**

---



### DANGER

**A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.**

---



## Brocade resources

Visit the Brocade website to locate related documentation for your product and additional Brocade resources.

You can download additional publications supporting your product at [www.brocade.com](http://www.brocade.com). Select the Brocade Products tab to locate your product, then click the Brocade product name or image to open the individual product page. The user manuals are available in the resources module at the bottom of the page under the Documentation category.

To get up-to-the-minute information on Brocade products and resources, go to [MyBrocade](#). You can register at no cost to obtain a user ID and password.

Release notes are available on [MyBrocade](#) under Product Downloads.

White papers, online demonstrations, and data sheets are available through the [Brocade website](#).

## Contacting Brocade Technical Support

As a Brocade customer, you can contact Brocade Technical Support 24x7 online, by telephone, or by e-mail. Brocade OEM customers contact their OEM/Solutions provider.

### Brocade customers

For product support information and the latest information on contacting the Technical Assistance Center, go to <http://www.brocade.com/services-support/index.html>.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7.

Online	Telephone	E-mail
<p>Preferred method of contact for non-urgent issues:</p> <ul style="list-style-type: none"> <li>• <a href="#">My Cases</a> through MyBrocade</li> <li>• <a href="#">Software downloads</a> and licensing tools</li> <li>• <a href="#">Knowledge Base</a></li> </ul>	<p>Required for Sev 1-Critical and Sev 2-High issues:</p> <ul style="list-style-type: none"> <li>• Continental US: 1-800-752-8061</li> <li>• Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33)</li> <li>• For areas unable to access toll free number: +1-408-333-6061</li> <li>• <a href="#">Toll-free numbers</a> are available in many countries.</li> </ul>	<p><a href="mailto:support@brocade.com">support@brocade.com</a></p> <p>Please include:</p> <ul style="list-style-type: none"> <li>• Problem summary</li> <li>• Serial number</li> <li>• Installation details</li> <li>• Environment description</li> </ul>

### Brocade OEM customers

If you have purchased Brocade product support from a Brocade OEM/Solution Provider, contact your OEM/Solution Provider for all of your product support needs.

- OEM/Solution Providers are trained and certified by Brocade to support Brocade® products.
- Brocade provides backline support for issues that cannot be resolved by the OEM/Solution Provider.

- Brocade Supplemental Support augments your existing OEM support contract, providing direct access to Brocade expertise. For more information, contact Brocade or your OEM.
- For questions regarding service levels and response times, contact your OEM/Solution Provider.

## Document feedback

To send feedback and report errors in the documentation you can use the feedback form posted with the document or you can e-mail the documentation team.

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. You can provide feedback in two ways:

- Through the online feedback form in the HTML documents posted on [www.brocade.com](http://www.brocade.com).
- By sending your feedback to [documentation@brocade.com](mailto:documentation@brocade.com).

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

# About This Document

---

- [What's new in this document](#).....19
- [Supported hardware and software](#).....21

## What's new in this document

This document is the first release of the NetIron Command Reference.

In this initial release of the NetIron command reference, not all commands supported on the NetIron devices are represented. All new commands supported in the NetIron Release 05.6.00 are included.

For new commands introduced since Release 5.6.00, the history table is shown. For legacy commands the history table is not shown unless an update has been added in recent releases.

The following are lists of the new, modified, and deprecated commands in Release 05.9.00:

### New commands

The following commands have been added (new for this release).

- **auto-enroll**
- **clear mpls rsvp statistics session**
- **clear pki counters**
- **clear pki crl**
- **cluster-client-static-mac-move**
- **crl-query**
- **crl-update-time**
- **egress-truncate**
- **egress-truncate-size**
- **enrollment**
- **ext-stats-mode slot**
- **ip allow-src-multicast**
- **ip allow-src-multicast switched-traffic**
- **ipv6 dhcp-relay include-options**
- **ipv6 nd proxy**
- **ipv6 nd local-proxy**
- **ip http client connection timeout connect**
- **ip http client connection timeout idle**
- **ip http client source-interface**
- **load-balance mask ip**
- **load-balance mask ipv6**
- **local-certificate**
- **ocsp-url**
- **pki enroll**
- **pki export**
- **pki export crl**

- **pki export key**
- **revocation-check**
- **show cam-detail-eth**
- **show cam-detail-ip**
- **show cam uda**
- **show egress-truncate**
- **show ip-tunnels**
- **show ipv6 interface tunnels**
- **show load-balance mask-options**
- **show ip allow-src-multicast**
- **show ip http-client**
- **show pki counters**
- **show pki crls**
- **show pki enrollment-profile**
- **show route-map**
- **show telemetry**
- **show vlan tvf-lag-lb**
- **snmp-server context**
- **snmp-server enable mib**
- **snmp-server mib community-map**
- **sysmon lp-high-cpu enable**
- **sysmon lp-high-cpu threshold**
- **system-max rstp**
- **system-max trunk-num**
- **system-max tvf-lag-lb-fid-pool**
- **tunnel mode ipsec ipv6**
- **terminal enable timestamp**
- **tunnel destination**
- **tunnel source**
- **tunnel-interface**
- **uda access-group**
- **uda-offsets**
- **update-lag-name**

## Modified commands

The following commands have been modified in this release.

- **access-list**
- **access-list accounting**
- **access-list sequence**
- **copy**
- **clear ikev2 sa**
- **clear ipsec sa**
- **clear mpls rsvp statistics**
- **ipv6-address**
- **ipv6 route**
- **logging enable**
- **rate-limit input**
- **show access-list count**
- **show ikev2 sa**

- **show interface ethernet**
- **show interfaces tunnel**
- **show ipsec egress-spi-table**
- **show ipsec ingress-spi-table**
- **show ipsec sa**
- **show ipv6 dhcp-relay interface**
- **show ipv6 dhcp-relay options**
- **show ipv6 vrrp**
- **show mpls bypass-lsp**
- **show mpls config**
- **show mpls ldp tunnel**
- **show mpls lsp**
- **show mpls summary**
- **show terminal**
- **snmp-server host**
- **traceroute**
- **tunnel protection ipsec profile**

## Deprecated commands

There are no deprecated commands in this release.

## Supported hardware and software

The following hardware platforms are supported by this release of this guide:

**TABLE 1** Supported devices

<b>Brocade NetIron XMR Series</b>	<b>Brocade NetIron MLX Series</b>	<b>NetIron CES 2000 and NetIron CER 2000 Series</b>
Brocade NetIron XMR 4000	Brocade MLX-4	Brocade NetIron CES 2024C
Brocade NetIron XMR 8000	Brocade MLX-8	Brocade NetIron CES 2024F
Brocade NetIron XMR 16000	Brocade MLX-16	Brocade NetIron CES 2048C
Brocade NetIron XMR 32000	Brocade MLX-32	Brocade NetIron CES 2048CX
	Brocade MLXe-4	Brocade NetIron CES 2048F
	Brocade MLXe-8	Brocade NetIron CES 2048FX
	Brocade MLXe-16	Brocade NetIron CER 2024C
	Brocade MLXe-32	Brocade NetIron CER-RT 2024C
		Brocade NetIron CER 2024F
		Brocade NetIron CER-RT 2024F
		Brocade NetIron CER 2048C
		Brocade NetIron CER-RT 2048C
		Brocade NetIron CER 2048CX
		Brocade NetIron CER-RT 2048CX
		Brocade NetIron CER 2048F
		Brocade NetIron CER-RT 2048F
		Brocade NetIron CER 2048FX
		Brocade NetIron CER-RT 2048FX

# Using the NetIron Command-Line Interface

---

- Logging on through the CLI.....23
- Command configuration modes..... 25
- CLI command structure..... 30
- Searching and filtering output..... 31
- Allowable characters for LAG names ..... 35
- CLI parsing enhancement..... 36
- Syntax shortcuts.....36
- Saving configuration changes..... 36

## Logging on through the CLI

After an IP address is assigned to the Brocade device's management port, you can access the CLI through a PC or terminal attached to the management module's serial (Console) port or 10BaseT/100BaseTX Ethernet (management) port, or from a Telnet or SSH connection to the PC or terminal.

You can initiate a local Telnet, SSH or SNMP connection by specifying the management port's IP address.

The commands in the CLI are organized into the following modes:

- **User EXEC mode** - Lets you display information and perform basic tasks such as pings and traceroutes.
- **Privileged EXEC mode** - Lets you use the same commands as those at the User EXEC level plus configuration commands that do not require saving the changes to the system-config file.
- **Global configuration mode** - Lets you make configuration changes to the device. To save the changes across software reloads and system resets, you need to save them to the system-config file. The global configuration mode contains sub-configuration modes for individual ports, for VLANs, for routing protocols, and other configuration areas.

---

### NOTE

By default, the Brocade devices have all management access disabled, except for console port management. To create access, you must configure Enable passwords or local user accounts, or you can configure the device to use a RADIUS or TACACS or TACACS+ server for authentication.

---

## On-line help

To display a list of available commands or command options, enter "?" or press Tab. If you have not entered part of a command at the command prompt, all the commands supported at the current CLI level are listed. If you enter part of a command, then enter "?" or press Tab, the CLI lists the options you can enter at this point in the command string.

If you enter an invalid command, a message appears indicating the command was unrecognized.

```
device(config)# router ip
Unrecognized command
```

## Command completion

The CLI supports command completion, so you do not need to enter the entire name of a command or option. As long as you enter enough characters of the command or option name to avoid ambiguity with other commands or options, the CLI understands what you are typing.

## Scroll control

By default, the CLI uses a page mode to paginate displays that are longer than the number of rows in your terminal emulation window. For example, if you display a list of all the commands at the global CONFIG level but your terminal emulation window does not have enough rows to display them all at once, the page mode stops the display and lists your choices for continuing the display.

```
aaa
access-list
all-client
arp
banner
base-mac-addr
boot
some lines omitted for brevity...
  default-vlan-id
  enable
  enable-acl-counter
  end
  exit
--More--, next page: Space, next line: Return key, quit: Control-c
```

The software provides the following scrolling options:

- Press the Space bar to display the next page (one screen at a time).
- Press the Return or Enter key to display the next line (one line at a time).
- Press Ctrl-C cancel the display.

## Line editing commands

The CLI supports the following line editing commands. To enter a line-editing command, use the CTRL+key combination for the command by pressing and holding the CTRL key, then pressing the letter associated with the command.

**TABLE 2** CLI line editing commands

Ctrl+Key combination	Description
Ctrl+A	Moves to the first character on the command line.
Ctrl+B	Moves the cursor back one character.
Ctrl+C	Escapes and terminates command prompts and ongoing tasks (such as lengthy displays), and displays a fresh command prompt.
Ctrl+D	Deletes the character at the cursor.
Ctrl+E	Moves to the end of the current command line.
Ctrl+F	Moves the cursor forward one character.



**TABLE 2** CLI line editing commands (Continued)

Ctrl+Key combination	Description
Ctrl+K	Deletes all characters from the cursor to the end of the command line.
Ctrl+L; Ctrl+R	Repeats the current command line on a new line.
Ctrl+N	Enters the next command line in the history buffer.
Ctrl+P	Enters the previous command line in the history buffer.
Ctrl+U; Ctrl+X	Deletes all characters from the cursor to the beginning of the command line.
Ctrl+W	Deletes the last word you typed.
Ctrl+Z	Moves from any CONFIG level of the CLI to the Privileged EXEC level; at the Privileged EXEC level, moves to the User EXEC level.

## Command configuration modes

The Brocade CLI uses an industry-standard hierarchical shell familiar to Ethernet/IP networking administrators. You can use one of three major command modes to enter commands and access sub-configuration modes on the device.

### User EXEC mode

User EXEC mode is the default mode for the device; it supports the lowest level of user permissions. In this mode, you can execute basic commands such as **ping** and **traceroute**, but only a subset of clear, show, and debug commands can be entered in this mode. The following example shows the User EXEC prompt after login. The **enable** command enters privileged EXEC mode.

```
device> enable
device#
```

### Privileged EXEC mode

Privileged EXEC mode supports all clear, show, and debug commands. In addition, you can enter some configuration commands that do not make changes to the system configuration. The following example shows the privileged EXEC prompt. At this prompt, you issue the **configure terminal** command to enter global configuration mode.

```
device# configure terminal
device(config)#
```

### Global configuration mode

Global configuration mode supports commands that can change the device configuration. For any changes to be persistent, you must save the system configuration before rebooting the device. The global configuration mode provides access to sub-configuration modes for individual interfaces, VLANs,

routing protocols, and other configuration areas. The following example shows how you access the interface sub-configuration mode by issuing the **interface** command with a specified interface.

```
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)#
```

## Configuration modes

Configuration command-line interface (CLI) commands are entered in various modes to configure a Brocade device. The initial configuration mode is named global configuration mode and all other configuration modes are accessed through this mode.

The following table displays a list of the most commonly-used sub-configuration modes, but this list is not exhaustive and new sub-configuration modes can be introduced with new features. Refer to the command pages for details of the configuration modes applicable to the CLI command and examples of how to access the required mode.

**TABLE 3** Sub-configuration modes

Configuration mode	Description
802.1X port security	The 802.1X port security mode allows you to configure the 802.1X port security. You access this mode by entering the <b>dot1x-enable</b> command from global configuration mode.
BGP	The BGP mode allows you to configure Border Gateway Protocol version 4 (BGP4) features. You access this mode by entering the <b>router bgp</b> command from global configuration mode.
BGP4 unicast address family	The BGP4 unicast address family mode allows you to configure a BGP4 unicast route. You access this mode by entering the <b>address-family ipv4 unicast</b> command from BGP configuration mode.
BGP4 multicast address family	The BGP4 multicast address family mode allows you to configure BGP4 multicast routes. You access this mode by entering the <b>address-family ipv4 multicast</b> command from BGP configuration mode, BGP unicast address configuration mode, or IPv6 BGP unicast configuration mode.
Ethernet service instance	Ethernet Service Instance (ESI) mode allows you to assign an ESI to a protocol, or port.
Interface	The interface mode allows you to assign or modify specific port parameters on a specific port. You access this mode by entering the <b>interface</b> command followed by an appropriate keyword and variables from global configuration mode. Available keywords are: <b>ethernet</b> , <b>loopback</b> , <b>management</b> , <b>ve</b> , <b>tunnel</b> , or <b>group-ve</b> .
LAG	The LAG mode allows you to change parameters for statically-configured LAG groups. You access this mode by entering the <b>lag</b> command with appropriate port parameters from global configuration mode.
MAC port security	The MAC port security mode allows you to configure the port security feature. You reach this level by entering the <b>port security</b> command at the global or interface configuration mode.
Metro ring	The Metro ring mode allows you to configure Layer 2 connectivity and fast failover in ring topologies. You access this mode by entering the <b>metro-ring</b> command with a <i>ring-id</i> variable from VLAN configuration mode..

**TABLE 3** Sub-configuration modes (Continued)

Configuration mode	Description
OSPF	The OSPF mode allows you to configure parameters for the OSPF routing protocol. You access this mode by entering the <b>router ospf</b> command from global configuration mode.
PIM	The PIM mode allows you to configure parameters for the Protocol Independent Multicast (PIM) routing protocol. You access this mode by entering the <b>router pim</b> command from global configuration mode.
Redundancy	The redundancy mode allows you to configure redundancy parameters for redundant management modules. You access this mode by entering the <b>redundancy</b> command from global configuration mode.
RIP	The RIP mode allows you to configure parameters for the RIP routing protocol. You access this mode by entering the <b>router rip</b> command from global configuration mode.
Route map	The route map mode allows you to configure parameters for a BGP4 route map. You access this mode by entering the <b>route-map</b> command with a <i>name</i> variable from global configuration mode.
Topology group	The topology group mode allows you to control the Layer 2 protocol configuration and Layer 2 state of a set of ports in multiple VLANs based on the configuration and states of those ports in a single master VLAN. One instance of the Layer 2 protocol controls all the VLANs. You access this mode by entering the <b>topology-group</b> command with a <i>group-id</i> variable from global configuration mode.
VLAN	Policy-based virtual Local Area Networks (VLANs) mode allow you to assign VLANs to a protocol, port, or 802.1q tags. You access this mode by entering the <b>vlan</b> command with a <i>vlan-id</i> variable from global configuration mode.
VSRP	The VSRP mode allows you to configure parameters for the Virtual Switch Redundancy Protocol (VSRP). You access this mode by entering the <b>vsrp vrid</b> command with a <i>num</i> variable from VLAN configuration mode.
VRRP	The VRRP mode allows you to configure parameters for the Virtual Router Redundancy Protocol (VRRP). You access this mode by entering the <b>router vrrp</b> command from global configuration mode and then entering the <b>ip vrrp vrid</b> command from interface configuration mode.
VRRP-E	The VRRP-E mode allows you to configure parameters for the VRRP Extended (VRRP-E) protocol. You access this mode by entering the <b>router vrrp-extended</b> command from global configuration mode and then entering the <b>ip vrrp-extended vrid</b> command from interface configuration mode.

## Accessing the CLI

The CLI can be accessed through both serial and Telnet connections. For initial log on, you must use a serial connection. Once an IP address is assigned, you can access the CLI through Telnet.

Once connectivity to the device is established, you will see the a prompt.

```
device>
```

When accessing the CLI through Telnet, you maybe prompted for a password. By default, the password required is the password you enter for general access at initial setup. You also have the option of

assigning a separate password for Telnet access with the **enable telnet password** *password* command, found at the Global Level.

At initial log on, all you need to do is type **enable** at the prompt, then press Return. You only need to enter a password after a permanent password is entered at the Global CONFIG Level of the CLI.

To reach the Global CONFIG Level, the uppermost level of the CONFIG commands, enter the following commands

device > enable	User Level commands
device # configure terminal	Privileged Level-EXEC commands
device (config)#	Global Level-CONFIG commands

You can then reach all other levels of the CONFIG command structure from this point.

The CLI prompt will change at each level of the CONFIG command structure, to easily identify the current level.

```
device> User Level EXEC Command
device# Privileged Level EXEC Command
device(config)# Global Level CONFIG Command
device(config-if-e10000-5/1)# Interface Level CONFIG Command
device(config-lbif-1)# Loopback Interface CONFIG Command
device(config-ve-1)# Virtual Interface CONFIG Command
device(config-trunk-4/1-4/8)# trunk group CONFIG Command
device(config-if-e10000-tunnel)# IP Tunnel Level CONFIG Command
device(config-bgp-router)# BGP Level CONFIG Command
device(config-ospf-router)# OSPF Level CONFIG Command
device(config-isis-router)# IS-IS Level CONFIG Command
device(config-pim-router)# PIM Level CONFIG Command
device(config-redundancy)# Redundant Management Module CONFIG Command
device(config-rip-router)# RIP Level CONFIG Command
device(config-port-80)# Application Port CONFIG Command
device(config-bgp-routemap Map_Name)# Route Map Level CONFIG Command
device(config-vlan-1)# VLAN Port-based Level CONFIG Command
device(config-vlan-ataalk-PROTO)# VLAN Protocol Level CONFIG Command
```

#### NOTE

The CLI prompt at the interface level includes the port speed. The speed is one of the following: `device (config-if-e100-5/1) #` - The interface is a 10/100 port. `device (config-if-e1000-5/1) #` - The interface is a Gigabit port. For simplicity, the port speeds sometimes are not shown in example Interface level prompts in this manual.

## Single user in global configuration mode

By default, more than one user can enter the global configuration mode of a device CLI, which is accessed through the **configure terminal** command. While in global configuration mode, users can override another user's configuration changes.

You can configure a device to allow only one user to be in global configuration mode at any one time. Other users who try to enter that mode in will be denied. To allow only one user to enter global configuration mode, enter the following command.

```
device#configure terminal
device(config)# single-config-user
device(config)# write memory
```

**Syntax:** `[no] single-config-user`

After the **single-config-user** command is issued, the device will not allow more than one user to enter global configuration mode. However, if you run the command while more than one user is in global configuration mode, the other users continue to be in global configuration mode and can potentially override each other's configuration changes. Only users who try to enter the global configuration mode after the command is issued are prevented from entering global configuration mode. If a user is already in that mode and another user tries to enter global configuration mode after the **single-config-user** command is issued, the following error is displayed.

```
device#configure terminal
Single user config mode is being enforced. Config mode is being used by <session-
type> session.
```

where *session-type* can be one of the following:

- **console**
- **telnet number**
- **SSH number**

## Multi-user conflict during deletion of group configuration (or stanza)

By default, a user may delete a group configuration, even if another user is simultaneously in that mode. You can disable this feature by issuing the **enable multi-user-mode-deletion** command.

To allow only one user to delete group configurations, enter the following command.

```
device#configure terminal
device(config)# enable multi-user-mode-deletion
device(config)# write memory
```

When a user attempts to delete a group configuration from the CLI, and another user is already within that group configuration, the user who tries to delete a group configuration in that mode will be denied and will receive the following error message.

```
Session 1:
device(config)# vlan 10
device(config-vlan-10)#
Session 2:
device(config)# no vlan 10
>Error: Cannot undo the configuration as {console|telnet|SSH} session is      using
this mode."
```

### Syntax: [no] enable multi-user-mode-deletion

Use the **no** form of this command will allow multiple users the ability to delete group configurations.

---

#### NOTE

This feature will not work on commands that are issued from the WEB management and the SNMP management.

---

## Navigating among command levels

To reach other CLI command levels, you need to enter certain commands. At each level there is a launch command that allows you to move either up or down to the next level.

## CLI command structure

Many CLI commands may require textual or numeral input as part of the command.

### Required or optional fields

These fields are either required or optional depending on how the information is bracketed. For clarity, a few CLI command examples are explained below.

**Syntax:** `[no] deny redistribute value { all | bgp | rip | static address ip-addr ip-mask [ match-metric value | set-metric value ] }`

When an item is in italics, the information requested is a variable and required.

When an item is not bracketed with "{" symbols, the item is a required keyword or variable.

When an item is bracketed with "{" symbols, one of the items separated by a vertical bar "|" must be chosen.

When an item is bracketed with "[" symbols, the information requested is optional.

### Optional fields

When two or more options are separated by a vertical bar, "|", you must enter one of the options as part of the command.

**Syntax:** `priority normal | high`

For example, the "normal | high" entry in the Syntax above means that priority can be either priority normal or priority high. The command in the syntax above requires that you enter either normal or high as part of the command.

### List of available options

To get a quick display of available options at a CLI level or for the next option in a command string, enter a question mark (?) at the prompt or press TAB.

To view all available commands at the user EXEC level, enter the following or press TAB at the User EXEC CLI level.

```
device> ?
enable
exit
fastboot
ping
show
stop-trace-route
traceroute
```

You also can use the question mark (?) with an individual command, to see all available options or to check context.

Enter the following to view possible **copy** command options.

```
device# copy ?
flash
running-config
```

```

startup-config
tftp
device# copy flash ?
tftp

```

## Searching and filtering output

You can filter CLI output from **show** commands and at the --More-- prompt. You can search for individual characters, strings, or construct complex regular expressions to filter the output.

### Searching and filtering output from show commands

You can filter output from **show** commands to display lines containing a specified string, lines that do not contain a specified string, or output starting with a line containing a specified string. The search string is a regular expression consisting of a single character or string of characters. You can use special characters to construct complex regular expressions. Refer to the "Using special characters in regular expressions" section for information on special characters used with regular expressions.

#### *Displaying lines containing a specified string*

The following command filters the output of the **show interface** command for port 3/11 so it displays only lines containing the word "Internet". This command can be used to display the IP address of the interface.

```

device# show interface e 3/11 | include Internet
Internet address is 192.168.1.11/24, MTU 1518 bytes, encapsulation ethernet

```

**Syntax:** **show-command include | regular-expression**

---

#### **NOTE**

The vertical bar ( | ) is part of the command.

---

Note that the regular expression specified as the search string is case sensitive. In the example above, a search string of "Internet" would match the line containing the IP address, but a search string of "internet" would not.

#### *Displaying lines that do not contain a specified string*

The following command filters the output of the **show who** command so it displays only lines that do not contain the word "closed". This command can be used to display open connections to the device.

```

device# show who | exclude closed
Console connections:
  established
  you are connecting to this session
  2 seconds in idle
Telnet connections (inbound):
  1    established, client ip address 192.168.9.37
      27 seconds in idle
Telnet connection (outbound):
SSH connections:

```

**Syntax:** **show-command exclude | regular-expression**

### ***Displaying lines starting with a specified string***

The following command filters the output of the **show who** command so it displays output starting with the first line that contains the word "SSH". This command can be used to display information about SSH connections to the Brocade device.

```
device# show who | begin SSH
SSH connections:
 1      established, client ip address 192.168.9.210
      7 seconds in idle
 2      closed
 3      closed
 4      closed
 5      closed
```

**Syntax:** show-command begin | regular-expression

### **Searching and filtering output at the --More-- prompt**

The --More-- prompt is displayed when output extends beyond a single page. From this prompt, you can press the Space bar to display the next page, the Return or Enter key to display the next line, or Ctrl-C or Q to cancel the display. You can also search and filter output from this prompt.

```
device# ?
  append          Append one file to another
  attrib          Change file attribute
  boot            Boot system from bootp/tftp server/flash image
  cd              Change current working directory
  chdir           Change current working directory
  clear           Clear table/statistics/keys
  clock           Set clock
  configure       Enter configuration mode
  copy            Copy between flash, tftp, config/code
  cp              Copy file commands
  debug           Enable debugging functions (see also 'undebug')
  delete          Delete file on flash
  dir             List files
  dm              test commands
  dot1x           802.1X
  erase           Erase image/configuration files from flash
  exit            Exit Privileged mode
  fastboot        Select fast-reload option
  force-sync-standby Sync active flash (pri/sec/mon/startup config/lp images)
                  to standby
  format          Format Auxiliary Flash card
  hd              Hex dump
  ipc             IPC commands
--More--, next page: Space, next line: Return key, quit: Control-c
```

At the --More-- prompt, you can press the forward slash key ( / ) and then enter a search string. The device displays output starting from the first line that contains the search string, similar to the *begin* option for **show** commands.

```
--More--, next page: Space, next line: Return key, quit: Control-c
/telnet
```

The results of the search are displayed.

```
searching...
telnet          Telnet by name or IP address
terminal        Change terminal settings
traceroute      TraceRoute to IP node
undelete        Recover deleted file
whois           WHOIS lookup
write           Write running configuration to flash or terminal
```



To display lines containing only a specified search string (similar to the *include* option for **show** commands) press the plus sign key ( + ) at the --More-- prompt and then enter the search string.

```
--More--, next page: Space, next line: Return key, quit: Control-c
+telnet
```

The filtered results are displayed.

```
filtering...
telnet                               Telnet by name or IP address
```

To display lines that do not contain a specified search string (similar to the *exclude* option for **show** commands) press the minus sign key ( - ) at the --More-- prompt and then enter the search string.

```
--More--, next page: Space, next line: Return key, quit: Control-c
-telnet
```

The filtered results are displayed.

```
filtering...
sync-standby                         Sync active flash (pri/sec/mon/startup config/lp images)
                                     to standby if different
terminal                             Change terminal settings
traceroute                           TraceRoute to IP node
undelete                             Recover deleted file
whois                                 WHOIS lookup
write                                 Write running configuration to flash or terminal
```

As with the commands for filtering output from **show** commands, the search string is a regular expression consisting of a single character or string of characters. You can use special characters to construct complex regular expressions. Refer to the next section for information on special characters used with regular expressions.

## Using special characters in regular expressions

You can use special characters to construct complex regular expressions to filter output from **show** commands. You can use a regular expression to specify a single character or multiple characters as a search string. In addition, you can include special characters that influence the way the software matches the output against the search string. These special characters are listed in the following table.

**TABLE 4** Special characters for regular expressions

Character	Operation
.	The period matches on any single character, including a blank space. For example, the following regular expression matches "aaz", "abz", "acz", and so on, but not just "az": a.z
*	The asterisk matches on zero or more sequential instances of a pattern. For example, the following regular expression matches output that contains the string "abc", followed by zero or more Xs: abcX*
+	The plus sign matches on one or more sequential instances of a pattern. For example, the following regular expression matches output that contains "de", followed by a sequence of "g"s, such as "deg", "degg", "deggg", and so on: deg+

**TABLE 4** Special characters for regular expressions (Continued)

Character	Operation
?	<p>The question mark matches on zero occurrences or one occurrence of a pattern.</p> <p>For example, the following regular expression matches output that contains "dg" or "deg":</p> <pre>de?g</pre>
	<p><b>NOTE</b></p> <p>Normally when you type a question mark, the CLI lists the commands or options at that CLI level that begin with the character or string you entered. However, if you enter Ctrl+V and then type a question mark, the question mark is inserted into the command line, allowing you to use it as part of a regular expression.</p>
^	<p>A caret (when not used within brackets) matches on the beginning of an input string.</p> <p>For example, the following regular expression matches output that begins with "deg":</p> <pre>^deg</pre>
\$	<p>A dollar sign matches on the end of an input string.</p> <p>For example, the following regular expression matches output that ends with "deg":</p> <pre>deg\$</pre>
_	<p>An underscore matches on one or more of the following:</p> <ul style="list-style-type: none"> <li>• , (comma)</li> <li>• { (left curly brace)</li> <li>• } (right curly brace)</li> <li>• ( (left parenthesis)</li> <li>• ) (right parenthesis)</li> <li>• The beginning of the input string</li> <li>• The end of the input string</li> <li>• A blank space</li> </ul> <p>For example, the following regular expression matches on "100" but not on "1002", "2100", and so on.</p> <pre>_100_</pre>
[ ]	<p>Square brackets enclose a range of single-character patterns.</p> <p>For example, the following regular expression matches output that contains "1", "2", "3", "4", or "5":</p> <pre>[1-5]</pre> <p>You can use the following expression symbols within the brackets. These symbols are allowed only inside the brackets.</p> <ul style="list-style-type: none"> <li>• ^ - The caret matches on any characters except the ones in the brackets. For example, the following regular expression matches output that does not contain "1", "2", "3", "4", or "5":<pre>^[^1-5]</pre></li> <li>• - The hyphen separates the beginning and ending of a range of characters. A match occurs if any of the characters within the range is present. See the example above.</li> </ul>
	<p>A vertical bar separates two alternative values or sets of values. The output can match one or the other value.</p> <p>For example, the following regular expression matches output that contains either "abc" or "defg":</p> <pre>abc defg</pre>

**TABLE 4** Special characters for regular expressions (Continued)

Character	Operation
( )	<p>Parentheses allow you to create complex expressions.</p> <p>For example, the following complex expression matches on "abc", "abcabc", or "defg", but not on "abcdefgdefg":</p> <p>((abc+))((defg)?)</p>

If you want to filter for a special character instead of using the special character as described in the table above, enter "\" (backslash) in front of the character. For example, to filter on output containing an asterisk, enter the asterisk portion of the regular expression as "\\\*".

```
device#show ip route bgp | include \*
```

## Allowable characters for LAG names

When creating a LAG name, you can use spaces in a file or subdirectory name if you enclose the name in double quotes. For example, to specify a subdirectory name that contains spaces, enter a string such as the following: "a long subdirectory name". The maximum length for a string is 64 characters.

The following characters are valid in file names:

- All upper and lowercase letters
- All digits

Any of the following special characters are valid:

- \$
- %
- '
  - -
  - \_
  - .
  - @
  - ~
  - `
  - !
  - (
  - )
  - {
  - }
  - ^
  - #
  - &

## CLI parsing enhancement

The response to an invalid keyword, the command returns to the cursor will include all valid content up to where the error was made. The prompt will only delete the invalid keyword "proc" and return to a prompt with the command "device# **show**". This will allow the user to continue typing from the point of failure, rather than having to type out the entire command again.

```
device# show proc
Unrecognized command
device# show
```

## Syntax shortcuts

A command or parameter can be abbreviated as long as enough text is entered to distinguish it from other commands at that level. For example, given the possible commands **copy tftp ...** and **config tftp ...**, possible shortcuts are **cop tftp** and **con tftp** respectively. In this case, **co** does not properly distinguish the two commands.

## Saving configuration changes

You can make configuration changes while the device is running. The type of configuration change determines whether or not it becomes effective immediately or requires a save to flash (**write memory**) and reset of the system (**reload**), before it becomes active.

This approach in adopting configuration changes:

- Allows you to make configuration changes to the operating or running configuration of the device to address a short-term requirement or validate a configuration without overwriting the permanent configuration file, the startup configuration, that is saved in the system flash, and;
- Ensures that dependent or related configuration changes are all cut in at the same time.

In all cases, if you want to make the changes permanent, you need to save the changes to flash using the **write memory** command. When you save the configuration changes to flash, this will become the configuration that is initiated and run at system boot.

---

### NOTE

Most configuration changes are dynamic and thus do not require a software reload. If a command requires a software reload to take effect, the documentation states this.

---

## Modifying startup and running configuration file manually

When you manually modify a **startup-config** or **running-config** file, ensure that you do not delete the **!** (**exclamation mark**) from any of the lines in the configuration file.

---

**NOTE**

For configuration files which are copied to device running, or startup config via TFTP/SCP, entering a blank comment line or ! (exclamation mark denotes a comment line) followed only by blank spaces, in any of the global config sublevels, resets the mode to global config level.

---



# Commands A - E

---

## access-list

Defines a numbered access control list (ACL), specifies ACL parameters, and creates the ACL permit and deny rules.

**Syntax** `access-list num [ permit | deny ] [ vlan vlan-id ] ipv6-source-prefix/prefix-length | ipv6-source-prefix wildcard-mask | any | host source-ipv6-address ipv6-destination-prefix/prefix-length | ipv6-destination-prefix wildcard-mask | any | host ipv6-destination-address [ ipv6-operator [ value ] ] [ copy-sflow ] [ drop-precedence dp-value ] [ drop-precedence-force dp-value ] [ dscp dscp-value ] [ dscp-marking dscp-value ] [ mirror ] [ priority-force number ] [ regenerate-seq-num dec ] [ sequence number ]`

`no access-list num [ permit | deny ] [ vlan vlan-id ] protocol ipv6-source-prefix/prefix-length ipv6-source-prefix wildcard-mask | any | host source-ipv6-address ipv6-destination-prefix/prefix-length | ipv6-destination-prefix wildcard-mask | any | host ipv6-destination-address [ ipv6-operator [ value ] ] [ copy-sflow ] [ drop-precedence dp-value ] [ drop-precedence-force dp-value ] [ dscp dscp-value ] [ dscp-marking dscp-value ] [ mirror ] [ priority-force number ] [ regenerate-seq-num dec ] [ sequence number ]`

**Command Default** No access list is created.

**Parameters** *num*

Indicates the selected ACL. 1 - 99 are standard IP access list; 100 - 199 are extended IP access lists; 400 - 1399 are Level 2 MAC address lists; 2000 - 2999 are UDA access lists.

**permit**

Indicates that the ACL permits (forwards) packets that match a policy in the ACL.

**deny**

Indicates that the ACL denies (drops) packets that match a policy in the ACL.

**vlan** *vlan-id*

Indicates the selected VLAN.

*protocol ipv6-source-prefix/prefix-length*

Specifies a source or destination prefix and prefix length that a packet must match for the specified deny or permit action to occur. The user must specify the *ipv6-source-prefix* and *ipv6-destination-prefix* parameters in hexadecimal using 16-bit values between colons, as documented in RFC 2373. You must specify the *prefix-length* parameter as a decimal value. A slash (/) must follow the *ipv6-prefix* parameter and precede the *prefix-length* parameter.

*ipv6-source-prefix wildcard-mask*

Lets the user specify a group of source destination IPv6 addresses. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**any**

Specifies instead of the *ipv6-source-prefix/prefix-length* or *ipv6-destination-prefix/prefix-length* parameters matches any IPv6 prefix and is equivalent to the IPv6 prefix ::/0.

**host**

The **host** *ipv6-source-address* and **host** *ipv6-destination-address* parameter lets you specify a host IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

*source-ipv6-address ipv6-destination-prefix/prefix\_length*

Specifies a source or destination prefix and prefix length that a packet must match for the specified deny or permit action to occur. The user must specify the *ipv6-source-prefix* and *ipv6-destination-prefix* parameters in hexadecimal using 16-bit values between colons, as documented in RFC 2373. The user must specify the *prefix-length* parameter as a decimal value. A slash (/) must follow the *ipv6-prefix* parameter and precede the *prefix-length* parameter.

*ipv6-destination-prefix wildcard-mask*

Lets you specify a group of host destination IPv6 addresses. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**any**

Specifies instead of the *ipv6-source-prefix/prefix-length* or *ipv6-destination-prefix/prefix-length* parameters matches any IPv6 prefix and is equivalent to the IPv6 prefix ::/0.

**host**

The **host** *ipv6-source-address* and **host** *ipv6-destination-address* parameter lets you specify a host IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

*ipv6-destination-address*

Lets you specify a host destination IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**ipv6-operator** *value*

If a port has an ACL applied, the user must remove ACL bindings prior to creating or adding that port to a VLAN or a VE interface.

**copy-sflow**

Sends packets matching the ACL permit clause to the sFlow collector.

**drop-precedence** *dp-value*

Sets the drop precedence by the selected value.

**drop-precedence-force** *dp-value*

Sets the force drop precedence by the selected value.

**dscp** *dscp-value*

*Differentiated Services Code Point (DSCP)*. Enter a value from 0 - 63 for the **dscp** *dscp-value* parameter if you want to filter packets based on their DSCP value.

**dscp-marking** *dscp-value*

Enter a value from 0 - 64 for the **dscp** *dscp-value* parameter if you want to filter packets based on their DSCP value.

**mirror**

Mirrors packets matching to the ACL permit clause.

**priority-force** *number*

Sets the force packet outgoing priority according to the selected number value.

**regenerate-seq-num** *dec*

Regenerates the filter sequence numbers based on the specified initial resequence number for the access list.

**Modes** Global configuration mode



**Usage Guidelines** The following related commands follow this protocol:

- ip access-list
- ipv6 access-list
- mac access-list

The **no** form of the command removes any definitions to the Access Control List (ACL).

**Examples** The following example shows how the keyword to specify a mask is added to all the places in the ACL configuration template where the IPv6 address prefix is present.

```
device configure terminal
device(config)# ipv6 access-list temp
device(config-ipv6-access-list temp)# permit ipv6
device(config-ipv6-access-list temp)# permit ipv6 1::1
device(config-ipv6-access-list temp)# permit ipv6 1::1 f::f
device(config-ipv6-access-list temp)# permit ipv6 1::1 f::f 2::2
```

Release version	Command history
5.4.00	This command was modified to include the <b>dscp-marking</b> <i>dscp-value</i> parameter.
5.9.00	This command was modified to include the <i>ipv6_destination_prefix wildcard-mask</i> and <i>pv6-source-prefix wildcard-mask</i> format to represent a group of addresses.  This command was modified to support the UDA ACLs.

## access-list sequence

Defines the Access Control List (ACL).

**Syntax** **access-list** *num* [ **sequence number** ] [ **permit** | **deny** ] [ **vlan** *vlan-id* ] **protocol** *ipv6-source-prefix/prefix-length* | *ipv6-source-prefix wildcard-mask* | **any** *hostsource-ipv6\_address* *ipv6-destination-prefix/prefix-length* | *ipv6-destination-prefix wildcard-mask* | **any** | **host** *ipv6-destination-address* [ **ipv6-operator** [ *value* ] ] [ **copy-sflow** ] [ **drop-precedence** *dp-value* ] [ **drop-precedence-force** *dp-value* ] [ **dscp** *dscp-value* ] [ **dscp-marking** *dscp-value* ] [ **mirror** ] [ **priorityforce** *number* ]

**no access-list** *num* **sequence number** ] [ **permit** | **deny** ] [ **vlan** *vlan-id* ] **protocol** *ipv6-source-prefix/prefix-length* | *ipv6-source-prefix wildcard-mask* | **any** *hostsource-ipv6\_address* *ipv6-destination-prefix/prefix-length* | *ipv6-destination-prefix wildcard-mask* | **any** | **host** *ipv6-destination-address* [ **ipv6-operator** [ *value* ] ] [ **copy-sflow** ] [ **drop-precedence** *dp-value* ] [ **drop-precedence-force** *dp-value* ] [ **dscp** *dscp-value* ] [ **dscp-marking** *dscp-value* ] [ **mirror** ] [ **priorityforce** *number* ]

**Parameters** **sequence number**

The sequence parameter takes a mandatory decimal integer ranging from 1 to 214748364. When the user tries to use a sequence number that is more than the limit (214748364), it causes the system to generate a sequence number that is greater than the limit. The system generates an error and does not allow the provisioning of the ACL filter.

**permit**

Indicates that the ACL permits (forwards) packets that match a policy in the ACL.

**deny**

Indicates that the ACL denies (drops) packets that match a policy in the ACL.

**vlan** *vlan-id*

Indicates the selected VLAN.

**protocol** *ipv6-source-prefix/prefix-length*

Specifies a source or destination prefix and prefix length that a packet must match for the specified deny or permit action to occur. The user must specify the *ipv6-source-prefix* and *ipv6-destination-prefix* parameters in hexadecimal using 16-bit values between colons, as documented in RFC 2373. You must specify the *prefix-length* parameter as a decimal value. A slash (/) must follow the *ipv6-prefix* parameter and precede the *prefix-length* parameter.

*ipv6-source-prefix wildcard-mask*

Lets the user specify a group source destination IPv6 addresses. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**any**

Specifies instead of the *ipv6-source-prefix/prefix-length* or *ipv6-destination-prefix/prefix-length* parameters it matches any IPv6 prefix and is equivalent to the IPv6 prefix ::/0.

**host**

The **host** *ipv6-source-address* and **host** *ipv6-destination-address* parameter lets you specify a host IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

*source-ipv6-address* *ipv6-destination-prefix/prefix-length*

Specifies a source or destination prefix and prefix length that a packet must match for the specified deny or permit action to occur. The user must specify the *ipv6-source-prefix* and *ipv6-destination-prefix* parameters in hexadecimal using 16-bit values between colons, as documented in RFC

2373. The user must specify the *prefix-length* parameter as a decimal value. A slash (/) must follow the *ipv6-prefix* parameter and precede the *prefix-length* parameter.

*ipv6-destination-prefix wildcard-mask*

Lets you specify a group of host destination IPv6 addresses. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**any**

Specifies instead of the *ipv6-source-prefix/prefix-length* or *ipv6-destination-prefix/prefix-length* parameters it matches any IPv6 prefix and is equivalent to the IPv6 prefix ::/0.

**host**

The **host** *ipv6-source-address* and **host** *ipv6-destination-address* parameter lets you specify a host IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

*ipv6-destination-address*

Lets you specify a host destination IPv6 address. When you use this parameter, you do not need to specify the prefix length. A prefix length of all 128 is implied.

**ipv6-operator value**

If a port has an ACL applied, the user must remove ACL bindings prior to creating or adding that port to a VLAN or a VE interface.

**copy-sflow**

Sends packets matching the ACL permit clause to the sFlow collector.

**drop-precedence** *dp-value*

Sets the drop precedence by the selected value.

**drop-precedence-force** *dp-value*

Sets the force drop precedence by the selected value.

**dscp** *dscp-value*

Enter a value from 0 - 64 for the **dscp** *dscp-value* parameter if you want to filter packets based on their DSCP value.

**dscp-marking** *dscp-value*

The traffic class bits on all IPv6 packets going to real servers bound to this virtual server are set to the configured value. The dscp-marking value ranges from 0 - 64.

**mirror**

Mirror packets matching the ACL permit clause.

**priorityforce** *number*

Sets the force packet outgoing priority according to the selected number value.

**Modes** Global configuration mode.

**Usage Guidelines** The following related commands follow this protocol:

- ip access-list
- ipv6 access-list
- mac access-list

The **no** form of the command removed the definitions from the *Access Control List (ACL)*.

**Examples** The following example shows the IPv6 wildcard match configuration.

```

device configure terminal
device(config)# ipv6 access-list wildcard
device(config-ipv6-access-list wildcard)# permit ipv6 ?
    X:X::X:X/M      IPv6 source prefix
    X:X::X:X        IPv6 source address
    any             Any source host
device(config-ipv6-access-list wildcard)# permit ipv6 1000::1 ?
    X:X::X:X        IPv6 source wildcard mask
device(config-ipv6-access-list wildcard)# permit ipv6 1000::1 ::FFFF:0 ?
    X:X::X:X/M      IPv6 destination prefix
    X:X::X:X        IPv6 destination address
    any             Any destination host
    host            A single destination host
device(config-ipv6-access-list wildcard)# permit ipv6 1000::1 ::FFFF:0 2000::1 ?
    X:X::X:X        IPv6 destination wildcard mask
device(config-ipv6-access-list wildcard)#permit ipv6 1000::1 ::FFFF:0 2000::1 ::FFFF:
0:0
    
```

**History**

Release version	Command history
5.9.00	This command was modified to include the <i>ipv6-source-prefix wildcard-mask</i> and <i>ipv6-destination-prefix wildcard-mask</i> format to represent a group of addresses.

# activate

Activates the configured Virtual Router Redundancy Protocol (VRRP) virtual routing instance.

**Syntax**     **activate**

**no activate**

**Command Default**   A VRRP virtual routing instance is not activated.

**Modes**            Virtual routing ID interface configuration mode.

**Usage Guidelines**   Before issuing this command, complete the configuration of the VRRP virtual router. The interface assigned to the VRID does not provide backup service for the virtual IP address until you activate the VRRP configuration.

The **no** form of this command disables the VRRP VRID.

**Examples**        The following example configures and activates the VRRP virtual routing ID 1.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ip address 10.53.5.1
device(conf-if-e1000-1/6-vrid-1)# activate
VRRP router 1 for this interface is activating
```

# adjustment-threshold

Specifies the sensitivity of the automatic bandwidth adjustment of a label-switched path (LSP) to changes in bandwidth utilization.

**Syntax** `adjustment-threshold [ num | use-threshold-table ]`

**no adjustment-threshold [ num | use-threshold-table ]**

**Parameters** *num*

Defines the adjustment threshold in percent. The range is 0 - 100. The default is 0.

**use-threshold-table**

Indicates that the template has to use the autobw-threshold table to determine the threshold.

**Modes** MPLS auto-bandwidth template configuration mode.

MPLS LSP auto-bandwidth configuration mode.

**Usage Guidelines** Under the MPLS auto-template configuration mode, the command sets the threshold for when to trigger automatic bandwidth adjustments. When the automatic bandwidth adjustment is configured, bandwidth demand for the current interval is determined and compared to the LSPs current bandwidth allocation.

Under the MPLS LSP autobw configuration mode, the command configures the LSP path to use adjustment-threshold from the autobw-threshold table instead of a percentage.

Under both configuration modes, the **no** form of the command sets the adjustment threshold to the default value.

**Examples** The following example under the MPLS autobw-template config mode configures the automatic bandwidth adjustment template to use the autobw-threshold table to determine the threshold.

```
deviceconfig terminal
device(config)# router mpls
device(config-mpls)# autobw-template templatel
device(config-mpls-autobw-template-templatel)# adjustment-interval 1200
device(config-mpls-autobw-template-templatel)# adjustment-threshold use-threshold-table
device(config-mpls-autobw-template-templatel)# overflow-limit 10
device(config-mpls-autobw-template-templatel)# underflow-limit 20
device(config-mpls-autobw-template-templatel)# sample-recording enable
```

The following example under the MPLS lsp autobw config mode defines the automatic bandwidth adjustment threshold as 40 percent.

```
deviceconfig terminal
device(config)# router mpls
device(config-mpls)# lsp lsp1
device(config-mpls-lsp-lsp1)# adaptive
device(config-mpls-lsp-lsp1)# auto-bandwidth
device(config-mpls-lsp-lsp1-autobw)# template templatel
device(config-mpls-lsp-lsp1-autobw-template-templatel)# overflow-limit 0
device(config-mpls-lsp-lsp1-autobw-template-templatel)# underflow-limit 20
device(config-mpls-lsp-lsp1-autobw-template-templatel)# mode monitor-only
device(config-mpls-lsp-lsp1-autobw-template-templatel)# sample-recording disable
```

**History**

Release	Command history
5.6.00	The command was introduced.

# advertise backup

Advertises a Virtual Router Redundancy Protocol (VRRP) backup router to a VRRP master router.

**Syntax**    **advertise backup**

**no advertise backup**

**Command Default**    A VRRP backup router does not advertise itself to a VRRP master router.

**Modes**            Virtual routing ID interface configuration mode.

**Usage Guidelines**    Hello messages are used to advertise a backup router to a master router. To configure the interval at which the messages are sent, use the **backup-hello-interval** command.

The **advertise-backup** command is configured only on VRRP backup routers and supported by VRRP and VRRP-E.

The **no** form of the command disables the advertisement of a VRRP backup router to a VRRP master router.

**Examples**            The following example enables advertisements from the VRRP backup router and configures the hello message interval to 10 seconds.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# advertise backup
device(conf-if-e1000-1/6-vrid-1)# backup-hello-interval 10
```

# advertise-fec

Configures the prefix-list to inject the routes learned by routing into the LDP and advertises the FEC to other LDP peers.

**Syntax** `advertise-fec prefix-list`

`no advertise-fec prefix-list`

**Parameters** `prefix-list`

The prefix-list specifies the prefixes. The range is an ASCII string, which is the Prefix List Name.

**Modes** MPLS LDP configuration mode.

**Usage Guidelines** Use to configure the prefix-list to inject the routes learned by routing into the LDP and advertises the FEC to other LDP peers. This command is similar to the **filter-fec** command used for inbound and outbound FEC filtering in LDP. This command is mutually exclusive with the ACL based command (advertise-labels), and only one of the two configurations can be present at any given time. When the ACL based configuration is already present, an error message displays to the operator to un-configure the ACL in LDP and the prefix-list command is rejected.

The command syntax is similar to the **filter-fec** command used for inbound and outbound FEC filtering in LDP.

The **no** form of the command removes the prefix listing.

**Examples** The following example displays the prefix-list when no ACL configuration is in the LDP:

```
device(config)# ip prefix-list list-abc deny 44.44.44.44/32
device(config)# ip prefix-list list-abc permit 0.0.0.0/0 ge 32

device(config)# router mpls
device(config-mpls)# ldp
device(config-mpls-ldp)# advertise-fec list-abc
```

History	Release version	Command history
	5.7.00	This command was introduced.



## area authentication

Enables authentication for an OSPF Version 3 (OSPFv3) area.

**Syntax** `area { A.B.C.D | decimal } authentication ipsec spi value esp sha1 key [ no-encrypt ] key`  
`no area { A.B.C.D | decimal } authentication ipsec spi value`

**Command Default** Authentication is not enabled on an area.

If the **no-encrypt** keyword is not used, the key is stored in encrypted format by default.

**Parameters** *A.B.C.D*

Area address in dotted decimal format.

*decimal*

Area address in decimal format.

**ipsec**

Specifies that IP security (IPsec) is the protocol that authenticates the packets.

**spi**

Specifies the Security Policy Index (SPI).

*value*

Specifies the SPI value. Valid values range from decimal numbers 256 through 4294967295. The near-end and far-end values must be the same.

**esp**

Specifies Encapsulating Security Payload (ESP) as the protocol to provide packet-level security. This is the only option currently available.

**sha1**

Enables Hashed Message Authentication Code (HMAC) Secure Hash Algorithm 1 (SHA-1) authentication on the OSPFv3 area.

*key*

Number used in the calculation of the message digest. The 40 hexadecimal character key is stored in encrypted format by default.

**no-encrypt**

The 40-character key is not encrypted upon either its entry or its display.

*key*

The 40 hexadecimal character key.

**Modes** OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** The 40 hexadecimal character key is encrypted by default. The system adds the following in the configuration to indicate that the key is encrypted:

- `encrypt` = the key string uses proprietary simple cryptographic 2-way algorithm (only for Brocade NetIron CES and Brocade NetIron CER devices)
- `encryptb64` = the key string uses proprietary base64 cryptographic 2-way algorithm (only for Brocade NetIron XMR and Brocade MLX series devices)

Use the **no-encrypt** parameter to disable encryption.

Enter **no area authentication spi** to remove an authentication specification for an area from the configuration.

**Examples** This example enables esp and SHA-1 authentication for an OSPFv3 area, setting a SPI value of 900.

```
device# configure terminal
device(config)# ip router-id 10.1.2.3
device(config)# ipv6 router ospf
device(config-ospf6-router)# area 0 authentication ipsec spi 750 esp sha1
abcef12345678901234fedcba098765432109876
```

## area nssa (OSPFv3)

Creates a not-so-stubby area (NSSA) or modifies its parameters.

**Syntax** `area { A.B.C.D | decimal } nssa [ metric ] [ default-information-originate [ metric num ] [ metric-type { type-1 | type-2 } ] ] [ no-redistribution ] [ no-summary ] [ translator-always ] [ translator-interval interval ]`

**no area nssa**

**Command Default** No areas are created.

**Parameters** *A.B.C.D*

Area address in dotted decimal format.

*decimal*

Area address in decimal format.

*metric*

Additional cost for using a route to or from this area. Valid values range from 1 through 1048575.

**default-information-originate**

When configured on the ABR, this parameter injects a Type 7 default route into the NSSA area. As a result, the other NSSA routers install the default route through the advertising NSSA ABR. By default the NSSA ABR does not originate a default route to the NSSA.

**metric-type**

Specifies how the cost of a neighbor metric is determined. The default is type-1.

**type-1**

The metric of a neighbor is the cost between itself and the router plus the cost of using this router for routing to the rest of the world.

**type-2**

The metric of a neighbor is the total cost from the redistributing routing to the rest of the world.

**no-redistribution**

The no-redistribution parameter prevents an NSSA ABR from generating external (type-7) LSA into a NSSA area. This is used in the case where an ASBR should generate type-5 LSA into normal areas and should not generate type-7 LSA into a NSSA area. By default, redistribution is enabled in a NSSA.

**no-summary**

When configured on the NSSA area border router (ABR), this parameter prevents any Type 3 and Type 4 summary link-state advertisement (LSA) from being injected into the area. The only exception is that a default route is injected into the NSSA by the ABR, and strictly as a Type 3 LSA (not a Type 7, because that could cause intra-AS traffic to get routed out the AS). This makes the NSSA a NSSA totally stubby area, which can only have Type 1, 2 and 7 LSAs.

**Note:** This parameter is disabled by default, which means the default route must use a Type 7 LSA.

**translator-always**

Configures the translator-role. When configured on an ABR, this causes the router to unconditionally assume the role of a NSSA translator. By default, translator-always is not set, the translator role by default is candidate.

**translator-interval** *interval*

Configures the time interval for which an elected NSSA translator continues to perform its duties even after its NSSA translator role has been disposed by another router. By default the stability-interval is 40 seconds and its range is 10 to 60 seconds.

- Modes** OSPFv3 router configuration mode  
 OSPFv3 router VRF configuration mode
- Usage Guidelines** NSSAs are typically needed when one-way transmission of Type-5 LSAs (out of the area) is desired but injection of the same LSAs into the area is not acceptable.
- Once created, the type of the area cannot be changed. The only exception to this rule is that a NSSA or stub area can be changed to a totally NSSA or a totally stub area, respectively.
- Enter **no area nssa** to delete a NSSA.
- Examples** This example sets an additional cost of 4 on a NSAA identified as 8 (in decimal format), and prevents any Type 3 or Type 4 summary LSAs from being injected into the area.
- ```
device# configure terminal
device(config)#ipv6 router ospf
device(config-ospf6-router)# area 8 nssa 4 no-summary
```

## area range (OSPFv2)

Specifies area range parameters on an area border router (ABR).

**Syntax** `area { A.B.C.D | decimal } range E.F.G.H I.J.K.L [ advertise | not-advertise ] [ cost cost_value ]`  
**no area range**

**Parameters** *A.B.C.D*

Area address in dotted decimal format.

*decimal*

Area address in decimal format.

*E.F.G.H I.J.K.L*

Specifies the IP address and mask portion of the range. All network addresses that match this network are summarized in a single route and advertised by the ABR.

**advertise**

Sets the address range status to *advertise* and generates a Type 3 summary LSA.

**cost cost\_value**

Sets the cost value for the area range. This value is used as the generated summary LSA cost. The range for *cost\_value* is 1 to 6777214. If this value is not specified, the cost value is the default range metric calculation for the generated summary LSA cost.

**not-advertise**

Sets the address range status to DoNotAdvertise; the Type 3 LSA is suppressed, and the component networks remain hidden from other networks. This setting is used to temporarily pause route summarization from the area.

**Modes** OSPF router configuration mode

OSPF router VRF configuration mode

**Usage Guidelines** Use this command only on ABRs to specify route summarization for an existing area. The result is that a single summary route is advertised to other areas by the ABR, in the form of a Type 3 LSA. Routing information is condensed at area boundaries and external to the area, and only a single route is advertised for each address range.

An example of when you might want to use this command is if you have many small networks advertised from area 0 to any other area, or from any non-backbone area into the backbone. This command gives you a summary route instead of many smaller routes. In an area, the OSPF database on each router must be an exact copy of the databases of the other routers. This means that no summarization is allowed within the area.

Enter **no area range** to disable the specification of range parameters on an ABR.

**Examples** This example advertises to Area 3 all the addresses on the network 1.1.1.0 255.255.255.0 in the ABR you are signed into.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# area 3 range 1.1.1.0 255.255.255.0 advertise
```

## area range (OSPFv3)

Specifies area range parameters on an area border router (ABR).

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>area</b> { <i>A.B.C.D</i>   <i>decimal</i> } <b>range</b> <i>ipv6 address/mask</i> [ <b>advertise</b>   <b>not-advertise</b> ] [ <b>cost</b> <i>cost_value</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                         | <b>no area range</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Parameters</b>       | <i>A.B.C.D</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                         | <i>decimal</i> Area address in dotted decimal format.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|                         | <i>decimal</i> Area address in decimal format.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                         | <i>ipv6 address/mask</i> Specifies the IPv6 address in dotted-decimal notation and the IPv6 mask in CIDR notation. All network addresses that match this network are summarized in a single route and advertised by the ABR.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                         | <b>advertise</b> Sets the address range status to <i>advertise</i> and generates a Type 3 summary LSA.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|                         | <b>cost</b> <i>cost_value</i> Sets the cost value for the area range. This value is used as the generated summary LSA cost. The range for <i>cost_value</i> is 1 to 6777214. If this value is not specified, the cost value is the default range metric calculation for the generated summary LSA cost.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|                         | <b>not-advertise</b> Sets the address range status to DoNotAdvertise; the Type 3 LSA is suppressed, and the component networks remain hidden from other networks. This setting is used to temporarily pause route summarization from the area.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Modes</b>            | OSPFv3 router configuration mode<br>OSPFv3 router VRF configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Usage Guidelines</b> | Use this command only on ABRs to specify route summarization for an existing area. The result is that a single summary route is advertised to other areas by the ABR, in the form of a Type 3 LSA. Routing information is condensed at area boundaries and external to the area, and only a single route is advertised for each address range.<br><br>An example of when you might want to use this command is if you have many small networks advertised from area 0 to any other area, or from any non-backbone area into the backbone. This command gives you a summary route instead of many smaller routes. In an area, the OSPF database on each router must be an exact copy of the databases of the other routers. This means that no summarization is allowed within the area.<br><br>Enter <b>no area range</b> to disable the specification of range parameters on an ABR. |
| <b>Examples</b>         | This example advertises to Area 3 all the addresses on the network 2001:db8:8::/45 in the ABR you are signed into.<br><br><pre>device# configure terminal device(config)# ipv6 router ospf device(config-ospf6-router)# area 3 range 2001:db8:8::/45 advertise</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## area stub

Creates or deletes a stub area or modifies its parameters.

**Syntax** `area { A.B.C.D | decimal } stub metric [ no-summary ]`

**no area stub**

**Command Default** No areas are created.

**Parameters** *A.B.C.D*

Area address in dotted decimal format.

*decimal*

Area address in decimal format.

*metric*

Additional cost for using a route to or from this area. Valid values range from 3 through 1048575 in OSPFv3 router and OSPFv3 router VRF configuration mode. Valid values range from 1 through 677215 in OSPF router and OSPF router VRF configuration mode.

**no-summary**

When configured on the ABR, this parameter prevents any Type 3 and Type 4 summary LSAs from being injected into the area. The only exception is that a default route is injected into the stub/totally stubby area by the ABR as a Type 3 LSA. Enabling this parameter makes the area a so-called totally stubby area, which can only have Types 1 and 2. This parameter is disabled by default.

**Modes** OSPF router configuration mode

OSPF router VRF configuration mode

OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** Once created, the type of the area cannot be changed. The only exception to this rule is that a NSSA or stub area can be changed to a totally NSSA or a totally stub area, respectively.

Enter **no area stub** to delete a stub area.

**Examples** This example sets an additional cost of 5 on a stub area called 2 (in decimal format).

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# area 2 stub 5
```

## area virtual-link (OSPFv3)

Creates or modifies virtual links for an area.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>area</b> { <i>A.B.C.D</i>   <i>decimal</i> } <b>virtual-link</b> <i>E.F.G.H</i> [ <b>dead-interval</b> <i>time</i>   <b>hello-interval</b> <i>time</i>   <b>hello-jitter</b> <i>interval</i>   <b>retransmit-interval</b> <i>time</i>   <b>transmit-delay</b> <i>time</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                         | <b>no area virtual-link</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Command Default</b>  | No virtual links are created.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Parameters</b>       | <p><i>A.B.C.D</i> Area address in dotted decimal format.</p> <p><i>decimal</i> Area address in decimal format.</p> <p><i>E.F.G.H</i> ID of the OSPFv3 device at the remote end of the virtual link.</p> <p><b>dead-interval</b> <i>time</i><br/>How long a neighbor device waits for a hello packet from the current device before declaring the device down. This value must be the same for all devices and access servers that are attached to a common network. Valid values range from 1 through 65535 seconds. The default is 40 seconds.</p> <p><b>hello-interval</b><br/>Time between hello packets that the device sends on an interface. The value must be the same for all devices and access servers that are attached to a common network. Valid values range from 1 through 65535 seconds. The default is 10 seconds.</p> <p><b>hello-jitter</b><br/>Sets the allowed jitter between hello packets. Valid values range from 1 through 50 percent (%). The default value is 10%.</p> <p><b>retransmit-interval</b> <i>time</i><br/>Time between Link State Advertisement (LSA) retransmissions for adjacencies belonging to the interface. Set this interval to a value larger than the expected round-trip delay between any two devices on the attached network. Valid values range from 0 through 3600 seconds. The default is 5 seconds.</p> <p><b>transmit-delay</b> <i>time</i><br/>Estimated time required to send an LSA on the interface. This value must be an integer greater than zero. The age of each LSA in the update packet is incremented by the value of this parameter before transmission occurs. Valid values range from 0 through 3600 seconds. The default is 1 second.</p> |
| <b>Modes</b>            | OSPFv3 router configuration mode<br>OSPFv3 router VRF configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Usage Guidelines</b> | <p>Enter <b>no area virtual-link</b> to remove a virtual link.</p> <p>The values of the <b>dead-interval</b> and <b>hello-interval</b> parameters must be the same at both ends of a virtual link. Therefore, if you modify the values of these parameters at one end of a virtual link, you must make the same modifications on the other end of the link. The values of the other virtual link parameters do not require synchronization.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |



**Examples** This example creates a virtual link for an area whose decimal address is 1, and where the ID of the OSPFv3 device at the remote end of the virtual link is 209.157.22.1.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# area 1 virtual-link 209.157.22.1
```

## area virtual-link authentication (OSPFv3)

Enables authentication for virtual links in an OSPFv3 area.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <p><b>area</b> { <i>A.B.C.D</i>   <i>decimal</i> } <b>virtual-link</b> <i>E.F.G.H</i> <b>authentication ipsec spi</b> <i>value</i> <b>esp sha1</b> <i>key</i> [ <b>no-encrypt</b> ] <i>key</i></p> <p><b>no area</b> { <i>A.B.C.D</i>   <i>decimal</i> } <b>virtual-link</b> <i>E.F.G.H</i> <b>authentication ipsec spi</b> <i>spi</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Command Default</b>  | <p>Authentication is not enabled on a virtual-link.</p> <p>The 40 hexadecimal character key is encrypted by default. Use the <b>no-encrypt</b> parameter to disable encryption.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Parameters</b>       | <p><i>A.B.C.D</i> Area address in dotted decimal format.</p> <p><i>decimal</i> Area address in decimal format.</p> <p><i>E.F.G.H</i> ID of the OSPFv3 device at the remote end of the virtual link.</p> <p><b>ipsec</b> Specifies that IP security (IPsec) is the protocol that authenticates the packets.</p> <p><b>spi</b> Specifies the Security Policy Index (SPI).</p> <p><i>value</i> Specifies the SPI value. Valid values range from decimal numbers 256 through 4294967295. The near-end and far-end values must be the same.</p> <p><b>esp</b> Specifies Encapsulating Security Payload (ESP) as the protocol to provide packet-level security. This is the only option currently available.</p> <p><b>sha1</b> Enables Hashed Message Authentication Code (HMAC) Secure Hash Algorithm 1 (SHA-1) authentication on the OSPFv3 area.</p> <p><i>key</i> Number used in the calculation of the message digest. The 40 hexadecimal character key is stored in encrypted format by default.</p> <p><b>no-encrypt</b> The 40-character key is not encrypted upon either its entry or its display.</p> <p><i>key</i> The 40 hexadecimal character key.</p> |
| <b>Modes</b>            | <p>OSPFv3 router configuration mode</p> <p>OSPFv3 router VRF configuration mode</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Usage Guidelines</b> | <p>Enter <b>no area</b> { <i>A.B.C.D</i>   <i>decimal</i> } <b>virtual-link</b> <i>E.F.G.H</i> <b>authentication ipsec spi</b> <i>spi</i> to remove authentication from the virtual-links in the area.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

**Examples** This example configures IPsec on a virtual link in an OSPFv3 area, and encryption is disabled.

```
device# configure terminal
device(config)# ip router-id 10.1.2.2
device(config)# ipv6 router ospf
device(config-ospf6-router)# area 2 virtual-link 10.1.2.2 authentication ipsec spi
600 esp sha1 no-encrypt 1134567890223456789012345678901234567890
```

## arp

Configures an IP mechanism that the routers use to learn the Media Access Control (MAC) address of a device on the network.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <pre>arp ip_addr mac_addr [ ethernet slot/port ]   [ multi-ports [ ethernet   pos ] ] vlan vlan_id [ vpls [ peer   vlan ] ]</pre> <pre>no arp ip_addr mac_addr [ ethernet slot/port ]   [ multi-ports [ ethernet   pos ] ] vlan vlan_id [ vpls [ peer   vlan ] ]</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Parameters</b>       | <p><i>ip_addr</i><br/>Specifies the IPv4 address of the host.</p> <p><i>mac_addr</i><br/>Specifies the MAC address of the host. The MAC address must be entered in the hexadecimal format.</p> <p><b>ethernet slot/port</b><br/>Specifies the selected Ethernet port.</p> <p><b>multi-ports</b><br/>Configures multi-ports static ARP.</p> <p><b>ethernet</b><br/>Configures the static ARP entry on the Ethernet port.</p> <p><b>pos</b><br/>Configures the static ARP entry on the POS port.</p> <p><b>vlan vlan_id</b><br/>Configures static ARP entry for a VLAN. The VLAN ID range is from 1 to 4090.</p> <p><b>vpls</b><br/>Configures static ARP entry for a VPLS instance.</p> <p><b>peer</b><br/>Configures the VPLS-peer IP address.</p> <p><b>vlan</b><br/>Configures the VLAN ID.</p> |
| <b>Modes</b>            | VRF sub-configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Usage Guidelines</b> | <p>If the VLAN ID is not configured when IP source guard is turned on, the IP address is assumed to be valid on all the VLANS on the port.</p> <p>If both the VLAN ID and the port are not configured when IP source guard is turned on, the IP address is assumed to be valid for all VLANs.</p> <p>Use the <b>no</b> form of the command to remove a static mapping address.</p>                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Examples</b>         | <p>The following example shows an ARP configuration command for VRF that is extended to support VPLS instances.</p> <pre>device config t device(config)# vrf red device(config-vrf-red# rd 55:55 device(config-vrf-red) #address-family ipv4 device(config-vrf-red-ipv4)# arp 1.1.1.1 000.111.222 device(config-vrf-red-ipv4)# arp 1.1.1.1 000.111.222 vpls vlan 10 ethernet 1/1 &lt;cr&gt; device(config-vrf-red-ipv4)# arp 1.1.1.1 000.111.222 vpls vlan 10 ethernet 1/1</pre>                                                                                                                                                                                                                                                                                                                  |

| History | Release version | Command history                                      |
|---------|-----------------|------------------------------------------------------|
|         | 5.8.00          | This command was modified to enable VRF for VPLS VE. |

## arp-guard

Discards all gratuitous ARP and ARP replies for IP addresses not permitted by the specified ARP-guard standard IP access control list (ACL).

**Syntax** `arp-guard arp-guard-access-list-name`

`no arp-guard arp-guard-access-list-name`

**Command Default** All gratuitous ARP and ARP replies for IP addresses are software forwarded.

**Parameters** `arp-guard-access-list-name`

ARP packets that do not match the specified ARP guard ACL are dropped by the LP and those which match will be software forwarded.

**Modes** Interface configuration mode

**Usage Guidelines** The **no** form of this command removes the ARP-guard filtering of ARP packets.

This command is used in conjunction with the **arp-guard-access-list** command to build a table of allowed IP addresses on the link on which the ARP-guard feature is enabled.

**Examples** The following example configures the ARP-guard feature to discard all gratuitous ARP and ARP replies for IP addresses that do not match the IP address and MAC address listed in the ACL named arpacl10.

```
device# configure terminal
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# arp-guard-access-list AS201
device(conf-if-e1000-1/6)# permit 10.0.0.2 0001.0002.0003
device(conf-if-e1000-1/6)# arp-guard arpacl10
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

# arp-guard-access-list

Creates the ARP guard access list.

**Syntax** **arp-guard-access-list** *arp-guard-access-list-name*  
**no arp-guard-access-list** *arp-guard-access-list-name*

**Command Default** No ARP guard access list is created.

**Parameters** *arp-guard-access-list-name*  
 The name of the ARP guard access-list, which contains the list of rules and filters for a specific ARP ACL.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command removes the ARP guard group.

**Examples** The following example creates an ARP guard access list named AS201.

```
device# configure terminal
device(config)# arp-guard-access-list AS201
```

| History | Release version | Command history             |
|---------|-----------------|-----------------------------|
|         | 5.7.00          | This command is introduced. |

## arp-guard-syslog-timer

Sets the system log timer duration for an ARP guard.

**Syntax** `arp-guard-syslog-timer dec`

`no arp-guard-syslog-timer dec`

**Command Default** By default, ARP guard syslog messages for the dropped packets are displayed on the active console for every 60 seconds.

**Parameters** *dec*

The syslog timer duration that is configurable in seconds. The default value is 60 seconds.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command removes the syslog timer value.

**Examples** The following command example is used to set the system log timer value at 240 seconds.

```
Brocade(config)# arp-guard-syslog-timer 240
Brocade(config)# show arp-guard-access-list all
Arp-guard configuration:
!
arp-guard-access-list AS200
!
arp-guard-access-list AS201
permit any 1.1.1.1 any
permit any 1.1.1.1 0001.0001.0001
!
arp-guard-syslog-timer 240
!
```

### History

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.7.00          | This command is introduced. |



# authentication

Configures the authentication proposal used with the IKEv2 profile.

**Syntax** `authentication authentication-proposal-name`

**Parameters** `authentication-proposal-name`  
Specifies authentication proposal name.

**Modes** IKEv2 profile configuration mode.

**Examples** The following example configures the authentication proposal used with the IKEv2 profile.

```
device(config)# ikev2 profile brocade
device(config-ikev2-profile-brocade)# authentication test1
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# auto-bandwidth

Allows an MPLS tunnel to automatically adjust its bandwidth allocation based on the volume of traffic flowing through the tunnel.

**Syntax** `auto-bandwidth sample-interval sec`  
`no auto-bandwidth sample-interval sec`

**Parameters** `sample-interval sec`  
 The **sample-interval** parameter is the time after which the traffic rate is sampled. The `sec` variable sets the sample interval in seconds. Range is 60 - 604,800 (7 days). Default is 300 seconds.

**Modes** Global configuration mode.  
 MPLS configuration mode (config-mpls-policy).

**Usage Guidelines** The **no** function disables the auto-bandwidth globally. Auto-bandwidth suspends functionality like the adjustment of bandwidth, rate-calculation, and timers. The rates for the auto-bandwidth LSP revert to traffic-engineering configured mean-rate.  
 The **auto-bandwidth sample-interval sec** command enables global auto-bandwidth and sets sample-interval to the entered value.  
 The **no auto-bandwidth** command disables global auto-bandwidth without changing the sample-interval.

---

**NOTE**  
 Disabling auto-bandwidth globally does not revert to the configured sample-interval value.

---

**Examples** The following example displays the **auto-bandwidth** command that enables auto-bandwidth globally:

```
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# auto-bandwidth sample-interval 30
```

The following example displays the command to enter the auto-bandwidth mode of the CLI for the primary/secondary path.

```
device(config-mpls-lsp-xyz)# auto-bandwidth (for primary path)
device(config-mpls-lsp-xyz-secpath-xyz2)# auto-bandwidth (for secondary path)
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.3.00          | This command was introduced. |

# autobw-threshold-table

Configures the MPLS auto-bandwidth threshold table.

**Syntax** **autobw-threshold-table**  
**no autobw-threshold table**

**Modes** MPLS configuration mode.  
MPLS auto-bandwidth threshold table configuration mode.  
MPLS LSP configuration mode.

**Usage Guidelines** The **no** form of the command clears all the entries in the adjustment-threshold table.

**Examples** The following example shows when the user wants to set the adjustment-threshold table.

```
device(config)# router mpls
device(config-mpls)# autobw-threshold-table
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 10 threshold 2000
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 1000 threshold 3000
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 10000 threshold 5000
```

The following example shows when the user wants to remove one of the threshold entries.

```
device(config)# router mpls
device(config-mpls)# autobw-threshold-table
device(config-mpls-autobw-threshold-table)# no bandwidth-ceiling 1000 threshold 3000
```

The following example shows when the user wants to clear the threshold table.

```
device(config)# router mpls
device(config-mpls)# no autobw-threshold-table
```

The following example shows when the user wants to configure an LSP to use the global table for adjustment threshold.

```
device(config)# router mpls
device(config-mpls)# lsp lsp1
device(config-mpls-lsp-lsp1)# auto
device(config-mpls-lsp-lsp1-autobw)# adjustment-threshold use-threshold-table
```

## History

| Release | Command history              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

## auto-cost reference-bandwidth (OSPFv2)

Configures reference bandwidth.

**Syntax** `auto-cost reference-bandwidth { value | use-active-ports }`

`no auto-cost reference-bandwidth`

**Command Default** Reference bandwidth is 100 Mbps.

**Parameters** *value*

Reference bandwidth in Mbps. Valid values range from 1 through 4294967.

**use-active-ports**

Specifies that any dynamic change in bandwidth immediately affects the cost of OSPF routes. This parameter enables cost calculation for currently active ports only.

**Modes** OSPF router configuration mode

OSPF router VRF configuration mode

**Usage Guidelines** Use this command to configure the cost of an interface that a device advertises to its OSPF neighbors. OSPF calculates the cost of a route as the ratio of the reference bandwidth to the bandwidth of the egress interface. An increase in the reference bandwidth results in an increased cost. If the resulting cost is less than 1, the software rounds the cost up to 1.

The bandwidth for interfaces that consist of more than one physical port is calculated as follows:

- LAG group — The combined bandwidth of all the ports.
- Virtual interface — The combined bandwidth of all the ports in the port-based VLAN that contains the virtual interface.

If a change to the reference bandwidth results in a cost change to an interface, the device sends a link-state update to update the costs of interfaces advertised by the device.

---

### NOTE

If you specify the cost for an individual interface (by using the `ip ospf cost` command), the cost you specify overrides the cost calculated by the software.

---

Enter `no auto-cost reference-bandwidth` to disable bandwidth configuration.

**Examples** This example configures a reference bandwidth of 500.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# auto-cost reference-bandwidth 500
```

The reference bandwidth specified in this example results in the following costs:

- 10 Mbps port's cost =  $500/10 = 50$ .
- 100 Mbps port's cost =  $500/100 = 5$ .
- 1000 Mbps port's cost =  $500/1000 = 0.5$ , which is rounded up to 1.

The costs for 10 Mbps and 100 Mbps ports change as a result of the changed reference bandwidth. Costs for higher-speed interfaces remain the same.

## auto-cost reference-bandwidth (OSPFv3)

Configures reference bandwidth.

**Syntax** `auto-cost reference-bandwidth value`

`no auto-cost reference-bandwidth`

**Command Default** Reference bandwidth is 100 Mbps.

**Parameters** *value*

Reference bandwidth in Mbps. Valid values range from 1 through 4294967. The default is 100 Mbps.

**Modes** OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** Use this command to configure the cost of an interface that a device advertises to its OSPF neighbors. OSPFv3 calculates the cost of a route as the ratio of the reference bandwidth to the bandwidth of the egress interface. An increase in the reference bandwidth results in an increased cost. If the resulting cost is less than 1, the software rounds the cost up to 1.

The bandwidth for interfaces that consist of more than one physical port is calculated as follows:

- LAG group — The combined bandwidth of all the ports.
- Virtual (Ethernet) interface — The combined bandwidth of all the ports in the port-based VLAN that contains the virtual interface.

If a change to the reference bandwidth results in a cost change to an interface, the device sends a link-state update to update the costs of interfaces advertised by the device.

---

### NOTE

If you specify the cost for an individual interface using the `ipv6 ospf cost` command, the cost you specify overrides the cost calculated by the software.

---

Some interface types are not affected by the reference bandwidth and always have the same cost regardless of the reference bandwidth in use:

- The cost of a loopback interface is always 1.
- The cost of a virtual link is calculated using the Shortest Path First (SPF) algorithm and is not affected by the auto-cost feature.
- The bandwidth for tunnel interfaces is 9 Kbps and is subject to the auto-cost feature.

Enter `no auto-cost reference-bandwidth` to restore the reference bandwidth to its default value and thus restore the default costs of the interfaces to their default values.

**Examples** This example configures a reference bandwidth of 500.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# auto-cost reference-bandwidth 500
```

The reference bandwidth specified in this example results in the following costs:

- 10 Mbps port's cost =  $500/10 = 50$ .
- 100 Mbps port's cost =  $500/100 = 5$ .
- 1000 Mbps port's cost =  $500/1000 = 0.5$ , which is rounded up to 1.
- 155 Mbps port cost =  $500/155 = 3.23$ , which is rounded up to 4
- 622 Mbps port cost =  $500/622 = 0.80$ , which is rounded up to 1
- 2488 Mbps port cost =  $500/2488 = 0.20$ , which is rounded up to 1

The costs for 10 Mbps, 100 Mbps, and 155 Mbps ports change as a result of the changed reference bandwidth. Costs for higher-speed interfaces remain the same.

# auto-enroll

Sends enrollment messages to the certificate authority (CA) and local certificates to either generate new key pair for a certificate or renew an expired certificate.

**Syntax** **auto-enroll** [ **regenerate** | *percent* ]

**no auto-enroll** [ **regenerate** | *percent* ]

**Command Default** The option to send enrollment messages is disabled.

**Parameters** **regenerate**

Generates a new key pair for the certificate even if the key pair already exists.

*percent*

Specifies the renewal percentage value to request a new certificate. Valid percentage values range from 10 through 90 percent. The default is 80 percent.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The **no** form of the command disables the device from sending enrollment messages.

**Examples** The following example specifies the percentage value as 20.

```
device(config)# pki trustpoint brocadel
device(config-pki-trustpoint-brocadel)# auto-enroll 20
```

The following example specifies the option of regenerating a new key pair for a certificate.

```
device(config)# pki trustpoint brocadel
device(config-pki-trustpoint-brocadel)# auto-enroll regenerate
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## backup

Designates a virtual router as a Virtual Router Redundancy Protocol (VRRP) or VRRP extended (VRRP-E) backup device and configures track and priority values.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>backup</b> [ <i>priority value</i> ] [ <b>track-priority</b> <i>value</i> ]<br><b>no backup</b> [ <i>priority value</i> ] [ <b>track-priority</b> <i>value</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Command Default</b>  | No virtual routers are designated as a VRRP or VRRP-E backup device.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Parameters</b>       | <b>priority value</b><br>Sets a priority value for a backup device. Values are from 8 to 254. In VRRP, the default backup device priority is 100, the owner device has a default priority of 255. In VRRP-E, the default backup device priority is 100.<br><b>track-priority value</b><br>Sets the new priority value if the interface goes down.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Modes</b>            | Virtual routing ID interface configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Usage Guidelines</b> | The <b>no</b> form of this command removes the virtual router configuration.<br><br>In VRRP, the backup device with the highest priority assumes the role of VRRP master device if the owner device fails. The interface on which the VRID is configured must be in the same subnet (but not be the same address) as the IP address associated with the VRID by the owner device.<br><br>In VRRP-E, all devices are configured as backup devices and the backup device with the highest priority becomes the master device. If the master device fails, the backup device with the highest priority at that time assumes the role of VRRP master device. The IP address assigned to the interface of any device in the same virtual router must be in the same IP subnet. The IP address assigned to the VRID must not be configured on any of the Brocade devices.<br><br>This command must be entered before the <b>ip-address</b> command can be configured for a VRRP or VRRP-E virtual routing ID. |
| <b>Examples</b>         | The following example configures the device as a VRRP backup and assigns a priority of 100.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ip address 10.53.5.3/24
device(conf-if-e1000-1/5)# ip vrrp vrid 1
device(conf-if-e1000-1/5-vrid-1)# backup priority 100
device(conf-if-e1000-1/5-vrid-1)# advertise backup
device(conf-if-e1000-1/5-vrid-1)# ip-address 10.53.5.254
device(conf-if-e1000-1/5-vrid-1)# activate
```

The following example configures the device as a VRRP-E backup, assigns a priority of 50 and a track priority of 10.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ip address 10.53.10.4/24
device(conf-if-e1000-1/5)# ip vrrp vrid 2
device(conf-if-e1000-1/5-vrid-2)# backup priority 50 track-priority 10
device(conf-if-e1000-1/5-vrid-2)# ip-address 10.53.10.254
device(conf-if-e1000-1/5-vrid-2)# activate
```



## backup-bw-best-effort

Configures bandwidth requirement's interpretation as 'best effort' for backup of all FRR LSPs initiated on this router.

**Syntax** **backup-bw-best-effort**

**no backup-bw-best-effort**

**Command Default** By default, this is not turned on ('Guarantee' mode). The bandwidth requested on the backup for FRR LSPs is a strict requirement that needs to be guaranteed by the router.

**Modes** MPLS RSVP configuration mode.

**Usage Guidelines** Configuring this command dictates this router to consider the bandwidth requested by FRR LSPs on their backup as a 'best-effort' requirement. So, if a backup with the requested bandwidth could not be setup as per the process described in previous sections, then a backup without any bandwidth is tried to setup instead.

This configuration is only available on a global level, and affects all the FRR LSPs passing through this router for which this router is acting as a PLR.

The **no** form of the command brings the router functionality back to default ("Guarantee" mode) and removes the configuration statement. Consider the bandwidth requested on the backup for FRR LSPs as a strict requirement.

**Examples** The following example shows the **backup-bw-best-effort** command.

```
device(config-mpls-rsvp)# backup-bw-best-effort
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## backup-hello-interval

Configures the interval at which backup Virtual Router Redundancy Protocol (VRRP) routers advertise their existence to the master router.

**Syntax** `backup-hello-interval seconds`

`no backup-hello-interval seconds`

**Command Default** The default backup hello interval is 60 seconds.

**Parameters** `seconds`

Interval at which a backup VRRP router advertises its existence to the master router. Valid values range from 60 through 3600 seconds.

**Modes** Virtual-router-group configuration mode

**Usage Guidelines** The interval is the length of time, in seconds, between each advertisement sent from the backup routers to the master router. The advertisement notifies the master router that the backup is still active. If the master router does not receive an advertisement from the backup in a designated amount of time, the backup with the highest priority can assume the role of master.

The **backup-hello-interval** command is configured only on VRRP backup routers and supported by VRRP and VRRP-E.

The **no** form disables the advertisement of a VRRP backup router to a VRRP master router.

**Examples** The following example enables advertisements from the VRRP backup router and sets the hello message interval to 10 seconds.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# advertise backup
device(conf-if-e1000-1/6-vrid-1)# backup-hello-interval 10
```

# bandwidth

Configures the LSP to inherit bandwidth from its protected LSP configuration.

**Syntax** **bandwidth** { **inherit** | *dec* }

**no bandwidth** { **inherit** | *dec* }

**Command Default** By default, this is not configured. The backup of the FRR LSP does not inherit bandwidth information from protected LSP.

**Parameters** **inherit** *dec*

Inherits bandwidth for detour/backup LSP from the protected LSP.

**Modes** MPLS configuration mode (config-mpls-lsp-frr).

**Usage Guidelines** The **no** form of the command stops inheriting the bandwidth information from the protected LSP path and removes the configuration statement.

Configuring this command dictates the backup LSP path to inherit the same amount of bandwidth as that of the signaled protected LSP.

For adaptive LSPs, this configuration can be changed on the fly without disabling the LSP first. Committing the configuration changes triggers a make-before-break.

**Examples** Display output of the **bandwidth** command:

```
device# show mpls config lsp to_NY
lsp to_NY
  to 28.28.28.28
  primary to-10-3_hop
  traffic-eng mean-rate 2000
  frr
    bandwidth inherit
  enable
```

---

## Release version

## Command history

---

5.8.00

This command is introduced.

---

## bandwidth-ceiling

Adds a new threshold change point to the autobw-threshold table.

**Syntax** **bandwidth-ceiling** [ *bw\_in\_kbps* | *max* ] **threshold** *threshold\_in\_kbps*

**no bandwidth-ceiling** [ *bw\_in\_kbps* | | *max* ] **threshold** *threshold\_in\_kbps*

**Parameters** *bw\_in\_kbps*

Defines the bandwidth ceiling in kilobytes per second. The range is 0 - 2, 147, 483, 647 kilobytes per second.

*max*

Defines the threshold for any traffic-rate as infinity.

**threshold** *threshold\_in\_kbps*

Sets the threshold to be used up to this defined ceiling.

**Modes** MPLS auto-bandwidth threshold table configuration mode.

**Usage Guidelines** This command adds a new threshold change point to the autobw-threshold table. If the change point is already there, the value of the threshold is updated.

The **no** form of the command removes the bandwidth ceiling entry from the table.

**Examples** The following example shows how to set the adjustment=threshold table.

```
device(config)# router mpls
device(config-mpls)# autobw-threshold-table
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 10 threshold 2000
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 1000 threshold 3000
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling 10000 threshold 5000
```

The following example shows how to remove one of the threshold entries.

```
device(config)# router mpls
device(config-mpls)# autobw-threshold-table
device(config-mpls-autobw-threshold-table)# no bandwidth-ceiling 1000 threshold 3000
```

The following example shows how to clear the threshold table.

```
device(config)# router mpls
device(config-mpls)# no autobw-threshold-table
```

### History

| Release | Command history              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

## bandwidth-ceiling max threshold percentage

Sets the threshold for any traffic-rate above the maximum bandwidth-ceiling configured in the table as a percentage.

**Syntax** `bandwidth-ceiling max threshold [ dec | percentagedec ]`

`no bandwidth-ceiling max threshold [ dec | percentagedec ]`

**Parameters** **max**

Any rate above the maximum ceiling configured. By default, the last ceiling is used.

*dec*

Sets the threshold value. Range 0 - 2, 147, 483, 647 kilobits per second.

**threshold**

Sets the threshold to be used up to this ceiling.

*percentage**dec*

Sets the specified threshold value in percentage. Range is 0 - 100%.

**Modes** MPLS auto-bandwidth threshold table configuration mode.

**Usage Guidelines** The **no** function of this command removes the entry.

**Examples** The following example shows how to set the maximum bandwidth percentage to 10.

```
device(config)# router mpls
device(config-mpls)# autobw-threshold-table
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling max threshold
percentage 10
device(config-mpls-autobw-threshold-table)# bandwidth-ceiling max threshold 10000
```

**History**

| Release | Command history             |
|---------|-----------------------------|
| 05.6.00 | The command was introduced. |

## base vrf

Configures the VRF to which the tunnel source and destination belongs.

**Syntax** **base vrf** *base-vrf-name*

**no base vrf** *base-vrf-name*

**Command Default** By default, the base VRF is not configured. The default VRF is considered the base VRF.

**Parameters** *base-vrf-name*

Specifies the VRF name of the base network.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** The **no** form of the command disables the base VRF configuration for the tunnel interface.

When the tunnel source interface is configured, the base VRF is checked and if the source interface does not belong to the configured base VRF, a configuration error message is displayed.

**Examples** The following example configures the base VRF for the tunnel interface.

```
device(config)# interface ethernet 3/1
device(config-int-e10000-3/1)# ip address 36.0.8.108/32
device(config-int-e10000-3/1)# exit
device(config)# interface tunnel 1
device(config-tnif-1)# base vrf vrf1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

# bfd

Configures Bidirectional Forwarding Detection (BFD) session parameters on BGP-enabled interfaces.

**Syntax** **bfd min-tx** *transmit-time* **min-rx** *receive-time* **multiplier** *number*  
**no bfd min-tx** *transmit-time* **min-rx** *receive-time* **multiplier** *number*

**Command Default** Default parameters are used.

**Parameters** **min-tx** *transmit-time*  
 Specifies the interval, in milliseconds, a device waits to send a control packet to BFD peers. Valid values range from 50 through 30000. The default is 1000 unless changed using the **bfd interval** command in interface sub-type configuration mode.

**min-rx** *receive-time*  
 Specifies the interval, in milliseconds, a device waits to receive a control packet from BFD peers. Valid values range from 50 through 30000. The default is 1000 unless changed using the **bfd interval** command in interface sub-type configuration mode.

**multiplier** *number*  
 Specifies the number of consecutive BFD control packets that must be missed by the BFD peer before the BFD peer determines that the connection is not operational. Valid values range from 3 through 50. The default is 3.

**Modes** BGP configuration mode  
 BGP address-family IPv4 unicast VRF configuration mode

**Usage Guidelines** When using BFD for BGP, you must configure BFD globally at the router BGP level. You can also use this configuration to set new default values for the transmit interval, receive interval, and for the detection time multiplier.

For a single-hop EBGp session, the BFD parameters configured under interface subtype configuration mode are used because the BFD session for a single hop is also shared with other applications. To create a BFD session for a single-hop BGP session, you must first enable BFD and configure the timers for the interface on which single-hop BGP peering is established using the **bfd interval** command in interface subtype configuration mode.

For multihop BFD sessions, BFD does not need to be enabled for any of the interfaces, and the BFD timers need not be configured, because the default values can be used.

The **min-tx**, **min-rx**, and **multiplier** keywords can also be configured for each peer and peer group and will override the global configuration.

When Brocade NetIron CER Series or Brocade NetIron CES Series devices are heavily loaded or under stress, BFD sessions may flap if the configured BFD interval is less than 500 milliseconds with a multiplier value of 3.

The *transmit-time* and *receive-time* variables are the intervals desired by the local device. The actual values in use will be the negotiated values.

The **no** form of the command globally removes BFD for BGP parameters from the device.

**Examples** The following example sets the BFD session parameters globally for BGP.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# bfd min-tx 120 min-rx 150 multiplier 8
```

The following example sets the BFD session parameters globally for BGP for VRF "red" in BGP address-family IPv4 unicast VRF configuration mode.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# bfd min-tx 120 min-rx 150 multiplier 8
```



## bfd all-interfaces

Enables Bidirectional Forwarding Detection (BFD) for all interfaces participating in the routing process.

**Syntax** **bfd all-interfaces all-vrfs**

**bfd all-interfaces**

**no bfd all-interfaces all-vrfs**

**no bfd all-interfaces**

**Command Default** BFD is disabled by default.

**Parameters** **all-vrfs**  
Specifies all VRFs.

**Modes** IS-IS router configuration mode  
OSPF router configuration mode  
OSPFv3 router configuration mode  
OSPF router VRF configuration mode

**Usage Guidelines** Although this command configures BFD for OSPFv2 on all OSPFv2-enabled interfaces for a device, it is not required if you use the **ip ospf bfd** command to configure specific interfaces. It can be used independently or together with the **ip ospf bfd** command.

Although this command configures BFD for OSPFv3 on all OSPFv3-enabled interfaces for a device, it is not required if you use the **ipv6 ospf bfd** command to configure specific interfaces. It can be used independently or together with the **ipv6 ospf bfd** command.

Although this command configures BFD for IS-IS on all IS-IS-enabled interfaces for a device, it is not required if you use the **isis bfd** command to configure specific interfaces. It can be used independently or together with the **isis bfd** command.

The **all-vrfs** keyword is only available in OSPF router configuration mode and OSPF router VRF configuration mode.

The **no** form of the command in OSPF router configuration mode disables BFD on all OSPFv2-enabled interfaces. The **no** form of the command in OSPFv3 router configuration mode disables BFD on all OSPFv3-enabled interfaces. The **no** form of the command in IS-IS router configuration mode disables BFD on all IS-IS-enabled interfaces.

**Examples** The following example enables BFD globally for all VRFs on all OSPFv2-enabled interfaces.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# bfd all-interfaces all-vrfs
```

The following example enables BFD globally on all OSPFv2-enabled interfaces for VRF instance "red".

```
device# configure terminal
device(config)# router ospf vrf red
device(config-ospf-router-vrf-red)# bfd all-interfaces
```

The following example disables BFD globally on all OSPFv3-enabled interfaces.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# no bfd all-interfaces
```

The following example enables BFD on all IS-IS-enabled interfaces.

```
device# configure terminal
device(config)# router isis
device(config-isis-router)# bfd all-interfaces
```

## bfd holdover-interval

Sets the time interval for which BFD session down notifications are delayed before a routing protocol is notified that a BFD session is down.

**Syntax** `bfd holdover-interval time`

`no bfd holdover-interval time`

**Command Default** The BFD holdover interval is set to 0 by default.

**Parameters** *time*

Specifies the BFD holdover interval in seconds. In the BGP and BGP address-family IPv4 unicast VRF configuration modes, valid values range from 1 through 30, and the default is 0. In the IS-IS router, OSPF router, OSPFv3 router, and OSPF router VRF configuration modes, valid values range from 1 through 20, and the default is 0.

**Modes** BGP configuration mode  
 BGP address-family IPv4 unicast VRF configuration mode  
 IS-IS router configuration mode  
 OSPF router configuration mode  
 OSPFv3 router configuration mode  
 OSPF router VRF configuration mode

**Usage Guidelines** For BGP, the BFD holdover interval is supported for both single-hop and multihop sessions. For OSPF and IS-IS, the BFD holdover interval is supported for single-hop sessions only.

In BGP configuration mode, use this command to set the BFD holdover-time interval globally for BGP. In IS-IS router configuration mode, use this command to set the BFD holdover-time interval globally for IS-IS. In OSPF router configuration mode, use this command to set the BFD holdover-time interval globally for OSPFv2. In OSPFv3 router configuration mode, use this command to set the BFD holdover-time interval globally for OSPFv3.

The holdover interval on BGP-enabled interfaces can be configured globally, on each peer, or peer-group.

The **no** form of the command removes the configured BFD holdover interval from the configuration, and reverts to the default value of 0.

**Examples** The following example sets the BFD holdover interval globally to 15 in BGP configuration mode.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# bfd holdover-interval 15
```

The following example sets the BFD holdover interval globally to 15 for VRF instance "red" in BGP address-family IPv4 unicast VRF configuration mode.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# bfd holdover-interval 15
```

The following example sets the BFD holdover interval globally to 12 in OSPF router configuration mode.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# bfd holdover-interval 12
```

The following example sets the BFD holdover interval globally 12 for VRF instance “red” in OSPF router VRF configuration mode.

```
device# configure terminal
device(config)# router ospf vrf red
device(config-ospf-router-vrf-red)# bfd holdover-interval 12
```

The following example sets the BFD holdover interval globally to 20 in OSPFv3 router configuration mode.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# bfd holdover-interval 20
```

The following example sets the BFD holdover interval globally to 20 in IS-IS router configuration mode.

```
device# configure terminal
device(config)# router isis
device(config-isis-router)# bfd holdover-interval 20
```

## bfd interval

Configures Bidirectional Forwarding Detection (BFD) session parameters on an interface.

**Syntax** **bfd interval** *transmit-time* **min-rx** *receive-time* **multiplier** *number*  
**no bfd interval** *transmit-time* **min-rx** *receive-time* **multiplier** *number*

**Command Default** Default parameters are used.

**Parameters** **interval** *transmit-time*  
 Specifies the interval, in milliseconds, a device waits to send a control packet to BFD peers. Valid values range from 50 through 30000.  
**min-rx** *receive-time*  
 Specifies the interval, in milliseconds, a device waits to receive a control packet from BFD peers. Valid values range from 50 through 30000.  
**multiplier** *number*  
 Specifies the number of consecutive BFD control packets that must be missed by a BFD peer before the peer determines that the connection is not operational. Valid values range from 3 through 50.

**Modes** Interface subtype configuration mode

**Usage Guidelines** The **interval** *transmit-time* and **min-rx** *receive-time* variables are the intervals desired by the local device. The actual values in use will be the negotiated values.

When Brocade NetIron CER Series or Brocade NetIron CES Series devices are heavily loaded or under stress, BFD sessions may flap if the configured BFD interval is less than 500 milliseconds with a multiplier value of 3.

The **no** form of the command reverts to the default parameters.

**Examples** The following example sets the BFD session parameters globally for an Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# bfd interval 100 min-rx 100 multiplier 4
```

## **bfd-enable**

Enables Bidirectional Forwarding Detection (BFD) globally on BGP-enabled interfaces.

**Syntax** **bfd-enable**

**no bfd-enable**

**Command Default** BFD is disabled by default.

**Modes** BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

**Usage Guidelines** If BFD for BGP is globally disabled and then enabled, the original BFD sessions for BGP may not be available, depending on whether the maximum BFD sessions limit has been reached. When a BFD session for BGP is disabled, the session is removed but BGP peering does not go down. The remote BFD peer is informed that BFD use is disabled.

This command overrides all other BGP BFD configurations.

The **no** form of this command disables BFD globally and terminates all BFD sessions used by BGP.

**Examples** The following example enables BFD globally for BGP.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# bfd-enable
```

The following example enables BFD globally for BGP4 for VRF "red" in BGP address-family IPv4 unicast VRF configuration mode.

```
device# configure terminal
device(config-bgp)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# bfd-enable
```

## **bfd mh-session-setup-delay**

Provides a time delay before establishing the multihop BFD session after the system initializes.

**Syntax** **bfd mh-session-setup-delay** *seconds*

**no bfd mh-session-setup-delay** *seconds*

**Command Default** By default, the time delay to establish the multihop session is set to 0 seconds.

**Parameters** *seconds*

The time delay in seconds. You can specify a value between 0 and 600 seconds. The default value is 0 seconds.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command removes the time delay for the multihop session.

**Examples** The following example sets a delay time of 90 seconds before establishing the multihop session.  
`device(config)#bfd mh-session-setup-delay 90`

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.7.00         | This command was introduced. |

## bfd sh-session-setup-delay

Provides a time delay before establishing the single hop BFD session after the port is enabled.

**Syntax** **bfd sh-session-setup-delay** *seconds*

**no bfd sh-session-setup-delay** *seconds*

**Command Default** By default, the time delay to establish the single hop session is set to 180 seconds.

**Parameters** *seconds*

The time delay in seconds. You can specify a value between 0 and 600 seconds. The default value is 180 seconds.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command removes the time delay for the session.

**Examples** The following example sets a delay time of 40 seconds before establishing the single hop session.

```
device(config)# bfd sh-session-setup-delay 40
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |



# cam ifsr

Disables or enables In-Field Soft Repair (IFSR) for TCAM hardware errors for a specified host name.

**Syntax** `cam ifsr { disable | enable }`

**Parameters** **disable**

Disables IFSR for TCAM hardware errors for a specified host name.

**enable**

Enables IFSR for TCAM hardware errors for a specified host name.

**Modes** Global configuration mode

**Usage Guidelines** Use this to command to disable or enable persistent hardware errors from displaying on the console as syslog messages as a result of hardware errors. Some hardware errors cannot be repaired. Continuous syslog messages will appear on the console displaying the system KBP errors. The command allows you to disable the feature, and stop the monitoring of hardware errors. After replacing the hardware, enable the feature. By default, the command is enabled.

The IFSR feature is supported only on the following interface modules for Brocade MLX Series devices.

- BR-MLX-100Gx2-CFP2-X2
- BR-MLX-10Gx20-M (1G/10G combo) and BR-MLX-10Gx20-X2 (1G/10G combo)
- BR-MLX-10Gx4-IPSEC-M

**Examples** The following example enables IFSR.

```
device(config)# cam ifsr enable
```

The following example disables IFSR on slot 3 of the LP module.

```
device(config)# cam ifsr disable
IFSR is disabled on slot 3
```

**History**

---

**Release version**

**Command history**

---

05.8.00a

This command was introduced.

---

## cam-mode amod

Enables Algorithmic mode which optimizes the CAM space and power utilization and achieves -X2 CAM profile numbers.

**Syntax** `cam-mode amod slot number`

`no cam-mode amod slot number`

**Command Default** The TCAM mode (non-Algorithmic mode) is enabled by default.

**Parameters** **slot**

Specifies the line processor (LP) slot on which Algorithmic mode must be enabled.

*number*

Specifies the slot number.

**Modes** Global configuration mode

**Usage Guidelines** The line card must be reloaded for Algorithmic mode to take effect.

By default, BR-MLX-100Gx2-CFP2-X2, BR-MLX-10Gx20-X2, and BR-MLX-1GX20-U10G-X2 cards boot up with -M CAM profile numbers and if uRPF is enabled, the number of routes are reduced by half. You must enable Algorithmic mode to achieve -X2 CAM profile numbers. Algorithmic mode also supports uRPF mode to work without reducing the route scale.

The configuration will be ignored at the LP if the command is applied on a slot other than BR-MLX-100Gx2-CFP2-X2, BR-MLX-10Gx20-X2, and BR-MLX-1GX20-U10G-X2.

If Algorithmic mode is enabled on an empty slot, the line card inserted at a later stage will be initialized to Algorithmic mode.

The **no** form of the command disables Algorithmic mode.

---

### NOTE

Algorithmic mode is supported on MR2-X management modules only.

---

**Examples** The following example configures Algorithmic mode on slot 2.

```
device# configure terminal
device(config)# cam-mode amod slot 2
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00a        | This command was introduced. |

## clear access-list receive accounting

Clears IPv4 receive access-control list (rACL) accounting statistics.

**Syntax** `clear access-list receive accounting { all | name acl-name }`

**Parameters** **all**

Specifies clearing accounting statistics for all configured IPv4 rACLs.

**name** *acl-name*

Clears accounting statistics for the specified IPv4 rACL.

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command is also available in global configuration mode.

**Examples** The following example clears accounting statistics for an IPv4 rACL named `acl_ext1`.

```
device(config)# clear access-list receive accounting name act-ext1
```

**History**

| Release | Command History              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

## clear arp-guard-statistics

Clears the different statistical information of the ARP guard.

**Syntax** `clear arp-guard statistics ethernet { all | [ ethernet slot/port [ vlan vlan-id ] } | all ]`

**Command Default** Clears all statistics related to the ARP guard.

**Parameters** **all**

Clears all ARP guard statistics.

**ethernet slot/port**

Specifies the defined Ethernet port to clear.

**vlan/vlan\_id**

Specifies the defined VLAN information to clear. The VLAN ID range is between 1 and 4090.

**Modes** EXEC mode.

**Usage Guidelines** Use the **show arp-guard statistics** command to verify changes after executing the **clear arp-guard statistics** command.

**Examples** The following example indicates clearing statistics information for all the ports.

```
Brocade# clear arp-guard-statistics all
Brocade# show arp-guard statistics ethernet all

Port          Vlan-id  Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped  LAG : Prim
1/1 (Def/Untag)1          0                          0                          0
1/1          3          0                          0                          0
1/1          2          0                          0                          0
2/1 (Def/Untag)1          0                          0                          0
2/1          2          0                          0                          0
2/1          4          0                          0                          0
2/1          5          0                          0                          0
```

The following example indicates clearing statistics information for any individual ports.

```
Brocade# clear arp-guard-statistics ethernet 1/1
Brocade# show arp-guard statistics ethernet 1/1

Port          Vlan-id  Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped  LAG : Prim
1/1 (Def/Untag)1          0                          0                          0
0
1/1          3          0                          0                          0
0
1/1          2          0                          0                          0
0
```

The following example indicates clearing statistics information for VLAN ID 2 from port 1/1.

```
Brocade# clear arp-guard-statistics ethernet 1/1 vlan 2
Brocade# show arp-guard statistics ethernet 1/1 vlan 2

Port          Vlan-id  Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped  LAG : Prim
1/1          2          0                          0                          0
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.7.00          | This command was introduced. |

## clear bm histogram

Clears buffer histogram data.

**Syntax** `clear bm histogram`

**Modes** Privileged EXEC mode

**Usage Guidelines** The histogram information is collected and maintained internally, in a cyclical buffer. It can be reviewed to determine if resource allocation failures or task CPU usage may have contributed to an application failure.

The main objective of the buffer histogram is to see if there was any buffer exhaustion in the last few seconds (10-60sec). Buffer usage is collected when available buffers in the 2K buffer size pool fall below the reserved limit. Before starting another collection cycle, it may be useful to clear the histogram buffers using the **clear bm histogram** command. This command can also be entered in global configuration mode.

**Examples** The following example clears buffer histogram data.

```
device# clear bm histogram
```

### History

| Release | Command History              |
|---------|------------------------------|
| 5.5.00  | This command was introduced. |

## clear cpu histogram sequence

Clears CPU histogram sequential execution of task data.

**Syntax** `clear cpu histogram sequence`

`no clear cpu histogram sequence`

**Modes** Privileged EXEC mode.

Global configuration mode.

**Usage Guidelines** The CPU histogram provides information about task CPU usage. The histogram information is collected and maintained internally, in a cyclical buffer. It can be reviewed to determine if resource allocation failures or task CPU usage may have contributed to an application failure.

Before starting another collection cycle of task CPU usage, it may be useful to clear the existing CPU histogram information using the **clear cpu histogram sequence** command. This command can also be entered in global configuration mode.

To view the CPU histogram information, use the **show cpu histogram** command.

**Examples** The following example clears the CPU histogram sequential execution of task information.

```
device(config)# clear cpu histogram sequence
```

### History

| Release | Command History              |
|---------|------------------------------|
| 5.5.00  | This command was introduced. |

## clear dot1x-mka statistics

Clears the 802.1x (dot1x) MACsec Key Agreement (MKA) traffic statistics for the specified interface.

**Syntax** `clear dot1x-mka statistics ethernet slot/port`

**Parameters** `ethernet slot/port`  
Specifies an Ethernet interface and its slot on the device, and interface on the slot.

**Modes** Privileged EXEC mode

**Examples** In the following example, dot1x-MKA traffic statistics are cleared for interface 3/2.

```
device(config)# clear dot1x-mka statistics ethernet 3/2
dot1x-MKA statistics cleared
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.8.00          | This command was introduced. |



## clear ikev2 statistics

Clears the IKEv2 statistics from the device. This resets the various IKEv2 counters to zero. This command supports IPsec IPv4 and IPv6.

**Syntax** `clear ikev2 statistics`

**Modes** User EXEC mode.  
Privileged EXEC mode.

**Examples** The following example clears IKEv2 statistics from the device.

```
device# clear ike statistics
```

### History

| Release version | Command history                                          |
|-----------------|----------------------------------------------------------|
| 5.8.00          | This command was introduced.                             |
| 5.9.00          | This command was modified to add support for IPsec IPv6. |

## clear ikev2 sa

Clears the current IKEv2 Security Associations (SAs) on the device or on the specified local or remote interface. During the clearing process, the current SAs (including child SAs) are deleted and re-established. The SAs remain unchanged. This command supports IPsec IPv4 and IPv6.

| <b>Syntax</b>           | <b>clear ikev2 sa</b> { <b>fvrif</b> <i>vrf-name</i> } [ <b>local</b> <i>ip-address</i>   <i>ipv6-address</i> ] [ <b>remote</b> <i>ip-address</i>   <i>ipv6-address</i> ]                                                                                                                                                                                                                                                                                                                                                  |                 |                 |        |                              |        |                                                          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------|--------|------------------------------|--------|----------------------------------------------------------|
| <b>Parameters</b>       | <p><b>fvrif</b> <i>vrf-name</i><br/>Specifies the forward VRF (FVRF) name.</p> <p><b>local</b> <i>ip-address</i><br/>(Optional) Specifies the IPv4 address for the local interface.</p> <p><b>local</b> <i>ipv6-address</i><br/>(Optional) Specifies the IPv6 address for the local interface.</p> <p><b>remote</b> <i>ip-address</i><br/>(Optional) Specifies the IPv4 address for the remote interface.</p> <p><b>remote</b> <i>ipv6-address</i><br/>(Optional) Specifies the IPv6 address for the remote interface.</p> |                 |                 |        |                              |        |                                                          |
| <b>Modes</b>            | Privileged EXEC mode.<br>User EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                 |                 |        |                              |        |                                                          |
| <b>Usage Guidelines</b> | When you use this command, the IKE SAs are deleted and re-established (including all child SAs).<br>If you do not specify any local or remote interfaces using the optional parameters, all IPsec SA on the device are cleared.                                                                                                                                                                                                                                                                                            |                 |                 |        |                              |        |                                                          |
| <b>Examples</b>         | <p>The following example clears the IKE SAs on the device.</p> <pre>device# clear ikev2 sa</pre> <p>The following example clears the IKE SAs on the specified local interface (10.10.20.1).<br/>This example is for IPv4.</p> <pre>device# clear ikev2 sa local 10.10.20.1</pre> <p>The following example clears the IKE SAs on the specified remote interface (192.0.10.1).<br/>This example is for IPv4.</p> <pre>device# clear ikev2 sa remote 192.0.10.1</pre>                                                         |                 |                 |        |                              |        |                                                          |
| <b>History</b>          | <table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>5.8.00</td> <td>This command was introduced.</td> </tr> <tr> <td>5.9.00</td> <td>This command was modified to add support for IPsec IPv6.</td> </tr> </tbody> </table>                                                                                                                                                                                                                                   | Release version | Command history | 5.8.00 | This command was introduced. | 5.9.00 | This command was modified to add support for IPsec IPv6. |
| Release version         | Command history                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                 |                 |        |                              |        |                                                          |
| 5.8.00                  | This command was introduced.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                 |                 |        |                              |        |                                                          |
| 5.9.00                  | This command was modified to add support for IPsec IPv6.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                 |                 |        |                              |        |                                                          |

## clear ip vrrp statistics

Clears IPv4 Virtual Router Redundancy Protocol (VRRP) statistics.

**Syntax** `clear ip vrrp statistics`

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command can be entered in privileged EXEC mode and in any configuration mode. Entering the command in another configuration mode can be useful if you are configuring VRRP options, for example, and want to clear existing statistics.

**Examples** The following example clears IPv4 VRRP statistics when entered in privileged EXEC mode.

```
device# clear ip vrrp statistics
```

The following example clears IPv4 VRRP statistics when entered in virtual router interface configuration mode.

```
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(config-if-e1000-1/6)# ip address 10.53.5.1/24
device(config-if-e1000-1/6)# ip vrrp vrid 1
device(config-if-e1000-1/6-vrid-1)# clear ip vrrp statistics
```

## clear ip vrrp-extended statistics

Clears IPv4 Virtual Router Redundancy Protocol (VRRP) Extended (VRRP-E) statistics.

- Syntax** `clear ip vrrp-extended statistics`
- Modes** Privileged EXEC mode
- Usage Guidelines** This command can be entered in privileged EXEC mode and in any configuration mode. Entering the command in another configuration mode can be useful if you are configuring VRRP-E options, for example, and want to clear existing statistics.
- Examples** The following example clears IPv4 VRRP-E statistics when entered in privileged EXEC mode.

```
device# clear ip vrrp-extended statistics
```

The following example clears IPv4 VRRP-E statistics when entered in virtual router interface configuration mode.

```
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/5
device(config-if-e1000-1/5)# ip address 10.53.4.1/24
device(config-if-e1000-1/5)# ip vrrp-extended vrid 2
device(config-if-e1000-1/5-vrid-2)# clear ip vrrp-extended statistics
```

## clear ipsec error-count

Clears the error counters for the IPsec errors.

**Syntax** `clear ipsec error-count`

**Modes** Privileged EXEC mode.

**Examples** The following example clears the error counters for the IPsec errors.

```
device# clear ipsec error-count
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## clear ipsec sa

Clears the current IPsec Security Associations (SAs) on the device or on the specified peer interface. During the clearing process, the current SAs (including child SAs) are deleted and re-established. The SAs remain unchanged. This command supports IPsec IPv4 and IPv6.

**Syntax** `clear ipsec sa [ fvrf vrf-name ] [ peer ip-address ipv6-address]`

**Parameters**

- fvrf vrf-name** Specifies the front VRF (FVRF) name.
- peer ip-address** Specifies the IPv4 address for the peer interface.
- peer ipv6-address** Specifies the IPv6 address for the peer interface.

**Modes** Privileged EXEC mode.

**Usage Guidelines** When you use this command, the IKE SAs are deleted and re-established (including all child SAs). If you do not specify any peers using the optional parameters, all IPsec SAs on the device are cleared.

**Examples** The following example clears the IPsec SAs on the device.

```
device# clear ipsec sa
```

### History

| Release version | Command history                                          |
|-----------------|----------------------------------------------------------|
| 5.8.00          | This command was introduced.                             |
| 5.9.00          | This command was modified to add support for IPsec IPv6. |

## clear ipsec statistics

Clears IPsec system counters (such as ESP packet counts and IPsec error counts), and IPsec tunnel packet and byte counts (such as transmitted and received packets). This command supports IPsec IPv4 and IPv6.

**Syntax** `clear ipsec statistics [ all ]`

**Parameters** `all`

(Optional) Specifies that all IPsec statistics should be cleared (this includes system counters and IPsec tunnel packet counts and byte counts).

**Modes** User EXEC mode .

Privileged EXEC mode.

**Usage Guidelines** If you do not include the optional `all` parameter, only the system counters (such as ESP packet counts and IPsec error counts) are cleared. If you include the `all` parameter, the system counters and IPsec tunnel packet and byte counts are also cleared.

**Examples** The following example clears the IPsec system counters.

```
device# clear ipsec statistics
```

The following example clears all of the IPsec statistics, including system counters and IPsec tunnel packet and byte counts.

```
device# clear ipsec statistics all
```

### History

| Release version | Command history                                                |
|-----------------|----------------------------------------------------------------|
| 5.8.00          | This command was modified to add the <code>all</code> keyword. |
| 5.9.00          | This command was modified to add support for IPsec IPv6.       |

## clear ipsec statistics tunnel

Clears the IPsec tunnel packet and bytes counters.

**Syntax** `clear ipsec statistics tunnel dec | all`

**Parameters** *dec*

Clears the IPsec counter for the tunnel specified by its ID number.

**all**

Clears the IPsec counters for all tunnels.

**Modes** User EXEC mode.

Privileged EXEC mode.

**Examples** The following example clears the IPsec tunnel packet and bytes counters.

```
device# clear ipsec statistics tunnel
```

**History**

---

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

---



## clear ipv6 vrrp statistics

Clears IPv6 Virtual Router Redundancy Protocol (VRRP) statistics.

**Syntax** `clear ip vrrp statistics`

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command can be entered in privileged EXEC mode and in any configuration mode. Entering the command in another configuration mode can be useful if you are configuring IPv6 VRRP options, for example, and want to clear existing VRRP statistics.

**Examples** The following example clears IPv6 VRRP statistics when entered in privileged EXEC mode.

```
device# clear ipv6 vrrp statistics
```

The following example clears IPv6 VRRP statistics when entered in virtual router interface configuration mode.

```
device(config)# interface ethernet 1/6
device(config-if-e1000-1/6)# ipv6 vrrp vrid 1
device(config-if-e1000-1/6-vrid-1)# clear ipv6 vrrp statistics
```

## clear ipv6 vrrp-extended statistics

Clears IPv6 Virtual Router Redundancy Protocol (VRRP) Extended VRRP-E statistics.

- Syntax** `clear ip vrrp-extended statistics`
- Modes** Privileged EXEC mode.
- Usage Guidelines** This command can be entered in privileged EXEC mode and in any configuration mode. Entering the command in another configuration mode can be useful if you are configuring IPv6 VRRP-E options, for example, and want to clear existing VRRP-E statistics.
- Examples** The following example clears IPv6 VRRP-E statistics when entered in privileged EXEC mode.

```
device# clear ipv6 vrrp-extended statistics
```

The following example clears IPv6 VRRP-E statistics when entered in virtual router interface configuration mode.

```
device(config)# interface ethernet 1/5
device(config-if-e1000-1/5)# ipv6 3003::2:2\24
device(config-if-e1000-1/5)# ipv6 vrrp-extended vrid 2
device(config-if-e1000-1/5-vrid-2)# clear ipv6 vrrp-extended statistics
```

## clear macsec statistics

Clears the MACsec traffic statistics for the specified interface.

**Syntax** `clear macsec statistics ethernet ethernet slot/port`

**Parameters** `ethernet slot/port`  
Specifies an Ethernet interface by slot on the device, and interface on the slot.

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command operates in all modes.

**Examples** In the following example, MACsec traffic statistics are cleared for interface 3/2.

```
device(config)# clear macsec statistics ethernet 3/2
MACsec statistics cleared
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# clear memory histogram

Clears memory histogram data.

**Syntax** `clear memory histogram`

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command operates in all modes.

The memory histogram keeps track of each memory allocation/deallocation request from an application. It helps to identify memory leak and memory usage across the task. It also monitors the under usage condition and reports to the system. The memory histogram is recorded when available memory goes below the threshold limit on each memory pool.

Before starting another collection cycle, it may be useful to clear the existing memory histogram information using the **clear memory histogram sequence** command. This command can also be entered in global configuration mode.

To view the memory histogram information, use the **show memory histogram** command.

**Examples** The following example clears memory histogram data.  
`device(config)# clear memory histogram`

**History**

| Release | Command History             |
|---------|-----------------------------|
| 5.5.00  | This command was introduced |

## clear metro mp-vlp-queue

Resets the management processor virtual line card (MP-VLP) queue statistics on Brocade NetIron CER Series devices.

**Syntax** `clear metro mp-vlp-queue`

**Modes** Privileged EXEC mode.

**Usage Guidelines** this command operates in all modes.

**Examples** This example clears all the counters in the MP-VLP queue statistics.

```
device# clear metro mp-vlp-queue
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00a         | This command was introduced. |

## clear mpls auto-bandwidth-samples

Deletes the sample-history from the auto-bandwidth LSPs.

**Syntax** `clear mpls auto-bandwidth-samples [ all | lsp lsp_name ]`

**Parameters** **all**

Clear all of the auto-bandwidth sample history.

**lsp *lsp\_name***

Clears the auto-bandwidth sample history for the specified LSP.

**Modes** Privileged EXEC mode.

**Usage Guidelines** Samples are not deleted or deallocated when the LSP is disabled or when auto-bandwidth is disabled at the global or LSP level.

**Examples** The following example shows the command used to clear all of the auto-bandwidth sample history.

```
device# clear mpls auto-bandwidth-samples all
```

**History**

| Release | Command history              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

# clear mpls rsvp statistics session

Clears RSVP session statistics.

**Syntax** `clear mpls rsvp statistics session` { [ **destination** *ip\_addr* ] } [ **source** *source\_ip* ] [ **tunnel-id** *tunnel\_id* **lsp-id** *lsp\_id* ] | { **name** *session\_name* } } { **p2mp** **p2mp-id** [ *ip\_addr* | *dec* ] } [ **source** *source\_ip* ] [ **tunnel-id** *tunnel\_id* **lsp-id** ]

**Parameters**

**destination** *ip\_addr*  
Defines the destination IP address.

**source** *source\_ip*  
Defines the source IP address.

**tunnel** *tunnel\_id*  
Defines the tunnel by decimal number 1 - 65535.

**lsp-id** *lsp\_id*  
Defines the LSP by decimal number 1 - 65535.

**name** *session\_name*  
Clears the session by name.

**p2mp** **p2mp-id**  
Clears the point to multipoint sessions.

*ip\_addr*  
Specifies the P2MP identifier as an IP address

*dec*  
Specifies the P2MP identifier as a decimal.

**Modes** Privileged EXEC mode.

**Usage Guidelines** This command operates in all modes.

**Examples** The following example clears the RSVP session statistics for the `lsp_test` session.

```
device(config)# clear mpls rsvp statistics session
device(config)# clear mpls rsvp statistics session destination 11.11.11.11
device(config)# clear mpls rsvp statistics session destination 11.11.11.11 source
14.14.14.14
device(config)# clear mpls rsvp statistics session destination 11.11.11.11 source
14.14.14.14 tunnel-id 10
device(config)# clear mpls rsvp statistics session name lsp_test
device(config)# clear mpls rsvp statistics session p2mp p2mp-id 1.1.1.1 source
1.1.1.1 tunnel-id 1
```

## History

| Release version | Command history                                                                                                                         |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| 5.9.00          | This command was modified to provide the same statistics that are available at the global and interface level at the per-session level. |

## clear mpls statistics

Clears MPLS statistics.

**clear mpls statistics 6pe** [ *slot/port* | **vrf** ]

**clear mpls statistics bypass-lsp** *lsp\_name*

**clear mpls statistics label** [ *num* | *slot/port* ]

**clear mpls statistics ldp** [ **transit** | **tunnel** ]

**clear mpls statistics lsp** *lsp\_name*

**clear mpls statistics oam**

**clear mpls statistics rsvp** [ **neighbor** | **session** ]

**clear mpls statistics tunnel** *num*

**clear mpls statistics vll** [ *vll\_id* | *vll\_name* ]

**clear mpls statistics vll-local** [ *vll\_local\_id* | *vll\_local\_name* ]

**clear mpls statistics vpls** [ *vpls\_id* | *vpls\_name* ]

**clear mpls statistics vrf** *vrf\_name*

### Parameters

#### **6pe**

Clears 6pe statistics.

*slot /port*

Interface slot and port number.

**vrf**

Clears IPv6 VRF statistics.

#### **bypass-lsp**

Clears statistics for bypass LSPs.

*lsp\_name*

Name of targeted LSP.

#### **label**

Clears in-label statistics.

*num*

In-label.

*slot/port*

Interface number.

#### **ldp**

Clears ingress tunnel accounting for LDP signaled LSP.

**transit**

Clears transit traffic statistics for LDP.

**tunnel**

Clears ingress tunnel accounting for LDP created tunnels.



|                       |                                                         |
|-----------------------|---------------------------------------------------------|
| <b>lsp</b>            | Clears ingress tunnel accounting for RSVP signaled LSP. |
| <i>lsp_name</i>       | Name of targeted LSP.                                   |
| <b>oam</b>            | Clears OAM statistics.                                  |
| <b>rsvp</b>           | Clears transit statistics for RSVP signaled LSP.        |
| <b>neighbor</b>       | Clears statistics for RSVP neighbor.                    |
| <b>session</b>        | Clears transit statistics for RSVP sessions.            |
| <b>tunnel</b>         | Clears MPLS tunnel statistics.                          |
| <i>num</i>            | Tunnel interface index.                                 |
| <b>vll</b>            | Clears VLL statistics.                                  |
| <i>vll_id</i>         | VLL identifier.                                         |
| <i>vll_name</i>       | Name of VLL.                                            |
| <b>vll-local</b>      | Clears VLL local statistics.                            |
| <i>local_vll_id</i>   | Local VLL identifier.                                   |
| <i>local_vll_name</i> | Name of local VLL.                                      |
| <b>vpls</b>           | Clears VPLS statistics.                                 |
| <i>vpls_id</i>        | VPLS identifier.                                        |
| <i>vpls_name</i>      | Name of VPLS.                                           |
| <b>vrf</b>            | Clears VRF statistics.                                  |
| <i>vrf_name</i>       | Name of VRF.                                            |

**Modes** Privileged EXEC mode.

**Examples** The following example clears bypass LSPs statistics:

```
device# clear mpls statistics bypass-lsp
Cleared statistics of bypass LSPs
```

| History | Release version | Command history                                                     |
|---------|-----------------|---------------------------------------------------------------------|
|         | 5.7.00          | This command was modified to include the <b>bypass-lsp</b> keyword. |

# clear openflow

Clears flows from the flow table.

**Syntax** `clear openflow { flowid flow-id | all }`

**Parameters** `flowid flow-id`

`all` Clears the given flow ID that you want to delete from the flow table.

`all`

Deletes all flows from the flow table.

**Modes** User EXEC mode

Privileged EXEC mode

Global configuration mode

**Usage Guidelines** When an OpenFlow rule or all flows in the flow table need to be deleted you can use the **clear openflow** command with the **all** option. To delete a single OpenFlow rule based on a flow-id, use the **clear openflow** command with the **flowid *flow-id*** options.

**Examples** The following example clears the flow with an ID of 6.

```
device# clear openflow flowid 6
```

The following example clears all flows in the flow table.

```
device# clear openflow all
```

## History

---

| Release | Command History |
|---------|-----------------|
|---------|-----------------|

|            |                                                                                                                  |
|------------|------------------------------------------------------------------------------------------------------------------|
| NI05.5.00c | This command was modified to delete a single flow on a specified flow-id or all flow deletion in the flow table. |
|------------|------------------------------------------------------------------------------------------------------------------|

---

## clear pki counters

Clears the Public Key Infrastructure (PKI) counters for a certificate authority (CA).

**Syntax** `clear pki counters`

**Modes** PKI trustpoint configuration mode.

**Examples** The following example clears the PKI counters for the CA.

```
device(config)# pki trustpoint brocadel  
device(config-pki-trustpoint-brocadel)# clear pki counters
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## clear pki crl

Removes the certificate revocation list (CRL) database for a specific trustpoint name.

**Syntax** `clear pki crl trustpoint name`

**Parameters** *trustpoint name*  
Specifies the trustpoint name whose CRL database has to be removed.

**Modes** PKI trustpoint configuration mode.

**Examples** The following example removes the CRL database for the specified trustpoint name.

```
device(config)# pki trustpoint brocade1
device(config-pki-trustpoint-brocadel)# clear pki crl Trustpoint1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## clear rate-limit counters bum-drop

Clears the accounting information for the Broadcast, Unicast, Multicast (BUM) traffic rate limit.

**Syntax** `clear rate-limit counters bum-drop [portid ] [ vlanid ]`

`clear rate-limit counters bum-drop [ shutdown ] [portid ] slot/port [ all ] [vlan-id ] [ vlan ]]`

**Parameters** *portid*

Optionally clears the accounting information for BUM rate-limiting for the specified port.

*vlanid*

Optionally clears the accounting information for BUM rate-limiting for the specified VLAN.

**Modes** Privileged EXEC configuration mode

**Usage Guidelines** This command is used to clear rate-limiting accounting information for BUM traffic and, optionally, for specified interfaces or VLANs.

**Examples** The following example clears the BUM rate-limiting information for VLAN 2.

```
device# clear rate-limit counters bum-drop vlan2
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

## clear rate-limit counters ip-option-pkt-to-cpu

Clears the rate-limit counters for IPv4 option packets.

**Syntax** `clear rate-limit counters ip-option-pkt-to-cpu`

**Modes** This command operates in all mode.

**Examples** The following example shows how to clear the rate-limit counters for IPv4 option packets.

```
Brocade# clear rate-limit counters ip-option-pkt-to-cpu
```

### History

| Release version                          | Command history              |
|------------------------------------------|------------------------------|
| Multi-Service IronWare Release<br>5.8.00 | This command was introduced. |

## clear rate-limit counters ipv6-hoplimit-expired-to-cpu

Clears the rate-limit counters for IPv6 hoplimit-expired-to-cpu packets.

**Syntax** `clear rate-limit counters ipv6-hoplimit-expired-to-cpu`

**Modes** This command operates in all mode.

**Examples** The following example shows how to clear the rate-limit counters for hoplimit-expired-to-cpu packets.

```
Brocade# clear rate-limit counters ipv6-hoplimit-expired-to-cpu
```

### History

| Release version                       | Command history              |
|---------------------------------------|------------------------------|
| Multi-Service IronWare Release 5.8.00 | This command was introduced. |



## clear rate-limit counters ip-ttl-expired-to-cpu

Clears the rate-limit counters for IPv4 ttl-expired-to-cpu packets.

**Syntax** `clear rate-limit counters ip-ttl-expired-to-cpu`

**Modes** This command operates in all mode.

**Examples** The following example shows how to clear the rate-limit counters for ip-ttl-expired-to-cpu.

```
Brocade# clear rate-limit counters ip-ttl-expired-to-cpu
```

### History

| Release version                          | Command history              |
|------------------------------------------|------------------------------|
| Multi-Service IronWare Release<br>5.8.00 | This command was introduced. |

## clear statistics openflow

Clears OpenFlow statistics.

| <b>Syntax</b>           | <b>clear statistics openflow { group   meter   controller }</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |         |                 |           |                              |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|-----------------|-----------|------------------------------|
| <b>Parameters</b>       | <p><b>group</b> Clears statistics for all groups.</p> <p><b>meter</b> Clears statistics for all meters.</p> <p><b>controller</b> Clears statistics for all controllers.</p>                                                                                                                                                                                                                                                                                                                                                                                              |         |                 |           |                              |
| <b>Modes</b>            | EXEC and Privileged EXEC mode<br>Global configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |         |                 |           |                              |
| <b>Usage Guidelines</b> | This command can be entered in three configuration modes as shown in the examples below.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |         |                 |           |                              |
| <b>Examples</b>         | <p>The following example, entered in User EXEC mode, clears statistics for all groups in User EXEC mode.</p> <pre>device&gt; clear statistics openflow group</pre> <p>The following example, entered in Privileged EXEC mode, clears statistics for all meters in Privileged EXEC mode.</p> <pre>device&gt; enable device# clear statistics openflow meter</pre> <p>The following examples, entered in global configuration mode, clears statistics for all controllers.</p> <pre>device# configure terminal device(config) # clear statistics openflow controller</pre> |         |                 |           |                              |
| <b>History</b>          | <table border="1"> <thead> <tr> <th>Release</th> <th>Command History</th> </tr> </thead> <tbody> <tr> <td>NI05.7.00</td> <td>This command was introduced.</td> </tr> </tbody> </table>                                                                                                                                                                                                                                                                                                                                                                                   | Release | Command History | NI05.7.00 | This command was introduced. |
| Release                 | Command History                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |         |                 |           |                              |
| NI05.7.00               | This command was introduced.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |         |                 |           |                              |

## cluster-client-static-mac-move

Enables the static MAC address movement from the local Cluster Client Edge Port (CCEP) to the Inter-Chassis Link (ICL) port in the MAC cluster and vice versa.

**Syntax** `cluster-client-static-mac-move`

`no cluster-client-static-mac-move`

**Modes** MCT cluster configuration mode

**Usage Guidelines** This command must be configured in both the MCT peers but the static MAC address under the VLAN must be configured on any one of the MCT peers.

The **no** form of the command disables the static MAC address movement from the local CCEP to the ICL port.

**Examples** The following example enables the static MAC address movement from the local CCEP to the ICL port (and vice versa) in the MAC cluster named "brocade" with the cluster ID set as 1.

```
device(config)# cluster brocade 1
device(config-cluster-brocade)# cluster-client-static-mac-move
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## copy

Copies a file from a source device to a destination server (usually remote) or from a server (source) to a Brocade device (destination). This command can also be used to upload or download a configuration file. Each syntax instance is slightly different for the various operations.

**Syntax** `copy source protocol { ipv4-address | ipv6-address } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename device-filename`

`copy protocol destination { ipv4-address | ipv6-address } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename device-filename`

`copy config-file protocol { ipv4-address | ipv6-address } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename`

`copy protocol config-file { ipv4-address | ipv6-address } [ public-key { dsa | rsa } ] [ remote-port ] remote-filename`

### Parameters

*source*

Specifies the location of the file on the source device to be copied to the server. Can be one of the following: **flash**, **scp**, **slot1**, or **slot2** depending on the device. CES and CER devices support only the flash option.

*protocol*

Specifies the protocol to be used. Can be one of the following: **flash**, **http**, **https**, or **scp**.

*destination*

Specifies the location on the destination device where the file is to be copied from the server. Can be one of the following: **flash**, **scp**, **slot1**, **slot2**, depending on the device. CES and CER devices support only the **flash** option.

*ipv4-address*

Specifies the IPv4 address of the server.

*ipv6-address*

Specifies the IPv6 address of the server.

*remote-filename*

Specifies the name of the file to be used on the remote server. You can specify up to 127 characters for the file name.

*device-filename*

Specifies the name of the file to be used on the local device. Certain filenames are reserved and the system will not allow you to use them.

*config-file*

Specifies the configuration file to be used. Can be either **running-config** or **startup-config**.

### Modes

Privileged EXEC mode

### Usage Guidelines

You are prompted for *username* and *password* when you execute this command. The maximum length is 48 characters for each.

Please note that each syntax instance is different and is used to perform the following actions:

- Upload a copy of a file from a Brocade device (source) using a specified protocol to a server (destination) using the first syntax
- Download a copy of a file from a server (destination) using a specified protocol to a Brocade device (source) using the second syntax

- Upload a configuration file using the third syntax
- Download a configuration file using the fourth syntax

---

**NOTE**

When downloading a file to flash, the destination filename cannot be same as any of the reserved file names in flash. CLI will throw the following error when destination filename is any of the reserved file name: Error: Destination file name(%s) cannot be same as any of the reserved file names in flash.

---

**Examples** The following example uploads a copy of an OS image file from the primary flash memory on a device to an SCP server with the IP address of 172.26.51.180:

```
device# copy scp slot1 172.26.51.180 public-key dsa image-filename primary
```

The following example downloads a copy of a file from an SCP server to a Brocade device with the IP address of 10.20.99.146

```
device# copy flash scp 10.20.99.146 ~/xmr05800.bin primary
```

The following example uploads a copy of the image file “startup-config” from the primary flash memory on a device to a file named “startup-config-srv.txt” on an HTTP server with the IP address of 172.26.51.180:

```
device# copy flash http 172.26.51.180 startup-config-srv.txt startup-config
```

The following example downloads a copy of the image file “startup-config-srv.txt” from the HTTP server with the IP address of 172.26.51.180 to a “startup-config” file on slot2 of the device.

---

**NOTE**

When downloading, the system will not allow you to use certain filenames as a destination (target) filename.

---

```
device# copy http slot2 172.26.51.180 startup-config-srv.txt startup-config-dev.txt
```

## copy-received-cos

Classifies and prioritizes the management traffic for QoS.

**Syntax** `copy-received-cos protocol`

**Parameters**

|        |                                |
|--------|--------------------------------|
| SSH    | Specifies the SSH protocol.    |
| Telnet | Specifies the Telnet protocol. |

| <b>History</b> | <b>Release version</b> | <b>Command history</b>       |
|----------------|------------------------|------------------------------|
|                | 5.7.00                 | This command was introduced. |

## common-name

Specifies the common name parameter for the Public Key Infrastructure (PKI) entity.

**Syntax** `common-name name`

**Parameters** `name`

Specifies the common name parameter for the PKI entity.

**Modes** PKI entity configuration mode

**Examples** The following example specifies the common name parameter for the PKI entity.

```
device(config)# pki entity brocade_entity
device(config-pki-entity-brocade_entity)# common-name brocade_e
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

## country-name

Configures the country code for the Public Key Infrastructure (PKI) entity.

- Syntax** `country-name name`
- Parameters** `name`  
Specifies the country code for the PKI entity.
- Modes** PKI entity configuration mode
- Usage Guidelines** The country code is specified as a standard two-character code for a country. For example, IN can be the country code for India and US for United States of America.
- Examples** The following example configures the India country code for the PKI entity.

```
device(config)# pki entity brocade_entity
device(config-pki-entity-brocade_entity)# country-name IN
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |



## crl-query

Sets the certificate revocation list (CRL) URL name if the revocation check is configured as CRL in the device.

**Syntax** `crl-query URL name`

`no crl-query URL name`

**Parameters** *URL name*

The CRL URL name.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The **no** form of the command removes the specified CRL URL name.

**Examples** The following example specifies the CRL URL name as provided.

```
device(config)# pki trustpoint brocade1
device(config-pki-trustpoint-brocade1)# crl-query http://WIN-
HJ98AK136A0.englab.brocade.com/CertEnroll/englab-WIN-HJ98AK136A0-CA-7.crl
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## crl-update-time

Sets the certificate revocation list (CRL) update period for a certificate.

**Syntax** `crl-update-time hours`

`no crl-update-time hours`

**Command Default** The CRL update period depends on the next update field in the CRL file.

**Parameters** *hours*

The CRL update period value in hours. Valid values range from 1 through 1000 hours.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The `no` form of the command removes the specified CRL update time.

**Examples** The following example specifies the CRL update time as 10 hours.

```
device(config)# pki trustpoint brocade1
device(config-pki-trustpoint-brocadel)# crl-update-time 10
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

# cspf-computation-mode

Configures the IS-IS ignore overload bit.

**Syntax** `cspf-computation-mode [ ignore-overload-bit | use-bypass-liberal | use-bypass-metric | use-igp-metric | use-te-metric ]`

`no cspf-computation-mode [ ignore-overload-bit | use-bypass-liberal | use-bypass-metric | use-igp-metric | use-te-metric ]`

**Command Default** By default, this command is disabled.

**Parameters** `ignore-overload-bit`

Ignores the overload bit during CSPF computation.

`use-bypass-liberal`

Uses the liberal mode for CSPF facility backup computation.

`use-bypass-metric`

Uses the bypass LSPs path for cost for selection between bypass LSPs.

`use-igp-metric`

Uses the IGP metric of the link for CSPF computation.

`use-te-metric`

Uses the TE metric of the link for CSPF computation.

**Modes** MPLS policy configuration mode

**Usage Guidelines** The **no** form of the command allows CSPF to reject the path transiting through and overloaded router from the ingress.

Configuring this command will indicate that all the future CSPF calculations through an overloaded transit router are not rejected.

Because the command is at the global level, it will affect all the LSPs.

**Examples** The following example configures the software to ignore the overload bit during CSPF computation. The output of the **show mpls config** command verifies the configuration.

```
device(config-mpls-policy)# cspf-computation-mode ignore-overload-bit
device(config-mpls-policy)#show mpls config
router mpls
  policy
    traffic-eng isis level-1
    handle-isis-neighbor-down
    cspf-computation-mode ignore-overload-bit
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## cspf-computation-mode (LSP level)

Configures the CSPF computation mode for RSVP LSPs.

**Syntax** `cspf-computation-mode [ use-igp-metric | use-te-metric ]`

`no cspf-computation-mode [ use-igp-metric | use-te-metric ]`

**Command Default** By default, LSP uses the CSPF computation mode from the global configuration at MPLS policy level.

**Parameters** `use-igp-metric`

Uses the IGP metric of the link for CSPF computation.

`use-te-metric`

Uses the TE metric of the link for CSPF computation

**Modes** Primary, secondary, and at static bypass LSP context level under the router MPLS mode.

**Usage Guidelines** The `cspf-computation-mode` command configures the computation mode for CSPF to use TE-metric or IGP-metric at primary, secondary, and static bypass LSP levels by overriding global LSP configuration.

The `no` version of this command will set the CSPF computation to use the global configuration from router MPLS policy level.

**Examples** The following example explains configuration of CSPF computation mode to use TE-metric or IGP-metric at LSP level.

```
device(config)# router mpls
device(config-mpls)# lsp test
device(config-mpls-lsp-test)# cspf-computation-mode ?
    use-igp-metric      use IGP metric of the link for CSPF computation
    use-te-metric       use TE metric of the link for CSPF computation
```

```
device(config-mpls-lsp-test)# cspf-computation-mode use-igp-metric
```

```
device(config-mpls-policy)# no cspf-computation-mode use-te-metric
Error:CSPF computation is configured to use igp-metric
```

```
device(config-mpls-policy)# no cspf-computation-mode use-igp-metric
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.6.00          | This command was introduced. |

## database-overflow-interval (OSPFv3)

Configures frequency for monitoring database overflow.

**Syntax** `database-overflow-interval interval`

`no database-overflow-interval`

**Command Default** 10 seconds. If the router enters OverflowState, you must reboot before the router leaves this state.

**Parameters** `interval`

Time interval at which the device checks to see if the overflow condition has been eliminated. Valid values range from 0 through 86400 seconds (24 hours).

**Modes** OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** This command specifies how long after a router that has entered the OverflowState before it can resume normal operation of external LSAs. However, if the external link state database (LSDB) is still full, the router lapses back into OverflowState.

When the maximum size of the LSDB is reached (this is a configurable value in the *external-lsdb-limit* CLI), the router enters OverflowState. In this state, the router flushes all non-default AS-external-LSAs that the router had originated. The router also stops originating any non-default external LSAs. Non-default external LSAs are still accepted if there is space in the database after flushing. If no space exists, the Non-default external LSAs are dropped and not acknowledged.

If the configured value of the database overflow interval is 0, then the device never leaves the database overflow condition.

Enter **no database-overflow-interval** to disable the overflow interval configuration.

**Examples** This example configures a database-overflow interval of 120 seconds.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# database-overflow-interval 120
```

## dead-interval

Configures the interval that a Virtual Router Redundancy Protocol (VRRP) backup router waits for a hello message from the VRRP master router before determining that the master is offline. When backup routers determine that the master is offline, the backup with the highest priority becomes the new VRRP master router.

**Syntax** **dead-interval** [ msec ] *interval*

**no dead-interval** [ msec ] *interval*

**Command Default** The default dead interval is internally derived from the hello interval. It is equal to 3 times the hello interval + skew time, where skew time is equal to (256 - priority) divided by 256.

**Parameters** **msec** *interval*

Sets the interval, in milliseconds, that a VRRP backup router waits for a hello message from the VRRP master router before determining that the master is offline. Valid values range from 100 through 84000 milliseconds. The default value is 1000 milliseconds. VRRP-E does not support the dead interval in milliseconds.

*interval*

Sets the interval, in seconds, that a VRRP backup router waits for a hello message from the VRRP master router before determining that the master is offline. Valid values range from 1 through 84 seconds. The default value is 1 second.

**Modes** Virtual-router-group configuration mode

**Usage Guidelines** The **no** form disables the advertisement of a VRRP backup router to a VRRP master router.

The dead interval is internally derived from the hello interval, by default. It is equal to 3 times the hello interval + skew time, where skew time is equal to (256 - priority) divided by 256. Generally, if you change the hello interval on the VRRP master device using the **hello-interval** command, you also should change the dead interval using the **dead-interval** command on the VRRP backup devices.

A VRRP master router periodically sends hello messages to the backup routers. The backups use the hello messages as verification that the master is still online. If the backup routers stop receiving the hello messages for the period of time specified by the dead interval, the backup routers determine that the master router is offline. At this point, the backup router with the highest priority becomes the new master router.

The **dead-interval** command is configured only on VRRP backup routers and supported by VRRP and VRRP-E.

---

### NOTE

VRRP-E does not support the hello message interval in milliseconds.

---

**Examples** The following example sets the waiting period before a VRRP backup router determines a VRRP master router is offline to 25000 milliseconds.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# backup priority 40 track-priority 10
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.5.99
device(conf-if-e1000-1/6-vrid-1)# dead-interval msec 25000
device(conf-if-e1000-1/6-vrid-1)# activate
```

The following example sets the waiting period before a VRRP-E backup router determines a VRRP master router is offline to 25 seconds.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ip address 10.53.5.3/24
device(conf-if-e1000-1/5)# ip vrrp-extended vrid 2
device(conf-if-e1000-1/5-vrid-2)# backup priority 50 track-priority 10
device(conf-if-e1000-1/5-vrid-2)# ip-address 10.53.5.1
device(conf-if-e1000-1/5-vrid-2)# dead-interval 25
device(conf-if-e1000-1/5-vrid-2)# activate
```

## default-link-metric

Configures the metric value globally on all active IPv4 IS-IS interfaces.

**Syntax** **default-link-metric** *value* [ **level-1** | **level-2** ]

**no default-link-metric** *value* [ **level-1** | **level-2** ]

**Command Default** The **default-link-metric** command is disabled by default.

**Parameters** **default-link-metric**

Specifies the global default-link-metric parameter for an IPv4 IS-IS unicast address family configuration.

**value**

Specifies the default-link-metric value in metric style and configurable range. The metric style consists of narrow or wide style. The narrow metric range is from 1 - 63. The wide metric range is from 1 - 16777215. If you change the metric style configuration, the default-link-metric value will also change. The new default-link-metric value is equal to the minimum of the configured value, and the maximum value supported by the new metric style. For example, if the metric style changes from a wide metric to a narrow metric, and the default-link-metric value is greater than 63, the default-link-metric value changes to 63 because it is the maximum value supported in the narrow metric style. When the metric style changes from a narrow metric to a wide metric, there is no change to the default-link-metric value.

**level-1 | level-2**

Specifies the IS-IS routing parameter as level-1 or level-2. You can choose to configure the default-link-metric parameter as either level-1 or level-2. If the IS-IS routing parameter is not configured, the default-link-metric value is applied to both level-1 and level-2.

**Modes** IPv4 IS-IS unicast address family configuration level.

**Usage Guidelines** Use the **default-link metric value** command to change the metric value globally on all active IPv4 IS-IS interfaces. The **default-link metric value** command is useful when you have a common IS-IS metric value on all IS-IS interfaces, other than the default metric value of 10. The command enables the metric value for IPv4 routes per address family configuration. Use the **no** form of the command to reset the metric value to the default value 10. The **default-link metric value** command is not applicable to MPLS IS-IS shortcuts and tunnel interfaces.

You can change the metric value for a specific interface using the **isis metric** command or the **isis ipv6** command. The **isis metric** command configuration takes precedence over the **default-link metric value** command configuration.

During switchover or hitless upgrade, the IS-IS default link metric configuration is not affected. Backward compatibility is not supported.

---

### NOTE

The **default-link metric value** command is supported on the Brocade NetIron XMR Series, the Brocade MLX Series, and the Brocade NetIron CER Series and Brocade NetIron CES Series platforms.

---



**Examples** The following example configures the IS-IS default link metric value to 30 for an IPv4 address family. The default-link-metric value of 30 is applied to both level-1 and level-2.

```
device(config)# router isis
device(config-isis-router)# address-family-ipv4 unicast
device(config-isis-router-ipv4u)# default-link-metric 30
device(config-isis-router-ipv4u)#
```

The following example configures the IS-IS default link metric value to 30 for level-1, and the IS-IS default link metric value of 40 to level-2.

```
device(config)# router isis
device(config-isis-router)# address-family-ipv4 unicast
device(config-isis-router-ipv4u)# default-link-metric 30 level-1
device(config-isis-router-ipv4u)# default-link-metric 40 level-2
```

Use the **show isis** command to display the configuration for the IS-IS default link metric value.

```
device(config)# show isis
....
Default redistribution metric: 0
Default link metric for level-1: 33 (conf)/ 33 (adv)
Default link metric for level-2: 5 (conf)/ 5 (adv)
Protocol Routes redistributed into IS-IS:
....
```

#### History

| Release version | Command history              |
|-----------------|------------------------------|
| \5.7.00         | This command was introduced. |

## default-metric (OSPF)

Sets the default metric value for the OSPFv2 or OSPFv3 routing protocol.

**Syntax** `default-metric metric`

`no default-metric`

**Command Default** The default metric value for the OSPFv2 or OSPFv3 routing protocol is 10.

**Parameters** *metric*

OSPF routing protocol metric value. Valid values range from 1 through 65535.

**Modes** OSPF router configuration mode  
OSPFv3 router configuration mode  
OSPF router VRF configuration mode  
OSPFv3 router VRF configuration mode

**Usage Guidelines** This command overwrites any incompatible metrics that may exist when OSPFv2 or OSPFv3 redistributes routes. Therefore, setting the default metric ensures that neighbors will use correct cost and router computation.

Enter **no default-metric** to return to the default setting.

**Examples** This example sets the default metric to 20.

```
device# configure terminal
device(config)# router ospf
device(config-ospf6-router)# default-metric 20
```

## default-passive-interface

Marks all OSPFv2 and OSPFv3 interfaces passive by default.

**Syntax** **default-passive-interface**

**no default-passive-interface**

**Modes** OSPF router configuration mode  
 OSPFv3 router configuration mode  
 OSPF router VRF configuration mode  
 OSPFv3 router VRF configuration mode

**Usage Guidelines** When you configure the interfaces as passive, the interfaces drop all the OSPFv2 and OSPFv3 control packets.

You can use the **ip ospf active** and **ip ospf passive** commands in interface subconfiguration mode to change active/passive state on specific OSPFv2 interfaces. You can use the **ipv6 ospf active** and **ipv6 ospf passive** commands in interface subconfiguration mode to change the active and passive state on specific OSPFv3 interfaces.

Use the **no** form of this command to disable it.

**Examples** This example marks all OSPFv2 interfaces as passive.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# default-passive-interface
```

This example marks all OSPFv3 interfaces as passive for VRF "red".

```
device# configure terminal
device(config)# ipv6 router ospf vrf red
device(config-ospf6-router-vrf-red)# default-passive-interface
```

## delete-certificate

Deletes all the trustpoint certificates or a specific certificate associated with a trustpoint.

- Syntax** `delete-certificate [ certificate-serial-number ]`
- Parameters** *certificate-serial-number*  
Specifies the serial number of the certificate.
- Modes** PKI trustpoint configuration mode.
- Usage Guidelines** When the local certificate is deleted, the existing established IKEv2 SA are not affected but any new IKEv2 SA establishment is not allowed if x509v3 certificate is needed for authentication.

---

### NOTE

This command is applicable only for certificates downloaded from CA server.

---

- Examples** The following example deletes a specific trustpoint certificate.

```
device(config)# pki-trustpoint test
device(config-pki-trustpoint-test)# delete-certificate fe:75:d1:a3:bc:56:28:8e
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# disable authenticate md5

Disables the MD5 authentication scheme for Network Time Protocol (NTP).

**Syntax**    **disable authenticate md5**

**no disable authenticate md5**

**Command Default**    If JITC is enabled, the MD5 authentication scheme is disabled. In the standard mode, the MD5 authentication scheme is enabled.

**Modes**    NTP configuration mode.

**Usage Guidelines**    In the standard mode, both SHA1 and MD5 authentication schemes are supported. If JITC is enabled using the **jitc enable** command, the MD5 authentication for Network Time Protocol (NTP) is disabled by default and the **disable authenticate md5** command can be seen in the running configuration. In the JITC mode, only the SHA1 authentication option is available. The SHA1 authentication scheme must be enabled manually by configuring the authentication key for NTP using the **authentication-key** command and an example of configuring this command is shown below.

The **no** form of the command enables the MD5 authentication scheme.

**Examples**    The following example disables the MD5 authentication scheme.

```
device# configure terminal
device(config)# ntp
device(config-ntp)# disable authenticate md5
```

The following example enables SHA1 authentication for NTP.

```
device# configure terminal
device(config)# ntp
device(config-ntp)# authentication-key key-id 20 sha1 keystring
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## distance (OSPF)

Configures an administrative distance value for OSPFv2 and OSPFv3 routes.

**Syntax** `distance { external | inter-area | intra-area } distance`

`no distance`

**Command Default** The administrative distance value for OSPFv2 and OSPFv3 routes is 110.

**Parameters** `external`

Sets the distance for routes learned by redistribution from other routing domains.

`inter-area`

Sets the distance for all routes from one area to another area.

`intra-area`

Sets the distance for all routes within an area.

`distance`

Administrative distance value assigned to OSPF routes. Valid values range from 1 through 255. The default is 110.

**Modes** OSPF router configuration mode

OSPFv3 router configuration mode

OSPF router VRF configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** You can configure a unique administrative distance for each type of OSPF route.

The distances you specify influence the choice of routes when the device has multiple routes from different protocols for the same network. The device prefers the route with the lower administrative distance. However, an OSPFv2 or OSPFv3 intra-area route is always preferred over an OSPFv2 or OSPFv3 inter-area route, even if the intra-area route's distance is greater than the inter-area route's distance.

Enter **no distance** to return to the default setting.

**Examples** This example sets the distance value for all external routes to 125.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# distance external 125
```

This example sets the distance value for intra-area routes to 80.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# distance intra-area 80
```

This example sets the distance value for inter-area routes to 90.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# distance inter-area 90
```

## display-pkt-bit-rate

Displays the Packet and Bit rate statistics for the policy based routing.

**Syntax** **display-pkt-bit-rate**  
**no display-pkt-bit-rate**

**Command Default** None.

**Modes** ACL policy sub-configuration mode (config-acl-policy).

**Usage Guidelines** When deploying this command, a new display format displays the PBR statistics. Otherwise, the old or existing CLI display format is used (only packet rate statistics are displayed).

This configuration stores in the configuration file.

**Examples** The following example shows how the new format can be enabled using the CLI command:

```
device(config-acl-policy) #display-pkt-bit-rate
```

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.8.00          | This command is introduced. |

## dot1ag-transparent

Forwards non-CCM packets without altering the packet prioritization at the ingress.

**Syntax** **dot1ag-transparent**

**no dot1ag-transparent**

**Command Default** The command is not enabled by default.

**Modes** Global configuration mode.

**Usage Guidelines** When IEE 802.1ag CFM is not configured for the device, the priority of non-CCM packets can change due to Protocol Packet Prioritization (PPP) at the ingress. Since the node needs to forward the packet without altering the packet priority, Brocade recommends using this command when forwarding non-CCM packets.

The **no** form of the command reverts the command behavior back to default; non-CCM packets are forwarded with altered packet prioritization.

The command is saved upon reload.

---

### NOTE

The command is supported on Brocade NetIron XMR Series and Brocade NetIron MLX Series devices.

---

**Examples** The following example forwards the non-CCM packet without altering the packet priority.

```
device(config)# dot1ag-transparent
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |



# dot1x-key

Configures switch port to dynamically obtain MKA keys from RADIUS server.

**Syntax** **dot1x-key**

**no dot1x-key**

**Command Default** By default, this command is disabled.

**Modes** Macsec ethernet and group configuration mode

**Usage Guidelines** The **dot1x-key** command is effective only if the interface is dot1x-enabled using the **dot1x-enable** command.

---

## NOTE

An MKA configuration group should be attached to the interface before applying dot1x-key configuration on the interface.

---

The **no** form of the command disables dot1x-key configuration from the port.

**Examples** The following example configures dot1x-key on Ethernet interface 1/1.

```
device# configure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# enable-mka ethernet 1/1
device(config-dot1x-mka-eth-1/1)# dot1x-key
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# dot1x-mka-enable

Enables MACsec Key Agreement (MKA) capabilities on a Brocade device and enters dot1x-mka configuration mode.

**Syntax** **dot1x-mka-enable**

**no dot1x-mka-enable**

**Command Default** By default, MACsec MKA capabilities are not enabled.

**Modes** Global configuration mode

**Usage Guidelines** When the **dot1-mka-enable** command is disabled, all the configurations under that mode are deleted. If MKA is disabled, all the ports go into a down state. To bring the ports back to online, you must manually enable each port.

The **no** form of this command disables the MKA and MACsec functionality on all ports.

**Examples** The following example enables MACsec MKA capabilities is enabled on the device.

```
device# configure terminal
device(config)# dot1x-mka-enable
Brocade(config-dot1x-mka)#
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# ekeypair

Specifies which Elliptic Curve key pair to use during enrollment.

**Syntax** `ekeypair { key-label label | encryption-key-size encryption key-size | key-size key-size }`

**Parameters** **key-label** *label*

Specifies the name of the key pair generated during enrollment. The name is specified if it is not already existing or if the **auto-enroll regenerate** command is configured.

**encryption-key-size** *encryption key-size*

Specifies the size of the second key that is generated to request separate encryption, signature keys, and certificates.

**key-size***key-size*

Specifies the size of the desired EC key pair. If the key size is not specified, the existing key size is used. The supported values are 256 and 384.

**Modes** PKI trustpoint configuration mode

**Usage Guidelines** The key pair is obtained by importing from the key file that has a specific label.

**Examples** The following example specifies which EC key pair to use during enrollment.

```
device(config)# pki-trustpoint test
device(config-pki-trustpoint-test)# ekeypair key-label brocade
```

The following example specifies the encryption key size.

```
device(config)# pki-trustpoint test
device(config-pki-trustpoint-test)# ekeypair encryption-key-size 100
```

The following example specifies the desired EC key size of 256.

```
device(config)# pki-trustpoint test
device(config-pki-trustpoint-test)# ekeypair key-size 256
```

**History**

| Release version | Command history                                                                               |
|-----------------|-----------------------------------------------------------------------------------------------|
| 05.8.00         | This command was introduced.                                                                  |
| 05.8.00b        | This command was modified to add the <b>encryption-key-size</b> and <b>key-size</b> keywords. |

## egress-truncate

Enables the truncation of egress packets for a port.

**Syntax** **egress-truncate**

**no egress-truncate**

**Command Default** The command is not enabled by default. The specified size of the truncated packet is set globally using the **egress-truncate-size** command.

**Modes** This command is used at the config level.

**Usage Guidelines** The **no** form of the command disables truncation on the specific port. The **egress-truncate** command is supported for LAG ports.

**Examples** The **egress-truncate-size** command enables truncation on all ports that are members of the LAG. The following example shows both LAG configuration and enabling truncate

```
device(config)# lag lag1 static id 1
device(config-lag-lag1)# ports Ethernet 1/1 to 1/4
device(config-lag-lag1)# primary Ethernet 1/1
device(config-lag-lag1)# deploy
```

```
device(config-if-1/1)# egress-truncate
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## egress-truncate-size

Sets the size of the truncated egress packets globally.

**Syntax** **egress-truncate-size** *value* **slot** [*all* |*slot\_no* [ <*device\_id*>]]

**no egress-truncate-size**

**Command Default** The command disabled by default. When enabled, the default setting is 64 bytes.

**Parameters** **value**

The packet size in bytes after being truncated.

*slot\_no*

An optional value for the slot number.

*device\_id*

An optional value for the device ID.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of this command disables truncating globally. Use the **egress-truncate** command to enable truncation. The **egress-truncate-size** command is supported globally for LAG ports.

**Examples** The command must be enabled on a port or LAG using the **egress-truncate** command. The following example sets the size of the truncated egress packets to 200 bytes on all slots.

```
Brocade(config)#egress-truncate-size 200 slot all
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## email

Configures the email ID for the Public Key Infrastructure (PKI) entity.

**Syntax** `email string`

`no email string`

**Parameters** `string`

Specifies the email ID for the PKI entity.

**Modes** PKI entity configuration mode.

**Usage Guidelines** The `no` form of the command removes the configured email ID.

**Examples** The following example configures the email ID (user@brocade.com) for the PKI entity.

```
device(config)# pki entity test
device(config-pki-entity-test)# email user@brocade.com
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## enable-mka

Enables MACsec Key Agreement (MKA) on a specified interface and changes the mode to dot1x-mka-interface mode to enable related parameters to be configured.

**Syntax** `enable-mka ethernet slot/port [ to slot/port ]`

`no enable-mka ethernet slot/port [ to slot/port ]`

**Command Default** MKA is not enabled on an interface.

**Parameters** `ethernet slot port`

Specifies an Ethernet interface and the slot on the device, and the port on that slot.

**Modes** dot1x-mka-interface mode

**Usage Guidelines** For a MACsec channel to be created between two ports, both ports and devices designated must have MACsec enabled and configured.

The **no** form of the command removes MACsec from the port.

---

### NOTE

Primary port configuration will not be applied to all secondary ports in a LAG. LAG member ports should have individual configurations to enable MACsec.

---

**Examples** The following example enables MACsec on Ethernet interface 1/1.

```
device(config-dot1x-mka)# enable-mka ethernet 1/1
device(config-dot1x-mka-eth-1/1)#
```

The following example configures MKA on multiple ports and enters the multiple interface configuration mode.

```
device(config-dot1x-mka)# enable-mka ethernet 1/1 to 1/10
device(config-dot1x-mka-mif-eth-1/1-1/10)#
```

### History

---

#### Release version

#### Command history

---

5.8.00

This command was introduced.

---

# encryption

Configures the encryption algorithm used to protect IKEv2 data.

**Syntax** `encryption { aes-cbc-128 | aes-cbc-256 }`

`no encryption { aes-cbc-128 | aes-cbc-256 }`

**Parameters** `aes-cbc-128`

Specifies the 128-bit advanced encryption standard cipher block chaining algorithm.

`aes-cbc-256`

Specifies 256-bit advanced encryption standard cipher block chaining algorithm.

**Modes** IKEv2 proposal configuration mode

**Usage Guidelines** The `no` form of the command removes the encryption algorithm.

**Examples** The following example configures the encryption algorithm used to protect IKEv2 data.

```
device(config)# ikev2 proposal brocade
device(config-ikev2-proposal-brocade)# encryption aes-cbc-256
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |



# enrollment

Configures the enrollment information such as retry count, retry period, or profile for the polling interval for the certificate authority (CA).

**Syntax** `enrollment { retry-count count | retry-period period | profile profile name }`

`no enrollment { retry-count count | retry-period period | profile profile name }`

**Parameters** **retry-count**

*count* Specifies the retry count value to get the CA.

*count*

The retry count value in numbers. Valid numbers range from 1 through 100. The default is 10.

**retry-period**

*period* Specifies the time period to keep trying to get the CA.

*period*

The time period value in minutes. Valid numbers range from 1 through 60 minutes. The default is 1 minute.

**profile**

*profile name* Specifies the profile name to get the CA.

*profile name*

The profile name specified to get the CA.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The **no** form of the command disables the device from configuring enrollment options.

When the device configures the **enrollment** command for a second time to request the CA, the retry period between requests increases exponentially, with an additional 1 minute interval added at every increment.

**Examples** The following example specifies the retry count value as 11.

```
device(config)# pki trustpoint brocadel
device(config-pki-trustpoint-brocadel)# enrollment retry-count 11
```

The following example specifies the retry period of 2 minutes to get the CA.

```
device(config)# pki trustpoint brocadel
device(config-pki-trustpoint-brocadel)# enrollment retry-period 2
```

The following example specifies the profile name as "Jane".

```
device(config)# pki trustpoint brocadel
device(config-pki-trustpoint-brocadel)# enrollment Jane
```

**History**

---

**Release version**

**Command history**

5.9.00

This command was introduced.

---

## esn-enable

Configures the Extended Sequence Number (ESN) for IPsec.

- Syntax**    **esn-enable**  
**no esn-enable**
- Modes**    IPsec proposal configuration mode.
- Usage Guidelines**    The **no** form of the command disables the ESN.
- Examples**    The following example configures the ESN for IPsec.

```
device(config)# ipsec proposal brocade
device(config-ipsec-proposal-brocade)# esn-enable
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## exclude-interface

The user can create a bypass LSP by using the `bypass-lsp` command. The bypass LSP is the specification of excluded interfaces, which can be embodied as individual interfaces, ranges of interfaces, groups, or LAGs. Using this command the user can choose the interface to avoid as well as protect.

**Syntax** `exclude-interface { ethernet slot/port [ ethernet slot/port | to slot/port ] | pos slot/port [ pos slot/port | to slot/port ] | ve interface_id }`

**no exclude-interface { ethernet slot/port [ ethernet slot/port | to slot/port ] | pos slot/port [ pos slot/port | to slot/port ] | ve interface\_id }**

**Command Default** By default, an interface is not protected.

**Parameters** `ethernet slot/port`

Specifies Ethernet port.

`to slot/port`

Specifies the receiving port.

`pos slot/port`

Specifies the selected individual POS interface port.

`to slot/port`

Specifies the receiving port.

`ve interface_id`

Specifies the selected Virtual Ethernet (VE) interface.

**Modes** MPLS bypass LSP sub-configuration mode

**Usage Guidelines** This is used for facility backup FRR. In the context of bypass LSP, the user can configure an MPLS interface as an exclude (protected) interface against resource failures using a bypass LSP. The user can specify a VE interface as exclude-interface. When a protected LSP egress interface is a VE interface, then any fault on a VE interface could trigger FastReroute. The following example configures protection for MPLS interface `ve 100` using facility backup FRR.

The **no** form of the command removes the bypass LSP.

**Examples** The following example displays the command.

```
device# configure terminal
device(config)# router-mpls
device(config-mpls)# bypass-lsp 123
device(config-mpls-bypasslsp-123)# exclude-interface ethernet 1/1 ethernet 1/3
device(config-mpls-bypasslsp-123)# exclude-interface ethernet 1/1 ethernet 1/3 to 1/4
```

## external-lsdb-limit (OSPFv3)

Configures the maximum size of the external link state database (LSDB).

|                         |                                                                                                                                                                                                                                               |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>external-lsdb-limit</b> <i>value</i><br><br><b>no external-lsdb-limit</b>                                                                                                                                                                  |
| <b>Command Default</b>  | 250000                                                                                                                                                                                                                                        |
| <b>Parameters</b>       | <i>value</i><br><br>Maximum size of the external LSDB. Valid values range from 1 through 250000.                                                                                                                                              |
| <b>Modes</b>            | OSPFv3 router configuration mode<br>OSPFv3 router VRF configuration mode                                                                                                                                                                      |
| <b>Usage Guidelines</b> | If you change the value, you must save the running-config file and reload the software. The change does not take effect until you reload or reboot the software.<br><br>Enter <b>no external-lsdb-limit</b> to return to the default setting. |
| <b>Examples</b>         | This example sets the limit of the external LSDB to 15000.<br><br><pre>device# configure terminal device(config)# ipv6 router ospf device(config-ospf6-router)# external-lsdb-limit 15000</pre>                                               |

## ext-stats-mode slot

Enables the extended statistics mode to display QinQ VLAN statistics.

**Syntax** `ext-stats-mode slot { number }`

`no ext-stats-mode slot { number }`

**Command Default** The extended statistics mode is not enabled.

**Parameters** *number*

Specifies the interface module slot number for a 32-slot chassis (1-32), a 16-slot chassis (1-16), an 8-slot chassis (1-8), and a 4-slot chassis (1-4).

**Modes** Global configuration mode

**Usage Guidelines** Use this command to enable egress QinQ statistics when the extended counters are configured for a particular VPLS, VLL, or VLL-local instance. Extended statistics is enabled for ingress QinQ statistics by default. This CLI is added to support egress QinQ statistics. The QinQ statistics support is enabled only for QinQ VLANs configured under VPLS, VLL, and VLL-local.

This command configuration is supported on the Brocade MLX Series and Brocade NetIron XMR Series devices. On the BR-MLX-10Gx24 interface module, only the ingress QinQ statistics extended counters are supported. Gen1.1 modules are not supported.

When the command is enabled, the number of counters supported for egress port VLAN statistics per NP is reduced to 8191. There is no change to the number of counters for ingress. When the command is not enabled for QinQ statistics, the number of counters supported for ingress and egress does not change. The following table details the number of egress port VLAN counters supported on both ingress and egress counters, before and after enabling the **ext-stats-mode slot** command.

| Switched and routed packets | Account based on internal priority of packet | Number of unique egress port-VLAN that have counters (pre-5.9)    | Number of unique egress port-VLAN counters after enabling QinQ statistics mode |
|-----------------------------|----------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------------------------------------|
| Switch and Route combined   | No                                           | 32767 on ingress and 32767 on egress; each set having 8 counters. | 32767 on ingress and 8191 on egress; each set having 1 counter.                |
| Switch and Route combined   | Yes                                          | 4095 on ingress and 4095 on egress; each set having 8 counters.   | 4095 on ingress and 4095 on egress; each set having 8 counters.                |
| Switch or Route separately  | No                                           | 16383 on ingress and 16383 on egress; each set having 2 counters. | 16383 on ingress and 8191 on egress; each set having 2 counters.               |
| Switch or Route separately  | Yes                                          | 2047 on ingress and 2047 on egress; each set having 16 counters.  | 2047 on ingress and 2047 on egress; each set having 16 counters.               |

You must reload the interface module for the command to go into effect. A warning message of the required reload is displayed when the command is executed.

A syslog and warning message is generated if all 8191 egress statistics are utilized on a specific LP. A warning message similar to the following is displayed:

"Warning: Extended-Counter Egress Stats ID allocation failed for VPLS Eth 2/1 Vlan Id 200, Inner Vlan Id 500 "

There is a set number of counters supported per NP from hardware. If you receive this message, you can move the ports to the other NP. Each vport (port-VLAN combination) utilizes one statistics ID.

The **show mpls statistics vpls** and **clear mpls statistics vpls** commands are modified to include the parameter **inner-vlan** *vlan-id*. The parameter specifies the ID of the configured inner VLAN. If the **inner-vlan/vlan-id** parameter is not specified, the output displays vlan statistics only. To display specific tx/egress statistics, the **ext-stats-mode** command must be enabled for the LP module. If the command is not enabled for a specific slot, the QinQ statistics displays an NA value for ports of that slot.

The **no** form of the command disables the extended statistics mode to display QinQ VLAN statistics.

**Examples** The following example enables the extended statistics mode to display QinQ VLAN statistics on interface module slot 4.

```
device(config)# ext-stats-mode slot ?
DECIMAL  LP slot (32-slot: 1-32, 16-slot: 1-16; 8-slot: 1-8; 4-slot: 1-4)
device(config)# ext-stats-mode slot 4
Please write memory. LP-2 reload is required for ext-stats-mode enable/disable to
take effect.
```

Use the **show running-config** command to display the configuration for the **ext-stats-mode** command.

```
device(config)# show running-config | inc ext-stats-mode
ext-stats-mode slot 1
ext-stats-mode slot 2
ext-stats-mode slot 3
ext-stats-mode slot 4
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

# Commands F - J

---

## fingerprint

Configures the fingerprint for the Certificate Authority (CA).

**Syntax** `fingerprint hex-data`

**Parameters** `hex-data`

Specifies the hex data for the fingerprint in the xx:xx:xx:xx format.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** When the CA sends the certificate, it should match the fingerprint configured for the certificate to be accepted.

**Examples** The following example configures the fingerprint for the CA.

```
device(config)# pki-trustpoint test
device(config-pki-trustpoint-test)# fingerprint 81:b7:d4:ab:05:53:fd:
64:05:18:09:36:94:82:b3:56:bc:93:74:c3
```

### History

---

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

---

## fqdn

Configures the fully qualified domain name (FQDN) for the PKI entity.

**Syntax** `fqdn string`

**Parameters** `string`

Specifies the FQDN for PKI entity.

**Modes** PKI entity configuration mode.

**Examples** The following example configures the FQDN for the PKI entity.

```
device(config)# pki entity brocade_entity
device(config-pki-entity-brocade_entity)# fqdn red
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |



# garp-ra-interval

Sets the interval between gratuitous ARP (GARP) router advertisements when Virtual Router Redundancy Protocol Extended (VRRP-E) scaling is configured.

**Syntax** `garp-ra-interval interval`

`no garp-ra-interval interval`

**Command Default** Gratuitous ARP router advertisements are sent every 30 seconds.

**Parameters** `interval`

Sets the gratuitous ARP router advertisements interval timer, in seconds. Values range from 30 to 120 seconds. Default is 30 seconds.

**Modes** Global configuration mode

**Usage Guidelines** This command is used with the VRRP-E scaling feature where VRRP-E instances are grouped and hello messages between group members are stopped to reduce the CPU load and allow more VRRP-E instances to be configured. Gratuitous ARP messages are still sent by the group master on behalf of its members to advertise the virtual MAC address to devices on the network, but at a longer intervals.

The **no** form of this command resets the default value of 30 seconds between gratuitous ARP router advertisements.

**Examples** The following example sets the gratuitous ARP router advertisement interval to 90 seconds.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# garp-ra-interval 90
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# gig-default

Enables auto-negotiation support for 1G ports.

**Syntax** `gig-default { auto-gig | neg-off | auto-full | neg-full-auto }`

`no gig-default { auto-gig | neg-off | auto-full | neg-full-auto }`

**Command Default** The default value is auto.

**Parameters** **auto-gig**

The port tries to performs a negotiation with its peer port to exchange capability information. This is the default state.

**neg-off**

The port does not try to perform a negotiation with its peer port.

**auto-full**

The port tries to perform a negotiation with its peer port to exchange capability information. If it is unable to reach an agreed upon speed, the port goes into a fixed speed and keeps the link up.

**neg-full-auto**

The port is only for copper-SFP and to support 10/100/1000M tri-speed auto negotiation.

**Modes** EXEC mode.

**Usage Guidelines** Unless the ports at both ends of a Gigabit Ethernet link use the same mode (either auto-gig or neg-off), the ports cannot establish a link. An administrator must intervene to manually configure one or both sides of the link to enable the ports to establish the link.

The **no** form of the command disables *Remote Fault Notification (RFN)* after enabling.

Supports the following modules:

- 20x10GE
- 4x10GE-IPSEC

**Examples** The following example displays how to change the negotiation mode for individual port.

```
device(config)# interface ethernet 4/1 to 4/4
device(config-mif-4/1-4/4)# gig-default neg-off
```

**History**

| Release version | Command history                                                                   |
|-----------------|-----------------------------------------------------------------------------------|
| 5.8.00a         | This command was modified include the parameters <b>neg-off</b> and <b>auto</b> . |

## graceful-restart (OSPFv2)

Enables the OSPF Graceful Restart (GR) capability.

**Syntax** `graceful-restart [ helper-disable | restart-time seconds ]`

`no graceful-restart`

**Command Default** Graceful restart and graceful restart helper capabilities are enabled.

**Parameters** **helper-disable**

Disables the GR helper capability.

**restart-time**

Specifies the maximum restart wait time, in seconds, advertised to neighbors. The default value is 120 seconds. The configurable range of values is from 10 through 1800 seconds.

**Modes** OSPF router configuration mode

OSPF router VRF configuration mode

**Usage Guidelines** The **no** form of the **graceful-restart** command disables the graceful restart capability.

Use **no graceful-restart helper-disable** to re-enable the GR helper capability.

**Examples** The following example disables the GR capability.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# no graceful-restart
```

The following example disables the GR helper capability.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# graceful-restart helper-disable
```

The following example re-enables the GR helper capability.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# no graceful-restart helper-disable
```

The following example re-enables the GR capability.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# graceful-restart
```

The following example re-enables the GR capability and changes the maximum restart wait time from the default value to 240 seconds.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# graceful-restart restart-time 240
```

## graceful-restart helper (OSPFv3)

Enables the OSPFv3 graceful restart (GR) helper capability.

**Syntax** `graceful-restart helper { disable | strict-lsa-checking }`

**no graceful-restart helper**

**Command Default** GR helper is enabled.

**Parameters** **disable**

Disables the OSPFv3 GR helper capability.

**strict-lsa-checking**

Enables the OSPFv3 GR helper mode with strict link-state advertisement (LSA) checking.

**Modes** OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** Enter **no graceful-restart helper** to disable the GR helper capability on a device.

**Examples** This example enables GR helper and set strict LSA checking.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router-ospf)# graceful-restart helper strict-lsa-checking
```

This example enables GR helper and set strict LSA checking.

## group-master interface

Configures a Virtual Router Redundancy Protocol Extended (VRRP-E) device in interface configuration mode as the VRRP-E group master of a logical grouping of VRRP-E instances.

**Syntax** **group-master interface** { **ethernet** *slot/port* | **ve** *vrid* } **vrid** *id*

**no group-master interface** { **ethernet** *slot/port* | **ve** *vrid* } **vrid** *id*

**Command Default** No group master is configured.

**Parameters** **ethernet** *slot/port*

Configures the VRRP-E group master for the specified port.

**ve** *vrid*

Configures the VRRP-E group master for the specified virtual Ethernet port.

**vrid** *id*

Assigns the VRID of the group master for the specified port.

**Modes** Virtual router interface configuration mode.

**Usage Guidelines** This command is used as a grouping mechanism to allow the scaling of the number of VRRP extended (VRRP-E) instances up to 4000 instances. VRRP-E instances are configured into logical groups consistently across all the VRRP-E master and backup devices.

The **no** form of this command removes the grouping configuration.

**Examples** The following examples configures virtual router 1 on interface ve 1 as the VRRP-E group master of the virtual router 2 on interface ve 2.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ve 2
device(conf-vif-2)# ip address 10.53.5.1/24
device(conf-vif-2)# ip vrrp vrid 2
device(conf-vif-2-vrid-2)# group-master interface ve 1 vrid 1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## hello-interval (VRRP)

Configures the interval at which master Virtual Router Redundancy Protocol (VRRP) routers advertise their existence to the backup VRRP routers.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>hello-interval</b> [ msec ] <i>interval</i>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Command Default</b>  | Hello messages from VRRP master routers are sent every second to backup routers.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Parameters</b>       | <p><b>msec</b> <i>interval</i></p> <p>Interval, in milliseconds, at which a master VRRP router advertises its existence to the backup routers. Valid values range from 100 through 84000 milliseconds. Default is 1000 milliseconds. VRRP-E does not support the hello message interval in milliseconds.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Modes</b>            | Virtual-router-group configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Usage Guidelines</b> | <p>A VRRP master router periodically sends hello messages to the backup routers. The backups use the hello messages as verification that the master is still online. If the backup routers stop receiving the hello messages for the period of time specified by the dead interval, the backup routers determine that the master router is dead. At this point, the backup router with the highest priority becomes the new master router.</p> <p>The dead interval is internally derived from the hello interval, by default. It is equal to 3 times the hello interval + skew time, where skew time is equal to (256 - priority) divided by 256. Generally, if you change the hello interval using the <b>hello-interval</b> command, you also should change the dead interval using the <b>dead-interval</b> command on the VRRP backup routers.</p> <p>The <b>hello-interval</b> command is configured only on VRRP master routers and supported by VRRP and VRRP-E.</p> <p>The <b>no</b> form resets the hello message interval to its default value.</p> |

---

### NOTE

VRRP-E does not support the hello message interval in milliseconds.

---

**Examples** The following example enables advertisements from the VRRP master router and sets the hello message interval to 10000 milliseconds.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e10000-1/6)# ip address 10.53.5.1/24
device(conf-if-e10000-1/6)# ip vrrp vrid 1
device(conf-if-e10000-1/6-vrid-1)# owner
device(conf-if-e10000-1/6-vrid-1)# ip-address 10.53.5.1
device(conf-if-e10000-1/6-vrid-1)# hello-interval msec 10000
device(conf-if-e10000-1/6-vrid-1)# activate
```

The following example enables advertisements from the VRRP-E master router and sets the hello message interval to 15 seconds.

```
device# configure terminal
device(config)# router vrrp-extended
device(config)# interface ethernet 1/5
device(conf-if-e10000-1/5)# ip address 10.53.5.3/24
device(conf-if-e10000-1/5)# ip vrrp-extended vrid 2
device(conf-if-e10000-1/5-vrid-2)# backup priority 50 track-priority 10
device(conf-if-e10000-1/5-vrid-2)# ip-address 10.53.5.1
device(conf-if-e10000-1/5-vrid-2)# hello-interval 15
device(conf-if-e10000-1/5-vrid-2)# activate
```

## ike-profile

Configures the IKE profile attached with the IPsec profile.

| <b>Syntax</b>           | <b>ike-profile</b> <i>ike-profile-name</i><br><b>no ike-profile</b> <i>ike-profile-name</i>                                                                                                  |                 |                 |         |                              |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------|---------|------------------------------|
| <b>Parameters</b>       | <i>ike-profile-name</i><br>Specifies the IKE profile name attached with the IPsec profile.                                                                                                   |                 |                 |         |                              |
| <b>Modes</b>            | IPsec profile configuration mode                                                                                                                                                             |                 |                 |         |                              |
| <b>Usage Guidelines</b> |                                                                                                                                                                                              |                 |                 |         |                              |
| <b>Examples</b>         | The following example configures the IKE profile attached with IPsec profile.<br><pre>device(config)# ipsec profile brocade device(config-ipsec-profile-brocade)# ike-profile red</pre>      |                 |                 |         |                              |
| <b>History</b>          | <table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>05.8.00</td> <td>This command was introduced.</td> </tr> </tbody> </table> | Release version | Command history | 05.8.00 | This command was introduced. |
| Release version         | Command history                                                                                                                                                                              |                 |                 |         |                              |
| 05.8.00                 | This command was introduced.                                                                                                                                                                 |                 |                 |         |                              |



## ikev2 auth-proposal

Configures the IKEv2 authentication name and enters the authentication configuration mode.

**Syntax** **ikev2 auth-proposal** *auth-name*  
**no ikev2 auth-proposal** *auth-name*

**Parameters** *auth-name*  
 Specifies the IKEv2 authentication name for the IKEv2 profile.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command removes the configured IKEv2 authentication name.

**Examples** The following example configures the IKEv2 authentication.

```
device(config)# ikev2 auth-proposal secure
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.8.00          | This command was introduced. |

## ikev2 cookie-challenge

Enables the Internet Key Exchange version 2 (IKEv2) cookie challenge option.

**Syntax** `cookie-challenge number`  
`no cookie-challenge number`

**Command Default** By default, this command is disabled.

**Parameters** *number*  
 Specifies the maximum number of Security Associations (SA) supported. The maximum number of SAs supported are from 1 through 2000.

**Modes** Global configuration mode.

**Usage Guidelines** The command is enabled only when the maximum number of half-open IKE SAs go beyond the configured cookie challenge number.

The **no** form of the command disables the cookie challenge number.

**Examples** The following example configures an IKEv2 cookie challenge.

```
device(config)# ikev2 cookie-challenge 5
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# ikev2 dhgroup

Configures the group used for Diffie-Hellman (DH) negotiations.

**Syntax** `ikev2 dhgroup { 1 } { 2 } { 5 } { 14 } { 15 } { 16 } { 19 } { 20 } { 24 }`

|                   |           |                                                       |
|-------------------|-----------|-------------------------------------------------------|
| <b>Parameters</b> | <b>1</b>  |                                                       |
|                   | <b>2</b>  | Specifies the 768-bit DH group.                       |
|                   | <b>5</b>  | Specifies the 1024-bit DH group.                      |
|                   | <b>14</b> | Specifies the 1536-bit DH group.                      |
|                   | <b>15</b> | Specifies the 2048-bit DH group.                      |
|                   | <b>16</b> | Specifies the 3072-bit DH group.                      |
|                   | <b>19</b> | Specifies the 4096-bit DH group.                      |
|                   | <b>20</b> | Specifies the 256-bit elliptic curve DH (ECDH) group. |
|                   | <b>24</b> | Specifies the 384-bit ECDH group.                     |
|                   |           |                                                       |

**Modes** IKEv2 proposal configuration mode.

**Examples** The following example configures the group used for Diffie-Hellman (DH) negotiations.

```
device(config)# ikev2-proposal
device(config-ikev2-proposal)# ikev2 dhgroup 20
```

| <b>History</b> | <b>Release version</b> | <b>Command history</b> |
|----------------|------------------------|------------------------|
|                |                        | 5.8.00                 |

## ikev2 exchange-max-time

Configures the maximum setup time for a message exchange.

**Syntax** **ikev2 exchange-max-time** *seconds*  
**no ikev2 exchange-max-time** *seconds*

**Command Default** The default time is 30 seconds.

**Parameters** *seconds*  
 Specifies the maximum setup time in seconds. The time range is from 0 through 300 seconds.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command disables the maximum time that was configured for a message exchange.

**Examples** The following example configures the maximum setup time for a message exchange as 30 seconds.

```
device(config)# ikev2 exchange-max-time 30
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ikev2 http-url-cert

Configures the HTTP certification support.

**Syntax**    **ikev2 http-url-cert**  
               **no ikev2 http-url-cert**

**Command Default**    By default, this command is disabled.

**Modes**                Global configuration mode.

**Usage Guidelines**    The **no** form of the command removes the configured HTTP certification support.

**Examples**             The following example configures HTTP certification support.

```
device(config)# ikev2 http-url-cert
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ikev2 limit

Configures the limitation of the total number of in-negotiation IKEv2 Security Associations (SA).

**Syntax** **ikev2 limit** { **max-in-negotiation-sa** *limit* | **max-sa limit** *limit* }  
**no ikev2 limit** {**max-in-negotiation-sa** *limit* | **max-sa limit** *limit* }

**Command Default** The default limit is 256.

**Parameters** **max-in-negotiation-sa** *limit*  
 Limits the total number of in-negotiation IKEv2 SAs on the LP.

**max-sa limit** *limit*  
 Limits the total number of IKEv2 SAs on the LP. The maximum SAs supported limit ranges from 1 through 256.

**Modes** Global configuration mode.

### Usage Guidelines

**Examples** The following example configures limitation of the total number of in-negotiation IKEv2 SAs as 10.

```
device(config)# ikev2 limit max-in-negotiation-sa 10
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# ikev2 policy

Selects the IKEv2 policy (by name) to be used during IKE negotiation with remote endpoint, and selects the IKE proposal to attach to the policy. This command supports IPv4 and IPv6.

**Syntax** `ikev2 policy name`  
`no ikev2 policy name`

**Command Default** This command is not configured.

**Parameters** *name*  
 Specifies the IKEv2 policy to be used during IKE negotiation with remote endpoint.

*proposalname*  
 Specifies the IKEv2 proposal to attach to the policy. The proposal determines which security parameters are used to protect the negotiation messages.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command removes the selected IKEv2 policy.

Only one policy can be selected for a local endpoint (single IPv4 or IPv6 address). Multiple IKEv2 policies selected for the same IP address is an invalid configuration.

If multiple matching policies are identified during IKE negotiations, the first matching policy is used.

If you do not select an IKEv2 policy, the default policy is used to protect the IKE SA negotiation.

You should select a proposal to ensure that the security mechanisms you want are used to protect the negotiation messages. If you do not select a proposal, the default proposal is used.

**Examples** The following example configures the IKEv2 policy named *test1*.

```
device(config)# ikev2 policy test1
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ikev2 profile

Configures the specified IKEv2 profile and gives you the option of identifying the local endpoint of the tunnel. This command supports IPsec IPv4 and IPv6.

**Syntax** **ikev2 profile** { *name*[**local-identifier**{**address** [*ipv4-address* |*ipv6-address*]}[**dndn-string**]}[**fqdnfqdn-string**]}[ **key-id***key-id string*]}[**email***email-string*]}[**remote-identifier****address** *ipv4-address* |*ipv6-address*]**dndn-string**|**fqdnfqdn-string**| **key-id***key-id string*|**email***email-string*]

[**match identity****local****address**[*ipv4-address*|*ipv6-address*]**dndn-string**|**fqdnfqdn-string**| **key-id***key-id string*|**email***email-string*]

**no ikev2 profile** { *name*[**local-identifier****address** *ipv4-address* |*ipv6-address*]**dndn-string**|**fqdnfqdn-string**| **key-id***key-id string*|**email***email-string*]

**Command Default** This command is not configured.

**Parameters** *name*

Specifies the IKEv2 profile name.

**local-identifier**

(Optional) Identifies the local endpoint of the tunnel. You can identify the endpoint using the IP address, distinguished name (dn), fully qualified domain name (fqdn), key identifier (key-id), or email.

**address**[*ipv4-address*|*ipv6-address*]

Identifies the local endpoint of the tunnel using the IPv4 or IPv6 IP address.

**dnstring**

Identifies the local endpoint of the tunnel using the LDAP distinguished name.

**fqdnstring**

Identifies the local endpoint of the tunnel using the fully qualified domain name.

**key-idstring**

Identifies the local endpoint of the tunnel using the key identifier (ID).

**emailstring**

Identifies the local endpoint of the tunnel using the email address.

**remote-identifier**

(Optional) Identifies the remote endpoint of the tunnel. You can identify the endpoint using the IP address, distinguished name (dn), fully qualified domain name (fqdn), key identifier (key-id), or email.

**address**[*ipv4-address*|*ipv6-address*]

Identifies the remote endpoint of the tunnel using the IPv4 or IPv6 IP address.

**dnstring**

Identifies the remote endpoint of the tunnel using the LDAP distinguished name.

**fqdnstring**

Identifies the remote endpoint of the tunnel using the fully qualified domain name.

**key-idstring**

Identifies the remote endpoint of the tunnel using the key identifier (ID).

**emailstring**



Identifies the remote endpoint of the tunnel using the email address.

**match identity**

(Optional) Causes the IKE profile Peer Authorization Database (PAD) for the peers to be automatically selected based on the identity parameters received by the local or remote endpoints. The parameters you specify are used to select the PAD.

**Modes** Global configuration mode.

**Usage Guidelines** Using the command automatically enters IKEv2 profile configuration mode.

**Examples** The following example configures the IKEv2 profile named test1.

```
device(config)# ikev2 profile test1
```

**History**

| Release version | Command history                                                                                 |
|-----------------|-------------------------------------------------------------------------------------------------|
| 5.8.00          | This command was introduced.                                                                    |
| 5.9.00          | This command was modified to add support for IPsec IPv6 and to add the local identifier option. |

## ikev2 proposal

Configures the IKEv2 proposal parameter and enters the IKEv2 proposal configuration mode.

**Syntax** **ikev2 proposal** *name*  
**no ikev2 proposal** *name*

**Parameters** *name*  
 Specifies the IKEv2 proposal name.

**Modes** IKEv2 configuration mode.

### Usage Guidelines

**Examples** The following example configures the IKEv2 proposal name *test1*.

```
device(config)# ikev2 proposal test1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ikev2 retransmit-interval

Configures the delay time for re-sending the IKEv2 messages.

**Syntax** **ikev2 retransmit-interval** *time*  
**no ikev2 retransmit-interval** *time*

**Command Default** The default time is 5 seconds.

**Parameters** *time*  
 Specifies the delay time in seconds. The time ranges from 1 through 60 seconds.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command removes the configured delay time. The retransmit interval increases exponentially.

**Examples** The following example configures the delay time for re-sending IKEv2 messages as 20 seconds.

```
device(config)# ikev2 retransmit-interval 20
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ikev2 retry-count

Configures the maximum number of attempts to retransmit a message.

**Syntax** **ikev2 retry-count** *number*  
**no ikev2 retry-count** *number*

**Command Default** The default number of attempts is 5.

**Parameters** *number*  
 Specifies the maximum number of attempts. The count ranges from 1 through 25.

**Modes** Global configuration mode.

### Usage Guidelines

**Examples** The following example configures the number of attempts to 15 to retransmit a message.

```
device(config)# ikev2 retry-count 15
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# ike-profile

Configures the IKE profile attached with the IPsec profile.

**Syntax** **ike-profile** *ike-profile-name*  
**no ike-profile** *ike-profile-name*

**Parameters** *ike-profile-name*  
 Specifies the IKE profile name attached with the IPsec profile.

**Modes** IPsec profile configuration mode

## Usage Guidelines

**Examples** The following example configures the IKE profile attached with IPsec profile.

```
device(config)# ipsec profile brocade
device(config-ipsec-profile-brocade)# ike-profile red
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 05.8.00         | This command was introduced. |

## ingress-tunnel-accounting

Excludes the Ethernet header (14 bytes) and Ethernet overhead (20 bytes) and CRC overhead (four bytes) when collecting byte statistics. In other words, it counts only the size of the MPLS packet.

**Syntax** `ingress-tunnel-accounting exclude-ethernet-overhead`

`no ingress-tunnel-accounting exclude-ethernet-overhead`

**Command Default** None.

**Modes** MPLS policy configuration mode

**Usage Guidelines** The operation of the command, based on the operator input, can be defined as 'y' - the configuration change is done and the counters are cleared, or 'n' - the configuration change is not done and the counters are not cleared.

The command `no ingress-tunnel-accounting exclude-ethernet-overhead` disables only the `exclude-ethernet-overhead` option. To disable `ingress-tunnel-accounting` itself, enter the command `no ingress-tunnel-accounting`.

### History

| Release version | Command history                                                                                                                                                                                                              |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5.5.00          | This command was modified to enforce the clearing of counters when <code>exclude-ethernet-overhead</code> mode is changed, a confirmation message is added to the command and on execution, the command clears the counters. |
| 5.6.00          | This command modified the <code>exclude-ethernet-overhead</code> option, lets the operator exclude the Ethernet header and Ethernet overhead and CRC overhead when collecting the byte statistics.                           |

# In-label

Specifies the label that is received in the packets and used to identify the static transit LSP in the router. This, in turn, decides where the next hop will be based on the "next-hop" configuration.

**Syntax** **in-label** *value*

**no in-label** *value*

**Parameters** **value**

Represents the label received in the MPLS header in the packets from upstream. Acceptable ranges for the parameter include Static label min-value and Static label max-value. The value must not exceed the static label range configured on the router.

**Modes** MPLS-transit LSP sub-configuration mode.

**Examples** The following example displays the **in-label** command:

```
device# configure terminal
device(config)# router mpls
device(config-mpls)# static-transit t1
device(config-mpls-static-transit-t1)# in-label 16
```

# integrity

Specifies the integrity algorithm for the IKEv2 proposal.

| <b>Syntax</b>           | <b>integrity {sha256   sha384}</b><br><b>no integrity {sha256   sha384}</b>                                                                                                                  |                 |                 |         |                              |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------|---------|------------------------------|
| <b>Parameters</b>       | <p><b>sha256</b> Specifies SHA-2 family 256-bit (HMAC variant) as the hash algorithm.</p> <p><b>sha384</b> Specifies SHA-2 family 384-bit (HMAC variant) as the hash algorithm.</p>          |                 |                 |         |                              |
| <b>Modes</b>            | IKEv2 proposal configuration mode                                                                                                                                                            |                 |                 |         |                              |
| <b>Usage Guidelines</b> | The <b>no</b> form of the command removes the integrity algorithm that was specified earlier.                                                                                                |                 |                 |         |                              |
| <b>Examples</b>         | <p>The following example specifies the integrity algorithm sha256.</p> <pre>device(config)# ikev2 proposal brocade device(config-ikev2-proposal-brocade)# integrity sha256</pre>             |                 |                 |         |                              |
| <b>History</b>          | <table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>05.8.00</td> <td>This command was introduced.</td> </tr> </tbody> </table> | Release version | Command history | 05.8.00 | This command was introduced. |
| Release version         | Command history                                                                                                                                                                              |                 |                 |         |                              |
| 05.8.00                 | This command was introduced.                                                                                                                                                                 |                 |                 |         |                              |



# ip

Configures the IP address used in the certificate for the PKI entity.

**Syntax** `ip ip-address`  
`no ip ip-address`

**Parameters** `ip-address`  
 Specifies the IP address for the PKI entity.

**Modes** PKI entity configuration mode.

## Usage Guidelines

**Examples** The following example configures the IP address for the PKI entity.

```
device(config)# pki entity brocade
device(config-pki-entity-brocade)# ip 10.10.20.1
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ip allow-src-multicast

Allows packets with multicast addresses as source IP addresses.

**Syntax** `ip allow-src-multicast [decimal | all ]`

`no ip allow-src-multicast [decimal | all ]`

**Command Default** Packets with multicast addresses as source IP addressed are not forwarded.

**Parameters** *decimal*

Specifies the slot number on which multicast addresses as source IP addresses should be allowed.

**all**

Specifies all slots on which multicast addresses as source IP addresses are allowed.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of this command disables multicast addresses as source IP addresses. You cannot configure the **ip allow-src-multicast** command along with the **ip allow-src-multicast switched-traffic** command on the same slot.

**Examples** The following example allows all multicast addresses as source IP addresses for all traffic and for all slots.

```
device(config)# ip allow-src-multicast all
```

The following example shows allowing multicast IP addresses as source address for a particular slot.

```
device(config)# ip allow-src-multicast 2
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

# ip allow-src-multicast switched-traffic

Disables packet drop for switched traffic only.

**Syntax** `ip allow-src-multicast switched-traffic [decimal | all]`

`no ip allow-src-multicast switched-traffic [decimal | all]`

**Command Default** Packet drop for switched traffic is enabled.

**Parameters** *decimal*

Specifies the slot number on which the switched traffic should be allowed.

**all**

Specifies all slots on which switched traffic is allowed.

**Modes** Global configuration mode

**Usage Guidelines** You cannot configure the **ip allow-src-multicast switched-traffic** command and **ip allow-src-multicast** command on the same slot. The **no** form of this command enables packet drop for switched traffic.

**Examples** The following example allows multicast addresses as source IP addresses for switched traffic for a particular slot.

```
device(config)# ip allow-src-multicast switched-traffic 2
```

The following example allows multicast addresses as source IP addresses for switched traffic for all slots.

```
device(config)# ip allow-src-multicast switched-traffic all
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## ip arp-refresh-request-timer

Sets the ARP refresh request timer and enhances the ARP scaling number to 128k.

|                         |                                                                                                                                                |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>ip arp-refresh-request-timer</b> <i>num</i>                                                                                                 |
| <b>Command Default</b>  | None.                                                                                                                                          |
| <b>Parameters</b>       | <i>num</i><br>The length, in seconds, to set the timer. Timer values are 10 - 3600 seconds.<br>The default value is 120 seconds.               |
| <b>Modes</b>            | Sub-configuration mode (config).                                                                                                               |
| <b>Usage Guidelines</b> | Use the default value as minimum the value in scaled configuration.<br>The ARP request timer must be greater than the ARP pending retry timer. |
| <b>Examples</b>         | The following example displays the ARP refresh timer configuration:                                                                            |

```
device (config) #ip arp-refresh-request-timer
device (config) #ip arp-refresh-request-timer
device (config) #
device (config) #ip arp-ref
device (config) #ip arp-refresh-request-timer
device (config) #
```

### History

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.8.00          | This command is introduced. |

## ip http client connection timeout connect

This command sets the maximum time for the client to wait for the connection to be established while initiating a connection to the HTTP(S) server.

**Syntax** `ip http client connection timeout connect seconds`

`no ip http client connection timeout connect`

**Parameters** `seconds`

Specifies the amount of time in seconds that the client will wait for the connection to be established with the HTTP(S) server. Can be an integer value from 1 to 15. The default value is 5.

**Modes** Privileged EXEC mode

### Usage Guidelines

**Examples** The following example sets the time to the default value of 5 seconds.

```
device(config)# no ip http client connection timeout connect
```

The following example sets the time to 12 seconds.

```
device(config)# ip http client connection timeout connect 12
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |

## ip http client connection timeout idle

This command sets the maximum time for the client to keep the connection to the http(s) server idle before closing the connection.

**Syntax** `ip http client connection timeout idle [ seconds ]`

**Parameters** `seconds`  
Specifies the amount of time in seconds that the client will wait for the connection to be established with the http(s) server. Can be an integer value from 1 to 15. The default value is 5.

**Modes** Privileged EXEC mode

**Examples** The following example sets the time to the default value of 5 seconds.

```
device(config)# ip http client connection timeout idle
```

The following example sets the time to 12 seconds.

```
device(config)# ip http client connection timeout idle 12
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |

## ip http client source-interface

Configures the source-interface for the HTTP[S] client.

**Syntax** `ip http client source-interface { ethernet | loopback | ve } interface-number`

**Parameters** *interface-number*

Specifies the interface number for the source interface of the HTTP(S) client. When the *source-interface* is *ethernet*, the *interface-number* must be in the form *slot/port*. For loopback and logical interfaces, you must use an integer value for *interface-number*.

**Modes** Privileged EXEC mode

**Examples** The following example configures the source interface (slot 7, port 12) for the HTTP(S) client.

```
device(config)# ip http client source-interface ethernet 7/12
```

The following example configures the loopback interface for the HTTP(S) client.

```
device(config)# ip http client source-interface loopback 1
```

The following example configures the logical interface (2) for the HTTP(S) client.

```
device(config)# ip http client source-interface ve 2
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |

## ip multicast-routing load-sharing

Enables or disables load distribution among IP ECMP paths.

**Syntax** `ip multicast-routing load-sharing [ rebalance ]`

`no ip multicast-routing load-sharing [ rebalance ]`

**Parameters** `rebalance`

Specifies that the ECMP load-sharing will be re-balanced for the interface on which the **rebalance** keyword is configured.

**Modes** Interface configuration mode.

**Examples** To configure Multicast ECMP, use this command in the configuration mode.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# ip multicast-routing load-sharing
```

To disable load distribution among ECMP IP paths use the **no** form of the command.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# no ip multicast-routing load-sharing
```

The following example configures re-balancing of the load distribution among ECMP IP paths.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# ip multicast-routing load-sharing rebalance
```

### History

| Release | Command History              |
|---------|------------------------------|
| 5.5.00  | This command was introduced. |



## ip ospf bfd

Enables Bidirectional Forwarding Detection (BFD) on a specific OSPFv2 interface.

**Syntax** `ip ospf bfd disable`

`no ip ospf bfd`

**Command Default** BFD is disabled by default.

**Parameters** `disable`

Disables BFD on the OSPFv2 interface.

**Modes** Interface subtype configuration mode

**Usage Guidelines** BFD sessions are initiated if BFD is also enabled globally using the **bfd all-interfaces** command in OSPF router configuration mode. If BFD is disabled using the **no bfd all-interfaces** command in OSPF router configuration mode, BFD sessions on specific OSPFv2 interfaces are deregistered.

The **no** form of the command removes all BFD sessions from a specified interface.

**Examples** The following example enables BFD on a specific OSPF Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ip ospf bfd
```

The following example disables BFD on a specific OSPF Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ip ospf bfd disable
```

## ip rate-limit option-pkt-to-cpu policy-map

Applies rate-limit on IPv4 option packets.

**Syntax** `ip rate-limit option-pkt-to-cpu policy-map rate-limit policy`

`no ip rate-limit option-pkt-to-cpu policy-map rate-limit policy`

**Command Default** By default this command is disabled.

**Parameters** `policy-map rate-limit policy`

Specifies the name of the policy-map.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables rate-limiting on IPv4 option packets.  
Create CPU bound rate-limit policy map before applying rate-limiting for option packets.

---

### NOTE

The following warning message is displayed if only some of the cards are supported and few are not supported.

```
Warning: rate-limit config for protocol "option-pkt-to-cpu" is not supported on  
module 1, 3
```

The following warning message is displayed if none of the cards are supported.

```
Warning: rate-limit config for protocol "option-pkt-to-cpu" is not supported on  
available modules. It is only supported on GEN-2 and later modules.
```

---

**Examples** The following example explains how to apply rate-limit for IPv4 option packets.

```
device(config)#ip rate-limit option-pkt-to-cpu policy-map save-cpu-policy
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

---

## ip rate-limit ttl-expired-to-cpu policy-map

Applies rate-limit option on IPv4 ttl packets, if the ttl count is less than or equal to one.

**Syntax** `ip rate-limit ttl-expired-to-cpu policy-map rate-limit policy`

`no ip rate-limit ttl-expired-to-cpu policy-map rate-limit policy`

**Command Default** By default this command is disabled.

**Parameters** `policy-map rate-limit policy`

Specifies the name of the policy-map.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables rate-limit option on IPv4 ttl-expired-to-cpu packets.  
Create a CPU bound rate-limit policy map before applying rate-limiting for ttl-expired-to-cpu packets.

---

### NOTE

The following warning message is displayed if only some of the cards are supported and few are not supported.

```
Warning: rate-limit config for protocol "ttl-expired-to-cpu" is not supported on
module 1, 3
```

The following warning message is displayed if none of the cards are supported.

```
Warning: rate-limit config for protocol "ttl-expired-to-cpu" is not supported on
available modules. It is only supported on GEN-2 and later modules.
```

---

**Examples** The following example explains how to apply rate-limit option on IPv4 ttl-expired-to-cpu packets.

```
device(config)# ip rate-limit ttl-expired-to-cpu policy-map save-cpu-policy
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ip receive access-list

Configures an IPv4 access-control list as an IPv4 receive access-control list (rACL).

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <p><b>ip receive access-list</b> { <b>acl-num</b>   <i>acl-name</i> } <b>sequence seq-num</b> [ <b>policy-map policy-map-name</b> [ <b>strict-ac</b> ] ]</p> <p><b>no ip receive access-list</b> { <b>acl-num</b>   <i>acl-name</i> } <b>sequence seq-num</b> [ <b>policy-map policy-map-name</b> [ <b>strict-acl</b> ] ]</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Parameters</b>       | <p><b>acl-num</b>   <i>acl-name</i></p> <p>Specifies, in number or name format, the access-control list to apply to all interfaces within the default VRF, for all CPU-bound traffic.</p> <p><b>sequence seq-num</b></p> <p>Defines the sequence number of the access-control list being applied as a rACL. IPv4 rACL commands are applied in the order of the lowest to the highest sequence numbers. The range of values is from 1 through 200.</p> <p><b>policy-map policy-map-name</b></p> <p>Specifies the name of a policy map. When the <b>policy-map</b> option is specified, traffic matching the "permit" clause of the specified IPv4 ACL is rate-limited as defined in the policy map and IPv4 traffic matching the "deny" clause in the IPv4 ACL is permitted without rate limiting.</p> <p><b>strict-acl</b></p> <p>Specifies that traffic matching the "permit" clause of the specified IPv4 ACL is rate-limited as defined in the policy map and IPv4 traffic matching the "deny" clause in the IPv4 ACL is dropped in the hardware.</p> |
| <b>Modes</b>            | Global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Usage Guidelines</b> | <p>The <b>no</b> form of the basic command removes the rACL.</p> <p>The <b>no</b> form of the command with both <b>policy-map</b> and <b>strict-acl</b> options specified, removes the <b>strict-acl</b> option: the rACL with <b>policy-map</b> remains and traffic matching "deny" clauses starts passing to the CPU.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Examples</b>         | <p>The following example configures the IPv4 ACL "101" as a rACL with the sequence number "15".</p> <pre>device(config)# ip receive access-list 101 sequence 15</pre> <p>The following example configures the IPv4 ACL "acl_stand1" as an rACL with the sequence number "10".</p> <pre>device(config)# ip receive access-list acl_stand1 sequence 10</pre> <p>The following example removes the <b>strict-acl</b> option so that traffic matching "deny" clauses starts passing to the CPU: the rACL "acl_stand1" with the policy map "m1" remains.</p> <pre>device(config)# no ip receive access-list acl_stand1 sequence 10 policy-map m1 strict-acl</pre>                                                                                                                                                                                                                                                                                                                                                                                             |

| History | Release | Command History                                   |
|---------|---------|---------------------------------------------------|
|         | 5.6.00  | This command was modified to support named rACLs. |

## ip route bfd

Enables Bidirectional Forwarding Detection (BFD) monitoring for an IP static route.

**Syntax** `ip route A.B.C.D/L A.B.C.D bfd [ metric | distance number | name name | tag number ]`

**Command Default** BFD monitoring for an IP static route is not enabled.

**Parameters** *A.B.C.D/L*

*A.B.C.D/L* Specifies the destination IPv4 address and mask.

*A.B.C.D*

Specifies the IPv4 address of the next hop.

*metric*

Specifies the cost metric of the route. Valid values range from 1 through 16. The default is 1.

**distance** *number*

Specifies the administrative distance of the route. Valid values range from 1 through 255. The default is 1.

**name** *name*

Specifies the name of the route in ASCII characters.

**tag** *number*

Specifies the tag value of the route to use for route filtering with a route map. Valid values range from 0 through 4294967295. The default is 0.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command removes BFD monitoring from the static route.

**Examples** The following example enables BFD route monitoring on an IP static route and sets the cost metric of the route to 8.

```
device# configure terminal
device(config)# ip route 10.1.0.0/24 10.2.0.5 bfd 8
```

The following example enables BFD route monitoring on an IP static route and sets the administrative distance of the route to 60.

```
device# configure terminal
device(config)# ip route 10.0.0.0/24 10.0.0.5 bfd distance 60
```

The following example enables BFD route monitoring on an IP static route and sets the name of the route to "route1".

```
device# configure terminal
device(config)# ip route 10.0.2.0/24 10.0.3.5 bfd name route1
```

The following example enables BFD route monitoring on an IP static route and sets the tag value of the route to 10.

```
device# configure terminal
device(config)# ip route 10.0.2.0/24 10.0.3.5 bfd tag 10
```

## ip route static-bfd

Configures Bidirectional Forwarding Detection (BFD) session parameters for IP static routes.

**Syntax** `ip route [ vrf vrf-name ] static-bfd dest-ip-address source-ip-address [ interval transmit-time min-rx receive-time multiplier number ]`

`no ip route [ vrf vrf-name ] static-bfd dest-ip-address source-ip-address`

**Command Default** BFD is not configured for an IP static route.

**Parameters** `vrf vrf-name`

Specifies the name of a VRF instance.

`dest-ip-address`

Specifies the destination IP address.

`source-ip-address`

Specifies the source IP address.

**interval** `transmit-time`

Specifies the interval, in milliseconds, a device waits to send a control packet to BFD peers. Valid values range from 50 through 30000.

**min-rx** `receive-time`

Specifies the interval, in milliseconds, a device waits to receive a control packet from BFD peers. Valid values range from 50 through 30000.

**multiplier** `number`

Specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD determines that the connection to that peer is not operational. Valid values range from 3 through 50.

**Modes** Global configuration mode

**Usage Guidelines** The **interval** `transmit-time` and **min-rx** `receive-time` variables are the intervals desired by the local device. The actual values in use will be the negotiated values.

For single-hop static BFD sessions, timeout values are optional because all required information is available from the outgoing interface. For multihop BFD sessions, if the configured **interval** and **min-rx** parameters conflict with those of an existing BGP session, the lower values are used.

If you configure a neighbor IP address and a source IP address that already exist in BFD, BFD overwrites the existing interval values and multiplier for the IP addresses with the new values on behalf of the static module.

When Brocade NetIron CER Series or Brocade NetIron CES Series devices are heavily loaded or under stress, BFD sessions may flap if the configured BFD interval is less than 500 milliseconds with a multiplier value of 3.

The **no** form of the command disables BFD monitoring by removing the BFD static neighbor and eliminating the BFD session, while keeping the static route in the route table manager (RTM), and retaining the existing IP traffic route. You only need to specify the destination and source IP address when removing a BFD neighbor.

**Examples** The following example configures a BFD session on an IP static route.

```
device# configure terminal
device(config)# ip route static-bfd 10.0.2.1 10.1.1.1 interval 500 min-rx 500
multiplier 5
```

## ip ssh encryption disable-aes-cbc

Disables the Advanced Encryption Standard - Cipher-Block Chaining (AES-CBC) encryption mode for the Secure Shell (SSH) protocol.

**Syntax** `ip ssh encryption disable-aes-cbc`

`no ip ssh encryption disable-aes-cbc`

**Command Default** If JITC is enabled, only AES-CTR encryption mode is supported and AES-CBC mode is disabled by default. In the standard mode, the AES-CBC encryption mode is enabled.

**Modes** Global configuration mode.

**Usage Guidelines** The `no` form of the command enables the AES-CBC encryption mode.

**Examples** The following example disables the AES-CBC encryption mode.

```
device# configure terminal
device(config)# ip ssh encryption disable-aes-cbc
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |



## ip tcp adjust-mss

Configures the TCP MSS value of the IP TCP synchronization packets passing through a router.

**Syntax** `ip tcp [ adjust-mss max-segment-size ]`

`no ip tcp [ adjust-mss max-segment-size ]`

**Command Default** Configuring the TCP MSS value of the IP TCP synchronization packets is not enabled by default.

**Parameters** **adjust-mss**

Specifies the TCP MSS value configuration parameter.

***max-segment-size***

Specifies the maximum segment size in bytes. The range is from 512 - 9158 bytes. Since the range is based on configuration of the IP MTU or GRE Tunnel MTU value, the CLI does not display the configurable range.

**Modes** Interface level, and virtual interface (VE) level.

**Usage Guidelines** Use the `ip tcp adjust-mss max-segment-size` command to modify the TCP MSS value of the IP TCP synchronization packets passing through a router. When you configure the IP MTU value on the same Ethernet interface as the configured TCP MSS value, the software internally modifies the TCP MSS value according to the current IP MTU value so dropped or fragmented packets are avoided. The TCP MSS value is modified based on the IP MTU or GRE tunnel MTU configuration. If the configured TCP MSS value is less than the current IP MTU value or GRE tunnel MTU value, then the software will not modify the TCP MSS value. Refer to the examples below for modifying the TCP MSS value based on the IP MTU configuration or the GRE tunnel MTU configuration.

### Modifying the TCP MSS value based on the IP MTU configuration

For example, on ethernet interface 1/1 the TCP MSS is configured to 1400 bytes. If you configure the IP MTU value to 1000 bytes on ethernet interface 1/1, the software internally modifies the TCP MSS value to 960 bytes. The TCP MSS value modification is required by software because the configured TCP MSS value (1400 bytes) is greater than the user configuration of the IP MTU value. The modified value is calculated by subtracting the user configuration from the current IP MTU value - 1000 bytes minus 40 bytes equals 960 bytes.

### Modifying the TCP MSS value based on the GRE tunnel MTU configuration

For example, on ethernet interface 1/1 the TCP MSS value is configured to 1400 bytes. The ethernet interface 1/1 is a tunnel source for the GRE tunnel 100. If you configure the GRE tunnel MTU value to 700 bytes on ethernet interface 1/1, the software internally modifies the TCP MSS value to 660 bytes. The TCP MSS value modification is required by software because the configured TCP MSS value (1400 bytes) is greater than the user configuration of the GRE tunnel MTU value. The modified value is calculated by subtracting the user configuration from the current GRE tunnel MTU value - 700 bytes minus 40 bytes equals 960 bytes.

After configuring the `ip tcp adjust-mss max-segment-size` command, and the `ip tcp redirect-gre-tcp-syn` command, the hardware redirects the TCP SYN packets received on interface port 1/1 to the LP software. The LP software adjusts the TCP MSS value in the incoming packet. For more information on the `ip tcp redirect-gre-tcp-syn` command, refer to [ip tcp redirect-gre-tcp-syn](#) on page 203.

The GRE tunnel MTU configuration takes a higher priority over the IP MTU configuration. If the GRE tunnel MTU is not configured, then the IP MTU configuration is used to modify the TCP MSS value. The `ip tcp adjust-mss max-segment-size` command can only be enabled on the GRE ingress interface. The TCP MSS value is modified only in the source port of the ingress GRE tunnel. The TCP MSS value

cannot be modified when the tunnel source port is configured as an IP address port. The **ip tcp adjust-mss *max-segment-size*** command is supported only on an IPv4 interface.

Use the **no** form of the command to disable the TCP MSS value configuration parameter. Backward compatibility is not supported.

---

**NOTE**

Configuring the TCP MSS value is supported only on the Brocade NetIron XMR Series and the Brocade NetIron MLX Series platforms.

---

**Examples** The following example configures the TCP MSS value to 1000 bytes.

```
device(config)# interface ethernet 2/1
device(config-if-e10000-2/1)# ip tcp adjust
      adjust-mss    Configure the TCP MSS
device(config-if-e10000-2/1)# ip tcp adjust-mss 10
Error - 10 not between 536 and 1460
device(config-if-e10000-2/1)# ip tcp adjust-mss 1000
device(config-if-e10000-2/1)#
```

Use the **show run interface** command to display the TCP MSS configuration on interface ethernet 2/1.

```
device(config-if-e10000-2/1)# show run interface
interface management 1
ip address x.x.x.x/24
enable
!
interface ethernet 2/1
ip tcp adjust-mss 1000
!
interface ethernet 2/3
ip address x.x.x.x/24
!
interface ethernet 2/4
enable
!
```

**History**

---

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

---

## ip tcp redirect-gre-tcp-syn

Configures the GRE-based TCP synchronization packets to the CPU when the TCP MSS value is adjusted.

**Syntax** `ip tcp [ redirect-gre-tcp-syn ]`

`no ip tcp [ redirect-gre-tcp-syn ]`

**Command Default** Configuring the GRE based TCP synchronization packets to the CPU is not enabled by default.

**Parameters** `redirect-gre-tcp-syn`

Specifies the GRE-based TCP synchronization packets parameter.

**Modes** Global configuration mode.

**Usage Guidelines** Use the `ip tcp redirect-gre-tcp-syn` command to optionally redirect the GRE-based TCP synchronization packets to the CPU when the TCP MSS value is adjusted. To redirect the GRE based TCP synchronization packets to the CPU, use the `ip tcp adjust-mss max-segment-size` command, and the `ip tcp redirect-gre-tcp-syn` command. To redirect only the IP TCP synchronization packets to the CPU, use `ip tcp adjust-mss max-segment-size` command.

After configuring the `ip tcp adjust-mss` command with the `max-segment-size` option, and the `ip tcp redirect-gre-tcp-syn` command, the hardware redirects the TCP SYN packets received on interface port 1/1 to the LP software. The LP software adjusts the TCP MSS value in the incoming packet. For more information on the `ip tcp adjust-mss max-segment-size` command, refer to the `ip tcp adjust-mss` command.

Use the `no` form of the command to disable the configuration of the GRE based TCP synchronization packets to the CPU. Backward compatibility is not supported. If the `ip tcp redirect-gre-tcp-syn` command is not configured, the incoming packet still receives the CPU for MAC learning.

You can optionally trap the TCP SYNC packet in a GRE transit router by creating a dummy GRE tunnel in the transit router. For example, port 1/1 is the ingress port and port 1/2 is the egress port for the GRE based TCP SYN packets incoming and outgoing transmission. To trap the TCP SYN packets to the LP CPU on port 1/1, you need to create a dummy GRE tunnel in the configured tunnel source port, either port 1/1 or port 1/2.

---

### NOTE

Configuring the GRE based TCP synchronization packets is supported only on the Brocade NetIron XMR Series and the Brocade NetIron MLX Series platforms.

---

**Examples** The following example configures the GRE based TCP synchronization packets to the CPU on the global interface level.

```
device(config)# ip tcp redirect-gre-tcp-syn ?
redirect-gre-tcp-syn  Control the GRE based TCP Synchronization packets
device(config)# ip tcp redirect-gre-tcp-syn
device(config)#
```

Use the `show running-configuration` command to display the GRE based TCP synchronization packets configuration.

```
device# show running-config
!
hostname dut3
acl-duplication-check
ip multicast-routing
ip tcp redirect-gre-tcp-syn
!
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.7.00          | This command was introduced. |

## ip vrrp auth-type

Configures the type of authentication used on a Virtual Router Redundancy Protocol (VRRP) interface.

**Syntax** `ip vrrp auth-type { no-auth | simple-text-auth auth-text }`  
`no ip vrrp auth-type { no-auth | simple-text-auth auth-text }`

**Command Default** No authentication is configured for a VRRP VRID.

**Parameters** **no-auth**  
 Configures no authentication on the VRRP interface.

**simple-text-auth *auth-text***  
 Configures a simple text string as a password used for authenticating packets on the interface. The maximum length of the text string is 64 characters.

**Modes** Interface configuration mode.

**Usage Guidelines** If the **no-auth** option is configured, ensure all interfaces on all the devices that support this virtual router ID do not use authentication.

If the **simple-text-auth** option is configured, ensure all interfaces on all the devices that support this virtual router ID are configured to use simple password authentication with the same password.

The **no** form of this command removes the VRRP authentication from the interface.

---

### NOTE

Authentication is not supported by VRRP-Ev3.

---

**Examples** The following example configures no authentication on Ethernet interface 1/6.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip vrrp auth-type no-auth
```

The following example configures simple password authentication on Ethernet interface 1/6.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip vrrp auth-type simple-text-auth yourpwd
```

## ip vrrp vrid

Configures an IPv4 Virtual Router Redundancy Protocol (VRRP) virtual router identifier (VRID).

**Syntax** `ip vrrp vrid vrid`

`no ip vrrp vrid vrid`

**Command Default** A VRRP VRID does not exist.

**Parameters** *vrid*

Configures a number for an IPv4 VRRP VRID. The range is from 1 to 255.

**Modes** Interface configuration mode

**Usage Guidelines** Before configuring this command, ensure that VRRP is enabled globally or an error stating "Invalid input..." is displayed as you try to create a VRRP instance.

The **no** form of this command removes the IPv4 VRRP VRID from the configuration.

**Examples** The following example configures the VRRP VRID 1.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.5.1
device(conf-if-e1000-1/6-vrid-1)# activate
```

## ip vrrp-extended auth-type

Configures the type of authentication used on a Virtual Router Redundancy Protocol Extended (VRRP-E) interface.

**Syntax** `ip vrrp-extended auth-type { no-auth | simple-text-auth auth-text | md5-auth auth-text }`  
`no ip vrrp-extended auth-type { no-auth | simple-text-auth auth-text | md5-auth auth-text }`

**Command Default** No authentication is configured for a VRRP-E interface.

**Parameters**

- no-auth**  
Configures no authentication on the VRRP-E interface.
- simple-text-auth *auth-text***  
Configures a simple text string as a password used for authenticating packets on the interface. The maximum length of the text string is 64 characters.
- md5-auth *auth-text***  
Configures MD5 authentication on the interface. The maximum length of the text string is 64 characters.

**Modes** Interface configuration mode.

**Usage Guidelines**

If the **simple-text-auth** option is configured, ensure all interfaces on all the devices that support this virtual router ID are configured to use simple password authentication with the same password.

If the **md5-auth** option is configured, syslog and SNMP traps are generated in the event of a packet being dropped due to MD5 authentication failure. Using MD5 authentication implies that the software does not need to run checksum verification on the receiving device and can rely on the authentication code (message digest 5 algorithm) to verify the integrity of the VRRP-E message header.

A **show run** command with appropriate parameters displays the encrypted password and you can use the **enable password-display** command to display the unencrypted password.

If the **no-auth** option is configured, ensure all interfaces on all the devices that support this virtual router ID do not use authentication.

The **no** form of this command removes the VRRP-E authentication from the interface.

---

### NOTE

Authentication is not supported by VRRP-Ev3.

---

**Examples** The following example configures no authentication on Ethernet interface 1/6.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip vrrp-extended auth-type no-auth
```

The following example configures simple password authentication on Ethernet interface 1/6.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip vrrp-extended auth-type simple-text-auth yourpwd
```

The following example configures MD5 authentication on Ethernet interface 1/6. When MD5 authentication is configured, a syslog message is displayed.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip vrrp-extended auth-type md5-auth lyk28d3j

Aug 10 18:17:39 VRRP: Configuration VRRP_CONFIG_MD5_AUTHENTICATION request received
Aug 10 18:17:39 VRRP: Port 1/6, VRID 2 - send advertisement
Ver:3 Type:1 Vrid:2 Pri:240 #IP:1 AuthType:2 Adv:1 Chksum:0x0000
HMAC-MD5 CODE:[000000000000000000000400010]
IpAddr: 10.53.5.1
```



## ip vrrp-extended vrid

Configures an IPv4 Virtual Router Redundancy Protocol Extended (VRRP-E) virtual router identifier (VRID).

**Syntax** `ip vrrp-extended vrid vrid`

`no ip vrrp-extended vrid vrid`

**Command Default** A VRRP-E VRID does not exist.

**Parameters** `vrid`

Configures a number for an IPv4 VRRP-E VRID. The range is from 1 to 255.

**Modes** Interface configuration mode.

**Usage Guidelines** Before configuring this command, ensure that VRRP-E is enabled globally or an error stating "Invalid input..." is displayed as you try to create a VRRP-E instance.

The **no** form of this command removes the IPv4 VRRP-E VRID from the configuration.

**Examples** The following example configures the VRRP-E VRID 1.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.10.1/24
device(conf-if-e1000-1/6)# ip vrrp-extended vrid 1
device(conf-if-e1000-1/6-vrid-1)# backup priority 50 track-priority 10
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.10.254
device(conf-if-e1000-1/6-vrid-1)# activate
```

# ip-address

Configures a virtual IP address for a Virtual Router Redundancy Protocol (VRRP) or VRRP extended (VRRP-E) instance.

**Syntax** `ip-address ip-address`

`no ip-address ip-address`

**Command Default** A virtual IP address is not configured for a VRRP or VRRP-E instance.

**Parameters** `ip-address`

Configures the IP address in dotted-decimal format.

**Modes** Virtual routing ID interface configuration mode.

**Usage Guidelines** For VRRP instances, the IP address used for the virtual router must be configured on the device assigned to be the initial VRRP owner device. The same IP address cannot be used on any other VRRP device.

For VRRP extended (VRRP-E) instances, the IP address used for the virtual router must not be configured on any other device.

The **no** form of this command removes the virtual router IP address.

**Examples** The following example configures a virtual IP address for VRID 1 when VRRP is implemented. In this example, the device is configured as the VRRP owner device.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.5.1
device(conf-if-e1000-1/6-vrid-1)# activate
```

The following example configures a virtual IP address for VRID 2 when VRRP-E is implemented. In this example, the device is configured as a VRRP backup device and the highest priority device will become the master VRRP device.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ip address 10.53.5.3/24
device(conf-if-e1000-1/5)# ip vrrp-extended vrid 2
device(conf-if-e1000-1/5-vrid-2)# backup priority 110
device(conf-if-e1000-1/5-vrid-2)# version 2
device(conf-if-e1000-1/5-vrid-2)# ip-address 10.53.5.254
device(conf-if-e1000-1/5-vrid-2)# activate
```

## ipsec profile

Configures the IP security profile name used between two IPsec-enabled Brocade devices.

**Syntax** **ipsec profile** *name*  
**no ipsec profile** *name*

**Parameters** *name*  
 Specifies the IPsec profile name.

**Modes** Global configuration mode.

**Examples** The following example configures IPsec profile parameter.

```
device(config)# ipsec profile test1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## ipsec proposal

Configures IP Security proposal parameter.

**Syntax** `ipsec proposal name`

**Parameters** *name*  
Specifies IPSec proposal name.

**Modes** IPSec proposal configuration mode.

**Examples** The following example configures IPSec proposal parameter.

```
device(config)# ipsec proposal test1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# ipv6 dhcp-relay include-options

Includes the parameters on the IPv6 DHCP relay agent messages.

**Syntax** **ipv6 dhcp-relay include-options** [*interface-id*] [*remote-id*] [*client -mac-address*]  
**no ipv6 dhcp-relay include-options** [*interface-id*] [*remote-id*] [*client -mac-address*]

**Command Default** The parameters are not included on the IPv6 DHCP relay agent messages.

**Parameters** *interface-id*  
 Includes the interface-ID parameter (option 18) in the IPv6 DHCP relay agent messages.

*remote-id*  
 Includes the remote-ID (option 37) parameter in the IPv6 DHCP relay agent messages.

*client-mac-address*  
 Includes the client link layer address (option 79) in the relay-forward messages.

**Modes** Interface configuration mode

**Usage Guidelines** The **no** form of the command disables the relay agent include options parameters.  
 You can enter either one or all of the include options as identifiers to specify in the relay-forward message.

**Examples** The following example includes the interface-ID parameter on the DHCPv6 relay agent messages.

```
device(config)# interface ethernet 1/1/3
device(config-if-eth1/1/3)# ipv6 dhcp-relay include-options interface-id
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.4             | This command was introduced. |
| 5.9             | This command was modified.   |

## ipv6 multicast-routing load-sharing rebalance

Enables or disables the rebalance of the load-sharing among ECMP IPv6 paths.

**Syntax** `ipv6 multicast-routing load-sharing [ rebalance ]`

`no ipv6 multicast-routing load-sharing [ rebalance ]`

**Parameters** `rebalance`

Specifies that the ECMP load-sharing will be rebalanced for the interface on which the **rebalance** keyword is configured.

**Modes** Interface configuration mode

**Examples** To configure IPv6 Multicast ECMP, use this command in the configuration mode.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# ipv6 multicast-routing load-sharing
```

To disable load distribution among ECMP IP paths use the **no** form of the command.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# no ipv6 multicast-routing load-sharing
```

The following example configures rebalancing of the load distribution among ECMP IP paths.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e10000-1/1)# ipv6 multicast-routing load-sharing rebalance
```

### History

---

**Release Command History**

---

5.5.00 This command was added to enable of disable the rebalance of the load-sharing among ECMP paths.

---

## ipv6 nd proxy

Configures a single IPv6 subnet prefix to support multiple physical links in IPv6 Neighbor Discovery.

**Syntax** `ipv6 nd proxy`

`no ipv6 nd proxy`

**Command Default** This feature is disabled.

**Modes** Interface subtype configuration mode.

**Usage Guidelines** The IPv6 ND proxy command turns on the IPv6 ND proxy capability for the node, and is run at the configuration level.

Use the **no** form of this command to remove the ND proxy configuration.

Per RFC 4389, ND proxy can be used to bridge multiple links into a single entity to simplify management, as there is no need to allocate subnet numbers to the different networks. This can help alleviate the need to configure NAT in IPv6 networks.

---

### NOTE

This is an IETF Experimental Protocol. It is the responsibility of the user to ensure that appropriate network-layer support is provided.

---

The following limitations apply:

- The `ipv6 nd proxy` is not supported over v6 tunnel interface.
- The `IPv6 nd proxy` programs the RAACL to force the Unicast NS, sent during neighbor refresh, to the CPU for processing as proxy NS.
- The `ipv6 nd proxy` is currently supported for NS and NA messages and are not supported for other ND messages like RS, RA and redirect message.
- The `IPv6 nd proxy` is not supported for the IPsec tunnels and on MCT.

**Examples** To enable the IPv6 ND proxy feature for the node:

```
R2>#en
No password has been assigned yet...
R2#conf t
R2(config)# ipv6 nd proxy
R2(config)#
```

## ipv6 nd ra-dns-server

Advertises the recursive Domain Name System (DNS) server address and the lifetime multiplier information to IPv6 hosts in the Router Advertisement (RA) message.

**Syntax** `ipv6 nd ra-dns-server ipv6-address [ lifetime-multiplier decimal ]`

**no** `ipv6 nd ra-dns-server ipv6-address [ lifetime-multiplier decimal ]`

**Command Default** By default, the recursive DNS server address and the lifetime multiplier information is not configured.

**Parameters** `ipv6-address`

Specifies the global IPv6 address of the DNS server.

**lifetime-multiplier decimal**

Specifies the percentage value of the maximum router advertisement interval. The maximum router advertisement interval is the maximum time that can be allowed between sending unsolicited RA messages for DNS name resolution. The lifetime-multiplier decimal value is calculated as a percentage of the RA lifetime. The maximum router advertisement interval percentage range is 100 percent through 200 percent and the default value is 200 percent.

**Modes** Global configuration mode.

Interface configuration mode.

**Usage Guidelines** You can configure a maximum of four recursive DNS server addresses and corresponding lifetime multiplier values at a given instance.

---

### NOTE

The `ipv6 nd ra-dns-server` command at the interface configuration level takes precedence over global configuration. In other words, if at least one DNS server address is configured on an interface, it will override other DNS server address configurations at the global configuration.

---

**Examples** The following examples configure the recursive DNS address for a lifetime-multiplier value of 200.

```
device(config)# ipv6 nd ra-dns-server 2001:DC8:200::3 lifetime 200
device(config-if-e10000-1/10)# ipv6 nd ra-dns-server 2001:DC8:200::3 lifetime 200
```



# ipv6 nd ra-domain-name

Configures the domain name of the Domain Name System (DNS) suffix and the lifetime multiplier information to IPv6 hosts in the Router Advertisement (RA) message. The **no** form of this command disables the advertisement of the specified domain name of DNS suffix in the RA message.

**Syntax** `ipv6 nd ra-domain-name string [ lifetime-multiplier decimal ]`

**no** `ipv6 nd ra-domain-name string [ lifetime-multiplier decimal ]`

**Parameters** *string*

Specifies the domain name of the DNS suffix.

**lifetime-multiplier *decimal***

Specifies the percentage value of maximum router advertisement interval. The maximum router advertisement interval is the maximum time that can be allowed between sending unsolicited RA messages for DNS name resolution. The **lifetime-multiplier *decimal* value is calculated as percentage of the RA lifetime. The maximum router advertisement interval percentage range is 100 through 200% and the default value is 200%.**

**Modes** Global configuration mode.

Interface configuration mode.

**Usage Guidelines**

You can configure a maximum of four different domain names of DNS suffix and corresponding lifetime multiplier values at a given instance.

The domain name of a DNS suffix at the global configuration level is used on all IPv6 routed interfaces that do not have a domain name of DNS suffix configured on them.

---

## NOTE

The **ipv6 nd ra-domain-name** command at the interface configuration takes precedence over global configuration. In other words, if at least one DNS server address is configured on an interface, it will override other DNS server address configurations at the global configuration.

---

**Examples**

The following examples configure the domain names of a DNS suffix for a lifetime-multiplier value of 200.

```
device (config)# ipv6 nd ra-domain-name brocade.com lifetime 200
device (config-if-e10000-1/10)# ipv6 nd ra-domain-name brocade.com lifetime 200
```

**History**

---

| Release | Command History |
|---------|-----------------|
|---------|-----------------|

---

|        |                              |
|--------|------------------------------|
| 5.5.00 | This command was introduced. |
|--------|------------------------------|

---

## ipv6 ospf active

Sets a specific OSPFv3 interface to active.

- Syntax** `ipv6 ospf active`
- Modes** Interface subtype configuration mode
- Usage Guidelines** Use the **ipv6 ospf active** command on each interface participating in adjacency formation. This command overrides the global passive setting on that interface, and enables transmission of OSPFv3 control packets.
- Examples** This example sets a specific OSPFv3 Ethernet interface to active.
- ```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf active
```

## ipv6 ospf area

Enables OSPFv3 on an interface.

**Syntax** `ipv6 ospf area area-id | ipv6-addr`

**no ipv6 ospf area**

**Command Default** OSPFv3 is disabled.

**Parameters** *area-id*

Area address in dotted decimal or decimal format.

*ipv6-addr*

IPv6 address.

**Modes** Interface subtype configuration mode

**Usage Guidelines** This command enables an OSPFv3 area on the interface to which you are connected.

Enter **no ipv6 ospf area** to disable OSPFv3 on this interface.

**Examples** This example enables a configured OSPFv3 area named 0 on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf area 0
```

## ipv6 ospf authentication ipsec

Specifies IP security (IPsec) as the authentication type for an OSPFv3 interface.

**Syntax** `ipv6 ospf authentication ipsec key-add-remove-interval interval`

`no ipv6 ospf authentication ipsec key-add-remove-interval interval`

**Command Default** Disabled.

**Parameters** `key-add-remove-interval interval`

Specifies the OSPFv3 authentication key add-remove interval. Valid values range from decimal numbers 0 through 14400. The default is 300.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Enter `no ipv6 ospf authentication ipsec` to remove IPsec authentication from the interface.

**Examples** This example enables IPsec on a specified OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf area 0
device(config-if-e1000/1/1)# ipv6 ospf authentication ipsec
```

This example sets the OSPFv3 authentication key add-remove interval to 480.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf area 0
device(config-if-e1000/1/1)# ipv6 ospf authentication ipsec key-add-remove-interval
480
```

## ipv6 ospf authentication ipsec disable

Disables IP security (IPsec) services on an OSPFv3 interface.

**Syntax** **ipv6 ospf authentication ipsec disable**

**no ipv6 ospf authentication ipsec disable**

**Command Default** Authentication is disabled.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Use this command to disable IPsec if it is enabled on the interface. Packets that are sent out will not be IPsec encapsulated and the received packets which are IPsec encapsulated will be dropped.

Enter **no ipv6 ospf authentication ipsec** to re-enable IPsec on the interface if IPsec is already configured on the interface.

**Examples** This example disables IPsec on a specific OSPFv3 interface where IPsec is already enabled.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf authentication ipsec disable
```

## ipv6 ospf authentication ipsec spi

Specifies the IP security (IPsec) security policy index (SPI) value for an OSPFv3 interface.

**Syntax** `ipv6 ospf authentication ipsec spi value esp sha1 key [ no-encrypt ] key }`

**no ipv6 ospf authentication spi**

**Command Default** Authentication is disabled.

The 40-hexadecimal character key is encrypted by default. Use the **no-encrypt** parameter to disable encryption.

**Parameters** **ipsec**

Specifies IPsec as the authentication protocol.

**spi**

Specifies the Security Policy Index (SPI).

*value*

Specifies the SPI value. Valid values range from decimal numbers 256 through 4294967295. The near-end and far-end values must be the same.

**esp**

Specifies Encapsulating Security Payload (ESP) as the protocol to provide packet-level security. This is the only option currently available.

**sha1**

Enables Hashed Message Authentication Code (HMAC) Secure Hash Algorithm 1 (SHA-1) authentication.

*key*

Number used in the calculation of the message digest. The 40 hexadecimal character key is stored in encrypted format by default.

**no-encrypt**

The 40-character key is not encrypted upon either its entry or its display.

*key*

The 40 hexadecimal character key.

**Modes** Interface subtype configuration mode

**Usage Guidelines** The 40 hexadecimal character key is encrypted by default. The system adds the following in the configuration to indicate that the key is encrypted:

- encrypt = the key string uses proprietary simple cryptographic 2-way algorithm (only for Brocade NetIron CES and Brocade NetIron CER devices)
- encryptb64 = the key string uses proprietary base64 cryptographic 2-way algorithm (only for Brocade NetIron XMR and Brocade MLX series devices)

To change an existing key, you must specify a different SPI value to that of the value already configured.

Enter **no ipv6 ospf authentication ipsec spi *spi*** to remove the SPI value from the interface.

**Examples** This example enables ESP and HMAC-SHA-1 on a specified OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf area 0
device(config-if-e1000/1/1)# ipv6 ospf authentication ipsec spi 512 esp sha1
abcef12345678901234fedcba098765432109876
```

## ipv6 ospf bfd

Enables Bidirectional Forwarding Detection (BFD) on a specific OSPFv3 interface.

**Syntax** `ipv6 ospf bfd disable`

`no ipv6 ospf bfd`

**Command Default** BFD is disabled by default.

**Parameters** `disable`

Disables BFD on the OSPFv3 interface.

**Modes** Interface subtype configuration mode

**Usage Guidelines** BFD sessions are initiated if BFD is also enabled globally using the **bfd all-interfaces** command in OSPFv3 router configuration mode. If BFD is disabled using the **no bfd all-interfaces** command in OSPFv3 router configuration mode, BFD sessions on specific interfaces are deregistered.

The **no** form of the command removes all BFD sessions from a specified interface.

**Examples** The following example enables BFD on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ipv6 ospf bfd
```

The following example disables BFD on a specific OSPF Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ipv6 ospf bfd disable
```



## ipv6 ospf cost

Configures cost for a specific OSPFv3 interface.

**Syntax** `ipv6 ospf cost value`

`no ipv6 ospf cost`

**Command Default** Cost value is 1.

**Parameters** *value*

Cost value. Valid values range from 1 through 65535. The default is 1.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Use this command to set or reset the OSPFv3 cost on the interface. If the cost is not configured with this command, OSPFv3 calculates the value from the reference and interface bandwidths.

For more information, refer to the **auto-cost reference-bandwidth** command.

Enter **no ipv6 ospf cost** to disable the configured cost.

**Examples** This example sets the cost to 620 on a specific IPv6 OSPF Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ipv6 ospf cost 620
```

## ipv6 ospf dead-interval

Specifies the time period for which a neighbor router waits for a hello packet from the device before declaring the router down.

**Syntax** `ipv6 ospf dead-interval interval`

**no ipv6 ospf dead-interval**

**Command Default** The specified time period is 40 seconds.

**Parameters** *interval*

Dead interval in seconds. Valid values range from 3 through 65535 seconds. The default is 40.

**Modes** Interface subtype configuration mode

**Usage Guidelines** If you change the dead interval, the hello interval is automatically changed to be one fourth of the new dead interval, unless the hello interval is also explicitly configured using the **ipv6 ospf hello-interval** command. The **running-config** command displays only explicitly configured values of the hello interval, which means that a value that is automatically changed as the result of a dead-interval change is not displayed.

Enter **no ipv6 ospf dead-interval** to use the default value.

**Examples** This example sets the dead interval to 80 on a specific IPv6 OSPF Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ipv6 ospf dead-interval 80
```

## ipv6 ospf hello-interval

Sets the length of time between the transmission of hello packets that an interface sends to neighbor routers.

**Syntax** `ipv6 ospf hello-interval interval`

`no ipv6 ospf hello-interval`

**Command Default** The length of time between the transmission of hello packets is set to 10 seconds.

**Parameters** *interval*

Hello interval in seconds. Valid values range from 1 through 65535 seconds.  
The default is 10.

**Modes** Interface subtype configuration mode

**Usage Guidelines** If you change the hello interval, the dead interval is automatically changed to be four times the new hello interval, unless the dead interval is also explicitly configured using the **ipv6 ospf dead-interval** command. The **running-config** command displays only explicitly configured values of the dead interval, which means that a value that is automatically changed as the result of a hello-interval change is not displayed.

Enter **no ipv6 ospf hello-interval** to use the default value.

**Examples** This example sets the hello interval to 220 on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# ipv6 ospf hello-interval 220
```

## ipv6 ospf hello-jitter

Sets the allowed jitter between HELLO packets.

**Syntax** `ipv6 ospf hello-jitter interval`

`no ipv6 ospf hello-jitter`

**Parameters** *jitter*

Allowed interval between hello packets. Valid values range from 1 through 50 percent (%).

**Modes** Interface subtype configuration mode

**Usage Guidelines** The hello interval can vary from the configured hello-interval to a maximum of percentage value of configured jitter.

**Examples** This example sets the hello jitter to 20 on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf hello-jitter 20
```

## ipv6 ospf instance

Specifies the number of OSPFv3 instances running on an interface.

**Syntax** `ipv6 ospf instance instanceID`

`no ipv6 ospf instance`

**Parameters** *instanceID*

Instance identification number. Valid values range from 0 through 255.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Enter `no ipv6 ospf instance` to use the default value.

**Examples** This example sets the number of IPv6 OSPF instances to 35 on a specific Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf instance 35
```

## ipv6 ospf mtu-ignore

Enables or disables maximum transmission unit (MTU) match checking.

**Syntax** `ipv6 ospf mtu-ignore`

`no ipv6 ospf mtu-ignore`

**Command Default** Enabled.

**Modes** Interface subtype configuration mode

**Usage Guidelines** In default operation, the IP MTU on both sides of an OSPFv3 link must be the same, and a check of the MTU is performed when Hello packets are first exchanged.

Enter **no ipv6 ospf mtu-ignore** to disable MTU-match checking on a specific interface.

**Examples** This example disables MTU-match checking on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# no ipv6 ospf mtu-ignore
```

This example enables MTU-match checking on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf mtu-ignore
```

# ipv6 ospf network

Configures network type.

**Syntax** `ipv6 ospf network { broadcast | point-to-point }`

`no ipv6 ospf network`

**Command Default** Network type is broadcast.

**Parameters** `broadcast`

Network type is broadcast, such as Ethernet.

`point-to-point`

Network type is point-to-point.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Point-to-point can support unnumbered links, which requires less processing by OSPFv3.

Enter **no ipv6 ospf network** to remove the network-type configuration.

---

## NOTE

The network type non-broadcast is not supported at this time.

---

**Examples** This example configures an OSPFv3 point-to-point link on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf network point-to-point
```

This example configures an OSPFv3 broadcast link on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf network broadcast
```

## ipv6 ospf passive

Sets a specific OSPFv3 interface to passive.

**Syntax** **ipv6 ospf passive**

**no ipv6 ospf passive**

**Modes** Interface subtype configuration mode

**Usage Guidelines** The **ipv6 ospf passive** command disables transmission of OSPFv3 control packets on that interface. OSPFv3 control packets received on a passive interface are discarded.

**Examples** This example sets a specific OSPFv3 Ethernet interface to passive:

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf passive
```



## ipv6 ospf priority

Configures priority for designated router (DR) election and backup designated routers (BDRs) on the interface you are connected to.

**Syntax** `ipv6 ospf priority value`

`no ipv6 ospf priority`

**Command Default** The value is set to 1.

**Parameters** *value*

Priority value. Valid values range from 0 through 255. The default is 1.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Enter `no ipv6 ospf priority` to use the default value.

The OSPFv3 router assigned the highest priority becomes the designated router, and the OSPFv3 router with the second-highest priority becomes the backup router.

**Examples** This example sets a priority of 4 for the OSPFv3 router that is connected to an OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf priority 4
```

## ipv6 ospf retransmit-interval

Configures the retransmit interval. The retransmit interval is the time between Link-State Advertisement (LSA) retransmissions to adjacent routers for a given interface

**Syntax** `ipv6 ospf retransmit-interval interval`

`no ipv6 ospf retransmit-interval`

**Command Default** The interval is 5 seconds.

**Parameters** *interval*

Retransmit interval in seconds. Valid values range from 0 through 3600 seconds. The default is 5.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Enter `no ip ospf retransmit-interval` to reset the retransmit interval to its default.

**Examples** This example sets the retransmit interval to 8 for all OSPFv3 devices on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf retransmit-interval 8
```

## ipv6 ospf suppress-linklsa

Suppresses link LSA advertisements.

**Syntax** `ipv6 ospf suppress-linklsa`

`no ipv6 ospf suppress-linklsa`

**Modes** Interface subtype configuration mode

**Examples** This example suppresses link LSAs from being advertised on devices on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf suppress-linklsa
```

## ipv6 ospf transmit-delay

Configures transmit delay for link-update packets. The transmit delay is the estimated time required for OSPFv3 to send link-state update packets on the interface to which you are connected.

**Syntax** `ipv6 ospf transmit-delay value`

`no ipv6 ospf transmit-delay`

**Command Default** The transmit delay is set to 1 second.

**Parameters** *value*

Transmit delay in seconds. Valid values range from 0 through 3600 seconds. The default is 1.

**Modes** Interface subtype configuration mode

**Usage Guidelines** Enter `no ipv6 ospf transmit-delay` to use the default value.

**Examples** This example sets a transmit delay of 25 seconds for devices on a specific OSPFv3 Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000/1/1)# ipv6 ospf transmit-delay 25
```

# ipv6 rate-limit hoplimit-expired-to-cpu

Applies rate-limit option on IPv6 hop-limit packets, if the hop-limit count is less than or equal to one.

**Syntax** `ipv6 rate-limit hoplimit-expired-to-cpu rate-limit policy`

`no ipv6 rate-limit hoplimit-expired-to-cpu rate-limit policy`

**Command Default** By default, the no rate-limit option is applied to IPv6 hop-limit packets, if the hop-limit count is less than or equal to one.

**Parameters** `rate-limit policy`  
Name of the policy-map.

**Modes** Global configuration mode,

**Usage Guidelines** Create CPU bound rate-limit policy map before applying rate-limiting for hop-limit packets.

---

**NOTE**

The following warning message is displayed if only some of the cards are supported and few are not supported.

Warning: rate-limit config for protocol "hoplimit-expired-to-cpu" is not supported on module 1, 3

---



---

**NOTE**

The following warning message is displayed if none of the cards are supported.

Warning: rate-limit config for protocol "hoplimit-expired-to-cpu" is not supported on available modules.  
It is only supported on GEN-2 and later modules.

---

The **no** form of the command disables rate-limit option on IPv6 hop-limit packets.

**Examples** The following example explains how to apply a rate-limit policy for IPv6 hop-limit packets.

```
device(config)# ipv6 rate-limit hoplimit-expired-to-cpu policy-map save-cpu-policy
```

**History**

Release version	Command history
5.8.00	This command was introduced.

## ipv6 receive access-list

Configures an IPv6 access-control list as an IPv6 receive access-control list (rACL).

<b>Syntax</b>	<p><b>ipv6 receive access-list</b> <i>acl-name</i> <b>sequence</b> <i>seq-num</i> [ <b>policy-map</b> <i>policy-map-name</i> [ <b>strict-acl</b> ] ]</p> <p><b>no ipv6 receive access-list</b> <i>acl-name</i> <b>sequence</b> <i>seq-num</i> [ <b>policy-map</b> <i>policy-map-name</i> [ <b>strict-acl</b> ] ]</p>
<b>Parameters</b>	<p><b>acl-name</b></p> <p>Specifies the name of the access-control list to apply to all interfaces within the default VRF, for all CPU-bound traffic. The maximum length of the access-control list name is 256 characters.</p> <p><b>sequence seq-num</b></p> <p>Defines the sequence number of the access-control list being applied as a rACL. IPv6 rACL commands are applied in the order of the lowest to the highest sequence numbers. The range of values is from 1 through 50.</p> <p><b>policy-map policy-map-name</b></p> <p>Specifies the name of a policy map. When the <b>policy-map</b> option is specified, traffic matching the "permit" clause of the specified IPv6 ACL is rate-limited as defined in the policy map and IPv6 traffic matching the "deny" clause in the IPv6 ACL is permitted without any rate limiting.</p> <p><b>strict-acl</b></p> <p>Specifies that traffic matching the "permit" clause of the specified IPv6 ACL is rate-limited as defined in the policy map and IPv6 traffic matching the "deny" clause in the IPv6 ACL is dropped in the hardware.</p>
<b>Modes</b>	Global configuration mode
<b>Usage Guidelines</b>	<p>The rACL works like a regular ACL where IPv6 traffic matching the "permit" clause specified in the IPv6 ACL is permitted, and IPv6 traffic matching the "deny" clause in the IPv6 ACL is dropped in hardware.</p> <p>The <b>no</b> form of the basic command removes the rACL.</p> <p>The <b>no</b> form of the command with both <b>policy-map</b> and <b>strict-acl</b> options specified, removes the <b>strict-acl</b> option: the rACL with <b>policy-map</b> remains and traffic matching "deny" clauses starts passing to the CPU.</p>
<b>Examples</b>	<p>The following example configures an IPv6 rACL to apply the ACL "b1" with a sequence number of "15" to all interfaces within the default VRF, for all CPU-bound traffic.</p> <pre>device(config)# ipv6 receive access-list b1 sequence 15</pre> <p>The following example configures an IPv6 rACL with a policy map "m1". The rACL applies the ACL "b1" with a sequence number of "15" to all interfaces within the default VRF, for all CPU-bound traffic. Traffic matching the permit clause of the "b1" ACL is rate-limited as defined in in the policy map "m1" and traffic matching the "deny" clause in "b1" ACL is permitted without any rate limiting.</p> <pre>device(config)# ipv6 receive access-list b1 sequence 15 policy map m1</pre>

The following example removes the **strict-acl** option so that traffic matching "deny" clauses starts passing to the CPU: the rACL with the policy map "m1" remains.

```
device(config)# no ipv6 receive access-list b1 sequence 15 policy-map m1 strict-acl
```

**History**

<b>Release version</b>	<b>Command history</b>
5.6.00	This command was modified to support named rACLs.

## ipv6 receive deactivate-acl-all

Deactivates the IPv6 receive access-control list (rACL) configuration and removes all rules from Content Addressable Memory (CAM). The **no** form of this command re-activates the rACL configuration.

**Syntax** **ipv6 receive deactivate-acl-all**

**no ipv6 receive deactivate-acl-all**

**Modes** Global configuration mode.

**Usage Guidelines** Use the **write memory** command to save this configuration permanently and to prevent ACL binding to CAM after reload.

The **no** version of the command removes the configured deactivate option and sets it to default.

**Examples** The following example deactivates the IPv6 rACL configuration.

```
device(config)# ipv6 receive deactivate-acl-all
```

The following example re-activates the IPv6 rACL configuration.

```
device(config)# no ipv6 receive deactivate-acl-all
```

### History

Release	Command History
5.6.00	This command was introduced.



## ipv6 receive delete-acl-all

Deletes IPv6 receive access-control list (rACL) rules from the system.

**Syntax** `ipv6 receive delete-acl-all`

**Modes** Global configuration mode.

**Usage Guidelines** You must confirm that you wish to proceed with the deletion. Enter 'y' or 'n' in response to the prompt "Are you sure?".

**Examples** The following example deletes all IPv6 rACL rules from the system.

```
device(config)# ipv6 receive delete-acl-all
This command deletes all IP Receive ACLs from system.
Are you sure? (enter 'y' or 'n'):y
```

### History

Release	Command History
5.6.00	This command was introduced.

## ipv6 receive rebind-acl-all

Rebinds an IPv6 receive access-control list (rACL).

- Syntax** `ipv6 receive rebind-acl-all`
- Modes** Global configuration mode.
- Usage Guidelines** When access list rules are modified or a policy map associated with a rACL is changed, an explicit rebind must be performed to propagate the changes to the interfaces.
- Examples** The following example rebinds an IPv6 rACL.

```
device(config)# ipv6 receive rebind-acl-all
```

**History**

Release	Command History
5.6.00	This command was introduced.

# ipv6 route

Configures a static IPv6 route for an interface, with a destination network, a next-hop gateway, and an optional administrative distance.

**Syntax** `ipv6 route dest-ipv6-prefix/prefix-length [ethernet| ve] [ slot/port | ve_id ]`

`ipv6 route dest-ipv6-prefix/prefix-length [next-hop-ipv6-address | link-local-next-hop-ipv6-address ] [ <N>gigabitethernet slot/port | null 0 | ve vlan_id ] [ metric ] [ distance number ] [ tag tag ]`

`ipv6 route ipv6-prefix/prefix-length next-hop-vrf vrf_name next-hop-ipv6-address`

`no ipv6 route dest-ipv6-prefix/prefix-length [next-hop-ipv6-address | link-local-next-hop-ipv6-address ] [ metric ] [ distance number ] [ tag tag ]`

`no ipv6 route dest-ipv6-prefix/prefix-length [next-hop-ipv6-address | link-local-next-hop-ipv6-address ] [ <N>gigabitethernet rbridge-id/slot/port | null 0 | ve vlan_id ] [ metric ] [ distance number ] [ tag tag ]`

`no ipv6 route ipv6-prefix/prefix-length next-hop-vrf vrf_name next-hop-ipv6-address`

**Command Default** An IPv6 static route is not configured.

**Parameters**

*dest-ipv6-prefix* Destination IPv6 prefix in hexadecimal with 16-bit values between colons, as specified in RFC 2373.

*prefix-length* A decimal value specifying the length of the IPv6 prefix.

*next-hop-ipv6-address* IPv6 address of the next-hop gateway.

*link-local-next-hop-ipv6-address* IPv6 address of the link-local next-hop gateway.

**next-hop-vrf** *vrf\_name**next-hop-ipv6-address* Specifies a VRF instance and a next-hop IPv6 address.

**<N>gigabitethernet** Represents a valid, physical Ethernet subtype for all available Ethernet speeds. Enter ? to see which interface subtypes are available. Replace **<N>gigabitethernet** with the desired operand (for example, **tengigabitethernet** specifies a 10-Gb Ethernet port). The use of **gigabitethernet** without a speed value specifies a 1-Gb Ethernet port.

*slot* Specifies a valid slot number.

*port* Specifies a valid port number.

**null 0** Causes packets to the selected destination to be dropped by shunting them to the "null0" interface. (This is the only available option.)

**ethernet** *slot/port* Specifies the Ethernet slot or port.

**ve** *ve\_id* Specifies the virtual Ethernet (VE) interface VE ID.

*metric*

Specifies a value that the Layer 3 switch uses to compare this route to other static routes in the IPv6 static route table that have the same destination. The metric applies only to routes that the Layer 3 switch has already placed in the IPv6 static route table. Two or more routes to the same destination with the same metric will load share (as in ECMP load sharing). The range is from 1 through 16. The default is 1.

**distance**

Specifies an administrative distance. This is a value that the Layer 3 switch uses to compare this route with routes from other route sources that have the same destination. By default, static routes take precedence over routes learned by routing protocols. To choose a dynamic route over a static route, configure the static route with a higher administrative distance than the dynamic route.

*number*

The range is from 1 through 255. The default is 1.

**tag**

Specifies a tag value for the route. The route tag can be used for route redistribution to routing protocols by means of route maps (as in IPv4 static route redistribution).

*tag*

A number from 0 through 4294967295. The default is 0.

<b>Modes</b>	Global configuration mode VRF configuration mode
<b>Usage Guidelines</b>	Use this command to configure a static IPv6 route for an interface, with a destination network, a next-hop gateway, and an optional administrative distance.
<b>Examples</b>	To configure the IPv6 ND proxy static route by specifying the destination prefix and the outgoing interface:

**NOTE**

As per the topology mentioned in the packet flow, if the IPv6 ND proxy is configured on R2, then this static route can be configured on R1 with the destination prefix being 2002::/64. The static route can also be configured with outgoing interface as **ve**, such as **ve 10**.

```
R1(config)#
R1(config)#ipv6 route 2002::/64 ethernet 1/1

R1(config)#
R1(config)#ipv6 route 2003::/64 ve 10

R1(config)#vrf green
R1(config-vrf-green)#address-family ipv6
R1(config-vrf-green-ipv6)#ipv6 route 2002::/64 eth 1/1

R1(config)#vrf green
R1(config-vrf-green)#address-family ipv6
R1(config-vrf-green-ipv6)#ipv6 route 2003::/64 ve 10
```

**To show the running-config (with truncated output showing only the static route):**

```
R1(config)#ipv6 route 2002::/64 ethernet 1/1
R1(config)#ipv6 route 2003::/64 ve 10

vrf green
 rd 66:66
  address-family ipv6
   ipv6 route 2002::/64 ethernet 1/1
   ipv6 route 2003::/64 ve 10
R1(config)#exit-vrf
```

## ipv6 route bfd

Enables Bidirectional Forwarding Detection (BFD) monitoring for an IPv6 static route.

**Syntax** `ipv6 route dest-ipv6-prefix/prefix-length next-hop-ipv6-address bfd`

`ipv6 route dest-ipv6-prefix/prefix-length next-hop-ipv6-address bfd [ metric | distance number | name name | tag number ]`

**Command Default** BFD monitoring for an IPv6 static route is not enabled.

**Parameters** `dest-ipv6-prefix`

Specifies the destination IPv6 prefix in hexadecimal with 16-bit values between colons.

`prefix-length`

A decimal value specifying the length of the IPv6 prefix.

`next-hop-ipv6-address`

Specifies the IPv6 address of the next hop.

`metric`

Specifies the cost metric of the route. Valid values range from 1 through 16. The default is 1.

**distance number**

Specifies the administrative distance of the route. Valid values range from 1 through 255. The default is 1.

**name name**

Specifies the name of the route in ASCII characters.

**tag number**

Specifies the tag value of the route to use for route filtering with a route map. Valid values range from 0 through 4294967295. The default is 0.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command removes BFD monitoring from the static route.

**Examples** The following example enables BFD route monitoring on an IPv6 static route and sets the cost metric of the route to 10.

```
device# configure terminal
device(config)# ipv6 route 2001:db8::0/32 2001:db:0:ee44::1 bfd 10
```

The following example enables BFD route monitoring on an IPv6 static route and sets the administrative distance of the route to 55.

```
device# configure terminal
device(config)# ipv6 route 2001:db8::0/32 2001:db:0:ee44::1 bfd distance 55
```

The following example enables BFD route monitoring on an IPv6 static route and sets the name of the route to "routed".

```
device# configure terminal
device(config)# ipv6 route 2001:db8::0/32 2001:db:0:ee44::1 bfd name routed
```

The following example enables BFD route monitoring on an IPv6 static route and sets the tag value of the route to 100.

```
device# configure terminal
device(config)# ipv6 route 2001:db8::0/32 2001:db:0:ee44::1 bfd tag 100
```

# ipv6 router ospf

Enables and configures the Open Shortest Path First version 3 (OSPFv3) routing protocol.

**Syntax** `ipv6 router ospf [ vrf name ]`

`no ipv6 router ospf`

**Command Default** This command is disabled by default.

**Parameters** `vrf name`

Specifies a nondefault VRF.

**Modes** Global configuration mode

**Usage Guidelines** If you save the configuration to the startup-config file after disabling OSPFv3, all OSPFv3 configuration information is removed from the startup-config file.

Use this command to enable the OSPFv3 routing protocol and enter OSPFv3 router or OSPFv3 router VRF configuration mode. OSPFv3 maintains multiple instances of the routing protocol to exchange route information among various VRF instances.

Enter **no ipv6 router ospf** to delete all current OSPFv3 configurations and to block any further OSPFv3 configuration.

**Examples** This example enables OSPFv3 on a default VRF and enters OSPFv3 router configuration mode.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)#
```

## ipv6 route static bfd

Configures Bidirectional Forwarding Detection (BFD) session parameters for IPv6 static routes.

**Syntax** `ipv6 route [ vrf vrf-name ] static-bfd dest-ipv6-address source-ipv6-address [ interval transmit-time min-rx receive-time multiplier number ]`

`no ipv6 route [ vrf vrf-name ] static-bfd dest-ipv6-address source-ipv6-address`

**Command Default** BFD is not configured for an IPv6 static route.

**Parameters** `vrf vrf-name`

Specifies the name of a VRF instance.

`dest-ipv6-address`

Specifies the destination IPv6 address.

`source-ipv6-address`

Specifies the source IPv6 address.

`interval transmit-time`

Specifies the interval, in milliseconds, a device waits to send a control packet to BFD peers. Valid values range from 50 through 30000.

`min-rx receive-time`

Specifies the interval, in milliseconds, a device waits to receive a control packet from BFD peers. Valid values range from 50 through 30000.

`multiplier number`

Specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD determines that the connection to that peer is not operational. Valid values range from 3 through 50.

**Modes** Global configuration mode

**Usage Guidelines** The `interval transmit-time` and `min-rx receive-time` variables are the intervals desired by the local device. The actual values in use will be the negotiated values.

For single-hop static BFD sessions, timeout values are optional because all required information is available from the outgoing interface. For multi-hop BFD sessions, if the configured `interval` and `min-rx` parameters conflict with those of an existing BGP session, the lower values are used.

If you configure a neighbor IPv6 address and a source IPv6 address that already exist in BFD, BFD overwrites the existing interval values and multiplier for the IPv6 addresses with the new values on behalf of the static module.

When Brocade Netron CER Series or Brocade Netron CES Series devices are heavily loaded or under stress, BFD sessions may flap if the configured BFD interval is less than 500 milliseconds with a multiplier value of 3.

The `no` form of the command removes the configured BFD IPv6 static route.

**Examples** The following example configures a BFD session on an IPv6 static route.

```
device# configure terminal
device(config)# ipv6 route static-bfd fe80::a fe80::b interval 100 min-rx 100
multiplier 10
```



## ipv6 router vrrp

Globally enables IPv6 Virtual Router Redundancy Protocol (VRRP).

**Syntax** `ipv6 router vrrp`

`no ipv6 router vrrp`

**Command Default** IPv6 VRRP is not globally enabled.

**Modes** Global configuration mode.

**Usage Guidelines** After globally enabling IPv6 VRRP, the command prompt does not change. Nearly all subsequent IPv6 VRRP configuration is performed at the interface level, but IPv6 VRRP must be enabled globally before configuring IPv6 VRRP instances.

The **no** form of the command globally disables VRRP.

**Examples** The following example globally enables IPv6 VRRP and enters interface configuration mode.

```
device# configure terminal
device(config)# ipv6 router vrrp
device(config)# interface ethernet 1/5
```

## ipv6 router vrrp-extended

Globally enables IPv6 Virtual Router Redundancy Protocol Extended (VRRP-E).

**Syntax** `ipv6 router vrrp-extended`

`no ipv6 router vrrp-extended`

**Command Default** VRRP-E is not globally enabled.

**Modes** Global configuration mode.

**Usage Guidelines** After globally enabling IPv6 VRRP-E, nearly all subsequent IPv6 VRRP-E configuration is performed at the interface level. If IPv6 VRRP-E is not globally enabled, you will see an error message when configuring IPv6 VRRP-E instances.

The **no** form of the command globally disables VRRP-E.

**Examples** The following example globally enables IPv6 VRRP-E and enters interface configuration mode for subsequent IPv6 VRRP-E configuration.

```
device# configure terminal
device(config)# ipv6 router vrrp-extended
device(config-ipv6-vrrpe-router)# interface ethernet 1/5
```

## ipv6 vrrp vrid

Configures an IPv6 Virtual Router Redundancy Protocol (VRRP) virtual router identifier (VRID).

**Syntax** `ip vrrp vrid vrid`

`no ip vrrp vrid vrid`

**Command Default** An IPv6 VRRP VRID does not exist.

**Parameters** `vrid`

Configures a number for an IPv6 VRRP VRID. The range is from 1 to 255.

**Modes** Interface configuration mode.

**Usage Guidelines** Before configuring this command, ensure that IPv6 VRRP is enabled globally or an error stating "Invalid input..." is displayed as you try to create a VRRP instance.

The **no** form of this command removes the IPv6 VRRP VRID from the configuration.

**Examples** The following example configures the IPv6 VRRP VRID 1.

```
device# configure terminal
device(config)# ipv6 router vrrp
device(config)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ipv6 address 3013::2/64
device(conf-if-e1000-1/5)# ipv6 vrrp vrid 2
device(conf-if-e1000-1/5-vrid-2)# owner
device(conf-if-e1000-1/5-vrid-2)# ipv6-address fe80::768e:f8ff:fe2a:0099
device(conf-if-e1000-1/5-vrid-2)# ipv6-address 3013::2
device(conf-if-e1000-1/5-vrid-2)# activate
```

## ipv6 vrrp-extended vrid

Configures an IPv6 Virtual Router Redundancy Protocol Extended (VRRP-E) virtual router identifier (VRID).

**Syntax** `ipv6 vrrp-extended vrid vrid`

`no ipv6 vrrp-extended vrid vrid`

**Command Default** An IPv6 VRRP-E VRID does not exist.

**Parameters** *vrid*

Configures a number for an IPv6 VRRP-E VRID. The range is from 1 to 255.

**Modes** Interface configuration mode.

**Usage Guidelines** Before configuring this command, ensure that IPv6 VRRP-E is enabled globally or an error stating "Invalid input..." is displayed as you try to create a VRRP-E instance.

The **no** form of this command removes the IPv6 VRRP-E VRID from the configuration.

**Examples** The following example configures the IPv6 VRRP-E VRID 2.

```
device# configure terminal
device(config)# ipv6 router vrrp-extended
device(config-ipv6-vrrpe-router)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ipv6 address 3014::2/64
device(conf-if-e1000-1/5)# ipv6 vrrp-extended vrid 2
device(conf-if-e1000-1/5-vrid-2)# backup priority 50 track-priority 10
device(conf-if-e1000-1/5-vrid-2)# ipv6-address fe80::768e:f8ff:fe3a:0099
device(conf-if-e1000-1/5-vrid-2)# ipv6-address 3014::99
device(conf-if-e1000-1/5-vrid-2)# activate
```

## ipv6-address

Configures a virtual IPv6 address for a Virtual Router Redundancy Protocol version 3 (VRRPv3) or VRRP Extended version 3 (VRRP-Ev3) instance.

**Syntax** `ipv6-address { ipv6-address | auto-gen-link-local }`

`no ipv6-address { ipv6-address | auto-gen-link-local }`

**Command Default** A virtual IPv6 address is not configured for a VRRPv3 or VRRP-Ev3 instance.

**Parameters** `ipv6-address`

Configures an IPv6 address.

**auto-gen-link-local**

Automatically generates a virtual IPv6 link-local address for the VRRPv3 instance. Not supported in VRRP-Ev3.

**Modes** Virtual routing ID interface configuration mode

**Usage Guidelines** For VRRP instances, the IPv6 address used for the virtual router must be configured on the device assigned to be the initial VRRP owner device. The same physical IPv6 address cannot be used on any other VRRP device.

If the **auto-gen-link-local** keyword is entered, a virtual IPv6 link-local address is generated automatically for the specific VRRPv3 instance. The virtual link-local address is carried in VRRPv3 advertisements. A manually configured link-local address takes precedence over the automatically generated address.

---

### NOTE

Automatically generated virtual link-local addresses are not supported for VRRP-Ev3 instances.

---

The **no** form of the command removes the virtual router IPv6 address. If the **auto-gen-link-local** keyword was active, the automatically generated virtual IPv6 link-local address is removed for the VRRPv3 instance and subsequent VRRPv3 advertisements will not carry this link-local address.

**Examples** The following example configures a virtual IPv6 address for VRID 1 when IPv6 VRRPv3 is implemented. In this example, the device is configured as the VRRPv3 owner device.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ipv6 address 3013::1/64
device(conf-if-e1000-1/6)# ipv6 vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ipv6-address fe80::768e:f8ff:fe2a:0099
device(conf-if-e1000-1/6-vrid-1)# ipv6-address 3013::1
device(conf-if-e1000-1/6-vrid-1)# activate
```

The following example automatically configures a virtual IPv6 link-local address for VRID 1 when an IPv6 VRRPv3 instance is activated. In this example, the device is configured as the VRRPv3 owner device.

---

**NOTE**

Automatically generated virtual IPv6 link-local addresses are not supported for VRRP-Ev3 instances.

---

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ipv6 address 3013::1/64
device(conf-if-e1000-1/6)# ipv6 vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ipv6-address auto-gen-link-local
device(conf-if-e1000-1/6-vrid-1)# ipv6-address 3013::1
device(conf-if-e1000-1/6-vrid-1)# activate
```

The following example configures a virtual IPv6 address for VRID 2 when VRRP-Ev3 is implemented. In this example, the device is configured as a VRRP-Ev3 backup device and the highest priority device will become the master VRRP-Ev3 device.

```
device# configure terminal
device(config)# ipv6 router vrrp-extended
device(config-ipv6-vrrpe-router)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ipv6 address 3014::1/64
device(conf-if-e1000-1/5)# ipv6 vrrp-extended vrid 2
device(conf-if-e1000-1/5-vrid-2)# backup priority 110
device(conf-if-e1000-1/5-vrid-2)# ipv6-address fe80::768e:f8ff:fe3a:0099
device(conf-if-e1000-1/5-vrid-2)# ipv6-address 3014::99
device(conf-if-e1000-1/5-vrid-2)# activate
```

**History**

Release version	Command history
5.9.00	This command was modified to add the <b>auto-gen-link-local</b> keyword that auto-generates an IPv6 virtual link-local address.

## isis bfd

Enables Bidirectional Forwarding Detection (BFD) on a specific IS-IS interface.

**Syntax** **isis bfd disable**

**no isis bfd**

**Command Default** BFD is disabled by default.

**Parameters** **disable**

Disables BFD on the IS-IS interface.

**Modes** Interface subtype configuration mode

**Usage Guidelines** BFD sessions are initiated if BFD is enabled globally using the **bfd all-interfaces** command in IS-IS router configuration mode. If BFD is disabled using the **no bfd all-interfaces** command in IS-IS router configuration mode, BFD sessions on specific IS-IS interfaces are deregistered.

The **no** form of the command removes all BFD sessions from a IS-IS specified interface.

**Examples** The following example enables BFD on a specific IS-IS Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# isis bfd
```

The following example disables BFD on a specific IS-IS Ethernet interface.

```
device# configure terminal
device(config)# interface ethernet 1/1
device(config-if-e1000-1/1)# isis bfd disable
```

## isis reverse-metric

Configures the reverse metric value on a single IS-IS interface.

**Syntax** `isis reverse-metric [ value ] [ whole-lan ] [ te-def-metric ]`

`no isis reverse-metric [ value ] [ whole-lan ] [ te-def-metric ]`

**Command Default** The `isis reverse-metric` command is disabled by default.

**Parameters** `isis reverse-metric`

Specifies the reverse metric parameter at the interface level.

***value***

Specifies the reverse metric value in metric style. The metric style consists of narrow or wide style. The narrow metric range is from 1 - 63. The wide metric range is from 1 - 16777215. The default value is 16777214 irrespective of the metric style configured. If the reverse-metric value is configured, the local LSP is updated with the sum of the default metric and the reverse metric value. When the IS-IS neighbor router receives the reverse metric value through the IS hello, the neighbor router updates the cost to reach the original IS-IS router with the sum of default metric and the reverse metric value. This helps in shifting traffic to the other alternate paths.

**whole-lan**

Specifies changing the reverse metric parameter for the entire LAN. The **whole-lan** option indicates the whole LAN bit in the flag. If the **whole-lan** option is enabled, the configured reverse metric value affects the entire LAN. If the **whole-lan** option is not enabled, the reverse metric value affects only the neighbor router. This option takes effect only on the multi-access LAN. IS-IS point-to-point interfaces are not affected when the **whole-lan** option is enabled.

**te-def-metric**

Specifies setting the TE default metric sub-TLV. If the **te-def-metric** option is enabled, the router sends a TE default metric sub-TLV within the reverse-metric TLV.

**Modes** IS-IS interface level.

**Usage Guidelines** Use the `isis reverse-metric` command when you are performing network maintenance operations, such as software upgrades, at the link level. When maintenance operations are performed, the link undergoing maintenance should not be used by the neighbor routers to forward transit traffic. In order to shift traffic away from the link undergoing maintenance, configure the `isis reverse-metric` command on the maintenance link. The router undergoing maintenance first advertises a reverse metric TLV in a IS-IS hello PDU to its neighbor router on a point-to-point or multi-access link. When the neighbor router receives a high reverse metric value, the router selects alternate paths to forward traffic while maintenance is going on. The neighbor router adds the reverse metric TLV to its own TE default metric sub-TLV and recalculates its SPF tree and route topology. The neighbor router floods the new LSP containing the extended IS reachability TLV throughout the domain. Traffic gradually shifts onto alternate paths away from the link between the maintenance router and the neighbor router as nodes in the IS-IS domain receive the new LSP. Once the maintenance is complete, you can remove the `isis reverse-metric` command configuration on the link, and the reverse metric TLV in the IS-IS hello PDU is no longer advertised to the neighbor router. The IS-IS neighbor router reverts back to its original IS-IS metric, and the traffic switches to the original IS-IS link to reach its destination.

In a multi-access link, the IS-IS DIS router adds the reverse metric TLV value to each node's default metric value in the pseudonode LSP when the whole-lan flag is set. All non-DIS nodes ignore the



reverse metric TLV. If multiple neighbor routers advertise the reverse metric TLV with the whole LAN flag set, the neighbor router with the highest MAC address takes precedence, and the value advertised by that neighbor is updated in the pseudonode LSP for all neighbors. If some neighbor routers do not set the whole LAN flag, then the reverse metric TLV value advertised by the neighbor router is updated in the pseudonode LSP for that neighbor only.

The S flag is set when the sender of the reverse metric TLV signals to the neighbor router to use the TE sub-tlv for the default metric (sub-tlv type 18) in the reverse metric TLV. When the receiving router finds the S flag set in the reverse metric TLV, the router searches for the TE sub-tlv. The router adds the default metric value in the TE sub-tlv to the configured TE default metric value and recalculates the CSPF.

The **no** form of the command, specified with the configured value, resets the metric value to the default value of 16777214. The **no isis reverse-metric** command removes the entire reverse metric configuration.

---

#### NOTE

The **isis reverse-metric value** command is supported on the Brocade NetIron XMR Series, the Brocade MLX Series, and the Brocade NetIron CER Series and Brocade NetIron CES Series platforms.

---

**Examples** The following example configures the reverse metric value to 40 on a single IS-IS interface level. The **whole-lan** option is enabled to include the entire LAN.

```
device(config)# interface ethernet 2/2
device(config-if-e1000-2/2)# isis reverse-metric ?
DECIMAL          Narrow metric range 1-63, Wide metric range 1-16777214,
                  Default is 16777214
te-def-metric    Update TE default metric sub-tlv
whole-lan        Change metric for whole LAN
device(config-if-e1000-2/2)# isis reverse-metric 40 ?
te-def-metric    Update TE default metric sub-tlv
whole-lan        Change metric for whole LAN
<cr>
device(config-if-e1000-2/2)# isis reverse-metric 40 whole-lan
device(config-if-e1000-2/2)#
```

Use the **show isis** command to display the configuration of the reverse metric value at the global level. The reverse metric value and flags are highlighted in the output.

```
device(config)# show isis
IS-IS Routing Protocol Operation State: Enabled
IS-Type: Level-1-2
System ID: aaaa.bbbb.cccc
Manual area address(es):
    49.2211
Level-1-2 Database State: On
Administrative Distance: 115
Maximum Paths: 4

ISIS Global Reverse Metric 40
ISIS Global Reverse Metric Flags: W S
```

Use the **show isis interface** command to display the configuration of the reverse metric value at the interface level. The reverse metric value and flags are highlighted in the output.

```
device(config)# show isis interface
Total number of IS-IS Interfaces: 1

Interface: eth 1/1
Circuit State: DOWN Circuit Mode: LEVEL-1-2
Circuit Type: BCAST Passive State: FALSE
Circuit Number: 1, MTU: 1500
Level-1 Auth-mode: None
Level-2 Auth-mode: None
Level-1 Metric: 10, Level-1 Priority: 64
Level-1 Hello Interval: 10 Level-1 Hello Multiplier: 3
Level-1 Designated IS: MLX-2-01 Level-1 DIS Changes: 1
Level-2 Metric: 10, Level-2 Priority: 64
Level-2 Hello Interval: 10 Level-2 Hello Multiplier: 3
Level-2 Designated IS: MLX-2-01 Level-2 DIS Changes: 1

IP Enabled: TRUE
IPv6 Enabled: FALSE
MPLS TE Enabled: FALSE
ISIS Reverse Metric 40
ISIS Reverse Metric Flags: W S
LDP-SYNC: Disabled, State: -
```

**History**

Release version	Command history
5.7.00	This command was introduced.

# jitc enable

Enables the Joint Interoperability Test Command (JITC) mode.

**Syntax** `jitc enable`

`no jitc enable`

**Command Default** JITC is not enabled.

**Modes** Global configuration mode.

**Usage Guidelines** When JITC is enabled, the Advanced Encryption Standard - Cipher-Block Chaining (AES-CBC) encryption mode for the Secure Shell (SSH) protocol is disabled and the AES-CTR (Counter) encryption mode is enabled. To enable the AES-only mode for SSH, use the `ip ssh encryption aes-only` command. To disable the AES-CBC encryption mode, use the `ip ssh encryption disable-aes-cbc` command. When the `jitc enable` command is configured, the `ip ssh encryption aes-only` command and the `ip ssh encryption disable-aes-cbc` command are automatically enabled.

When JITC is enabled, the MD5 authentication scheme for NTP is disabled. The SHA1 authentication scheme is available to define the authentication key for NTP.

The `no` form of the command disables the JITC mode and puts the system back to the standard mode and enables both AES-CBC encryption mode and MD5 authentication configuration. The `ip ssh encryption disable-aes-cbc` command is removed from the running configuration. The `ip ssh encryption aes-only` command configuration is retained in the running configuration.

**Examples** The following example enables the JITC mode.

```
device# configure terminal
device(config)# jitc enable
```

In the output below, when the JITC mode is configured, the running configuration displays MD5 as disabled. The `ip ssh encryption aes-only` command and the `ip ssh encryption disable-aes-cbc` command are enabled. The commands are highlighted below.

---

## NOTE

In the output below, the authentication-key entry is displayed when the authentication key for NTP is configured separately.

---

```
device(config)# show run | begin jitc
!
jitc enable
!
ntp
  disable authenticate md5
  authentication-key key-id 1 sha1 2 $b24tb25V
!
ip ssh encryption aes-only
ip ssh encryption disable-aes-cbc
end
```

## History

Release version	Command history
5.8.00	This command was introduced.

jitc enable

# Commands K - Sh

---

## key-add-remove-interval

Alters the timing of the authentication key add-remove interval.

**Syntax** **key-add-remove-interval** *interval*  
**no key-add-remove-interval** *interval*

**Command Default** The interval is 300 seconds.

**Parameters** *interval*

Specifies the add-remove interval in seconds. Valid values range from 0 through 14400. The default is 300.

**Modes** OSPFv3 router configuration mode  
OSPFv3 router VRF configuration mode

**Usage Guidelines** Enter **no key-add-remove-interval** to set the add-remove interval to the default value of 300 seconds.

**Examples** This example sets the key add-remove interval to 240 seconds.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# key-add-remove-interval 240
```

This example sets the key add-remove interval to 210 seconds in a nondefault VRF instance:

```
device# configure terminal
device(config)# ipv6 router ospf vrf red
device(config-ospf6-router-vrf-red)# key-add-remove-interval 240
```

## key-rollover-interval

Alters the timing of the existing configuration changeover.

**Syntax** `key-rollover-interval interval`

`no key-rollover-interval interval`

**Command Default** The interval is 300 seconds.

**Parameters** *interval*

Specifies the key-rollover-interval in seconds. Valid values range from 0 through 14400. The default is 300.

**Modes** OSPFv3 router configuration mode  
OSPFv3 router VRF configuration mode

**Usage Guidelines** In order to have consistent security parameters, rekeying should be done on all nodes at the same time. Use the **key-rollover-interval** command to facilitate this. The key rollover timer waits for a specified period of time before switching to the new set of keys. Use this command to ensure that all the nodes switch to the new set of keys at the same time.

Enter **no key-rollover-interval** to set the rollover interval to the default value of 300 seconds.

**Examples** This example sets the key rollover interval to 420 seconds.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# key-rollover-interval 420
```

This example re-sets the key rollover interval to the default value.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# no key-rollover-interval
```

This example re-sets the key rollover interval to the default value in a nondefault VRF instance.

```
device# configure terminal
device(config)# ipv6 router ospf vrf red
device(config-ospf6-router-vrf-red)# no key-rollover-interval
```

# key-server-priority

Configures the MACsec key-server priority for the MACsec Key Agreement (MKA) group to select key server.

**Syntax** `key-server-priority value`

`no key-server-priority value`

**Command Default** Key-server priority is set to 16. This is not displayed in configuration details.

**Parameters** `value`

Specifies key-server priority. The possible values range from 0 to 255, where 0 is highest priority and 255 is lowest priority. Default is 16.

**Modes** dot1x-mka-cfg-group mode.

**Usage Guidelines** During key-server election, the server with the highest priority (the server with the lowest key-server priority value) becomes the key-server.

The **no** form of the command removes the previous priority setting.

**Examples** The following example explains how to set the key-server priority for MKA group group1 to 20.

```
deviceenable
deviceconfigure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# key-server-priority 20
```

## History

Release version	Command history
5.8.00	This command was introduced.

## I2 policy route-map

Enables Layer 2 PBR by applying a route map that is configured for Layer 2 PBR on an interface.

**Syntax** **I2 policy route-map** *route-map-name*

**no I2 policy route-map** *route-map-name*

**Command Default** Layer 2 PBR is not enabled by default.

**Parameters** *route-map-name*

Specifies the name of the route map to be applied on the physical interface.

**Modes** Interface configuration mode.

**Usage Guidelines** Layer 2 PBR cannot be applied globally. Layer 2 PBR can be applied only at the physical interface level.

If both Layer 2 PBR and Layer 3 PBR are applied on the same interface (or Layer 3 PBR is applied globally), Layer 2 PBR only filters non-IP packets. If only Layer 2 PBR is applied, Layer 2 PBR filters both IP and non-IP packets.

Layer 2 PBR cannot be applied on a VE interface.

Layer 2 PBR cannot be applied on an interface where Layer 2 ACL or Layer 3 ACL is already applied.

Layer 2 PBR cannot be applied on an interface where ACL-based rate limiting is already applied.

The **no** form of the command removes the route map applied on the interface.

**Examples** The following example enables Layer 2 PBR by applying a route map that is configured for Layer 2 PBR on an interface.

```
deviceenable
deviceconfigure terminal
device(config)# mac access-list abc
device(config-mac-acl-abc)# permit any any any etype 8000
device(config-mac-acl-abc)# exit

device(config)# route-map pbr permit 1
device(config-routemap pbr)# match l2acl abc
device(config-routemap pbr)# set next-hop-flood-vlan 100
device(config-routemap pbr)# exit

device(config) interface ethernet 1/1
device(config-if-e10000-1/1)# l2 policy route-map pbr
```

### History

Release version	Command history
5.8.00b	The command was introduced.



# label-range static

Configures the minimum and maximum values for user-configurable static labels.

**Syntax** `label-range static { min-value num | max-value num }`  
`no label-range static { min-value num | max-value num }`

**Parameters** **min-value**

Denotes the lower end of the range for the static labels.

*num*

The range designation and can be between 16 - 499999. The default value is 16.

**max-value**

Denotes the top end of the range for the static labels.

*num*

The range designation and can be between 16 - 499999. The default value is 2047.

**Modes** MPLS router mode (config-mpls).

**Usage Guidelines** Labels are automatically distributed using LDP, RSVP or BGP. If a LSR is connected to a device that supports MPLS forwarding but does not support LDP, static labels can be used to maintain forwarding.

LDP, RSVP or BGP can be used to dynamically distribute label bindings. After an LSR receives labels, it installs the bindings into the *Label Forwarding Information Base (LFIB)* for MPLS forwarding.

- Static labels to IPv4 prefix binding
- Static cross-connects of labels
- To configure static label binding, define a static label range
- Cannot configure static labels for IPv4 VPN prefixes
- Bindings remain in LFIB even if the next hop LSR is down

The **no** form of the command restores the default to 16 for the min-value and to 2047 for max-value.

**Examples** The following example displays the **label-range static** command:

```
deviceconfigure terminal
device(config)# router-mpls
device(config-mpls)# label-range static min 16 max 2047
```

## label-withdrawal-delay

Delays sending a label withdrawal message for a FEC to a neighbor in order to allow the IGP and LDP to converge.

**Syntax** `label-withdrawal-delay secs`

`no label-withdrawal-delay secs`

**Command Default** The default is 60.

**Parameters** `secs`

Specifies the delay period in seconds for the label withdrawal delay timer. The range is 0 - 300.

**Modes** MPLS LDP configuration mode.

**Usage Guidelines** Setting the `secs` variable to zero (0) disables the feature for subsequent events.

Setting the `secs` variable to a value in the range 1 - 300, updates the configured value.

When using the **no** form of the command to restore the default behavior, the specified value for the `secs` variable must match the configured value at the time that the **no** form of the command executes.

**Examples** The following example sets the label withdrawal delay timer to 30 seconds.

```
device(config-mpls-ldp)# label-withdrawal-delay 30
```

The following example restores the command default behavior when the delay period configuration is already 30 seconds.

```
device(config-mpls-ldp)# no label-withdrawal-delay 30
```

The following example disables the label withdrawal delay timer.

```
device(config-mpls-ldp)# label-withdrawal-delay 0
```

### History

Release	Command history
5.5.00	This command is introduced.

# link-protection

Enables link protection for an FRR enabled LSP.

**Syntax** **link-protection**

**no link-protection**

**Command Default** The default configuration is always node protection.

**Modes** FRR-LSP mode (config-mpls-lsp-frr).

**Usage Guidelines** The **no** function of the command sets protection type back to default behavior, which is node protection.

**Examples** The following example displays the configuration example for an adaptive LSP:

```
device#configure terminal
device(config)# router mpls
device(config-mpls)# lsp t1
device(config-mpls-lsp-t1)# to 44.44.44.44
device(config-mpls-lsp-t1)# frr
device(config-mpls-lsp-t1-frr)# link-protection
device(config-mpls-lsp-t1)# enable
```

The following example displays the configuration example for a non-adaptive LSP:

```
device#configure terminal
device(config)# router mpls
device(config-mpls)# lsp t1
device(config-mpls-lsp-t1)# to 44.44.44.44
device(config-mpls-lsp-t1)# adaptive
device(config-mpls-lsp-t1)# enable
device(config-mpls)# lsp t1
device(config-mpls-lsp-t1)# frr
device(config-mpls-lsp-t1-frr)# link-protection
device(config-mpls-lsp-t1)# commit
```

## History

Release	Command history
5.6.00	This command is introduced.

## local-as

Specifies the BGP autonomous system number (ASN) where the device resides.

<b>Syntax</b>	<b>local-as</b> <i>num</i> <b>no local-as</b> <i>num</i>
<b>Parameters</b>	<i>num</i> The local ASN. The range is from 1 through 4294967295.
<b>Modes</b>	BGP configuration mode
<b>Usage Guidelines</b>	Use the <b>no</b> form of this command to remove the ASN from the device. ASNs in the range from 64512 through 65535 are private numbers that are not advertised to the external community.
<b>Examples</b>	This example assigns a separate local AS number. <pre>device# configure terminal device(config)# router bgp device(config-bgp)# local-as 777</pre>

# load-balance mask ip

Masks specific values during ECMP and LAG index hash calculations.

**Syntax** **load-balance mask ip** [ **dst-ip** [ *slot number* | **all** | **pre-symmetriclb** ] | **src-ip** [ *slot number* | **all** | **pre-symmetriclb** ] | **dst-l4-port** [[ *slot number* | **all** ] | **src-l4-port** [ *slot number* | **all** ] | **protocol** [ *slot number* | **all** ] ]

**no load-balance mask ip** [ **dst-ip** [ *slot number* | **all** | **pre-symmetriclb** ] | **src-ip** [ *slot number* | **all** | **pre-symmetriclb** ] | **dst-l4-port** [[ *slot number* | **all** ] | **src-l4-port** [ *slot number* | **all** ] | **protocol** [ *slot number* | **all** ] ]

**Command Default** The functionality is disabled by default.

**Parameters** **dst-ip**

Masks the destination IP address.

**pre-symmetriclb**

Masks the IP address before symmetric load balancing can occur.

*slot number*

Identifies the slot number for the specific source or destination IP address, TCP or UDP source or destination port, or IPv4 protocol.

**all**

Applies the command to all ports within the device.

**src-ip**

Masks the source IP address.

**dst-l4-port**

Masks the Layer 4 destination port.

**src-l4-port**

Masks the Layer 4 source port.

**protocol**

Masks the IPv4 protocol ID.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables the masking of specified values during ECMP and LAG index hash calculations.

**Examples** The following example masks all the Layer 4 source ports within the device.

```
device(config)# load-balance mask ip src-l4-port all
```

The following example masks the source IP address before symmetric load balancing can occur for the IPv4 traffic entering slot 10 of the device.

```
device(config)# load-balance mask ip src-ip pre-symmetriclb 10
```

**History**

**Release version**

**Command history**

5.4.00

This command was introduced.

5.9.00

This command was modified to include the **pre-symmetriclb** option.

## load-balance mask ipv6

Masks specific values during ECMP and LAG index hash calculations for IPv6.

**Syntax** **load-balance mask ipv6** [ **dst-ip** [ *slot number* | **all** | **pre-symmetriclcb** ] | **src-ip** [ *slot number* | **all** | **pre-symmetriclcb** ] | **dst-l4-port** [ *slot number* | **all** ] | **src-l4-port** [ *slot number* | **all** ] | **next-hdr** [ *slot number* | **all** ] ]

**no load-balance mask ipv6** [ **dst-ip** [ *slot number* | **all** | **pre-symmetriclcb** ] | **src-ip** [ *slot number* | **all** | **pre-symmetriclcb** ] | **dst-l4-port** [ *slot number* | **all** ] | **src-l4-port** [ *slot number* | **all** ] | **next-hdr** [ *slot number* | **all** ] ]

**Command Default** The functionality is disabled by default.

**Parameters** **dst-ip**

Masks the destination IPv6 address.

**pre-symmetriclcb**

Masks the IPv6 address before symmetric load balancing can occur.

*slot number*

Identifies the slot number for the specific source or destination IPv6 address, TCP or UDP source or destination port, or IPv6 protocol.

**all**

Applies the command to all ports within the device.

**src-ip**

Masks the source IPv6 address.

**dst-l4-port**

Masks the Layer 4 destination port.

**src-l4-port**

Masks the Layer 4 source port.

**next-hdr**

Masks the IPv6 next header.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables masking of specified values during ECMP and LAG index hash calculations for IPv6.

**Examples** The following example masks all the source IPv6 ports within the device.

```
device(config)# load-balance mask ipv6 src-ip all
```

The following example masks the destination IPv6 address before symmetric load balancing can occur for the IPv6 traffic entering on slot 5 of the device.

```
device(config)# load-balance mask ipv6 dst-ip pre-symmetriclcb 5
```

**History**

Release version	Command history
5.4.00	This command was introduced.
5.9.00	This command was modified to include the <b>pre-symmetriclcb</b> option.

# local-certificate

Specifies the URL for the local peer certificate of a specific trustpoint.

**Syntax** `local-certificate url URL name`

`no local-certificate url URL name`

**Parameters** `url`

Specifies the URL name for the local peer certificate.

*URL name*

The URL name for the local peer certificate.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The `no` form of the removes the local certificate URL name.

**Examples** The following example specifies the local certificate URL name as provided here.

```
device(config)# pki trustpoint brocade1
device(config-pki-trustpoint-brocade1)# local-certificate url http://WIN-
HJ98AK136A0.englab.brocade.com/pki_local_cert
```

**History**

Release version	Command history
5.9.00	This command was introduced.

## location

Configures the location for the Public Key Infrastructure (PKI) entity.

**Syntax** `location string`

**Parameters** *string*

Specifies name of the location for PKI entity.

**Modes** PKI entity configuration mode

**Examples** The following example configures the location for PKI entity.

```
device(config)# pki entity brocade-entity
device(config-pki-entity-brocade-entity)# location brocade_location
```

### History

Release version	Command history
05.8.00	This command was introduced.



## log (OSPFv2)

Controls the generation of OSPFv2 logs.

<b>Syntax</b>	<b>log</b> { <b>adjacency</b> [ <b>dr-only</b> ]   <b>all</b>   <b>bad_packet</b> [ <b>checksum</b> ]   <b>database</b>   <b>memory</b>   <b>retransmit</b> }
	<b>no log</b> { <b>adjacency</b> [ <b>dr-only</b> ]   <b>all</b>   <b>bad_packet</b> [ <b>checksum</b> ]   <b>database</b>   <b>memory</b>   <b>retransmit</b> }
<b>Command Default</b>	Only OSPFv2 messages indicating possible system errors are logged. Refer to the Parameters section for specific defaults.
<b>Parameters</b>	<p><b>adjacency</b> Specifies the logging of essential OSPFv2 neighbor state changes. This option is disabled by default.</p> <p><b>dr-only</b> Specifies the logging of essential OSPF neighbor state changes where the interface state is designated router (DR).</p> <p><b>all</b> Specifies the logging of all syslog messages.</p> <p><b>bad-packet</b> Specifies the logging of bad OSPFv2 packets. This option is enabled by default.</p> <p><b>checksum</b> Specifies all OSPFv2 packets that have checksum errors.</p> <p><b>database</b> Specifies the logging of OSPFv2 LSA-related information. This option is disabled by default.</p> <p><b>memory</b> Specifies the logging of OSPFv2 memory issues. This option is enabled by default.</p> <p><b>retransmit</b> Specifies the logging of OSPFv2 retransmission activities. This option is disabled by default.</p>
<b>Modes</b>	<p>OSPF router configuration mode</p> <p>OSPF router VRF configuration mode</p>
<b>Usage Guidelines</b>	<p>Use the <b>no</b> form of this command to restore the defaults. Use the <b>no log all</b> command to return all OSPFv2 logging options to the default settings.</p> <p>Use this command to disable or re-enable the logging of specific events related to OSPFv2. If this command is not enabled only OSPFv2 messages indicating possible system errors are logged.</p> <p>For interfaces where the designated router state is not applicable, such as point-to-point and virtual links, OSPF neighbor state changes are always logged irrespective of the setting of the <b>dr-only</b> sub-option.</p> <p>A limitation with the <b>dr-only</b> sub-option is that when a DR/BDR election is underway, OSPF neighbor state changes pertaining to non-DR/BDR routers are not logged. Logging resumes once a DR is elected on that network.</p>

**Examples** This example enables the logging of all OSPFv2-related syslog events.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# log all
```

This example enables the logging of OSPFv2 retransmission activities.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# log retransmit
```

## logging enable

Enables system log messages and traps for the specified protocol or event.

**Syntax** `logging enable { bfd | cfm | config-changed | fan-speed-change | fan-state-change | ikev2 | ipsec | link-state-change | mac-mismatch-detection | mgmt-mod-redun-state-change | module-hotswap | mpls | mvrp-vlan | ntp | ospf | rstp | snmp-auth-failure | temp-error | user-login | vrrp-config-validate | vrrp-if-state-change }`

`no logging enable { bfd | cfm | config-changed | fan-speed-change | fan-state-change | ikev2 | ipsec | link-state-change | mac-mismatch-detection | mgmt-mod-redun-state-change | module-hotswap | mpls | mvrp-vlan | ntp | ospf | rstp | snmp-auth-failure | temp-error | user-login | vrrp-config-validate | vrrp-if-state-change }`

**Command Default** Log messages for specific protocols or events are enabled.

<b>Parameters</b>	<b>bfd</b>	Specifies the log messages and traps for BFD.
	<b>cfm</b>	Specifies the log messages and traps for CFM.
	<b>config-changed</b>	Specifies the log messages and traps for configuration data changed.
	<b>fan-speed-change</b>	Specifies the log messages and traps for fan speed change events.
	<b>fan-state-change</b>	Specifies the log messages and traps for fan state change events.
	<b>ikev2</b>	Specifies the log messages and traps for IKEv2 events.
	<b>ipsec</b>	Specifies the log messages and traps for IPsec events.
	<b>link-state-change</b>	Specifies the log messages and traps for link state change events.
	<b>mac-mismatch-detection</b>	Enables or disables the Ethernet MAC address and ARP MAC address mismatch detection syslog message.
	<b>mgmt-mod-redun-state-change</b>	Specifies the log messages and traps for management module redundant state change events.
	<b>module-hotswap</b>	Specifies the log messages and traps for module inserted or removed events.
	<b>mpls</b>	Specifies the log messages and traps for MPLS events.
	<b>mvrp-vlan</b>	Specifies the log messages and traps for MVRP VLAN events.
	<b>ntp</b>	Specifies the log messages and traps for NTP events.
	<b>ospf</b>	Specifies the log messages and traps for OSPF events.
	<b>rstp</b>	Specifies the log messages and traps for RSTP events.
	<b>snmp-auth-failure</b>	Specifies the log messages and traps for RSTP events.

- temp-error** Specifies the log messages and traps for SNMP authentication failure events.
- user-login** Specifies the log messages and traps for temperature error events.
- user-login** Specifies the log messages and traps for login usernames.
- vrrip-config-validate** Specifies the log messages and traps for VRRP for configuration validation events.
- vrrip-if-state-change** Specifies the log messages and traps for VRRP if state change events.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command disables the generation of the specified syslog messages and traps.

**Examples** The following example configures syslog generation for IPsec events.

```
device(config)# logging enable ipsec
```

The following example enables the syslog message to be displayed if there is any source MAC address mismatch between the Layer 2 Ethernet header and the ARP header.

```
device(config)# logging enable mac-mismatch-detection
```

**History**

Release version	Command history
5.9.00	This command was modified to add the <b>mac-mismatch-detection</b> and <b>vrrip-config-validate</b> keywords to the syntax.

# log-status-change

Controls the generation of all OSPFv3 logs.

**Syntax** **log-status-change**

**no log-status-change**

**Command Default** Disabled

**Modes** OSPFv3 router configuration mode

OSPFv3 router VRF configuration mode

**Usage Guidelines** Use this command to disable or re-enable the logging of events related to OSPFv3, such as neighbor state changes and database overflow conditions.

Use the **no** form of this command to restore the default.

**Examples** This example disables the logging of events.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# no log-status-change
```

This example enables the logging of events.

```
device# configure terminal
device(config)# ipv6 router ospf
device(config-ospf6-router)# log-status-change
```

## logs-per-interval-per-mep-rmep

Limits the log generation of individual MEPs or RMEPs in a 15 minute time window.

**Syntax** `logs-per-interval-per-mep-rmep value`

`no logs-per-interval-per-mep-rmep value`

**Command Default** Limiting the log generation for MEPs or RMEPs is not enabled by default.

**Parameters** *value*

Specifies the number of logs generated per MEP or RMEP per 900000 milliseconds. The decimal range is from 1 to 100. The default is 10.

**Modes** CFM Protocol Configuration mode.

**Usage Guidelines** Use the `logs-per-interval-per-mep-rmep value` command to limit the number of logs generated for each MEP or RMEP in a 15 minute time window. When the *value* parameter is configured, the value is uniform for all MEPs and RMEPs. The `no logs-per-interval-per-mep-rmep value` command resets the value to the default value.

---

### NOTE

The `logs-per-interval-per-mep-rmep value` command is supported on Brocade NetIron XMR Series and Brocade NetIron MLX Series devices, and Brocade NetIron CES Series and Brocade NetIron CER Series devices.

---

**Examples** The following example limits the log generation to 20 logs per MEP or RMEP in a 15 minute time window.

```
device(config)#cfm-enable
device(config-cfm)#logs-per-interval-per-mep-rmep 20
device(config-cfm)#
```

Use the `show cfm logs-limit-per-mep-rmep` command to display the *value* parameter configured for the log limit generation for each MEP or RMEP. The *value* parameter is highlighted in the output.

```
device(config-cfm)# show cfm logs-limit-per-mep-rmep
Logs limit per interval (900000 ms) per MEP/RMEP : 20 (Default : 10)
```

### History

Release version	Command history
05.7.00	This command was introduced.

# Isr-id

Enables the feature and sets the desired configured IP address for the feature.

**Syntax** `Isr-id ip_addr`

**Parameters** `ip_addr`

The value set to use as the LSR-ID for LDP protocol.

**Modes** MPLS configuration mode (config-mpls-ldp).

**Usage Guidelines** When the **no** form of the command is executed and LDP protocol is in enabled state, it continues with same LSR-ID because the IP address selected as LSR-ID for LDP protocol is still valid and is the operationally UP IP address on an enabled loopback interface. When, at the time of disabling the feature, LDP protocol is in disabled state (this happens when the loopback interface on which IP address is configured is in the disabled state), the system falls back to default behavior which tries to enable LDP protocol when it finds a valid IP address on any one of the enabled loopback interfaces.

In order to disable the feature, specify the exact IP address during configuration of the feature.

The user can configure only the IPv4 address.

**Examples** The following example displays the output of the **Isr-id** command:

```
device> enable
device# config t
device(config)# router mpls
device(config-mpls)# ldp
device(config-mpls-ldp)# lsr-id 22.22.22.22
```

## History

Release	Command history
5.5.00	This command is introduced.

## mac-age-time

Tunes the system so it can function the most effectively based on the deployment and a specific configuration.

<b>Syntax</b>	<b>mac-age-time</b> [ <i>dec</i>   <b>vpls</b> [ <b>local</b>   <b>remote</b> ] ]
<b>Parameters</b>	<p><i>dec</i> Sets the aging period, in seconds, to age the software MAC table.</p> <p><b>vpls</b> Sets the aging period for VPLS mac entries.</p> <p><b>local</b> MAC entries learned from local endpoints.</p> <p><b>remote</b> MAC entries learned from PW.</p>
<b>Modes</b>	Global configuration mode.
<b>Usage Guidelines</b>	<ul style="list-style-type: none"> <li>The values are bound by the same global system range shared with the regular MAC entries.</li> <li>The default values remain the same, which are 300 seconds for VPLS local entries and 600 seconds for the remote entries.</li> <li>Age time "0" disables the software aging. VPLS MAC follows the same format to be consistent. However, the value "0" is hidden as the valid range.</li> <li>When the software aging is disabled after the hardware aging is kicked in, and the software aging has already started, the age field displays the time value that elapsed prior to the aging being disabled.</li> <li>When the aging is re-enabled after a disable, the software aging resumes from the age value where it was stopped.</li> <li>Under the node <i>vpls</i>, you can specify a separate timer value for the local and the remote timers.</li> <li>The VPLS age timers are fully configurable for both local and remote entries.</li> <li>The formula '2 x' between the local timer and the remote timer is removed. Now, you have the flexibility to specify values for the age timers independently for the local and the remote entries.</li> </ul>
<b>Examples</b>	The following example displays a sample configuration for the <b>mac-age-time</b> command:

```
device(config)# mac-age-time vpls remote 240
```

### History

Release	Command history
5.5.00	This command is introduced.



# mac-move-det-syslog

Enables the display of MAC movement syslog messages.

**Syntax** **mac-move-det-syslog**

**no mac-move-det-syslog**

**Command Default** By default, MAC movement syslog messages are displayed.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables the display of MAC movement syslog messages.

---

## NOTE

This command is only supported on Brocade NetIron MLX Series devices.

---

**Examples** The following example shows the MAC movement syslog message output when **mac-move-det-syslog** command is used.

```
device(config)# mac-move-det-syslog
device(config)# show arp

Total number of ARP entries: 2
(In all VRFs)

Entries in default routing instance:
IP Address      MAC Address      Type      Age Port (Vpls-Id, Vlan)/ Vpls-Id:Peer
1  10.19.19.1     0010.9400.0606   Dynamic   1  1/24
2  172.26.67.1    0024.381c.b900   Dynamic   1  mgmt1
device(config)# exit
device#
SYSLOG: <12>Sep 25 02:43:07 IP/ARP: IP address 19.19.19.1 MAC movement detected,
changed from MAC 0010.9400.0606 / port 1/24 to MAC 0010.9400.0001 / port 1/24

device#
device#
device# configure terminal
device(config)# show arp
Total number of ARP entries: 2
(In all VRFs)

Entries in default routing instance:
IP Address      MAC Address      Type      Age Port (Vpls-Id, Vlan)/ Vpls-Id:Peer
1  10.19.19.1     0010.9400.0001   Dynamic   1  1/24
2  172.26.67.1    0024.381c.b900   Dynamic   2  mgmt1
device(config)#
device(config)#
SYSLOG: <12>Sep 25 02:43:40 IP/ARP: IP address 19.19.19.1 MAC movement detected,
changed from MAC 0010.9400.0001 / port 1/24 to MAC 0010.9400.0606 / port 1/24
```

The following example shows the MAC movement syslog message output when the display is disabled.

```
device(config)#no mac-move-det-syslog
device(config)#
device(config)# exit
device# show arp
Total number of ARP entries: 2
(In all VRFs)

Entries in default routing instance:
IP Address      MAC Address      Type      Age Port (Vpls-Id, Vlan)/ Vpls-Id:Peer
```

```
1 10.19.19.1 0010.9400.0001 Dynamic 1 1/24  
2 172.26.67.1 0024.381c.b900 Dynamic 2 mgmt1  
device#  
device#
```

**History**

<b>Release version</b>	<b>Command history</b>
5.7.00	This command was introduced.

# macsec cipher-suite

Enables GCM-AES-128 bit encryption or GCM-AES-128 bit integrity checks on MACsec frames transmitted between group members.

**Syntax** `macsec cipher-suite gcm-aes-128 [ integrity-only ]`

`no macsec cipher-suite gcm-aes-128 [ integrity-only ]`

**Command Default** By default GCM-AES-128 bit encryption or integrity checking is not enabled. Frames are encrypted starting with the first byte of the data packet, and ICV checking is enabled.

**Parameters** `gcm-aes-128`

Enables GCM-AES-128 bit encryption.

`integrity-only`

Enables GCM-AES-128 bit integrity checks.

**Modes** dot1x-mka-cfg-group mode.

**Usage Guidelines** The `macsec cipher-suite` command can be used in conjunction with an encryption offset configured using the `macsec confidentiality-offset` command.

The no form of the command restores the default encryption and integrity checking.

---

## NOTE

- When cipher suite is configured without integrity the capability of the system is confidentiality and integrity plus confidentiality offset 0.
  - When integrity only is configured, then confidentiality offset configuration is not allowed and vice-versa.
- 

**Examples** The following example enables GCM-AES-128 encryption for group1.

```
device# configure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# macsec cipher-suite gcm-aes-128
```

The following example enables GCM-AES-128 bit integrity checking for group1.

```
device# configure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# macsec cipher-suite gcm-aes-128 integrity-only
```

## History

---

### Release version

### Command history

5.8.00

This command was introduced.

---

## macsec confidentiality-offset

Configures the offset size for MACsec encryption.

**Syntax** `macsec confidentiality-offset size`  
`no macsec confidentiality-offset size`

**Command Default** By default the offset size is set to 0.

**Parameters** `size`

Specifies the off-set value of 0 bytes. Valid values are:

<b>0</b>	Complete packet is encrypted.
<b>30</b>	Encryption begins at byte 31 of the data packet.
<b>50</b>	Encryption begins at byte 51 of the data packet.

**Modes** dot1x-mka-cfg-group mode

**Usage Guidelines** The **no** form of the command disables encryption offset on all interfaces in the MACsec MKA group. This command is applicable only when encryption is enabled for the MACsec group using the **macsec cipher-suite** command.

---

### NOTE

Configuring the confidentiality off-set value to 0 bytes is not allowed.

---

**Examples** The following example configures a 30-byte offset on encrypted transmissions as part of the parameters for group1.

```
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# macsec confidentiality-offset 30
```

### History

Release version	Command history
5.8.00	This command was introduced.

# macsec frame-validation

Enables validation checks for frames with MACsec headers and configures the validation mode (strict or not strict).

**Syntax** `macsec frame-validation [ disable | check | strict ]`

`no macsec frame-validation [ disable | check | strict ]`

**Command Default** By default **strict** parameter is set as frame-validation mode.

**Parameters** **disable**

Disables validation checks for frames with MACsec headers.

**check**

Enables validation checks for frames with MACsec headers and configures non-strict validation mode. If frame validation fails, counters are incremented but packets are accepted.

**strict**

Enables validation checks for frames with MACsec headers and configures strict validation mode. If frame validation fails, counters are incremented and packets are dropped.

**Modes** dot1x-mka-cfg-group mode.

**Usage Guidelines** The **no** form of the command restores the default mode of validation, (validation checks for frames with MACsec headers is disabled).

**Examples** The following example enables validation checks for frames with MACsec headers on group group1 and configures strict validation mode.

```
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# macsec frame-validation check
```

**History**

Release version	Command history
5.8.00	This command was introduced.

## macsec replay-protection

Specifies the action to be taken when packets are received out of order, based on their packet number. If replay protection is configured, you can specify the window size within which out-of-order packets are allowed.

**Syntax** `macsec replay-protection [ strict | out-of-order window-size size ]`

`no macsec replay-protection [ strict | out-of-order window-size size ]`

**Command Default** Macsec replay protection is enabled in Strict mode.

**Parameters** **strict**

Does not allow out-of-order packets.

**out-of-order window size size**

Specifies the allowable window within which an out-of-order packet can be received. Allowable range is from 1 through 4294967295.

**Modes** dot1x-mka-cfg-group mode

**Usage Guidelines** The **no** form of the command disables macsec replay protection.

**Examples** The following example configures group group1 to accept packets with window size 100.

```
device# configure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)# macsec replay-protection out-of-order
window-size 100
```

**History**

Release version	Command history
5.8.00	This command was introduced.

# match identity

Configures the selection of IKEv2 profile Peer Authorization Database (PAD) for a peer based on local or remote identity parameters received.

**Syntax** **match identity** {**local** {**address** *ip address* | **dn** *dn name* | **email** *email address* | **fqdn** *fqdn name* | **key-id** *key ID name* } | **remote** {**address** *ip address* | **dn** *dn name* | **email** *email address* | **fqdn** *fqdn name* | **key-id** *key ID name* } }

**no match identity** {**local** {**address** *ip address* | **dn** *dn name* | **email** *email address* | **fqdn** *fqdn name* | **key-id** *key ID name* } | **remote** {**address** *ip address* | **dn** *dn name* | **email** *email address* | **fqdn** *fqdn name* | **key-id** *key ID name* } }

<b>Parameters</b>	<i>ipv4 address</i>	
	<i>dn name</i>	Specifies the local IP address in the identity parameter received.
	<i>email address</i>	Specifies the DN value.
	<i>fqdn name</i>	Specifies the email address.
	<i>key id name</i>	Specifies the FQDN name.
	<i>ipv4 address</i>	Specifies the key ID name.
	<i>dn name</i>	Specifies the remote IP address in the identity parameter received.
	<i>email address</i>	Specifies the DN name for the remote identity parameter received.
	<i>fqdn name</i>	Specifies the email address for the remote identity parameter received.
	<i>key id name</i>	Specifies the FQDN name for the remote identity parameter received.
		Specifies the key ID name for the remote identity parameter received.

**Modes** IKEv2 profile configuration mode

## Usage Guidelines

**Examples** The following example configures the selection of IKEv2 profile (PAD) for a peer based on local IPv4 address.

```
device(config)# ikev2 profile brocade
device(config-ikev2-profile-brocade)# match identity local address 10.20.20.10
```

## History

Release version	Command history
05.8.00	This command was introduced.

# match l2acl

Configures a route map that matches with the configured Layer 2 ACL.

**Syntax** `match l2acl { acl-number | acl-name }`  
`no match l2acl { acl-number | acl-name }`

**Command Default** The Layer 2 ACL information is not configured in the route map configuration.

**Parameters** *acl-number*  
 Specifies the numbered Layer 2 ACL.  
*acl-name*  
 Specifies the named Layer 2 ACL.

**Modes** Route map configuration mode .

**Usage Guidelines** Five Layer 2 ACLs separated by spaces can be added in the **match l2acl** configuration of the route map.

The **no** form of the command removes the Layer 2 ACL match statement from the route map.

**Examples** The following example configures a route map that matches with the configured Layer 2 ACL.

```
device(config)# route-map xGW_map permit 1
device(config-routemap xGW_map)# match l2acl abc
```

The following example configures multiple Layer 2 ACLs to a route map.

```
device(config)# route-map xGW_map permit 1
device(config-routemap xGW_map)# match l2acl 400 401 402
```

History	Release version	Command history
	5.8.00b	The command was introduced.



# method

Configures the IKEv2 authentication method.

**Syntax** `method {local {ecdsa384 | pre-shared} | remote {ecdsa384 | pre-shared} }`  
`no method {local {ecdsa384 | pre-shared} | remote {ecdsa384 | pre-shared} }`

**Parameters**

- local** Specifies the local authentication method.
- remote** Specifies the remote authentication method.
- ecdsa384** Specifies the digital signature for the authentication certificate.
- pre-shared** Specifies the pre-shared key value.

**Modes** IKEv2 auth-proposal configuration mode

## Usage Guidelines

**Examples** The following example configures IKEv2 authentication method.

```
device(config)# ikev2 auth-proposal brocade
device(config-ike-auth-brocade)# method local ecdsa384
```

History	Release version	Command history
	05.8.00	This command was introduced.

## metric-type

Configures the default metric type for external routes.

**Syntax** `metric-type { type1 | type2 }`

`no metric-type { type1 | type2 }`

**Command Default** Type 2

**Parameters** `type1`

The metric of a neighbor is the cost between itself and the device plus the cost of using this device for routing to the rest of the world.

`type2`

The metric of a neighbor is the total cost from the redistributing device to the rest of the world.

**Modes** OSPF router configuration mode  
 OSPFv3 router configuration mode  
 OSPF router VRF configuration mode  
 OSPFv3 router VRF configuration mode

**Usage Guidelines** Use the **no** form of this command to return to the default setting. You must specify a type parameter when using the **no** form.

**Examples** This example sets the default metric type for external routes to type 1.

```
device# configure terminal
device(config)# router ospf
device(config-ospf6-router)# metric-type type1
```

# mka-auth-fail-action

Configures MACsec Key Agreement (MKA) authentication fail action on MKA group.

**Syntax** **mka-auth-fail-action** [ **allow-unencrypted-traffic** | **deny-all-traffic** ]

**no mka-auth-fail-action** [ **allow-unencrypted-traffic** | **deny-all-traffic** ]

**Command Default** By default, **deny-all-traffic** is enabled.

**Parameters** **allow-unencrypted-traffic**

Allows unencrypted traffic exchange between peers, even if MKA authentication fails.

**deny-all-traffic**

Drops all traffic exchange between peers, if MKA authentication fails.

**Modes** MKA group configuration mode.

**Usage Guidelines** The key-server is elected by comparing key-server priority values during MKA message exchange between peer devices, in-case no peer is elected as key server then the MKA protocol moves to failed state. Under such scenario default behavior is to drop all the traffic on the link. However this behavior can be controlled using **mka-auth-fail-action** command by allowing unencrypted traffic exchange between peer devices even if MKA protocol fails.

The **no** form of the command disables MKA authentication fail action configuration on MKA group.

**Examples** The following example explains how to configure MKA authentication fail action on MKA group.

```
device(config)#dot1x-mka-enable
device(config-dot1x-mka)#mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)#mka-auth-fail-action allow-unencrypted-traffic
```

**History**

Release version	Command history
5.8.00	This command was introduced.

## mka-cfg-group

Configures a MACsec Key Agreement (MKA) configuration groups and enabling this command will enter into mka-cfg-group mode .

<b>Syntax</b>	<b>mka-cfg-group</b> <i>group-name</i>
	<b>no mka-cfg-group</b> <i>group-name</i>
<b>Parameters</b>	<i>group-name</i> Specifies the MKA configuration group name that can be applied to ports.
<b>Modes</b>	dot1x-mka configuration mode.
<b>Usage Guidelines</b>	The <b>dot1x-mka-enable</b> command must be executed before the <b>mka-cfg-group</b> command can be used.

---

### NOTE

1. When a group is created, all group parameters will be assigned with the default values.
  2. Maximum number of groups allowed is 128.
- 

The **no** form of this command deletes the MKA configuration group.

**Examples** The following example configures the MKA configuration group, group1.

```
device(config-dot1x-mka)# mka-cfg-group group1
device(config-dot1x-mka-cfg-group-group1)#
```

### History

Release version	Command history
5.8.00	This command was introduced.

## neighbor bfd

Enables Bidirectional Forwarding Detection (BFD) sessions for specified BGP neighbors or peer groups.

**Syntax** **neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **bfd** { **holdover-interval** *time* | **min-tx** *transmit-time* **min-rx** *receive-time* **multiplier** *number* }

**no neighbor** { *ip-address* | *ipv6-address* | *peer-group-name* } **bfd** { **holdover-interval** *time* | **min-tx** *transmit-time* **min-rx** *receive-time* **multiplier** *number* }

**Command Default** BFD sessions are not enabled on specific BGP neighbors or peer groups.

**Parameters**

*ip-address* Specifies the IP address of the neighbor.

*ipv6-address* Specifies the IPv6 address of the neighbor.

*peer-group-name* Specifies a peer group.

**holdover-interval** *time* Specifies the holdover interval, in seconds, for which BFD session down notifications are delayed before notification that a BFD session is down. Valid values range from 1 through 30.

**min-tx** *transmit-time* Specifies the interval, in milliseconds, a device waits to send a control packet to BFD peers. Valid values range from 50 through 30000. The default value is 1000 (unless changed at the global level).

**min-rx** *receive-time* Specifies the interval, in milliseconds, a device waits to receive a control packet from BFD peers. Valid values range from 50 through 30000. The default value is 1000 (unless changed at the global level).

**multiplier** *number* Specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD determines that the connection to that peer is not operational. Valid values range from 3 through 50.

**Modes** BGP configuration mode  
BGP address-family IPv4 unicast VRF configuration mode

**Usage Guidelines** Before using the **holdover-interval**, **min-tx**, **min-rx**, and **multiplier** parameters, you must first enable BFD.

When Brocade NetIron CER Series or Brocade NetIron CES Series devices are heavily loaded or under stress, BFD sessions may flap if the configured BFD interval is less than 500 milliseconds with a multiplier value of 3.

The **no** form of this command removes the BFD for BGP configuration for BGP neighbors or peer groups.

**Examples** The following example sets the BFD holdover interval for a specified peer group to 18.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# neighbor pgl bfd holdover-interval 18
```

The following example sets the BFD session timer values for a BGP neighbor with the IP address 10.1.1.1.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# neighbor 10.1.1.1 bfd min-tx 120 min-rx 150 multiplier 8
```

The following example sets the BFD session timer values for a BGP neighbor with the IP address 10.1.1.1 for VRF "red" in BGP address-family IPv4 unicast VRF configuration mode.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# address-family ipv4 unicast vrf red
device(config-bgp-ipv4u-vrf)# neighbor 10.1.1.1 bfd min-tx 120 min-rx 150 multiplier 8
```

## neighbor fail-over

Enables or disables Bidirectional Forwarding Detection (BFD) protocol support for failover.

**Syntax** `neighbor { ip-address | ipv6-address | peer-group-name } fail-over { bfd-enable | bfd-disable }`

`no neighbor { ip-address | ipv6-address | peer-group-name } fail-over { bfd-enable | bfd-disable }`

**Command Default** BFD support for failover is disabled.

**Parameters** *ip-address*

Specifies the IP address of the neighbor.

*ipv6-address*

Specifies the IPv6 address of the neighbor.

*peer-group-name*

Specifies a peer group.

**bfd-enable**

Enables BFD support for failover.

**bfd-disable**

Disables BFD support for failover.

**Modes** BGP configuration mode

BGP address-family IPv4 unicast VRF configuration mode

**Usage Guidelines** The **no** form of the command disables BFD support for failover.

**Examples** The following example enables BFD support for failover for a BGP neighbor with the IP address 10.1.1.1.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# neighbor 10.1.1.1 fail-over bfd-enable
```

The following example enables BFD support for failover for a BGP neighbor with the IP address 10.1.1.1 for VRF instance "blue" in BGP address-family IPv4 unicast VRF configuration mode.

```
device# configure terminal
device(config)# router bgp
device(config-bgp)# address-family ipv4 unicast vrf blue
device(config-bgp-ipv4u-vrf)# neighbor 10.1.1.1 fail-over bfd-enable
```

The following example enables BFD support for failover for a BGP peer group.

```
device# configure terminal
device(config)# router bgp
device(config-bgp-ipv4u-vrf)# neighbor pgl fail-over bfd-enable
```

## neighbor next-hop-self (BGP)

Causes the device to list itself as the next hop in updates that are sent to the specified neighbor.

**Syntax** `neighbor ip-address | ipv6-address | peer-group-name next-hop-self [ always ]`

`no neighbor ip-address | ipv6-address | peer-group-name next-hop-self`

**Parameters** *ip-address*

The IPv4 address of the neighbor.

*ipv6-address*

The IPv6 address of the neighbor.

*peer-group-name*

The peer group name configured by the `neighbor peer-group-name`

**always**

Enables this feature for route reflector (RR) routes.

**Modes** BGP configuration mode.

**Usage Guidelines** Use this command to cause the device to list itself as the next hop in updates that are sent to the specified neighbor.

Use the **no** form of this command to remove this configuration at BGP level.

**Examples** The following example configures the device to list itself as the next hop in updates sent to a neighbor with the IP address 10.157.22.26.

```
device# config
device(config)# router bgp
device(config-bgp-router)# neighbor 10.157.22.26 next-hop-self
```

The following example configures the device to list itself as the next hop in updates sent to a neighbor that is a route-reflector client of the device.

```
device# config
device(config)# router bgp
device(config-bgp-router)# neighbor 10.157.22.26 next-hop-self always
```



## non-preempt-mode

Disables preempt mode for a Virtual Router Redundancy Protocol (VRRP) or VRRP Extended (VRRP-E) backup device.

**Syntax**    **non-preempt-mode**

**no non-preempt-mode**

**Command Default**    Preemption is enabled by default.

**Modes**    Virtual routing ID interface configuration mode.

**Usage Guidelines**    This command is supported in VRRP and VRRP-E. When the **non-preempt-mode** command is entered, a backup device with a higher VRRP priority is prevented from taking control of the virtual routing ID (VRID) from another backup that has a lower priority, but has already assumed control of the VRID. Disabling preemption is useful to prevent flapping when there are multiple backup devices and a backup with a lower priority assumes the role of master. When other backup devices with higher priority are back online, the role of master can flap between devices.

In VRRP, the owner device always assumes the role of master when it comes back online, regardless of the preempt mode setting.

Enter **no non-preempt-mode** to reenables preemption.

**Examples**    The following example disables preempt mode for a virtual-router ID 1 session:

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/5
device(conf-if-e1000-1/5)# ip address 10.53.5.3/24
device(conf-if-e1000-1/5)# ip vrrp vrid 1
device(conf-if-e1000-1/5-vrid-1)# non-preempt-mode
```

## ocsp-url

Sets the Online Certificate Status Protocol (OCSP) URL name to determine the revocation state of a certificate.

<b>Syntax</b>	<b>ocsp-url</b> <i>URL name</i>				
	<b>no ocsp-url</b> <i>URL name</i>				
<b>Parameters</b>	<i>URL name</i> The OSCP URL name.				
<b>Modes</b>	PKI trustpoint configuration mode.				
<b>Usage Guidelines</b>	The <b>no</b> form of the command removes the OCSP URL name.				
<b>Examples</b>	The following example specifies the OCSP URL name as provided here.  <pre>device(config)# pki trustpoint brocade1 device(config-pki-trustpoint-brocadel)# ocsp-url http://WIN- HJ98AK136A0.englab.brocade.com/ocsp</pre>				
<b>History</b>	<table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>5.9.00</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release version	Command history	5.9.00	This command was introduced.
Release version	Command history				
5.9.00	This command was introduced.				

# openflow controller source-interface

Configures a source-interface for the connection from the device to the controller.

**Syntax** **openflow controller source-interface** { **ethernet** *slot/port* | **loopback** *number* | **ve** *number* } **force-reconnect**

**no openflow controller source-interface** { **ethernet** *slot/port* | **loopback** *number* | **ve** *number* } **force-reconnect**

**Command Default** The CLI command is applicable only when the device is in active mode. The device initiates connection to the remote OpenFlow controller.

**Parameters**

- ethernet** *slot port*  
Gives information about a particular slot and port in an internet
- loopback** *number*  
Specifies a loopback interface.
- ve** *number*  
Specifies a virtual interface.
- force-reconnect**  
Forces the existing connections to use the newly configured source-interface.

**Modes** Privileged EXEC mode

**Usage Guidelines** When adding a new controller to the device, a connection will be attempted to the controller IP address using the configured source-interface. If the source-interface has no IP address configured or the interface is down, the syslog messages will be generated and a connection attempt will be made again in 15 seconds.

**Examples** To see the source-interface, use this command.

```
device(config)#openflow controller ?
ip-address      Set the Controller IPv4 address
passive        Configure passive connection mode
source-interface Set the Source Interface to be used for controller
connections
```

If a new controller is added after this, routing table will be used to connect to the controller.

```
Device(config)#openflow controller source-interface ?
ethernet      Ethernet interface
loopback      Loopback interface
ve            Virtual Ethernet interface
```

For a specified ethernet interface, use this command.

```
device(config)#openflow controller source-interface ethernet 2/2?
force-reconnect Force the existing connections to use the newly configured
source-interface
```

## History

Release version	Command history
5.8.00	This command was introduced.

# openflow enable

Enables or disables the OpenFlow hybrid port-mode on the port.

**Syntax** `openflow enable [ layer2 | layer3 | layer23 [hybrid-mode ] ]`  
`no openflow enable [ layer2 | layer3 | layer23 [hybrid-mode ] ]`

**Parameters**

- layer2** Enables Layer 2 matching mode for flows.
- layer3** Enables Layer 3 matching mode for flows.
- layer23 hybrid-mode** Enables Layer 2 and Layer 3 matching mode for flows with an option for hybrid port-mode.

**Modes** Interface configuration mode.

**Usage Guidelines** In interface configuration mode, this command enables Layer 2 or Layer 3 matching mode for flows with an optional enabling of hybrid port-mode.

---

**NOTE**

OpenFlow must be globally enabled before the Layer 2 or Layer 3 matching modes can be specified.

---

**Examples** After OpenFlow 1.3 is enabled, the following example configures Layer 2 and Layer 3 matching mode for flows.

```
device# configure terminal
device(config)# openflow enable ofv130
device(config)# interface ethernet 1/1/1
device(config-if-1/1/1)# openflow enable layer 23
```

---

**History**

Release	Command History
---------	-----------------

5.6.00	This command was modified to display OpenFlow hybrid port mode information.
--------	---

---

# openflow hello-reply disable

Allows the second Hello message (Hello-reply) to be disable on the OpenFlow Controller.

**Syntax** **openflow hello-reply disable**

**Command Default** This command needs to be run and saved when connecting to the OpenFlow Controller and any other controllers by default.

**Modes** EXEC and Privileged EXEC mode  
Global configuration mode

**Usage Guidelines** When the OpenFlow Controller receives the Hello message that the controller sent, it replies with another Hello message using the same transaction-ID as in the received Hello message.

**Examples**

```
device(config)# openflow ?
  controller          Configure controller
  default-behavior    Default forwarding for no match packets
  enable              Enable/disable OpenFlow
  hello-reply         Configure HELLO Reply for HELLO originated from Controller

device(config)# openflow hello-reply ?
  disable             Disable HELLO Reply from the switch/router

device(config)# openflow hello-reply disable ?

device# show openflow
Administrative Status:      Enabled
SSL Status:                 Enabled
Source-Interface:          Not Configured
Source-Interface Status:   NA

Controller Type:           ofv130
HELLO Reply:               disabled
Number of Controllers:     2
.....

device# show running-config | i openflow
openflow enable ofv130
openflow hello-reply disable
```

## History

Release version	Command history
NI05.7.00	This command was introduced.

## org-name

Configures the organization name for the Public Key Infrastructure (PKI) entity.

**Syntax** `org-name string`

**Parameters** `string`

Specifies name of the organization for the PKI entity.

**Modes** PKI entity configuration mode.

**Examples** The following example configures the organization for PKI entity.

```
device(config)# pki entity brocade-entity  
device(config-pki-entity-brocade-entity)# org-name Brocade
```

**History**

Release version	Command history
5.8.00	This command was introduced.

## org-unit-name

Configures the unit name of the organization to which the Public Key Infrastructure (PKI) entity belongs to.

**Syntax** `org-unit-name string`

**Parameters** `string`

Specifies unit name of the organization for PKI entity.

**Modes** PKI entity configuration mode.

**Examples** The following example configures unit of the organization the PKI entity belongs to.

```
device configure terminal
device(config)# pki entity brocade-entity
device(config-pki-entity-brocade-entity)# org-unit-name routing
```

### History

Release version	Command history
5.8.00	This command was introduced.

## owner

Designates a virtual router as the Virtual Router Redundancy Protocol (VRRP) owner and configures track and priority values.

**Syntax** **owner** [ **priority** *value* ] [ **track-priority** *value* ]

**no owner** [ **priority** *value* ] [ **track-priority** *value* ]

**Command Default** No virtual routers are designated as the VRRP owner.

**Parameters** **priority** *value*

Abdicates owner status by setting a value that is lower than backup default priority value.

**track-priority** *value*

Sets the priority value if track port fails.

**Modes** Virtual routing ID interface configuration mode.

**Usage Guidelines** This command specifies that the device on which it is configured owns the IP address that is associated with the virtual router. This device owns the IP address configured as the virtual router making this device the default VRRP master router and its priority is set to 255.

This command must be entered before the **ip-address** command can be configured for a VRRP virtual routing ID.

The **no** form of this command removes the virtual router configuration.

**Examples** The following example configures the device as the VRRP owner.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.5.1
device(conf-if-e1000-1/6-vrid-1)# activate
```

The following example configures the device as the VRRP owner and sets the track priority to 10.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# owner track-priority 10
device(conf-if-e1000-1/6-vrid-1)# ip-address 10.53.5.1
device(conf-if-e1000-1/6-vrid-1)# activate
```



## permit (arp-guard-access-list)

Specifies the required set of ACL rules and filters for an associated ARP guard group.

**Syntax** `permit vlan-id src-ip-address [ src-mac-address | any ]`

`no permit vlan-id src-ip-address [ src-mac-address | any ]`

**Command Default** If this command is not entered, no ACL rules or filters are associated with an ARP guard group.

**Parameters** *vlan-id*

Specifies a VLAN ID in the range between 1 and 4090.

*src-ip-address*

Specifies a source IP address.

*src-mac-address*

Specifies a source MAC address.

**any**

Specifies all addresses.

**Modes** ARP-Guard access-list name mode.

**Usage Guidelines** The **no** form of the command removes the rules and filters for the specific ARP guard group.

**Examples** The following command example specifies the required set of ACL rules and filters for the AS201 ARP guard group.

```
device# configure terminal
device(config)# arp-guard-access-list AS201
device(config-arp-guard-access-list-AS201)#permit 100 1.2.3.4 1111.2222.3333
```

**History**

Release version	Command history
5.7.00	This command was introduced.

# pim neighbor-filter

filters the neighbor routers on an interface.

**Syntax** [ ip | ipv6 ] **pim neighbor-filter** *aclname*

**no** [ ip | ipv6 ] **pim neighbor-filter** *aclname*

**Parameters** **acl name**  
Filters neighbor to participate in PIM.

**Modes** Global configuration mode.  
EXEC mode.  
Privileged EXEC mode.

**Command Output** The **pim neighbor-filter** command is used on an interface to filter the neighbor routers.

**Examples**

```
device configure terminal
device(config)# interface ethernet 1/3
device(config-if-e1000-1/3)# ip pim neighbor-filter 10
device(config-if-e1000-1/3)# ipv6 pim neighbor-filter f10
```

**History**

Release	Command History
5.5.00	This command was added to filter the neighbor router on the interface.

# ping mpls ldp

Sends an MPLS echo request from the ingress to the egress LSR.

<b>Syntax</b>	<b>ping mpls ldp</b> { <i>ip_addr</i>   <i>ip_addr/mask-length</i> } [ <b>count</b> <i>num</i>   <b>destination</b> <i>ip_addr</i>   <b>detail</b>   <b>nexthop</b> <i>ip_addr</i>   <b>reply-mode</b> [ <i>no_reply</i>   <i>router_alert</i> ]   <b>reply-tos</b> <i>num</i>   <b>size</b> <i>bytes</i>   <b>source</b> <i>ip_addr</i>   <b>timeout</b> <i>msec</i> ]
<b>Parameters</b>	
<i>ip_addr</i>	Specifies the LDP IPv4 FEC destination prefix.
<i>ip_addr/mask_length</i>	Specifies the LDP IPv4 destination prefix and mask length. If the mask-length is not specified, the default value is 32.
<b>count</b> <i>num</i>	Specifies the number of echo requests to send. Values are from 1 to 4294967294. The default value is five.
<b>destination</b> <i>ip_addr</i>	Specifies an IP address within the 127/8 subnet. The default address is 127.0.0.1.
<b>detail</b>	Displays the details of the echo request and reply messages. By default, the display is in the brief mode.
<b>nexthop</b> <i>ip_addr</i>	The next closest router a packet can go through. The nexthop IPv4 address to send the OAM request to. If an address that does not match the outgoing path for the tunnel is given, following error message appears as the response: <b>Ping fails: LDP next-hop does not exist.</b>
<b>reply-mode</b>	Specifies the reply mode field in the echo request only if the user does not want the reply to be sent as an IPv4 UDP packet.
<i>no_reply</i>	Use to test one-way connectivity.
<i>router_alert</i>	Use when the normal IP return path is unreliable. This option indicates that the reply must be sent as an IPv4 UDP packet with the Router Alert option. This option requires extra overhead processing at each LSR along the return path.
<b>reply-tos</b> <i>num</i>	Specifies a TOS value between 0 and 254 to include in the Reply-TOS-byte TLV. By default, the reply-tos TLV is not included in the echo request. The last bit of the TOS byte is always 0.
<b>size</b> <i>bytes</i>	Specifies that the size of the echo request, including the label stack, to send. The pad TLV is used to fill the echo request message to the specified size. The minimum packet size is 80 bytes for an LDP echo request. The maximum packet size is the size of the LSP MTU.
<b>source</b> <i>ip_addr</i>	Specifies the IP address of any interface. Use this address as the destination address for the echo reply address. The default address is the LSR ID.
<b>timeout</b> <i>msec</i>	

Specifies an interval in milliseconds for the echo request message. The value range is from 50 to 300000. The default timeout is 5 seconds. The maximum timeout value is 5 minutes.

**Modes** Global configuration mode.

**Usage Guidelines**

---

**NOTE**

Once an outgoing path is chosen to send the ping request, it is not changed. Disabling the path does not cause the ping packet to be sent over other ECMP paths. Upon disabling the path, the ping operation stops because the path is down. This is the expected behavior.

---

**Examples** The following example displays how to perform the LSP LSP ping operation.

```
device# ping mpls ldp 10.22.22.22
Send 5 80-byte MPLS Echo Requests for LDP FEC 10.22.22.22/32, timeout 5000 msec
Type Control-c to abort
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max=0/1/1 ms.
device#
```

**History**

Release	Command history
5.6.00	<b>nexthop <i>ipv4-address</i></b> is added to the existing <b>ping</b> command.

# pki authenticate

Configures authentication for the CA.

**Syntax** `pki authenticate trustpoint-name`

**Parameters** `trustpoint-name`  
Specifies trustpoint name.

**Modes** Global configuration mode.

**Usage Guidelines** This command authenticates the CA by obtaining the self-signed certificate of the CA that contains the public key of the CA. Since the CA signs its own certificate, you should manually authenticate the public key of the CA by contacting the CA administrator before you run this command. This command is saved to the router configuration and the certificates are saved to the router.

**Examples** The following example configures authentication for the CA.

```
device configure terminal
device(config)# pki authenticate brocade
```

## History

Release version	Command history
5.8.00	This command was introduced.

# pki cert validate

Validates or checks if a trustpoint has been successfully authenticated, a certificate has been requested and granted, and if the certificate is currently valid.

- Syntax** `pki cert validate trustpoint-name`
- Parameters** `trustpoint-name`  
Specifies the trustpoint name.
- Modes** Global configuration mode.
- Usage Guidelines** Use this command after loading the router certificate using the **import** command to validate the router certificate.  
  
The following files must be downloaded first to the MP flash drive using TFTP and then imported into the system software using the **import** command:
  - CA/trustpoint certificate
  - Router certificate
  - Router private key
- Examples** The following example configures validation of a trustpoint.

```
device(config)# pki cert validate brocade
```

History	Release version	Command history
	5.8.00	This command was introduced.

## pki enroll

Generates a certificate request that is sent to the specified CA trustpoint. This enrolls the router on the CA trustpoint.

**Syntax** **pki enroll** *name*

**no pki enroll** *name*

**Command Default** By default, this command is not configured.

**Parameters** *name*

Specifies the CA trustpoint to which the router sends the request for certificates.

**Modes** Global configuration mode

**Usage Guidelines** Use the **no** form of this command to remove the certificates from the router.

The requested certificates are added to each key pair of your router.

The requested certificates are saved to the router, but the command is not.

**Examples** This example generates a certificate request that is sent to the CA trustpoint named *mytrustpoint*.

```
device(config)# pki enroll mytrustpoint
```

**History**

Release version	Command history
5.9.00	This command was introduced.

## pki entity

Configures the Public Key Infrastructure (PKI) end-user parameters and enters the PKI entity configuration mode.

**Syntax** `pki entity name`

**Parameters** `name`  
Specifies entity name for the PKI entity.

**Modes** Global configuration mode.

**Examples** The following example configures the PKI entity and enters the PKI entity configuration mode.

```
device configure terminal
device(config)# pki entity brocade-entity
device(config-pki-entity-brocade-entity)#
```

**History**

Release version	Command history
5.8.00	This command was introduced.



# pki export

Manually exports certificates from the specified CA trustpoint to the flash memory of the router. Export certificates after the router is rebooted to ensure the router has current, valid certificates.

**Syntax** `pki export name pem url filename`

**Command Default** By default, this command is not configured.

**Parameters** *name*

Specifies the name of the CA trustpoint that has the certificates you want to export to the flash memory of the router.

**pem url filename**

Specifies the name of the file being exported to the flash memory of the router. The file contains the certificates.

**Modes** Privileged EXEC mode

## Usage Guidelines

---

### NOTE

The trustpoint name you specify must match the name of the trustpoint you specified using the **pki trustpoint** command.

---

Use the **pki export key** command to manually export key-pairs to the router, or the **pki export crl** to manually export certificate revocation lists to the router.

**Examples** This example manually exports certificates from the CA trustpoint named *mytrustpoint* to the flash memory of the router. The exported file that contains the certificates is named *file1certs*.

```
device# pki export mytrustpoint pem url file1certs
```

## History

---

### Release version

### Command history

---

5.9.00

This command was introduced.

---

## pki export crl

Manually exports certificate revocation lists (CRL) from the specified CA trustpoint to the flash memory of the router. Export the CRL after the router is rebooted to ensure the router has current, valid lists.

<b>Syntax</b>	<b>pki export crl</b> <i>trustpointname</i> <b>url</b> <i>filename</i>
<b>Command Default</b>	By default, this command is not configured.
<b>Parameters</b>	<p><i>trustpointname</i></p> <p>Specifies the name of the CA trustpoint that has the CRL you want to export to the flash memory of the router.</p> <p><b>url</b> <i>filename</i></p> <p>Specifies the name of the file being exported to the flash memory of the router. The file contains the CRL.</p>
<b>Modes</b>	Privileged EXEC mode

### Usage Guidelines

---

#### NOTE

The trustpoint name you specify must match the name of the trustpoint you specified using the **pki trustpoint** command.

---

Use the **pki export** command to manually export certificates to the router, or the **pki export key** command to manually export key-pairs to the router.

**Examples** This example manually exports CRL from the CA trustpoint named *mytrustpoint* to the flash memory of the router. The exported file that contains the CRL is named *file1crl*.

```
device# pki export crl mytrustpoint url file1crl
```

### History

Release version	Command history
5.9.00	This command was introduced.

## pki export key

Manually exports key-pairs from the specified CA trustpoint to the flash memory of the router. Export key-pairs after the router is rebooted to ensure the router has current, valid key-pairs.

**Syntax** `pki export key label password filename`

**Command Default** By default, this command is not configured.

**Parameters** *label*

Specifies the label (name) of the key-pair being exported to the flash memory of the router.

*password*

Specifies the password required to export key-pairs.

*filename*

Specifies the name of the file being exported to the flash memory of the router. The file contains the key-pair.

**Modes** Privileged EXEC mode

**Usage Guidelines** Use the **pki export** command to manually export certificates to the router, or the **pki export crl** command to manually export CRL to the router.

**Examples** This example manually exports the key-pair labeled *1212* from the CA trustpoint named *mytrustpoint* to the flash memory of the router. The exported file that contains the key-pair is named *file1key*, and the password is *password*.

```
device# pki export 1212 password file1key
```

**History**

Release version	Command history
5.9.00	This command was introduced.

# pki import

Manually imports certificates from the flash memory of the router to the specified CA trustpoint.

**Syntax** `pki import name { pem | url flash: file-name }`

**Command Default** By default, this command is not configured.

**Parameters**

- name* Specifies the name of the CA trustpoint that receives the certificates being imported from the router.
- pem** (Optional) Specifies the name of the .pem file to be imported. The file contains the certificates.
- url flash: file-name** (Optional) Specifies the name of the flash file to be imported. The file contains the certificates.

**Modes** Global configuration mode

**Examples** The following example manually imports certificates to the CA trustpoint named *brocade*.

```
device(config)# pki import brocade pem url flash: mlx2.crt
```

History	Release version	Command history
	5.8.00	This command was introduced.

## pki import key ec

Enables importing the Elliptic Curve (EC) key pair from the flash file with the specified key label.

**Syntax** **pki import key ec** *key-label* **pem url flash:** *file-name*  
**no pki import key ec** *key-label* **pem url flash:** *file-name*

**Parameters** *key-label*  
 Specifies the key label name.  
**pem**  
 Specifies .pem file name used to import.  
**url flash:** *file-name*  
 Specifies the flash file name.

**Modes** Global configuration mode.

**Usage Guidelines** The **no** form of the command cancels the import request that was enabled earlier.

**Examples** The following example enables importing the EC key pair from the flash file with the specified key label.

```
deviceconfigure terminal
device(config)# pki import key ec brocade pem url flash: mlx2_eckey.pem
```

History	Release version	Command history
	5.8.00	This command was introduced.

## pki profile-enrollment

Creates a PKI enrollment profile you can use to efficiently enroll requester systems. Systems you enroll using the profile have the same You name the profile and specify the profile settings using command parameters.

<b>Syntax</b>	<p><b>pki profile-enrollment</b> <i>name</i> <b>authentication-url</b> <i>url-string</i> <b>authentication-command</b> <i>url-string</i> <b>enrollment-url</b> <i>url-string</i> <i>password</i></p> <p><b>no pki profile-enrollment</b> <i>name</i> <b>authentication-url</b> <i>url-string</i> <b>authentication-command</b> <i>url-string</i> <b>enrollment-url</b> <i>url-string</i> <i>password</i></p>
<b>Command Default</b>	By default, this command is not configured.
<b>Parameters</b>	<p><i>name</i> Specifies the name of the enrollment profile.</p> <p><b>authentication-url</b> <i>url-string</i> Specifies the URL of the certification authority (CA) server you want to receive the authentication requests. Make sure you use the correct form of the URL.</p> <p><b>authentication-command</b> <i>string</i> Specifies the HTTP command that is sent to the certification authority (CA) for authentication.</p> <p><b>enrollment-url</b> <i>url-string</i> Specifies the URL of the certification authority (CA) server you want to receive the enrollment requests. Make sure you use the correct form of the URL.</p> <p><i>password</i> Specifies the password for the SCEP challenge used to revoke the requester's current certificate and issue another certificate for auto mode. Copy the password from the server.</p>
<b>Modes</b>	<p>Global configuration mode (to enter the command)</p> <p>Pki-profile mode (to specify parameter values)</p>
<b>Usage Guidelines</b>	<p>Use the <b>no</b> form of this command to delete all information defined in the enrollment profile.</p> <p>Entering the <b>pki profile-enrollment</b> command automatically enters pki-profile mode, which is required to specify the command parameter values.</p>

---

### NOTE

You must specify the authentication and enrollment URLs in the correct form. The URL argument must be in the form `http://CA_name`, where `CA_name` is the host Domain Name System (DNS) name or the IP address of the CA.

---

**Examples** This example creates an enrollment profile named profileA. The values for the parameters are:

- **authentication-url:** http://win-ab12aaa123a1.lab.myco.com/CertServer/mscep/mcse
- **authentication-command:** win-as12aa123a1.lab.myco.com\_lab-WIN-A1B1A1BBBB
- **enrollment-url:** http://win-ab12aaa123a1.lab.myco.com/CertServer/mscep/mscep
- **password:** 1B1111AB111A2222

```

device(config)# pki profile-enrollment profileA
                                device(config-pki-profile)# authentication-url
http://win-ab12aaa123a1.lab.myco.com/CertServer/mscep/mcse
                                device(config-pki-profile)# authentication-command win-
as12aa123a1.lab.myco.com_lab-WIN-A1B1A1BBBB
                                device(config-pki-profile)# enrollment-url http://win-
ab12aaa123a1.lab.myco.com/CertServer/mscep/mscep
                                device(config-pki-profile)# 1B1111AB111A2222
    
```

**History**

Release version	Command history
5.9.00	This command was introduced.

## pki trustpoint

Configures the trustpoint used in all the relevant parameters needed for communication and enters the Public Key Infrastructure (PKI) trustpoint configuration mode.

<b>Syntax</b>	<b>pki trustpoint</b> <i>name</i> <b>no pki trustpoint</b> <i>name</i>				
<b>Parameters</b>	<i>name</i> Specifies the PKI trustpoint name.				
<b>Modes</b>	Global configuration mode.				
<b>Usage Guidelines</b>	The <b>no</b> form of the command deletes all the certificates associated with this Certificate Authority (CA). The trustpoint can be a self-signed root CA or a subordinate CA.				
<b>Examples</b>	The following example configures the PKI trustpoint and enters the PKI trustpoint configuration mode.  <pre>device configure terminal device(config)# pki trustpoint brocade device(config-pki-trustpoint-brocade)#</pre>				
<b>History</b>	<table><thead><tr><th>Release version</th><th>Command history</th></tr></thead><tbody><tr><td>5.8.00</td><td>This command was introduced.</td></tr></tbody></table>	Release version	Command history	5.8.00	This command was introduced.
Release version	Command history				
5.8.00	This command was introduced.				



## pki-entity

Configures the Public Key Infrastructure (PKI) entity parameter to be used while enrolling to a CA.

**Syntax** `pki-entity entity-name`

**Parameters** `entity-name`

Specifies the entity name for the PKI entity.

**Modes** PKI trustpoint configuration mode.

**Examples** The following example configures the PKI entity and enters the PKI trustpoint configuration mode.

```
device configure terminal
device(config)# pki trustpoint brocade
device(config-pki-trustpoint-brocade)# pki-entity brocade-entity
```

### History

Release version	Command history
5.8.00	This command was introduced.

## pre-shared-key

Configures the pre-shared MACsec key on the interface.

**Syntax** `pre-shared-key key-id key-name`

`no pre-shared-key key-id key-name`

**Command Default** No pre-shared MACsec key is configured on the interface.

**Parameters** `key-id`

Specifies the Connectivity Association Key (CAK) key value. Key-id must be hexadecimal string of 32 characters.

`name`

Specifies the Connectivity Association Key (CAK) key name. Key-name must be hexadecimal string of maximum 64 characters.

**Modes** dot1x-mka-interface mode.

**Usage Guidelines** The pre-shared key is required for communications between MACsec peers.

---

### NOTE

1. Group must be attached to the interface before applying pre-shared key on the interface.
  2. Key-name length should be multiple of 4.
  3. Key-name and pre-shared key must be hexadecimal string.
- 

The **no** form of the command removes the pre-shared key from the interface.

**Examples** The following example configures pre-shared key with a name beginning with 11223344 and with the value shown, to port 1, slot 1 on the device.

```
device configure terminal
device(config)# dot1x-mka-enable
device(config-dot1x-mka)# enable-mka ethernet 1/1
device(config-dot1x-mka-eth-1/1)# pre-shared-key 0102030405060708090A0B0C0D0E0F10 key-
name 11223344
```

### History

Release version	Command history
5.8.00	This command was introduced.

# prf

Configures a hash algorithm used to generate key material for IKE SA negotiation.

**Syntax** **prf {sha384 | sha256}**  
**no prf {sha384 | sha256}**

**Parameters** **sha256** Specifies SHA-2 family 256-bit (HMAC variant) as the hash algorithm.  
**sha384** Specifies SHA-2 family 384-bit (HMAC variant) as the hash algorithm.

**Modes** IKEv2 proposal configuration mode

## Usage Guidelines

**Examples** The following example configures a hash algorithm used to generate key material for IKE SA negotiation.

```
device(config)# ikev2 proposal brocade
device(config-ikev2-proposal-brocade)# prf sha384
```

## History

Release version	Command history
05.8.00	This command was introduced.

## protected

Configures the VRF with the traffic that will be protected by the specific IKEv2 profile.

**Syntax** **protected** *vrf*  
**no protected** *vrf*

**Parameters** *vrf*  
 Specifies the VRF name.

**Modes** IKEv2 profile configuration mode

**Examples** The following example configures VRF traffic protection using IKEv2.

```
device(config)# ikev2 profile test
device(config-ikev2-profile-test)# protected red
```

**History**

Release version	Command history
05.8.00	This command was introduced.

# rate-limit input

Configures the per-port or port per VLAN broadcast, unknown-unicast, or multicast (BUM) rate-limiting.

<b>Syntax</b>	<b>rate-limit input</b> [ <i>vlan</i> <i>vlan id</i> ] [ <b>broadcast</b>   <b>unknown-unicast</b>   <b>multicast</b> ] [ <i>average-rate</i> <i>maximum burst size</i> ] [ <b>include-control</b> ] [ <b>shutdown</b> <i>timeout</i> ] [ <b>alert</b> <i>high-watermark low-watermark</i> ]						
<b>Parameters</b>	<p><b>vlan</b> <i>vlan-id</i></p> <p>Specifies the VLAN id of the specific port on which the rate-limiting of BUM traffic is accounted.</p> <p><b>broadcast unknown-unicast multicast</b></p> <p>Define a rate limit for ingress broadcast, unknown-unicast, or multicast packets on the port. Any combination of these parameters can be used to define the rate limit.</p> <p><i>average-rate</i></p> <p>Specifies the maximum number of bits a port is allowed to receive during a one-second interval and is the aggregate sum of the broadcast, unknown-unicast, and multicast packets rate limit, if the rate limit is configured for all three packets. The software automatically adjusts the number you enter to the nearest multiple of 8,144 bits per second (bps).</p> <p><i>maximum burst size</i></p> <p>Specifies the value of the maximum burst of traffic allowed by the specific port.</p> <p><b>include-control</b></p> <p>Extends the existing BUM rate-limit to include rate limit of ARP, other control packets.</p> <p><b>shutdown</b> <i>timeout</i></p> <p>Specifies that the port is to be shut down if the amount of BUM traffic exceeds the pre-defined limit. Time out value is between 0 to 1440 minutes.</p> <p><b>alert</b> <i>high-watermark low-watermark</i></p> <p>Alert message if the rate crossed over/under limit shutdown. Shut down the port if the rate is over limit.</p>						
<b>Modes</b>	Interface configuration mode						
<b>Examples</b>	<p>The following is an example for rate-limit input configuration.</p> <pre>device(config)#int eth 1/1 device(config-if-e1000-1/1)#rate-limit input broadcast 100000 10000 include-control shutdown 1 alert 80000 10000 device(config-if-e1000-1/1)#rate-limit input multicast 100000 10000 include-control shutdown 1 alert 80000 10000</pre>						
<b>History</b>	<table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>Release 05.7.00</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 05.9.00</td> <td>This command was modified to include the <b>include-control</b> option.</td> </tr> </tbody> </table>	Release version	Command history	Release 05.7.00	This command was introduced.	Release 05.9.00	This command was modified to include the <b>include-control</b> option.
Release version	Command history						
Release 05.7.00	This command was introduced.						
Release 05.9.00	This command was modified to include the <b>include-control</b> option.						

## rd

Each instance of a VRF must have a unique Route Distinguisher (RD) assigned to it.

**Syntax** `rd { as-num:id | ip-num:id }`

`no rd { as-num:id | ip-num:id }`

**Command Default** No RD is assigned to the VRF.

**Parameters** *as-num:id*

Composed of the local ASN number followed by a colon ":" and a unique arbitrary number. For example 3:6.

*ip-num:id*

Composed of the local IP address followed by a colon ":" and a unique arbitrary number.

**Modes** VRF configuration mode

**Usage Guidelines** Each instance of a VRF must have a unique Route Distinguisher (RD) assigned to it. The RD is prepended to any address being routed or advertised. The RD can be defined as either ASN relative or IP address relative. Because the RD is unique to an instance of a VRF, it allows the same IP address to be used in different VPNs without creating any conflict.

The **no** form of the command returns to the default setting.

**Examples** The following example displays the command which assigns a Route Distinguisher (RD) based on the AS number 3 and the arbitrary identification number 6.

```
device(config-vrf)# rd 3:6
```

## remove-tagged-ports / remove-untagged-ports

Removes tagged or untagged ports on the VLAN.

**Syntax** **remove-tagged-ports**  
**remove-untagged-ports**

**Command Default** None.

**Modes** VLAN configuration mode (config-vlan).

**Examples** The following example displays the remove-tagged-ports command.

```
device(config-vlan-100)# remove-tagged-ports
Vlan : 100, Ports removed : ethe 1/1 to 1/2 ethe 4/1 to 4/8
device(config-vlan-100)#
```

The following example displays the remove-untagged-ports command.

```
device(config-vlan-100)# remove-untagged-ports
Vlan : 100, Ports removed : ethe 3/1 to 3/24
device(config-vlan-100)#
```

### History

Release version	Command history
5.8.00	This command is introduced.

## remove-vlan

Removes tagged and untagged ports from all or defined VLANs.

**Syntax** `remove-vlan [ all | vlan [ vlan_id ] ] { to vlan_id }`

**Parameters** **all**

Removes all configured VLANs.

**vlan** *vlan\_id*

Specifies the VLAN where the ports should be removed.

**to** *vlan\_id*

Specifies the VLAN range to remove.

**Modes** User configuration level.

**Examples** The following example displays the command with the **all** option.

```
device(config-if-e100000-1/1)# remove-vlan all
Port ethe 1/1 removed from tagged vlan : 300 400 500 600 700 800 900 1000 2000 3000
4000 and untagged vlan : 200 .
device(config-if-e100000-1/1)#
```

The following example displays the command with a specified VLAN range.

```
device(config-if-e100000-1/2)# remove-vlan vlan 2 to 4090
Port ethe 1/2 removed from tagged vlan : 300 400 500 600 700 800 900 1000 2000 3000
4000 and untagged vlan : 200 .
device(config-if-e100000-1/2)#
```

The following example displays the command that remove a specific VLAN.

```
device(config-if-e10000-4/1)# remove-vlan vlan 500
Vlan : 500, Ports removed : ethe 4/1
device(config-if-e10000-4/1)#
```

**History**

Release version	Command history
5.8.00	This command was introduced.



## reverse-metric

Configures the reverse metric value at the IS-IS router level.

**Syntax** **reverse-metric** [ *value* ] [ **whole-lan** ] [ **te-def-metric** ]  
**no reverse-metric** [ *value* ] [ **whole-lan** ] [ **te-def-metric** ]  
**reverse-metric tlv-type** [ *value* ]  
**no reverse-metric tlv-type** [ *value* ]

**Command Default** The **reverse-metric** command is disabled by default.

**Parameters** **reverse-metric**

Specifies the reverse metric parameter at the IS-IS router level.

**value**

Specifies the reverse metric value in metric style. The metric style consists of narrow or wide style. The narrow metric range is from 1 - 63. The wide metric range is from 1 - 16777215. The default value is 16777214 irrespective of the metric style configured. If the reverse-metric value is configured, the local LSP is updated with the sum of the default metric and the reverse metric value. When the IS-IS neighbor router receives the reverse metric value through the IS hello, the neighbor router updates the cost to reach the original IS-IS router with the sum of default metric and the reverse metric value. This helps in shifting traffic to the other alternate paths.

**whole-lan**

Specifies changing the reverse metric parameter for the entire LAN. The **whole-lan** option indicates the whole LAN bit in the flag. If the **whole-lan** option is enabled, the configured reverse metric value affects the entire LAN. If the **whole-lan** option is not enabled, the reverse metric value affects only the neighbor router. This option takes effect only on the multi-access LAN. IS-IS point-to-point interfaces are not affected when the **whole-lan** option is enabled.

**te-def-metric**

Specifies setting the TE default metric sub-TLV. If the **te-def-metric** option is enabled, the router sends a TE default metric sub-TLV within the reverse-metric TLV.

**tlv-type value**

Specifies the TLV type for the reverse metric parameter. The TLV type can only be configured at the IS-IS router level. The **tlv-type value** parameter must be configured in the range of unassigned IS-IS TLV values. The **tlv-type value** parameter should not be configured with existing IS-IS TLV types. The default value is 254.

**Modes** IS-IS router level.

**Usage Guidelines** Use the **reverse-metric** command when you are performing network maintenance operations, such as software upgrades, on an IS-IS router node. When maintenance operations are performed, the router undergoing maintenance should not be used by the neighbor routers to forward transit traffic. In order to shift traffic away from the router undergoing maintenance, configure the **reverse-metric** command on the maintenance router. The router undergoing maintenance first advertises a reverse metric TLV in a IS-IS hello PDU to its neighbor router on a point-to-point or multi-access link. When the neighbor router receives a high reverse metric value, the router selects alternate paths to forward traffic while

maintenance is going on. The neighbor router adds the reverse metric TLV to its own TE default metric sub-TLV and recalculates its SPF tree and route topology. The neighbor router floods the new LSP containing the extended IS reachability TLV throughout the domain. Traffic gradually shifts onto alternate paths away from the link between the maintenance router and the neighbor router as nodes in the IS-IS domain receive the new LSP. Once the maintenance is complete, you can remove the **reverse-metric** command configuration from the router, and the reverse metric TLV in the IS-IS hello PDU is no longer advertised to the neighbor router. The IS-IS neighbor router reverts back to its original IS-IS metric, and the traffic switches to the original IS-IS router to reach its destination.

In a multi-access link, the IS-IS DIS router adds the reverse metric TLV value to each node's default metric value in the pseudonode LSP when the whole-lan flag is set. All non-DIS nodes ignore the reverse metric TLV. If multiple neighbor routers advertise the reverse metric TLV with the whole LAN flag set, the neighbor router with the highest MAC address takes precedence, and the value advertised by that neighbor is updated in the pseudonode LSP for all neighbors. If some neighbor routers do not set the whole LAN flag, then the reverse metric TLV value advertised by the neighbor router is updated in the pseudonode LSP for that neighbor only.

The S flag is set when the sender of the reverse metric TLV signals to the neighbor router to use the TE sub-tlv for the default metric (sub-tlv type 18) in the reverse metric TLV. When the receiving router finds the S flag set in the reverse metric TLV, the router searches for the TE sub-tlv. The router adds the default metric value in the TE sub-tlv to the configured TE default metric value and recalculates the CSPF.

The **no** form of the command, specified with the configured value, resets the metric value to the default value of 16777214. The **no reverse-metric** command removes the entire reverse metric configuration.

---

#### NOTE

The **reverse-metric value** command is supported on the Brocade NetIron XMR Series, the Brocade MLX Series, and the Brocade NetIron CER Series and Brocade NetIron CES Series platforms.

---

**Examples** The following example configures the reverse metric value to 50 at the router level. The **whole-lan** option is enabled to include the entire LAN.

```
device(config)# router isis
device(config-isis-router)# reverse-metric
device(config-isis-router)# reverse-metric 50
device(config-isis-router)# reverse-metric 50 whole-lan
device(config-isis-router)#
```

The following example configures the reverse metric TLV type in the range of unassigned IS-IS TLV values.

```
device(config-isis-router)# reverse-metric tlv-type
device(config-isis-router)# reverse-metric tlv-type 230
device(config-isis-router)#
```

Use the **show isis config** command to display the configuration of the reverse metric value at the router level. The reverse metric value and the parameters, **whole-lan** and **te-def-metric** are highlighted in the output.

```
device(config)# show isis config
    router isis
    net 49.2211.aaaa.bbbb.cccc.00
    reverse-metric 50 whole-lan te-def-metric
    address-family ipv4 unicast
    exit-address-family

    address-family ipv6 unicast
    exit-address-family
```

History	Release version	Command history
	5.7.00	This command was introduced.

# revocation-check

Specifies the type of method to be followed for revocation check of the certificate authority (CA).

**Syntax** `revocation-check { crl | ocsp | none }`  
`no revocation-check { crl | ocsp | none }`

**Command Default** Revocation check is not enabled.

**Parameters**

- crl** Specifies the certificate revocation list (CRL) method for revocation check.
- ocsp** Specifies the Online Certificate Status Protocol (OCSP) method for revocation check.
- none** Specifies that none of the methods are selected for revocation check.

**Modes** PKI trustpoint configuration mode.

**Usage Guidelines** The **no** form of the command removes the method selected for revocation check.

**Examples** The following example specifies the **crl** as the revocation check method.

```
device(config)# pki trustpoint brocade1
device(config-pki-trustpoint-brocadel)# revocation-check crl
```

History	Release version	Command history
	5.9.00	This command was introduced.

## rfc1583-compatibility (OSPF)

Configures compatibility with RFC 1583.

**Syntax**    **rfc1583-compatibility**  
**no rfc1583-compatibility**

**Command Default**    This command is disabled by default.

**Modes**    OSPF router configuration mode  
 OSPF router VRF configuration mode

**Usage Guidelines**    Enter **no rfc1583-compatibility** to disable compatibility with RFC 1583 if it has been enabled. Enter **no rfc1583-compatibility** if it has been enabled to re-enable compatibility with RFC 2328.

When this command is enabled, OSPF is compatible with RFC 1583 (OSPFv2) and maintains a single best route to an autonomous system (AS) boundary router in the OSPF routing table. Disabling this compatibility causes the OSPF routing table to maintain multiple intra-AS paths, which helps prevent routing loops.

**Examples**    This example enables compatibility with RFC 1583.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# rfc1583-compatibility
```

This example disables compatibility with RFC 1583 if it has been enabled and re-enables compatibility with RFC 2328.

```
device# configure terminal
device(config)# router ospf
device(config-ospf-router)# no rfc1583-compatibility
```

### History

Release version	Command history
5.9.00	This command was modified so that it is disabled by default.

## router-interface

Configures the VE per VPLS instance.

<b>Syntax</b>	<b>router-interface</b> { <i>ve num</i> }
<b>Command Default</b>	None.
<b>Parameters</b>	<b>ve num</b> Specifies the Virtual Ethernet interface number.
<b>Modes</b>	MPLS VPLS sub-configuration mode (config-mpls-vpls).
<b>Usage Guidelines</b>	The user must specify a router-interface for each VPLS instance.
<b>Examples</b>	The following example displays when the user must specify a router-interface for each VPLS instance.

```
device(config)# router mpls
device(config-mpls)# vpls test 10
device(config-mpls-vpls-test)# router-interface ve 200
device(config-mpls-vpls-test)# vlan 10
device(config-mpls-vpls-test-vlan-10)# tagged ethe 4/1
device(config-mpls-vpls-test-vlan-10)# vlan 200 isid 20000
```

## router vrrp

Globally enables Virtual Router Redundancy Protocol (VRRP).

**Syntax**    **router vrrp**

**no router vrrp**

**Command Default**    VRRP is not globally enabled.

**Modes**            Global configuration mode

**Usage Guidelines**    After globally enabling VRRP, the command prompt does not change. Nearly all subsequent VRRP configuration is performed at the interface level but VRRP must be enabled globally before configuring VRRP instances.

The **no protocol vrrp** command globally disables VRRP.

**Examples**          The following example globally enables VRRP and enters interface configuration mode.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/5
```

## router vrrp-extended

Globally enables Virtual Router Redundancy Protocol Extended (VRRP-E).

**Syntax**    **router vrrp-extended**

**no router vrrp-extended**

**Command Default**    VRRP-E is not globally enabled.

**Modes**            Global configuration mode

**Usage Guidelines**    After globally enabling VRRP-E, nearly all subsequent VRRP-E configuration is performed at the interface level. VRRP-E must be enabled globally before configuring VRRP-E instances.

          The **no router vrrp-extended** command globally disables VRRP-E.

**Examples**          The following example globally enables VRRP-E and enters interface configuration mode.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# interface ethernet 1/5
```



# rpf shortcut

Enables RPF shortcut for LSP paths.

**Syntax** **rpf shortcut**

**no rpf shortcut**

**Parameters** *slot/port*

Specifies the port that you want to display RPF shortcuts for LSP paths.

**Modes** User EXEC mode

Privileged EXEC mode

**Usage Guidelines** When RPF lookup results in the LSP path, then another lookup is executed to get the underlying native route and that route's next-hop is used as the RPF.

The **no** form of the command disables the feature.

**Examples** To configure **rpf shortcut**, use this command in the configuration mode.

```
device(config)# router pim
device(config-pim-router)# rpf shortcut
```

## History

Release	Command History
5.5.00	This command was modified to RPF shortcut for LSP paths information.

## rsvp-hello

Configures the RSVP-TE Hello with default values on all the mpls-interfaces, providing the mpls-interface does not have any local-interface level configuration for the same.

<b>Syntax</b>	<b>rsvp-hello</b> [ <b>acknowledgments</b> [ <b>interval</b> <i>num</i>   <b>tolerance</b> <i>num</i> ]   <b>interval</b> <i>num</i>   <b>tolerance</b> <i>num</i> ]  <b>no rsvp-hello</b> [ <b>acknowledgments</b> [ <b>interval</b> <i>num</i>   <b>tolerance</b> <i>num</i> ]   <b>interval</b> <i>num</i>   <b>tolerance</b> <i>num</i> ]
<b>Parameters</b>	<p><b>acknowledgments</b> Acknowledges RSVP Hellos on the interface supporting RSVP Hello and <i>not</i> having RSVP sessions.</p> <p><b>interval</b> <i>num</i> Interval between two RSVP Hello requests in seconds. Value range is 1 - 60, default 9.</p> <p><b>tolerance</b> <i>num</i> Number of unacknowledged RSVP Hello requests, seconds, before a timeout. Value range is 1 - 255, default 3.</p>
<b>Modes</b>	MPLS configuration mode.  MPLS interface configuration mode.
<b>Usage Guidelines</b>	<p><b>RSVP Hello configuration at the global MPLS RSVP level</b></p> <p>Interval and tolerance for RSVP-TE Hello protocol can be configured at global MPLS RSVP level. The global configuration is pushed to all the mpls-interfaces when the interface level configurations are not present. In addition to these two parameters, one more parameter may be configured at global MPLS RSVP level, namely, acknowledgments.</p> <p><b>Hello-interval and hello-tolerance at mpls-interface level</b></p> <p>RSVP-TE Hello interval and tolerance can be configured at mpls-interface level as well. Interface level configurations take precedence over global configurations. These parameters can be individually configured for each mpls-interface.</p> <p>By default, acknowledgments are <i>not sent</i> on mpls-interface supporting RSVP Hello when no sessions are taking that interface.</p> <p>Interface-level configuration takes precedence over global configuration.</p>



### CAUTION

**When disabling RSVP hello, disable it on both sides of the link at the same time to avoid bringing down all the RSVP sessions going over that link.**

The **no** form of the command does not take interval or tolerance as parameters. Executing the **no rsvp-hello** command on the mpls-interface level sets the RSVP-TE Hello parameters to the globally configured RSVP Hello parameter values. If RSVP Hello is not configured globally, it disables the RSVP Hello on the mpls-interface. Executing this removes the configuration from the interface level and will no longer display the RSVP Hello configuration at the interface level in the **show configuration** output.

**Examples** The following example displays the command in the Global configuration mode.

```
device configure terminal
device(config)# router mpls
device(config-mpls)#rsvp
device(config-mpls-rsvp) rsvp-hello
device(config-mpls-rsvp) rsvp-hello interval 15 tolerance 5 acknowledgments
```

The following example displays the command in the Interface configuration mode.

```
device configure terminal
device(config)# router mpls
device(config-mpls-if-e100-1/1)# rsvp
device(config-mpls-if-e100-1/12) rsvp-hello
device(config-mpls-if-e100-1/12) rsvp-hello interval 5 tolerance 2
```

**History**

Release	Command history
5.6.00	The command was introduced.

# rsvp-hello acknowledgments

Configures the RSVP-TE Hello to respond back with Hello ACKs to neighbors not carrying any RSVP sessions.

The **rsvp-hello acknowledgments** command configures the RSVP-TE Hello to respond back with Hello ACKs to neighbors not carrying any RSVP sessions. The configuring for acknowledgments is at the global MPLS RSVP level.

**Syntax** **rsvp-hello acknowledgments**

**no rsvp-hello acknowledgments**

**Modes** MPLS RSVP Hello global configuration mode.

**Usage Guidelines** By default, RSVP-TE Hello does not send ACKs to neighbors not carrying any RSVP sessions.

The **no** format of this command sets it back to the default behavior of not sending ACKs to neighbors not carrying any RSVP sessions. This erases the configuration line from the global configuration. All the mpls-interfaces supporting RSVP Hello having *ZERO* sessions to neighbors *do not send HELLO\_ACKs* for requests sent to those neighbors (which is the default behavior).

**Examples** The following example enables RSVP-TE Hello on all mpls-interfaces with default values for hello-interval and hello-tolerance if no interface level specific configuration is present.

```
device configure terminal
device(config)# router mpls
device(config-mpls)# rsvp
device(config-mpls-rsvp)# rsvp-hello interval 15
device(config-mpls-rsvp)# rsvp-hello tolerance 5
```

**History**

Release	Command history
5.6.00	This command was introduced.

## rsvp-hello disable

Disables RSVP Hello on an mpls-interface.

**Syntax** `rsvp-hello disable`

`no rsvp-hello disable`

**Modes** MPLS interface configuration mode.

**Usage Guidelines** This command erases the configuration line from the configuration like any other **no** command. When there is global configuration, the interface starts picking up globally configured parameters for the RSVP Hello.

If there is no global configuration, the interface does not run RSVP-Hello.



### CAUTION

**When disabling RSVP hello, please disable it on both sides of the link at the same time to avoid bringing down all the RSVP sessions going over that link.**

The **no** form of the rsvp-hello command will not take any parameters other than **disable** at the interface level local configuration. When the parameter needs to be changed to the default value, the user has to execute the normal configuration command.

**Examples** The following example displays the command under the Interface configuration.

```
device (config-mpls-if-e100-1/6)# rsvp-hello disable
```

The following example displays the RSVP Hello is being disabled on the interface. It generates on the configuration. The RSVP Hello would not be running on this interface irrespective of any global or local configuration present.

```
device configure terminal
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# traffic-eng isis level-2

device(config-mpls-policy)# rsvp
device(config-mpls-rsvp)# rsvp-hello interval 15 tolerance 5
device(config-mpls-rsvp)# rsvp-hello acknowledgements

device(config-mpls-rsvp)# mpls-interface e1/1
device(config-mpls-rsvp)# rsvp-hello interval 5 tolerance 2

device(config-mpls-rsvp)# mpls-interface e1/2
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/3

device(config-mpls-rsvp)# mpls-interface e1/4
device(config-mpls-rsvp)# rsvp-hello interval 20 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/5
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 7

device(config-mpls-rsvp)# mpls-interface e1/6
device(config-mpls-rsvp)# rsvp-hello disable
```

The following example displays that the RSVP Hello is configured with the default parameters on the interface. The parameters are auto-generated.

```
device (config-mpls-if-e100-1/7) rsvp-hello
device (config-mpls-if-e100-1/7) rsvp-hello disable

device configure terminal
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# traffic-eng isis level-2

device(config-mpls-policy)# rsvp
device(config-mpls-rsvp)# rsvp-hello interval 15 tolerance 5
device(config-mpls-rsvp)# rsvp-hello acknowledgements

device(config-mpls-rsvp)# mpls-interface e1/1
device(config-mpls-rsvp)# rsvp-hello interval 5 tolerance 2

device(config-mpls-rsvp)# mpls-interface e1/2
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/3

device(config-mpls-rsvp)# mpls-interface e1/4
device(config-mpls-rsvp)# rsvp-hello interval 20 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/5
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 7

device(config-mpls-rsvp)# mpls-interface e1/6
device(config-mpls-rsvp)# rsvp-hello disable

device(config-mpls-rsvp)# mpls-interface e1/7
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3
device(config-mpls-rsvp)# rsvp-hello disable
```

The following example displays that the RSVP Hello is enabled back on the interface. The interface starts taking the values that were previously configured on it. When there is no previous interface-specific configuration, then the interface starts taking all of the configuration from the Global level.

When there is no Global configuration as well, then the interface does not run RSVP Hellos.

```
device (config-mpls-if-e100-1/7) no rsvp-hello disable

device configure terminal
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# traffic-eng isis level-2

device(config-mpls-policy)# rsvp
device(config-mpls-rsvp)# rsvp-hello interval 15 tolerance 5
device(config-mpls-rsvp)# rsvp-hello acknowledgements

device(config-mpls-rsvp)# mpls-interface e1/1
device(config-mpls-rsvp)# rsvp-hello interval 5 tolerance 2

device(config-mpls-rsvp)# mpls-interface e1/2
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/3

device(config-mpls-rsvp)# mpls-interface e1/4
device(config-mpls-rsvp)# rsvp-hello interval 20 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/5
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 7

device(config-mpls-rsvp)# mpls-interface e1/6
device(config-mpls-rsvp)# rsvp-hello disable

device(config-mpls-rsvp)# mpls-interface e1/7
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3
```

The following example displays that the RSVP Hello's are being enabled back on the interface.

```
device (config-mpls-if-e100-1/6) no rsvp-hello disable Interval is 15 seconds (Global configuration).
```

```
device configure terminal
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# traffic-eng isis level-2

device(config-mpls-policy)# rsvp
device(config-mpls-rsvp)# rsvp-hello interval 15 tolerance 5
device(config-mpls-rsvp)# rsvp-hello acknowledgments

device(config-mpls-rsvp)# mpls-interface e1/1
device(config-mpls-rsvp)# rsvp-hello interval 5 tolerance 2

device(config-mpls-rsvp)# mpls-interface e1/2
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/3

device(config-mpls-rsvp)# mpls-interface e1/4
device(config-mpls-rsvp)# rsvp-hello interval 20 tolerance 3

device(config-mpls-rsvp)# mpls-interface e1/5
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 7

device(config-mpls-rsvp)# mpls-interface e1/6

device(config-mpls-rsvp)# mpls-interface e1/7
device(config-mpls-rsvp)# rsvp-hello interval 9 tolerance 3
```

#### History

Release	Command history
5.6.00	This command was introduced.

## sample-recording

Use this command to set the sample recording for the LSP.

**Syntax** `sample-recording [ enable | disable ]`

`no sample-recording [ enable | disable ]`

**Command Default** Sample-recording is disabled.

**Parameters** **enable**

Enables sample recording for the LSP.

**disable**

Disables sample recording for the LSP.

**Modes** MPLS autobw-template configuration mode.

MPLS LSP mode.

**Usage Guidelines** Under the MPLS LSP mode, when autobw-template is configured for this LSP, the sample recording configuration from the template is taken, otherwise sample recording is disabled by default.

This command configures the template to record the sample history.

Under the MPLS autobw-template config mode, the **no** option disables this option.

**Examples** The following example shows when the the user wants to record the sample history for an LSP or template.

```
device configure terminal
device(config)# router mpls
device(config-mpls)# autobw-template template1
device(config-mpls-autobw-template-template1)# sample-recording enable
```

```
device configure terminal
device(config)# router mpls
device(config-mpls)# lsp lsp1-autobw
device(config-mpls-lsp-lsp1-autobw)# sample-recording enable
```

**History**

Release version	Command history
5.6.00	This command was introduced.



## scale-timer

Configures a scale time factor that increases the timing sensitivity across all configured and default Virtual Router Redundancy Protocol Extended (VRRP-E) timers.

<b>Syntax</b>	<b>scale-timer vrrp-extended</b> <i>scale-factor</i>
<b>Command Default</b>	VRRP timers are not scaled.
<b>Parameters</b>	<p><i>scale-factor</i></p> <p>Number representing the scale of the division of a VRRP-E configured or default interval timer. Valid values are in a range from 1 to 10. The default value is 1.</p>
<b>Modes</b>	VRRP-E router configuration mode
<b>Usage Guidelines</b>	Configuring the VRRP-E scale timer is only supported in VRRP-E sessions. When a scaling value is configured, the existing timer values are divided by the scaling value. For example: a value of 10 divides the timers by a factor of 10, allowing the default dead interval to be set to 300 ms. Using the timer scaling, VRRP-E sub-second convergence is possible if a master VRRP device fails.

---

### NOTE

Increased timing sensitivity as a result of this configuration could cause protocol flapping during periods of network congestion.

---



---

### NOTE

Brocade MLX devices only support a scaling factor of 10. For interoperability with MLX devices, use an advertisement interval scale factor of 10.

---

**Examples** The following example scales all VRRP-E timers by a factor of 10.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# scale-timer vrrp-extended 10
```

## sflow null0-sampling

Enables the null0 sampling.

**Syntax** **sflow null0-sampling** *slot lport*

**no sflow null0-sampling** *slot lport*

**Parameters** *slot port*

Enables null0 sampling for a specific slot and port.

**Modes** Global configuration mode

**History**

Release	Command History
5.5.00	This command was modified to display sFlow null0 sampling status.

## shortcuts isis

Forces ISIS IGP protocol not to use the configured LSP metric values for the shortcuts when doing SPF calculations.

**Syntax** **shortcuts isis** { **level1** | **level2** } [ **announce announce-metric** *value* | **ignore-lsp-metric** ] [ **announce** [ **announce-metric** *value* ] ] [ **relative-metric +/-** *value* ]

**no shortcuts isis** { **level1** | **level2** } [ **announce announce-metric** *value* | **ignore-lsp-metric** ] [ **announce** [ **announce-metric** *value* ] ] [ **relative-metric +/-** *value* ]

**Command Default** The configured LSP metric is used as the shortcut's cost when performing IGP SPF calculation.

**Parameters** **level1**

A level1 router routes traffic only within the area that includes the router. To forward

traffic to another area, a level1 router sends the traffic to the nearest level2 router.

**level2**

A level2 router routes traffic between areas within a domain.

**announce**

Announces tunnel into ISIS domain.

**announce-metric** *value*

Announces the metric value between 1-16777215. The default is 10.

**ignore-lsp-metric**

Ignore configured LSP metric as the shortcut's cost when performing IGP SPF calculation.

**announce**

Announce tunnel into ISIS domain.

**announce-metric** *value*

Announces the metric value between 1-16777215. The default is 10.

**relative-metric**

Configures relative metric.

**+/-** *value*

The + or – sign is required. + denotes a positive number. – denotes a negative number. For *value*, enter a value from 1 – 16777215. The default is 0 (zero).

**Modes** MPLS LSP sub configuration mode (config-mpls-lsp-lspxxx ).

**Usage Guidelines** Use the **no** form of this command without other optional keywords to disable this feature. The LSP must be disabled before configuring/de-configuring this feature.

When "ignore-lsp-metric" is enabled, ISIS will behave like the shortcut LSP metrics are not configured.

When announce is not enabled and a metric is not explicitly configured under the LSP configuration mode of the CLI, the relative metric is used to compute the shortcut cost.

**Examples** The following example displays that when the tunnel is enabled, the user must disable it before enabling announce, then re-enable the tunnel.

```
device(config-mpls-lsp-tomu3)# disable
Disconnecting signaled LSP tomu3
device(config-mpls-lsp-tomu3)# shortcuts isis level2 announce
device(config-mpls-lsp-tomu3)# enable
Connecting signaled LSP tomu3
```

**History**

Release version	Command history
5.4.0	This command is modified to include the new option keyword <b>ignore-lsp-metric</b> . This is added to the existing shortcut command under the LSP configuration mode.

## short-path-forwarding

Enables short-path forwarding on a Virtual Router Redundancy Protocol (VRRP) router.

**Syntax** **short-path-forwarding** [ **revert-priority** *number* ]

**no short-path-forwarding** [ **revert-priority** *number* ]

**Command Default** Short-path forwarding is disabled.

**Parameters** **revert-priority** *number*

Allows additional control over short-path-forwarding on a backup router. If you configure this option, the revert-priority number acts as a threshold for the current priority of the session, and only if the current priority is higher than the revert-priority will the backup router be able to route frames. The range of revert-priority is 1 to 254.

**Modes** Virtual-router-group configuration mode

**Usage Guidelines** Short-path forwarding means that a backup physical router in a virtual router attempts to bypass the VRRP-E master router and directly forward packets through interfaces on the backup router.

This command can be used for VRRP-E, but not for VRRP. You can perform this configuration on a virtual Ethernet (VE) interface only.

Enter **no short-path-forwarding** to remove this configuration.

**Examples** To enable short-path-forwarding on a VRRP-E group:

```
device# configure terminal
device(config)# router vrrp-extended
switch(config-vrrpe-router)# slow-start 40
switch(config-vrrp-extended-group-100)# short-path-forwarding
```

short-path-forwarding

# Show Commands

---

## show access-list accounting

Displays Access Control List (ACL) accounting statistics of IPv4 ACLs, IPv6 ACLs, and Layer 2 ACLs.

**Syntax** `show access-list accounting brief [ rate-limit [ I2 | uda ] [ policy-based-routing [ omit-zero ] ] ]`

`show access-list accounting ethernet slot/port { in | out } [ rate-limit [ I2 | uda ] [ policy-based-routing [ omit-zero ] ] ]`

`show access-list accounting ve ve-number { in | out } [ rate-limit [ I2 | uda ] [ policy-based-routing [ omit-zero ] ] ]`

### Parameters

#### brief

Displays the ACL accounting summary.

#### rate-limit

Displays rate-limit accounting information.

#### I2

Displays Layer 2 ACL accounting information.

#### uda

Displays UDA ACL accounting information.

#### policy-based-routing

Displays policy-based routing accounting information.

#### omit-zero

Specifies not to display ACL entry with 0 packet/bits.

#### in

Displays statistics of the inbound packets.

#### out

Displays statistics of the outbound packets.

#### ethernet slot/port

Displays the accounting statistics for ACLs on a physical interface.

#### ve ve-number

Displays the statistics for ACLs bound to ports that are members of a virtual routing interface.

**Modes** User EXEC mode

**Usage Guidelines** The output displays information about IPv4 ACLs, IPv6 ACLs, or Layer 2 ACLs, based on the configuration of the port or interface.

**Command Output** The `show access-list accounting` command displays the following information:

Output field	Description
Int	Identifies the interface.
In ACL	Displays the name of the ingress ACL.

Output field	Description
Total In Hit	Displays the number of ingress-packet hits during the specified interval: <ul style="list-style-type: none"> <li>• 1s—one second</li> <li>• 1m—one minute</li> <li>• 5m—five minutes</li> <li>• acc—total accumulated packet hits</li> </ul>
Out ACL	Displays the name of the egress ACL.
Total Out Hit	Displays the number of egress-packet hits during the specified interval.

**Examples** The following example displays the incoming accounting information on a physical interface.

```
device(config)# enable-acl-counter
device# show access-list accounting ethernet 1/1 in
Inbound:
ACL 1
  0: permit host 29.7.51.11
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
  1: permit host 29.7.51.9
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
  2: permit host 29.7.51.10
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
  3: permit host 29.7.51.14
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
  4: permit host 29.7.51.15
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
```

The following example displays the Layer 2 PBR incoming accounting information on a physical interface.

```
device(config)# show access-list accounting ethernet 1/2 in l2 policy-based-routing
L2 Policy based Routing Accounting Information:

Routemap l2pbr10
ACL x10
  0: 10: permit any any any etype any
    Hit count: (1 sec)          0 (1 min)          0
              (5 min)          0 (accum)         0
```

The following example displays the general brief accounting summary.

```
device# show access-list accounting brief
Int      In ACL      Total In Hit      Out ACL      Total Out Hit
1/1      1            0 (1s)           2            0 (1s)
          0 (1m)           0 (1m)           0 (1m)
          0 (5m)           0 (5m)           0 (5m)
          0 (ac)            0 (ac)           0 (ac)
```

The following example displays the Layer 2 PBR accounting summary.

```
device# show access-list accounting brief l2 policy-based-routing
1/1            x10            0 (1s)
               0 (1m)
               0 (5m)
               0 (ac)

4/2            x10            0 (1s)
               0 (1m)
               0 (5m)
               0 (ac)
```



The following example displays the UDA PBR statistics on the specified interface.

```
device(config)# show access-list accounting ethernet 3/1 in uda policy-based-routing
Policy based Routing Accounting Information:
Routemap routel
ACL ACLNameTest112345679-023456789-0123456789
  0: sequence 10 permit 100 any any 1234 ffff any
    Hit count: (1 sec) 0 (1 min) 0
(5 min) 0 (accum) 0
                0(ac)
```

## History

Release version	Command history
5.8.00b	The <b>I2</b> option was introduced.
5.9.00	The command was modified to display the UDA PBR statistics on the specified interface.

## show access-list bindings

Displays all access-lists bound to different interfaces. This includes both rule-based ACL and receive access-control list (rACL) information

**Syntax** `show access-list bindings`

**Modes** User EXEC node

**Examples** The following example displays all access-list bindings.

```
Brocade(config)# show access-list bindings
L4 configuration:
!
interface ethe 2/1
 mac access-group SampleACL in
!
```

## show access-list receive accounting

Displays accounting information for a receive access-control list (rACL) or brief information for all rACLs.

**Syntax** `show access-list receive accounting { acl-num | name acl-name | brief }`

**Parameters** *acl-num*

Specifies a receive ACL in number format. Valid values are 1 through 99 for standard ACLs and 100 through 199 for extended ACLs.

**name** *acl-name*

Specifies a receive ACL in name format.

**brief**

Displays receive-ACL accounting in brief.

**Modes** User EXEC mode

**Examples** The following example displays rACL accounting information for an ACL named "acl\_ext1".

```
device(config)# show access-list receive accounting name acl_ext1
IP Receive ACL Accounting Information:
IP Receive ACL acl_ext1
ACL hit count for software processing (accum)                0
HW counters:
  0: permit tcp any host 10.10.10.14
    Hit count: (1 sec)                0 (1 min)                0
              (5 min)                0 (accum)                0
```

### History

Release	Command History
5.6.00	This command was modified to support named ACLs, in addition to numbered ACLs.

## show arp

Displays an IP mechanism that the routers use to learn the Media Access Control (MAC) address of a device on the network.

**Syntax** **show arp** [ *ip-addr* [ *ip-mask* ] | *num-entries-to-skip* | **ethernet slot / port** | **mac-address** *xxxx.xxxx.xxxx* [ *MAC-mask* ] | **vrf vrf-name** ]

**Parameters**

*ip\_addr*  
Specifies IP address.

*ip\_mask*  
Specifies IP subnet.

*num-entries-to-skip*  
Number of entries to skip.

**ethernet slot/port**  
Displays specified ethernet port.

**mac-address** *xxxx.xxxx.xxxx*  
Displays the mac address of the specified entry.

*MAC-mask*  
Specifies a mask for display of multiple MAC addresses.

**vrf vrf\_name**  
Displays ARP entries belonging to a given VRF instance.

**Modes** User EXEC mode

**Usage Guidelines** This command operates in all modes.

**Command Output** The **show arp** command displays the following information:

Output field	Description
IP Address	The IP address of the entry.
MAC Address	The MAC address of the entry.
Type	Displays the type of entry. The options are: <ul style="list-style-type: none"> <li>• Static: The Layer 3 switch loaded the entry from the static ARP table when the device for the entry was connected to the Layer 3 switch.</li> <li>• Dynamic: The Layer 3 switch learned the entry from an incoming packet.</li> <li>• DHCP - The Layer 3 Switch learned the entry from the DHCP binding address table. In this case, the port number is not available until the entry gets resolved through ARP.</li> </ul>
Age	The number of minutes before which the ARP entry was refreshed. If this value reaches the ARP aging period, the entry is removed from the table. Static entries do not age out.
Port/Port	The 'To' and 'From' ports. If the ARP entry type is DHCP, the port number is not available until the entry gets resolved through ARP.
Vpls-Id:Vlan	Displays VPLS identification information.
Vpls-Id:Peer	Displays VPLS peer information.

**Examples** The following example displays the **show arp** command output:

```
device(config)# show arp
Total number of ARP entries: 4
Entries in default routing instance:
IP Address  MAC Address  Type  Age  Port/Port  (Vpls-Id:Vlan)/(Vpls-Id:Peer)
10.25.104.1 0000.0012.3eb5 Static None 4/1 (101, 26)
10.25.104.3 0000.000f.c200 Dynamc 0 mgmt1
10.1.1.2 0000.00f8.0090 Dynamc 1 mgmt1
10.25.104.1 0000.0012.3eb5 Static None (21,10.32.332.1)
```

## show arp-guard-access-list

Displays details for a specified ARP-guard access list (ACL) or all ARP-guard ACLs.

**Syntax** `show arp-guard-access-list { all | name arp-guard-access-list }`

**Parameters** **all**

Specifies all ARP-guard ACLs.

**name** *arp-guard-access-list*

Specifies the name of an ARP-guard access list.

**Modes** User EXEC mode

**Examples** The following example displays information about the ARP guard access list named C5-global-arp.

```
Brocade#show arp-guard-access-list name C5-global-arp
Arp-Guard : C5-global-arp
Number of rules : 6
Number of Ports : 16
Rules configured
  permit 40 31.0.8.1 0012.f290.7400
  permit 1500 31.0.10.2 0000.0015.0000
  permit 1001 100.0.0.2 0024.38a3.6e00
  permit 20 41.0.100.1 0024.38a3.6e00
  permit 80 51.0.4.2 748e.f874.4900
  permit any 31.0.11.1 0012.f290.7400
C5(config)#
```

The following example displays information about all the ARP guard access list.

```
Brocade#sh arp-guard-access-list all
Arp-guard configuration:
!
arp-guard-access-list C5-8
!
arp-guard-access-list MCT-A3
  permit any 31.0.10.2 0000.0300.0000
  permit any 31.0.10.3 0000.0300.0001
  permit any 31.0.10.4 0000.0300.0002
  permit any 31.0.10.5 0000.0300.0003
  permit any 31.0.11.1 any
  permit any 31.0.11.2 any
  permit any 31.0.11.3 any
!
arp-guard-access-list C5-global-arp
  permit 40 31.0.8.1 0012.f290.7400
  permit 1500 31.0.10.2 0000.0015.0000
  permit 1001 100.0.0.2 0024.38a3.6e00
  permit 20 41.0.100.1 0024.38a3.6e00
  permit 80 51.0.4.2 748e.f874.4900
  permit any 31.0.11.1 0012.f290.7400
!
arp-guard-access-list AS201
  permit any 1.1.1.1 any
  permit any 1.1.1.1 0001.0001.0001
!
```

**History**

Release version	Command history
R05.7.00	This command was introduced.

## show arp-guard port-bindings

Displays list of ports associated with an ARP-guard access-list (ACL) or with all ARP-guard ACLs.

**Syntax** `show arp-guard port-bindings { arp-guard-access-list | all }`

**Parameters** `arp-guard-access-list`  
 Displays port-binding associations for an ARP-guard access list.

`all`  
 Displays port-binding associations for all ARP-guard ACLs.

**Modes** User EXEC mode

**Usage Guidelines** This command can be entered in most configuration modes. See the Examples section for several examples in different configuration modes.

**Command Output** The `show arp-guard port-bindings` command displays the following information:

Output field	Description
Arp-Guard	Displays the name of the ARP-guard.
Number of Ports	Displays the total number of ports associated with this ARP-guard.
Port Lists	Displays the list of ports associated with that ARP-guard.

**Examples** The following example displays information about the ARP-guard port bindings for AS200.

```
device(config-if-e10000-1/8)# show arp-guard port-bindings AS200
Arp-Guard : AS200
Number of Ports : 1
Port Lists : ethe 1/8
```

The following example displays information about the ports associated with ARP-guard.

```
device# show arp-guard port-bindings all
Arp-Guard Port Bindings:

Arp-Guard      : ag1
Number of Ports : 0

Arp-Guard      : ag2
Number of Ports : 2
  Ethe 1/2      Log : Disabled
  Ethe 1/4      Log : Disabled

Arp-Guard      : ag3
Number of Ports : 8
  Ethe 1/1      Log : Disabled
  Ethe 2/1      Log : Enabled      Num of violations : Default
  Ethe 2/2      Log : Enabled      Num of violations : 32
  Ethe 2/3      Log : Enabled      Num of violations : 32
  Ethe 2/4      Log : Enabled      Num of violations : 32
  Ethe 2/6      Log : Disabled
  Ethe 3/1      Log : Enabled      Num of violations : Default
  Ethe 4/1      Log : Enabled      Num of violations : Default
```

### History

Release version	Command history
5.7.00	This command was introduced.

# show arp-guard statistics ethernet

Displays ARP-guard statistical information.

- Syntax** `show arp-guard statistics ethernet { all | slot/port [ vlan vlan-id ] }`
- Parameters**
  - all** Displays all ARP-guard port statistics.
  - slot/port* Displays statistics specific to a port.
  - vlan vlan-id** Displays statistics specific to a VLAN on a port. The VLAN ID range is from 1 through 4090.
- Modes** User EXEC mode
- Usage Guidelines** This command displays statistics for LAG primary ports, but not for secondary ports.
- Command Output** The `show arp-guard statistics ethernet` command displays the following information:

Output field	Description
Port	The port number.
Vlan-id	The VLAN ID.
Total_Arp_pkts_captured	The total number of ARP packets captured.
Total_Arp_pkts_forwarded	The total number of ARP packets forwarded
Total_Arp_pkts_dropped	The total number of ARP packets dropped
LAG : Prim	Displayed only in the show arp-guard statistics ethernet all alone. To denote LAG ID and its Primary port for that LAG associated with all the ARP-guard enabled ports.

**Examples** The following example displays statistics information for all the ports.

```
Brocade(config)# show arp-guard statistics ethernet all
Port          Vlan-id  Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped  LAG : Prim
1/1 (Def/Untag)1          0                          0
1/1          3          10000                      9000
1/1          2          10000                      9000
2/1 (Def/Untag)1          0                          0
2/1          2          10000                      9000
2/1          4          10000                      9000
2/1          5          10000                      9000
```

The following example displays statistics information for any individual port.

```
Brocade(config)# show arp-guard statistics ethernet 1/1
Port          Vlan-id  Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped  LAG : Prim
1/1 (Def/Untag)1          0                          0
1/1          3          10000                      9000
1/1          2          10000                      9000
```



The following example displays statistics information for a VLAN of the ARP-guard-enabled port

```
Brocade# show arp-guard statistics ethernet 1/1 vlan 2
Port      Vlan-id      Total_Arp_pkts_captured  Total_Arp_pkts_forwarded
Total_Arp_pkts_dropped
1/1
9000          2          10000          100
```

**History**

Release version	Command history
R05.7.00	This command was introduced.

## show bfd

Displays Bidirectional Forwarding Detection (BFD) information.

**Syntax** `show bfd`

**Modes** User EXEC mode

**Command Output** The `show bfd` command displays the following information:

Output field	Description
BFD State	Specifies whether BFD is enabled or disabled on the device.
Version	Specifies the version of the BFD protocol operating on the device.
Use PBIF Assist	Specifies the status of PCI Bus Interface (PBIF) Assist.
Current Registered Protocols	Specifies which protocols are registered to use BFD on the device. Possible values are mpls/0, ospf/0, ospf6/0, or isis_task/0.
All Sessions	
Current:	The number of BFD sessions currently operating on the device.
Maximum Allowed	The maximum number of BFD sessions that are allowed on the device. The maximum number of sessions supported is 250 for Brocade NetIron MLX Series devices and Brocade NetIron XMR Series devices and 40 for Brocade NetIron CES Series devices.
Maximum Exceeded Count	The number of times the request to set up a BFD session was declined because it would have resulted in exceeding the maximum number of BFD sessions allowed on the device.
LP Sessions:	
Maximum Allowed on LP	The maximum number of BFD sessions that are allowed on an interface module. The maximum number of sessions supported on an interface module is 40 for Brocade NetIron XMR Series devices and Brocade NetIron MLX Series devices, and 20 for Brocade NetIron CES Series devices.
Maximum Exceeded Count for LPs	The number of times the request to set up a BFD session was declined because it would have resulted in exceeding the maximum number of BFD sessions allowed on an interface module.
LP	The number of the interface module for which the Current Session Count is displayed.
TX/RX Sessions	The number of Transmit (Tx) and Receive (Rx) BFD sessions currently operating on the specified interface module.
BFD Enabled ports count	The number of ports on the device that have been enabled for BFD.

Output field	Description
Port	The port that BFD is enabled on.
MinTx	The interval in milliseconds between which the device desires to send a BFD message from this port to its peer.
MinRx	The interval in milliseconds that this device desires to receive a BFD message from its peer on this port.
Mult	The number of times that the device will wait for the MinRx time on this port before it determines that its peer device is non-operational.
Sessions	The number of BFD sessions originating on this port.

**Examples** The following example displays BFD information for the device.

```
device# show bfd
BFD State: ENABLED Version: 1 Use PBIF Assist: Y
Current Registered Protocols: ospf/0 ospf6/0
All Sessions: Current: 4 Maximum Allowed: 100 Maximum Exceeded Count: 0
LP Sessions: Maximum Allowed on LP: 40 Maximum Exceeded Count for LPs: 0
LP Tx/Rx Sessions LP Tx/Rx Sessions LP Tx/Rx Sessions LP Tx/Rx Sessions
1 4/4 2 2/2 3 0/0 4 0/0
5 0/0 6 0/0 7 0/0 8 0/0
9 0/0 10 0/0 11 0/0 12 0/0
13 0/0 14 0/0 15 0/0 16 0/0
BFD Enabled ports count: 2
Port MinTx MinRx Mult Sessions
eth 2/1 100 100 3 2
eth 3/1 100 100 3 2
```

#### History

Release version	Command history
5.6.00	This command was modified to include MPLS in the registered protocol list. In addition, the number of sessions on the LP is shown separately as TX and RX.

## show bfd applications

Displays Bidirectional Forwarding Detection (BFD) registered protocol information.

**Syntax** `show bfd applications`

**Modes** User EXEC mode

**Command Output** The `show bfd applications` command displays the following information:

Output field	Description
Registered Protocols Count	Total number of protocols registered to use BFD on the device.
Protocol	Which protocols are registered to use BFD on the device.
VRFID	The VRFID of the protocol.
Parameter	The parameter value passed by the protocol during registration with BFD.
HoldoverInterval	The time by which the BFD session down notification is delayed. If within that holdover time, the BFD session is up, then it is not notified of the BFD session flap.

**Examples** The following example displays BFD registered protocol information for the device.

```
device# show bfd applications
Registered Protocols Count: 3
Protocol  VRFID      Parameter HoldoverInterval
isis      0            0          2
ospf6     0            1          10
ospf      0            0          5
```

**History**

Release version	Command history
5.6.00	The command was modified to include MPLS information.

# show bfd mpls

Displays information about MPLS Bi-Directional Forwarding (BFD) sessions. You can filter BFD sessions based on LSP name or egress RSVP session ID.

**Syntax** **show bfd mpls**

**show bfd mpls detail**

**show bfd mpls lsp** *lsp-name*

**show bfd mpls rsvp-session** *src\_addr dest\_addr tunnel-id*

**Parameters** **detail**

Displays the MPLS BFD session in detail.

**lsp** *lsp-name*

Displays the MPLS BFD session associated with a specific LSP.

**rsvp-session** *src\_addr dest\_addr tunnel-id*

Displays the MPLS BFD session associated with the egress RSVP session specified using the source address, destination address, and tunnel ID options.

**Modes** User EXEC mode

**Usage Guidelines** If no optional keywords are entered, information about all MPLS BFD sessions is displayed. You can filter BFD session based on LSP name or egress RSVP session ID or show detailed MPLS BFD information. For MPLS BFD sessions associated with LSP, the LSP name is displayed. For a BFD session associated with an egress RSVP session, the RSVP session ID issued to identify the BFD session is displayed.

**History**

Release	Command history
5.6.00	This command was introduced.

## show bfd neighbors

Displays detailed Bidirectional Forwarding Detection (BFD) neighbor information.

**Syntax** `show bfd neighbors [ ip-address | ipv6-address ]`

**Parameters** `ip-address`

Specifies the IP address of a neighbor.

`ipv6-address`

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Command Output** The `show bfd neighbors` command displays the following information:

Output field	Description
Total number of Neighbor entries	The number of neighbors that have established BFD sessions with ports on this device.
NeighborAddress	The IPv4 or IPv6 address of the remote peer.
State	The current state of the BFD session: <ul style="list-style-type: none"> <li>• UP</li> <li>• DOWN</li> <li>• A.DOWN - The administrative down state.</li> <li>• INIT - The initialization state.</li> <li>• UNKNOWN - The current state is unknown.</li> </ul>
Interface	The logical port (physical or virtual port) on which the peer is known.
Holddown	The interval in milliseconds after which the session will transition to the down state if no message is received.
Interval	The interval in milliseconds at which the local device sends BFD messages to the remote peer.
R/H	R - Heard from Remote. Displays Y for Yes or N for No. H - Hops. Display S for single hop or M for multihop.

**Examples** The following example displays BFD neighbor information for the device.

```
device# show bfd neighbors
Total number of Neighbor entries: 2
NeighborAddress      State  Interface  Holddown  Interval  R/H
10.14.1.1            UP     eth 3/1    300000    100000    Y/S
10.2.1.1             UP     eth 2/1    300000    100000    Y/S
```

## show bfd neighbors bgp

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for BGP.

**Syntax** `show bfd neighbors bgp [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Command Output** The `show bfd neighbors bgp details` command displays the following information:

Output field	Description
Total Entries	Total number of BFD sessions.
NeighborAddress	IPv4 or IPv6 address of the remote peer.
State	The current state of the BFD session: <ul style="list-style-type: none"> <li>• UP</li> <li>• DOWN</li> <li>• A.DOWN - The administrative down state.</li> <li>• INIT - The initialization state.</li> <li>• UNKNOWN - The current state is unknown.</li> </ul>
Interface	The logical port on which the peer is known.
Holddown	The interval in milliseconds after which the session will transition to the down state if no message is received.
Interval	The interval in milliseconds at which the local device sends BFD messages to the remote peer.
R/H	R - Heard from Remote. Displays Y for Yes or N for No. H - Hops. Display S for single hop or M for multihop.
Registered Protocols	Specifies which protocols are registered to use BFD on this port.
Local:	The local device
Disc	Value of the local discriminator field in the BFD control message as used by the local device in the last message sent.
Diag	Value of the diagnostic field in the BFD control message as used by the local device in the last message sent.

Output field	Description
Demand	Value of the demand bit in the BFD control message as used by the local device in the last message sent.
Poll	Value of the poll bit in the BFD control message as used by the local device in the last message sent.
MinTxInterval	The interval in milliseconds during which the device will send a BFD message from this local neighbor port to the peer.
MinRxInterval	The interval in milliseconds that the neighbor device waits to receive a BFD message from the peer on this local port.
Multiplier	The number of times the neighbor device will wait for the MinRxInterval time on this port before it determines the peer device is non-operational.
Remote:	Remote peer.
Disc	Value of the local discriminator field in the BFD control message as received in the last message sent by the remote peer.
Diag	Value of the diagnostic field in the BFD control message as received in the last message sent by the remote peer.
Demand	Value of the demand bit in the BFD control message as received in the last message sent by the remote peer.
Poll	Value of the poll bit in the BFD control message as received in the last message sent by the remote peer.
MinTxInterval	The interval in milliseconds during which the device will send a BFD message from the remote neighbor port to the peer.
MinRxInterval	The interval in milliseconds that the neighbor device waits to receive a BFD message from the peer on this remote port.
Multiplier	The number of times that the remote neighbor device will wait for the MinRxInterval time on this port before it determines that the peer device is non-operational.
Stats:	Statistics
Rx	Total number of BFD control messages received from the remote peer.
Tx	Total number of BFD control messages sent to the remote peer.
SessionUpCount	The number of times the session has transitioned to the up state.
SysUpTime	The amount of time that the system has been up.
Session Uptime	The amount of time the session has been in the up state.



Output field	Description
LastSessionDownTimestamp	The system time at which the session last transitioned from the up state to some other state.
Physical Port	The physical port on which the peer is known.
Vlan Id	The VLAN ID of the VLAN on which the physical port is resident.

**Examples** The following example displays BFD neighbor information for BGP for the device.

```
device# show bfd neighbors bgp

Neighbor AS4 Capability Negotiation:
As-path attribute count: 2
Outbound Policy Group:
ID: 1, Use Count: 3
BFD:Enabled,BFDSessionState:UP,Multihop:Yes
LastBGP-BFDEvent:RX:Up,BGP-BFDError:No Error
NegotiatedTime(msec):Tx:1000000,Rx:1000000,BFDHoldTime:3000000
HoldOverTime(sec) Configured:22,Current:0,DownCount:0
TCP Connection state: ESTABLISHED, flags:00000044 (0,0)
Maximum segment size: 1460
```

The following example displays detailed BFD neighbor information for BGP for a Brocade NetIron MLX Series or Brocade NetIron XMR Series device.

```
device# show bfd neighbors bgp details

Total Entries:4 R:RxRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State Interface Holddown Interval R/H
10.101.101.100      UP ve 3 3000000 1000000 Y/M
Registered Protocols(Protocol/VRFID): bgp/0
Local: Disc: 26, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Remote: Disc: 7, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Stats: RX: 14682 TX: 12364 SessionUpCount: 1 at SysUpTime: 0:2:46:24.725
Session Uptime: 0:1:37:50.600, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/1,RX: eth 1/1,Vlan Id: 3
NeighborAddress      State Interface Holddown Interval R/H
10.100.100.100      UP ve 3 3000000 1000000 Y/M
Registered Protocols(Protocol/VRFID): bgp/0
Local: Disc: 27, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Remote: Disc: 8, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Stats: RX: 14232 TX: 12046 SessionUpCount: 1 at SysUpTime: 0:2:46:24.725
Session Uptime: 0:1:37:49.650, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/1,RX: eth 1/1,Vlan Id: 3
NeighborAddress      State Interface Holddown Interval R/H
10.1.1.1            UP ve 3 3000000 1000000 Y/M
Registered Protocols(Protocol/VRFID): bgp/0
Local: Disc: 28, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Remote: Disc: 9, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Stats: RX: 15652 TX: 12044 SessionUpCount: 1 at SysUpTime: 0:2:46:24.725
Session Uptime: 0:1:37:48.725, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/1,RX: eth 1/1,Vlan Id: 3
NeighborAddress      State Interface Holddown Interval R/H
10.102.102.100      UP ve 3 3000000 1000000 Y/M
Registered Protocols(Protocol/VRFID): bgp/0
Local: Disc: 29, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Remote: Disc: 10, Diag: 0, Demand: 0 Poll: 0
MinTxInterval: 1000000, MinRxInterval: 1000000, Multiplier: 3
Stats: RX: 14232 TX: 12044 SessionUpCount: 1 at SysUpTime: 0:2:46:24.725
Session Uptime: 0:1:37:48.550, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/1,RX: eth 1/1,Vlan Id: 3
```

The following example displays detailed BFD neighbor information for BGP for a Brocade NetIron CES Series or Brocade NetIron CER Series device.

```
device# show bfd neighbors bgp details

Total Entries:1 R:RXRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface Holddown  Interval R/H
fe80::224:38ff:fe79:9310  UP    eth 1/17 1500000  500000  Y/S
Registered Protocols(Protocol/VRFID): bgp/0
Local: Disc: 8, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 500000, MinRxInterval: 500000, Multiplier: 3
Remote: Disc: 2, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 500000, MinRxInterval: 500000, Multiplier: 3
Stats: RX: 160394 TX: 142648 SessionUpCount: 1 at SysUpTime: 5:17:14:13.225
      Session Uptime: 0:17:49:42.100, LastSessionDownTimestamp: 0:0:0:0.0
      Physical Port:TX: eth 1/17,RX: eth 1/17,Vlan Id: 1
      Using PBIF Assist: Y
```

## show bfd neighbors details

Displays detailed Bidirectional Forwarding Detection (BFD) neighbor information.

**Syntax** `show bfd neighbors details [ ip-address | ipv6-address ]`

**Parameters**

`ip-address` Specifies the IP address of a neighbor.

`ipv6-address` Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Command Output** The `show bfd neighbors details` command displays the following information:

Output field	Description
Total number of Neighbor entries	Total number of BFD sessions.
NeighborAddress	IPv4 or IPv6 address of the remote peer.
State	The current state of the BFD session: <ul style="list-style-type: none"> <li>• UP</li> <li>• DOWN</li> <li>• A.DOWN - The administrative down state.</li> <li>• INIT - The initialization state.</li> <li>• UNKNOWN - The current state is unknown.</li> </ul>
Interface	The logical port on which the peer is known.
Holddown	The interval in milliseconds after which the session will transition to the down state if no message is received.
Interval	The interval in milliseconds at which the local device sends BFD messages to the remote peer.
R/H	R - Heard from Remote. Displays Y for Yes or N for No. H - Hops. Display S for single hop or M for multihop.
Registered Protocols	Specifies which protocols are registered to use BFD on this port.
Local:	The local device
Disc	Value of the local discriminator field in the BFD control message as used by the local device in the last message sent.
Diag	Value of the diagnostic field in the BFD control message as used by the local device in the last message sent.

<b>Output field</b>	<b>Description</b>
Demand	Value of the demand bit in the BFD control message as used by the local device in the last message sent.
Poll	Value of the poll bit in the BFD control message as used by the local device in the last message sent.
MinTxInterval	The interval in milliseconds between which the device will send a BFD message from this local neighbor port to its peer.
MinRxInterval	The interval in milliseconds that the neighbor device waits to receive a BFD message from its peer on this local port.
Multiplier	The number of times that the neighbor device will wait for the MinRxInterval time on this port before it determines that its peer device is non-operational.
Remote:	Remote peer.
Disc	Value of the local discriminator field in the BFD control message as received in the last message sent by the remote peer.
Diag	Value of the diagnostic field in the BFD control message as received in the last message sent by the remote peer.
Demand	Value of the demand bit in the BFD control message as received in the last message sent by the remote peer.
Poll	Value of the poll bit in the BFD control message as received in the last message sent by the remote peer.
MinTxInterval	The interval in milliseconds between which the device will send a BFD message from the remote neighbor port to its peer.
MinRxInterval	The interval in milliseconds that the neighbor device waits to receive a BFD message from its peer on this remote port.
Multiplier	The number of times that the remote neighbor device will wait for the MinRxInterval time on this port before it determines that its peer device is non-operational.
Stats	Statistics
Rx	Total number of BFD control messages received from the remote peer.
Tx	Total number of BFD control messages sent to the remote peer.
SessionUpCount	The number of times the session has transitioned to the up state.
SysUpTime	The amount of time that the system has been up.
Session Uptime	The amount of time the session has been in the up state.

Output field	Description
LastSessionDownTimestamp	The system time at which the session last transitioned from the up state to some other state.
Physical Port	The physical port on which the peer is known.
Vlan Id	The VLAN ID of the VLAN on which the physical port is resident
Session	Session details
Using PBIF Assist	Y for Yes: PBIF Assist is used for this BFD session. N for No: PBIF is not used for this BFD session.

**Examples** The following example displays detailed BFD neighbor information for the device.

```
device# show bfd neighbors details
Total number of Neighbor entries: 1
NeighborAddress      State   Interface  Holddown  Interval  R/H
10.14.1.1            UP      ve 50      300000    100000    Y/S
  Registered Protocols(Protocol/VRFID): ospf/0
  Local: Disc: 1, Diag: 0, Demand: 0 Poll: 0
    MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
  Remote: Disc: 22, Diag: 7, Demand: 0 Poll: 0
    MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
  Stats: RX: 72089 TX: 72101 SessionUpCount: 1 at SysUpTime: 0:1:30:54.775
  Session Uptime: 0:1:30:6.375, LastSessionDownTimestamp: 0:0:0:0.0
  Physical Port: eth 4/1, Vlan Id: 50,Session: Active
Using PBIF Assist: Y
```

## show bfd neighbors interface

Displays Bidirectional Forwarding Detection (BFD) neighbor information about specified interfaces.

- Syntax** `show bfd neighbors interface [ ethernet slot/port | pos slot/port | ve vlan_id ] [ details ] [ ip-address | ipv6-address ]`
- Parameters**
- ethernet slot /port** Specifies an Ethernet interface with a valid slot and port number.
  - pos slot /port** Specifies an Packet over SONET (POS) interface with a valid slot and port number.
  - ve vlan-id** Specifies a virtual Ethernet (VE) interface.
  - details** Displays detailed neighbor interface information.
  - ip-address** Specifies the IP address of a neighbor.
  - ipv6-address** Specifies the IPv6 address of a neighbor.
- Modes** User EXEC mode
- Examples** The following example displays BFD neighbor information for the Ethernet 1/1 interface.

```
device# show bfd neighbors interface ethernet 1/1

BFD State: ENABLED Version: 1 Use PBIF Assist: Y SH setup delay 180 MH setup delay 0
Current Registered Protocols: mpls/0 ospf/2 ospf6/0 ospf/4 ospf/0
All Sessions: Current: 0 Maximum Allowed: 250 Maximum Exceeded Count: 0
Maximum TX/RX Sessions Allowed on LP: 80 Maximum Session Exceeded Count for LPs: 0
  LP Tx/Rx Sessions LP Tx/Rx Sessions LP Tx/Rx Sessions LP Tx/Rx Sessions
  1 0/0      2 0/0      3 0/0      4 0/0
BFD Enabled ports count: 1
Port      MinTx      MinRx      Mult Sessions
eth 1/1   55         55         5 0
```

## show bfd neighbors isis

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for IS-IS.

**Syntax** `show bfd neighbors isis [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Examples** The following example displays BFD neighbor information for IS-IS.

```
device# show bfd neighbors isis
```

```
Total Entries:1 R:RxRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface      Holddown  Interval  R/H
10.40.40.10          UP    eth 3/6        900000    300000    Y/S
```

The following example displays detailed BFD neighbor information for IS-IS.

```
device# show bfd neighbors isis details
```

```
Total Entries:1 R:RxRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface      Holddown  Interval  R/H
10.40.40.10          UP    eth 3/6        900000    300000    Y/S
Registered Protocols(Protocol/VRFID): isis/0
Local: Disc: 9, Diag: 0, Demand: 0 Poll: 0
  MinTxInterval: 300000, MinRxInterval: 300000, Multiplier: 3
Remote: Disc: 5, Diag: 0, Demand: 0 Poll: 0
  MinTxInterval: 300000, MinRxInterval: 300000, Multiplier: 3
Stats: RX: 226 TX: 252 SessionUpCount: 1 at SysUpTime: 2:0:25:44.306
Session Uptime: 0:0:0:59.278, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 3/6,RX: eth 3/6,Vlan Id: 1
Using PBIF Assist: Y
```

## show bfd neighbors ospf

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for OSPFv2.

**Syntax** `show bfd neighbors ospf [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Examples** The following example displays BFD neighbor information for OSPFv2.

```
device# show bfd neighbors ospf
```

```
Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1.1.1.1              UP    eth 1/2    300000    100000    Y/S
```

The following example displays detailed BFD neighbor information for OSPFv2.

```
device# show bfd neighbors ospf details
```

```
Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1.1.1.2              UP    eth 1/2    300000    100000    Y/S
Registered Protocols(Protocol/VRFID): static/0 ospf/0
Local: Disc: 1, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Remote: Disc: 1, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Stats: RX: 1053134 TX: 917679 SessionUpCount: 1 at SysUpTime: 0:23:30:4.55
Session Uptime: 0:23:24:40.367, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/2,RX: eth 1/2,Vlan Id: 1
Using PBIF Assist: Y
```



## show bfd neighbors ospf6

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for OSPFv3.

**Syntax** `show bfd neighbors ospf6 [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Examples** The following example displays BFD neighbor information for OSPFv3.

```
device# show bfd neighbors ospf6
```

```
Total Entries:1 R:RxRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
fe80::21b:edff:fe3b:8601  UP    eth 1/2    300000    100000    Y/S
```

The following example displays detailed BFD neighbor information for OSPFv3.

```
device# show bfd neighbors ospf6 details
```

```
Total Entries:1 R:RxRemote(Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
fe80::21b:edff:fe3b:8601  UP    eth 1/2    300000    100000    Y/S
Registered Protocols(Protocol/VRFID): ospf6/0
Local: Disc: 2, Diag: 0, Demand: 0 Poll: 0
  MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Remote: Disc: 2, Diag: 0, Demand: 0 Poll: 0
  MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Stats: RX: 1046743 TX: 912150 SessionUpCount: 1 at SysUpTime: 0:23:30:25.808
Session Uptime: 0:23:16:8.793, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/2,RX: eth 1/2,Vlan Id: 1
Using PBIF Assist: Y
```

## show bfd neighbors static

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for IP static routes.

**Syntax** `show bfd neighbors static [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Examples** The following example displays BFD neighbor information for IP static routes.

```
device# show bfd neighbors static

Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1.1.1.1              UP    eth 1/2    300000    100000    Y/S
```

The following example displays detailed BFD neighbor information for IP static routes.

```
device# show bfd neighbors static details

Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop(S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1.1.1.2              UP    eth 1/2    300000    100000    Y/S
Registered Protocols(Protocol/VRFID): static/0 ospf/0
Local: Disc: 1, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Remote: Disc: 1, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Stats: RX: 1054000 TX: 918434 SessionUpCount: 1 at SysUpTime: 0:23:31:13.409
Session Uptime: 0:23:25:49.719, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/2,RX: eth 1/2,Vlan Id: 1
Using PBIF Assist: Y
```

## show bfd neighbors static6

Displays Bidirectional Forwarding Detection (BFD) neighbor session information for IPv6 static routes.

**Syntax** `show bfd neighbors static6 [ details ] [ ip-address | ipv6-address ]`

**Parameters** **details**

Displays detailed neighbor interface information.

*ip-address*

Specifies the IP address of a neighbor.

*ipv6-address*

Specifies the IPv6 address of a neighbor.

**Modes** User EXEC mode

**Examples** The following example displays BFD neighbor information for IPv6 static routes.

```
device# show bfd neighbors static6
```

```
Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop (S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1::1                 UP    eth 1/2    300000    100000    Y/S
```

The following example displays detailed BFD neighbor information for IPv6 static routes.

```
device# show bfd neighbors static6 details
```

```
Total Entries:1 R:RxRemote (Y:Yes/N:No)H:Hop (S:Single/M:Multi)
NeighborAddress      State  Interface  Holddown  Interval  R/H
1::1                 UP    eth 1/2    300000    100000    Y/S
Registered Protocols(Protocol/VRFID): static6/0
Local: Disc: 3, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Remote: Disc: 3, Diag: 0, Demand: 0 Poll: 0
      MinTxInterval: 100000, MinRxInterval: 100000, Multiplier: 3
Stats: RX: 1192696 TX: 1023053 SessionUpCount: 1 at SysUpTime: 0:23:31:37.757
Session Uptime: 0:23:11:58.266, LastSessionDownTimestamp: 0:0:0:0.0
Physical Port:TX: eth 1/2,RX: eth 1/2,Vlan Id: 1
Using PBIF Assist: Y
```

# show bip slot

Displays a table that contains the lane number for a Physical Coding Sublayer (PCS) lane and a count of Bit Interleaved Parity (BIP) errors for that PCS lane, for each lane where a counter is active.

**Syntax** `show bip slot slot_number`

**Parameters** `slot_number`  
 Specifies the slot number for which the BIP information is to be displayed.

**Modes** User EXEC mode.

**Command Output** The `show bip slot` command displays the following information:

Output field	Description
Lane	The PCS lane on the port.
Count	The value of the counter associated with the lane.

**Examples** The following example shows the `show bip slot` command:

```
device# show bip slot 3
Port 3/1:
PCS Lane BIP Error Counters :
*****
Lane00 : 001      Lane01 : 001
Lane02 : 001      Lane03 : 001
Lane04 : 001      Lane05 : 001
Lane06 : 001      Lane07 : 001
Lane08 : 001      Lane09 : 001
Lane10 : 001      Lane11 : 001
Lane12 : 001      Lane13 : 001
Lane14 : 001      Lane15 : 001
Lane16 : 001      Lane17 : 001
Lane18 : 001      Lane19 : 001
Port 3/2:
PCS Lane BIP Error Counters :
*****
Lane00 : 000      Lane01 : 000
Lane02 : 000      Lane03 : 000
Lane04 : 000      Lane05 : 000
Lane06 : 000      Lane07 : 000
Lane08 : 000      Lane09 : 000
Lane10 : 000      Lane11 : 000
Lane12 : 000      Lane13 : 000
Lane14 : 000      Lane15 : 000
Lane16 : 000      Lane17 : 000
Lane18 : 000      Lane19 : 000
All show BIP done
```

History	Release	Command History
	05.8.00a	This command was modified

## show cam-detail-eth

Displays Content Addressable Memory (CAM) programming information for a specific Layer 2 CAM flow entry.

**Syntax** `show cam-detail-eth slot/port mac_address [ vlan vlan_id | vpls-vlan vlan_id ]`

**Parameters**

*slot/port* Specifies the LP module slot and port number.

*mac\_address* Specifies the MAC address of the Layer 2 PRAM entry.

**vlan***vlan\_id* Specifies the VLAN ID number.

**vpls-vlan***vlan\_id* Specifies the VPLS-VLAN ID number

**Modes** Privileged EXEC level.

**Usage Guidelines** Use this command to retrieve and display Layer 2 CAM or PRAM flow entry information without using a separate sequence of debugging commands. The command eliminates the need to remember indices information required to capture Layer 2 flow information by doing all the work in the back-end. The command only uses the MAC address or the VLAN ID or VPLS VLAN ID for Layer 2 to read and display information for a specific Layer 2 PRAM entry.

The command is supported only on the LP module.

---

### NOTE

The command is supported on Brocade NetIron XMR Series and Brocade MLX Series devices.

---

**Examples** The **show cam-detail-eth** command displays the following information on 2/8 with address fdab: 1234:4567 of VLAN 100:

```

device# show cam-detail-eth 2/8 fdab:1234:4567 vlan 100
***** (show cam ethernet <slot/port>)
output*****
LP Index MAC                Age Port  IFL/ Out IF PRAM Type
   (Hex)                VLAN                (Hex)
2  4ffff ffff.ffff.0000 Dis 2/8   100   CPU   3ff5b DA
***** (dm cam [<interface> <index>])
output*****
(CAM 0x0004ffff): ffff.ffff.0000/ffff.ffff.0000 VPN 0/0
***** (dm cam2pram <interface> <index>)
output*****
(CAM2PRAM entry 0x09ffffe): 0003ff5b cam_idx: 0x0004ffff
(CAM2PRAM entry 0x09ffff [MAC SA or Right IP]): 0003ff80
***** (dm pram <interface> <index> mac-da)
output*****
PRAM 0x3ff5b 255[00000000:00000000:00000000:00000000]128
127[00000000:00100000:8600800f:05f00000]0
*****PRAM MAC entry (DA)*****
ALT SRC PORT      1          Use alternate src port
MONITOR           0          Copy packet to MONITOR port
CPU               0          Packet must be copied to CPU
DISCARD INVLD    0          Discard if lookup invalid
DISCARD PACKET   0          Force packet to be discarded
USE FID           1          Use FID from this PRAM entry
USE QOS ID       1          Use QOS ID for rate limiting
INNER VLAN VALID 0000          Inner Vlan Valid
QOS ID            0x20          QOS rate limiting ID
VALID             0x000000f    Per-port entry valid
FID              0x05f0          Forwarding ID
TRUNK ADJUST     0          Adjust FID based on trunk index
DIS_QOS OVERRIDE 0          Disable QOS Override
PRIORITY_FORCE   0          Force pram priority to packet
PRIORITY         0          Packet priority
FASTPATH ENA     0          DA/SA is a known router
IGNORE BLOCK     0          Ignore port or RX block
DPA KNOWN        0          DPA associated with this DA is known
US               0          Set RX US bit
LOCAL ADDRESS    0          Address was learned locally
IGNORE US        0          Ignore router MAC
IGNORE ACLRES    0          Ignore ACL lookup
INNER VLAN       0000          Replacement Inner Vlan ID
PRAM TYPE        1          PRAM Entry Type
TRUNK ID         0          Trunk group ID
REPLACE VLAN     0          Use Outer Replacement VLAN ID
OUTER VLAN       0          Outer Replacement VLAN ID
MULTICAST VLAN   0          Set Multicast VLAN Flag
MATCH ALL DA     0          Match All DA Entry
LOCAL SWITCHING (MAC-DA only) 0    Perform L2 DA forwarding
DONT MODIFY PKT  0          Send Unmodified Copy
SOURCE PORT      0x00          Source Port of CAM entry
HPORT VALID      0x00          Host port per port entry valid
BOGUS LABEL BIT  0          Indicates if this label is used for single hop acct
TAG              0          VPLS Tag Mode support
NEXT HOP INDEX   0          next hop router index
PRAM MCAST SKIP MCAST 0          MCT/PBB mask indicating where to forward
PRAM EGRESS ID HI 0          higher 12-bits of PRAM_EGRESS_ID for HQOS support
PRAM EGRESS ID LO 0          Lower 4-bits of PRAM_EGRESS_ID for HQOS support
PUSH OUTER LABEL 0          Push the Outer Label
INNER LABEL 0    inner label
OUTER LABEL 0    outer label
REPLACE INNER VLAN 0          Use replacement inner VLAN
***** (dm fid-entry-table <fid>)
output*****
FID 25 (00000019): cpu = 0, mcpu = (0, 0), num_write_not_needed = 0
Slot0: 00000000 00000000
Slot1: 00000000 00000002
Slot2: 00000000 00000000
Slot3: 00000000 00000000
Slot4: 00000000 00000000
Slot5: 00000000 00000000
Slot6: 00000000 00000000
Slot7: 00000000 00000000
Slot8: 00000000 00000000
Slot9: 00000000 00000000
Slot10: 00000000 00000000

```

```

Slot11: 00000000 00000000
Slot12: 00000000 00000000
Slot13: 00000000 00000000
Slot14: 00000000 00000000
Slot15: 00000000 00000000
Slot16: 00000000 00000000
Slot17: 00000000 00000000
Slot18: 00000000 00000000
Slot19: 00000000 00000000
Slot20: 00000000 00000000
Slot21: 00000000 00000000
Slot22: 00000000 00000000
Slot23: 00000000 00000000
Slot24: 00000000 00000000
Slot25: 00000000 00000000
Slot26: 00000000 00000000
Slot27: 00000000 00000000
Slot28: 00000000 00000000
Slot29: 00000000 00000000
Slot30: 00000000 00000000
Slot31: 00000000 00000000
Slot32: 00000000 00000000
Slot33: 00000000 00000000
***** (dm statsram pram <slot/port> <index>)
output*****
(STATSRAM entry 0x03ff5b): pkt cnt: 217243, byte cnt: 32151964

```

**History**

Release version	Command history
5.9.00	This command was introduced.

## show cam-detail-ip

Displays Content Addressable Memory (CAM) programming information for a specific Layer 3 CAM flow entry.

**Syntax** `show cam-detail-ip slot/port ip_address/mask`

**Parameters** *slot/port*

Specifies the LP module slot and port number.

*ip\_address/mask*

Specifies IP address and mask of the Layer 3 PRAM entry.

**Modes** Privileged EXEC mode.

**Usage Guidelines** Use this command to retrieve and display Layer 3 CAM or Parameter Random Access Memory (PRAM) flow entry information without using a separate sequence of debugging commands. The command eliminates the need to remember indices information required to capture Layer 3 flow information by doing all the work in the back-end. The command only uses the network IP address and mask to read and display information for a specific PRAM entry.

The command is supported only on the Line Processor (LP) module. The command is supported only for IPv4 CAM or PRAM flow entry. IPv6 CAM or PRAM is not supported. The output from the command displays only default Virtual Routing and Forwarding (VRF) flow information.

---

**NOTE**

The command is supported on Brocade NetIron XMR Series and Brocade MLX Series devices.

---



**Examples** The **show cam-detail-ip** command displays the following information on 2/2 with address 1.1.1.1/24:

```

device# show cam-detail-ip 2/2 1.1.1.1/24
*****
output*****
LP Index      IP Address      MAC              Age IFL/ Out IF PRAM
   (Hex)                (Hex)
2  01a8da(R)  1.1.1.0/24      0024.3892.4c01  Dis 1    2/2    3ff62
*****
***** (dm cam [<interface> <index>])
output*****
(CAM 0x0001a8da left): 0.0.0.0/255.255.255.255
(CAM 0x0001a8da right): 1.1.1.0/255.255.255.0
*****
***** (dm cam2pram <interface> <index>)
output*****
(CAM2PRAM entry 0x0351b4): 0003ffbb cam idx: 0x0001a8da
(CAM2PRAM entry 0x0351b5 [MAC SA or Right IP]): 0003ff62
*****
***** (dm pram <interface> <index> ip)
output*****
PRAM 0x3ff62 255[01770000:00000002:00000024:38924c01]128
127[60008003:00000000:0400000d:00190200]0
*****PRAM IP entry *****
DA HIGH      0x0024      Replacement DA (high 2 bytes)
DA LOW       0x38924c01 Replacement DA (low 4 bytes)
VLAN ID      0001        Replacement VLAN ID
MULTICAST_VLAN 0          Set multicast flag in packet header
REPLACE_VLAN_ID 1        Use replacement VLAN ID
SPA_DISCARD_PKT 0        If 1, allow RPF to discard the packet
MTU_CHECK    1          If 1, enforce mtu check
REPLACE_DA   1          Use replacement DA
IGNORE_SPA_MASK 0        If 1, Ignore SPA mask
MONITOR      0          Copy packet to MONITOR port
CPU          0          Packet must be copied to CPU
DISCARD_INVLD 0        Discard if lookup invalid
DISCARD_PACKET 0        Force packet to be discarded
USE_FID      1          Use FID from this PRAM entry
USE_QOS_ID   0          Use QOS ID for rate limiting
INNER_VLAN_VALID 0        Inner Vlan Valid
QOS_ID       0x00        QOS rate limiting ID
VALID        0x0000000d Per-port entry valid
FID          0x0019      Forwarding ID
TRUNK_ADJUST 0          Adjust FID based on trunk index
PRIORITY_FORCE 0
PRIORITY     0
FWD_COMMAND  2          L3 hardware forwarding command
USE_TOS_ID   0          Use replacement TOS
TOS_ID       0x000      TOS replacement
IGNORE_ACLRES 0        Ignore ACL lookup
VLAN_ID      0000        Replacement Inner VLAN ID
PRAM_TYPE    0
TRUNK_ID     0
NEXTHOP_ROUTER_INDEX 0x00000000
TNNL_MTU_CHECK_LENGTH 1500
SRC_IPV4_ADDR_SPA_MASK 0x00000002
GRE_TNNL_INGRESS 0
GRE_TNNL_EGRESS 0
GRE_ENFORCE_SESSION_CHECK 0
6_TO_4_TNNL_INGRESS 0
6_TO_4_TNNL_EGRESS 0
6_TO_4_ENFORCE_SESSION_CHECK 0
TNNL_OUTER_TOS 0
REPLACE_INNER_VLAN 0
*****
***** (dm statsram pram <slot/port> <index>)
output*****
(STATSRAM entry 0x3ff62): pkt cnt: 118298, byte cnt: 1750810

```

**History**

Release version	Command history
5.9.00	This command was introduced.

# show cam ifl

Displays CAM interface entries..

- Syntax** `show cam ifl slot/port`
- Parameters** `slot port`  
 Displays CAM interface entries for the specified port.
- Modes** Privileged EXEC mode.
- Usage Guidelines** Use this command to display IPv4 interface CAM entries, including local (port+VLAN+IP) and remote (VC+IP) entries.
- Command Output** The `show cam ifl` command displays the following information:

**TABLE 5** show cam ifl output

Output field	Description
Slot	Slot-number
Index (Hex)	Shows the row number of this entry in the IP route table.
Port	Port-number
Outer VLAN	Shows path
Inner VLAN	Shows channel
PRAM (Hex)	Shows the ACL PRAM entries.
IFL ID	Same as VPN-ID in IPVPN CAM
IPv4/v6 Routing	Shows whether IPv4 or IPv6 is enabled or disabled on the interface

**Examples** The following examples displays CAM entries for interface 1/1.

```
device#show cam ifl 1/1
Slot Index  Port  Outer VLAN Inner VLAN PRAM  IFL ID IPV4/V6
      (Hex)                (Hex)                (Hex)                Routing
4      0061ffd 1/2   1          0          001ffd 4097  0/0
4      0061fff 1/1   1          0          001fff 4097  1/0
```

To add VRF to VE.

```
Brocade(config)# vlan 22
Brocade(config-vlan-22)# tagged ethernet 1/7
Brocade(config-vlan-22)# router-interface ve 22
Brocade(config-vlan-22)# exit
Brocade(config)# interface ve 22
Brocade(config-vrf-22)# vrf forwarding blue
Brocade(config-vrf-22)# ip address 10.0.0.22/24
Brocade(config-vrf-22)# exit

device# show cam ifl 1/7
Slot Index  Port  Outer  VLAN  Inner VLAN  PRAM  IFL ID  IPV4/V6
      (Hex)                (Hex)                (Hex)                Routing
1      0061fff 1/7   22     0          001fff 4097  1/0
```

## show cam ipvpn

Displays CAM VPN entries.

**Syntax** `show cam ipvpn slot/port`

**Parameters** `slot port`

Displays CAM VPN entries for the specified port.

**Modes** Privileged EXEC mode

**Usage Guidelines** Use this command to display IPv4 VPN CAM entries, including local (port+VLAN+IP) and remote (VC+IP) entries.

**Command Output** The `show cam ipvpn` command displays the following information:

**TABLE 6** show cam ipvpn output

Output field	Description
LP	Shows the number of the interface module.
Index (Hex)	Shows the row number of this entry in the IP route table.
IP Address	Shows the IP address of the interface.
In Port	Shows the port number.
In VLAN	Shows the VLAN number.
VPNID	Shows VPNID in the display.
In VC Lb	Shows VC label.
MAC	Shows the MAC address of the interface.
Age	Shows whether the age is enabled or disabled.
IFL VLAN	Shows the VLAN to which the port belongs.
IF	Shows the state of outgoing interface action.
PRAM (Hex)	Shows the ACL PRAM entries.

**Examples** The following example displays CAM entries for slot 1, port 7.

```
device# show cam ipvpn 1/7
```

LP	Index	IP Address	IFL/ IF	In	In	VPNID	In		
MAC	Age			Port	VLAN	PRAM	VC		(Hex)
Lb									
1	308fa	10.0.0.0/32		N/A	N/A	4097	N/A	N/A	
Dis		N/A	Drop						
								000a8	
1	308fb	10.0.0.255/32		N/A			N/A	4097	N/A
N/A		Dis		Mgmt				000a7	
1	308fc	10.0.0.22/32		N/A	N/A	4097	N/A		N/
A		Dis	N/A	Mgmt				000a6	
1	308fd	192.168.1.0/32		N/A			4097	N/A	N/A
Dis		N/A	Drop						
								000a5	
1	308fe	192.168.1.255/32	N/A	N/A	4097	N/A			Dis
Mgmt		000a4							N/A
1	308ff	192.168.1.1/32		N/A	N/A	4097	N/A		Dis
N/A		Mgmt						000a3	
1	3e566	10.0.0.0/24			N/A	N/A	4097	N/A	N/A
Dis		N/A	CPU						
								000a9	
1	3e567	192.168.1.0/24	N/A	N/A	4097	N/A			Dis
CPU		000a1							N/A

```
To add VRF to VE.
Brocade(config)# vlan 22
Brocade(config-vlan-22)# tagged ethe 1/7
Brocade(config-vlan-22)# router-interface ve 22
Brocade(config-vlan-22)# exit
Brocade(config)# interface ve 22
Brocade(config-vif-22)# vrf forwarding blue
Brocade(config-vif-22)# ip address 10.0.0.22/24
Brocade(config-vif-22)# exit
```

```
Brocade# show cam ipvpn slot/port
```

## show cam uda

Provides the details of the User Defined ACL (UDA) ACL CAM entry.

**Syntax** `show cam { uda } slot/port`

**Parameters** `slot/port`

Specifies the selected slot and port.

**Modes** EXEC mode

**Examples** The following example displays the output of the command.

```
device(config)# show cam uda 1/1
LP Index  VLAN UDA0      UDA1      UDA2      UDA3      Port  Action  PRAM
      (Hex)
1  057bfe 0    11223344  44556677  aabbccdd  0     1     Drop   7ff67
1  057c00 0    11223344  44556677  aabbccdd  0     0     Pass   7ff64
1  057c02 0    11223344  44556677  aabb      3333     0     Pass   7ff63
1  057c04 0    11223344  6677      aabb      aabb     0     Pass   7ff62
```

### History

---

#### Release version

#### Command history

5.9.00

This command was introduced.

---

## show configuration

Displays the router, switch, or firewall's current configuration.

- Syntax** `show configuration`
- Modes** EXEC mode.
- Usage Guidelines** The outbound-fec filter configuration parameter now records in the startup or running configuration. It also now displays the name of the prefix-list configured in the LDP for outbound FEC filtering.
- The outbound-fec filter configuration parameter is recorded in the startup or running configuration.
- This command operates in all modes.

**Examples** The following example displays output containing additional information indicating configured link protection:

```
device> show mpls conf
router mpls
.....
lsp 1
  to 44.44.44.44
  adaptive
  frr
    link-protection
  enable
```

The following example displays output when there is no request for link protection:

```
device> show mpls conf
router mpls
.....
lsp 1
  to 44.44.44.44
  adaptive
  frr
  enable
```

### History

---

#### Release Command history

---

- |        |  |
|--------|--|
| 5.6.00 | The outbound-fec filter configuration parameter is recorded in the startup or running configuration.<br>The output of this command now contains additional information indication link protection is configured. |
|--------|--|
-

## show cpu histogram

Displays task CPU usage information, including the percentage, and total percentage of the CPU utilization of a task histogram at 1, 5, and 10 second average duration.

**Syntax** `show cpu histogram { hold | wait | interrupt | timer } [ above threshold-value | noclear | taskname name ]`

`show cpu histogram { util-10s | util-1s | util-5s } [ above threshold-value | noclear | taskname name ]`

`show cpu histogram { util-all-10s | util-all-1s | util-all-5s } [ above threshold-value | noclear ]`

<b>Parameters</b>	<b>hold</b>	Specifies the display of task hold time information.
	<b>wait</b>	Specifies the display of task wait time information.
	<b>interrupt</b>	Specifies the display of task user-interrupt usage information.
	<b>timer</b>	Specifies the display of task sys-timer time usage information.
	<b>util-10s</b>	Specifies the CPU utilization per task histogram at a 10 second average duration.
	<b>util-1s</b>	Specifies the CPU utilization per task histogram at a 1 second average duration.
	<b>util-5s</b>	Specifies the CPU utilization per task histogram at a 5 second average duration.
	<b>util-all-10s</b>	Specifies the total CPU utilization of a task histogram at a 10 second average duration.
	<b>util-all-1s</b>	Specifies the total CPU utilization of a task histogram at a 1 second average duration.
	<b>util-all-5s</b>	Specifies the total CPU utilization of a task histogram at a 5 second average duration.
	<b>above <i>threshold-value</i></b>	Specifies the display of histogram information for tasks whose maximum hold time is above the specified value.
	<b>noclear</b>	Specifies that histogram data should not be cleared after display. By default, information is cleared on read.
	<b>taskname <i>name</i></b>	Specifies the display of histogram information for a specific task.

**Modes** User EXEC mode

**Usage Guidelines** Use the command to display the task CPU usage information.

Use the **show cpu histogram**{ **util-10s** | **util-1s** | **util-5s** } command to display the CPU percentage of a task histogram utilizing high CPU conditions at 1, 5, and 10 second durations.

To display the total CPU unitization of a task histogram at 1, 5, and 10 second average duration, use the **show cpu histogram** { **util-all-10s** | **util-all-1s** | **util-all-5s** } command. This command is supported on the management module and the interface module. The CPU percent utilization and time stamps are displayed for the durations.

Tasks that may use high CPU utilization include packet burst in the interface module, multiple protocols flapping at the same time, a protocol task in a wrong state that keeps the CPU busy, and high route processing that causes high CPU conditions in the management module and interface module CPUs.

**Command Output** The **show cpu histogram** command displays the following information:

Output field	Description
No of bucket	The task run time that is divided into interval buckets. For example, bucket 1(0-50ms), bucket2 (50-100ms), and bucket3(100-150ms).
Bucket Granularity	The bucket granularity is 5%. Each bucket contains values within 5% of range. For example, bucket 1 contains values 0-4, bucket 2 contains values 5-9, and so on.
Last Cleared at	The time at which the values are cleared last.
No of Task	The total number of tasks running in the system at a time.
Task Name	The name of the task displayed.
BktNum	The bucket number -1,2, or 3 that corresponds with the value it belongs to.
Bkt Value (%)	The time range of the bucket.
No of Time	The number of times the value in the bucket range is utilizing CPU. For example, task, sfm_mgr, was using the CPU in the range of 10-15, at 83 times.
CPU Util Total (%)	The total CPU utilization of a task.
Util Time Max	The maximum CPU utilization value of a bucket.
Time	The time stamp of the most recent CPU utilization for a particular task.



**Examples** The following example displays task hold time information:

```
device# show cpu histogram hold
HISTOGRAM CPU HISTOGRAM INFO
-----
No of Bucket      : 51
Bucket Granularity : 10 ms
Last cleared at   : 2012.07.10-07:29:20.704
No of Task        : 67
Task Name  Bkt    Bkt      No of Time  HoldTime  HoldTime      Time
           Num    Time (ms)          Total (s)  Max (ms)
-----
ip_rx      1      000-010      4      .000463     .201  2012.07.10-07:29:20.701
vlan       1      000-010      1      .000025     .025  2012.07.10-07:29:20.700
mac_mgr    1      000-010      1      .000010     .010  2012.07.10-07:29:20.701
mrp        1      000-010      1      .000025     .025  2012.07.10-07:29:20.700
erp        1      000-010      1      .000025     .025  2012.07.10-07:29:20.700
mxrp       1      000-010      1      .000009     .009  2012.07.10-07:29:20.700
rtm        1      000-010      1      .000062     .062  2012.07.10-07:29:20.700
rtm6       1      000-010      1      .000091     .091  2012.07.10-07:29:20.700
ip_tx      1      000-010      1      .000207     .207  2012.07.10-07:29:20.700
l2vpn      1      000-010      1      .000018     .018  2012.07.10-07:29:20.701
ospf       1      000-010      1      .000046     .046  2012.07.10-07:29:20.700
isis       1      000-010      1      .000009     .009  2012.07.10-07:29:20.700
mcast      1      000-010      1      .000017     .017  2012.07.10-07:29:20.700
ospf6      1      000-010      1      .000012     .012  2012.07.10-07:29:20.700
mcast6     1      000-010      1      .000012     .012  2012.07.10-07:29:20.700
web        1      000-010      1      .000029     .029  2012.07.10-07:29:20.700
lacp       1      000-010      1      .000013     .013  2012.07.10-07:29:20.700
loop_detect 1      000-010      1      .000009     .009  2012.07.10-07:29:20.701
cluster_mgr 1      000-010      1      .000011     .011  2012.07.10-07:29:20.701
telnet_0   1      000-010      4      .003        3     2012.07.10-07:29:20.672
-----
```

The following example displays the CPU utilization of a task histogram at a 5 second average duration.

```
device# show cpu histogram util-5s
HISTOGRAM CPU UTIL PER TASK INFO (5sec average)
-----
No of Bucket      : 21
Bucket Granularity : 5%
Last cleared at   : 2014.09.04-18:18:39.607
No of Task        : 72
Task Name  Bkt    Bkt      No of Time  CPU
Util       Num    Time          Value (%)  Total (%)  Max (%)
-----
$flash     1      000-005      4           4           4
2014.09.10-01:08:29.500
$flash     2      005-010     17           7           7
2014.09.14-05:28:22.450
main       1      000-005      1          17           1
2014.09.04-18:18:44.350
ip_rx      1      000-005     18           1           1
2014.09.14-21:03:19.850
ip_rx      2      005-010      1          37           7
2014.09.05-02:00:13.050
console    1      000-005      2           7           1
2014.09.15-11:32:08.400
console    2      005-010      1          17           8
2014.09.04-18:18:44.350
```

**History**

---

**Release**                      **Command History**

---

05.5.00                      This command was introduced.

---

## show cpu histogram sequence

Displays sequential execution of CPU task information.

**Syntax** `show cpu histogram sequence [ taskname name | above threshold-value | trace ]`

**Parameters** **sequence**

Specifies the display of sequential execution of CPU task information.

**taskname name**

Specifies the display of histogram information for a specific CPU task.

**above threshold-value**

Specifies the display of histogram information for CPU tasks whose maximum hold time is above the specified value.

**trace**

Specifies the display of high CPU condition task trace information.

**Modes** User EXEC mode

**Examples** The follow example displays sequential execution of CPU task information:

```
device# show cpu histogram sequence
HISTOGRAM TASK SEQUENCE INFO
-----
THRESHOLD   : 10 ms
DURATION    : 30 s
-----
Seq No Task Name      Context  HoldTime  Start Time  End Time  Date
      Max (ms)
-----
   1 snms             TASK      16 07:33:08.790 07:33:08.806 2012.07.10
   2 snms             TASK      16 07:33:08.772 07:33:08.789 2012.07.10
   3 snms             TASK      17 07:33:08.755 07:33:08.772 2012.07.10
   4 snms             TASK      16 07:23:08.790 07:23:08.806 2012.07.10
   5 snms             TASK      16 07:23:08.772 07:23:08.789 2012.07.10
   6 snms             TASK      17 07:23:08.755 07:23:08.772 2012.07.10
   7 snms             TASK      16 07:13:08.790 07:13:08.806 2012.07.10
   8 snms             TASK      16 07:13:08.772 07:13:08.789 2012.07.10
   9 snms             TASK      17 07:13:08.755 07:13:08.772 2012.07.10
  10 snms             TASK      16 07:03:08.790 07:03:08.806 2012.07.10
  11 snms             TASK      16 07:03:08.772 07:03:08.789 2012.07.10
  12 snms             TASK      17 07:03:08.755 07:03:08.772 2012.07.10
  13 snms             TASK      16 06:53:08.790 06:53:08.806 2012.07.10
  14 telnet_0         TASK      50 09:51:50.091 09:51:50.142 2012.07.05
  15 telnet_0         TASK      50 09:51:35.184 09:51:35.234 2012.07.05
  16 console          TASK      50 09:51:11.451 09:51:11.501 2012.07.05
  17 telnet_0         TASK      50 09:47:01.459 09:47:01.509 2012.07.05
  18 console          TASK      52 09:46:32.443 09:46:32.496 2012.07.05
  19 mpl              TIMER     12 09:46:32.428 09:46:32.441 2012.07.05
  20 telnet_0         TASK      54 09:46:03.018 09:46:03.072 2012.07.05
  21 telnet_0         TASK      52 09:44:31.749 09:44:31.802 2012.07.05
  22 telnet_0         TASK      50 09:44:17.984 09:44:18.034 2012.07.05
  23 telnet_0         TASK      50 09:43:43.638 09:43:43.689 2012.07.05
  34 telnet_0         TASK      12 09:43:43.623 09:43:43.636 2012.07.05
  35 telnet_0         TASK      54 09:43:20.669 09:43:20.724 2012.07.05
  36 snms             TASK      16 09:43:08.740 09:43:08.756 2012.07.05
  37 snms             TASK      16 09:43:08.723 09:43:08.740 2012.07.05
-----
```

**History**

Release	Command History
R05.5.00	This command was introduced

## show dot1x-mka group

Shows details for the specified MACsec Key Agreement (MKA) groups configured on this device, or for a designated MKA group.

**Syntax** `show dot1x-mka group group-name`

**Parameters** `group-name`

Limits the group configuration displayed to the named MKA group.

**Modes** EXEC or Privileged EXEC mode

**Command Output** The `show dot1x-mka group` command displays the following information:

Output field	Description
dot1x-mka group	The configuration details that follow are for the specified MACsec MKA group.
key-server-priority	The key server priority value used by MKA protocol for electing the key server.
macsec cipher-suite gcm-aes-128	MACsec transmissions are encrypted.
or	or
macsec cipher-suite gcm-aes-128 integrity-only	ICV checking only is performed.
macsec confidentiality-offset	The byte offset used for encrypted data is set to the value shown. Allowable values are 0, 30 (the first 30 bytes of data are not encrypted), and 50 (the first 50 bytes of data are not encrypted).
macsec frame-validation {check   discard}	Indicates whether the MACsec frame header is checked and what action is taken for invalid frames (counted or discarded).
macsec replay-protection {strict   out-of-order window-size size}	Replay protection is enabled. The type of protection is shown as strict (discard any frame received out of sequence) or as allowing receipt of out-of-sequence frames within the specified window.
Capability	

**Examples** The following example lists the configuration details for MKA group test1.

```
Brocade(config-dot1x-mka)#show dot1x-mka group group1
Brocade Group name group1
  Key Server Priority      : 16
  Cipher Suite            : gcm-aes-128
  Capability               : Integrity, Confidentiality with offset
  Confidentiality Offset  : 0
  Frame Validation        : strict
  Replay Protection       : strict
```

## Show Commands

History	Release version	Command history
	5.8.00	This command was introduced.

## show dot1x-mka config

Shows the MACsec Key Agreement (MKA) configuration for the device.

**Syntax** `show dot1x-mka config`

**Modes** User EXEC mode

**Usage Guidelines** Default configuration is not displayed when this command is executed.

**Command Output** The `show dot1x-mka config` command displays the following information:

Output field	Description
dot1x-mka-enable	MACsec is enabled on the device.
enable-mka ethernet <i>slot/port</i>	The ethernet interfaces specified are enabled for MACsec.
mka-cfg-group <i>group-name</i>	The configuration details that follow are for the named MACsec MKA group.
key-server-priority <i>value</i>	The key server priority value used by MKA protocol for electing the key server.
macsec confidentiality-offset <i>value</i>	The byte offset used for encrypted data is set to the value shown. Allowable values are 30 (the first 30 bytes of data are not encrypted), and 50 (the first 50 bytes of data are not encrypted).
macsec frame-validation { check   discard }	For transmissions between MKA group members, indicates whether the MACsec frame header is checked and what action is taken for invalid frames (counted or discarded).
macsec-replay protection { strict   out-of-order window-size <i>value</i> }	Replay protection is enabled. The type of protection is shown as strict (discard any frame received out of sequence) or as allowing receipt of out-of-sequence frames within the specified window.
pre-shared-key <i>value</i> key-name <i>value</i>	The pre-shared key is set to this value and name for the MKA configuration group. Both key and name are hexadecimal strings.

**Examples** The following example displays MACsec configuration information on Brocade device with MACsec enabled.

```

Brocade(config-dot1x-mka)#show dot1x-mka config
dot1x-mka-enable
  mka-cfg-group group1
    key-server-priority 20
    macsec frame-validation check
    macsec confidentiality-offset 30
    macsec replay-protection out-of-order window-size 100
  mka-cfg-group group2

enable-mka ethernet 1/1 to ethernet 1/9
  mka-cfg-group group1
  pre-shared-key 0102030405060708090A0B0C0D0E0F10 key-name 11223344
enable-mka ethernet 1/10
  mka-cfg-group group1
  pre-shared-key 0505030405060708090A0B0C0D0E0F10 key-name 55667788
    
```

**History**

Release version	Command history
5.8.00	This command was introduced.

## show dot1x-mka sessions brief

Displays a brief summary of all MACsec Key Agreement (MKA) sessions on the device.

**Syntax** `show dot1x-mka sessions brief`

**Modes** User EXEC mode

**Command Output** The `show dot1x-mka sessions` command with the `brief` option displays the following information:

Output field	Description
Port	Designates the interface for which MACsec information is listed (by device, slot, and port).
Link-Status	Indicates whether the link is up or down.
MKA-Status	Indicates whether a secure channel has been established.
Key-Server	Indicates whether the interface is operating as a key-server.
Negotiated Capability	Indicates MACsec parameters negotiated on the designated interface.

**Examples** In the following example, all enabled MKA interfaces on the device are listed, along with configured parameters and current status.

```
device(config-dot1x-mka)# show dot1x-mka sessions brief
Port      Link-Status  Secured  Key-Server  Negotiated
Capability
-----
4/2       Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/3       Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/4       Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/7       Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/11      Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/12      Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/17      Up           Yes      Yes         Integrity, Confidentiality with offset
0
4/18      Up           Yes      Yes         Integrity, Confidentiality with offset 0
```

### History

Release version	Command history
5.8.00	This command was introduced.

## show dot1x-mka sessions ethernet

Displays a summary of all MACsec Key Agreement (MKA) sessions on the device.

**Syntax** `show dot1x-mka sessions [ ethernet slot / port ]`

**Parameters** `ethernet slot / port`

Displays MKA sessions that are active on a specified Ethernet interface. The Ethernet interface is specified by slot on the device, and interface on the slot.

**Modes** User EXEC mode

**Command Output** The `show dot1x-mka sessions` command with the `ethernet` interface options displays the following information:

Output field	Description
Interface	The information that follows applies to the designated interface.
DOT1X-MKA Enabled (Yes, No)	Indicates whether MKA is enabled for the designated interface.
DOT1X-MKA Active (Yes, No)	Indicates whether MKA is active on the interface.
Key Server (Yes, No)	Indicates whether the MKA key-server is active over the interface.
<b>Configuration Status:</b>	<b>The following fields describe the MKA configuration applied to the interface.</b>
Enabled (Yes, No)	Indicates whether MACsec is currently enabled.
Group name	MKA configuration group that has been associated with the interface.
Capability (Integrity and or confidentiality)	Indicates whether ICV checks are being performed on MACsec frames and whether encryption is being applied.
Confidentiality offset	Specifies the offset value set.
Desired (Yes, No)	Indicates whether port is interested in securing the communication using MACsec.
Protection (Yes, No)	Indicates whether replay protection is applied to the interface.
Validation	Indicates whether frames received are being checked for valid MACsec headers.
Replay Protection (Strict, Out of Order)	Indicates that replay protection is configured and whether frames must be received in exact order or within an allowable window.
Replay Protection Size	Indicates the allowable window size within which frames may be received.
Cipher Suite (GCM-AES-128)	Specifies the cipher suite used for ICV checking, encryption, and decryption.
Authenticator	
Key Server Priority	Specifies the key-server priority configured on the interface.
Algorithm Agility	
CAK NAME	



Output field	Description
<b>Secure Channel Information(SCI)</b>	<b>The following fields describe a secure channel established on this interface.</b>
Actor SCI	Provides the hexadecimal value of the Secure Channel Identifier for this channel.
Actor Priority	
Key Server SCI	
Key Server Priority	
<b>Logon Status:</b>	
Enabled	
Authenticated	
Secured	
Failed	
<b>Latest KI, KN and AN Information:</b>	
Latest KI	
Tx Key Number	
Rx Key Number	
Tx Association Number	
Rx Association Number	
<b>Participant Information:</b>	
SCI	
Key Identifier	
Member Identifier	Provides the MACsec number assigned to the MKA peer.
Message Number	Provides the Message Number contained in Hello packets from this MKA peer. Hello packets are exchanged to determine peer status, MACsec capabilities, and SAK Key Identifier.
CKN	
Key Length(in bytes)	
<b>Secure Channel Information:</b>	
No. of Peers (Live and Potential)	
Latest SAK Status	Indicates the Secure Association Key (SAK) state.
Negotiated Capability (Integrity and or Confidentiality with offset)	Indicates whether ICV checking, encryption, and a confidentiality offset have been applied on the secure channel. (The negotiated capability may differ from parameters configured on the interface when it does not have key-server status.)

The output fields that follow provide information on actual and potential MACsec peer interfaces

<b>Output field</b>	<b>Description</b>
State (Live or Potential)	Indicates whether the peer is considered a live peer or a potential peer for MKA protocol.
Member Identifier	Designates the peer by its Member Identifier, a hexadecimal value.
Message Number	Provides the Message Number that appears in Hello packets from the designated peer interface as a hexadecimal value.
SCI	Provides the peer's Secure Channel Identifier.
Priority	Provides the key-server priority configured on the peer interface.

**Examples** The following example lists MKA sessions that are active on Ethernet interface 4/1, with configuration details for each active interface.

```

Brocade(config)#show dot1x-mka sessions ethernet 4/1

Interface                : 4/1
  DOT1X-MKA Enabled      : Yes
  DOT1X-MKA Active       : Yes

Configuration Status:
  Group Name             : 1
  Capability              : Integrity, Confidentiality with offset
  Confidentiality offset : 0

  Desired                : Yes
  Protection             : Yes
  Validation             : Strict
  Replay Protection      : None
  Replay Protection Size : 0
  Cipher Suite          : GCM-AES-128

  Authenticator          : No
  Key Server Priority    : 16
  Algorithm Agility      : 80C201

  CAK NAME               : 11223344

SCI Information:
  Actor SCI              : 0024388f6b900001
  Actor Priority         : 16
  Key Server SCI        : 0024388f6b900001
  Key Server Priority    : 16

MKA Status:
  Enabled               : Yes
  Authenticated         : No
  Secured               : Yes
  Failed               : No

Latest KI, KN and AN Information:
  Latest KI             : 42b4d71d520263cad8727d9100000001
  Tx Key Number         : 1
  Rx Key Number         : 0
  Tx Association Number : 0
  Rx Association Number : 0

Participant Information:
  SCI                   : 0024388f6b900001
  Key Identifier        : 1
  Member Identifier     : 42b4d71d520263cad8727d91
  Message Number        : 3491
  CKN Name              : 11223344
  Key Length(in bytes) : 16

Secure Channel Information:
  No. of Peers (Live and Potential) : 1
  Latest SAK Status                  : Rx & TX
  Negotiated Capability              : Integrity, Confidentiality with offset 0

Peer Information(Live and Potential):
State Member Identifier      Message Number  SCI                Priority  Capability
-----
Live 66dfa9b5037a9c7aa8b5c71e 3490          0024389e2d300001 16       2

```

---

**History**

Release version	Command history
5.8.00	This command was introduced.

---

## show dot1x-mka statistics

Displays current MACsec Key Agreement (MKA) statistics on the interface.

**Syntax** `show dot1x-mka statistics ethernet slot/port`

**Parameters** `ethernet slot/port`

Ethernet interface for which MKA statistics are to be displayed. The interface is designated by a slot on the device and interface on the slot.

**Modes** EXEC or Privileged EXEC mode

**Usage Guidelines** It is recommended that you use the **clear dot1x-mka statistics** command to clear results of the previous **show dot1x-mka statistics** command before re-executing it.

**Command Output** The **show dot1x-mka statistics** command displays the following information:

Output field	Description
Interface (slot/port)	The output fields describe MACsec activity for the designated interface.
MKA in Pkts	MKA protocol packets received
MKA in SAK Pkts	MKA protocol packets received containing a SAK
MKA in Bad Pkts	MKA protocol packets received that are bad
MKA in Bad ICV Pkts	MKA protocol packets received with a bad ICV
MKA in Mismatch Pkts	MKA protocol packets received with mismatched CAK
MKA out Pkts	MKA protocol packets transmitted
MKA out SAK Pkts	MKA protocol packets transmitted containing a SAK

**Examples** The following example shows MKA statistics for Ethernet interface 3/2, which is transmitting and receiving MACsec frames.

```
Brocade(config)# show dot1x-mka statistics ethernet 3/2
Interface                : 3/2
MKA in Pkts              : 89858
MKA in SAK Pkts          : 0
MKA in Bad Pkts          : 0
MKA in Bad ICV Pkts     : 0
MKA in Mismatch Pkts    : 0
MKA out Pkts             : 90225
MKA out SAK Pkts        : 192
```

**History**

Release version	Command history
5.8.00	This command was introduced.

# show egress-truncate

Displays the configuration details for the egress-truncate command.

**Syntax** **show egress-truncate**

**show egress-truncate interface** *slot/port*

**Parameters** **interface**

Displays the configuration of the ports in a slot determined by the *slot/port* variable.

**Modes** This command operates under all modes.

**Command Output** The **show egress-truncate interface** command displays the following information:

Output field	Description
SlotNo	The slot number where egress-truncate has been applied.
Device-id	The device ID of where egress-truncate has been applied.
Size	The configured size of the egress truncated packet.
Status	The status (enabled or disabled) for the specified interface.

**Examples** The following example displays the **show egress-truncate** command:

```
device#show egress-truncate
SlotNo Device-id  Size      Status
1       1             100      Enabled
2       2             90       Enabled
3       1             64       Enabled
Enabled Ports:  e 10/1
device#
```

The following example displays the **show egress-truncate interface** command

```
device#show egress-truncate interface 10/1
Device status : Enabled
Egress Truncate Packet Size:200
Port Status: Enabled
device#
```

**History**

Release version	Command history
05.9.00	This command was introduced.

## show ikev2 policy

Displays information about the configured IKEv2 policy.

**Syntax** `show ikev2 policy policy-name`

**Parameters** *policy-name*  
Specifies the policy name for the IKEv2 profile.

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ikev2 policy** command output.

```
device# show ikev2 policy

Name           : ike_policy_red
vrf            : Default
Local address/Mask : 0.0.0.0/0.0.0.0
Proposal       : ike_proposal_red

Name           : ikev2-default-policy
vrf            : Default
Proposal       : ikev2-default-proposal
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show ikev2 profile

Displays information about the configured IKEv2 profile.

**Syntax** `show ikev2 profile profile-name`

**Parameters** `profile-name`  
Specifies the IKEv2 profile name.

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ikev2 profile** command output.

```
device# show ikev2 profile

IKEv2 profile      : ike_profile_blue
Auth Profile      : auth_blue
Match criteria    :
  IKE session vrf : default-vrf
Local:
  address 1.2.10.1
Remote:
  address 1.2.10.2
Local identifier   : address 1.2.10.1
Remote identifier  : address 1.2.10.2
Local auth method: pki
Remote auth method(s): pki
Lifetime          : 86400 sec
keepalive check   : disabled

IKEv2 profile     : ike_profile_green
Auth Profile: auth_green
Match criteria:
  IKE session vrf : default-vrf
Local:
  address 1.2.10.1
Remote:
  address 1.2.10.2   fdqn RTB green
Local identifier   : address 1.2.10.1
Remote identifier  : address 1.2.10.2
Local auth method: pki
Remote auth method(s): pki
Lifetime          : 1440 minutes
keepalive check   : disabled
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show ikev2 proposal

Displays information about the configured IKEv2 proposals.

**Syntax** `show ikev2 proposal name`

**Parameters** *name*  
Specifies the proposal name for IKEv2 profile.

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ikev2 proposal** command output.

```
device# show ikev2 proposal
      Name       : ikev2-default-proposal
      Encryption : AES-CBC-256
      Integrity  : sha384
      PRF        : sha384
      DH Group   : 384_ECP/Group 20
```

### History

Release version	Command history
05.8.00	This command was introduced.



## show ikev2 sa

Displays information about the current IKEv2 Security Associations (SA) that exist between the specified local and remote interfaces. This command supports IPsec IPv4 and IPv6.

**Syntax** `show ikev2 sa [spi-index | fvrf vrf-name | local [ address | ipv6-address ] | remote address ] [ detail ]`

<b>Parameters</b>	<b>spi-index</b>	(Optional) Specifies the IKEv2 Security Parameter Index (SPI) value.
	<b>fvrf vrf-name</b>	(Optional) Specifies the front VRF name.
	<b>local address</b>	(Optional) Specifies the IPv4 address of the local interface.
	<b>local ipv6-address</b>	(Optional) Specifies the IPv6 address of the local interface.
	<b>remote address</b>	(Optional) Specifies the IP address of the remote interface.
	<b>detail</b>	(Optional) Specifies to include details of the IKEv2 SA in the output.

**Modes** Privileged EXEC mode

**Usage Guidelines** If you do not include the optional **detail** parameter, only the basic information about the SA is included in the output. If you want to view information about the interface role (initiator or responder), SPI indexes, or the selected IKEv2 policy or profile, make sure you include the **detail** parameter.

**Examples** These examples are for IPsec IPv4.

The following example shows output for command **show ikev2 sa** for the SA between local interface 1.2.10.1 and remote interface 1.2.10.2. The **detail** keyword was not included.

```
device# show ikev2 sa

tnl-id      local                remote                Status      vrf(i) vrf(f)
-----
tnl 2       1.2.10.1/500         1.2.10.2/500         rdy Blue   Default
```

The following example shows output for command **show ikev2 sa detail** for the SA between local interface 1.2.10.1 and remote interface 1.2.10.2. The **detail** keyword was included.

```
device# show ikev2 sa detail

tnl-id      local                remote                status      vrf(i) vrf(f)
-----
2           1.2.10.1/500         1.2.10.2/500         rdy Blue   Default
  Role      : Initiator
  Local SPI : 0xf327d32cd0df9106   Remote SPI: 0x34bec986ed6c232e
  Ike Profile : mlx2_1
  Ike Policy : mlx2_1
  Auth Proposal : def-Ike-auth-prop
```

### History

Release version	Command history
05.8.00	This command was introduced.
05.9.00	This command was modified to add support for IPsec IPv6.

# show ikev2 session

Displays information about the configured IKEv2 profile.

- Syntax** `show ikev2 session local-spi-id [detail]`
- Parameters**
  - local-spi-id* Specifies the local SPI ID value.
  - detail** Specifies the detailed description of the IKEv2 profile.
- Modes** Privileged EXEC mode
- Examples** The following example displays **show ikev2 session** command output.

```
device# show ikev2 session
IKE count:1, CHILD count:1
Tunnel-id Local Remote Status vrf(i) vrf(f)
-----
Tnl 2 1.2.10.1/500 1.2.10.2/500 rdy|in-use Blue Default
child sa:
id 1
local selector 0.0.0.0/0 - 255.255.255.255/65535
remote selector 0.0.0.0/0 - 255.255.255.255/65535
ESP spi in/out: 0x0000004b/0x0000005e
Encryption: aes-gcm-256, ICV Size: 16 octects, Esp_hmac: null
Authetication: null DH Group:none , Mode: tunnel
```

The following example displays **show ikev2 session detailed** command output.

```
device# show ikev2 session detailed
IKE count:1, CHILD count:1
Tunnel-id Local Remote Status vrf(p) vrf(f)
-----
2 1.2.10.1/500 1.2.10.2/500 rdy|in-use Blue Default
Encr: aes-cbc-256, Hash: sha384, DH Grp:384_ECP/Group 20, Auth: not supported
Life/Active Time: 86400/361 sec
Status Description: Negotiation done
Local spi: f7c029048eb25082 Remote spi: 56b8735e2f6afbde
Local id : address 1.2.45.2 Remote id : address 1.2.45.1
No Exchange in Progress
Next Request Message id=29
Total Keepalive sent: 0 Total Keepalive Received: 0
Time Past Since Last Msg: 60
child sa:
id 1
local selector 0.0.0.0/0 - 255.255.255.255/65535
remote selector 0.0.0.0/0 - 255.255.255.255/65535
ESP spi in/out: 0x0000004b/0x0000005e
Encryption: aes-gcm-256, ICV Size: 16 octects, Esp_hmac: null
Authetication: null DH Group:none , Mode: tunnel
```

History	Release version	Command history
	05.8.00	This command was introduced.

## show ikev2 statistics

Displays information about IKEv2 counters.

**Syntax** `show ikev2 statistics`

**Modes** Privileged EXEC mode

**Examples** The following example displays `show ikev2 statistics` command output.

```
device#show ikev2 statistics
Total IKEv2 SA Count    : 1 active: 1 negotiating: 0
Incoming IKEv2 Requests: 0 accepted: 0 rejected: 0
Outgoing IKEv2 Requests: 1 accepted: 1 rejected: 0
Rejected IKEv2 Requests: 0
Incoming IKEv2 Cookie Challenged Requests: 0
accepted: 0 rejected: 0 rejected no cookie: 0
IKEv2 Packet Statistics:
  Total Packets Received      : 57
  Total Packets Transmitted   : 57
  Total Packets Retransmitted: 0
  Total Keepalive Received    : 10
  Total Keepalive Transmitted: 10
IKEv2 Error Statistics:
  Unsupported Payload : 0      Invalid IKE SPI : 0
  Invalid Version     : 0      Invalid Syntax  : 0
  Proposal Mismatch   : 0      Invalid Selectors: 0
  Authentication Failed : 0      Others           : 0
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show interface ethernet

Displays the interfaces associated with the specified port.

<b>Syntax</b>	<b>show interface ethernet</b> <slot/port>
<b>Parameters</b>	<b>slot/port</b> Indicate the slot and port for the port of which the interface information is required.
<b>Modes</b>	This command operates under all modes.
<b>Command Output</b>	The <b>show interface ethernet</b> command displays the following information in list form.

### Examples

```
Brocade(config)#show interface ethernet 1/1
10GigabitEthernet5/1 is disabled, line protocol is down
  STP Root Guard is disabled, STP BPDU Guard is disabled
  Hardware is 10GigabitEthernet, address is 001b.edae.6e00 (bia 001b.edae.6ec0)
  Configured speed 10Gbit, actual unknown, configured duplex fdx, actual unknown
  Member of Control VLAN 4095, VLAN 1 (untagged), 1 L2 VLANS (tagged),
  port is in dual mode (default vlan), port state is Disabled
  STP configured to ON, Priority is level0, flow control enabled
  Egress truncate is ON, egress truncate size is 64 bytes
  Priority force disabled, Drop precedence level 0, Drop precedence force disabled
  dhcp-snooping-trust configured to OFF
  mirror disabled, monitor disabled
  LACP BPDU Forwarding:Disabled
  LLDP BPDU Forwarding:Disabled
  Not member of any active trunks
  Not member of any configured trunks
  No port name
  Port is not enabled to receive all vlan packets for pbr
  MTU 1548 bytes, encapsulation ethernet
  Openflow: Disabled, Openflow Index 193
  Cluster L2 protocol forwarding enabled
  300 second input rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  300 second output rate: 0 bits/sec, 0 packets/sec, 0.00% utilization
  0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 multicasts, 0 unicasts
  0 input errors, 0 CRC, 0 frame, 0 ignored
  0 runts, 0 giants
  NP received 0 packets, Sent to TM 0 packets
  NP Ingress dropped 0 packets
  0 packets output, 0 bytes, 0 underruns
  Transmitted 0 broadcasts, 0 multicasts, 0 unicasts
  0 output errors, 0 collisions
  NP transmitted 0 packets, Received from TM 0 packets
```

The following example shows an output with the port-state-change time highlighted for port 3 on slot 1.

```
Brocade(config)#show interface ethernet 1/3
10GigabitEthernet1/3 is up, line protocol is down (LACP-BLOCKED)
  Port state change time: Jan 21 02:40:21, (0 days, 00:07:16 ago)
  Loopback: None
  STP Root Guard is disabled, STP BPDU Guard is disabled
  Hardware is 10GigabitEthernet, address is 0024.38a4.3802 (bia 0024.38a4.3802)
  ...
  NP transmitted 11115 packets, Received from TM 11115 packets
```

History	Release version	Command history
	5.6.00	This command was introduced.
	5.9.00	This command was modified to display Egress truncate status and configured size and port state change time.

# show interfaces tunnel

Displays the IP addresses and unicast and multicast traffic counters for the specified IPv4 IPsec tunnel. This command cannot be used on IPv6 IPsec tunnels.

**Syntax** `show interfaces tunnel num`

**Parameters** `num`  
Specifies the tunnel number.

**Modes** User EXEC mode

**Command Output** The `show interfaces tunnel` command displays the following information:

Output field	Description
Tunnel number	The number of the tunnel.
Tunnel source	The IP address of the interface that is configured as the source of the tunnel. IP packets are forwarded from this interface across the tunnel.
Tunnel destination	The IP address of the interface that is configured as the destination of the tunnel. IP packets forwarded from the tunnel source interface are received by this interface.
Tunnel mode	The specified tunnel mode for the tunnel. This indicates which version of IP (IPv4 or IPv6) has been enabled on the tunnel interface.
<b>NOTE</b>	
The tunnel mode is always IPv4 when using this command (this command can only be used on IPv4 IPsec tunnels).	
Port name	The specified name of the port. If a name was not specified, the output shows no port name.
Internet address	The IP address of the port. This is not the IP address of the tunnel source or destination.
Tunnel TOS	The value to write into the ToS byte in the IP header of a tunnel packet (the carrier packet). The value ranges from 0 through 99, where 0 means a tunnel packet copies the ToS value from the packet being encapsulated (the passenger packet).
Tunnel TTL	The value to write into the TTL field in the IP header of a tunnel packet (the carrier packet). The value ranges from 0 through 255, where 0 means a tunnel packet copies the value from the packet being encapsulated (the passenger packet). The default value is 255.
Tunnel MTU	This maximum size allowable for IP packets entering the tunnel. Packets that exceed the value you specify (or the default) are sent back to the source. The default value is 1480 bytes.
Tunnel vrf	
Forwarding vrf	
Tunnel protection profile	The name of the IPsec profile used to encapsulate and encrypt the IP packets being transmitted by the tunnel interface. A tunnel profile defines a set of encapsulation and encryption methods used to secure IP packets.

Output field	Description
Tunnel packet statistics	<p>The following packet counts for <b>unicast</b> traffic on the tunnel:</p> <ul style="list-style-type: none"> <li>• <b>RxPkts:</b> The total number of IP packets received from the tunnel on the interface.</li> <li>• <b>TxPkts:</b> The total number of IP packets transmitted across the tunnel from the interface.</li> <li>• <b>RxBytes:</b> The total number of bytes received from the tunnel on the interface. (The total is for IP packets only.)</li> <li>• <b>TxBytes:</b> The total number of bytes transmitted across the tunnel from the interface. (The total is for IP packets only.)</li> </ul>
Tunnel multicast packet statistics	<p>The following packet counts for <b>multicast</b> traffic on the tunnel:</p> <ul style="list-style-type: none"> <li>• <b>RxMcPkts:</b> The total number of IP multicast packets received from the tunnel on the interface.</li> <li>• <b>TxMcPkts:</b> The total number of IP multicast packets transmitted across the tunnel from the interface.</li> </ul>

**Usage Guidelines** This command is restricted to showing data for IPv4 IPsec tunnels.

**NOTE**

If you want to view the same information for IPv6 IPsec tunnels, use the **show ipv6 interface tunnel** command.

**Examples** The following example shows output for tunnel number 10.

```
device# show interfaces tunnel 10
Tunnel10 is IPsec port up, line protocol is up
  Hardware is Tunnel
  Tunnel source is 1.1.1.1
  Tunnel destination is 1.1.1.2
  Tunnel mode IPsec IPv4
  No port name
  Internet address is: 11.11.11.5/24
  Tunnel TOS 0, Tunnel TTL 255, Tunnel MTU 1431 bytes
  Tunnel vrf (IVRF): default-vrf
  Forwarding vrf (FVRF): default-vrf
  Tunnel protection profile: abcd
Tunnel Packet Statistics:
  RxPkts: 100           TxPkts: 11200
  RxBytes: 150         TxBytes: 12544
Tunnel Multicast Packet Statistics:
  RxMcPkts: 5394      TxMcPkts: 67
```

**History**

Release version	Command history
5.8.00	This command was introduced.
5.9.00	This command was modified to include multicast packet statistics information for the tunnel.

# show ip allow-src-multicast

Displays whether the packet drop for multicast IPv4 or IPv6 as the source IP address is enabled or disabled.

**Syntax** `show ip allow-src-multicast [switched-only]`

**Parameters** `switched-only`  
Displays switched multicast traffic as the source IP address.

**Modes** User EXEC mode

**Command Output** The `show ip allow-src-multicast` command displays the following information.

Output field	Description
Disable packet drop for multicast IPv4/IPv6 as source IP	Displays whether the disable packet drop for multicast IPv4 or IPv6 addresses as the source IP address is enabled or disabled.
Disable packet drop for multicast switched traffic only	Displays the slot on which the disable packet drop for switched traffic only is enabled.

**Examples** The following example displays the disable packet drop for multicast IPv4 or IPv6 addresses as source IP address in a disabled state.

```
device# show ip allow-src-multicast
  Disable packet drop for multicast ipv4/ipv6 as source ip:
  DISABLED
```

The following example displays the disabled packet drop for switched traffic only in an enabled state for slot 3.

```
device# show ip allow-src-multicast switched-only
  Disable packet drop for switched traffic only:
  ENABLED ON:
  Slot 3
```

History	Release version	Command history
	5.9.00	This command was introduced.

## show ip bgp neighbors

Displays configuration information and statistics for BGP4 neighbors of the device.

**Syntax** **show ip bgp neighbors**

**show ip bgp neighbors** *ip-addr*

**show ip bgp neighbors last-packet-with-error**

**show ipv6 bgp neighbors routes-summary**

**Parameters** *ip-addr*

IPv4 address of a neighbor in dotted-decimal notation.

**last-packet-with-error**

Displays information about the last packet from a neighbor that contained an error.

**routes-summary**

Displays information about all route information received in UPDATE messages from BGP neighbors.

**Modes** User EXEC mode

**Usage Guidelines** Use this command to view configuration information and statistics for BGP neighbors of the device. Output shows all configured parameters for the neighbors. Only the parameters whose values differ from defaults are shown.



**Examples** This example shows sample output from the show ip bgp neighbors command.

```

device> show ip bgp neighbors

Total number of BGP Neighbors: 1
'+': Data in InQueue '>': Data in OutQueue '-': Clearing
'*': Update Policy 'c': Group change 'p': Group change Pending
'r': Restarting 's': Stale '^': Up before Restart '<': EOR waiting

1 IP Address: 70.1.1.8, AS: 100 (IBGP), RouterID: 10.8.8.8, VRF: default-vrf
State: ESTABLISHED, Time: 0h9m23s, KeepAliveTime: 60, HoldTime: 180
KeepAliveTimer Expire in 8 seconds, HoldTimer Expire in 139 seconds
Minimal Route Advertisement Interval: 0 seconds
RefreshCapability: Received
Messages:   Open   Update   KeepAlive   Notification   Refresh-Req
Sent       : 1     0       11          0              0
Received: 1     0       11          0              0
Last Update Time: NLRI      Withdraw      NLRI      Withdraw
                  Tx: ---      ---          Rx: ---      ---
Last Connection Reset Reason:Unknown
Notification Sent:      Unspecified
Notification Received: Unspecified
Neighbor NLRI Negotiation:
Peer Negotiated IPV4 unicast capability
Peer configured for IPV4 unicast Routes
Neighbor ipv6 MPLS Label Capability Negotiation:
Neighbor AS4 Capability Negotiation:
Outbound Policy Group:
ID: 2, Use Count: 2
BFD:Disabled
TCP Connection state: ESTABLISHED, flags:00000033 (0,0)
Maximum segment size: 1460
TTL check: 0, value: 0, rcvd: 64
Byte Sent: 254, Received: 254
Local host: 78.1.1.7, Local Port: 8080
Remote host: 78.1.1.8, Remote Port: 179
ISentSeq: 413066676 SendNext: 413066931 TotUnAck: 0
TotSent: 255 ReTrans: 0 UnAckSeq: 413066931
IRcvSeq: 3375969591 RcvNext: 3375969846 SendWnd: 65000
TotalRcv: 255 DupliRcv: 0 RcvWnd: 65000
SendQue: 0 RcvQue: 0 CngstWnd: 1460

```

## History

Release version	Command history
5.9.00	The command was modified. Description codes were added to display output.

## show ip bgp summary

Displays summarized information about the status of all BGP connections.

**Syntax** `show ip bgp summary`

**Modes** User EXEC mode

**Command Output** The `show ip bgp summary` command displays the following information:

This field	Displays
Router ID	The device ID.
Local AS Number	The BGP4 AS number for the device.
Confederation Identifier	The AS number of the confederation in which the device resides.
Confederation Peers	The numbers of the local autonomous systems contained in the confederation. This list matches the confederation peer list you configure on the device.
Maximum Number of Paths Supported for Load Sharing	The maximum number of route paths across which the device can balance traffic to the same destination. The feature is enabled by default but the default number of paths is 1. You can increase the number from 2 through 8 paths.
Number of Neighbors Configured	The number of BGP4 neighbors configured on this device, and currently in established state.
Number of Routes Installed	The number of BGP4 routes in the device BGP4 route table and the route or path memory usage.
Number of Routes Advertising to All Neighbors	The total of the RtSent and RtToSend columns for all neighbors, the total number of unique ribout group entries, and the amount of memory used by these groups.
Number of Attribute Entries Installed	The number of BGP4 route-attribute entries in the device route-attributes table and the amount of memory used by these entries.
Neighbor Address	The IP addresses of the BGP4 neighbors for this device.
AS#	The AS number.

This field	Displays
State	<p>The state of device sessions with each neighbor. The states are from this perspective of the device, not the neighbor. State values are based on the BGP4 state machine values described in RFC 1771 and can be one of the following for each device:</p> <ul style="list-style-type: none"> <li>• IDLE - The BGP4 process is waiting to be started. Usually, enabling BGP4 or establishing a neighbor session starts the BGP4 process. A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> <li>• ADMND - The neighbor has been administratively shut down.</li> <li>• CONNECT - BGP4 is waiting for the connection process for the TCP neighbor session to be completed.</li> <li>• ACTIVE - BGP4 is waiting for a TCP connection from the neighbor. <b>Note</b> : If the state frequently changes between CONNECT and ACTIVE, there may be a problem with the TCP connection.</li> <li>• OPEN SENT - BGP4 is waiting for an Open message from the neighbor.</li> <li>• OPEN CONFIRM - BGP4 has received an Open message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the device receives a KEEPALIVE message from the neighbor, the state changes to Established. If the message is a NOTIFICATION, the state changes to Idle.</li> <li>• ESTABLISHED - BGP4 is ready to exchange UPDATE packets with the neighbor.</li> </ul> <p><b>Operational States:</b></p> <p>Additional information regarding the operational states of BGP described above may be added as described in the following:</p> <ul style="list-style-type: none"> <li>• <b>(+)</b> - is displayed if there is more BGP data in the TCP receiver queue. <b>Note</b> : If you display information for the neighbor using the <b>show ip bgp neighbor ip-addr</b> command, the TCP receiver queue value will be greater than 0.</li> <li>• <b>(&gt;)</b> - indicates that there is more BGP data in the outgoing queue.</li> <li>• <b>(-)</b> - indicates that the session has gone down and the software is clearing or removing routes.</li> <li>• <b>(*)</b> - indicates that the inbound or outbound policy is being updated for the peer.</li> <li>• <b>(c)</b> - indicates that the table entry is clearing.</li> <li>• <b>(p)</b> - indicates that the neighbor ribout group membership change is pending or in progress</li> <li>• <b>(s)</b> - indicates that the peer has negotiated restart, and the session is in a stale state.</li> <li>• <b>(r)</b> - indicates that the peer is restarting the BGP4 connection, through restart.</li> <li>• <b>(^)</b> - on the standby MP indicates that the peer is in the ESTABLISHED state and has received restart capability (in the primary MP).</li> <li>• <b>(&lt;)</b> - indicates that the device is waiting to receive the "End of RIB" message the peer.</li> </ul>
Time	The time that has passed since the state last changed.
Accepted	The number of routes received from the neighbor that this device installed in the BGP4 route table. Usually, this number is lower than the RoutesRcvd number. The difference indicates that this device filtered out some of the routes received in the UPDATE messages.

This field	Displays
Filtered	The routes or prefixes that have been filtered out: <ul style="list-style-type: none"> <li>If soft reconfiguration is enabled, this field shows how many routes were filtered out (not placed in the BGP4 route table) but retained in memory.</li> <li>If soft reconfiguration is not enabled, this field shows the number of BGP4 routes that have been filtered out.</li> </ul>
Sent	The number of BGP4 routes the device has sent to the neighbor.
ToSend	The number of routes the device has queued to advertise and withdraw to a neighbor.

**Examples** This example displays sample output from the **show ip bgp summary** command.

```
device> show ip bgp summary
  BGP4 Summary
  Router ID: 7.7.7.7   Local AS Number: 100
  Confederation Identifier: not configured
  Confederation Peers:
  Maximum Number of IP ECMP Paths Supported for Load Sharing: 1
  Number of Neighbors Configured: 1, UP: 1
  Number of Routes Installed: 0
  Number of Routes Advertising to All Neighbors: 0 (0 entries)
  Number of Attribute Entries Installed: 0
  '+': Data in InQueue '>': Data in OutQueue '-': Clearing
  '*': Update Policy 'c': Group change 'p': Group change Pending
  'r': Restarting 's': Stale '^': Up before Restart '<': EOR waiting
  Neighbor Address  AS#           State    Time           Rt:Accepted  Filtered  Sent
  ToSend
  10.1.1.8         100           ESTAB   0h 9m16s      0            0         0
  0
```

**History**

Release version	Command history
5.9.00	The command was modified. Description codes were added to display output.

# show ip http client

Displays information about the http(s) link and request between the http(s)server and the Brocade device (client).

**Syntax** `show ip http client`

**Modes** User EXEC mode.

**Command Output** The `show ip http client` command displays the following information:

**TABLE 7** Callers

Output field	Description
Session	The session ID
Username	The <i>username</i> . (Blank if none used)
Server	The server connection number

**TABLE 8** Servers

Output field	Description
Connection	The server connection number
Version	HTTP 1.0 or 1.1
Transport	TCP or TLS
Request	Current request number being processed
IP Address[:Port]	Remote server IPv4 or IPv6 address, and port (if non-default port)

**TABLE 9** Request

Number	The Request number
Method	GET, PUT, ...

**Examples** The following example shows the output from a `show ip http client` command:

```
device# show ip http client
Callers:
Session      Username      Server
1            lab           1

Servers:
Connection  Version      Transport    Request     IP Address
1           1.0          TCP          1           10.25.104.10

Requests:
Number      Method
1           GET
```

## NOTE

There is no history of prior connections being maintained. Once the file transfer is completed, the HTTP(S) session will be closed, and it will no longer be visible under the Server connections.

## Show Commands

### History

<b>Release</b>	<b>Command History</b>
05.9.00	This command was introduced.

## show ip interface

Displays useful information about the configuration and status of the IP protocol and its services, on all interfaces.

**Syntax** **show ip interface counters** | [ **ethernet** *slot/port* ] | [ **loopback** *num* ] | [ **pos** *slot/port* ] | [ **tunnel** *num* ]  
**show ip interface ve** *num* [ **statistics** [ **detail** | **ethernet** *slot/port* ] | [ **vpls** **vlan** *vlan\_id* ] ]

### Parameters

#### counters

Displays the interface level IP counters.

**ethernet** *slot/port*

Displays the specified Ethernet interface port.

**loopback** *num*

Displays the loopback interface number.

**pos** *slot/port*

Displays the POS interface number.

**tunnel** *num*

Displays the tunnel interface number.

**ve** *num*

Displays the Virtual Ethernet interface number.

#### statistics

Displays the interface level IP counters.

##### detail

Displays the interface IP extended counters in detail.

**ethernet** *slot/port*

Displays the interface IP counters for the specified port.

##### vpls

Displays the VPLS-VE end point IP counters.

**vlan** *vlan\_id*

Displays the specified VPLS-VE end point IP counters.

**Modes** EXEC mode

**Command Output** The **show ip interface** command displays the following information:

Output field	Description
Interface	The type and the slot and port number of the interface.
IP-Address	The IP address of the interface.
OK?	Whether the IP address is configured on the interface.
Method	Whether the IP address is saved in NVRAM. If you have set the IP address for the interface in the CLI, the Method field is "manual".
Status	The link status of the interface. If the user has disabled the interface with the <b>disable</b> command, the entry in the 'Status' field is "administratively DOWN". Otherwise, the entry in the 'Status' field is either UP or DOWN.

Output field	Description
Protocol	Whether the interface can provide two-way communication. If the IP address is configured and the link status of the interface is up, the entry in the 'Protocol' field is UP. Otherwise, the entry in the 'Protocol' field is DOWN.
VRF	Whether the VRF is configured or set to default.
Flag	Interface flag: <ul style="list-style-type: none"> <li>• U- Unnumbered</li> <li>• S- Secondary</li> <li>• US- Unnumbered Secondary</li> <li>• V- V-VE over VPLS</li> <li>• VS- S-VE over VPLS Secondary</li> </ul>

**Examples** The following example displays the **show ip interface** command modified to display a flag "V" when the interface is a VE over VPLS interface. This enhancement is on the MP as well as the LP.

```
device# show ip int
Flags : U-Unnumbered, S-Secondary, US-Unnumbered Secondary, V-VE over VPLS, VS-VE
over VPLS Secondary
Interface  IP-Address  OK?  Method  Status  Protocol  VRF          FLAG
-----  -
mgmt 1    10.25.106.36  YES  NVRAM   up      up        default-vrf
ve 40     10.40.40.1   YES  NVRAM   down    down      default-vrf
ve 150    10.15.15.1   YES  NVRAM   up      up        default-vrf  V
ve 150    10.20.20.1   YES  NVRAM   up      up        default-vrf  V
ve 150    10.15.15.2   YES  NVRAM   up      up        default-vrf  VS
loopback 1 10.1.1.1     YES  NVRAM   up      up        default-vrf
```



The following example displays the **show ip interface ve *num*** command modified to display ve-type information.

```
device# show ip interface ve 77
Interface Ve 77
  type: vpls
  vpls-id: 3 (name: a)
  members: vlan 20 - ethe 2/2, vlan 20 - ethe 2/3, vlan 101 - ethe 4/1, peer -
12.12.2.5
  active: vlan 20 - ethe 2/2, vlan 20 - ethe 2/3, peer - 12.12.2.5
  port disabled
  port state: DOWN
  ip address: 77.77.77.77/24
  Port belongs to VRF: default-vrf
  encapsulation: ETHERNET, mtu: 1500
  directed-broadcast-forwarding: disabled
  ip icmp redirect: enabled
  ip local proxy arp: disabled
  ip ignore gratuitous arp: disabled
  No inbound ip access-list is set
  No outbound ip access-list is set
  No Helper Addresses are configured.
```

The following example displays the **show ip interface tunnel *num*** command modified to display the traffic counters for the IPSec IPv4 tunnel.

```
device#show ip interface tunnel 10
Interface Tunnel 10
  port enabled
  port state: UP
  ip address: 11.11.11.5/24
  Port belongs to VRF: default-vrf
  encapsulation: ETHERNET, mtu: 1431
  directed-broadcast-forwarding: disabled
  ip icmp redirect: enabled
  ip local proxy arp: disabled
  ip ignore gratuitous arp: disabled
  No inbound ip access-list is set
  No outbound ip access-list is set
  No Helper Addresses are configured.
  RxPkts: 100          TxPkts:11200
  RxBytes:150         TxBytes:12544
```

The following example displays the **show ip interface** command with the **ve *num* statistics** option. This command is only applicable for G2/G3a modules.

```
device# show ip interface ve 1001 statistics
Extended Routed Counters (only applicable for G2/G3a modules):

VPLS Name: instance1001, VPLS Id: 1001
Total      RxPkts      TxPkts      RxBytes      TxBytes
          17             0           3478         0
```

```
device# show ip interface ve 1001 statistics detail
VPLS Extended Counters (only applicable for G2/G3a modules):
VPLS Name: instance1001, VPLS Id: 1001
with the
VPLS Vlan: vlan 1001
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 6/6   265         2170         37882        235824
```

The following example displays the **show ip interface** command with the **ve *num* statistics detail** option. This command is only applicable for G2/G3a modules.

```
device# show ip interface ve 1001 statistics detail
VPLS Extended Counters (only applicable for G2/G3a modules):
VPLS Name: instance1001, VPLS Id: 1001

VPLS Vlan: vlan 1001
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 6/6   265         2170         37882        235824
```

The following example displays the **show ip interface** command with the **ve num statistics vpls vlan vlan\_id** option. This command is only applicable for G2/G3a modules.

```
device# show ip interface ve 1001 statistics vpls vlan 1001 ethernet 6/6
Extended Routed Counters (only applicable for G2/G3a modules):

VPLS Name: instance1001, VPLS Id: 1001
Total      RxPkts      TxPkts      RxBytes      TxBytes
device#    17              0           3478         0
```

**History**

Release version	Command history
5.4.00	<p>The <b>show ip interface</b> command was modified to display a flag "V" if the interface is a VE over VPLS interface.</p> <p>The <b>show ip interface ve</b> command was modified to display VPLS-VE specific information. A new 'Type' field is introduced that shows what type of ve interface it is (VLAN or VPLS). This enhancement is only available for the MP.</p>

## show ip ospf

Displays the OSPF state.

**Syntax** **show ip ospf**

**Modes** User EXEC mode

**Examples** This example displays sample output from the **show ip ospf** command.

```
device> show ip ospf

OSPF Version Version 2
Router Id 10.1.1.2
ASBR Status No
ABR Status No (0)
Redistribute Ext Routes from
Initial SPF schedule delay 0 (msecs)
Minimum hold time for SPF's 0 (msecs)
Maximum hold time for SPF's 0 (msecs)
External LSA Counter 0
External LSA Checksum Sum 00000000
Originate New LSA Counter 9
Rx New LSA Counter 6
External LSA Limit 174762
Database Overflow Interval 0
Database Overflow State : NOT OVERFLOWED
RFC 1583 Compatibility : Enabled
Slow neighbor Flap-Action : Disabled, timer 300
Nonstop Routing: Disabled
Graceful Restart: Disabled, timer 120
Graceful Restart Helper: Enabled
LDP-SYNC: Globally enabled, Hold-down time 66 sec
Interfaces with LDP-SYNC enabled:
eth 1/3 eth 1/4
```

## show ip route

Displays a table that contains routes through LSP tunnels.

**Syntax** `show ip route [ ip_addr | num | bgp | connected | import | isis | local | nexthop | ospf | rip | static | summary | tags | vrf ]`

<b>Parameters</b>	<i>ip_addr</i>	
	<i>num</i>	Displays Ip subnet mask length.
	<b>bgp</b>	Displays route starting from index.
	<b>connected</b>	Displays BGP routes.
	<b>import</b>	Displays directly connected routes.
	<b>isis</b>	Displays imported IPv4 routes.
	<b>local</b>	Displays IS-IS routes.
	<b>nexthop</b>	Displays local IPv4 routes.
	<b>ospf</b>	Displays route nexthop table.
	<b>rip</b>	Displays OSPF routes.
	<b>static</b>	Displays RIP routes.
	<b>summary</b>	Displays static IP routes.
	<b>tags</b>	Displays route summary.
	<b>vrf</b>	Displays labels associated with routes.
		Displays VRF routes.

**Modes** User EXEC mode.

**Command Output** The `show ip route` command displays the following information:

Output field	Description
Destination	The destination network of the route.
Gateway	The nexthop router.
Port	The port through which the device sends packets to reach the route's destination.
Cost	The route's cost.

Output field	Description
Type	<p>The route type, which can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>B</b> - The route was learned from BGP.</li> <li>• <b>D</b> - the destination is directly connected to this Brocade device.</li> <li>• <b>R</b>- The route was learned from RIP.</li> <li>• <b>S</b> - The route is a static route.</li> <li>• * - The route is a candidate default route.</li> <li>• <b>O</b> - The route is an OSPF route. Unless you use the OSPF option to display the route table, 'O' is used for all OSPF routes. If you do not use the OSPF option, the following type codes are used: <ul style="list-style-type: none"> <li>- <b>O</b> - OSPF intra area route (within the same area.)</li> <li>- <b>IA</b> - The route is an OSPF inter area route (a route that passes from one area in another area.)</li> <li>- <b>E1</b> - The route is an OSPF external type 1 route.</li> <li>- <b>E2</b> - The route is an external type 2 route.</li> </ul> </li> </ul>

**Examples** The following example shows the **show ip route** command:

```

device# show ip route
Total number of IP routes: 1027
Type codes - B:BGP D:Disconnected S:Static R:RIP O:OSPF; Cost-Dist/Metric
  Destination      Gateway          Port           Cost      Type
1  10.1.1.1/32      DIRECT          loopback 1     0/0       D
2  10.1.2.1/32      DIRECT          loopback 2     0/0       D
3  10.1.3.1/32      DIRECT          loopback 3     0/0       D
4  10.2.2.2/32      10.0.0.2        eth 1/1         110/10    O
5  10.3.3.3/32      10.0.0.2        eth 1/1         110/12    O
   10.3.3.3/32      10.8.0.2        eth 1/4         110/12    O
6  10.4.4.4/32      10.8.0.2        eth 1/4         110/10    O
7  10.5.1.5/32      10.5.5.5        lsp (LDP)       200/0     B
8  10.5.3.5/32      10.5.5.5        lsp (LDP)       200/0     B
9  10.5.5.5/32      10.0.0.2        eth 1/1         110/13    O
   10.5.5.5/32      10.8.0.2        eth 1/4         110/13    O
10 10.6.1.6/32      10.6.6.6        lsp (LDP)       200/0     B
11 10.6.1.6/32      10.6.6.6        lsp (LDP)       200/0     B
12 10.6.3.6/32      10.6.6.6        lsp (LDP)       200/0     B
13 10.6.4.6/32      10.6.6.6        lsp (LDP)       200/0     B
14 10.6.5.6/32      10.6.6.6        lsp (LDP)       200/0     B
15 10.6.6.6/32      10.0.0.2        eth 1/1         110/14    O
   10.6.6.6/32      10.8.0.2        eth 1/4         110/14    O

```

## show ip static-arp

Displays port, VPLS-ID, VLAN, and VPLS peer information.

**Syntax** `show ip static-arp [ ip_addr ip_mask ] | num | [ ethernet slot / port ] | [ mac-address mac_addr ] | [ vlan vlan_id ] | [ vrf vrf_name ]`

<b>Parameters</b>	<i>ip_addr</i>	Specifies the selected IP address.
	<i>ip_mask</i>	Specifies the selected IP network mask.
	<i>num</i>	Specifies the number of entries to skip.
	<b>ethernet slot/port</b>	Displays the specified ethernet port.
	<b>mac-address mac_addr</b>	Displays the specified mac address in hexadecimal (xxxx.xxxx.xxxx).
	<b>vlan vlan_id</b>	Displays the specified VLAN. A choice of zero (0) signifies
	<b>vrf vrf_name</b>	Displays static ARP entries belonging to a given VRF instance.

**Modes** EXEC mode

**Command Output** The `show ip static-arp` command displays the following information:

Output field	Description
Index	The number of this entry in the table. You specify the entry number when you create the entry.
IP Address	The IP address of the device.
MAC Address	The MAC address of the device.
Port/VLAN	Port and VLAN ID.
ESI	<i>Ethernet Service Instance (ESI)</i> associated with this entry, if any.
Vpls-Vlan: Port/Vpls-Peer	Shows the VPLS ID under the 'Port' field when applicable. The 'Port' field for the VPLS VE ARP displays in the format '*:vpls-vlan: port' or '*: vpls-peer_ip_address'

**Examples** The following example shows the `show ip static-arp` command output.

```
device(config)# show ip static-arp
Total no. of entries: 2
Index  IP Address  MAC Address  Port/VLAN  ESI  Vpls-Vlan:Port/Vpls-Peer
1      10.10.10.10  0000.0033.4444  100
2      10.11.11.11  0000.0066.7777  4/1
3      10.12.12.12  0000.0023.4343
4      10.26.5.12   0000.00F3.4343
                                     *:21:3/2
                                     *:1.2.3.105
```

# show ip vrrp

Displays information about IPv4 Virtual Router Redundancy Protocol (VRRP) sessions.

**Syntax** `show ip vrrp [ brief ]`

`show ip vrrp [ ethernet slot / port | ve num ]`

`show ip vrrp [ statistics [ ethernet slot / port | ve num ] ]`

`show ip vrrp [ ve num [ vrid VRID ] ]`

`show ip vrrp [ vrid VRID [ ethernet slot / port | ve num ] ]`

**Parameters** **brief**

Displays summary information about the VRRP session.

**ethernet slot / port**

Displays IPv4 VRRP information only for the specified port.

**statistics**

Displays statistical information about the VRRP session.

**ve num**

Displays IPv4 VRRP information only for the specified virtual Ethernet port.

**vrid VRID**

Displays IPv4 VRRP information only for the specified virtual-group ID.

**Modes** User EXEC mode

**Usage Guidelines** Use this command to display information about IPv4 VRRP sessions, either in summary or full-detail format. You can also specify a virtual group or interface for which to display output.

This command supports IPv4 VRRP. You can modify or redirect the displayed information by using the default Linux tokens (|, >).

**Command Output** The `show ip vrrp` command displays the following information:

Output field	Description
Total number of VRRP routers defined	The total number of virtual routers configured and currently running on this Brocade device. For example, if the Brocade device is running VRRP-E, the total applies only to VRRP-E routers.
Interface	The interface on which VRRP or VRRP-E is configured. If VRRP or VRRP-E is configured on multiple interfaces, information for each interface is listed separately.
VRID	The ID of the virtual router configured on this interface. If multiple virtual routers are configured on the interface, information for each virtual router is listed in a separate row.
Current Priority	The current VRRP or VRRP-E priority of this Brocade device for the virtual router.

Output field	Description
Flags	<p>Whether the backup preempt mode is enabled. If the backup preempt mode is enabled, this field contains a "P". If the mode is disabled, this field is blank.</p> <ul style="list-style-type: none"> <li>• P:Preempt 2:V2 3:V3</li> <li>• 2: implies VRRP Version2</li> <li>• 3: implies VRRP Version3</li> </ul>
Short-Path-Fwd	<p>This Brocade device's VRRP state for the virtual router. The state can be one of the following:</p> <ul style="list-style-type: none"> <li>• Init—The virtual router is not enabled (activated). If the state remains Init after you activate the virtual router, make sure that the virtual router is also configured on the other routers and that the routers can communicate with each other.</li> </ul> <p>If the state is Init and the mode is incomplete, make sure you have specified the IP address for the virtual router.</p> <ul style="list-style-type: none"> <li>• Backup—This Brocade device is a backup for the virtual router.</li> <li>• Master—This Brocade device is the master for the virtual router.</li> </ul>
Master IP Address	The IP address of the router interface that is currently the Master for the virtual router.
Backup IP Address	The IP addresses of the router interfaces that are currently backups for the virtual router.
Virtual IP Address	The virtual IP address that is being backed up by the virtual router.

**Examples** The following example displays VRRP session information in summary format.

```
device(config)# show ip vrrp brief
Total number of VRRP routers defined: 2
Flags Codes - P:Preempt 2:V2 3:V3 S:Short-Path-Fwd
Inte- VRID  Current  Flags  State  Master IP Backup IP  Virtual IP
rface  Priority
-----
1/1   10    255    P2-    Master  Local   Unknown  10.30.30.2
1/3   13    100    P2-    Master  Local   Unknown  10.13.13.3
```

The following example displays IPv4 VRRP configuration information about VRID 1.

```
device# show ip vrrp vrid 1

Interface 1/1
-----
auth-type no authentication
VRID 1 (index 1)
interface 1/1
state master
administrative-status enabled
version v2
mode owner
virtual mac aaa.bbb.ccc (configured)
priority 255
current priority 255
track-priority 2
hello-interval 1 sec
backup hello-interval 6
```



# show ip vrrp-extended

Displays information about IPv4 Virtual Router Redundancy Protocol Extended (VRRP-E) sessions.

**Syntax** `show ip vrrp-extended [ brief ]`

`show ip vrrp-extended [ ethernet slot / port | ve num ]`

`show ip vrrp-extended [ statistics [ ethernet slot / port | ve num ] ]`

`show ip vrrp-extended [ ve num [ vrid VRID ] ]`

`show ip vrrp-extended [ vrid VRID [ ethernet slot / port | ve num ] ]`

**Parameters** **brief**

Displays summary information about the VRRP-E session.

**ethernet slot / port**

Displays IPv4 VRRP-E information only for the specified port.

**statistics**

Displays statistical information about the VRRP-E session.

**ve num**

Displays IPv4 VRRP-E information only for the specified virtual Ethernet port.

**vrid VRID**

Displays IPv4 VRRP-E information only for the specified virtual-group ID.

**Modes** User EXEC mode

**Usage Guidelines** Use this command to display information about IPv4 VRRP-E sessions, either in summary or full-detail format. You can also specify a virtual group or interface for which to display output.

This command supports IPv4 VRRP-E. You can modify or redirect the displayed information by using the default Linux tokens (|, >).

This command can be entered in any configuration mode on the device.

**Command Output** The `show ip vrrp-extended` command displays the following information:

Output field	Description
Total number of VRRP-E routers defined	The total number of virtual routers configured on this Brocade device. The total number of virtual routers configured and currently running on this Brocade device. For example, if the Brocade device is running VRRP-E, the total applies only to VRRP-E routers.
Interface	The interface on which VRRP or VRRP-E is configured. If VRRP or VRRP-E is configured on multiple interfaces, information for each interface is listed separately.
VRID	The ID of the virtual router configured on this interface. If multiple virtual routers are configured on the interface, information for each virtual router is listed in a separate row.
Current Priority	The current VRRP or VRRP-E priority of this Brocade device for the virtual router.

Output field	Description
Flags	<p>Whether the backup preempt mode is enabled. If the backup preempt mode is enabled, this field contains a "P". If the mode is disabled, this field is blank.</p> <ul style="list-style-type: none"> <li>• P:Preempt 2:V2 3:V3</li> <li>• 2: implies VRRP Version2</li> <li>• 3: implies VRRP Version3</li> </ul>
Short-Path-Fwd	<p>This Brocade device's VRRP state for the virtual router. The state can be one of the following:</p> <ul style="list-style-type: none"> <li>• Init—The virtual router is not enabled (activated). If the state remains Init after you activate the virtual router, make sure that the virtual router is also configured on the other routers and that the routers can communicate with each other.</li> </ul> <p>If the state is Init and the mode is incomplete, make sure you have specified the IP address for the virtual router.</p> <ul style="list-style-type: none"> <li>• Backup—This Brocade device is a backup for the virtual router.</li> <li>• Master—This Brocade device is the master for the virtual router.</li> </ul>
Master IP Address	The IP address of the router interface that is currently the Master for the virtual router.
Backup IP Address	The IP addresses of the router interfaces that are currently backups for the virtual router.
Virtual IP Address	The virtual IP address that is being backed up by the virtual router.

**Examples** The following example displays summary information for a VRRP-E session.

```
device# show ip vrrp-extended brief
Total number of VRRP-E routers defined: 2
Flags Codes - P:Preempt 2:V2 3:V3 S:Short-Path-Fwd
Inte- VRID  Current  Flags  State  Master IP Backup IP  Virtual IP
rface  Priority
-----
Ve 1  2    255    P2-    Master  Local   10.30.20.2 10.30.30.2
Ve 3  4    100    P2-    Backup Local   10.30.20.2 10.30.30.2
```

The following example displays the number of configured virtual IPv4 addresses for each VRRP-E router instance and the virtual IPv4 addresses when the VRRP-E multiple virtual IP addresses feature is configured.

```
device# show ip vrrp-extended brief
Total number of VRRP-Extended routers defined: 3
Flags Codes - P:Preempt 2:V2 3:V3
Short-Path-Fwd Codes - ER: Enabled with revertible option, RT: reverted,
NR: not reverted
Intf VRID  Curr  Flags  State  MasterIP  BackupIP (No)  VirtualIP  Short-  Track MCT
Prio
-----
1/1  1    100  P2    Master Local   Unknown ( 7)  10.10.10.10 Enabled Disable
10.20.20.20
10.30.30.30
10.40.40.40
10.50.50.50
10.60.60.60
10.70.70.70
```

The following example displays detailed information for a VRRP-E backup device.

```
device(config)# show ip vrrp-extended

Total number of vrrp-extended routers defined: 1
Interface v10
-----
auth-type no authentication
VRID 10 (index 1)
interface v10
state backup
administrative-status enabled
mode non-owner(backup)
virtual mac 02e0.52a0.c00a
priority 50
current priority 50
track-priority 5
hello-interval 1 sec
backup hello-interval 60 sec
slow-start timer (configured) 30 sec
advertise backup disabled
dead-interval 3600 ms
preempt-mode true
virtual ip address 10.10.10.254
next hello sent in 1000ms
track-port 1/1 (up)
master router 10.10.10.4 expires in 3.1 sec
short-path-forwarding enabled
```

The following example displays display IPv4 VRRP-E statistics. The received vrrp packets with unknown or inactive vrid shows the number of packets that contain virtual routers that are not configured on the device or its interface.

```
device> show ip vrrp-extended statistics

Global VRRP-Extended statistics
-----
- received vrrp-extended packets with checksum errors = 0
- received vrrp-extended packets with invalid version number = 0
- received vrrp-extended packets with unknown or inactive vrid = 1480
Interface v10
-----
VRID 1
- number of transitions to backup state = 1
- number of transitions to master state = 1
- total number of vrrp-extended packets received = 0
. received backup advertisements = 0
. received packets with zero priority = 0
. received packets with invalid type = 0
. received packets with invalid authentication type = 0
. received packets with authentication type mismatch = 0
. received packets with authentication failures = 0
. received packets dropped by owner = 0
. received packets with ip ttl errors = 0
. received packets with ip address mismatch = 0
. received packets with advertisement interval mismatch = 0
. received packets with invalid length = 0
- total number of vrrp-extended packets sent = 2004
. sent backup advertisements = 0
. sent packets with zero priority = 0
- received arp packets dropped = 0
- received proxy arp packets dropped = 0
- received ip packets dropped = 0
```

The following example displays IPv4 VRRP-E configuration information about VRID 1.

```
device# show ip vrrp-extended vrid 1

Interface 1/1
-----
auth-type md5-authentication
VRID 1 (index 1)
interface 1/1
state master
administrative-status disabled
mode non-owner(backup)
virtual mac aaaa.bbbb.cccc (configured)
priority 100
current priority 100
track-priority 5
hello-interval 1 sec
backup hello-interval 60 sec
slow-start timer (configured) 30 sec
advertise backup disabled
dead-interval 0 ms
preempt-mode true
virtual ip address 10.20.1.100
short-path-forwarding disabled
```

The following example displays group member information for the VRRP-E scaling feature for VRID 1. Only partial output is displayed.

```
device(config)# show ip vrrp-extended vrid 1

VRID 1 (index 1)
 interface 1/1
  state master
  . administrative-status enabled
  .
  .
 group-member count 3
 group-members
  ethernet 1/2 vrid 2
  ethernet 1/2 vrid 3
  ethernet 1/2 vrid 4
```

The following example displays group master information for the VRRP-E scaling feature for interface Ethernet 1/1 and VRID 2. Only partial output is displayed.

```
device(config)# show ip vrrp-extended ethernet 1/1 vrid 2

VRID 2 (index 2)
 interface 1/2
  state master
  administrative-status enabled
  .
  .
  .
 short-path-forwarding disabled
 group-master ethernet 1/1 vrid 1
```

**History**

Release version	Command history
05.8.00	This command was modified to add new output for the VRRP-E scaling and VRRP-E multiple virtual IP addresses features.

## show ipsec egress-config

Displays egress configuration register contents for IPsec.

**Syntax** `show ipsec egress-config`

**Modes** Privileged EXEC mode

**Examples** The following example displays `show ipsec egress-config` command output.

```
device# show ipsec egress-config

IPSec Egress Configuration
Packet with Seq no maxout error:      Packet Drop
Packet with NHT entry error:         Packet Drop
Packet with unsupported IP header error: Packet Drop
Packet with invalid SPI error:       Packet Drop
Non-IP packet for Encapsulation:     Packet Drop
Packet encryption:                   Enabled
IP header check:                     Enabled
```

History	Release version	Command history
	05.8.00	This command was introduced.

## show ipsec egress-spi-table

Displays the software copy and the details of the IPsec egress SPI lookup table entry. This command supports IPsec IPv4 and IPv6.

**Syntax** `show ipsec egress-spi-table`

**Modes** Privileged EXEC mode

**Examples** The following example shows the output for an IPsec egress SPI lookup table.

This example is for IPsec IPv4.

```
device#show ipsec egress-spi-table
Egress SPI Lookup Table (total entries: 5)
idx  spi          spa          dpa          tnnl
  1  0x7883db6f  52.54.112.52  52.54.112.54  112
  2  0xefeaffe5  52.54.111.52  52.54.111.54  111

device#show ipsec egress-spi-table 2
egress-spi-id: 2
SPA: 0x00000000 00000000 00000000 34366f34
DPA: 0x00000000 00000000 00000000 34366f36
Mode: IPv4(Tunnel)  ReplayCheck: Enabled  ESN_Support: Disabled
TC/TOS: 0(ValidBit: UnSet)  HopLimit/TTL: 255
SPI: 0xefeaffe5  Salt: 0x88876d98  SequenceNumber: 0x0000000000000002
ReplayVector: 0x0000000000000001
AES-256-GCM-KEY: 0x8478313e48f17e2ae1554db2f46762d7865a7ab2a51b4760a6e0c6e522e87988
```

**History**

Release version	Command history
05.8.00	This command was introduced.
05.9.00	This command was modified to add support for IPsec IPv6.

## show ipsec error-count

Displays the number of packets encountered with errors, while processing IPsec packets.

**Syntax** `show ipsec error-count`

**Modes** Privileged EXEC mode

**Examples** The following example displays `show ipsec error-count` command output.

```
device#show ipsec error-count
  Ingress Replay Error Count                : 0
  Ingress Authentication Error Count        : 0
  Ingress Pkt Length not in 4byte boundry Error Count : 0
  Ingress Pkt ESP header not in 16byte boundry Error Count : 0
  Ingress Pkt Drop due to Tunnel Mis-match Error Count : 0
  Ingress Pkt EOF before indicated by IP pkt length Error Count: 0
  Ingress Pkt De-encapsulation Error Count : 0
  Ingress Pkt ESP header in fragmented IP pkt Error Count : 0
  Egress Invalid SPI table entry Error Count : 0
  Egress non-IP Pkt Encapsulation Error Count : 0
  Egress Nexthop Table Error Count         : 0
  Egress Unsupported Pkt Encapsulation Error Count : 0
  Egress Sequence Number Max-out Error Count : 0
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show ipsec ingress-config

Displays ingress configuration register contents for IPsec.

**Syntax** `show ipsec ingress-config`

**Modes** Privileged EXEC mode

**Examples** The following example displays `show ipsec ingress-config` command output.

```
device#show ipsec ingress-config

IPSec Ingress Configuration
  Packet with encapsulation error:      Send to CPU
  Packet with tunnel check error:       Send to CPU
  Packet with replay check error:       Send to CPU
  Packet with authentication error:      Send to CPU
  Packet with fragmentation error:      Send to CPU
  Packet with IP length error:          Send to CPU
  Hash based on SPI used as Ingress SPI table index
  Decapsulation:                       Enabled
  Decryption:                           Enabled
  Next header check:                   Enabled
  IPDA check:                           Enabled
  IPSA check:                           Enabled
  Early EOF check:                      Enabled
  IP length not in 4B boundary check:    Disabled
  ESP length not in 16B boundary check:  Enabled
  IP fragmentation check:               Enabled
  Authentication check:                 Enabled
```

### History

Release version	Command history
05.8.00	This command was introduced.



## show ipsec ingress-spi-table

Displays the software copy and the details of the IPsec ingress SPI lookup table entry. This command supports IPsec IPv4 and IPv6.

**Syntax** `show ipsec ingress-spi-table`

**Modes** Privileged EXEC mode

**Examples** The following example shows the output for an IPsec ingress SPI lookup table.

This example is for IPsec IPv4.

```
device#show ipsec ingress-spi-table
  Ingress SPI Lookup Table (total entries: 5)
idx  spi          spa          dpa          tnnl
  1  0x6e2d9ba8  52.54.112.54  52.54.112.52  112
  2  0x3b191431  52.54.111.54  52.54.111.52  111
device#show ipsec ingress-spi-table 2
  ingress-spi-id: 2
  SPA: 0x00000000 00000000 00000000 34366f36
  DPA: 0x00000000 00000000 00000000 34366f34
  Mode: IPv4(Tunnel)  ReplayCheck: Enabled  ESN_Support: Disabled
  SPI: 0x3b191431  Salt: 0xf1db462b  SequenceNumber: 0x000000000dc042a
  ReplayVector: 0xffffffffffffffff
  AES-256-GCM-KEY: 0xe5649a5cf623dcd134cbf280bfd95eb390719557bd1663d748aece2c6b8eacb0
```

### History

Release version	Command history
05.8.00	This command was introduced.
05.9.00	This command was modified to add support for IPsec IPv6.

## show ipsec policy

Displays the database for the IP security policies.

**Syntax** **show ipsec policy**

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ipsec policy** command output .

```
device# show ipsec policy
IPSEC Security Policy Database(Entries:2)
PType Dir Proto Source(Prefix:TCP/UDP Port)
          Destination(Prefix:TCP/UDPPort)
SA: SPDID(vrf:if) Dir Encap SPI          Destination
use   in  OSPF FE80::/10:any
      ::/0:any
SA: 0:v2          in  ESP  400          FE80::
use   out OSPF FE80::/10:any
      ::/0:any
SA: 0:v2          out ESP  400          ::
use   in  all  0.0.0.0/0:any
      0.0.0.0/0:any
SA: 1:Tun1       in  ESP  0xBD481319 1.2.10.2
use   out  all  0.0.0.0/0:any
      0.0.0.0/0:any
SA: 1:Tun1       out  ESP  0x9EAB77D6 1.2.10.2
```

### History

Release version	Command history
5.8.00	This command was introduced.

## show ipsec profile

Displays the configured IPsec profile information.

**Syntax** `show ipsec profile [ profile-name ]`

**Parameters** *profile-name*  
Specifies the IPsec profile name.

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ipsec profile** command output.

```
device# show ipsec profile
Name           : red
Ike Profile    : red
Lifetime       : 28800
Anti-replay service : Enabled
  Replay window size : 64
DH group       : None
Proposal       : red
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show ipsec proposal

Displays the configured IPsec proposals.

**Syntax** `show ipsec proposal [ proposal-name ]`

**Parameters** *proposal-name*  
Specifies the proposal name for the IPsec profile.

**Modes** Privileged EXEC mode

**Examples** The following example displays **show ipsec proposal** command output .

```
device# show ipsec proposal
Name           : prop_red
Protocol       : ESP
Encryption    : aes-gcm-256
Authentication: NULL
ESN           : Enable
Mode          : Tunnel
```

### History

Release version	Command history
05.8.00	This command was introduced.

## show ipsec sa

Displays information about the current IPsec Security Associations (SA) that exist on the device or on the IPsec interface. This command supports IPsec IPv4 and IPv6.

**Syntax** **show ipsec sa** [ **address** [ *address* | *ipv6-address* ] | **identity** *id* | **interface** *name* | **peer** *ip-address* ] [ **detail** ]

**Parameters**

- address** *address*  
(Optional) Specifies the IPv4 address of the IPsec interface.
- address** *ipv6-address*  
(Optional) Specifies the IPv6 address of the IPsec interface.
- identity** *id*  
(Optional) Specifies the IPsec identity ID value.
- interface** *name*  
(Optional) Specifies the IPsec interface name.
- peer** *ip-address*  
(Optional) Specifies the IP address of the IPsec interface.
- detail**  
(Optional) Specifies to include details of the IPsec SA in the output.

**Modes** Privileged EXEC mode

**Usage Guidelines** If you do not include the optional **detail** parameter, only the basic information about the IPsec SA is included in the output.

**Examples** These examples are for IPsec IPv4.

The following example shows output for command **show ipsec sa** for the an IPsec SAs on the device.

```
device# show ipsec sa
          IPSEC Security Association Database(Entries:2)
SPDID(vrf:if) Dir Encap SPI      Destination
  AuthAlg  EncryptAlg Status Mode
0:v2      out  ESP    400      ::
  sha1     Null      ACT      TRAN
0:v2      in   ESP    400      FE80::
  sha1     Null      ACT      TRAN
1:Tun1    in   ESP    0xBD481319  1.2.10.2
  Null     AES-GCM-256 ACT      TNL
1:Tun1    out  ESP    0x9EAB77D6  1.2.10.2
  Null     AES-GCM-256 ACT      TNL
```

The following example shows output for command **show ipsec sa <ipaddress> detail** for the IPsec SAs set up on interface 1.2.10.2.

```
device# show ipsec sa address 1.2.10.2 detail
Total ipsec SAs: 2

0:
  interface          : tnl 1
  Local address: 1.2.45.1/500, Remote address: 1.2.45.2/500
  Inside vrf: default-vrf
  Local identity (addr/mask/prot/port): address(0.0.0.0/0/0/0)
  Remote identity(addr/mask/prot/port): address(0.0.0.0/0/0/0)
  DF-bit: clear
  Profile-name: red
  DH group: none
  Direction: inbound, SPI: 0x0000004b
  Mode: tunnel,
  Protocol: esp, Encryption: gcm-256, Authentication: null
  ICV size: 16 bytes
  lifetime(sec): Expiring in (4606816/3576)
  Anti-replay service: Enabled, Replay window size: 0
  Status: ACTIVE
  slot Assigned 0
  nht_index 0000ffff
  Is Tunnel NHT: false

1:
  interface          : tnl 1
  Local address: 1.2.45.1/500, Remote address: 1.2.45.2/500
  Inside vrf: default-vrf
  Local identity (addr/mask/prot/port): address(0.0.0.0/0/0/0)
  Remote identity(addr/mask/prot/port): address(0.0.0.0/0/0/0)
  DF-bit: clear
  Profile-name: red
  DH group: none
  Direction: inbound, SPI: 0x0000009c
  Mode: tunnel,
  Protocol: esp, Encryption: gcm-256, Authentication: null
  ICV size: 16 bytes
  lifetime(k/sec): Expiring in (4606816/3576)
  Anti-replay service: Enabled, Replay window size: 0
  Status: ACTIVE
  slot Assigned 0
  nht_index 00000004
  Is Tunnel NHT: true
```

**History**

Release version	Command history
05.8.00	This command was introduced.
05.9.00	This command was modified to add support for IPsec IPv6.

## show ipsec statistics

Displays IPsec Security Association (SA) statistics.

**Syntax** `show ipsec statistics [tunnel tunnel-id]`

**Parameters** `tunnel`*tunnel-id*  
Specifies the IPsec tunnel ID value.

**Modes** Privileged EXEC mode

**Command Output** The `show ipsec statistics` command displays the following information:

Output field	Description
IPSecurity Statistics	Displays the total current and total inbound as well as outbound security association statistics.
IPSecurity Packet Statistics	Displays the total inbound, outbound and dropped packets.
IPSecurity Error Statistics	Displays the total packet errors, such as the authentication, replay, receive, policy and send errors.

The `show ipsec statistics tunnel` command displays the following information:

Output field	Description
RxPkts	The number of packets received on the interface.
RxBytes	The volume of data (in bytes) transmitted on the interface.
TxPkts	The number of packets transmitted by the interface.
TxBytes	The volume of data (in bytes) transmitted by the interface.
RxMcPkts	The number of multicast packets received on the interface.
TxMcPkts	The number of multicast packets transmitted by the interface.

**Examples** The following example displays the IPsec SA statistics.

```
device# show ipsec statistics
                    IPSecurity Statistics
ipsecEspCurrentInboundSAs 1      ipsecEspTotalInboundSAs: 1
ipsecEspCurrentOutboundSA 1      ipsecEspTotalOutboundSAs: 1
                    IPSecurity Packet Statistics
ipsecEspTotalInPkts:      0      ipsecEspTotalInPktsDrop: 0
ipsecEspTotalOutPkts:    7
                    IPSecurity Error Statistics
ipsecAuthenticationErrors 0
ipsecReplayErrors:        0      ipsecPolicyErrors:      0
ipsecOtherReceiveErrors:  0      ipsecSendErrors:        0
ipsecUnknownSpiErrors:   0
```

The following example displays the **show ipsec statistics tunnel** command output.

```
device# show ipsec statistics tunnel
#      Tnnl  RxPkts      RxBytes      TxPkts      TxBytes      RxMcPkts
TxMcPkts
1      1      1393          219574      3696386     510126444   546
321
```

The following example displays the **show ipsec statistics tunnel** command output for tunnel 1.

```
device# show ipsec statistics tunnel 1
IPSec tunnel 1 statistics:
RxPkts:      1399          TxPkts:  3714027
RxBytes:     220522        TxBytes:  512560982
Multicast Packet Statistics:
RxPkts:      5394          TxPkts:   67
```

**History**

Release version	Command history
5.8.00	This command was introduced.
5.9.00	This command was modified to include the <b>show ipsec statistics tunnel</b> command output.



## show ip-tunnels

Displays information about the configured and valid IPsec tunnels (IPv4 IPsec and IPv6 IPsec) on the device. The information includes the number of the tunnels, source and destination IP addresses, whether tunnels statistics collection is enabled, the protection profile, the spi-idx and more.

**Syntax** `show ip-tunnels`

**Modes** Privileged EXEC mode

**Examples** The following example shows the protection profile and spi-idx for the IPsec tunnels. This example is for IPsec IPv4.

```
device# show ip-tunnels
# of Configured Tunnels : 1, GRE Session Enforce: FALSE, IPv6 Session Enforce: FALSE,
  IP Tunnel Statistics collection Disabled
IPSec IPv4 tnnl 10 UP : src_ip 1.1.1.1, dst_ip 1.1.1.2
  TTL 255, TOS 0, NHT 1, MTU 1431
  ipsec protection profile : abcd
    egress-spi-idx: 0
device#
```

```
device#show ip-tunnels
# of Valid Tunnels : 2, GRE Session Enforce: FALSE, IPv6 Session Enforce: FALSE
  IP Tunnel Statistics collection Disabled
IPSec IPv4 tnnl 10 UP : src_ip 1.1.1.1, dst_ip 1.1.1.2, TTL 255, TOS 0
  nht 1, mtu 1431, nht_visited 1, ingresspram_visited 0, arp_index 0x00000001
  PRAM-PPCR2:1: SrcIngressChk 0xffffffff
  ipsec protection profile : abcd
    egress-spi-idx: 1   ingress-spi-idx: 1
device#
```

### History

Release version	Command history
5.8.00	This command was introduced.
5.9.00	This command was modified to add support for IPv6.

## show ipv6 access-list bindings

Displays all IPv6 access-lists bound to different interfaces. This includes both rule-based ACL and receive access-control list (rACL) information

**Syntax** `show ipv6 access-list bindings`

**Modes** User EXEC node

### Usage Guidelines

**Examples** The following example displays all IPv6 access-list bindings.

```
device(config)# show ipv6 access-list bindings
!  
ipv6 receive access-list b1 sequence 11  
ipv6 receive access-list b2 sequence 12  
!
```

### History

Release	Command History
5.6.00	This command was introduced.

## show ipv6 access-list receive accounting

Displays accounting information for an IPv6 receive access-control list (rACL).

**Syntax** `show ipv6 access-list receive accounting { brief | name acl-name }`

**Parameters** **brief**

Displays IPv6 rACL accounting information in brief.

**name** *acl-name*

Specifies the name of a receive access-control list.

**Modes** User EXEC mode

**Examples** The following example displays rACL accounting information for the ACL "b1".

```
device(config)# show ipv6 access-list receive accounting name b1
IPv6 Receive ACL Accounting Information:
IPv6 Receive ACL b1
ACL hit count for software processing (accum)                                0
HW counters:
  0: permit tcp any host 2000::2
    Hit count: (1 sec)                                0 (1 min)                0
               (5 min)                                0 (accum)                0
  1: permit udp any host 1000::1
    Hit count: (1 sec)                                0 (1 min)                0
               (5 min)                                0 (accum)                0
```

**History**

Release	Command History
5.6.00	This command was introduced.

## show ipv6 bgp neighbors

Displays configuration information and statistics for BGP4+ neighbors of the device.

**Syntax** `show ipv6 bgp neighbors`

`show ipv6 bgp neighbors ipv6-addr`

`show ipv6 bgp neighbors last-packet-with-error`

`show ipv6 bgp neighbors routes-summary`

**Parameters** *ipv6-addr*

IPv6 address of a neighbor in dotted-decimal notation.

**last-packet-with-error**

Displays information about the last packet from a neighbor that contained an error.

**routes-summary**

Displays information about all route information received in UPDATE messages from BGP neighbors.

**Modes** User EXEC mode

**Examples** The following is sample output from the `show ipv6 bgp neighbors` command.

```
device> Total number of BGP Neighbors: 1
'+' : Data in InQueue '>': Data in OutQueue '-': Clearing
'*': Update Policy 'c': Group change 'p': Group change PENDING
'r': Restarting 's': Stale '^': Up before Restart '<': EOR waiting

1  IP Address: 78:2::2, AS: 100 (IBGP), RouterID: 0.0.0.0, VRF: default-vrf
   State: CONNECT, Time: 0h9m7s, KeepAliveTime: 60, HoldTime: 180
   Minimal Route Advertisement Interval: 0 seconds
   Messages:   Open   Update   KeepAlive   Notification   Refresh-Req
   Sent       : 0     0         0           0               0
   Received: 0     0         0           0               0
   Last Connection Reset Reason:Unknown
   Notification Sent:      Unspecified
   Notification Received: Unspecified
   Neighbor NLRI Negotiation:
     Peer configured for IPV6 unicast Routes
   Neighbor ipv6 MPLS Label Capability Negotiation:
   Neighbor AS4 Capability Negotiation:
   Outbound Policy Group:
     ID: 2, Use Count: 2
   BFD:Disabled
   Error: TCP status not available
```

**History**

Release version	Command history
5.9.00	The command was modified. Description codes were added to display output.

## show ipv6 bgp summary

Displays summarized information about the status of all BGP4+ connections.

**Syntax** `show ipv6 bgp summary`

**Modes** User EXEC mode

**Command Output** The `show ipv6 bgp summary` command displays the following information.

Output field	Description
Router ID	The device's router ID.
Local AS Number	The BGP4+ AS number in which the device resides.
Confederation Identifier	The autonomous system number of the confederation in which the device resides.
Confederation Peers	The numbers of the local autonomous systems contained in the confederation. This list matches the confederation peer list you configure on the device.
Maximum Number of Paths Supported for Load Sharing	The maximum number of route paths across which the device can balance traffic to the same destination. The feature is enabled by default but the default number of paths is 1. You can increase the number from 2 - 8 paths.
Number of Neighbors Configured	The number of BGP4+ neighbors configured on this device.
Number of Routes Installed	The number of BGP4+ routes in the device's BGP4+ route table.
Number of Routes Advertising to All Neighbors	The total of the RtSent and RtToSend columns for all neighbors.
Number of Attribute Entries Installed	The number of BGP4+ route-attribute entries in the route-attributes table.
Neighbor Address	The IPv6 addresses of this BGP4+ neighbors.
AS#	The autonomous system number.

Output field	Description
--------------	-------------

State	<p>The state of this neighbor session with each neighbor. The states are from this perspective of the session, not the neighbor's perspective. The state values can be one of the following for each:</p> <ul style="list-style-type: none"> <li>• IDLE - The BGP4+ process is waiting to be started. Usually, enabling BGP4+ or establishing a neighbor session starts the BGP4+ process. <ul style="list-style-type: none"> <li>- A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> </ul> </li> <li>• ADMND - The neighbor has been administratively shut down. <ul style="list-style-type: none"> <li>- A minus sign (-) indicates that the session has gone down and the software is clearing or removing routes.</li> </ul> </li> <li>• CONNECT - BGP4+ is waiting for the connection process for the TCP neighbor session to be completed.</li> <li>• ACTIVE - BGP4+ is waiting for a TCP connection from the neighbor.</li> </ul>
-------	--

**NOTE**

If the state frequently changes between CONNECT and ACTIVE, there may be a problem with the TCP connection.

- OPEN SENT - BGP4+ is waiting for an Open message from the neighbor.
- OPEN CONFIRM - BGP4+ has received an OPEN message from the neighbor and is now waiting for either a KEEPALIVE or NOTIFICATION message. If the receives a KEEPALIVE message from the neighbor, the state changes to Established. If the message is a NOTIFICATION, the state changes to Idle.
- ESTABLISHED - BGP4+ is ready to exchange UPDATE packets with the neighbor.
  - If there is more BGP data in the TCP receiver queue, a plus sign (+) is also displayed.

**NOTE**

If you display information for the neighbor using the **show ipv6 bgp neighbor<ipv6-address>** command, the TCP receiver queue value will be greater than 0.

**Operational States:**

Additional information regarding the operational states of BGP described above may be added as described in the following:

- **(+)** - is displayed if there is more BGP data in the TCP receiver queue. **Note** : If you display information for the neighbor using the **show ip bgp neighborip-addr** command, the TCP receiver queue value will be greater than 0.
- **(>)** - indicates that there is more BGP data in the outgoing queue.
- **(-)** - indicates that the session has gone down and the software is clearing or removing routes.
- **(\*)** - indicates that the inbound or outbound policy is being updated for the peer.
- **(c)** - indicates that the table entry is clearing.
- **(p)** - indicates that the neighbor ribout group membership change is pending or in progress
- **(s)** - indicates that the peer has negotiated restart, and the session is in a stale state.
- **(r)** - indicates that the peer is restarting the BGP4 connection, through restart.

Output field	Description
	<ul style="list-style-type: none"> <li>(^) - on the standby MP indicates that the peer is in the ESTABLISHED state and has received restart capability (in the primary MP).</li> <li>(&lt;) - indicates that the device is waiting to receive the "End of RIB" message the peer.</li> </ul>
Time	The time that has passed since the state last changed.
Accepted	The number of routes received from the neighbor that this installed in the BGP4+ route table. Usually, this number is lower than the RoutesRcvd number. The difference indicates that this filtered out some of the routes received in the UPDATE messages.
Filtered	<p>The routes or prefixes that have been filtered out.</p> <ul style="list-style-type: none"> <li>If soft reconfiguration is enabled, this field shows how many routes were filtered out (not placed in the BGP4+ route table) but retained in memory.</li> <li>If soft reconfiguration is not enabled, this field shows the number of BGP4+ routes that have been filtered out.</li> </ul>
Sent	The number of BGP4+ routes that the has sent to the neighbor.
ToSend	The number of routes the has queued to send to this neighbor.

**Examples** This example displays sample output from the **show ipv6 bgp summary** command.

```
device> show ipv6 bgp summary
```

```

BGP4 Summary
Router ID: 10.7.7.7   Local AS Number: 100
Confederation Identifier: not configured
Confederation Peers:
Maximum Number of IP ECMP Paths Supported for Load Sharing: 1
Number of Neighbors Configured: 1, UP: 0
Number of Routes Installed: 0
Number of Routes Advertising to All Neighbors: 0 (0 entries)
Number of Attribute Entries Installed: 0
'+': Data in InQueue '>': Data in OutQueue '-': Clearing
'*': Update Policy 'c': Group change 'p': Group change Pending
'r': Restarting 's': Stale '^': Up before Restart '<': EOR waiting
Neighbor Address   AS#      State   Time           Rt:Accepted  Filtered  Sent   ToSend
10:2::2           100     CONN    0h 9m 0s      0             0         0
0

```

#### History

Release version	Command history
5.9.00	The command was modified. Description codes were added to display output.

## show ipv6 dhcp-relay interface

Displays the IPv6 DHCP relay information for a specific interface.

**Syntax** `show ipv6 dhcp-relay interface`

**Modes** Privileged EXEC mode

**Command Output** The `show ipv6 dhcp-relay interface` command displays the following information:

Output field	Description
DHCPv6 Relay Information for <i>interface interface-type port-num</i>	The DHCPv6 relay information for the specific interface.
Destination	The configured destination IPv6 address.
OutgoingInterface	The interface on which the packet will be relayed if the destination relay address is a link local or multicast address.
Options	The current information about the DHCPv6 relay options for the interface.
Interface-Id	The interface ID option indicating whether the option is used.
Client-mac-address	Displays if the client MAC address is used or not.

**Examples** The following example displays the DHCPv6 Relay information for an interface.

```
device# show ipv6 dhcp-relay interface ethernet 4/1
DHCPv6 Relay Information for interface eth 4/1:
Destinations:
  Destination                OutgoingInterface
  2000::1                     NA
Options:
  Interface-Id: Yes          Remote-Id:Yes          Client-mac-address:Yes
Prefix Delegation Information:
  Current:0 Maximum:8000 AdminDistance:10
```

**History**

Release version	Command history
5.4	This command was introduced.
5.9	This command was modified.



## show ipv6 dhcp-relay options

Displays information about the relay options available to the prefixed delegates for a specific interface.

**Syntax** `show ipv6 dhcp-relay options`

**Modes** Privileged EXEC mode

**Command Output** The `show ipv6 dhcp-relay options` command displays the following information:

Output field	Description
Interface	The interface name.
Interface-Id	The interface ID option. Yes indicates the option is used; no indicates the option is not used.
Remote-Id	The remote ID option. Yes indicates the option is used; no indicates the option is not used.
Client-mac-address	The client MAC address option. Yes or No indicates if the option is used or not.

**Examples** The following example displays relay options information.

```
device# show ipv6 dhcp-relay options
DHCPv6 Relay Options Information:
Interface      Interface-Id      Remote-Id      Client-mac-address
eth 4/1        Yes               Yes            Yes
```

**History**

Release version	Command history
5.4	This command was introduced.
5.9	This command was modified.

## show ipv6 interface tunnel

Displays the IP addresses and unicast and multicast traffic counters for the specified IPv6 IPsec tunnel. This command cannot be used on IPv4 IPsec tunnels.

- Syntax** `show ipv6 interface tunnel num`
- Parameters** *num*  
Specifies the tunnel number.
- Modes** User EXEC mode
- Command Output** The `show interfaces tunnel` command displays the following information:

Output field	Description
Tunnel number	The number of the tunnel.
Tunnel source	The IP address of the interface that is configured as the source of the tunnel. IP packets are forwarded from this interface across the tunnel.
Tunnel destination	The IP address of the interface that is configured as the destination of the tunnel. IP packets forwarded from the tunnel source interface are received by this interface.
Tunnel mode	The specified tunnel mode for the tunnel. This indicates which version of IP ( IPv6 or IPv4) has been enabled on the tunnel interface.
<b>NOTE</b>	
The tunnel mode is always IPv6 when using this command (this command can only be used on IPv6 IPsec tunnels).	
Port name	The specified name of the port. If a name was not specified, the output shows no port name.
Internet address	The IP address of the port. This is not the IP address of the tunnel source or destination.
Tunnel TOS	The value to write into the ToS byte in the IP header of a tunnel packet (the carrier packet). The value ranges from 0 through 99, where 0 means a tunnel packet copies the ToS value from the packet being encapsulated (the passenger packet).
Tunnel TTL	The value to write into the TTL field in the IP header of a tunnel packet (the carrier packet). The value ranges from 0 through 255, where 0 means a tunnel packet copies the value from the packet being encapsulated (the passenger packet). The default value is 255.
Tunnel MTU	This maximum size allowable for IP packets entering the tunnel. Packets that exceed the value you specify (or the default) are sent back to the source. The default value is 1480 bytes.
Tunnel vrf	
Forwarding vrf	
Tunnel protection profile	The name of the IPsec profile used to encapsulate and encrypt the IP packets being transmitted by the tunnel interface. A tunnel profile defines a set of encapsulation and encryption methods used to secure IP packets.

Output field	Description
Tunnel packet statistics	<p>The following packet counts for <b>unicast</b> traffic on the tunnel:</p> <ul style="list-style-type: none"> <li>• <b>RxPkts:</b> The total number of IP packets received from the tunnel on the interface.</li> <li>• <b>TxPkts:</b> The total number of IP packets transmitted across the tunnel from the interface.</li> <li>• <b>RxBytes:</b> The total number of bytes received from the tunnel on the interface. (The total is for IP packets only.)</li> <li>• <b>TxBytes:</b> The total number of bytes transmitted across the tunnel from the interface. (The total is for IP packets only.)</li> </ul>
Tunnel multicast packet statistics	<p>The following packet counts for <b>multicast</b> traffic on the tunnel:</p> <ul style="list-style-type: none"> <li>• <b>RxMcPkts:</b> The total number of IP multicast packets received from the tunnel on the interface.</li> <li>• <b>TxMcPkts:</b> The total number of IP multicast packets transmitted across the tunnel from the interface.</li> </ul>

**Usage Guidelines** This command is restricted to showing data for IPv6 IPsec tunnels.

---

**NOTE**

If you want to view the same information for IPv4 IPsec tunnels, use the **show interfaces tunnel** command.

---

**Examples**

**History**

Release version	Command history
05.9.00	This command was introduced.

# show ipv6 ospf interface

Displays interface information for all or specific OSPFv3-enabled interfaces.

<b>Syntax</b>	<b>show ipv6 ospf interface</b> [ <b>brief</b> ] [ <b>ethernet</b> <i>slot/port</i> ] [ <b>loopback</b> <i>number</i> ] [ <b>tunnel</b> <i>number</i> ] [ <b>ve</b> <i>number</i> ]
<b>Parameters</b>	<p><b>brief</b> Displays brief summary about OSPFv3-enabled interfaces.</p> <p><b>ethernet</b> Specifies an Ethernet interface</p> <p style="padding-left: 20px;"><i>slot</i> Specifies a valid slot number.</p> <p style="padding-left: 20px;"><i>port</i> Specifies a valid port number.</p> <p><b>loopback</b> Specifies a loopback interface.</p> <p style="padding-left: 20px;"><i>port-number</i> Specifies the port number for the loopback interface.</p> <p><b>tunnel</b> Specifies a tunnel.</p> <p style="padding-left: 20px;"><i>number</i> Specifies a tunnel number.</p> <p><b>ve</b> Specifies a virtual Ethernet interface.</p> <p style="padding-left: 20px;"><i>vlan_id</i> Specifies the port number for the VE interface.</p>
<b>Modes</b>	User EXEC mode
<b>Usage Guidelines</b>	<p>Use the <b>brief</b> keyword to limit the display to the following fields:</p> <ul style="list-style-type: none"> <li>• Interface</li> <li>• Number of Interfaces</li> <li>• Area</li> <li>• Status</li> <li>• Type</li> <li>• Cost</li> <li>• State</li> <li>• Nbrs(F/C)</li> </ul>
<b>Command Output</b>	The <b>show ipv6 ospf interface</b> command displays the following information:

---

Output field	Description
Interface status	The status of the interface. Possible status includes the following: <ul style="list-style-type: none"> <li>• Up.</li> <li>• Down.</li> </ul>

---

Output field	Description
Type	The type of OSPFv3 circuit running on the interface. Possible types include the following: <ul style="list-style-type: none"> <li>• BROADCAST</li> <li>• POINT TO POINT UNKNOWN</li> <li>• POINT TO POINT</li> </ul>
IPv6 Address	The IPv6 address assigned to the interface.
Instance ID	An identifier for an instance of OSPFv3.
Router ID	The IPv4 address of the device. By default, the router ID is the IPv4 address configured on the lowest numbered loopback interface. If the device does not have a loopback interface, the default router ID is the lowest numbered IPv4 address configured on the device.
Area ID	The IPv4 address or numerical value of the area in which the interface belongs.
Cost	The overhead required to send a packet through the interface.
default	Shows whether or not the default passive state is set.
State	The state of the interface. Possible states include the following: <ul style="list-style-type: none"> <li>• DR - The interface is functioning as the Designated Router for OSPFv3.</li> <li>• BDR - The interface is functioning as the Backup Designated Router for OSPFv3.</li> <li>• Loopback - The interface is functioning as a loopback interface.</li> <li>• P2P - The interface is functioning as a point-to-point interface.</li> <li>• Passive - The interface is up but it does not take part in forming an adjacency.</li> <li>• Waiting - The interface is trying to determine the identity of the BDR for the network.</li> <li>• None - The interface does not take part in the OSPF interface state machine.</li> <li>• Down - The interface is unusable. No protocol traffic can be sent or received on such a interface.</li> <li>• DR other - The interface is a broadcast or NBMA network on which another router is selected to be the DR.</li> <li>• Active - The interface sends or receives all the OSPFv3 control packets, and forms the adjacency.</li> </ul>
Transmit delay	The amount of time, in seconds, it takes to transmit Link State Updates packets on the interface.
Priority	The priority used when selecting the DR and the BDR. If the priority is 0, the interface does not participate in the DR and BDR election.
Timer intervals	The interval, in seconds, of the hello-interval, dead-interval, and retransmit-interval timers.
DR	The router ID (IPv4 address) of the DR.
BDR	The router ID (IPv4 address) of the BDR.
Number of I/F scoped LSAs	The number of interface LSAs scoped for a specified area, AS, or link.

Output field	Description
DR Election	The number of times the DR election occurred.
Delayed LSA Ack	The number of the times the interface sent a delayed LSA acknowledgement.
Neighbor Count	The number of neighbors to which the interface is connected.
Adjacent Neighbor Count	The number of neighbors with which the interface has formed an active adjacency.
Neighbor	The router ID (IPv4 address) of the neighbor. This field also identifies the neighbor as a DR or BDR, if appropriate.
Interface statistics	The following statistics are provided for the interface: <ul style="list-style-type: none"> <li>Unknown - The number of Unknown packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Unknown packets.</li> <li>Hello - The number of Hello packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Hello packets.</li> <li>DbDesc - The number of Database Description packets transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received Database Description packets.</li> <li>LSReq - The number of link-state requests transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state requests.</li> <li>LSUpdate - The number of link-state updates transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state requests.</li> <li>LSAck - The number of link-state acknowledgements transmitted and received by the interface. Also, the total number of bytes associated with transmitted and received link-state acknowledgements.</li> </ul>

The **show ipv6 ospf interface brief** command displays the following information:

Output field	Description
Number of Interfaces	Number of OSPFv3-enabled interfaces.
Interface	The interface type, and the port number or number of the interface.
Area	The OSPF area configured on the interface.
Status	The status of the link and the protocol. Possible status include the following: <ul style="list-style-type: none"> <li>Up.</li> <li>Down.</li> </ul>
Type	The type of OSPFv3 circuit running on the interface. Possible types include the following: <ul style="list-style-type: none"> <li>BCST- Broadcast interface type</li> <li>P2P- Point-to-point interface type</li> <li>UNK- The interface type is not known at this time</li> </ul>

---

Output field	Description
Cost	The overhead required to send a packet across an interface.
State	<p>The state of the interface. Possible states include the following:</p> <ul style="list-style-type: none"><li>• DR - The interface is functioning as the Designated Router for OSPFv3.</li><li>• BDR - The interface is functioning as the Backup Designated Router for OSPFv3.</li><li>• Loopback - The interface is functioning as a loopback interface.</li><li>• P2P - The interface is functioning as a point-to-point interface.</li><li>• Passive - The interface is up but it does not take part in forming an adjacency.</li><li>• Waiting - The interface is trying to determine the identity of the BDR for the network.</li><li>• None - The interface does not take part in the OSPF interface state machine.</li><li>• Down - The interface is unusable. No protocol traffic can be sent or received on such a interface.</li><li>• DR other - The interface is a broadcast or NBMA network on which another router is selected to be the DR.</li></ul>
Nbrs (F/C)	The number of adjacent neighbor routers. The number to the left of the "/" are the neighbor routers that are fully adjacent and the number to the right represents all adjacent neighbor routers.

---

**Examples** This example show sample output from the **show ipv6 ospf interface** command when no arguments or keywords are used.

```
device> show ipv6 ospf interface
eth 1/3 is down, type BROADCAST
Interface is disabled
eth 1/8 is up, type BROADCAST
IPv6 Address:
  2001:db8:18:18:18::1/64
  2001:db8:18:18:18::/64
Instance ID 255, Router ID 10.1.1.1
Area ID 1, Cost 1
State Active(default passive) DR, Transmit Delay 1 sec, Priority 1
Timer intervals :
  Hello 10, Hello Jitter 10 Dead 40, Retransmit 5
Authentication: Enabled
KeyRolloverTime(sec): Configured: 30 Current: 0
KeyRolloverState: NotActive
Outbound: SPI:121212, ESP, SHA1
  Key:12345678901234567890123456789012345678901234567890
Inbound: SPI:121212, ESP, SHA1
  Key:12345678901234567890123456789012345678901234567890
DR:10.2.2.2 BDR:10.1.1.1 Number of I/F scoped LSAs is 2
DRElection: 1 times, DelayedLSAck: 83 times
Neighbor Count = 1, Adjacent Neighbor Count= 1
Neighbor:
  10.2.2.2 (DR)
Statistics of interface eth 1/8:
Type      tx      rx      tx-byte  rx-byte
Unknown  0       0       0         0
Hello    1415   1408   56592    56320
DbDesc   3       3       804      804
LSReq    1       1       28       28
LSUpdate 193    121    15616   9720
LSAck    85     109    4840    4924
OSPF messages dropped,no authentication: 0
eth 2/2 is up, type POINT-TO-POINT
IPv6 Address:
  2001:db8:22:22::1/64
  2001:db8:22:22::/64
  2001:db8:202:202::1/64
  2001:db8:202:202::/64
Instance ID 0, Router ID 10.1.1.1
Area ID 100, Cost 1
State P2P, Transmit Delay 1 sec, Priority 1
Timer intervals:
  Hello 10, Hello Jitter 10 Dead 40, Retransmit 5
Authentication: Enabled
KeyRolloverTime(sec): Configured: 30 Current: 0
KeyRolloverState: NotActive
Outbound: SPI:11022, ESP, SHA1
  Key:12345678901234567890123456789012345678901234567890
Inbound: SPI:11022, ESP, SHA1
  Key:12345678901234567890123456789012345678901234567890
DR:0.0.0.0 BDR:0.0.0.0 Number of I/F scoped LSAs is 2
.....
```

This example shows sample output from the **show ipv6 ospf interface** command when the **brief** keyword is used.

```
device> show ipv6 ospf interface brief
Number of Interfaces is 3

Interface   Area   Status  Type  Cost  State  Nbrs (F/C)
eth 1/1     1      up      BCST  1     BDR    0/1
eth 2/1     1      up      BCST  1     DR     0/0
loopback 1   1      up      BCST  1     Loopback 0/0
```

**History**

Release version	Command history
5.9.00	The <b>Number of Interfaces</b> field was added to the <b>show ipv6 ospf interface brief</b> field displays.



# show ipv6 vrrp

Displays information about IPv6 Virtual Router Redundancy Protocol (VRRP) sessions.

**Syntax** `show ipv6 vrrp [ brief ]`

`show ipv6 vrrp [ ethernet slot/port | ve num ]`

`show ipv6 vrrp [ statistics [ ethernet slot/port | ve num ] ]`

`show ipv6 vrrp [ ve num [ vrid VRID ] ]`

`show ipv6 vrrp [ vrid VRID [ ethernet slot/port | ve num ] ]`

**Parameters** **brief**

Displays summary information about the IPv6 VRRP session.

**ethernet slot port**

Displays IPv6 VRRP information only for the specified Ethernet port.

**statistics**

Displays statistical information about the IPv6 VRRP session.

**ve num**

Displays IPv6 VRRP information only for the specified virtual Ethernet port.

**vrid VRID**

Displays IPv6 VRRP information only for the specified virtual router ID (VRID).

**Modes** User EXEC mode

**Usage Guidelines** This command can be entered in any mode. This command supports IPv6 VRRP, to display information about VRRP Extended (VRRP-E) sessions, use the **show ipv6 vrrp-extended** command.

**Command Output** The following is a partial list of output field descriptions for the **show ipv6 vrrp** command.

Output field	Description
Total number of VRRP routers defined	The total number of virtual routers configured and currently running on this Brocade device. For example, if the Brocade device is running VRRP-E, the total applies only to VRRP-E routers.
Interface	The interface on which VRRP is configured. If VRRP is configured on multiple interfaces, information for each interface is listed separately.
VRID	The ID of the virtual router configured on this interface. If multiple virtual routers are configured on the interface, information for each virtual router is listed in a separate row.

Output field	Description
state	<p>This Brocade device's VRRP state for the virtual router. The state can be one of the following:</p> <ul style="list-style-type: none"> <li>init—The virtual router is not enabled (activated). If the state remains init after you activate the virtual router, make sure that the virtual router is also configured on the other routers and that the routers can communicate with each other.</li> </ul> <p>If the state is init and the mode is incomplete, make sure you have specified the IP address for the virtual router.</p> <ul style="list-style-type: none"> <li>backup—This Brocade device is a backup for the virtual router.</li> <li>master—This Brocade device is the master for the virtual router.</li> </ul>
current priority	The current VRRP priority of this Brocade device for the virtual router.
preempt-mode	Whether the backup preempt mode is enabled. If the backup preempt mode is enabled, this field contains a "true". If the mode is disabled, this field is blank.

**Examples** The following example displays IPv6 VRRP session information in detail.

```
device(config)# show ipv6 vrrp

Total number of VRRP routers defined: 1
Interface 1/3
-----
auth-type no authentication
VRID 13 (index 2)
interface 1/3
state master
administrative-status enabled
version v3
mode non-owner(backup)
virtual mac 0000.5e00.0217
priority 100
current priority 100
track-priority 1
hello-interval 1000 ms
backup hello-interval 60000 ms
advertise backup disabled
dead-interval 3000 ms
preempt-mode true
ipv6-address 3013::1
next hello sent in 700 ms
short-path-forwarding disabled
```

The following example displays IPv6 VRRP statistical information.

```
device# show ipv6 vrrp statistics

Global IPv6 VRRP statistics
-----
- received vrrp packets with checksum errors = 0
- received vrrp packets with invalid version number = 0
- received vrrp packets with unknown or inactive vrid = 0
Interface 1/3
-----
VRID 13
- number of transitions to backup state = 1
- number of transitions to master state = 1
- total number of vrrp packets received = 0
. received backup advertisements = 19
. received packets with zero priority = 0
. received packets with invalid type = 0
. received packets with invalid authentication type = 0
. received packets with authentication type mismatch = 0
. received packets with authentication failures = 0
. received packets dropped by owner = 0
. received packets with ttl errors = 0
. received packets with ipv6 address mismatch = 0
. received packets with advertisement interval mismatch = 0
. received packets with invalid length = 0
- total number of vrrp packets sent = 1175
. sent backup advertisements = 0
. sent packets with zero priority = 0
- received neighbor solicitation packets dropped = 0
- received proxy neighbor solicitation packets dropped = 0
- received ipv6 packets dropped = 0
```

The following example displays IPv6 VRRP configuration information about VRID 1.

```
device# show ipv6 vrrp vrid 1

Interface 1/1
-----
auth-type no authentication
VRID 1 (index 1)
interface 1/1
state master
administrative-status enabled
version v3
mode non-owner(backup)
virtual mac dddd.eeee.ffff (configured)
priority 100
current priority 100
track-priority 1
hello-interval 1000 ms
backup hello-interval 60000 ms
advertise backup disabled
dead-interval 3600 ms
preempt-mode true
ipv6 address 10:20:1::100
next hello sent in 400 ms
```

The following example displays an auto-generated IPv6 virtual link-local address used in the VRRPv3 VRID 1 instance.

---

**NOTE**

This example is applicable only to the auto-generation of an IPv6 virtual link-local address.

---

```
device# show ipv6 vrrp vrid 1

VRID 1 (index 1)
 interface 1/1
  state master
  administrative-status enabled
  version v3
  mode owner
  virtual mac 0000.5e00.0101
  virtual link-local fe80::200:5eff:fe00:201
  priority 255
  current priority 255
  track-priority 2
  hello-interval 1000 ms
  backup hello-interval 60000 ms
  number of configured virtual address 2
  ipv6-address 1:2:45::2
  ipv6-address 1:2:46::2
  next hello sent in 300 ms
  Track MCT-VPLS-State: Disable
```

**History**

Release version	Command history
5.9.00	This command was modified to display an auto-generated IPv6 virtual link-local address.

# show ipv6 vrrp-extended

Displays information about IPv6 Virtual Router Redundancy Protocol Extended (VRRP-E) sessions.

**Syntax** `show ipv6 vrrp-extended [ brief ]`

`show ipv6 vrrp-extended [ ethernet slot/port | ve num ]`

`show ipv6 vrrp-extended [ statistics [ ethernet slot/port | ve num ] ]`

`show ipv6 vrrp-extended [ ve num [ vrid VRID ] ]`

`show ipv6 vrrp-extended [ vrid VRID [ ethernet slot/port | ve num ] ]`

**Parameters**

**brief** Displays summary information about the IPv6 VRRP-E session.

**ethernet slot/port** Displays IPv6 VRRP-E information only for the specified port.

**statistics** Displays statistical information about the IPv6 VRRP-E session.

**ve num** Displays IPv6 VRRP-E information only for the specified virtual Ethernet port.

**vrid VRID** Displays IPv4 VRRP-E information only for the specified virtual-group ID.

**Modes** User EXEC mode

**Usage Guidelines** Use this command to display information about IPv6 VRRP-E sessions, either in summary or full-detail format. You can also specify a virtual group or interface for which to display output.

This command supports IPv6 VRRP-E. You can modify or redirect the displayed information by using the default Linux tokens (|, >).

**Command Output** The `show ipv6 vrrp-extended` command displays the following information:

Output field	Description
Total number of VRRP-E routers defined	The total number of virtual routers configured on this Brocade device.
<p><b>NOTE</b></p> <p>The total applies only to the protocol the Brocade device is running. For example, if the Brocade device is running VRRP-E, the total applies only to VRRP-E routers.</p>	
Interface	The interface on which VRRP-E is configured. If VRRP-E is configured on multiple interfaces, information for each interface is listed separately.
VRID	The ID of the virtual router configured on this interface. If multiple virtual routers are configured on the interface, information for each virtual router is listed in a separate row.
Current Priority	The current VRRP-E priority of this Brocade device for the virtual router.

Output field	Description
Flags	<p>Whether the backup preempt mode is enabled. If the backup preempt mode is enabled, this field contains a "P". If the mode is disabled, this field is blank.</p> <ul style="list-style-type: none"> <li>• P:Preempt 2:V2 3:V3</li> <li>• 2: implies VRRP Version2</li> <li>• 3: implies VRRP Version3</li> </ul>
Short-Path-Fwd	<p>This Brocade device's VRRP state for the virtual router. The state can be one of the following:</p> <ul style="list-style-type: none"> <li>• Init—The virtual router is not enabled (activated). If the state remains Init after you activate the virtual router, make sure that the virtual router is also configured on the other routers and that the routers can communicate with each other.</li> </ul>
<p><b>NOTE</b></p> <p>If the state is Init and the mode is incomplete, make sure you have specified the IP address for the virtual router.</p>	
	<ul style="list-style-type: none"> <li>• Backup—This Brocade device is a backup for the virtual router.</li> <li>• Master—This Brocade device is the master for the virtual router.</li> </ul>
Master IP Address	The IPv6 address of the router interface that is currently the Master for the virtual router.
Backup IP Address	The IPv6 addresses of the router interfaces that are currently backups for the virtual router.
Virtual IP Address	The virtual IPv6 address that is being backed up by the virtual router.

**Examples** The following example displays summary information for an IPv6 VRRP-E session.

```
device(config)# show ipv6 vrrp-extended brief

Total number of VRRP routers defined: 1
Flags Codes - P:Preempt 2:V2 3:V3 S:Short-Path-Fwd
Intf VRID CurrPrio Flags State Master-IPv6 Backup-IPv6 Virtual-IPv6
Address Address Address
-----
1/3 2 100 P3- Master Local 3013::2 3013::99
```

The following example displays detailed IPv6 VRRP-E configuration information about VRID 1.

```
device#show ipv6 vrrp-extended vrid 1

Interface 1/1
-----
auth-type md5-authentication
VRID 1 (index 1)
interface 1/1
state master
administrative-status enabled
mode non-owner(backup)
virtual mac dddd.eeee.ffff (configured)
priority 100
current priority 100
track-priority 5
hello-interval 1 sec
backup hello-interval 60 sec
advertise backup disabled
dead-interval 0 ms
preempt-mode true
virtual ipv6 address 10:20:1::100
```

The following example displays group member information for the VRRP-E scaling feature for VRID 1. Only partial output is displayed.

```
device# show ipv6 vrrp-extended ve 100 vrid 1

VRID 2 (index 2)
 interface v100
  state backup
  .
  .
  .
 group-member count 3
 group-members
  ve 100 vrid 2
  ve 100 vrid 3
  ve 100 vrid 4
```

The following example displays group master information for the VRRP-E scaling feature for interface ve 100 and VRID 2. Only partial output is displayed.

```
device# show ipv6 vrrp-extended ve 100 vrid 2

VRID 2 (index 2)
 interface v100
  state backup
  .
  .
  .
 group-master ve 100 vrid 1
```

#### History

Release version	Command history
05.8.00	This command was modified to add new output for the VRRP-E scaling and VRRP-E multiple IP addresses features.

## show isis

Displays the status of the IS-IS enabled interfaces.

**Syntax** `show isis [ config | counts | database [ detail | level1 | level2 | summary ] | hostname | interface [ brief | ethernet | loopback | pos | ipv6 | tunnel | ve ] | neighbor [ detail ] | routes ip-addr | shortcut [ detail | lsp ] | spf-log [ detail | level1 | level2 ] | traffic ]`

<b>Parameters</b>	<b>config</b>	Displays integrated IS-IS configuration.
	<b>counts</b>	Displays integrated IS-IS counters.
	<b>database</b>	Displays integrated IS-IS database.
	<b>detail</b>	Displays detailed IS-IS link state database information.
	<b>level1</b>	Displays IS-IS level-1 link state database.
	<b>level2</b>	Displays IS-IS level-2 link state database.
	<b>summary</b>	Displays IS-IS link state database summary.
	<b>hostname</b>	Displays integrated IS-IS dynamic hostname mapping.
	<b>interface</b>	Displays integrated IS-IS interface information.
	<b>brief</b>	Displays IS-IS interface information in brief mode.
	<b>ethernet</b>	Displays Ethernet port.
	<b>loopback</b>	Displays loopback interface.
	<b>pos</b>	Displays POS port.
	<b>tunnel</b>	Displays tunnel port.
	<b>ve</b>	Displays virtual port.
	<b>ipv6</b>	Displays IS-IS IPv6 integrated SPF logging.
	<b>spf-log</b>	Displays integrated IS-IS IPv6 SPF logging.
	<b>neighbor</b>	Displays integrated IS-IS neighbor list.
	<b>detail</b>	Displays detailed information.
	<b>routes <i>ip_addr</i></b>	



<b>shortcut</b>	Displays integrated IS-IS route by IP address.
<b>detail</b>	Displays integrated IS-IS shortcut information.
<b>lsp</b>	Displays IS-IS shortcut detail information.
<b>spf-log</b>	Displays IS-IS shortcut.
<b>detail</b>	Displays integrated IS-IS SPF logging.
<b>level1</b>	Displays IS-IS SPF log detail information.
<b>level2</b>	Displays IS-IS level1 SPF log.
<b>traffic</b>	Displays IS-IS level 2 SPF log.
	Displays IS-IS traffic counts

**Modes** User EXEC mode

**Usage Guidelines** Use the **no** form of this command to disable this feature.  
This command operates in all modes.

**Command Output** The **show isis database summary** command shows the following information:

Output field	Description
Number of LSPs	Total number of LSPs in database (includes those in the loading state).
Number of LSPs loading	Number of LSPs pending a full LSP update. This value is non-zero during adjacency formation.
Number of LSP fragments	The number of LSPs with a non-zero LSP number (a fragment of an LSP).
Number of Pseudo LSPs	The number of pseudo LSPs.
Number of Pseudo LSP fragments	The number of pseudo LSPs with a non-zero LSP number (a fragment of an LSP).
Number of My LSPs	Total number of LSPs originated by this router.
Number of My LSP fragments	The number of LSPs originated by this router with a non-zero LSP number (a fragment of an LSP).
Number of My Pseudo LSPs	The number of pseudo LSPs originated by this router.
Number of My Pseudo LSP fragments	The number of pseudo LSPs originated by this router with a non-zero LSP number (a fragment of an LSP).
Sum of LSPs Checksum	Total checksum of all LSPs in database (including those in a loading state). This number should be the same across ISIS routers during periods of network stability.

The **show isis shortcut detail** command shows the following information:

Output field	Description
Name	The name of the IS-IS shortcut.
To	This line contains the following information: <ul style="list-style-type: none"> <li>The LSP endpoint address.</li> <li>Whether or not this LSP is used in the SPF calculation. This field displays either 'Used by SPF' or 'Not used by SPF'.</li> <li>Whether or not the announce metric is used.</li> </ul>
LSP metric	This field displays the following information: <ul style="list-style-type: none"> <li>The metric value configured at the MPLS LSP configuration level of the CLI.</li> <li>A dash (-), which denotes that the LSP metric is not configured.</li> <li>(Ignored), which denotes that the ignore LSP metric feature is enabled.</li> </ul>
Relative metric	This field displays one of the following: <ul style="list-style-type: none"> <li>The relative metric value configured with the shortcut IS-IS command.</li> <li>A dash (-), which denoted that the announce metric is not configured.</li> </ul>
Announce metric	This field displays the metric value configured with the shortcut IS-IS command.
IS-IS System ID	The matching IS-IS system ID for the LSP endpoint.
Not used by the SPF due to	When the tunnel is not used by SPF, one of the following reasons is noted: <ul style="list-style-type: none"> <li>Not used by the SPF due to no IS-IS system IS-IS mapping to router-ID. No mapping exists between the tunnel destination and the IS-IS system ID.</li> <li>Not used by the SPF due to IS-IS native route to the LSP tunnel designation. There is no IS-IS native route to the LSP tunnel destination.</li> <li>Not used by SPF due to an IS-IS alternate path preferred to this tunnel. An alternate path has a better metric than the LSP tunnel.</li> </ul>
Not announced due to configuration	Indicates that announce is not configured.
Last notification from MPLS received	The last time (in hours, minutes, seconds) a status notification was received from MPLS.

**Examples** The following example shows the output of the **show isis** command with the default-link-metric configured:

```
device#sh isis
....
Default redistribution metric: 0
Default link metric for level-1: 33
Default link metric for level-2: 5
Protocol Routes redistributed into IS-IS:
....
```

The following example shows the output of the **show isis database summary** command:

```
device# show isis database summary
IS-IS Level-1 Link State Database Summary
Number of LSPs : 2
Number of LSPs loading : 0
Number of LSP fragments : 0
Number of Pseudo LSPs : 1
Number of Pseudo LSP fragments : 0
Number of My LSPs : 1
Number of My LSP fragments : 0
Number of My Pseudo LSPs : 0
Number of My Pseudo LSP fragments : 0
Sum of LSPs Checksum : 0x00018004
IS-IS Level-2 Link State Database Summary
Number of LSPs : 2
Number of LSPs loading : 0
Number of LSP fragments : 0
Number of Pseudo LSPs : 1
Number of Pseudo LSP fragments : 0
Number of My LSPs : 1
Number of My LSP fragments : 0
Destination addresses The rows of information below the IP address row are the
destinations
advertised by the LSP. The Brocade device can reach these destinations
by using the IP address listed above as the next hop.
Each destination entry contains the following information:
• Metric - The value of the default metric, which is the IS-IS cost of
using the IP address above as the next hop to reach this
destination.
• Device type - The device type at the destination. The type can be
one of the following:
• End System - The device is an ES.
• IP-Internal - The device is an ES within the current area. The
IP address and subnet mask are listed.
• IS - The device is another IS. The NET (NSAP address) is
listed.
• IP-Extended - Same as IP-Internal, except the device uses the
extended TLV fields described in draft-ietf-isis-traffic-02.txt to
carry the information.
• IS-Extended - Same as IS, except the device uses the
extended TLV fields described in draft-ietf-isis-traffic-02.txt to
carry the information.
Flooding to <num> interface: Identifies the number of interfaces on which the
specific LSP entry will
be flooded and identifies the interfaces.
Acking to <num> interface: Identifies the number of interfaces on which the specific
LSP entry will
be acknowledged and identifies the interfaces.
TABLE 219 IS-IS detailed LSP database information (Continued)
This field... Displays...

Number of My Pseudo LSPs : 0
Number of My Pseudo LSP fragments : 0
Sum of LSPs Checksum : 0x00019775
```

The following example shows the output of the **show isis shortcut** command:

```
device# show isis shortcuts
Configured: 3, Up: 2, Announced: 1
Name      To          Metric      Announce  Tunnel
          (SPF/Announce)
lsp tomu2  10.4.1.1    10/-        No         tn11
lsp tomu3  10.3.1.1    -/-         Yes        tn12
lsp toolong 10.20.1.1  10/10       Yes        tn13
toreachmu3
```

## History

Release version	Command history
5.4.00	A new keyword option <b>ignore-lsp-metric</b> is added to the existing shortcut command under LSP configuration mode.
5.7.00	The <b>show isis</b> command output is modified to reflect the default-link-metric configured.

## show isis shortcut

Displays information about all IS-IS shortcuts configured on the device.

**Syntax** `show isis shortcut [ detail | lsp lsp_name ]`

**Parameters** **detail**

Displays IS-IS shortcut detail information.

**lsp *lsp\_name***

Displays specified LS PIS-IS shortcut.

**Modes** User EXEC mode.

**Usage Guidelines** Only LSPs that are UP (administratively and operationally enabled in the MPLS domain) are kept in the database and displayed in the show command outputs. LSPs that are down are not kept in the database and are not displayed in the command outputs.

This command also operates in all modes.

**Command Output** The `show isis shortcut` command displays the following information:

Output field	Description
Configured	The number of IS-IS shortcuts configured.
Up	The number of IS-IS shortcuts that are UP.
Announced	The number of IS-IS shortcuts that are advertised.
Name	The name of the IS-IS shortcut. When the name is longer than 11 characters, it wraps to the next line.
To	The LSP endpoint address.
Metric (SPF or Announce)	<p>The metric used in the SPF calculation or the metric used in the advertisement of the IS adjacency TLV.</p> <p>The SPF metric can be one of the following:</p> <ul style="list-style-type: none"> <li>• The metric configured at the MPLS LSP configuration level.</li> <li>• The native IGP metric plus or minus (+ or -) the relative metric configured with the <b>shortcuts isis</b> command.</li> <li>• The native IGP metric</li> <li>• A dash (-) denotes that the tunnel is not used in SPF calculations.</li> </ul> <p>The Announce metric can be one of the following:</p> <ul style="list-style-type: none"> <li>• 10 (the default announce metric)</li> <li>• The metric configured with the <b>announce-metric</b> keyword</li> <li>• A dash (-) denotes that the tunnel is not used in the IS adjacency TLV advertisement.</li> </ul>

Output field	Description
Announce	Indicates whether or not IS-IS shortcuts are advertised: <ul style="list-style-type: none"> <li>• Yes - IS-IS shortcuts are advertised</li> <li>• No - IS-IS shortcuts are not advertised.</li> </ul>
Tunnel Intf	The tunnel index of the LSP. This is assigned by MPLS whenever an LSP is created.

**Examples** The following example shows the output of the **show isis shortcut** command.

```
device# show isis shortcut
Configured: 3, Up: 2, Announced: 1
Name      To          Metric      Announce  Tunnel
          (SPF/Announce)
lsp tomu2  10.4.1.1    10/-        No        tn11
lsp tomu3  10.3.1.1    -/-         Yes       tn12
lsp toolong 10.20.1.1  10/10       Yes       tn13
toreachmu3
```

The following example shows the **show isis shortcut detail** command.

```
device# show isis shortcut lsp tomu2 detail
lsp tomu2
  To 10.1.1.1, Used by SPF (10), Not Announced
  LSP metric: 10, Relative metric: -, Announce metric: -
  ISIS System Id for 10.4.1.1. is mu2.00-00
  Not announced due to configuration
  Last notification from MPLS received 0hhm35s ago.
```

## show macsec ethernet

Displays status information for the designated MACsec interface.

**Syntax** `show macsec ethernet slot/port`

**Parameters** `slot/port`

Interface for which MACsec status information is to be displayed. The interface is designated slot on the device and interface on the slot.

**Modes** User EXEC mode

**Usage Guidelines** It is recommended that you use the **clear macsec ethernet** command to clear previous results.

**Examples** The following code sample shows details for ethernet interface 1/1.

```
device(config)#show macsec ethernet 1/1

Transmit SC
-----
SC state           : Transmitting

SA[0] :
SA state          : Transmitting
Next PN          : 94a16300

Receive SC
-----
SCstate           : Receiving

SA[0] :
SA State          : Receiving
Next PN          : 96a32071
```

**History**

---

Release version	Command history
5.8.00	This command was introduced.

---

## show macsec statistics ethernet

Displays status information and secure channel statistics for the designated MACsec interface.

**Syntax** `show macsec statistics ethernet slot / port`

**Parameters** `slot / port`

Interface for which MACsec status information is to be displayed. The interface is designated slot on the device and interface on the slot.

**Modes** User EXEC mode

**Usage Guidelines** It is recommended that you use the `clear macsec ethernet` command to clear previous results for the `show macsec ethernet` command before re-executing it.

**Examples** The following code sample shows details for ethernet interface 1/1. The interface is verifying MACsec frames and is providing strict replay protection.

```

Brocade(config)#show macsec statistics ethernet 1/1
Interface statistics
-----
rx Untagged Pkts      : 3          tx Untagged Pkts      :
0
rx Notagged Pkts     : 0          tx Too long Pkts     : 0
rx Bad Tag Pkts      : 0
rx Unknown SCI Pkts  : 0
rx No SCI Pkts       : 0
rx Overrun Pkts      : 0

Transmit Secure Channels
-----

SC Statistics
Protected Pkts       : 0          Protected Octets      :
0
Encrypted Pkts       : 3          Encrypted Octets      :
144

SA[0] Statistics - In use
Protected Pkts       : 3
Encrypted Pkts       : 3

SA[1] Statistics
Protected Pkts       : 0
Encrypted Pkts       : 0

SA[2] Statistics
Protected Pkts       : 0
Encrypted Pkts       : 0

SA[3] Statistics
Protected Pkts       : 0
Encrypted Pkts       : 0

Receive Secure Channels
-----

SC Statistics
OK Pkts              : 0          Not Valid Pkts       :
0
Unchecked Pkts       : 0          Not using SA Pkts    :
0
Delayed Pkts         : 0          Unused SA Pkts       :
0
Late Pkts            : 0          Validated Octets     :
0
Invalid Pkts         : 0          Decrypted Octets     :

SA[0] Statistics - In use
OK Pkts              : 0          Invalid Pkts         :
0
Not using SA Pkts    : 0          Unused SA Pkts       :

SA[1] Statistics
OK Pkts              : 0          Invalid Pkts         :
0
Not using SA Pkts    : 0          Unused SA Pkts       :

SA[2] Statistics
OK Pkts              : 0          Invalid Pkts         :
0
Not using SA Pkts    : 0          Unused SA Pkts       :

```



0

```
SA[3] Statistics
  OK Pkts           : 0           Invalid Pkts       :
0  Not using SA Pkts : 0           Unused SA Pkts     : 0
```

**History**

<b>Release version</b>	<b>Command history</b>
5.8.00	This command was introduced.

# show memory histogram

Displays task memory usage information.

**Syntax** `show memory histogram [ pool pool-id | below threshold-value | trace taskname ]`

**Parameters** `pool pool-id`

Specifies the display of memory histogram information for a specific memory pool. The valid range is 0-3, where "0" = OS, "1" = Shared, "2" = Global and "3" = User Private.

`below threshold-value`

Specifies the display of memory histogram information when available memory falls below the specified percentage (5, 10 or 20 percent).

`trace taskname`

Specifies the display of high CPU condition task traces.

**Modes** User EXEC mode

**Examples** The following example displays memory histogram information.

```
device# show memory histogram
HISTOGRAM MEMORY SEQUENCE INFO
-----
DURATION      : 60 s
SEQ IDX       : 1
TIME          : 2012.07.10-11:14:08.539
AVAIL MEM     : below 5 %
-----
POOL          Total Memory      Used Memory Available Memory
              (bytes)           (bytes)           (bytes)
-----
Global        2855272448        2843262976        12009472
-----
Task Name     Alloc-Number    Alloc-Size (bytes)
-----
main          1355             28486529
itc           4                 645
tmr           63             10173
ip_rx         425             396453
scp           748             17995881
lpagent       63             31309
console       101             3515673
vlan          44             5814177
mac_mgr       40             2305485
mrp           26             8541
vsrp          28             8557
erp           28             8557
mxrp          26             7527
snms          192             188337
rtm           98             33724605
rtm6          109             1918717
ip_tx         151             1274437
rip           70             323733
ospf_msg_task 17             7453
telnet_0      28             7689
telnet_1      29             7817
-----
```

**History**

Release	Command History
5.5.00	This command was introduced.

## show metro mp-ulp-queue

Displays priority information about management processor virtual line card (MP-VLP) queues on Brocade NetIron CER Series devices.

**Syntax** `show metro mp-ulp-queue`

**Modes** Privileged EXEC mode

**Usage Guidelines** Use this command to view statistics about messages from the MP are that are queued in the VLP to dequeue.

---

### NOTE

If the Dequeue Time is less than 1 millisecond, it is not recorded in the **show metro mp-ulp-queue** statistics. The corresponding timestamp is also not recorded. The initial timestamp is shown as "0000.00.00-00:00:00.000".

---

**Command Output** The **show metro mp-ulp-queue** command displays the following information:

Output field	Description
MP => VLP Queue	The queue priority: high, medium, or low.
Queue Size	The maximum amount of packet counts that the queue can handle at a given time.
Total Pkt Count	The total count of messages queued in each queue.
Current Pkt Count	The count of messages queued at a specific moment in each queue.
Pkt High WM	The maximum messages reached in the queue at any point of time.
Pkt drop Count	The amount of messages that were dropped because the queue was full.
Dequeue High WM(msec)	The longest period of time, in milliseconds, that a message remained in that queue.
Timestamp Pkt High WM(High)	The timestamp for the time when the high water mark for the number of messages in the high priority queue is reached.
Timestamp Pkt High WM(Medium)	The timestamp for the time when the high water mark for the number of messages in the medium priority queue is reached.
Timestamp Pkt High WM(Low)	The timestamp for the time when the high water mark for the number of messages in the low priority queue is reached.
Timestamp Dequeue Time HWM(High)	The timestamp for the time when the most delay is observed in the high priority queue.
Timestamp Dequeue Time HWM(Medium)	The timestamp for the time when the most delay is observed in the medium priority queue.

Output field	Description
Timestamp Dequeue Time HWM(Low)	The timestamp for the time when the most delay is observed in the low priority queue.

**Examples** This example shows sample output from the **show metro mp-ulp-queue** command. Three MP-VLP queues are shown with priority High, Medium and Low. The messages from the MP are queued in these queues for the VLP to dequeue.

```
LP-1# show metro mp-ulp-queue

MP => VLP Queue      :      High      Medium      Low
Queue Size          :      2000      2000      2000
Total Pkt Count     :      2160279    0      61210672
Current Pkt Count   :      0      0      0
Pkt High WM        :      13      0      1992
Pkt drop count     :      0      0      0
Dequeue Time HWM(msec):      12000    0      12675

Timestamp Pkt High WM(High) : [      13]: 2015.02.25-08:07:16.533
Timestamp Pkt High WM(Medium): [      0]: 0000.00.00-00:00:00.000
Timestamp Pkt High WM(Low) : [     1992]: 2015.02.25-08:07:17.223

Timestamp Dequeue Time HWM(High) : [     12000]: 2015.02.25-08:07:17.230
Timestamp Dequeue Time HWM(Medium): [      0]: 0000.00.00-00:00:00.000
Timestamp Dequeue Time HWM(Low) : [     12675]: 2015.02.25-08:07:17.800
```

This example shows sample output from the **show metro mp-ulp-queue** command after statistics have been cleared using the **clear metro mp-ulp-queue** command.

```
LP-1# show metro mp-ulp-queue

MP => VLP Queue      :      High      Medium      Low
Queue Size          :      2000      2000      2000
Total Pkt Count     :      0      0      0
Current Pkt Count   :      0      0      0
Pkt High WM        :      0      0      0
Pkt drop count     :      0      0      0
Dequeue Time HWM(msec):      0      0      0

Timestamp Pkt High WM(High) : [      0]: 0000.00.00-00:00:00.000
Timestamp Pkt High WM(Medium): [      0]: 0000.00.00-00:00:00.000
Timestamp Pkt High WM(Low) : [      0]: 0000.00.00-00:00:00.000

Timestamp Dequeue Time HWM(High) : [      0]: 0000.00.00-00:00:00.000
Timestamp Dequeue Time HWM(Medium): [      0]: 0000.00.00-00:00:00.000
Timestamp Dequeue Time HWM(Low) : [      0]: 0000.00.00-00:00:00.000
```

**History**

Release version	Command history
5.8.00a	This command was introduced.

## show mmrp

Displays Multiple MAC Registration Protocol (MMRP) information.

**Syntax** `show mmrp [ ethernet slot/port [ vlan vlan-id ] ]`

**Parameters** `ethernet slot port`

Displays information for a specific Ethernet port.

`vlan vlan-id`

Displays information for a specific virtual LAN (VLAN).

**Modes** User EXEC mode

**Usage Guidelines** MMRP provides a mechanism for end-stations and bridges to dynamically register or declare group membership for individual MAC addresses to bridges attached in the same LAN or VLAN.

Use this command without any options to review MMRP information for all ports and VLANs. Use the optional **ethernet** and **vlan** keywords to display specific information about interfaces and VLANs that are registered as MMRP members.

**Examples** The following example shows MMRP information for Ethernet interface 1/1.

```
device> show mmrp ethernet 1/1
-----
MMRP Status:           Enabled
Join-timer(in ms):    500
Leave-timer(in ms):    1600
Leaveall-timer(in ms): 10000
Include-vlan:         100,200,300-500,666
P2p:                  Yes
-----
Port   Vlan   Mac-count
-----
1/1    100    3
1/1    200    1
```

The following example shows MMRP information for VLAN 100.

```
device> show mmrp ethernet 1/1 vlan 100
-----
MMRP Status:           Enabled
Join-timer(in ms):    500
Leave-timer(in ms):    1600
Leaveall-timer(in ms): 10000
Include-vlan:         100,200,300-500,666
P2p:                  Yes
-----
Port   Vlan   Mac-count
-----
1/1    100    3
```

## show mmrp attributes

Displays Multiple MAC Registration Protocol (MMRP) attributes.

**Syntax** `show mmrp attributes [ ethernet slot/port [ vlan vlan-id ] ]`

**Parameters** `ethernet slot port`

Displays information for a specific Ethernet port.

`vlan vlan-id`

Displays information for a specific virtual LAN (VLAN).

**Modes** User EXEC mode

**Usage Guidelines** MMRP provides a mechanism for end-stations and bridges to dynamically register or declare group membership for individual MAC addresses to bridges attached in the same LAN or VLAN.

Use this command to review the addresses that are attached to various ports (and optionally, VLANs) and determine the registration state and applicant status. If no keyword options are used, information about all interfaces and VLANs that are registered as MMRP members is displayed.

**Examples** The following example displays the MMRP registered member states.

```
device> show mmrp attributes
```

Port	Vlan	Mac-address	Registrar State	Registrar Mgmt	Applicant State
1/1	100	011e.8300.3001	IN	Fixed	Quiet Active
1/5	100	011e.8300.3001	LV	Normal	Quiet Active
1/5	100	011e.8300.3001	MT	Normal	Quiet Active
1/1	200	011e.8300.3002	IN	Fixed	Quiet Active

The following example displays the MMRP information for Ethernet interface 1/1.

```
device> show mmrp attributes ethernet 1/1
```

Port	Vlan	Mac-address	Registrar State	Registrar Mgmt	Applicant State
1/1	100	011e.8300.3001	IN	Fixed	Quiet Active
1/1	200	011e.8300.3002	IN	Fixed	Quiet Active

The following example displays the MMRP information for VLAN 100.

```
device> show mmrp attributes ethernet 1/1 vlan 100
```

Port	Vlan	Mac-address	Registrar State	Registrar Mgmt	Applicant State
1/1	100	011e.8300.3001	IN	Fixed	Quiet Active

## show mmrp config

Displays the Multiple MAC Registration Protocol (MMRP) configuration.

**Syntax** `show mmrp config`

**Modes** User EXEC mode

**Usage Guidelines** MMRP provides a mechanism for end-stations and bridges to dynamically register or declare group membership for individual MAC addresses to bridges attached in the same LAN or VLAN.

Use this command to review the MMRP parameters configured on this device.

**Examples** The following example displays the parameters configured for MMRP on this device.

```
device> show mmrp config

mmrp enable
  mmrp include-vlan 100,200,300
  mmrp timer join 400 leave 1400 leave-all 10000
!
interface ethernet 1/1
  mmrp enable
  mmrp point-to-point
  mmrp timer join 500 leave 2000 leave-all 15000
  mmrp include-vlan 600,500,300
  enable
!
interface ethernet 1/3
  mmrp enable
  mmrp timer join 600 leave 2200 leave-all 20000
  enable
!
interface ethernet 1/5
  mmrp enable
  mmrp point-to-point
  mmrp timer join 500 leave 2000 leave-all 15000
  enable
```

## show mmrp statistics

Displays Multiple MAC Registration Protocol (MMRP) statistics.

- Syntax** `show mmrp statistics [ vlan vlan-id ]`
- Parameters** `vlan vlan-id`  
 Displays information for a specific virtual LAN (VLAN).
- Modes** User EXEC mode
- Usage Guidelines** MMRP provides a mechanism for end-stations and bridges to dynamically register or declare group membership for individual MAC addresses to bridges attached in the same LAN or VLAN.
- Use this command to review the statistics for MMRP members. If the `vlan` keyword option is used, statistics for the specified VLAN are displayed.

**Examples** The following example displays all MMRP statistics for this device.

```
device> show mmrp statistics
Vlan 100 - Ports 1/1 to 1/5
-----
Message type   Received   Transmitted
-----
In              0           0
Join In        0           0
Join Empty     0           0
Empty          0          156
Leave           0           0
Leave All       40          41
-----
Total PDUs     2           826
-----
Vlan 200 - Ports 2/1 to 2/5
-----
Message type   Received   Transmitted
-----
In              0           0
Join In        0           0
Join Empty     0           0
Empty          0          156
Leave           0           0
Leave All       40          41
-----
Total PDUs     2           826
-----
```

The following example displays MMRP statistics only for VLAN 100.

```
device> show mmrp statistics vlan 100
Vlan 100 - Ports 1/1 to 1/6
-----
Message type   Received   Transmitted
-----
In              0           0
Join In        0           0
Join Empty     0           0
Empty          0          156
Leave           0           0
Leave All       40          41
-----
Total PDUs     2           826
-----
```



## show mpls autobw-threshold-table

Displays the global-threshold table.

**Syntax** `show mpls autobw-threshold-table`

**Modes** User EXEC mode

**Usage Guidelines** This command displays the global-threshold table with the range of current-bandwidth and the corresponding absolute adjustment-threshold.

This command operates in all modes.

**Command Output** The `show mpls autobw-threshold-table` command displays the following information:

Output field	Description
Range (kbps)	Auto-bandwidth range in kilobytes per second.
Threshold (kbps)	Auto-bandwidth threshold in kilobytes per second.

**Examples** The following example shows the `show mpls autobw-threshold-table` command.

```
device# show mpls autobw-threshold-table
Auto-bandwidth threshold table
Range (kbps)      Threshold (kbps)
0-10              2000
11-1000          3000
1001-10000       5000
10001-max        10000
```

**History**

Release	Command history
5.6.00	The command was introduced.

## show mpls bypass-lsp

Displays all dynamic bypass LSPs along with static bypass LSPs.

**Syntax** `show mpls bypass-lsp [ brief | wide | detail | name lsp_name extensive [ descending ] | invalid-tunnel-interface`

`show mpls bypass-lsp { up | down } { detail | extensive [ descending ] | wide }`

`show mpls bypass-lsp { dynamic | static } { brief | detail | extensive [ descending ] | interface { ethernet slot / port { brief | wide } | pos slot / port { brief | wide } | ve ve-id { brief | wide } } }`

### Parameters

#### **brief**

Displays brief information.

#### **detail**

Displays detailed information.

#### **wide**

Displays long LSP names.

#### **name**

*lsp\_name*

Displays LSP by name.

Selected LSP to display.

#### **extensive**

Displays detailed information with History.

#### **descending**

Displays detailed information with History in reverse chronological order.

#### **invalid-tunnel-interface**

Displays LSPs with an invalid tunnel-interface.

#### **up**

Displays operationally UP LSPs.

#### **down**

Displays operationally DOWN LSPs.

#### **detail**

Displays operationally UP/DOWN LSP detailed information.

#### **extensive**

Displays operationally UP/DOWN LSP detailed information with History.

#### **descending**

Displays operationally UP/DOWN LSPs History in reverse chronological order.

#### **wide**

Displays operationally UP/DOWN LSP long names.

#### **dynamic**

Displays dynamic bypass LSPs.

#### **static**

Displays static bypass LSPs.

#### **brief**

Displays dynamic/static LSP brief information.

#### **detail**

Displays dynamic/static LSP detailed information

**extensive**

Displays dynamic/static LSP detailed information with History.

**descending**

Displays detailed information with History in reverse chronological order.

**interface**

Displays dynamic/static LSP protected interface.

**ethernet slot / port**

Specifies an ethernet port.

**pos slot / port**

Specifies a POS port.

**ve ve-id**

Specifies a virtual interface (VE).

**Modes** User EXEC mode

**Examples** The following example displays the command with the brief option.

```
device# show mpls bypass-lsp dynamic brief
Note: LSPs marked with + are Dynamic Bypass LSPs
Name          To          Admin Oper  Tunnel  Up/Dn  Retry  Active
State State Intf    Times No.  Path
blsp01        22.22.22.22  UP    UP+   tn11    1      0      bypas_path_1
_2
```

The following example displays that the non-brief versions include the tunnel-interface index.

```
device#show mpls bypass detail
LSP bypl, to 3.3.3.3, Tunnel interface index: 5002
From: 120.120.120.2, admin: UP, status: DOWN (CSPF fails: Excluded MPLS interface
is down)
Times primary LSP goes up since enabled: 0
Maximum retries: NONE, no. of retries: 0
Pri. path: NONE, up: no, active: no
Setup priority: 7, hold priority: 0
Max rate: 0 kbps, mean rate: 0 kbps, max burst: 0 bytes
CSPF-computation-mode configured: use te-metric(global)
Constraint-based routing enabled: yes
Path calculated using constraint-based routing: no
Path calculated using interface constraint: no
Path cspf-group computation-mode: disabled, cost: 0
Tie breaking: random, hop limit: 0
Exclude interface(s): e3/1
Active Path attributes:
Tunnel index: 65535
```

The following example displays information about the specified bypass-lsp using the **show mpls bypass-lsp name name** command.

```
device# show mpls bypass-lsp name t100
LSP t100, to 10.1.1.1
From: 10.2.2.2, admin: UP, status: UP
Times primary LSP goes up since enabled: 1
Metric: 0, number of installed aliases: 0 Adaptive
Maximum retries: NONE, no. of retries: 0
Pri. path: NONE, up: no, active: no
Setup priority: 7, hold priority: 0 ReoptimizeTimer: 300
Max rate: 0 kbps, mean rate: 0 kbps, max burst: 0 bytes
Constraint-based routing enabled: yes
Path calculated using constraint-based routing: no
Path calculated using interface constraint: no
Tie breaking: random, hop limit: 0
Active Path attributes:
```

History	Release version	Command history
	5.4.00	This command was modified to include filtering based of static bypass types, dynamic bypass types, and protected interface.
	5.6.00	This command was modified to display the cspf-computation mode for the LSP at the local level. This is applicable to bypass LSPs, as well as dynamic bypass LSPs.
	5.8.00	This command was modified to include the <b>descending</b> keyword.
	5.9.00	This command was modified to include the tunnel-interface index in the display output for all non-brief versions.

## show mpls config

Displays user-configured MPLS parameters.

**Syntax** **show mpls config autobw-template** *autobw\_template\_name* | **autobw-threshold-table** | **brief** | **cspf-group** *cspf\_group\_name* | **dynamic-bypass** | **lsp** *lsp\_name* | **path** *path\_name* | **rsvp** | **static-lsp** *transit* | **vll** *vll\_name* | **vll-local** *vll\_local\_name* | **vpls** *vpls\_name*

**show mpls config vpls** [ *vpls\_id* | *vpls\_name* ]

**show mpls config interface** [ **ethernet** *slot/port* | **pos** *slot/port* | **tunnel** *tunnel\_id* | **ve** *num* ]

**show mpls config use-bypass-liberal**

**Parameters**

**autobw-template** *autobw\_template\_name*  
Displays the named automatic bandwidth template configuration information.

**autobw-threshold-table**  
Displays autobw-threshold-table.

**brief**  
Displays brief MPLS configuration information.

**cspf-group** *cspf\_group\_name*  
Displays the named cspf-group configuration information.

**dynamic-bypass** *dynamic\_bypass\_name*  
Displays the named dynamic bypass configuration information.

**interface**  
Displays interface MPLS configuration information.

**ethernet** *slot/port*  
Display the named ethernet port information.

**pos** *slot/port*  
Displays the named POS port information.

**tunnel** *tunnel\_id*  
Displays the named tunnel interface information.

**ve** *num*  
Displays the named virtual ethernet (VE) interface information.

**lsp** *lsp\_name*  
Displays the named LSP configuration information.

**path** *path\_name*  
Displays the named MPLS path configuration information.

**rsvp**  
Displays all RSVP global configurations.

**static-lsp** *static\_lsp\_name*  
Displays the named MPLS static LSPs configuration information.

**use-bypass-liberal**  
Displays liberal mode as part of the command.

**vll** *vll\_name*  
Displays the named VLL configuration information.

**vll-local** *vll\_local\_name*  
Displays the named VLL-local configuration information.

**vpls** *vpls\_name*  
Displays the named VPLS configuration information.

**Modes** Privileged EXEC mode

**Usage Guidelines** Use the **show mpls config** with the optional **brief** keyword to display the prefix list configuration, instead of the ACL.

This command displays the MPLS configuration that exists for each of the keyword/variable options.

The **show mpls config use-bypass-liberal** command operates under the MPLS router mode (config-mpls-policy).

**Examples** The following example shows the **show mpls config brief** command.

```
device show mpls config
device(config t)#
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)#
device(config-mpls-policy)# ingress-tunnel-accounting
device(config-mpls-policy)# auto-bandwidth sample-interval 300
device(config-mpls-policy)# ldp
device(config-mpls-ldp)# advertise-fec list-abc
```

The following example shows the output was modified to the overload bit configuration.

```
device# show mpls config
device(config t)#
device(config)# router mpls
device(config-mpls)# policy
device(config-mpls-policy)# traffic-eng isis level-1
device(config-mpls-policy)# handle-isis-neighbor-down
device(config-mpls-policy)# cspf-computation-mode ignore-overload-bit
```

The following example displays the configuration output for LSPs and bypass LSPs. They now show the tunnel interface index as part of the output.

```
lsp c2
  to 3.3.3.3
  tunnel-interface 5001
  enable

bypass-lsp byp1
  to 3.3.3.3
  exclude-interface e3/1
  tunnel-interface 5002
  enable
```

## History

Release	Command history
5.5.00	This command was modified to display the label withdrawal delay setting.
5.6.00	This command was modified to display the outbound FEC filter configuration parameter. This command was modified to include <b>use-bypass-liberal</b> under the cspf-computation-mode command output line.
5.7.00	This command was modified to display the prefix-list configuration instead of the ACL.
5.8.00	This command was modified to include the line "backup-bw-best-effort" in the <b>show mpls config rsvp</b> command output display.
5.9.00	This command was modified to include the next available RSVP LSP tunnel interface index.

## show mpls forwarding

Displays the MPLS forwarding behavior when the router receives a labeled packet.

**Syntax** **show mpls forwarding** *ip\_prefix\_addr* **longer**

**show mpls forwarding in-label** *in\_label*

**show mpls forwarding p2p** *ip\_addr*

**show mpls forwarding p2mp** [ *dest\_prefix* **detail** *in\_label* *p2mp\_id* ]

**Parameters** *ip\_prefix\_addr*

Displays P2P forwarding entries for the given destination.

**longer**

Displays P2P forwarding entries for the given destination with longer match.

**in-label**

Displays the P2P forwarding entry.

*in\_label*

Specifies the selected in-label.

**p2p**

Displays all P2P forwarding entries for the specified destination or a specified in-label value.

*ip\_addr*

Displays P2P forwarding entries for the given destination.

**p2mp**

Displays all P2MP forwarding entries.

*dest\_prefix*

Specifies the selected destination prefix.

**detail**

Displays all P2MP forwarding entries in a detailed format.

*in\_label*

Specifies the selected in-label to display.

*p2mp\_id*

Specifies the selected P2MP to display.

**Modes** User EXEC mode

**Command Output** The **show mpls forwarding** command displays the following information:

Output field	Description
Dest-prefix	The destination FEC of the LSP.
In-lbl	The incoming segment or upstream label for the LSP. A value of 0 indicates the absence of the segment.
Out-lbl	The outgoing segment or downstream label for the LSP.

Output field	Description
Out-intf	<p>The interface through which the label identified in the 'out-lbl' column has been distributed for the LSP. The 'out-intf' field displays whether an interface/port is an Ethernet port, POS port, or a VE interface. The VE interface ID specified by the <i>vid</i> variable.</p> <p>The out-intf display format for the interface/port is as follows:</p> <ul style="list-style-type: none"> <li>[e   p] slot/port</li> <li>- 'e' represents an Ethernet port.</li> <li>- 'p' represents a POS port.</li> </ul>
Sig	<p>The signal protocol type associated with the label. Possible values are:</p> <ul style="list-style-type: none"> <li>L - LDP</li> <li>R - RSVP</li> </ul>
Next-hop	The next hop of the LSP.
Type	The 'Type' field identifies a P2MP LSP.

**Examples** The following example displays the output of the **show mpls forwarding** command.

```

device# show mpls forwarding
Total number of MPLS forwarding entries: 5
  Dest-prefix      In-lbl  Out-lbl  Out-intf  Sig  Next-hop  Type
1   80.80.80.80/32  1024    1500     e1/12    R    12.12.12.7
2   80.80.80.80/32  1025    1502     e1/11    R    11.11.11.7
3   80.80.80.80/32  1026    1503     e1/12    R    12.12.12.7
4   70.70.70.70/32  1027     3        e1/11    R    11.11.11.7
5   70.70.70.70/32  1028     3        e1/12    R    12.12.12.7

```

**History**

Release version	Command history
4.1.00	This command was introduced.
5.1.00	This command was modified to so the 'out-intf' field displays whether an interface/port is either Ethernet or POS.
5.5.00	This command CLI command syntax changed to <b>show mpls forwarding</b> and includes the options in the parameter section.



# show mpls interface

Displays the details about a specific interface.

**Syntax** **show mpls interface** [ **brief** | **ethernet** *slot/port* | **pos** *slot/port* | **pos** *slot/port* | **tunnel** *tunnel\_id* | **ve** *vid* ]

**Parameters** **brief**

Displays brief interface information.

**ethernet** *slot/port*

Specifies the Ethernet port information to display.

**pos** *slot/port*

Specifies the POS port information to display.

**tunnel** *tunnel\_id*

Specifies the Tunnel interface information to display.

**ve** *vid*

Specifies the Virtual Ethernet (VE) interface information to display.

**Modes** User EXEC mode.

**Usage Guidelines** This command operates in all modes.

**Command Output** The **show mpls interface ethernet** command displays the following information:

Output field	Description
Interface	The interface type refers to any one of the following: <ul style="list-style-type: none"> <li>Use the <b>ethernet</b> <i>slot/port</i> to limit the display to a single Ethernet port.</li> <li>Use the <b>pos</b> <i>slot/port</i> to limit the display to a single POS port.</li> <li>Use the <b>ve</b> <i>vid</i> to limit the display to a VE interface ID specified by the <i>vid</i> variable.</li> </ul>
Maximum BW	The maximum outbound bandwidth that can be used on the interface. This TLV reflects the actual physical bandwidth of the interface.
Maximum reservable BW	The maximum reservable bandwidth on the interface. By default, the maximum reservable bandwidth is the same as the maximum bandwidth for the interface. The user can optionally change the reservable bandwidth on the interface by using the <b>reservable-bandwidth percentage</b> <i>num</i> command. The maximum reservable bandwidth displays as either an absolute value or a percentage value of the total interface bandwidth. In the show output displayed above, the maximum reservable bandwidth is configured as a percentage value. However, the percentage value and the absolute value both display in the <b>show mpls interface ethernet</b> <i>slot/port</i> command output so that the user is aware that the bandwidth is configured as a percentage value, not an absolute value.
<p><b>NOTE</b></p> <p>When the maximum reservable bandwidth is configured as an absolute value, the percentage value is not displayed in the output of the <b>show mpls interface ethernet</b> <i>slot/port</i> command. Only the absolute value displays in the output.</p>	

Output field	Description
Admin group	The administrative groups to which this interface belongs, set with the admin-group command.
Reservable BW [priority] kbps	The amount of bandwidth not yet reserved on the interface. Eight octets are displayed, indicating the amount of unreserved bandwidth (in kbps) that can be reserved with a hold priority of 0 through 7. The value in each of the octets is less than or equal to the maximum reservable bandwidth.
Last sent reservable BW [priority] kbps	The values in the Unreserved Bandwidth TLV sent in the most recent OSPF-TE LSA. When the device is not sending out OSPF-TE LSAs for the interface, the unreserved bandwidth value for each of the priorities is zero (0).
Configured Protecting bypass LSPs	The name and operational state of any bypass LSPs that are protecting this interface.

**Examples** The following example shows the **show mpls interface ethernet** command:

```
device# show mpls interface ethernet 1/1
e1/1
Admin: Up Oper: Up
Maximum BW: 10000000 kbps, maximum reservable BW: 8000000 kbps (80%)
Admin group: 0x00000000
Reservable BW [priority] kbps:
  [0] 8000000    [1] 8000000    [2] 8000000    [3] 8000000
  [4] 8000000    [5] 8000000    [6] 8000000    [7] 8000000
Last sent reservable BW [priority] kbps:
  [0] 8000000    [1] 8000000    [2] 8000000    [3] 8000000
  [4] 8000000    [5] 8000000    [6] 8000000    [7] 8000000
Configured Protecting bypass lsp: 1
```

# show mpls label-range

Displays the MPLS label ranges.

**Syntax** `show mpls label-range`

**Modes** This command operates under all modes.

**Usage Guidelines** For an MPLS label, the label range must be between 16 and 499999.

Configuration of in-label values outside of the label range is not permitted.

When the label range is increased or reloaded, there is nothing to be handled. The user gets a wider label range to use.

When the label range is shortened or shifted, and when there are existing static LSPs that have in-labels that fall under the old range—but no longer under the new range—the following guidelines apply:

- They continue to stay UP as the label range change takes effect only after reload.
- When the user reloads with a configuration, that is, with some in-labels now outside of the label range, those LSPs do not come UP if they were or are enabled. However, they remain in the configuration.
- They are allowed to stay in the configuration only so that if the user re-configures the label range to include them and reloads, they can come UP. Also, removing from the configuration due to errors is incorrect behavior.
- The user can disable or enable the LSPs, but they do not come UP.
- The user cannot change the in-labels to another value outside the range, as per point 1 above. If the user changes any in-label successfully to a value inside the range, the user cannot change it back to the old outside-the-range value again. This follows from point 1.
- When there are LSPs in the configuration that have an in-label value outside the static range, point 3 is the only way the user is able to end up in that state. User configuration of the in-label is not allowed to go outside the range.

**Command Output** The `show mpls label-range` command displays the following information:

Output field	Description
MPLS label range	The header for the label ranges configured using commands <code>label-range [static   dynamic] min-value value max-value value</code> .
Static	Represents the static label range for transit labels.
Dynamic	Represents the dynamic label range for transit labels.
Modified label range	This header displays the values that have been configured, but not yet effective as label range changes require a reload. This section is visible only if a different set of values have been configured to take effect after reload.

**Examples** Example of the **show mpls label-range** command display:

```
device# show mpls label-range
MPLS label range:
    Static          = 16 - 3000
    Dynamic         = 3001 - 499999
Modified label range:*
    Static          = 16 - 5000
    Dynamic         = 5001 - 499999
*These values will become effective after reload with saved config.
```

## show mpls ldp

Displays the inbound FEC-filter configuration.

**Syntax** `show mpls ldp`

**Modes** User EXEC mode

**Examples** The following example displays the inbound FEC-filter configuration.

```
device# show mpls ldp
Label Distribution Protocol version 1
LSR ID:10.122.122.122,using Loopback 1 (deleting stops LDP)
Hello interval: Link 5 sec, Targeted 15 sec
Hello time value sent in Hellos: Link 15 sec, Targeted 45 sec
Keepalive interval: 10 sec, Hold time multiple: 3 intervals
Keepalive timeout: 30
Inbound FEC filtering prefix-list list-abc
Tunnel metric: 0
FEC used for auto discovered peers: current 129, configured 129
Label Withdrawal Delay: 30s
Graceful restart: disabled
Reconnect time: 0 seconds, Max peer reconnect time: 120 seconds
Recovery time: 0 seconds, Max peer recovery time: 120 seconds
Forwarding state holding timer: not running
Label Withdrawal Delay: 30s
```

### History

Release version	Command history
5.5.00	This command was modified to display the label withdrawal delay setting.

## show mpls ldp database

Displays the contents of the LSRs LDP Label Information database.

<b>Syntax</b>	<b>show mpls ldp database</b> [ <i>ip_addr</i> ] [ <b>filtered</b> ]
<b>Parameters</b>	<i>ip_addr</i>
	Displays the specified peer ID address.
	<b>filtered</b>
	Displays sessions with filtered mappings.
<b>Modes</b>	User EXEC mode
<b>Usage Guidelines</b>	This database contains all the labels it has learned from each of its LSR peers, as well as all of the labels it has sent to its LDP peers.
	This command operates in all modes.
<b>Command Output</b>	The <b>show mpls ldp database</b> command displays the following information:

Output field	Description
Session	The LDP identifiers of this LSR and its peer.
Downstream label database	Information about labels received from the LDP peer.
Upstream label database	Information about labels distributed by this LSR to the LDP peer. The device sends the same label for a given prefix to all of its upstream peers.
Label	The label value received from or distributed to LDP peers. It also displays the label values for VC FECs received from LDP peers or advertised to upstream LDP peers.
Prefix	The destination route associated with the label. Since the Prefix is not applicable to the VC-FECs, this field indicates that the label is associated with the VC FEC.
State	Whether the label is actively being used for data forwarding. It can be one of the following: <ul style="list-style-type: none"> <li>'Installed' indicates that the label is being used with an active LDP-created LSP to forward packets.</li> <li>'Retained' indicates that the label is not being used for packet forwarding. Since the LSRs use Liberal Label Retention, these unused labels are retained in the database and not discarded.</li> </ul>

**Examples** The following example displays the output of the **show mpls ldp database** command.

```
device# show mpls ldp database
Session 10.210.210.21:0 - 10.2.2.2:0
Downstream label database:
  Label  Prefix                               State
Upstream label database:
  Label  Prefix                               State
  1024   10.125.125.25/32 (Stale)
  3      10.210.210.21/32 (Stale)
  1025   10.220.220.22/32 (Stale)

Session 10.210.210.21:0 - 10.220.220.22:0
Downstream label database:
  Label  Prefix                               State
  3      10.220.220.22/32                     Installed
  1024   10.125.125.25/32                     Installed
  983097 VC-FEC                           Retained
Upstream label database:
  Label  Prefix
  3      10.210.210.21/32
  983040 VC-FEC
```

## show mpls ldp fec

Displays MPLS forwarding equivalence class (FEC) information.

**Syntax** `show mpls ldp fec [ summary | vc vc_id`

`show mpls ldp fec prefix [ ip_addr | ip_addr / subnet-mask-length | filtered [ in | out ] ] | prefix-filter prefix-list-name ]`

**Parameters** **summary**

Displays LDP FEC summary information.

**vc *vc\_id***

Displays a detailed view of the FEC VC specified by the *vc\_id* variable.

**prefix**

Displays Layer 3 prefix FEC information.

*ip\_addr* / *subnet-mask-length*

Specifies an IP address, with the option of adding subnet mask length.

**filtered**

Displays only filtered mapping configuration information.

**in**

Specifies inbound information.

**out**

Specifies outbound information.

*prefix-filter prefix-list-name*

Displays the FEC prefixes filtered by the specified prefix-list name.

**Modes** Privileged EXEC mode

**Command Output** The `show mpls ldp fec` command options display the following information:

Output field	Description
Total number of prefix FECs	The total number of Layer 3 FECs.
Total number of prefix FECs installed	The total number of Layer 3 FECs installed.
Total number of prefix FECs filtered(in/out)	The total number of Layer 3 FECs filtered.
Total number of prefix FECs with LWD timer running	The total number of Layer 3 FECs with LWD timer running.
Destination	The IP Prefix associated with the host address or the prefix FEC type.
State	State of the FEC which indicates the FEC advertised to any LDP session (state equal to 'current'. When it has no session, it is either called 'cur_no_sess' (currently no session) for local FECs or is marked "retained" for non-local FECs.
Out-intf	For an ingress FEC, this mentions the output interface to reach to the Next-hop. The 'Out-Intf' field displays the egress interface associated with the FEC entry. When applicable, the 'Out-Intf' field displays a VC interface specified by the <i>vc_id</i> variable.



Output field	Description
Next-hop	For an ingress FEC, this mentions the next-hop IP address.
Ingress	Whether the FEC is an ingress FEC.
Egress	Whether the FEC is an egress FEC.
Filtered	The FEC is filtered Inbound (In) or Outbound (Out) or is not filtered ( - ).
LWD	Indicate if the Label withdrawal delay timer is active for the FEC.
LDP FEC summary	Summarized information for LDP FEC.
Total number of prefix FECs	The total number of prefix FECs in the LDP FEC database.
Total number of VC-FEC type 128	The total number of VC FECs for type 128. The FEC type for VC FEC can be 128 or 129.
Total number of VC-FEC type 129	The total number of VC FECs for type 129. The FEC type for VC FEC can be 128 or 129.
Total number of route update processing errors	The total number of route update processing errors for L3 FEC prefix.
Total number of VC FEC processing errors	The total number of L3 VC FEC internal processing errors.
Total number of FECs	The total number of VC FECs.
Peer LDP ID	The remote LDP ID of the peer (or local LSR) from where the VC FEC originates.
VC-ID	The VC identifier associated with the VC FEC.
VC-Type	The VC Type associated with the VC FEC.
FEC-Type	The number that identifies the FEC type. The FEC type for VC FEC can be 128 or 129.
FEC_CB	Memory address of the FEC CB.
Idx	A monotonically increasing number assigned to each FEC in the LDP FEC tree.
Pend_notif	Any notification pending on this FEC.
UM Dist. done	Specifies when Upstream Mapping Distribution is complete.
Grp_id	Group identifier associated with the VC FEC.
Local-mtu	The local MTU for a specified VC FEC.
Remote-mtu	The remote MTU for a specified VC FEC.
MTU enforcement	The user configured MTU enforcement setting that display 'Enabled' when a specified VC ID is UP.
Label	MPLS label advertised to the upstream LDP LSR.

**Examples** The following example displays the output of the **show mpls ldp fec prefix** command.

```
device# show mpls ldp fec prefix
Total number of prefix FECs: 4
Total number of prefix FECs installed: 1
Total number of prefix FECs filtered(in/out): 1/0
Total number of prefix FECs with LWD timer running: 0
```

Destination	State	Out-intf	Next-hop	Ingress	Egress
77.77.77.77/32	current	--	--	No	Yes
144.144.1.1/32	current	e1/5	5.5.5.6	Yes	No
144.144.1.64/32	current	e1/5	5.5.5.6	Yes	No
155.0.0.0/8	current	e1/3	3.3.3.5	Yes	No

The following example shows the output of the **show mpls ldp fec prefix-filter** command.

```
device(config)# ip prefix-list listabc deny 172.16.0.0/16 ge 24 le 24
device(config)# ip prefix-list listabc permit 172.16.0.0/16 ge 28 le 28
device(config)# ip prefix-list listabc per 0.0.0.0/0 ge 32 le 32
device(config)# router mpls
device(config-mpls)# ldp
device(config-mpls-ldp)# filter-fec list abc in
device(config)# show mpls ldp fec prefix filtered
Total number of prefix FECs: 11
```

Destination	State	Out-intf	Next-hop	Ingress	Egress	Filtered	LWD
77.77.77.77/32	current	--	--	No	Yes	-	No
144.144.1.1/32	current	e1/5	5.5.5.6	Yes	No	-	No
144.144.1.64/32	current	e1/5	5.5.5.6	Yes	No	In	No
155.0.0.0/8	current	e1/3	3.3.3.5	Yes	No	-	No

```
device(config)#
device(config)# show mpls ldp fec prefix prefix-filter 172.16.8.0/24
FEC CB: 0x2cd83d78, idx: 4, type: 2, pend notif: None, fec_definition:22080000
State: current, Ingr: Yes, Egr: No, UM Dist. done: No
Prefix: 172.16.8.0/24
next_hop: 10.55.55.14, out_if: e3/16
Downstream mappings:
Local LDP ID Peer LDP ID Label State CB
10.44.44.44:0 10.14.14.14:0 1024 Retained (f)
```

The following example shows the output of the **show mpls ldp fec summary** command.

```
device# show mpls ldp fec summary
LDP FEC summary:
Total number of prefix FECs: 8
Total number of VC-FEC type 128:0
Total number of VC-FEC type 129:0
LDP error statistics:
Total number of route updates processing errors:0
Total number of VC FEC processing errors: 0
```

The following example shows the output of the **show mpls ldp fec vc** command.

```
device# show mpls ldp fec vc
Total number of VC FECs:2
Peer LDP ID State VC-ID VC-Type FEC-Type Ingress Egress
10.125.125.1:0 current 100 4 128 Yes Yes
10.125.125.1:0 current 1000 5 128 Yes Yes
```

The following example shows the output of a MTU mismatch for VC ID of 100, where the VC label received from the remote peer is in a 'Retained' state instead of an 'Installed' state.

```
device# show mpls ldp fec vc 100
FEC_CB: 0x293916f8, inx:3, type:128, pend_notif:None
State:current, Ingr:Yes, Egr:Yes, UM Dist. done:Yes
VC Id:100, vc-type:4, grp_id:0
Local-mtu:2000, remote-mtu:1500, MTU enforcement:enabled

Downstream mappings:
Local LDP ID      Peer LDP Id      Label   State      CB
10.128.128.28:0  10.125.125.1:0  800000  Retained   0x29391328 (-1)

Upstream mappings:
Local LDP ID      Peer LDP ID      Label           CB
10.128.128.28:0  10.125.125.1:0  800001          0x29391604 (-1)
```

## History

---

### Release Command history

---

- |        |  |
|--------|--|
| 5.4.00 | This command was introduced.   |
| 5.5.00 | This command was modified to display label withdrawal delay information.   |
| 5.6.00 | The filtered options on the <b>show mpls ldp fec filtered</b> command now includes lists for both inbound and outbound FECs. |
| 5.8.00 | This command was modified to display the prefix FECs in order of the FEC definition.   |
-

## show mpls ldp interface

Displays information about the LDP-enabled interfaces on the LSR.

**Syntax** `show mpls ldp interface [ brief | ethernet slot/port | pos slot/port | tunnel tunnel_id | ve interface_id ]`

**Parameters** **brief**

Displays brief interface information.

**ethernet slot/port**

Displays the specified ethernet port.

**pos slot/port**

Displays the specified pos interface.

**tunnel tunnel\_id**

Displays the specified tunnel.

**ve interface\_id**

Displays the specified virtual ethernet interface.

**Modes** EXEC mode.

**Command Output** The `show mpls ldp interface` command displays the following information:

Output field	Description
Label-space ID	The label space ID. The second two octets are always zero (0) for LSRs that use per-platform label spaces.
Nbr Count	The number of LDP peers or adjacencies that have been established on this interface. This number can be greater than one (1) when this is a multi-access network.
Hello Interval	The number of seconds between LDP Hello messages.
Next Hello	The number of seconds before the next LDP Hello message is sent (multicast) to the LDP interface (non-targeted). The LDP Hello message is unicast for a targeted interface. For every neighbor, the next LDP Hello message is sent at a different time. In order to find out when the next LDP Hello message is sent out of any targeted adjacency, use the command <code>show mpls ldp neighbor</code> .

**Examples** The following example shows the `show mpls ldp interface` command.

```
device# show mpls ldp interface
          Label-space  Nbr      Hello      Next
Interface  ID             Count    Interval   Hello
e4/1       0                1        5          0 sec
(targeted) 0                0        15         --
(targeted) 0                0        0          --
```

## show mpls ldp neighbor

Displays information about the connection between this LSP and its LDP-enabled neighbors.

**Syntax** `show mpls ldp neighbor [ ip_addr space_id | detail [ ip_addr | space_id ] ]`

**Parameters** `ip_addr`

Displays the peer IP address.

`space_id`

The label space identifier.

**detail**

Displays detailed information.

`ip_addr`

The LDP identifier of the neighbor whose details are to be shown.

`space_id`

The label space identifier of the peer. If not provided, global (0) is assumed.

**Modes** User EXEC mode

**Usage Guidelines** This command operates in all modes.

**Command Output** The `show mpls ldp neighbor detail` command displays the following information:

Output field	Description
Nbr Transport	The transport address of the LDP neighbor.
Interface	The interface to which the LDP neighbor is connected. "Targeted" indicates that the session between this device and the neighbor was established using Targeted Hello messages (that is, through extended discovery).
Nbr LDP ID	The neighbor's LDP identifier.
MaxHold	The number of seconds the device waits for its LDP peers to send a Hello message.
Time Left	The amount of time, in seconds, before the LDP neighbor times out when no Hello message is received from the neighbor.
Up Time	The Up Time is the time since the LDP adjacency is established. It is displayed in days, hours, minutes, and seconds. When there is no adjacency, then nothing is displayed.

**Examples** The following example shows the output of the `show mpls ldp neighbor detail` command.

```
device# show mpls ldp neighbor detail
Nbr Transport Addr: 10.22.22.1, Interface: e1/1, Nbr LDP ID: 10.22.22.1:0
  MaxHold: 44 sec, Time Left: 43 sec, Up Time: 36 min 22 sec
Nbr Transport Addr: 10.22.22.1, Interface: e1/2, Nbr LDP ID: 10.22.22.1:0
  MaxHold: 75 sec, Time Left: 74 sec, Up Time: 36 min 27 sec
Nbr transport Addr: 10.33.33.1, Interface: 31/3, Nbr Ldp ID: 10.33.33.1:0
  MaxHold: 75 sec, Time Left: 72 sec, Up Time: 36 min 22 sec
Nbr Transport Addr: 10.33.33.1, Interface: targeted, Nbr LDP ID: 10.33.33.1:0
  MaxHold: 75 sec, Time Left: 69 sec, Up Time: 35 min 36 sec
```

History	Release version	Command history
	5.4.00	This command was modified. New variables were introduced under the <b>detail</b> option of the command.

## show mpls ldp path

Displays information about active LDP-created LSPs for which the device is an ingress, transit, or egress LSR.

**Syntax** `show mpls ldp path ip_prefix`

**Parameters** `ip_prefix`  
Designates the IP prefix to display.

**Modes** User EXEC mode

**Usage Guidelines** The output of this command indicates that the device has received a label for the destination IP prefix (that is, the attached route) from the downstream peer and then advertised a label for that IP prefix to the upstream peer.

This command operates in all modes.

**Command Output** The `show mpls ldp path` command displays the following information:

Output field	Description
Upstr-session (label)	The LDP identifier of the upstream peer, as well as the incoming label.  Note that upstream session information does not apply to LSPs for which this is the ingress LER.  Because the device uses a per-platform label space, the incoming interface for LDP-created LSP is not relevant.
Downstr-session (label, intf)	The LDP identifier of the downstream peer, as well as the outgoing label and interface. When applicable, the ingress interface 'intf' field displays a VE interface specified by the <code>vid</code> variable.  Because the device uses a per-platform label space, the incoming interface for LDP-created LSP is not relevant.  Note that downstream session information does not apply to LSPs for which this is the egress LER. When LDP selects its outgoing interface as an RSVP tunnel, the ingress interface 'intf' field displays the RSVP tunnel name.
Destination route	The destination route bound to this LSP.

**Examples** The following example shows the output of the `show mpls ldp path` command.

```
device(config)# show mpls ldp path
Upstr-session(label)    Downstr-session(label, intf)    Destination route
10.3.3.3:0(3)          (egress)                        10.1.1.1/32
10.2.2.2:0(3)          (egress)                        10.1.1.1/32
10.3.3.3:0(1024)       10.2.2.2:0(3, e2/10)           10.2.2.2/32
10.2.2.2:0(1024)       10.2.2.2:0(3, e2/10)           10.2.2.2/32
(ingress)              10.2.2.2:0(3, e2/10)           10.2.2.2/32
10.3.3.3:0(1026)       10.3.3.3:0(3, e2/20)           10.3.3.3/32
10.2.2.2:0(1026)       10.3.3.3:0(3, e2/20)           10.3.3.3/32
(ingress)              10.3.3.3:0(3, e2/20)           10.3.3.3/32
```

## show mpls ldp peer

Displays LDP peering information for each LDP session.

**Syntax** `show mpls ldp peer [ [ peer-ip-addr label-id ] | brief | detail ]`

**Parameters** `peer-ip-addr label-id`

Displays the peer IP address and the peer label space identifier.

**brief**

Displays summary LDP peering information.

**detail**

Displays detailed LDP peering information.

**Modes** User EXEC mode

**Usage Guidelines** Use this command to view summary or detailed information about LDP sessions and peers. This command operates in all modes.

**Command Output** The `show mpls ldp peer` command displays the following information:

Output field	Description
Peer LDP ID	The LDP identifier of the peer LSR. The first four octets identify the peer LSR Ip address; the second two octets identify a label soace on the LSR. For LSRs that use per-platform label spaces, the second two octets are always zero (0).
Local LDP ID	This LSRs LDP identifier.
State	The LDP session state, as defined in <i>RFC 3036</i> . This can be 'Nonexistent', 'Initialized', 'OpenRec', or 'Operational'.
Session Status	Whether the session is operationally IP or DOWN.
Entity Idx	This displays the LDP session entity CB index maintained by the LDP session controller.
Targeted	Whether the session was established using Targeted Hello messages (that is, through extended discovery).
Target Adj Added	Whether the targeted adjacency was initiated for this LDP peer.
Num VLL	Number of VLL instances using the LDP peer.
Num VPLS	Number of VPLS instances using the LDP peer.
Rcvd VC FECs	Displays the contents of received VC FECs.
From	Peer LSR ID where the VC FEC was received from.
VC ID	The VC identifier associated with the VC FEC.
Grp_Id	The group identifier associated with the VC FEC.
VC Type	The VC Type associated with the VC FEC.
MTU	The MTU value received in a VC Label Matching message from a peer.



**Examples** The following example displays output of the **show mpls ldp peer** command.

```
device# show mpls ldp peer
Peer LDP ID      State           Num- VLL      Num-VPLS-Peer
10.2.2.2:0       Operational     2             0
10.3.3.3:0       Operational     0             0
10.8.8.8:0       Operational     2             0
10.9.9.9:0       Unknown        2             0
10.14.14.14:0    Operational     1             0
```

The following example displays output of the **show mpls ldp peer** with the **detail** keyword.

```
device# show mpls ldp peer detail
Peer LDP ID:10.2.2.2:0, Local LDP ID:10.1.1.1:0, State:Operational
Session Status UP, Entity Idx:4, Targeted:No, Target Adj Added:Yes
Num VLL:2, Num VPLS:0
Rcvd VC-FECs:
  From 10.2.2.2: Label:800001, VC Id:120, Grp_Id:0, VC Type:4, MTU:5000

Peer LDP ID:10.8.8.8:0, Local LDP ID:10.1.1.1:0, State:Operational
Session Status UP, Entity Idx:2, Targeted:Yes, Target Adj Added:Yes
Num VLL:2, Num VPLS:0
Rcvd VC-FECs:
  From 10.8.8.8: Label:16, VC Id:19, Grp_Id:0, VC Type:32773, MYU:5000
  From 10.8.8.8: Label:18, VC Id:18, Grp_Id:0, VC Type:32772, MTU:5555
```

## show mpls ldp session

Displays information about LDP sessions between a specified router and VLL peers.

**Syntax** `show mpls ldp session [ ip_addr | brief | detail ]`

**Parameters** `ip_addr`

Displays LDP session information for the selected peer IP address.

**brief**

Displays summary LDP session information.

**detail**

Displays detailed LDP session information.

**Modes** Privileged EXEC mode.

**Usage Guidelines** Use this command with the **detail** option to display the number of FECs from the peer which are filtered due to the inbound FEC filter configuration.

**Command Output** The `show mpls ldp session` command displays the following information:

Output field	Description
Peer LDP Ident	The VLL peer's LDP identifier, consisting of the LSR ID and the label space ID.
Local LDP Ident	The device's LDP identifier.
Active	Whether this LSR is playing an active role in session establishment.
State	The LDP session state, as defined in RFC 3036. Options are: <ul style="list-style-type: none"> <li>• Nonexistent</li> <li>• Initialized</li> <li>• OpenRec</li> <li>• OpenSent</li> <li>• Operational</li> </ul>
Adj	The type of adjacency formed with a peer. Possible values: <ul style="list-style-type: none"> <li>• Link</li> <li>• Targeted</li> </ul>
Role	Possible values: <ul style="list-style-type: none"> <li>• Active</li> <li>• Passive</li> </ul>
Next KeepAlive	The number of seconds after which a Hello message is sent to a peer.
Hold time left	The number of seconds after which a session can be terminated when a 'Hello' message is not received from a peer within its time.
KeepAlive interval	The frequency within which LDP Hello messages are sent out.
Max hold time	the length of time the device waits for a Hello message from its peer before terminating the session.

Output field	Description
Neighboring interfaces	The physical interfaces on which the adjacency to the neighbor is formed.
TCP connection, state	The TCP local or remote IP address, port, and state.
Addresses bound to peer LDP Ident	IP addresses carried in the VLL peer's LDP address messages.
Next-hop addresses received from the peer	Next hop IP addresses received in the VLL peer's LDP address messages.

**Examples** The following example displays the output of the show mpls ldp peer command. It displays information about LDP sessions between the device and VLL peers.

```
device# show mpls ldp session
Peer LDP Ident:192.168.2.100:1, Local LDP Ident:10.1.1.1:1
Active:no, State:Operational
TCP connection:10.1.1.1:646-10.2.2.2:9001, State:ESTABLISHED
Address bound to peer LDP Ident:
 10.1.1.2
 1.1.1.2
 20.1.1.2
 22.2.2.2
```

Display output of the show mpls ldp session command showing information about LDP sessions between a specified router and VLL peers.

```
device# show mpls ldp session 10.22.22.22
Peer LDP ID:10.22.22.22:0, Local LDP ID:10.24.24.24:0, State:Operational
Adj:Lik, Role:Active, Next keepalive:0, State:Operational
Keepalive interval:6 sec, Hold time left:30 sec
Neighboring interfaces:e1/4
TCP connection:10.24.24.24:9012-10.22.22.22:646, State:ESTABLISHED
Next-hop addresses received from the peer:
 10.22.22.22 10.40.40.1 10.10.10.2
```

## History

### Release Command history

- |        |   |
|--------|---|
| 5.5.00 | The command output was modified to display the total number of link and targeted sessions in operational state. |
| 5.6.00 | The command was modified to add the <b>in</b> and <b>out</b> keywords to the <b>filtered</b> option.            |

## show mpls ldp statistics

Displays packet statistics for packet types and packet errors.

**Syntax** `show mpls ldp statistic ip_addr`

**Parameters** `ip_addr`  
Specifies the selected IP address.

**Modes** EXEC mode.

**Command Output** The `show mpls ldp statistics` command displays the following information:

Output field	Description
PacketType	The type of LDP packet being counted.
Total	The number of packets of the type describe for the row, sent and received since the Brocade device came UP.
Since last clear	The number of packets of the type described in the row, sent and received, since issuing the last clear command.
Errors	The type of packet error being counted. These errors are associated with the received packets only.
Total	The number of errors of the type describe in the row, generated since the Brocade device came UP.
Since last clear	The number of errors of the type described in the row generated since issuing the last clear command.

**Examples** The following example displays the **show mpls ldp statistics** command:

```
device# show mpls ldp statistics
Total                               Since last clear
Packet type      Sent   Received   Sent   Received
Link Hello      215   214       215   214
Targeted Hello  138   110       138   110
Init             1     1         1     1
KeepAlive       16    18        16    18
Notification    0     0         0     0
Address         2     0         2     0
AddressWithdraw 0     0         0     0
LabelMapping    0     0         0     0
LabelRequest    0     0         0     0
LabelWithdraw   0     0         0     0
LabelRelease    0     0         0     0
LabelAbortReq   0     0         0     0

Errors                               Total   Since last clear
Rcv pkt bad pdu length               0       0
Rcv pkt bad msg legnth               0       0
Rcv pkt bad tlv length               0       0
Rcv pkt notify unkn tlv              0       0
Rcv pct notify unkn addrfam          0       0
Rcv pkt missing tlv                  0       0
Rcv pkt incorrect tlv                0       0
Rcv pkt malformed tlv                0       0
Rcv pkt bad traffic parm              0       0
Rcv pkt partial pdu                   0       0
Rcv pkt internal error                0       0
TCP send error                        0       0
TCP get send pkt error                0       0
TCP memory fail                       0       0
```

Num of TCP socket buffers: 0

The following example displays the **show mpls ldp statistics** command for a specific session.

```
device# show mpls ldp statistics 10.10.10.10
Peer IP address:10.10.10.10
Total                               Since last clear
Message Type      Sent   Received   Sent   Received
Notify            0     0         0     0
Hello Link        0     0         0     0
Targeted Hello    0     0         0     0
Initialize        1     1         1     1
KeepAlive         11    11        11    11
Addr              1     1         1     1
AddrWdrw          0     0         0     0
LabelReq          0     0         0     0
LabelWdrw         0     0         0     0
LabelRel          0     0         0     0
LabelAbReq        0     0         0     0
Unknown           0     0         0     0

Errors                               Total   Since last clear
Rcv pkt bad pdu length               0       0
Rcv pkt bad msg legnth               0       0
Rcv pkt bad tlv length               0       0
Rcv pkt notify unkn tlv              0       0
Rcv pct notify unkn addrfam          0       0
Rcv pkt missing tlv                  0       0
Rcv pkt incorrect tlv                0       0
Rcv pkt malformed tlv                0       0
Rcv pkt bad traffic parm              0       0
Rcv pkt partial pdu                   0       0
Rcv pkt internal error                0       0
TCP send error                        0       0
TCP get send pkt error                0       0
TCP memory fail                       0       0
```

Num of TCP socket buffers: 0

## show mpls ldp tunnel

Displays the output sorted by the FEC address, which is the first column of the output.

**Syntax** `show mpls ldp tunnel ip_addr ip_mask | brief | detail | out-interface [ ethernet slot/port | pos slot/port | ve interface_id ]`

**Parameters** `ip_addr`

The tunnel destination IP address.

`ip_mask`

the tunnel IP prefix subnet mask.

**brief**

Displays brief information.

**detail**

Displays detailed information.

**out-interface**

Displays LDP tunnels going out of an interface.

**ethernet slot/port**

Displays the specified ethernet port.

**pos slot/port**

Displays the specified POS port.

**ve interface\_id**

Displays the specified Virtual Ethernet (VE) interface.

**Modes** EXEC mode.

**Usage Guidelines** The command displays information about LDP-created LSPs for which this device is the ingress LER.

The command is always sorted by FEC address.

This command operates in all modes.

**Examples** The following example shows the command output sorted by the FEC address (the 'To' column).

```
Total number of LDP tunnels : 4
To          Oper    Tunnel  Outbound
2.2.2.2     State  Intf    Intf
2.2.2.2     UP     tnl0    e1/1
2.2.2.3     UP     tnl4    e1/1
3.3.3.3     UP     tnl2    e1/1
20.1.1.1    UP     tnl1    e1/1
```

The following example displays the show mpls ldp tunnel command that includes the tunnel-index interface.

```
device#show mpls ldp tunnel 11.11.11.11
LDP tunnel tnl7, to 11.11.11.11/32
Tunnel index: 7, metric: 0, status: UP
Outgoing interface: e1/1, Next-hop index: 0
Tunnel interface index: 18603
```

**History**

---

**Release Command History**

---

5.4.00 This command is modified to include the new parameter **out-interface**.

---

5.5.00 The output of this command is modified to include all the paths in the LDP tunnel.

---

---

**Release Command History**

---

5.7.00 This command is modified so the output of the **show mpls ldp tunnel** command is always sorted by FEC address.

---

5.9.00 This command is modified to include the tunnel-interface index in the display output.

---

## show mpls lsp

Displays information about configured and active dynamic *Multiprotocol Label Switching (MPLS) label-switched paths (LSPs)*.

<b>Syntax</b>	<b>show mpls lsp autobw-sample   brief   detail [ [ down   up [ autobw-sample   detail   extensive   wide ] ]   extensive   name <i>lsp_name</i> autobw-sample   invalid-tunnel-interface wide   wide</b>
<b>Parameters</b>	<p><b>auto-sample</b></p> <p><b>brief</b> Displays the sample History for all the auto-bandwidth LSPs.</p> <p><b>detail</b> Displays brief information.</p> <p><b>down</b> Displays detailed information.</p> <p><b>up</b> Displays operationally DOWN (inactive) LSPs.</p> <p><b>autobw-sample</b> Displays operationally UP (active) LSPs.</p> <p><b>detail</b> Displays sample History.</p> <p><b>extensive</b> Displays detailed information.</p> <p><b>wide</b> Displays detailed information with History.</p> <p><b>name <i>lsp_name</i></b> Displays long LSP names.</p> <p><b>invalid-tunnel-interface</b> Displays information by the specified LSP name.</p> <p><b>wide</b> Displays the long name of the LSP.</p> <p><b>invalid-tunnel-interface</b> Displays LSPs that have an invalid tunnel-interface index because of a bad startup-configuration.</p> <p><b>wide</b> Displays long LSP names.</p>
<b>Modes</b>	EXEC mode.
<b>Usage Guidelines</b>	<p>This command operates in all modes.</p> <p>The <b>show mpls lsp brief</b> command displays the same information as the <b>show mpls lsp</b> command.</p>
<b>Command Output</b>	The <b>show mpls lsp extensive</b> command displays the following information:

Output field	Description
Name	The name of the LSP. LSPs display in alphabetical order.
To	The egress LER for the LSP.



Output field	Description
From	The LSPs source address, configured with the from command. When a source IP address has not been specified for the LSP with the <b>from</b> command, and the LSP has not been enabled, then 'n/a' is displayed in the 'From' field.
admin	The administrative state of the LSP. Once the user activates the LSP with the <b>enable</b> command, the administrative state changes from DOWN to UP.
status	<p>The operational state of the LSP. This field indicates whether the LSP has been established through signaling and is capable of having packets forwarded through it.</p> <p>When the status of the LSP is DOWN, the reason the LSP is down is shown in parentheses "( )".</p> <p>There may be a short after the user enables the LSP that the administrative state of the LSP is UP, but the status is DOWN. Once the LSP establishes through signaling, both the administrative state and the status is UP.</p>
tunnel interface (primary path)	The MPLS tunnel interface port ID.
Times primary LSP goes up since enabled	The number of times the status of the LSPs primary path transitions from DOWN to UP.
Metric	The metric for the LSP configured with the metric command.
Maximum retries	The maximum number of attempts the ingress LER attempts to connect to the egress LER, set with the retry-limit command.
no. of retries	The number of attempts the ingress LER has made to connect to the egress LER.
Pri. path	The name of the primary path for this LSP and whether the path is currently active.
up	Displays if the primary path is UP.
active	Displays if the primary path is active.
Setup priority	The configured setup priority for the LSP.
hold priority	The configured hold priority for the LSP.
Max rate	The maximum rate of packets that can go through the LSP (in kbps), set with the <b>traffic-eng max-rate</b> command.
mean rate	The average rate of packets that can go through the LSP (in kbps), set with the <b>traffic-eng mean-rate</b> command.
max burst	The maximum size (in bytes) of the largest burst the LSP can send at the maximum rate, set with the <b>traffic-eng max-burst</b> command.
Auto-bandwidth template	Displays the named auto-bandwidth template configuration information for the path specified by the <b>show mpls config autobw-template template_name</b> command.
mode	Displays when the LSP is in monitor-only mode or monitor-and-signal mode. The default mode is monitor-and-signal.
adjustment interval	The configured adjustment interval in seconds. Default value: 86400 seconds; range: 300 -2592000 seconds.

Output field	Description
adjustment threshold	The configured adjustment threshold percentage. Default percentage: 0; range: 0 - 100 percent.
minimum bw	The configured minimum bandwidth. Default value: 0 kbps; range: 0 - 2147483647 kbps.
maximum bw	The configured maximum bandwidth. Default value: 2147483647 kbps; range: 0 - 2147483647 kbps.
overflow limit	Displays the configured overflow limit.
underflow limit	The number of samples which have below the threshold to trigger a premature adjustment. Default value: 0; range: 0 - 65535.
sample-record	The record of all events related to auto-bandwidth of an LSP.
Constraint-based routing enabled	Whether CSPF is in effect for the LSP.
Path calculated using constraint-based routing	Whether the explicit path used by the active path was calculated using the constraint-based routing.
Path calculated using interface constraint	Whether the explicit path used by the active path was calculated using the interface-constraint routing.
Path cost	The total cost of this path.
Tie breaking	The tie-breaking method CSPF uses to select a path from a group of equal-cost paths to the egress LER, set with the <b>tie-breaking</b> command.
hop limit	The maximum number of hops a path calculated by CSPF can have, set with the <b>hop-limit</b> command.
LDP tunneling enabled	If LDP tunneling is enabled, the line reads 'yes'. If it is not enabled, the line reads 'no'.
Soft preemption enabled	Soft preemption minimizes traffic disruptions and gracefully reroute the preempted LSPs.
Sec. path	The name of the secondary path for this LSP and whether the path is currently active.
active	Displays if the secondary path is active.
Hot-standby	Whether the secondary path is a hot-standby path.
status	The operational state of the secondary path.
Setup priority	The name of the secondary path for this LSP and whether the path is currently active.
hold priority	The configured hold priority for the LSP.
Max rate	The maximum rate of packets that can go through the LSP (in kbps), set with the <b>traffic-eng max-rate</b> command.
mean rate	The average rate of packets that can go through the LSP (in kbps), set with the <b>traffic-eng mean-rate</b> command.
max burst	The maximum size (in bytes) of the largest burst the LSP can send at the maximum rate, set with the <b>traffic-eng max-burst</b> command.

Output field	Description
Auto-bandwidth template	Displays the named auto-bandwidth template configuration information for the path specified by the <b>show mpls config autobw-template</b> <i>template_name</i> command.
mode	Displays when the LSP is in monitor-only mode or monitor-and-signal mode. The default mode is monitor-and-signal.
adjustment interval	The configured adjustment interval in seconds. Default value: 86400 seconds; range: 300 -2592000 seconds.
adjustment threshold	The configured adjustment threshold percentage. Default percentage: 0; range: 0 - 100 percent.
minimum bw	The configured minimum bandwidth. Default value: 0 kbps; range: 0 - 2147483647 kbps.
maximum bw	The configured maximum bandwidth. Default value: 2147483647 kbps; range: 0 - 2147483647 kbps.
overflow limit	Displays the configured overflow limit value.
underflow limit	The number of samples which have fallen below the threshold to trigger a premature adjustment. Default value: 0; range: 0 - 65535.
sample record	The record of all events related to auto-bandwidth of an LSP.
Constraint-based routing enabled	Whether CSPF is in effect for the LSP.
hop limit	The maximum number of hops a path calculated by CSPF can have, set with the <b>hop-limit</b> command.
Soft preemption enabled	Soft preemption minimizes traffic disruptions and gracefully reroute the preempted LSPs.
Active Path attributes:	
Tunnel interface	The MPLS tunnel interface port ID.
outbound interface	The outbound interface taken by the active path of the LSP. When the egress interface is a VE-enabled interface, the VE interface ID specified by the <i>vid</i> variable.
Tunnel-interface index	The value of the tunnel-interface index (configured or allocated).
Tunnel interface	Please note that this specifies the vif index. For example: tn1 would mean a vif of 1.
tunnel instance	Source port of the LSP.
outbound label	The outbound label used by the active path of the LSP.
Auto-bandwidth running info. mode	Displays when the auto-bandwidth running information mode is in monitor-only mode or monitor-and-signal mode. The default mode is monitor-and-signal.
adjustment interval	The configured adjustment interval in seconds. Default value: 86400 seconds; range: 300 -2592000 seconds.
adjustment threshold	The configured adjustment threshold percentage. Default percentage: 0; range: 0 - 100 percent.

Output field	Description
overflow limit	Displays the configured overflow limit value.
underflow limit	The number of samples which have to be below the threshold to trigger a premature adjustment.
minimum bw	The configured minimum bandwidth. Default value: 0 kbps; range: 0 - 2147483647 kbps.
maximum bw	The configured maximum bandwidth. Default value: 2147483647 kbps; range: 0 - 2147483647 kbps.
Samples collected	Number of samples collected so far in the current adjustment-interval.
max sampled bw	The maximum of the samples collected so far in the current adjustment-interval.
last sample	The last sampled-bandwidth.
Overflow-count	Displays the number of samples that have consecutively exceeded the adjust-threshold. When a sample does not exceed the threshold, the counter is reset.
Underflow-count	Displays when the actual traffic rate is much less than the reserved bandwidth.
Sample-record	Records the sample history.
Adjustment ignored	This consecutive number of times the adjustment was ignored due to any reason.
Recorded routes	The addresses recorded by the RECORD_ROUTE object during RSVP signaling.
Protection codes/Rtr Id flag	The Local out-interface information label and protection flags: P: Local N: Node B: Bandwidth I: InUse R: RtrID

**Examples** The following example shows the output of the **show mpls lsp brief** command:

```
device# show mpls lsp
*: The LSP is taking a Secondary path
Name      To          Admin  Oper  Tunnel  Up/Dn  Retry  Active
State     State      State  State Int1    Times  No.    Path
t1        10.3.3.3  UP     UP*   tn11    1      5      v2
```

The following example shows the output of the **show mpls lsp detail** command:

```
device(config-mpls)#show mpls lsp detail
LSP c2, to 3.3.3.3, tunnel-interface index: 100
  From: 120.120.120.2, admin: UP, status: DOWN (CSPF fails: code 0)
  Times primary LSP goes up since enabled: 0
  Metric: 0
  Maximum retries: NONE, no. of retries: 0
  Pri. path: NONE, up: no, active: no
  Setup priority: 7, hold priority: 0
  Max rate: 0 kbps, mean rate: 0 kbps, max burst: 0 bytes
  CSPF-computation-mode configured: use te-metric(global)
  Constraint-based routing enabled: yes
    Path calculated using constraint-based routing: no
    Path calculated using interface constraint: no
  Tie breaking: random, hop limit: 0
  LDP tunneling enabled: no
  Soft preemption enabled: no
  Active Path attributes:
    Tunnel interface: tn11, outbound interface: e1/6
    Tunnel index: 1, Tunnel instance: 1 outbound label: 3
  Recorded routes:
    Protection codes/Rtr Id flag: P: Local  N: Node  B: Bandwidth  I: InUse R: RtrId
    6.6.6.41
```

The following example shows the output of the **show mpls lsp extensive** command:

```
device# show mpls lsp extensive
LSP lsp1, to 23.23.23.23
  From: 34.34.34.34, admin: UP, status: UP, tunnel interface(primary path): tn11
  Times primary LSP goes up since enabled: 1
  Metric: 0, Adaptive
  Maximum retries: NONE, no. of retries: 0
  Pri. path: NONE, up: yes, active: yes
  Setup priority: 7, hold priority: 0
  Max rate: 0 kbps, mean rate: 0 kbps, max burst: 0 bytes
  Auto-bandwidth. template: templatel, mode: monitor-only
    adjustment interval: 86400 sec, adjustment threshold: 0
    minimum bw: 0 kbps, maximum bw: 2147483647 kbps
    overflow limit: 0, underflow limit: 20, sample-record: disabled
  Constraint-based routing enabled: yes
    Path calculated using constraint-based routing: yes
    Path calculated using interface constraint: no
    Path cost: 20
  Tie breaking: random, hop limit: 0
  LDP tunneling enabled: no
  Soft preemption enabled: no
  Sec. path: vial6, active: no
  Hot-standby: no, status: down, adaptive
  Setup priority: 7, hold priority: 0
  Max rate: 0 kbps, mean rate: 0 kbps, max burst: 0 bytes
  Auto-bandwidth. template: NONE, mode: monitor-and-signal
    adjustment interval: 300 sec, adjustment threshold: Table
    minimum bw: 0 kbps, maximum bw: 2147483647 kbps
    overflow limit: 5, underflow-limit: 10, sample-record: enabled
  Constraint-based routing enabled: yes
  hop limit: 0
  Soft preemption enabled: no
  Active Path attributes:
    Tunnel interface: tn11, outbound interface: e4/3
    Tunnel index: 2, Tunnel instance: 1 outbound label: 2049
  Auto-bandwidth running info. Mode: monitor-only
    adjustment interval: 1200 sec(T), adjustment threshold: Table(T)
    overflow limit: 0, underflow limit: 3
    minimum bw: 0 kbps(T), maximum bw: 9647 kbps(T)
    Samples collected: 14, max sampled bw: 0 kbps, last sample: 0 kbps
    Overflow-count: 0, Underflow-count: 2,max-underflow-sample: 34kbps
    Sample-record: enabled(T)
    adjustment due in 1174 seconds
    Adjustment ignored: 0 time(s)
    No adjustment since activation. Current bandwidth: 0 kbps
  Recorded routes:
    Protection codes/Rtr Id flag: P: Local  N: Node  B: Bandwidth  I: InUse R: RtrId
    31.31.31.16 -> 161.161.161.1
```

The following example shows the output of the **show mpls lsp wide** command. The full LSP name displays on a single line.

```
device# show mpls lsp wide
note: LSPs marked with * are taking a Secondary Path
Name      To      Admin Oper Tunnel Up/Dn  Retry  Active
          State State Int1  Times No.    Path
tunnel1   10.3.3.3 UP     UP   tn10    1      0      --
tunnel2   10.3.3.3 UP     UP   tn14    1      0      ppath1
tunnelfromsanfranciscotonewyork
          10.3.3.3 UP     UP   tn13    1      0      pathfrom sanfranciscotonewyork
```

The following example shows the bandwidth inherited from the protected LSP.

```
device# show mpls lsp name to_NY
LSP to NY, to 28.28.28.28
From: 34.34.34.34, admin: UP, status: UP, tunnel interface(primary path): tn18
Times primary LSP goes up since enabled: 1
Metric: 0
Maximum retries: NONE, no. of retries: 0
Pri. path: to-NY via Chicago, up: yes, active: yes
Setup priority: 7, hold priority: 0
Max rate: 0 kbps, mean rate: 2000 kbps, max burst: 0 bytes
CSPF-computation-mode configured: use te-metric(global)
Constraint-based routing enabled: yes
Path calculated using constraint-based routing: yes
Path calculated using interface constraint: no
Path calculated using te-metric
Path cost: 22
Tie breaking: random, hop limit: 0
LDP tunneling enabled: no
Soft preemption enabled: no
Active Path attributes:
Tunnel interface: tn18, outbound interface: ve11
Tunnel index: 4, Tunnel instance: 1 outbound label: 2048
Explicit path hop count: 3
150.150.150.16 (S) -> 93.93.93.9 (S) -> 28.28.28.28 (L)
Recorded routes:
Protection codes/Rtr Id flag: P: Local N: Node B: Bandwidth I: InUse R: RtrId
150.150.150.16 (PN) -> 93.93.93.9 (P) -> 90.90.90.10
Fast Reroute: facility backup desired, node protection desired
Bandwidth: 2000 kbps (Inherited from Protected LSP)
Backup LSP: UP, out-label: 2048, outbound interface: e1/9 bypass_lsp: to_NY_via_DC
cost: 0
cspf-group computation-mode: disabled
cspf-computation-mode use-bypass-metric: disabled
FRR Forwarding State: Pri(active), Backup(up)
```

**History**

Release version	Command history
5.4.00	This command is modified to include new events that are logged in the LSP history. The only change is that a new message has been defined for an RRO change. The rest of the fields are unchanged.
5.5.00	This command is modified to include LSP history with IGP synchronization related history logs when using the extensive option.
5.6.00	This command is modified to show: <ul style="list-style-type: none"> <li>The <b>underflow-limit</b> parameter and the number of consecutive underflows.</li> <li>The <b>adjustment-threshold</b> is used from the global mode and is indicated by the value of the current rate.</li> <li>The sample history for the current adjustment interval.</li> <li>The <b>autobw-sample</b> parameter is introduced.</li> </ul>
5.8.00	This command is modified to include "Inherited from Protected LSP" in display output for the <b>detail</b> , <b>extensive</b> , and <b>wide</b> options.

---

Release version	Command history
5.9.00	<p>This command is modified so the output of <b>show mpls lsp</b> command in the non-brief versions includes the tunnel-interface index.</p> <p>This command is modified to include an option to display those LSPs that have invalid tunnel-interface index because of bad startup-configuration (<b>invalid-tunnel-interface</b>).</p>

---

# show mpls lsp\_p2mp\_xc

Displays hardware information about the forwarding information of hardware that is allocated for the *point-to-multipoint (P2MP)* cross-connect.

**Syntax** `show mpls lsp_p2mp_xc in_label`

**Parameters** `in_label`  
Specifies the MPLS input label value.

**Modes** Privileged EXEC mode.

**Usage Guidelines** The `show mpls lsp_p2mp_xc` command displays information about the forwarding information of hardware that is allocated for the *point-to-multipoint (P2MP)* cross-connect.

This command operates in all modes.

**Examples** The following example displays hardware forwarding statistics on a Brocade NetIron MLX Series device:

```
device# show mpls lsp_p2mp_xc
P2MP XC TABLE:
TOTAL USED = 2
      IN-LABEL  XC#  FID      MVID  IN-PORT  NUM_OUT_SEGS
      1159      0   0a00a   106   65535    1
      1160      1   0a00b   107   65535    1

device# show mpls lsp_p2mp_xc 1159
TOTAL OUT_SEGS under the given in_label = 1
      BRANCH-ID OUT-LABEL OUT-PORT  NH-ID
      0         0         14       6
Event History -
Tue Aug 14 02:21:54 2012 P2MP BRANCH ADD
Tue Aug 14 02:21:54 2012 P2MP XC ADD
flag: 0, pool_index:1, avail_data:270e0800
```

The following example displays hardware forwarding statistics on a Brocade NetIron CES Series device:

```
device# show mpls lsp_p2mp_xc
P2MP XC TABLE:
TOTAL USED = 1
      IN-LABEL  XC#  IP-TTI @ PPCR{1, 2, 3} MPLS-TTI@{PPCR 1, 2, 3} IN-PORT NUM_OUT_SEGS
START-DIT
1024      1   65274                65275                1/1      2
2049

device# show mpls lsp_p2mp_xc 1024
TOTAL OUT_SEGS under the given in_label = 2
      BRANCH-ID OUT-LABEL OUT-PORT  NH-ID      DIT      TSI
      0         2001      4         0         2049     0
      1         2002      4         0         2050     1
Event History -
Tue Aug 14 12:53:17 2012 P2MP BRANCH ADD
Tue Aug 14 12:52:33 2012 P2MP BRANCH ADD
Tue Aug 14 12:52:33 2012 P2MP XC ADD
```

History	Release	Command history
	5.5.00	This command is introduced.



# show mpls path

Displays a list of device hops that specifies a route across an MPLS domain.

**Syntax** `show mpls path [ path_name | detail | wide ]`

**Parameters** *path\_name*

`wide` Displays only information for a specified path.

`detail` Displays the full path name on a single line.

`detail` Displays detailed path information.

**Usage Guidelines** A path is a list of device hops that a specifies a route across an MPLS domain. The user can create a path, and then configure LSPs that see the path. When the LSP is enabled, the ingress LER attempts to signal the other LSRs in the path, so that resources can be allocated to the LSP.

This command operates in all modes.

**Command Output** The `show mpls path` command displays the following information:

Output field	Description
Path name	The configured name of the path.
Address	The IP address of each node in the path. A node corresponds to an MPLS-enabled router in the network.
Strict or Loose	Whether the node is strict or loose. A strict node means that the router must directly connect to the preceding node. A loose node means that the other routers can reside between the source and destination nodes.
Usage Count	The number of LSPs that are either currently using or configured to use the path. For example, when an LSP named 'to_sqa' has primary and secondary paths and both paths are configured to use the same MPLS path 'path_to_sqa', then the usage count for 'path_to_sqa' would be two (when no other LSP in the system is configured to use 'path_to_sqa').

**Examples** The following example displays the output of the `show mpls path` command.

```
device# show mpls path
Path Name  Address          Strict/loose  Usage Count
to110_120  10.110.110.2    Strict        1
           10.120.120.3    Strict
to2_pri    10.10.10.2      Strict        0
to2_sec    10.110.110.2    Strict        0
to3        10.110.110.2    Loose         1
           10.120.120.3    Loose
to3_pri    10.10.10.2      Strict        1
           10.120.120.3    Strict
to3_sec    10.110.110.2    Strict        0
           10.120.120.3    Strict
to4        10.110.110.2    Loose         1
           10.120.120.3    Loose
           10.130.130.4    Loose
to_23     10.110.110.2    Strict        1
           10.20.20.3      Strict
```

The following example displays the **show mpls path wide** command. This option lets the full name of the display on a single line.

```
device# show mpls path wide
Path Name      Address      Strict/loose  Usage Count
pathfromsanfranciscotonewyork
                10.10.10.2   Strict        1
ppath          10.10.10.2   Strict        1
spath          10.20.20.2   Strict        1
```

**History**

Release version	Command history
4.1.00	This command is modified, so the display output displays additional information.
5.1.00	This command is modified so when using the <b>wide</b> option; the LSP name is displays on a single line. Previously, an LSP name greater than 12 characters was wrapped to multiple lines.

## show mpls policy

Displays the current parameter settings configured under the MPLS policy mode.

**Syntax** `show mpls policy`

**Modes** MPLS policy configuration mode

**Usage Guidelines** The output includes a display of bypass liberal mode if the **use bypass liberal** keyword was configured as part of the **CSPF computation-mode** command.

**Command Output** The **show mpls policy** command displays the following information:

Output field	Description
Current MPLS policy settings:	
CSPF interface constraint	Directs the router to include the interface address as a constraint when it determines the shortest path.
CSPF-Group computation-mode	Specifies the mode that is used when setting up a fate-sharing group.
CSPF computation-mode :	
Use bypass metric	Displays if enabled or disabled. TE metric of TE link for CSPF computation.
Use bypass liberal	Displays if enabled or disabled. Liberal mode for CSPF facility backup computation.
Use te-metric	Displays if enabled or disabled. By default, the cspf-computation mode is set to use te-metric.
ignore-overload-bit	Displays if enabled or disabled. <ul style="list-style-type: none"> <li>With this enabled, even when overload bit is set on a transit a router, CSPF at the ingress will not reject any path for new LSPs.</li> <li>If the ignore overload bit is set, already existing transit sessions will not be brought down from ingress on enabling overload bit on transit router.</li> </ul>
TTL propagation for MPLS label	Displays if the TTL propagation for MPLS is enabled or disabled.
IPVPN	Displays if IPVPN is enabled or disabled.
IP over MPLS	Displays ID IP over MPLS is enabled or disabled.
Inter-AS-route filtering	When the user enables inter-AS-route filtering, the RTM does not send any inter-AS routes to MPLS.
Intra-AS iBGP route filtering	Displays if intra-AS iBGP route filtering is enabled or disabled.
Ingress tunnel accounting	Displays if ingress tunnel accounting is enabled or disabled.
Polling interval for MPLS LSP traffic statistics	Displays the polling interval, in seconds.
Advertise TE parameters via	Displays which level option enables LSPs with TE extensions. The level-1 option enables TE extensions for the IS-IS level-1 domain. The level-2 option enables LSPs with TE extensions for the IS-IS level-2 domains.
Handle IGP neighbor down event - ISIS	Displays if IS-IS is handling the IGP neighbor DOWN event.

Output field	Description
Handle IGP neighbor down event - OSPF	Displays if OSPF is handling the IGP neighbor DOWN event.
LSP rapid retry	Displays if LSP rapid retry is enabled or disabled.
Maximum number of retries	Displays the maximum number of times the port will try the health check. Values are from 3 - 64. The default value is 7.
LSP periodic retry time	Displays the LSP periodic retry time in seconds.
FRR backup/detour retry time	Displays the FRR backup and detour retry time in seconds.
Auto-bandwidth	Displays if auto-bandwidth is enabled or disabled.
Sample-interval	On changing the sample-interval the sample-timer is reset for all the auto-bandwidth LSPs. Any rate information already collected so far in the current sample-interval is considered a valid sample.
Maximum samples recorded per LSP	Displays the maximum samples recorded per LSP.
Soft preemption cleanup-timer	Interval time between when the path is taken down and the new LSP is established. Any traffic attempting to use the LSP is lost.
MPLS TE Periodic Flooding Timer	Displays the timer in seconds. All MPLS interfaces are checked every three minutes by default. TE advertisements are triggered when there is a difference in the available bandwidth and advertised available bandwidth.
MPLS TE flooding thresholds:	
Global UP thresholds	Displays global UP thresholds. UP values are 10, 20, 30, 40, 50, 55, 60, 65, 70, 85, 90, 92, 93, 94, 95, 96, 97, 98, 99, 100.
Global DOWN thresholds	Displays global DOWN thresholds. DOWN values are 99, 98, 97, 96, 95, 94, 93, 92, 91, 90, 85, 80, 75, 70, 65, 60, 55, 50, 45, 30, 20, 10.
Default UP thresholds	Displays default UP thresholds. UP values are 10, 20, 30, 40, 50, 55, 60, 65, 70, 75, 80, 85, 90, 92, 93, 94, 95, 96, 97, 98, 99, 100.
Default DOWN thresholds	Displays default Down thresholds. DOWN values are 99, 98, 97, 96, 95, 94, 93, 92, 91, 90, 85, 80, 75, 70, 65, 60, 55, 50, 40, 30, 20, 10.

**Examples** The following example displays the output of the **show mpls policy** command:

```
device# show mpls policy
Current MPLS policy settings:
  CSPF interface constraint: disabled
  CSPF-Group computation-mode: disabled
  Use bypass metric: disabled
  Use bypass liberal: disabled
  Use te-metric (default), Ignore-overload-bit: disabled
  TTL propagation for MPLS label: disabled, IPVPN: disabled, IP over MPLS: enabled
  Inter-AS route filtering: enabled, Intra-AS iBGP route filtering: disabled
  Ingress tunnel accounting: disabled
  Polling interval for MPLS LSP traffic statistics: 300 seconds
  Advertise TE parameters via: OSPF
  Handle IGP neighbor down event - ISIS: No OSPF: No
  LSP rapid retry: enabled, maximum number of retries: no limit
  LSP periodic retry time: 30 seconds
  FRR backup/detour retry time: 30 seconds
  Auto-bandwidth: enabled, sample-interval: 60 seconds
  Maximum samples recorded per LSP: 1500
  Soft preemption cleanup-timer: 30 seconds
  MPLS TE Periodic Flooding Timer : 180 seconds
  MPLS TE flooding thresholds
    Global UP thresholds : None
    Global DOWN thresholds : None
    Default UP thresholds : 15 30 45 60 75 80 85 90 95 96 97 98 99 100
    Default DOWN thresholds : 99 98 97 96 95 90 85 80 75 60 45 30 15
```

## History

---

### Release Command history

---

- 5.6.00 This command was modified to include bypass liberal output when the **use bypass liberal** keyword is configured in the **cspf-computation-mode** command.

---

- 5.8.00 This command was modified to include 'CSPF computation-mode' information in the display output.

---

## show mpls route

Displays the contents of the MPLS routing table.

**Syntax** `show mpls route [ ip_addr [ / ip_mask ] ]`

**Parameters** `ip_addr`

Specifies the destination IP address.

`/ ip-mask`

Specifies the IP subnet mask.

**Modes** User EXEC mode

**Usage Guidelines** With LDP ECMP LER tunnels, the output for one tunnel could be greater than one line where each line shows one outgoing path - the repetitive lines do not have the 'Destination' and 'Tnnl' columns filled because they match what is in the first line.

**Command Output** The `show mpls route` command displays the following information:

Output field	Description
Destination	The destination for the route. This can be either the address of the egress LER in an LSP, or a configured alias.
Gateway	The address of the egress LER in the LSP. When the destination address is not a network alias, the gateway is the same as the destination address.
Tnnl	The address of the egress LER in the LSP. When the destination address is not a network alias, the gateway is the same as the destination address.
Port	<p>The MPLS tunnel interface associated with the LSP.</p> <p>The port field displays whether an interface/port is an Ethernet port, POS port, or a VE interface. The VE interface ID is specified by the <code>vid</code> variable. When applicable, the egress interface of the routing entry displays the VE interface.</p> <p>The port display format for interface or port is as follows:</p> <ul style="list-style-type: none"> <li>• [e p] slot or port</li> <li>• "e" represents an Ethernet port</li> <li>• "p" represents a POS port</li> </ul>
Label	The MPLS label received from the downstream router.
Sig	<p>The signal protocol type associated with the label. Possible values are:</p> <ul style="list-style-type: none"> <li>• L – LDP</li> <li>• R – RSVP</li> </ul>
Cost	The metric for the LSP, set with the metric command in the LSPs configuration.
Use	The number of LSPs that are either currently using or configured to use the path. For example, when an LSP named "to_sqa" has primary and secondary paths and both paths are configured to use the same MPLS path "path_to_sqa," then the usage count for "path_to_sqa" would be two (when no other LSP in the system is configured to use "path_to_sqa").

**Examples** The following example displays the **show mpls route** command.

```
device# show mpls route
Total number of MPLS tunnel routes: 4
R:RSVP L:LDP S:Static O:Others
  Destination      Gateway          Tnnl  Port  Label Sig Cost Use
1 10.12.12.12/32   10.12.12.12     tn11  e2/1  3    R   0   0
2 10.12.12.12/32   10.12.12.12     tn15  e2/1  3    L   0   0
   10.12.12.12     10.12.12.12     e2/2  3    L   0   0
   10.12.12.12     10.12.12.12     e3/8  3    L   0   0
3 10.13.13.13/32   10.13.13.13     tn14  e1/1  3    L   0   0
4 10.77.77.12/32   10.12.12.12     tn110 e2/1  3    L   0   0
   10.12.12.12     10.12.12.12     e2/2  3    L   0   0
   10.12.12.12     10.12.12.12     e3/8  3    L   0   0
```

## History

---

### Release Command history

---

5.5.00 With LDP ECMP LER tunnels, the output for one tunnel could be greater than one line where each line shows one outgoing path.

---

## show mpls rsvp interface

Displays the status of RSVP on devices where it is enabled.

<b>Syntax</b>	<b>show mpls rsvp interface brief   detail   [ ethernet   pos   ve slot/port ]</b>
<b>Parameters</b>	<p><b>brief</b> Displays brief interface information.</p> <p><b>detail</b> Displays detailed interface information.</p> <p><b>ethernet slot/port</b> Displays the specified ethernet port.</p> <p><b>pos slot/port</b> Displays the specified POS port.</p> <p><b>ve slot/port</b> Displays the specified virtual ethernet interface.</p>
<b>Modes</b>	Privileged EXEC mode.
<b>Usage Guidelines</b>	This command operates in all modes.
<b>Command Output</b>	The <b>show mpls rsvp interface</b> command displays the following information:

Output field	Description
Status	Whether the interface is UP or DOWN.
MD5	Whether RSVP message authentication is enabled on the interface.
RelMsg	Whether RSVP reliable messaging is enabled on the interface.
Bundle	Whether RSVP bundle messages are enabled on the interface.
SRefresh	Whether RSVP summary refresh is enabled on the interface.
Num of OutSegAct/Inact/Resv	Out segments are traffic connections on the link. These connections may be active or inactive. 'Resv' represents the number of active out segments with a nonzero mean rate.
Num of Preempts	Number of times lower-priority LSPs have been preempted on this interface.

**Examples** The following example displays the **show mpls rsvp interface** command:

```
device# show mpls rsvp interface

Interface      State  MD5  RelMsg  Bundle  SRefresh  Act/Inact/Resv  Preempts
e3/2 (Trunk8)  Up    OFF  ON      ON      ON        0/0/0           0
e3/4 (Trunk9)  Up    OFF  ON      ON      ON        0/0/0           0
e3/6           Up    OFF  ON      ON      ON        0/0/0           0
e3/7 (Trunk2)  Up    OFF  ON      ON      ON        1699/0/1684     1142
e3/8 (Trunk6)  Up    OFF  ON      ON      ON        167/0/106       0
e4/3 (Trunk3)  Up    OFF  ON      ON      ON        2526/0/2526     1471
e4/5 (Trunk4)  Up    OFF  ON      ON      ON        8421/0/8421     774
e7/1 (Trunk17) Up    OFF  ON      ON      ON        8480/0/8421     5479
e7/2 (Trunk19) Up    OFF  ON      ON      ON        7489/0/7484     0
e9/3 (Trunk7)  Up    OFF  ON      ON      ON        178/0/158       0
(output truncated)
```



The following example displays a shorter output, using the **show mpls rsvp interface brief** command.

```
device# show mpls rsvp interface brief
Interface      State      MD5 Auth
e2/1           Up         OFF
e2/2           Dn         OFF
e4/1           Dn         OFF
e4/2           Dn         OFF
```

# show mpls rsvp neighbor

Displays RSVP neighbors that were discovered dynamically during the exchange of RSVP packets.

**Syntax** `show mpls rsvp neighbor [ ipv4address | detail ]`

**Parameters** `ip_addr`

Specifies the IP address of a learned neighbor.

**detail**

Displays RSVP neighbor information in a detailed format.

**Modes** Privileged EXEC mode.

**Usage Guidelines** Use this command to display all the current RSVP neighbors for this router.

The 'RR' and 'MsgID' flags in this command show the ability of the neighbor to support Refresh Reduction and Message IDs respectively.

The 'MsgID' field is set to 'YES' in the following cases:

- This field is defaulted to 'YES' initially.
- It is set to 'YES' if the neighbor sends a message containing a Message ID.
- It is also set to 'YES' if the remote MPLS interface is configured to send Message IDs to this neighbor.

The 'MsgID' field is set to 'NO' when the peer rejects a message (with a 'PathErr' or 'ResvErr') because it contains a Message ID object.

If the neighbor sends a NACK to a Message ID object that is sent and then subsequently sends a Path or Resv message that does not contain a Message ID, then RSVP sets this field to 'NO'. This allows RSVP to inter-operate with devices that do not support Message IDs.

This command operates in all modes.

**Command Output** The `show mpls rsvp neighbor` command displays the following information:

Output field	Description
RSVP neighbors learnt	Number of neighbors the router has learned.
Nbr Address	Address of the learned neighbor.
Interface	Name of the interface where the neighbor has been detected.
State	Current status of the neighbor.  <b>UP</b> - Router can detect RSVP-TE Hello messages from the neighbor.  <b>DOWN</b> - Router has received a failure from the neighbor or change in the sequence numbers in RSVP Hello messages sent by the neighbor.
Last_Change	Time elapsed since the neighbor state changed.  Format: days: hours: minutes: seconds.
Number of LSPs to or from this Nbr	This field displays the number of LSPs or RSVP sessions using this next-hop (neighbor).(Detail mode only.)

Output field	Description
Hello-interval	<b>Hello-interval</b> - Frequency at which RSVP-TE Hello Request messages are sent on the interface, in seconds.
Hello-tolerance	<b>Hello-tolerance</b> - The number of hello periods that may pass without receiving a complete Hello message before the Hello session times out. (Detail mode only.)
Hello Tx/Rx Count	Number of Hello packets sent to or received from the neighbor.
RR/MsgID Support	Indicates if Refresh Reduction and Message ID support is enabled and/or supported by the neighbor.  ( <b>Y</b> - Enabled, <b>N</b> - Disabled)
No Hello message received since	This field displays how far back (in seconds) the last RSVP Hello (Request OR Ack) message was received.
Time left to send next Hello Req	This field is valid and displays the time only when the Neighbor supports RSVP Hellos. Otherwise, it displays "-". (Detail mode only.)
Remote instance	Identifier provided by the remote router during Hello messages (Dest_Instance or Neighbor_Src_Instance). (Detail mode only.)
Local instance	Identifier sends to the neighbor during Hello messages (Src_Instance). (Detail mode only.)
Refresh Reduction	Indicates if Refresh Reduction is enabled or supported by the neighbor. (Detail mode only.)
Message ID	Indicates if Message ID support is enabled by the neighbor. (Detail mode only.)

**Examples** The following example displays the output of the **show mpls rsvp neighbor** command.

```
device# show mpls rsvp neighbor
RSVP neighbors learnt: 4
Nbr Address Interface State Last_Change HelloTx/Rx RR/MsgID
d:h:m:s Count Support
10.152.152.15 e1/2 UP 10:2:31:44 8498/8349 Y/Y
10.92.98.9 e1/12 UP 0:6:39:36 3995/3587 N/Y
10.31.31.15 e4/3 DOWN 6:6:39:36 3000/1267 N/Y
10.92.99.9 e3/2 UP 0:0:31:44 2995/0 N/N

device# show mpls rsvp neighbor 10.92.98.9
Nbr Address: 92.92.98.9, Interface: e1/12, State: UP
Last changed time (d:h:m:s): 0:6:39:38, Number of active LSPs to or from this
Nbr: 22
Hello sent: 3995, received: 3587, Hello-interval: 15 sec, Hello-tolerance: 5
No Hello message received since: 5 sec
Time left to send next Hello Req: 10 sec
Remote instance: 0x65c6b2, Local instance: 0x5a4f9f21
Refresh Reduction: Disabled, Message ID: Enabled

device# show mpls rsvp neighbor 10.1.1.1
RSVP neighbor with the provided IP address does not exist
```

#### History

Release	Command History
5.6.00	This command is introduced.

## show mpls rsvp session

Displays information regarding *Resource reSerVation Protocol (RSVP)* sessions.

<b>Syntax</b>	<b>show mpls rsvp session</b> [ <b>backup</b>   <b>brief</b>   <b>bypass</b>   <b>destination</b>   <b>detail</b>   <b>detour</b>   <b>down</b>   <b>egress</b>   <b>extensive</b>   <b>in-interface</b>   <b>ingress</b>   <b>name</b> <i>sess-name</i>   <b>out-interface</b>   <b>p2mp</b>   <b>p2p</b>   <b>ppend</b>   <b>transit</b>   <b>up</b>   <b>wide</b> ]
<b>Parameters</b>	
<b>backup</b>	Displays facility backup session.
<b>brief</b>	Displays brief session information.
<b>bypass</b>	Displays bypass session.
<b>destination</b>	Destination IP address.
<b>detail</b>	Displays detailed session information.
<b>detour</b>	Displays detour session.
<b>down</b>	Displays inactive session.
<b>egress</b>	Displays egress session.
<b>extensive</b>	Displays extensive session information.
<b>in-interface</b>	Displays RSVP sessions coming into an interface.
<b>ingress</b>	Displays ingress session.
<b>name</b> <i>sess-name</i>	Displays session by name.
<b>out-interface</b>	Displays RSVP sessions going out on an interface.
<b>p2mp</b>	Displays point to multipoint sessions.
<b>p2p</b>	Displays point to point sessions.
<b>ppend</b>	Displays sessions in soft preemption pending state.
<b>transit</b>	Displays a transit session.
<b>up</b>	Displays up session.
<b>wide</b>	Displays long LSP names.
<b>Modes</b>	User EXEC mode
<b>Usage Guidelines</b>	The <b>show mpls rsvp session brief</b> command displays the same information as the <b>show mpls rsvp session</b> command.

This command operates in any mode.

**Command Output** The **show mpls rsvp session** command displays the following information:

Output field	Description	Command
Ingress RSVP	Displays information about ingress RSVP sessions.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> show mpls rsvp session <b>extensive</b>
Transit RSVP	Displays information about transit RSVP sessions.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
Egress RSVP	Displays information about egress RSVP sessions.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
To	Destination (egress LER) of the session.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
From	Source (ingress LER) of the session; the source address for the LSP configured with the <b>from</b> command.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
St	State can be UP or DOWN.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
Style	The RSVP reservation style. Possible values are <i>Fixed Filter (FF)</i> , <i>Wildcard Filter (WF)</i> , or <i>Shared Explicit (SE)</i> .	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
Lbl_In	The label for inbound packets on this LSP.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>

Output field	Description	Command
Lbl_Out	The label applied to outbound packets on this LSP.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
Out_if	The outbound interface displays the egress interface for a session. When applicable, the outbound interface displays a VE interface specified by the <i>vid</i> variable.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
LSPname	The name of the LSP.	<b>show mpls rsvp session</b> <b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b> <b>show mpls rsvp session wide</b>
Time left in seconds	The amount of time left for the PATH or RESV refreshes.	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
Tspec	Traffic engineering specification for the LSP, including the max-rate ("peak"), mean rate ("rate"), number of burst bytes ("size"), maximum policed unit ("M"—or maximum packet size), and minimum policed unit ("m"—or minimum packet size).	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
Explicit path hop count	The number of explicit hops used in this RSVP session.	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
Received RRO count	The number of Record Route Objects received on this RSVP session.	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
PATH sentto	Address of the next LSR in the LSP, and the interface used to reach this LSR. When applicable, 'PATH sentto' displays a VE interface specified by the <i>vid</i> variable.	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>
PATH rcvfrom	Address of the previous LSR in the LSP, and the interface used to reach this LSR. When the session is downstream only, then it is displayed. When applicable, 'PATH rcvfrom' displays a VE interface specified by the <i>vid</i> variable.	<b>show mpls rsvp session detail</b> <b>show mpls rsvp session extensive</b>

Output field	Description	Command
PATH history	<p>Displays history of the last 20 RSVP event. Each event contains:</p> <ul style="list-style-type: none"> <li>• Event index (used to provide the number of events).</li> <li>• Time stamp</li> <li>• File name and line number where the event is logged.</li> <li>• Event description and extra information associated with each event.</li> </ul>	<b>show mpls rsvp session extensive</b>

**Examples** The following example displays the **show mpls rsvp session** command.

```
device(config)# show mpls rsvp session
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress

Ingress RSVP: 10 session(s)
To      From      St Style Lbl_In Lbl_Out Out_If LSPname
10.22.22.22 10.11.11.11  Up FF   -     3     e4/3   xmr2
10.33.33.33 10.11.11.11  Up SE   -     3     e4/4   rj-vpls
10.33.33.33 10.11.11.11  Up SE   -    1039   e1/15  rj-vpls
.....

Transit RSVP: 1009 session(s)
To      From      St Style Lbl_In Lbl_Out Out_If LSPname
10.22.22.22 10.33.33.33  Up SE  1024   3     e4/3   2
10.22.22.22 10.33.33.33  Up SE  1072  1319  e2/4   toxmr2frr-
.....

Egress RSVP: 62 session(s)
To      From      St Style Lbl_In Lbl_Out Out_If LSPname
10.11.11.11 10.22.22.22  Up SE   3     -     -     toxml-frr
10.11.11.11 210.22.22.22  Up SE   3     -     -     toxml-frr
10.11.11.11 10.22.22.22  Up SE   3     -     -     toxml-frr
10.11.11.11 10.44.44.44  Up FF   3     -     -     toxmrl
```

The following command allows the user to display the full LSP name in a single line.

```
device# show mpls rsvp session wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress

Ingress RSVP: 4 session(s)
10.3.3.3 10.2.2.2      Up SE - 3 e1/1 tunnel1
10.3.3.3 10.10.10.10  Dn - - - e1/3 tunnel1
10.3.3.3 10.2.2.2  (BYI)  Up SE - 3 e1/3 byl
10.3.3.3 10.2.2.2      Up SE - 3 e1/1 tunnelfromsanfranciscotonewyork
10.3.3.3 10.10.10.10  Dn - - - e1/3 tunnelfromsanfranciscotonewyork
10.3.3.3 10.2.2.2  (BYI)  Up SE - 3 e1/3 bypasstunnelfromsfotonewyork

Transit RSVP: 0 session(s)
Egress RSVP: 0 session(s)
```

the following example displays the command using the wide parameter.

```
device# show mpls rsvp session backup wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
      DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
      RP:Repaired Session BYI: Bypass Ingress
Ingress RSVP: 2 session(s)
To      From      St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.3.3.3 10.2.2.2      Up  SE    -        3        e1/1    tunnell
10.3.3.3 10.10.10.10(BI) Dn  -     -        -        e1/3    tunnell
10.3.3.3 10.2.2.2      Up  SE    -        3        e1/1
tunnelfromsanfranciscotonewyork
10.3.3.3 10.10.10.10(BI) Dn  -     -        e1/3
tunnelfromsanfranciscotonewyork
Transit RSVP: 0 session(s)
Egress RSVP: 0 session(s)
```

History

Release version	Command History
3.6.00	This command is enhanced to include a new option that allows the display of RSVP events such as state transitions and events associated with RSVP sessions.
5.1.00	This command is enhanced to display the full LSP name on a single line. Previously, a long LSP name (greater than 12 characters) was text wrapped in multiple lines. Enhanced command: <b>show mpls rsvp session wide</b> .  The show mpls rsvp session command is enhanced to display if the session is downstream only. Command: <b>show mpls rsvp session detail</b> .
5.5.00	This command is enhanced to include the following new filters: <ul style="list-style-type: none"> <li>• p2mp   p2p - filters RSVP sessions based on type (p2p vs p2mp)</li> <li>• p2mp_id - this is P2MP ID, applicable to P2MP RSVP session types only.</li> </ul>
5.8.00	This command is modified to display explicitly on the protected session if it has bandwidth protection or not. It will display only on the protected session. Available on the <b>show mpls rsvp session detail</b> command.



## show mpls rsvp session backup

Displays the Reserved Reservation Protocol (RSVP) facility backup session.

**Syntax** `show mpls rsvp session backup [ active [ brief | destination | detail | egress | extensive | in-interface | ingress | name | out-interface | p2mp | p2p | ppend | protection-available | protection-unavailable | transit | up | wide ]`

<b>Parameters</b>	<b>active</b>	Displays active backup and or detour sessions.
	<b>brief</b>	Displays brief session information.
	<b>destination</b>	Displays the destination IP address
	<b>detail</b>	Displays detailed session information.
	<b>egress</b>	Displays the egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessin coming into an interface.
	<b>ingress</b>	Displays the ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displys RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint sessions.
	<b>p2p</b>	Displays point to point sessions.
	<b>ppend</b>	Displays sessions in a soft preemption pending state.
	<b>protection-available</b>	Displays sessions with protection available.
	<b>protection-unavailable</b>	Displays sessions with protection unavailable.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays the output from the command using the wide option.

```

device#show mpls rsvp session backup wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress

Ingress RSVP: 2 session(s)
To      From          St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.3.3.3 10.2.2.2          Up  SE     -        3        e1/1    tunnel1
10.3.3.3 10.10.10.10(BI)  Dn  -      -        -        e1/3    tunnel1
10.3.3.3 10.2.2.2          Up  SE     -        3        e1/1
tunnelfromsanfranciscotonewyork
10.3.3.3 10.10.10.10(BI)  Dn  -      -        -        e1/3
tunnelfromsanfranciscotonewyork

Transit RSVP: 0 session(s)
Egress RSVP: 0 session(s)

```

## show mpls rsvp session brief

Displays the Reserved Reservation Protocol (RSVP) brief session information.

**Syntax** `show mpls rsvp session brief [ backup | bypass | destination | detour | down | egress | in-interface | ingress name | out-interface | p2mp | p2p | ppend | transit | up ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Displays the destination IP address.
	<b>detour</b>	Displays detour session.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>in-interface</b>	Displays RSVP sessions going out on an interface.
	<b>ingress</b>	Displays the ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessiond going
	<b>p2mp</b>	Displays point to multipoint.
	<b>p2p</b>	Displays point to point.
	<b>ppend</b>	Displays sessions in soft preemption pending status.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP session.

**Modes** User EXEC mode

**Usage Guidelines** This command operates in all modes.

The **show mpls rsvp session brief** command displays the same information as the **show mpls rsvp session** command.

**Command Output** The **show mpls rsvp session brief** command displays the following information:

Output field	Description
Ingress RSVP	Information about ingress RSVP sessions.
Transit RSVP	Information about transit RSVP sessions.

Output field	Description
Egress RSVP	Information about egress RSVP sessions.
To	Destination (egress LER) of the session.
From	Source (ingress LER) of the session; the source address for the LSP that was configured with the from command.
St	State can be UP or DOWN.
Style	The RSVP reservation style. Possible values are FF (Fixed Filter), WF (Wildcard Filter), or SE (Shared Explicit).
Lbl_In	The label for inbound packets on this LSP.
Lbl_Out	The label applied to outbound packets on this LSP.
Out_If	The outbound interface displays the egress interface for a session. When applicable, the outbound interface displays a VE interface specified by the vid variable.
LSPname	The name of the LSP.

**Examples** The following example shows the **show mpls rsvp session** command.

```

device(config)#show mpls rsvp session
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress
Ingress RSVP: 10 session(s)
To      From      St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.22.22.22 10.11.11.11  Up  FF    -       3        e4/3    xmr2
10.33.33.33 10.11.11.11 (DI) Up  SE    -       3        e4/4    rj-vpls
10.33.33.33 10.11.11.11  Up  SE    -       1039     e1/15   rj-vpls
.....
Transit RSVP: 1009 session(s)
To      From      St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.22.22.22 10.33.33.33  Up  SE    1024    3        e4/3    2
10.22.22.22 10.33.33.33 (DI) Up  SE    1072    1319     e2/4    toxmr2frr-
.....
Egress RSVP: 62 session(s)
To      From      St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.11.11.11 10.22.22.22 (DE) Up  SE    3       -        -       toxml-frr
10.11.11.11 210.22.22.22 (DE) Up  SE    3       -        -       toxml-frr
10.11.11.11 10.22.22.22  Up  SE    3       -        -       toxml-frr
10.11.11.11 10.44.44.44  Up  FF    3       -        -       toxmr1

```

## show mpls rsvp session bypass

Displays *Reserved Reservation Protocol (RSVP)* bypass sessions.

<b>Syntax</b>	<b>show mpls rsvp session bypass</b> [ <b>brief</b>   <b>destination</b>   <b>detail</b>   <b>down</b>   <b>extensive</b>   <b>in-interface</b>   <b>ingress</b>   <b>name</b>   <b>out-interface</b>   <b>p2mp</b>   <b>p2p</b>   <b>ppend</b>   <b>up</b>   <b>wide</b> ]
<b>Parameters</b>	<p><b>brief</b> Displays brief session information.</p> <p><b>destination</b> Destination IP address.</p> <p><b>detail</b> Displays detailed session information.</p> <p><b>down</b> Displays inactive session.</p> <p><b>extensive</b> Displays extensive session information.</p> <p><b>in-interface</b> Displays RSVP sessions coming into an interface.</p> <p><b>ingress</b> Displays ingress session.</p> <p><b>name</b> Displays session by name.</p> <p><b>out-interface</b> Displays RSVP sessions going out on an interface.</p> <p><b>p2mp</b> Displays point to multipoint sessions.</p> <p><b>p2p</b> Displays point to point sessions.</p> <p><b>ppend</b> Displays sessions in soft preemption pending status.</p> <p><b>up</b> Displays Up session.</p> <p><b>wide</b> Displays long LSP names.</p>
<b>Modes</b>	EXEC mode.

**Examples** The following example displays the output of the command with the detail parameter.

```

device# show mpls rsvp session bypass detail
Codes: DI:Ingress Detour  DT:Transit Detour  DM:Merged Detour
       DE:Egress Detour   BI:Ingress Backup  BM: Merged Backup  BE:Egress Backup
       RP:Repaired Session  BYI: Bypass Ingress

Total Number of such sessions are: 2

Ingress RSVP:      2 session(s)
To                From                St Style Lbl_In  Lbl_Out  Out_If  LSPname
1.1.4.1           1.1.1.1(BYI)           Up SE    -    1024    ve33
GREEN_DOWN_PE1toP1 VE1111-11.11.1.1-29
Tunnel ID: 48, LSP ID: 1
Time left in seconds (PATH refresh: 24, ttd: 4235431
                    RESV refresh: 18, ttd: 113)
Tspec: peak 19200 kbps rate 19200 kbps size 0 bytes m 20 M 65535
Setup Priority: 7 Holding Priority: 0
Session attribute flags:0x04
(SE Style)
Explicit path hop count: 3
11.1.3.0 (S) -> 23.1.100.1 (S) -> 32.1.10.1 (S)
Received RRO count: 3
Protection codes/Rtr Id flag: P: Local  N: Node  B: Bandwidth  I: InUse  R: RtrId
11.1.3.0 -> 23.1.100.1 -> 32.1.10.1
PATH sentto: 11.1.3.0      (ve33          ) (MD5 OFF), Message ID: --
RESV rcvfrom: 11.1.3.0    (ve33          ) (MD5 OFF), Message ID: --

```

## show mpls rsvp session destination

Displays the selected Resource Reservation Protocol (RSVP) session destination IP address.

<b>Syntax</b>	<b>show mpls rsvp [ destination <i>dest_ip</i> ] [ in-interface   out-interface   backup   brief   bypass   detail   detour   egress   ingress   extensive   name <i>session_name</i>   ppend   transit   up   down   wide   p2mp   p2p ]</b>
<b>Parameters</b>	<p><b>destination <i>dest_ip</i></b> Displays the selected destination IP address.</p> <p><b>in-interface</b> Displays RSVP sessions coming into an interface.</p> <p><b>out-interface</b> Displays RSVP session going out on an interface.</p> <p><b>backup</b> Displays facility backup session.</p> <p><b>brief</b> Display brief session information.</p> <p><b>bypass</b> Displays bypass session.</p> <p><b>detail</b> Displays detailed session information.</p> <p><b>detour</b> Displays detour session.</p> <p><b>egress</b> Displays egress session.</p> <p><b>ingress</b> Displays ingress session.</p> <p><b>extensive</b> Displays extensive session information.</p> <p><b>name <i>session_name</i></b> Displays session by specified name.</p> <p><b>ppend</b> Displays sessions in soft preemption pending state.</p> <p><b>transit</b> Displays transit session.</p> <p><b>up</b> Displays UP session.</p> <p><b>down</b> Displays inactive session.</p> <p><b>wide</b> Displays long LSP names.</p> <p><b>p2mp</b></p>

Displays point to multipoint sessions.

**p2p**

Displays point to point sessions.

**Modes** User EXEC mode

**Examples** The following example displays the output of the command.

```
device(config)#show mpls rsvp session dest 10.30.30.30 source 10.10.10.10 tun 1
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress
```

```
Total Number of such sessions are: 1
To      From      St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
10.30.30.30 10.10.10.10 Up  FF    1024    3        e3/1    t1
```



## show mpls rsvp session detail

Displays detailed *Reserved Reservation Protocol (RSVP)* session information.

<b>Syntax</b>	<b>show mpls rsvp session detail</b> [ <b>backup</b>   <b>bypass</b>   <b>destination</b>   <b>detour</b>   <b>down</b>   <b>egress</b>   <b>in-interface</b>   <b>ingress</b>   <b>name</b>   <b>out-interface</b>   <b>p2mp</b>   <b>p2p</b>   <b>ppend</b>   <b>transit</b>   <b>up</b> ]
<b>Parameters</b>	
<b>backup</b>	Displays facility backup session.
<b>bypass</b>	Displays bypass session.
<b>destination</b>	Destination IP address.
<b>detour</b>	Displays detour session.
<b>down</b>	Displays inactive session.
<b>egress</b>	Displays egress session.
<b>in-interface</b>	Displays RSVP sessions coming into an interface.
<b>ingress</b>	Displays ingress session.
<b>name</b>	Displays session by name.
<b>out-interface</b>	Displays RSVP sessions going out on an interface
<b>p2mp</b>	Displays point to multipoint sessions.
<b>p2p</b>	Displays point to point sessions.
<b>ppend</b>	Displays sessions in a soft preemption pending state.
<b>transit</b>	Displays transit session.
<b>up</b>	Displays UP session.
<b>Modes</b>	EXEC mode.

**Examples** The following example displays the output of the command when the session is only downstream.

```

device# show mpls rsvp session detail
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
      DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
      RP:Repaired Session BYI: Bypass Ingress

Total Number of such sessions are: 1
To      From      St Style Lbl In  Lbl Out Out If LSPname
28.28.28.28  34.34.34.34  Up SE   2050  2049  e1/8  to_NY
Tunnel ID: 4, LSP ID: 1
Time left in seconds (PATH refresh: 44, ttd: 119
                    RESV refresh: 7, ttd: 152)
Tspec: peak 300 kbps rate 300 kbps size 0 bytes m 20 M 65535
Setup Priority: 7 Holding Priority: 0
Session attribute flags:0x1f
(Label recording,SE Style,Protection: Local,Bandwidth,Node)
Fast Reroute: Facility backup desired
Setup priority: 7, hold priority: 0
Bandwidth: 300 kbps, hop limit: 255
Backup LSP: UP. Nexthop (node) protection available.
Bandwidth protection available.
Up/Down times: 1, num retries: 0
cost: 0
Path cspf-group computation-mode: disabled
Path cspf-computation-mode use-bypass-metric: disabled,
Explicit path hop count: 2
93.93.93.9 (S) -> 90.90.90.10 (S)
Received RRO count: 2
Protection codes/Rtr Id flag: P: Local N: Node B: Bandwidth I: InUse R: RtrId
93.93.93.9 (P) -> 90.90.90.10
PATH rcvfrom: 150.150.150.15 (ve11) (MD5 OFF), Message ID: --
PATH sentto: 93.93.93.9 (e1/8) (MD5 OFF), Message ID: --
RESV rcvfrom: 93.93.93.9 (e1/8) (MD5 OFF), Message ID: --

To      From      St Style Lbl In  Lbl Out Out If LSPname
28.28.28.28  35.35.35.35(BI)  Up -   2050  3    e1/I0 to_NY
Tunnel ID: 4, LSP ID: 1
Time left in seconds (PATH refresh: 0, ttd: 4280803)
Tspec: peak 300 kbps rate 300 kbps size 0 bytes m 20 M 65535
Setup Priority: 7 Holding Priority: 0
Session attribute flags:0x06
(Label recording,SE Style)
Explicit path hop count: 1
28.28.28.28 (S)
PATH rcvfrom: None (downstream only)
PATH sentto: 28.28.28.28 (e1/10) (MD5 OFF), Message ID: --
Riding bypass lsp: DUT_16-93.93.93.16-28.28.28.28-2

```

**History**

Release version	Command history
5.1.00	This command is modified to display when the session is only downstream.

## show mpls rsvp session detour

Displays the Reserved Reservation Protocol (RSVP) detour session.

**Syntax** `show mpls rsvp session { detour [ active | brief | destination | detail | down | egress | extensive | in-interface | inactive | ingress | name | out-interface | p2mp | p2p | ppend | protection-available | protection-unavailable | transit | up wide ]`

<b>Parameters</b>	<b>active</b>	Displays active backup and detour sessions.
	<b>brief</b>	Displays brief session information.
	<b>destination</b>	Destination IP address.
	<b>detail</b>	Displays detailed session information.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>inactive</b>	Displays inactive, but UP, backup or detour session.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint sessions.
	<b>p2p</b>	Displays point to point sessions.
	<b>ppend</b>	Displays sessions in a soft preemption pending state.
	<b>protection-available</b>	Displays sessions with protection available.
	<b>protection-unavailable</b>	Displays sessions with protection unavailable.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays a typical output of the command.

```
device# show mpls rsvp session detour
Codes: DI:Ingress Detour  DT:Transit Detour  DM:Merged Detour
       DE:Egress Detour   BI:Ingress Backup  BM:Merged Backup  BE:Egress Backup
       RP:Repaired Session  BYI:Bypass Ingress

Total Number of such sessions are: 0

Ingress RSVP:                0 session(s)
Transit RSVP:                 0 session(s)
Egress RSVP:                  0 session(s)
```

## show mpls rsvp session down

Displays inactive Reserved Reservation Protocol (RSVP) sessions.

**Syntax** `show mpls rsvp session down [ backup | brief | bypass | destination | detail | detour | egress | extensive | in-interface | ingress | name | out-interface | p2mp | p2p | ppend | transit | wide ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session.
	<b>brief</b>	Displays brief session information.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Destination IP address.
	<b>detail</b>	Displays detailed session information.
	<b>detour</b>	Displays detour session.
	<b>egress</b>	Displays egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint session.
	<b>p2p</b>	Displays point to point session.
	<b>ppend</b>	Displays sessions in a soft preemption pending state.
	<b>transit</b>	Displays transit session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays the output of the command using the wide option.

```

device#show mpls rsvp session down wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress
Total Number of such sessions are: 59
Transit RSVP: 59 session(s)
To          From          St Style Lbl_In  Lbl_Out Out_If LSPname
10.0.11.11  10.0.0.5  Dn -    -      -      e1/2   to_AR11_autoBW_11
10.0.11.12  10.0.0.5  Dn -    -      -      e1/2   to_AR11_autoBW_12
10.0.11.13  10.0.0.5  Dn -    -      -      e1/2   to_AR11_autoBW_13
10.0.11.14  10.0.0.5  Dn -    -      -      e1/2   to_AR11_autoBW_14

```

## show mpls rsvp session extensive

Displays extensive Reserved Reservation Protocol (RSVP) session information.

**Syntax** `show mpls rsvp session extensive [ backup | bypass | destination | detour | down | egress | in-interface | ingress | name | out-interface | p2mp | p2p | ppend | transit | up ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Destination IP address.
	<b>detour</b>	Displays detour session.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress sessions.
	<b>name</b>	Displays sessionn by name.
	<b>out-interface</b>	Displays RSVP sessions going out of an interface.
	<b>p2mp</b>	Displays point to multipoint sessions.
	<b>p2p</b>	Displays point to point sessions.
	<b>ppend</b>	Displays sessions in a soft preemption pending state.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP sessions.

**Modes** User EXEC mode

**Command Output** The `show mpls rsvp session extensive` command displays the following information:

Output field	Description
Ingress RSVP	Displays information about ingress RSVP sessions.
Transit RSVP	Displays information about transit RSVP sessions.
Egress RSVP	Displays information about egress RSVP sessions.
From	Source (ingress LER) of the session; the source address for the LSP that was configured with the <b>from</b> command.

Output field	Description
St	State can be UP or DOWN.
Style	The RSVP reservation style. Possible values are Fixed Filter (FF), Wildcard Filter (WF), or Shared Explicit (SE).
Lbl_In	The label for inbound packets on this LSP.
Lbl_Out	The label applied to outbound packets on this LSP.
Out_If	The outbound interface displays the egress interface for a session. When applicable, the outbound interface displays a VE interface specified by the <i>vid</i> variable.
LSPname	The name of the LSP.
Time left in seconds	The amount of time left for the PATH or RESV refreshes.
Tspec	Traffic engineering specification for the LSP, including the max-rate ("peak"), mean rate ("rate"), number of burst bytes ("size"), maximum policed unit ("M"-or maximum packet size), and minimum policed unit ("m"-or minimum packet size).
Explicit path hop count	The number of explicit hops used in this RSVP session.
Received RRO count	The number of Record Route Objects received on this RSVP session.
PATH sentto	Address of the next LSR in the LSP, and the interface used to reach this LSR. When applicable, 'PATH sentto' displays a VE interface specified by the <i>vid</i> variable.
PATH rcvfrom	Address of the previous LSR in the LSP, and the interface used to reach this LSR. When the session is downstream only, then it is displayed. When applicable, 'PATH rcvfrom' displays a VE interface specified by the <i>vid</i> variable.
PATH history	Displays history of the last 20 RSVP event. Each event contains: <ul style="list-style-type: none"> <li>• Event index (used to provide the number of events).</li> <li>• Time stamp</li> <li>• File name and line number where the event is logged.</li> <li>• Event description and extra information associated with each event.</li> </ul>



**Examples** The following example displays the command output containing the contents of the History buffer for the last 20 RSVP events.

```

device# show mpls rsvp session extensive
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress

Ingress RSVP: 7 session(s)
To      From      St Style Lbl_In Lbl_Out Out_If LSPname
10.33.33.33 10.11.11.11(DI) Up SE - 3 e4/4 rj-vpls
Tunnel ID: 1, LSP ID: 1
Time left in seconds (PATH refresh: 10, ttd: 4288020
                    RESV refresh: 0, ttd: 4288177)
Tspec: peak 0 kbps rate 0 kbps size 0 bytes m 20 M 65535
Explicit path hop count: 1
 10.0.0.6 (S)
Received RRO count: 1
  Protection codes/Rtr Id flag: P: Local N: Node B: Bandwidth I: InUse R: RtrId
 10.0.0.6
Detour Sent: Number of PLR and Avoid Node ID pair(s): 1
 [1]: PLR: 10.1.1.1 Avoid Node: 10.1.1.2
PATH sentto: 10.0.0.6 (e4/4) (MD5 OFF)
RESV rcvfrom: 10.0.0.6 (e4/4) (MD5 OFF)
PATH history:
 1 Dec 10 11:57:59 Query route to 10.33.33.33: nhop 10.0.0.6
 2 Dec 10 11:57:59 Tx PATH: out if(e4/4), flg(0x01000500/0x0000000a)
 3 Dec 10 11:57:59 Rx RESV: label(3), flg(0x01000500/0x0000000a)
 4 Dec 10 11:57:59 Tx cnnt req: hdl(0x0010c001), flg(0x01100500/0x0000000a)
 5 Dec 10 11:57:59 Start TC event(NEW_FLOW): action(0x0000000a)
 6 Dec 10 11:57:59 Rx cnnt resp: hdl(0x0010c001), flg(0x01100500/0x0000000a)
 7 Dec 10 11:57:59 Complete TC event(NEW_FLOW)
RESV history:
 1 Dec 10 11:57:59 Add RSB: style(SE), filterSpec(1), flg(0x00000000)
 2 Dec 10 11:57:59 Add filterSpec: 10.11.11.11/1, label(3)

```

**History**

Release version	Command history
3.6.00	This command was enhanced to include a new option that allows the display of RSVP events such as state transitions and events associated with RSVP sessions.

## show mpls rsvp session (ingress/egress)

Displays Reserved Reservation Protocol (RSVP) ingress or egress session.

**Syntax** `show mpls rsvp session ingress [ backup | brief | bypass | destination | detail | detour | down | extensive | in-interface | name | out-interface | p2mp | p2p | ppend | up | wide ]`

`show mpls rsvp session egress [ backup | brief | destination | detail | detour | down | extensive | in-interface | name | out-interface | p2mp | p2p | ppend | up | wide ]`

<b>Parameters</b>	<b>backup</b>	
	<b>brief</b>	Displays facility backup session.
	<b>bypass</b>	Displays brief session information.
	<b>destination</b>	(For <b>ingress</b> only) Displays bypass session information.
	<b>detail</b>	Destination IP address.
	<b>detour</b>	Displays detailed session information.
	<b>down</b>	Displays detour session.
	<b>extensive</b>	Displays inactive session.
	<b>in-interface</b>	Displays extensive session information.
	<b>name</b>	Displays RSVP sessions coming into an interface.
	<b>out-interface</b>	Displays session by name.
	<b>p2mp</b>	Displays RSVP sessions going out on an interface.
	<b>p2p</b>	Displays point to multipoint sessions.
	<b>ppend</b>	Displays point to point sessions.
	<b>up</b>	Displays sessions in a soft preemption pending status.
	<b>wide</b>	Displays UP session.
		Displays long LSP names.

**Modes** User EXEC mode

## show mpls rsvp session (interface)

Displays RSVP sessions that are coming into (in-interface) or going out to (out-interface) an interface.

**Syntax** **show mpls rsvp session in-interface** { **ethernet** *slot / port* | **pos** *slot / port* | **ve** *interface\_id* }  
**show mpls rsvp session out-interface** { **ethernet** *slot / port* | **pos** *slot / port* | **ve** *interface\_id* }

**Parameters** **ethernet** *slot / port*  
 Displays the specified Ethernet port.

**pos** *slot / port*  
 Displays the specified POS port.

**ve** *interface\_id*  
 Displays the specified Virtual Ethernet Interface ID.

**Modes** User EXEC mode

## show mpls rsvp session name

Displays the Reserved Reservation Protocol (RSVP) session by name.

**Syntax** `show mpls rsvp session name session_name [ [ backup | brief | bypass | destination | detail | detour | down | egress | extensive | in-interface | ingress | out-interface | p2mp | p2p | ppend | transit | up | wide ] extensive ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session information.
	<b>brief</b>	Displays brief session information.
	<b>bypass</b>	Display bypass session information.
	<b>destination</b>	Destination IP address information.
	<b>detail</b>	Displays detailed session information.
	<b>detour</b>	Displays detour session information.
	<b>down</b>	Displays inactive session information.
	<b>egress</b>	Displays egress session information.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session information.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint session information.
	<b>p2p</b>	Displays point to point session information.
	<b>ppend</b>	Displays sessions in the soft preemption pending state.
	<b>transit</b>	Displays transit session information.
	<b>up</b>	Displays up session information.
	<b>wide</b>	Displays the long LSP name.

**Modes** User EXEC mode

**Command Output** The `show mpls rsvp session name` command displays the following information:

Output field	Description
To	Destination (egress LER) of the session.
From	Source (ingress LER) of the session; the source address for the LSP that was configured with the <b>from</b> command.
St	State can be UP or DOWN.
Style	The RSVP reservation style. Possible values are FF (Fixed Filter), WF (Wildcard Filter), or SE (Shared Explicit).
Lbl_in	The label for inbound packets on this LSP.
Lbl_out	The label applied to outbound packets on this LSP.
Out_if	The outbound interface displays the egress interface for a session. When applicable, the outbound interface displays a VE interface specified by the <i>vid</i> variable.
LSPname	The name of the LSP.
Tunnel ID	A numerical value that identifies the tunnel being configured.
Time left in seconds	The amount of time left for the PATH or RESV refreshes.
Tspec	Traffic engineering specification for the LSP, including the max-rate ("peak"), mean rate ("rate"), number of burst bytes ("size"), maximum policed unit ("M"—or maximum packet size), and minimum policed unit ("m"—or minimum packet size).
Setup Priority	An LSPs setup priority is considered during admission control, and its hold priority is considered when bandwidth is allocated to the LSP.  The setup priorities are expressed as numbers between zero (0) (highest priority level) and seven (7) (lowest priority level).
Holding Priority	The hold priority is considered when bandwidth is allocated to the LSP.  The hold priorities are expressed as numbers between zero (0) (highest priority level) and seven (7) (lowest priority level).
Received RRO count	The number of Record Route Objects received on this RSVP session.
PATH sentto	Address of the next LSR in the LSP, and the interface used to reach this LSR. When applicable, PATH sentto displays a VE interface specified by the <i>vid</i> variable.
PATH history	Displays history of the last 20 RSVP events. Each event contains: <ul style="list-style-type: none"> <li>• Event index (used to provide the number of events).</li> <li>• Time stamp.</li> <li>• File name and line number where the event is logged.</li> <li>• Event description and extra information associated with each event.</li> </ul>
RESV history	Displays reservation history.
Session history	Displays session history.
<b>Packet Type</b>	
Path	The number of Path messages sent and received. Path messages store information about the state of the path along the LSRs in the LSP.

<b>Output field</b>	<b>Description</b>
Resv	The number of RESV messages sent and received. RESV messages include FF (Fixed Filter), WF (Wildcard Filter), and SE (Shared Explicit) messages.
PathErr	The number of PathErr messages sent and received.
RevErr	The number of ResvErr messages sent and received.
PathTear	The number of PathTear messages sent and received. PathTear messages cause path states to be deleted.
ResvTear	The number of ResvTear messages sent and received. ResvTear messages cause reservation states to be deleted.
ResvConf	The number of reservation confirmation messages sent and received.
<b>Error</b>	
PATH state timeout	The PATH timeout.
RESV state timeout	The reservation confirmation timeout.
<b>Rcv pkt proc error</b>	
Path	The number of Path messages received with a packet processing error.
Resv	The number of RESV messages received with a packet processing error.
PathErr	The number of PathErr messages received with a packet processing error.
RevErr	The number of ResvErr messages received with a packet processing error.
PathTear	The number of PathTear messages received with a packet processing error.
ResvTear	The number of reservation confirmation messages received with a packet processing error.
ResvConf	The number of reservation confirmation messages received with a packet processing error.

**Examples** The following example shows how the protocol statistics display when using the **extensive** option.

```

device# show mpls rsvp session name lsp1 extensive
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
      DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
      RP:Repaired Session BYI: Bypass Ingress

Total Number of such sessions are: 1
To      From      St  Style  Lbl_In  Lbl_Out  Out If  LSPname
14.14.14.14  12.12.12.12  Up  FF    -      3      e2/I    lsp1
  Tunnel ID: 1, LSP ID: 1
  Time left in seconds (PATH refresh: 26, ttd: 3889074
                        RESV refresh: 4, ttd: 141)
  Tspec: peak 0 kbps rate 0 kbps size 0 bytes m 20 M 65535
  Setup Priority: 7 Holding Priority: 0
  Session attribute flags:0x00
  Received RRO count: 1
  Protection codes/Rtr Id flag: P: Local N: Node B: Bandwidth I: InUse R: RtrId
  22.22.22.14
  PATH sentto: 22.22.22.14 (e2/1 ) (MD5 OFF), Message ID: 1
  RESV rcvfrom: 22.22.22.14 (e2/1 ) (MD5 OFF), Message ID: --
  PATH history:
    1 Dec 11 20:40:23 Add PSB: tunnel endpt 14.14.14.14/12.12.12.12
<SNIP>
    17 Dec 11 20:40:23 Tx Resv to TE-MIB: flg(0x00005404/0x00000000)
  RESV history:
    1 Dec 11 20:40:23 Add RSB: style(FF), filterSpec(1), flg(0x00000000)
    2 Dec 11 20:40:23 Add filterSpec: 12.12.12.12/1, label(3)

  Session history:
    1 Dec 11 20:40:23 A new PSB 0x30ee03c8 created. stack[1]=0x00000001
    stack[2]=0x21bab8d4
<SNIP>
    12 Dec 11 20:40:23 TC-action LDB_CONNECT completed

                                Protocol Stats
                                Since Last Clear
Packet Type      Sent  Received
Path              1      0
Resv              0      0
PathErr          0      0
RevErr           0      0
PathTear         0      0
ResvTear         0      0
ResvConf         0      0

Error            Since Last Clear
PATH state timeout 0
RESV state timeout 0

Rcv pkt proc error:  Since Last Clear
Path                0      0
Resv                0      0
PathErr            0      0
RevErr             0      0
PathTear           0      0
ResvTear           0      0
ResvConf           0      0

```

**History**

Release version	Command history
5.9.00	This command was modified to show the protocol statistics under the <b>extensive</b> option.

## show mpls rsvp session p2mp

Displays Reserved Reservation Protocol (RSVP) point-to-multipoint sessions.

<b>Syntax</b>	<b>show mpls rsvp session p2mp [ brief   detail   down   egress   extensive   in-interface   ingress   name   out-interface   p2mp-id   ppend   s21   transit   up   wide ]</b>
<b>Parameters</b>	<p><b>brief</b> Displays brief session information.</p> <p><b>detail</b> Displays detailed session information.</p> <p><b>down</b> Displays inactive session.</p> <p><b>egress</b> Displays egress session.</p> <p><b>extensive</b> Displays extensive session information.</p> <p><b>in-interface</b> Displays RSVP sessions coming into an interface.</p> <p><b>ingress</b> Displays ingress session.</p> <p><b>name</b> Displays session by name. Some vendors allow each S2L sub-LSP for a P2MP LSP to have a different name. With such configurations in place the name filter responds in two different ways based on what other filters are applied in conjunction to the name filter.</p> <ul style="list-style-type: none"> <li>• When the name filter is applied with p2mp filter and without and s2l filter, the entire P2MP session displays with all the S2L sub-LSPs in the detail format by default even if one of the S2L sub-LSP name matches with the supplied name in the CLI.</li> <li>• When the name filter is applied with both p2mp filter and s2l filter, only that S2L-sub LSP whose name matches the name supplied displays along with the P2MP session's common information in detail format.</li> <li>• When name filter is applied with out-interface filter, only that S2L which matches both criteria displays.</li> <li>• By default, in the common part of the P2MP session information, the name displayed would be the name of the first S2L-sub LSP displays in the detail format when no s2l filter is applied.</li> </ul> <p><b>out-interface</b> Displays RSVP sessions going out on an interface. The out-interface filter would filter and display only those p2mp S2Ls that are going out via the interface requested. Other S2Ls not going out of the interface requested would not be displayed. The part common to all the S2Ls for a P2MP LSP displays first in the detail format followed by the S2L information.</p> <p><b>p2mp-id</b> P2MP ID. It is the IP address picked from PE1 (Ingress), which could be same for multiple P2MP sessions originating from PE1. The P2MP ID is not a loopback address and may be any 32 bit number. The P2MP ID can also be local IP address. The P2MP-ID can be in Ip address or decimal format.</p> <p><b>ppend</b></p> <p><b>s21</b> Displays sessions in soft preemption pending state.</p>



**transit** Displays point to multipoint source to leaf sub-LSPs.

**up** Displays transit session.

**wide** Displays UP session.

Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays the output of the command.

```
device# show mpls rsvp session p2mp
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress
Total Number of such sessions are: 2

Ingress RSVP:    0 session(s)
Transit RSVP:    2 session(s)

P2MP Id          From          Tunnel_Id  Style  Lbl In  Num_S2L  LSPname
10.10.10.1       7.7.7.6       45         SE    1037   3         to-pe2
10.10.10.1       5.5.5.1       43         FF    3021   1         to-nyc

Egress RSVP:    0 session(s)
```

The following example displays the command with the wide option.

```
device# show mpls rsvp session p2mp s2l wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress
Total Number of such sessions are: 2

Ingress RSVP:    0 session(s)
Transit RSVP:    2 session(s)

P2MP_ID          From          Tunnel_ID  Style  Lbl In  Num_S2L  LSPname
10.10.10.1       7.7.7.6       45         SE    1037   3         to-pe2

To              From          St Style  Lbl In  Lbl Out  Out If  LSPname
92.92.94.48     7.7.7.6       Up SE    1037   1028    ve101   to-pe2
92.92.95.48     7.7.7.6       Up SE    1037   1028    ve101   to-pe3
92.92.96.48     7.7.7.6       Up SE    1037   1028    ve101   to-pe4
```

The following example displays the command using the option P2MP-ID. The P2MP-ID can be in Ip address or decimal format.

```
device# show mpls rsvp session p2mp p2mp-id 168430081

Total Number of such sessions are: 1
Ingress RSVP:    0 session(s)
Transit RSVP:    1 session(s)

P2MP ID          From          Tunnel_ID  Style  Lbl In  Num_S2L  LSPname
168430081        7.7.7.6       45         SE    1037   3         to-pe2

Egress RSVP:    0 session(s)

device#show mpls rsvp sess p2mp p2mp-id 20.0.0.1

Total Number of such sessions are: 1
Ingress RSVP:    0 session(s)
Transit RSVP:    1 session(s)

P2MP ID          From          Tunnel_ID  Style  Lbl In  Num_S2L  LSPname
10.10.10.1       7.7.7.6       45         SE    1037   3         to-pe2

Egress RSVP:    0 session(s)
```

The following example displays the output of the command with the detail option. The first part of the command displays the attributes and information that are common to all S2Is of the P2MP LSP. The second part displays information about each of the individual S2L sub LSP. In this output, there are two S2Ls for the session.

```

device# show mpls rsvp session p2mp detail

Total Number of such sessions are: 1

Ingress RSVP:      0 session(s)
P2MP Id            From            Tunnel_Id  Style  Lbl_In  Num_S2L  LSPname
10.10.10.1         7.7.7.6          45         SE    1037    3         to-pe2

  Tspec: peak 1 kbps rate 1 kbps size 0 bytes m 20 M 65535
  Setup Priority: 7 Holding Priority: 0
  Session attribute flags:0x04(SE Style)

To                From                St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
92.92.94.48       7.7.7.6             Up  SE    1037    1028     ve101   to-pe2

  LSP ID: 2, Sub-group Originator ID: 7.7.7.6 Sub-group ID: 2
  Time left in seconds (PATH refresh: 0, ttd: 133
                        RESV refresh: 0, ttd: 136)
  Explicit path hop count: 2
  7.1.13.2 (S) -> 21.21.21.1 (S) -> 31.31.31.1(S)
  Received RRO count: 2

  Protection codes/Rtr Id flag: P: Local  N: Node  B: Bandwidth  I: InUse R: RtrId
  7.1.13.2 -> 21.21.21.1 -> 31.31.31.1

  PATH rcvfrom: 7.1.18.2          (e4/1)          (MD5 OFF), Message ID: 75
  PATH sentto:  7.1.13.2          (ve101)         (MD5 OFF), Message ID: 2575
  RESV rcvfrom: 7.1.13.2          (ve101)         (MD5 OFF), Message ID: 54024

To                From                St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
92.92.95.48       7.7.7.6             Up  SE    1037    1028     ve101   to-pe3

  LSP ID: 2, Sub-group Originator ID: 7.1.18.2 Sub-group ID: 2
  Time left in seconds (PATH refresh: 0, ttd: 143
                        RESV refresh: 0, ttd: 121)
  Explicit path hop count: 3
  7.1.13.2 (S) -> 21.21.21.1 (S)-> 41.41.41.1 (S)
  Received RRO count: 3
  Protection codes/Rtr Id flag: P: Local  N: Node  B: Bandwidth  I: InUse R: RtrId
  7.1.13.2 -> 21.21.21.1 -> 41.41.41.1
  PATH rcvfrom: 7.1.18.2          (e4/1)          (MD5 OFF), Message ID: 77
  PATH sentto:  7.1.13.2          (ve101)         (MD5 OFF), Message ID: 2577
  RESV rcvfrom: 7.1.13.2          (ve101)         (MD5 OFF), Message ID: 54026
<SNIPPED output for 3rd S2L>
Egress RSVP:      0 session(s)

```

**History**

Release version	Command history
5.5.00	This command was modified to include the P2MP option.

## show mpls rsvp session p2p

Displays Reserved Reservation Protocol (RSVP) point-to-point sessions.

**Syntax** `show mpls rsvp session p2p [ backup | brief | bypass | destination | detail | detour | down | egress | extensive | in-interface | ingress | name | out-interface | ppend | transit | up | wide ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session information.
	<b>brief</b>	Displays brief session information.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Destination IP address.
	<b>detail</b>	Displays detailed session information.
	<b>detour</b>	Displays detour session.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>ppend</b>	Displays sessions in a soft preemption pending state.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

<b>History</b>	<b>Release version</b>	<b>Command history</b>
	5.5.00	This command was modified to include the P2P option.

# show mpls rsvp session ppend

Displays Reserved Reservation Protocol (RSVP) sessions that are in a soft preemption state.

**Syntax** `show mpls rsvp session ppend [ brief | destination | detail | down | egress | extensive | in-interface | ingress | name | out-interface | p2mp | p2p | transit | up | wide ]`

<b>Parameters</b>	<b>brief</b>	Displays brief session information.
	<b>destination</b>	Destination IP address.
	<b>detail</b>	Displays detailed session information.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint session.
	<b>p2p</b>	Displays point to point session.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays Up session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays the appended view of the session.

```
device(config-mpls-lsp-high)#show mpls rsvp sess ppend
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
RP:Repaired Session BYI: Bypass Ingress

Total Number of such sessions are: 1

Transit RSVP: 1 session(s)
To          From          St  Style  Lbl_In  Lbl_Out  Out_If  LSPname
80.80.80.80 40.40.40.40 Up   SE     1024    3        e1/7    1
```

## show mpls rsvp session transit

Displays Reserved Reservation Protocol (RSVP) transit sessions.

<b>Syntax</b>	<b>show mpls rsvp session transit [ backup   brief   destination   detail   detour   down   extensive   in-interface   name   out-interface   p2mp   p2p   ppend   statistics   up   wide ]</b>
<b>Parameters</b>	<p><b>backup</b> Displays facility backup session.</p> <p><b>brief</b> Displays brief session information.</p> <p><b>destination</b> Destination IP address.</p> <p><b>detail</b> Displays detailed session information.</p> <p><b>detour</b> Displays detour session.</p> <p><b>down</b> Displays inactive session.</p> <p><b>extensive</b> Displays extensive session information.</p> <p><b>in-interface</b> Displays RSVP session coming into an interface.</p> <p><b>name</b> Displays session by name.</p> <p><b>out-interface</b> Displays RSVP sessions going out on an interface.</p> <p><b>p2mp</b> Displays point to multipoint sessions.</p> <p><b>p2p</b> Displays point to point sessions.</p> <p><b>ppend</b> Displays sessions on a soft preemption pending state.</p> <p><b>statistics</b> Displays transit LSP traffic statistics.</p> <p><b>up</b> Displays UP session.</p> <p><b>wide</b> Displays long LSP names.</p>
<b>Modes</b>	User EXEC mode

**Examples** The following example displays when at least one LP does not support all three statistics.

```
device# show mpls rsvp session transit statistics
* means statistics collection is not supported on one or more of the line cards

Total Number of such sessions are: 4

To          From          Packets  Bytes  Rate (kbps)  LSPname
150.150.150.10  190.190.190.9  1007    7654903*  53556*      test1
150.150.150.10  190.190.190.9   0        0*        0*          test2
```

The following example displays when all of the LPs support all three statistics.

```
device# show mpls rsvp session transit statistics
* means statistics collection is not supported on one or more of the line cards
```

Total Number of such sessions are: 4

To	From	Packets	Bytes	Rate(kbps)	LSPname
150.150.150.10	190.190.190.9	1007	7654903	53556	test1
150.150.150.10	190.190.190.16	626241	56255	485	test2
150.150.150.10	190.190.190.9	65946	35648469	63582	test3
150.150.150.10	190.190.190.9	0	0	0	test4

**History**

Release version	Command history
5.4.00	This command was modified to include the keyword "statistics".

## show mpls rsvp session up

Displays the number of UP Reserved Reservation Protocol (RSVP) sessions.

**Syntax** `show mpls rsvp session up [ backup | brief | bypass | destination | detail | detour | egress | extensive | in-interface | ingress | name | out-interface | p2mp | p2p | ppend | transit |wide ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session.
	<b>brief</b>	Displays brief session information.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Destination IP address.
	<b>detail</b>	Displays detailes session information.
	<b>detour</b>	Displays detour session.
	<b>egress</b>	Displays egress session.
	<b>extensive</b>	Displays extensive session information.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint sessions.
	<b>p2p</b>	Displays point to point sessions.
	<b>ppend</b>	Displays sessions in a soft preemption pending status.
	<b>transit</b>	Displays transit session.
	<b>wide</b>	Displays long LSP names.

**Modes** User EXEC mode

**Examples** The following example displays the command using the wide option.

```

device#show mpls rsvp session up wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
       DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
       RP:Repaired Session BYI: Bypass Ingress

Total Number of such sessions are: 59946
Transit RSVP: 59439 session(s)

To          From          St Style Lbl_In  Lbl_Out Out_If LSPname
172.16.20.1 172.16.50.1   Up SE   58368   3       e15/2  LSP-63301
172.16.22.1 172.16.30.1   Up SE   15873   23328   e21/6  LSP-10002
172.16.22.1 172.16.32.1(BI) Up -    15873   45255   e1/2   LSP-10002
172.16.22.1 172.16.30.1   Up SE   54733   49673   e15/1  LSP-10003
172.16.22.1 172.16.32.1(BI) Up -    54733   43841   e1/2   LSP-10003
172.16.22.1 172.16.30.1   Up SE   19472   15317   e1/8   LSP-10006
172.16.22.1 172.16.32.1(BI) Up -    19472   15317   e1/2   LSP-10006

```



## show mpls rsvp session wide

Displays Reserved Reservation Protocol (RSVP) sessions with long LSP names.

**Syntax** `show mpls rsvp session wide [ backup| bypass | destination | detour | down | egress | in-interface| ingress | name | out-interface | p2mp | p2p | ppend | transit | up ]`

<b>Parameters</b>	<b>backup</b>	Displays facility backup session.
	<b>bypass</b>	Displays bypass session.
	<b>destination</b>	Destination IP address.
	<b>detour</b>	Displays detour session.
	<b>down</b>	Displays inactive session.
	<b>egress</b>	Displays egress session.
	<b>in-interface</b>	Displays RSVP sessions coming into an interface.
	<b>ingress</b>	Displays ingress session.
	<b>name</b>	Displays session by name.
	<b>out-interface</b>	Displays RSVP sessions going out on an interface.
	<b>p2mp</b>	Displays point to multipoint sessions.
	<b>p2p</b>	Displays point to point sessions.
	<b>ppend</b>	Displays sessions in a soft preemption pending status.
	<b>transit</b>	Displays transit session.
	<b>up</b>	Displays UP session.
<b>Modes</b>	User EXEC mode	

**Examples** The following example displays the output of the command.

```

device#show mpls rsvp session wide
Codes: DI:Ingress Detour DT:Transit Detour DM:Merged Detour
      DE:Egress Detour BI:Ingress Backup BM: Merged Backup BE:Egress Backup
      RP:Repaired Session BYI: Bypass Ingress

Total Number of such sessions are: 1611

Ingress RSVP: 1088 session(s)
To          From          St Style Lbl_In  Lbl_Out Out_If LSPname
3.3.3.1     2.2.2.1     Up SE   -       3       ve207   to-
nakul-156-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve205   to-
nakul-179-3.3.3.1
3.3.3.1     2.2.2.1     Up FF   -       3       ve225   to-nakul-4
3.3.3.1     2.2.2.1     Up SE   -       3       ve218   to-
nakul-17-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve209   to-
nakul-8-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve206   to-
nakul-55-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve216   to-
nakul-40-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve220   to-
nakul-194-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve204   to-
nakul-78-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve213   to-
nakul-212-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve217   to-
nakul-141-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve208   to-
nakul-32-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve215   to-
nakul-164-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve223   to-
nakul-197-3.3.3.1
3.3.3.1     2.2.2.1     Up SE   -       3       ve225   to-
nakul-174-3.3.3.1

device#

```

**History**

Release version	Command history
5.1.00	This command was modified to include the wide option. This option displays the full LSP name on a single line.

## show mpls rsvp statistics

Displays the RSVP control packet statistics combined over all the interfaces.

**Syntax** `show mpls rsvp statistics`

**Modes** User EXEC mode

**Usage Guidelines** The device constantly gathers RSVP statistics. RSVP statistics are collected from the time RSVP is enabled, as well as from the last time the RSVP statistics counters were cleared.

The command resets the counters listed under the 'Since last clear' column for the **show mpls rsvp interface detail** and **show mpls rsvp statistics** commands.

This command operates in all modes.

**Command Output** The **show mpls rsvp statistics** command displays the following information:

Output field	Description
Path	The number of Path messages sent and received. Path messages store information about the state of the path along the LSRs in the LSP.
Resv	The number of RESV messages sent and received. RESV messages include Fixed Filter (FF), Wildcard Filter (WF), and Shared Explicit (SE) messages.
PathErr	The number of PathErr messages sent and received.
ResvErr	The number of ResvErr messages sent and received.
PathTear	The number of PathTear messages sent and received. PathTear messages cause path states to be deleted.
ResvTear	The number of ResvTear messages sent and received. ResvTear messages cause reservation states to be deleted.
ResvConf	The number of reservation confirmation messages sent and received.
Rcv pkt bad length	The number of times a packet was not processed because it was the wrong length.
Rcv pkt unknown type	The number of times an RSVP packet was not processed because it was not one of the types defined in RFC 2205.
Rcv pkt bad version	The number of times a packet was not processed because it was an RSVP version other than one.
Rcv pkt bad cksum	The number of times a packet was not processed because of a bad RSVP checksum.
Memory alloc fail	The number of times a packet was not processed because RSVP memory allocation failed on the device.

**TABLE 10** Rcv pkt processing errors

Output field	Description
Path	The number of Path messages received with a packet processing error.
Resv	The number of RESV messages received with a packet processing error.
PathErr	The number of PathErr messages received with a packet processing error.
ResvErr	The number of ResvErr messages received with a packet processing error.
PathTear	The number of PathTear messages received with a packet processing error.
ResvTear	The number of reservation confirmation messages received with a packet processing error.
ResvConf	The number of reservation confirmation messages received with a packet processing error.

**Examples** The following example displays the **show mpls rsvp statistics** command output.

```

device# show mpls rsvp statistics
Total Since last clear
PacketType Sent Received Sent Received
Path 4 4 4 4
Resv 4 4 4 4
PathErr 0 0 0 0
ResvErr 0 0 0 0
PathTear 0 0 0 0
ResvTear 0 0 0 0
ResvConf 0 0 0 0
Errors Total Since last clear
Rcv pkt bad length 0 0
Rcv pkt unknown type 0 0
Rcv pkt bad version 0 0
Rcv pkt bad cksum 0 0
Memory alloc fail 0 0
Rcv pkt processing error:
Path 0 0
Resv 0 0
PathErr 0 0
ResvErr 0 0
PathTear 0 0
ResvTear 0 0
ResvConf 0 0
    
```

**History**

Release version	Command history
5.6.00	The 'Hello' packet type was added.  The <b>clear mpls rsvp statistics</b> command clears the 'since last clear' column for the 'Hello' packet type.

## show mpls static-lsp

Displays the static LSPs in the system.

**Syntax** `show mpls static-lsp [ brief | debug | detail | wide ]`  
`show mpls static-lsp extensive [ descending ]`  
`show mpls static-lsp name lsp-name extensive [ descending ]`  
`show mpls static-lsp { down | up } [ detail | wide | extensive [ descending ] ]`

**Parameters**

- brief** Displays brief information.
- debug** Displays debug information, with history.
- detail** Displays detailed information.
- wide** Displays long LSP names.
- extensive** Displays detailed information with History.
- descending** Displays LSP History with newer entries on top.
- name *lsp-name*** Displays information by LSP name.
- down** Displays operationally DOWN LSPs.
  - detail** Displays detailed information of the operationally DOWN LSPs.
  - extensive** Displays detailed information with History of the operationally DOWN LSPs.
  - wide** Displays long LSP names of the operationally DOWN LSPs.
- up** Displays operationally UP LSPs.

**Modes** User EXEC mode

**Command Output** The `show mpls static-lsp` command displays the following information:

Output field	Description
Name	Name of the static LSP as configured by the user.
Admin	Whether or not the static LSP is enabled.
Oper	Operational state of the LSP.
In-label	The in-label configured for the LSP.

Output field	Description
Out-label	The out-label configured. If none, the implicit-null label 3 is shown.
Next-hop	The configured next-hop.
Out-Intf	The out-interface that corresponds to the next-hop configured.

The **show mpls static-lsp extensive** command displays the following information:

Output field	Description
Role	The role of the LSP. Only transit.
Enabled	Whether the LSP is enabled or not.
Times LSP goes UP since enabled	Number of times the LSP has gone UP since being enabled.
In-label	The in-label configured for the LSP.
Next-hop	The configured next-hop.
History	The static-lsp sample History.
Static-LSP	Identifier of the static-LSP.
Role	The role of the LSP. Currently, only transit.
Enabled	Whether the LSP is enabled or not.
UP	Whether LSP is operational or not.
LSP error	Reason LSP is down or if there was any error during any processing on the LSP.
Times LSP goes UP since enabled	Number of times the LSP has gone UP since being enabled.
In-label	The in-label configured for the LSP.
Out-label	The configured out-label, three if implicit-null.
Next-hop	The configured next-hop.
Out-interface for the next-hop	The out-interface that corresponds to the configured next-hop.
Next-hop interface address to reach configured next-hop	The interface address to reach the next-hop address configured. It is the same as the configured next-hop in case the configured next-hop address is directly connected and different if not directly-connected.

**Examples** The following example displays the output of the **show mpls static-lsp** command.

```
device# show mpls static-lsp
Number of transit lsps: 2
Name      Admin  Oper  In-label  Out-label  Next-hop      Out-Intf
c2        UP     DOWN  21        1024       160.168.123.122  e2/1
c3        UP     UP    22        3          160.168.111.100  ve10
```

The following example displays the output of the **show mpls static-lsp extensive** command.

```
device# show mpls static-lsp extensive
Static-LSP t1, Role: Transit
  Enabled: Yes, UP: Yes
  Times LSP goes up since enabled: 1
  In-label: 201, Out-label: 3,
  Next-hop: 120.120.120.2,
  Out-Interface for the next-hop: e2/1
  Next-hop interface address to reach configured next-hop: 10.1.1.2
  History
    0 Jul 11 01:38:32 : LSP tunnel is Enabled
    1 Jul 11 01:38:33 : Static Transit LSP UP
Static-LSP t2, Role: Transit
  Enabled: Yes, UP: No
  LSP error: No interface available for next-hop
  Times LSP goes up since enabled: 1
  In-label: 202, Out-label: 3,
  Next-hop: 20.1.1.2,
  Out-Interface for the next-hop: --
  Next-hop interface address to reach configured next-hop: --
  History
    0 Jul 11 01:38:32 : LSP tunnel is Enabled
```

#### History

Release version	Command history
5.8.00	This command was modified to include the keyword "descending" to display the LSP History in reverse chronological order.

## show mpls statistics 6pe

Displays 6PE MPLS statistics.

- Syntax** `show mpls statistics 6pe slot/port | vrf`
- Parameters** *slot/port* Displays specified interface number.
- vrf** Displays statistics based on VRFs.
- Modes** User EXEC mode.
- Usage Guidelines** The `clear mpls statistics 6pe slot/port` command clears the 6pe statistics.
- Examples** The following example displays the number of 6PE packets going into or coming out of the MPLS cloud. The packet counter is per PPCR.
- ```
device#show mpls statistics 6pe
In-Port(s)      Endpt Out-Pkt      Tnl Out-Pkt
e2/1 - e2/4      0                0
e2/5 - e2/8      0                0
e4/1 - e4/2      41810353         0
e4/3 - e4/4      0                41810352
device
```



## show mpls statistics bypass-lsp

Displays the incoming packet count and byte count rate (in bytes) on a tunnel interface for bypass LSPs.

**Syntax** `show mpls statistics bypass-lsp lsp-name`

**Parameters** *lsp-name*  
The name of the specified LSP.

**Modes** User EXEC mode

**Examples** The following example shows the `show mpls statistics bypass-lsp lsp-name` command.

```
device# show mpls statistics bypass-lsp
LSP B1
  Tunnel interface   tn14  100 pkt   2200 Byte Last Update Dec 17 18:51:21.000
LSP B1
  Tunnel interface   tn16  900 pkt   33445 Byte Last Update Dec 17 18:51:38.000
LSP B1
  Tunnel interface   tn19  78 pkt   7229 Byte Last Update Dec 17 18:51:41.000
LSP B1
  Tunnel interface   tn115 456 pkt   2398 Byte Last Update Dec 17 18:52:1.000
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

## show mpls statistics label

Displays statistics for LDP ECMP paths.

**Syntax** `show mpls statistics label`

**Parameters** `label`

Displays the in-label statistics.

**Modes** User EXEC mode

**Command Output** The `show mpls statistics label` command displays the following information:

| Output field    | Description                                                      |
|-----------------|------------------------------------------------------------------|
| In-label        | The MPLS label ID.                                               |
| In-Port (s)     | The port where the traffic arrives.                              |
| In-Packet Count | The number of packets meeting the In-label and In-port criteria. |
| In-Bytes Count  | The number of bytes meeting the In-label and In-port criteria.   |

**Examples** The following example displays all of the MPLS traffic statistics by their MPLS label.

```
device# show mpls statistics label
In-label  In-Port(s)      In-Packet Count
1024     e3/1                 315431
         e3/2                 349193
         e3/3                 0
         e3/4                 0
1025     e3/1                 419750
         e3/2                 0
         e3/3                 0
         e3/4                 0
1024     e5/1 - e5/10        364690
         e5/11 - e5/20    0
         e5/21 - e5/30    0
1025     e5/1 - e5/10        0
         e5/11 - e5/20    0
         e5/21 - e5/30    0
```

The following example displays all the MPLS traffic statistics by their MPLS label for a Brocade NetIron CES Series or Brocade NetIron CER Series device.

```
device# show mpls statistics label
In-label  In-Port(s)      In-Bytes Count
1024     e1/1-e1/24      315431
         e1/25-e1/48    0
```

The following example displays all MPLS traffic statistics, by their MPLS label, which are gathered by the corresponding network processor.

```
device# show mpls statistics label 3/1
In-label  In-Port(s)      In-Packet Count
1024     e3/1 - e3/20    30
1026     e3/1 - e3/20    21
1030     e3/1 - e3/20    100
1032     e3/1 - e3/20    0
1033     e3/1 - e3/20    0
1034     e3/1 - e3/20    12
1036     e3/1 - e3/20    0
```

The following example displays all MPLS traffic statistics by their MPLS label for a specific port on a Brocade NetIron CES Series or Brocade NetIron CER Series device.

```
device# show mpls statistics label 1/1
In-label    In-Port(s)    In-Bytes count
1024        e1/1-e1/24    315431
```

**History**

| Release version | Command history                                                     |
|-----------------|---------------------------------------------------------------------|
| 5.1.00          | This command was modified to display statistics for LDP ECMP paths. |

# show mpls statistics ldp transit

Displays the traffic statistics for transit LDP FECs.

**Syntax** `show mpls statistics ldp transit [ fec ip-addr [subnet-mask ] ]`

**Parameters** `fec ip_addr`

Displays the traffic statistics for the transit LDP FECs.

*IP-subnet-mask*

Specifies an IP subnet-mask length.

**Modes** User EXEC mode

**Usage Guidelines** This command operates in all modes.

Packet count is not available for Brocade NetIron CES Series and Brocade NetIron CER Series devices.

**Command Output** The `show mpls statistics ldp transit` command displays the following information:

| Output field | Description                                        |
|--------------|----------------------------------------------------|
| FEC          | The specified FEC for MPLS LDP transit statistics. |
| Packets      | Specifies the number of packets received.          |
| Bytes        | Specifies the number of bytes received.            |
| Rate-kbps    | Rate is in kilobits per second.                    |

**Examples** The following example displays output from the `show mpls statistics ldp transit` command:

```
device# show mpls statistics ldp transit
FEC          Packets    Bytes      Rate-kbps
10.35.3.0/30      0          0*         0*
10.35.10.1/32     0          0*         0*
10.255.245.214/32 112        7566182*  6224*
192.168.37.36/30 532114     2350644*  564*
```

\* means statistics collection is not supported on one or more of the line cards.

The following example displays output from the `show mpls statistics transit` command with the `fec` keyword:

```
device# show mpls statistics ldp transit fec 10.255.245.214
FEC          Packets    Bytes      Rate-kbps
10.255.245.214/32 112        7566182*  6224*
```

\* means statistics collection is not supported by one or more of the line cards.

**History**

| Release version | Command history                                                                                                         |
|-----------------|-------------------------------------------------------------------------------------------------------------------------|
| 5.4.00          | This command is modified to include the parameters <code>transit</code> , <code>fec</code> , and <code>ip_addr</code> . |

## show mpls statistics ldp tunnel

Displays the total combined statistics of all ECMP paths of an LDP tunnel with LDP ECMP LER feature.

**Syntax** `show mpls statistics ldp tunnel [ dec | vif-index ]`

**Parameters** *dec*

Specifies the destination prefix.

*vif-index*

Displays the total combined statistics of all ECMP paths of an LDP tunnel with LDP ECMP LER feature.

**Modes** User EXEC mode

**Usage Guidelines** The statistics are not accurate when the system runs out of CAM entries for all the ECMP paths.

**Command Output** The `show mpls statistics ldp tunnel` command displays the following information:

| Output field | Description                                                                                          |
|--------------|------------------------------------------------------------------------------------------------------|
| LSP          | The name of the LSP that statistics are being displayed for (displayed for RSVP-signaled LSPs only). |
| tnl          | The index number of the MPLS tunnel                                                                  |
| pkt          | The total number of packets forwarded through the specified LSP.                                     |
| Byte         | The total number of bytes forwarded through the specified LSP.                                       |
| Avg. pps     | The number of packets-per-second forwarded through the specified LSP.                                |
| Avg. Bps     | The number of bytes-per-second forwarded through the specified LSP.                                  |

**Examples** The following example shows the output of the `show mpls statistics ldp tunnel` command.

```
device# show mpls statistics ldp tunnel
LDP tunnel interface tn113 0 pkt 0 Byte 0 Avg. pps 0 Avg. Bps
```

**History**

**Release Version** **Command history**

5.5.00 This command was modified to show the total combined statistics of all ECMP paths of an LDP tunnel with the LDP ECMP LER feature.

## show mpls statistics lsp

Displays ingress tunnel accounting for RSVP-signaled LSPs.

**Syntax** `show mpls statistics lsp [ lsp_name ]`

**Parameters** *lsp\_name*  
Displays statistics for a specified LSP.

**Modes** User EXEC mode

**Examples** The following example displays output from the **show mpls statistics lsp** command:

```
device# show mpls statistics lsp
LSP tope4
  Tunnel index 0 0 pkt 0 Byte 0 Avg. pps 0 Avg. Bps
LSP 400
  Tunnel index 2 0 pkt 0 Byte 0 Avg. pps 0 Avg. Bps
LSP 4000
  Tunnel index 3 0 pkt 0 Byte 0 Avg. pps 0 Avg. Bps
LSP tope41
  Tunnel index 4 99205408 pkt 11314220016 Byte 84459 pps 9628340 Bps
```

## show mpls statistics oam

Displays OAM MPLS statistics.

**Syntax** `show mpls statistics oam`

**Modes** User EXEC mode.

**Usage Guidelines** Use the `show mpls statistics oam` command to display the following LSP ping and traceroute counters:

- Ping and traceroute requests that are issued by the user
- Echo requests sent
- Echo requests received
- Echo request time-outs
- Echo replies sent
- Echo replies received
- Echo replies with error return codes

The `clear mpls statistics oam` command clears the LSP ping and traceroute counters.

**Examples** The following example displays the output of the `show mpls statistics oam` command.

```
device # show mpls statistics oam
User ping request processed: 8
User traceroute request processed: 3
Echo requests: sent(102658), received(2865), timeout(0)
Echo replies: sent(2865), received(102628)
Echo reply return code distribution: TX RX
Egress(3) : 0 102628
Transit(8) : 0 0
No return code(0) : 0 0
Malformed request(1) : 0 0
Unsupported TLV(2) : 2865 0
No FEC mapping(4) : 0 0
DS map mismatch(5) : 0 0
Unknown upstream intf(6) : 0 0
Reserved return code(7) : 0 0
Unlabeled output intf(9) : 0 0
FEC mapping mismatch(10) : 0 0
No label entry(11) : 0 0
Rx intf protocol mismatch(12) : 0 0
Premature LSP termination(13) : 0 0
```

## show mpls statistics vll

Displays VLL endpoint traffic statistics to see the forwarding counters for each VLL configured on the system.

|                       |                                                                                                                                                                                                                                                     |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>         | <b>show mpls statistics vll [ <i>vll-id</i> <b>extended-counters</b>   <i>vll_name</i> <b>extended-counters</b> ]</b>                                                                                                                               |
| <b>Parameters</b>     | <p><i>vll_id</i><br/>Specifies the identifier of a VLL instance.</p> <p><i>vll_name</i><br/>Specifies the configured name for a VLL instance.</p> <p><b>extended-counters</b><br/>Displays extended counter (Generation 2 and 3a modules only).</p> |
| <b>Modes</b>          | User EXEC mode.                                                                                                                                                                                                                                     |
| <b>Command Output</b> | The <b>show mpls statistics vll</b> command displays the following information:                                                                                                                                                                     |

| Output field     | Description                                                              |
|------------------|--------------------------------------------------------------------------|
| VLL-Name         | The configured name of the VLL instance.                                 |
| VLL-Ports        | The port where the traffic is monitored.                                 |
| VLL-ingress-Pkts | Packets arriving from the Customer Endpoint.                             |
| VLL-Egress-Pkts  | Packets arriving from the MPLS core and going to the customer interface. |

**Examples** The following example displays output of all VLL traffic statistics on a Brocade device.

```
device# show mpls statistics vll
VLL-name      VLL-Ports      VLL-Ingress-Pkts      VLL-Egress-Pkts
-----
VLL1          e1/1           100                    100
VLL2          e1/4           100                    100
```

### NOTE

The VLL name repeats for each module where the statistics are collected and display on the Management console.

The following example shows the output of VLL traffic statistics for a VLL instance, specified by its VLL name.

```
device# show mpls statistics vll vll1
VLL-Name      VLL-Ports      VLL-Ingress-Pkts      VLL-Egress-Pkts
-----
VLL1          e1/1           100                    100
```

The following example shows the output of VLL traffic statistics for a VLL specified, by its VLL ID.

```
device# show mpls statistics vll 4
VLL-Name      VLL-Ports      VLL-Ingress-Pkts      VLL-Egress-Pkts
-----
VLL1          e1/1           100                    100
```



## show mpls statistics vll-local

When extended counters are enabled, displays the number of bytes and packets received and sent on a particular endpoint or all endpoints of that Local VLL instance.

**Syntax** `show mpls statistics local-vll [vll_name | vll_id [extended-counters [ [vlan vlan_id] [ethernet port_id ] ] ] ]`

**Parameters**

- `vll_name` Specifies the configured name for the Local VLL instance.
- `vll_id` Specifies the ID of a Local VLL instance.
- `extended-counters` Enables the extend counters for a particular Local VLL instance.
- `vlan vlan_id` Specifies the ID of the configured VLAN.
- `ethernet port_id` Specifies the Ethernet port.

**Modes** User EXEC mode.

### Usage Guidelines

**Command Output** The `show mpls statistics vll-local` command with the `extended-counters` option displays the following information:

| Output field | Description                                                                    |
|--------------|--------------------------------------------------------------------------------|
| VLL          | The configured name for a Local VLL instance.                                  |
| VLL-ID       | The ID of the Local VLL instance.                                              |
| VLAN         | The ID of the configured VLAN.                                                 |
| Port         | The port ID of the interface for which the user wants to display the counters. |
| RxPkts       | The number of packets received at the specified port.                          |
| TxPkts       | The number of packets transmitted from the specified port.                     |
| RxBytes      | The number of bytes received at the specified port.                            |
| TxBytes      | The number of bytes transmitted from the specified port.                       |

**Examples** The following example displays the output of the `show mpls statistics vll-local` command with the `extended-counters` option:

```
device# show mpls statistics vll-local loc8 extended-counters
VLL loc8, VLL-ID9:Extended Counters (only applicable for G2 modules)
VLAN  Port  RxPkts  TxPkts  Rxbytes  TxBytes
94    5/2    4639941  0       1187824896  0
      p0     0        0        0         0
      p1     0        0        0         0
      p2     0        0        0         0
      p3     0        0        0         0
      p4    4639941  0       1187824896  0
      p5     0        0        0         0
      p6     0        0        0         0
      p7     0        0        0         0
```

When the per-VLAN, port, and priority-based accounting mode is disabled, the following output is displays for the **show mpls statistics vll-local** command with the **extended-counters** option:

```
device# show mpls statistics vll-local loc8 extended-counters
VLL loc8, VLL-ID9:Extended Counters (only applicable for G2 modules)
VLAN    Port    RxPkts    TxPkts    Rxbytes    TxBytes
94      5/2    1175769   0         300996864  0
92      8/2    0         1178559   0         301711104
```

# show mpls statistics vpls

Displays statistics based on VPLSs.

**Syntax** `show mpls statistics vpls [ vpls_id | vpls_name ]`

`show mpls statistics vpls { vpls_id | vpls_name } extended-counters vlan vlan_id [ detail | routed | switched ]`

`show mpls statistics vpls { vpls_id | vpls_name } extended-counters vlan vlan_id [ inner-vlan inner_vlan_id ] [ ethernet slot / port ] [ detail | routed | switched ]`

**Parameters** `vpls_id`

Displays specified VPLS by numerical ID.

`vpls_name`

Displays specified VPLS by name.

`vlan vlan_id`

Displays Extended Counters for end points of a VPLS VLAN (single tag only).

**extended-counters**

Displays Extended Counters (G2/G3 modules only).

**detail**

Displays Extended Counters in a detailed format.

**routed**

Displays Extended Counters for routed packets.

**switched**

Displays Extended Counters for switched packets.

**inner-vlan inner\_vlan\_id**

Specifies the ID of the configured inner VLAN.

**ethernet slot / port**

Displays Extended Counters for a VPLS endpoint.

**Modes** User EXEC mode

**Examples** The following example displays the `show mpls statistics vpls` command with the **extended-counters detail** option.

```
device#show mpls statistics vpls 1 extended-counters detail
VPLS Extended Counters (only applicable for G2 modules):
VPLS Name: a, VPLS Id: 1

VPLS Vlan: vlan 100
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/1
  Routed      0           0           0           0
  Switched 6525316    15195085    574227808    1337167480
  Combined 6525316    15195085    574227808    1337167480

VPLS Vlan: vlan 200
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/8
  Routed      0           0           0           0
  Switched 17084263    5845698     1503415144    514421424
  Combined 17084263    5845698     1503415144    514421424
```

The following example displays the **show mpls statistics vpls** command with the **extended-counters routed** option.

```
device#show mpls statistics vpls 1 extended-counters routed
VPLS Extended Counters (only applicable for G2 modules):
VPLS Name: a, VPLS Id: 1

VPLS Vlan: vlan 100
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/1    0            0            0            0

VPLS Vlan: vlan 200
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/8    0            0            0            0
```

The following example displays the **show mpls statistics vpls** command with the **extend-counters switched** option.

```
device#show mpls statistics vpls 1 extended-counters switched
VPLS Extended Counters (only applicable for G2 modules):
VPLS Name: a, VPLS Id: 1

VPLS Vlan: vlan 100
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/1    6525316     15195085     574227808    1337167480

VPLS Vlan: vlan 200
Interface RxPkts      TxPkts      RxBytes      TxBytes
eth 4/8    17084263    5845698      1503415144   514421424
```

**History**

| Release version | Command history                                                                                                                                                                                            |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5.4.00          | This command was modified to display MPLS routed and switched statistics. Use this command to get statistics per VLAN and per interface, either routed or switched. This is available for only Gen2 cards. |
| 5.9.00          | This command was modified to include the <b>inner-vlan</b> <i>vlan_id</i> parameter.                                                                                                                       |

## show mpls statistics vrf

Displays statistics based on Virtual Routing and Forwarding (VRF)s.

**Syntax** `show mpls statistics vrf vrf_name`

**Parameters** `vrf_name`  
Displays specified VRF by name.

**Modes** User EXEC mode

**Command Output** The `show mpls statistics vrf` command displays the following information:

| Output field  | Description                                                                 |
|---------------|-----------------------------------------------------------------------------|
| VRF Name      | The name of the VRF from which packets originated or are destined.          |
| In-Port(s)    | The port that is either the VRF or MPLS interface.                          |
| Endpt Out-Pkt | The number of packets forwarded to the specified VRF interface.             |
| Tnl Out-Pkt   | The number of VRF data packets sent to the remote peer over an MPLS tunnel. |

**Examples** The following example displays out-packet statistics for VRFs.

```
device# show mpls statistics vrf
VRF Name In-Port(s) Endpt Out-Pkt Tnl Out-Pkt
red e3/1 0 0
e3/2 0 0
e3/3 0 0
e3/4 0 0
e5/1 - e5/10 0 0
e5/11 - e5/20 0 0
e5/21 - e5/30 0 0
e5/31 - e5/40 0 0
green e3/1 3707480 0
e3/2 2692915 0
e3/3 0 0
e3/4 0 0
e5/1 - e5/10 0 0
e5/11 - e5/20 0 5834179
e5/21 - e5/30 0 0
e5/31 - e5/40 0 0
pink e3/1 0 0
e3/2 0 0
e3/3 0 0
e3/4 0 0
e5/1 - e5/10 0 0
e5/11 - e5/20 0 0
e5/21 - e5/30 0 0
e5/31 - e5/40 0 0
```

The following example displays out-packet statistics for a specific VRF.

```
device# show mpls statistics vrf black
VRF Name In-Port(s) Endpt Out-Pkt Tnl Out-Pkt
black e3/1 0 0
e3/2 29607351 0
e3/3 27522998 25828420
e3/4 0 0
e5/1 - e5/10 0 0
e5/11 - e5/20 0 0
e5/21 - e5/30 0 0
e5/31 - e5/40 0 0
e5/31 - e5/40 0
```

## show mpls summary

Displays a summary of MPLS information, including the number of configured paths and signaled LSPs for which this device is the ingress LSR.

|                         |                                                                                                                                                                                                                    |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>show mpls summary</b>                                                                                                                                                                                           |
| <b>Parameters</b>       | <b>summary</b><br>Displays MPLS global counters.                                                                                                                                                                   |
| <b>Modes</b>            | User EXEC mode                                                                                                                                                                                                     |
| <b>Usage Guidelines</b> | The <b>show mpls summary</b> command output has additional information on the total number of bypass LSPs in the system. This total number is the sum of the configured static and dynamic bypasses in the system. |
| <b>Command Output</b>   | The <b>show mpls summary</b> command displays the following information:                                                                                                                                           |

| Output field             | Description                                    |
|--------------------------|------------------------------------------------|
| Transit-LSPs configured  | The number of static LSP transits configured.  |
| Transit-LSPs enabled     | The number of static LSP transits enabled.     |
| Transit-LSPs operational | The number of static LSP transits operational. |

**Examples** The following example displays the output of the **show mpls summary** command.

```
device# show mpls summary
CER40 (config-mpls-lsp-test)#show mpls summary
Path:
    Paths configured          =      2

RSVP-Signaled LSPs:
    LSPs configured          =      6
    LSPs enabled              =      6
    LSPs operational         =      6
    Detour LSPs UP           =      0
    Backup LSPs UP           =      0
    Bypass LSPs              =      0
    Bypass LSPs UP          =      0
    Bypass LSPs enabled      =      0

LDP-Signaled LSPs:
    LSPs operational         =      3
...
Number of times MPLS has been enabled: 1
Next available RSVP LSP tunnel-interface index: 7
```

| History | Release version | Command history                                                                          |
|---------|-----------------|------------------------------------------------------------------------------------------|
|         | 5.9.00          | This command was modified to include the next available RSVP LSP tunnel-interface index. |

# show mpls ted database

Displays the contents of an LSR TED.

**Syntax** `show mpls ted database [ node_id detail | detail node_id ]`

**Parameters** `node_id detail`

Displays the detailed node identification information.

`detail node_id`

Displays the detailed information of the Traffic Engineering Database (TED) content specified by the `node_id` variable.

**Modes** User EXEC mode.

**Command Output** The `show mpls ted database` command displays the following information:

| Output field | Description                                                                                                                                                                                                                 |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AreaID       | The identification of this OSPF area.                                                                                                                                                                                       |
| NodeID       | The identification of the node. For router nodes, can be any interface address or a loopback interface address on the LER. For network nodes, this is the router identification of the network's designated router.         |
| (node) Type  | The node type can be either 'Router' or 'Network'. <ul style="list-style-type: none"> <li>'Router' indicates the node is an actual LSR.</li> <li>'Network' indicates the node represents a multi-access network.</li> </ul> |
| (link) Type  | The link type can be either 'P2P' or 'M/A'. <ul style="list-style-type: none"> <li>'P2P' indicates this is a point-to-point link.</li> <li>'M/A' indicates the link is a broadcast, multi-access network.</li> </ul>        |
| To           | The identification of the node at the end of the link.                                                                                                                                                                      |
| Local        | The address of the interface used to reach the remote node.                                                                                                                                                                 |
| Remote       | The address of the interface on the remote node that connects to the local node. For M/A types, this is always 0.0.0.0.                                                                                                     |

**Examples** The following example displays the output of the `show mpls ted database` command.

```
device# show mpls ted database
AreaID: 0
NodeID: 2.2.2.2, Type: Router
Type: M/A, To: 10.1.1.2, Remote: 0.0.0.0
NodeID: 3.3.3.3, type: Router
Type: P2P, To: 10.1.1.2, Local: 10.1.1.1, Remote: 10.1.1.2
Type: M/A, To: 10.1.1.3, Local: 10.1.1.3, Remote: 0.0.0.0
Type: M/A, To: 10.1.1.2, Local: 10.1.1.1, Remote: 0.0.0.0
NodeID: 10.1.1.3, Type: Network
Type: M/A, To: 10.1.1.1, Local: 0.0.0.0, Remote: 0.0.0.0
Type: M/A, To: 10.2.2.2, Local: 0.0.0.0, Remote: 0.0.0.0
Type: M/A, To: 10.3.3.3, Local: 0.0.0.0, Remote: 0.0.0.0
NodeID: 30.1.1.2, type: Network
Type: M/A, To: 10.1.1.1, Local: 0.0.0.0, Remote: 0.0.0.0
Type: M/A, To: 10.6.6.6, Local: 0.0.0.0, Remote: 0.0.0.0
```

## show mpls ted path

Displays a traffic path to an IPv4 destination address using a specified set of resource parameters.

|                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>         | <b>show mpls ted path</b> { <i>ip_addr</i> } [ <b>bandwidth</b> <i>kbps</i> ] [ <b>cspf-comp-mode</b> { <b>use-igp-metric</b>   <b>use-te-metric</b> } ] [ <b>exclude-any</b> <i>name</i> ] [ <b>hop-limit</b> <i>max_hops</i> ] [ <b>include-all</b> <i>name</i> ] [ <b>include-any</b> <i>name</i> ] [ <b>path-name</b> <i>name</i> ] [ <b>priority</b> <i>setup</i> ] [ <b>tie-breaking</b> { <b>least-fill</b>   <b>most-fill</b>   <b>random</b> } ]                               |
| <b>Parameters</b>     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <i>ip_addr</i>        | The IPv4 address of the destination host.                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>bandwidth</b>      | The minimum bandwidth of the path to its destination.                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <i>kbps</i>           | Enter the bandwidth value in decimal form for kilobits per second units. The valid range is between 0 - 2147483647. When the value entered is larger than 2147483647, then the value is truncated to the max limit of 2147483647 and accepted as the bandwidth input.                                                                                                                                                                                                                   |
| <b>cspf-comp-mode</b> | Selects CSPF computation mode to use to calculate the path.                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <i>use-igp-metric</i> | Selects igp-metric to calculate the path.                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <i>use-te-metric</i>  | Selects te-metric to calculate the path.                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>exclude-any</b>    | Excludes any of the administrative groups.                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <i>name</i>           | Selects the list of administrative groups to exclude. A list of any combination of administrative groups names or numbers. The valid range for the administrative group number is between 0 - 31. The administrative group name must start with an alphabet character. When entering an invalid range for an administrative group number or name, the CLI prompts a warning message, and then the CLI prompts a warning message. It accepts the CLI but ignores the out of range value. |
| <b>hop-limit</b>      | The <i>maximum</i> number of hops for the path to reach its destination.                                                                                                                                                                                                                                                                                                                                                                                                                |
| <i>max-hops</i>       | The valid range is between 0 - 255. When an invalid range is entered, an error message displays. When a path to the destination is available, but the hop count for the path is greater than the <i>max_hops</i> value, then MPLS indicates that the path is not available.                                                                                                                                                                                                             |
| <b>include-all</b>    | Includes all of the administrative groups.                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <i>name</i>           | Selects the list of administrative groups. A list of any combination of administrative groups names or numbers. The valid range for the administrative group number is between 0 - 31. The administrative group name must start with an alphabet character. When an invalid range is entered for an administrative group number or name, then the CLI prompts a warning message, the CLI prompts a warning message. The CLI is accepted, but the out of range value is ignored.         |



**path**

Displays by path name.

*name*

Name of selected path.

**priority**

The setup priority of the path.

*setup*

The valid range is between 0 - 7. The default is 7, the *lowest* setup priority value. When an invalid range is entered, an error message displays. The priority parameter must be entered along with the bandwidth parameter because while setting up an LSP, the setup priority value decides the ability to reserve a bandwidth amount.

**tie-breaking**

Use when multiple equal-cost paths to a destination exist. The tie-breaking rule selects only one path to display from among multiple equal cost paths. The default is random.

*least-fill*

Path is selected on least-fill criteria.

*most-fill*

Path is selected on most-fill criteria.

*random*

Path is selected randomly.

**Modes** User EXEC mode

**Command Output** The **show mpls ted path** command displays the following information:

| Output field          | Description                                                          |
|-----------------------|----------------------------------------------------------------------|
| Path to x.x.x.x found | The IPv4 address of the destination host is found.                   |
| Time taken to compute | The total time taken by CSPF (in milliseconds) to compute this path. |
| Hop-count             | The hop count of this path.                                          |
| Cost                  | The total cost of this path.                                         |
| IS-IS                 | The IS-IS or OSPF or CSPF area ID through which this path traverses. |
| Hop                   | The ingress interface IPv4 address at each top.                      |
| Rtr                   | The traffic engineering router ID (IPv4 address) at each hop.        |

**Examples** The following example displays the **show mpls ted path** command.

```
device# show mpls ted path 10.12.12.12. hop-limit 2
Path to 10.12.12.12. found! Time taken to compute: 0 msec
Hop-count: 2 Cost: 2000 ISIS Level-1
Hop 1: 10.1.0.1, Rtr 10.13.13.13
Hop 2: 10.1.0.2, Rtr 10.12.12.12
```

The following example displays the **show mpls ted path** command for a router where the **exclude-any** parameter is used.

```
device# show mpls ted path 10.11.11.11 exclude-any 0
Path to 10.12.12.12. found! Time taken to compute: 0 msec
Hop-count: 1 Cost: 10 ISIS Level-2
Hop 1: 10.0.0.13, Rtr 10.11.11.11
```

The following example displays the **show mpls ted path** command using the **hop-limit** parameter when entering an out-of-range parameter value.

```
device# show mpls ted path 10.2.2.2 hop-limit 300
Error- Hop count value is out of range [0-255]
```

When entering an out-of-range parameter value, the following error message displays for the priority parameter:

```
Priority
```

# show mpls vll

Displays detailed information about the configurations of the VLLs on the device.

**Syntax** `show mpls vll [ vll_id | vll_name | detail | redundancy ]`

`show mpls vll brief [ redundancy ]`

|                   |                   |                                                    |
|-------------------|-------------------|----------------------------------------------------|
| <b>Parameters</b> | <i>vll_id</i>     | Displays the selected VLL.                         |
|                   | <i>vll_name</i>   | Displays the selected named VLL.                   |
|                   | <b>detail</b>     | Displays detailed information.                     |
|                   | <b>redundancy</b> | Displays MCT VLLs and VLLs having redundant peers. |
|                   | <b>brief</b>      | Displays brief information.                        |
|                   | <b>redundancy</b> | Displays MCT VLLs and VLLs having redundant peers. |

**Modes** User EXEC mode

**Usage Guidelines** The `show mpls vll detail` command displays information about the operation state of the VPLS instance in regard to the local endpoints.

**Command Output** The `show mpls vll detail` command displays the following information:

| Output field | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| End-point    | <p>How packets forward once they reach the egress LER. It can be one of the following:</p> <ul style="list-style-type: none"> <li>"untagged <i>portnum</i>" - Forward the packet out the specified port as untagged.</li> <li>"tagged <b>vlan</b> <i>vlan_id</i> / <i>portnum</i>" - Tag the packet with the specified VLAN ID and forward the packet out the specified port.</li> <li>"tagged <b>vlan</b> <i>vlan-id</i> <b>inner-vlan</b> <i>vlan-id</i>" - Tag the packet with the specified outer and inner vlan IDs and forward the packet out the specified port</li> <li>"undefined" - An endpoint has not been configured for this VLL.</li> </ul> |

| Output field      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| End-point state   | <p>The current state of the VLL. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• "UP" VLL is operational - packets can flow</li> <li>• "DOWN - configuration incomplete" A required configuration statement is missing.</li> <li>• "DOWN - endpoint port to CE is down" The physical endpoint port that must connect to the Customer Edge device is down, due to a link outage or it is administratively disabled.</li> <li>• "DOWN - no tunnel LSP to vll-peer" cannot find a working LSP.</li> <li>• "DOWN - PW is Down (Reason: LDP session is down)" LDP session is not yet ready.</li> <li>• "DOWN - Waiting for PW Up" VLL is waiting for MPLS to bring up the session.</li> <li>• "DOWN - Waiting for VC withdrawal Completion" PW is down, and VLL is waiting for MPLS to withdraw the labels that VLL has requested.</li> <li>• "DOWN - PW is Down (Reason: Out of VC labels)" PW is down; VC labels are not available.</li> <li>• "DOWN - PW is Down (Reason: Out of Memory)" PW is down; there is not sufficient memory available.</li> <li>• "DOWN - PW is Down (Reason: Waiting for Remote VC label)" PW is down; waiting for remote peer's VC label to advertise.</li> <li>• "DOWN - waiting for VC label binding from vll-peer" The device has advertised its VC label binding to the VLL peer, but has not yet received the peer's VC label binding.</li> <li>• "DOWN - PW is Down (Reason: MTU mismatch Local- MTU <i>mtu-value</i> , Remote-MTU <i>mtu-value</i>)" PW is down, and the MTU values for the local and remote peers are not equal.</li> <li>• "DOWN - PW is Down (Reason: VC type mismatch, Local VC type: <i>vc-type</i> , Remote VC type: <i>vc-type</i> " - The session cannot be come up because the VC types of the local and remote peers are not equal. The possible values for the <i>vc-type</i> variable are 5 for raw mode or 4 for tagged mode.</li> </ul> |
| MCT state         | Options: Active, Passive, NC                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| IFL-ID            | The <i>Internal Forwarding Lookup Identifier (IFL-ID)</i> allocation to each Local VLL instance that has at least one dual-tagged endpoint. For instances that do not have dual-tagged endpoints, the IFL-ID is displayed as "--".                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Local VC type     | Indicates whether the local VC is in Raw-mode or Tagged-mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Local VC MTU      | The MTU value configured for this local VC.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| COS               | The optional CoS setting for the VLL. When a CoS value sets, the device attempts to select a tunnel LSP that also has this CoS value. The CoS value can be between 0 - 7.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Extended Counters | Indicates whether or not the extended counters are enabled for the configured VLL.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Vll-Peer          | The remote PE router. It must be the same as the LSP destination for the LSPs that the VLL transports over.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

| Output field    | Description                                                                                                                                                                                                                                                                                                                                                             |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State           | The current state of the remote VLL.<br><br>The current state of the VLL. It can be either UP or DOWN. Data can be forwarded over the VLL only when the state is UP.                                                                                                                                                                                                    |
| Remote VC type  | Indicates whether the remote VC is in Raw-mode or Tagged-mode.                                                                                                                                                                                                                                                                                                          |
| Remote VC MTU   | The MTU value advertised from the VLL peer.                                                                                                                                                                                                                                                                                                                             |
| Local label     | The VC label value locally allocated for this VLL. Packets forwarded from the VLL peer to this device are expected to contain this label.<br><br>It is the label that is advertised to the VLL peer through LDP.                                                                                                                                                        |
| Remote label    | The VC label allocated by the VLL peer and advertised to this device through LDP.<br><br>The device applies this label to outbound MPLS packets sent to the VLL peer.                                                                                                                                                                                                   |
| Local group-id  | The VLL group-ID (defined in draft-martini-l2circuit-trans-mpls-07.txt) advertised to the VLL peer through LDP. In this release, it is always zero.                                                                                                                                                                                                                     |
| Remote group-id | The VLL group-ID selected and advertised by the VLL Peer.                                                                                                                                                                                                                                                                                                               |
| Tunnel LSP      | The name, as well as internal tunnel index number, of the tunnel LSP selected for the VLL.                                                                                                                                                                                                                                                                              |
| MCT Status TLV  | Options: <ul style="list-style-type: none"> <li>• <b>Active</b> - Node will start peering with the remote peers, signaling Status TLV as Active.</li> <li>• <b>Standby</b> - Node will start peering with remote peers, signaling Status TLV as Standby.</li> <li>• <b>Transit</b> - MCT VLL is not in Operational state. Remote Peering is not yet enabled.</li> </ul> |
| Assigned LSPs   | Lists the assigned LSPs.                                                                                                                                                                                                                                                                                                                                                |

**Examples** The following example displays the **show mpls vll** detail command.

```
device# show mpls vll detail
VLL test, VC-ID 210, VLL-INDEX 15

End-point      : tagged vlan 210 e 1/6
End-Point state : Up
MCT state      : None
IFL-ID         : --
Local VC type   : tag
Local VC MTU    : 1500
COS            : --
Extended Counters: Enabled

Vll-Peer       : 12.12.12.12
State          : UP
Remote VC type : tag                      Remote VC MTU : 1500
Local label    : 852667                   Remote label   : 852184
Local group-id : 0                        Remote group-id: 0
Tunnel LSP     : to12 (tn12)
MCT Status TLV : --
Assigned LSPs : to12_1 to12_3 to12_4 to12_2 to12_8 to12_7 to12_6 to_5
```

History

| Release version | Command history                                                                                                                                                                                                                          |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5.5.00          | <p>A new option was added to allow the user to select raw pass-through mode.</p> <p>It behaves like tagged-mode when the endpoint is configured as tagged endpoint or raw mode when the endpoint is configured as untagged endpoint.</p> |
| 5.7.00          | <p>This command was modified to include the 'Assigned LSPs' field in the display output for the <b>show mpls vll detail</b>, <b>show mpls vll vll_name</b> , and <b>show mpls vll vll_id</b> commands.</p>                               |

## show mpls vll-local

Displays information about individual Local VLLs configured on the router.

**Syntax** `show mpls vll-local local_vll_name [ brief | detail ]`

**Parameters** `local_vll_name`

Specifies the local VLL name.

**brief**

Displays brief information.

**detail**

Displays detailed information for all local VLLs in the router. Specifying a particular VLL using the *vll-name* option limits the display to the specified Local VLL.

**Modes** User EXEC mode.

**Command Output** The `show mpls vll-local` command displays the following information:

| Output field | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Command level                                     |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| Name         | The configured name of the Local VLL.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | show mpls vll-local                               |
| VLL-ID       | The VLL ID.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | show mpls vll-local                               |
| End-point    | How packets forward out of the egress port of the Local VLL. This can be one of the following: <ul style="list-style-type: none"> <li>'<b>untagged portnum</b>' - Forward the packet out the specified port as untagged.</li> <li>'<b>tag vlan vlan_id/portnum</b>' - Tag the packet with the specified VLAN ID and forward the packet out the specified port.</li> <li>'<b>undefined</b>' - An endpoint has not been configured for this Local VLL.</li> <li>'<b>inner-vlan</b>' - describes the inner-vlan tag for an end-point that is configured for dual-tagging.</li> </ul> | show mpls vll-local<br>show mpls vll-local detail |
| IFL-ID       | The <i>Internal Forwarding Lookup Identifier (IFL-ID)</i> allocated to each Local VLL instance that has at least one dual tag endpoint. For instances that do not have dual tag endpoints, the IFL-ID is displayed as '-'.                                                                                                                                                                                                                                                                                                                                                        | show mpls vll-local detail                        |

| Output field      | Description                                                                                                                                                                                                                                                                                                                                                                                               | Command level                                     |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| State             | The current state of the Local VLL. It can be one of the following: <ul style="list-style-type: none"> <li>'UP'- The local VLL is operational - packets can flow.</li> <li>'DOWN - configuration complete' - A required configuration statement is missing.</li> <li>'DOWN - endpoint port is down' - The physical endpoint port is down due to a link outage or is administratively disabled.</li> </ul> | show mpls vll-local<br>show mpls vll-local detail |
| COS               | The optional CoS setting for the Local VLL. When a CoS value sets, the CoS value can be between 0 - 7.                                                                                                                                                                                                                                                                                                    | show mpls vll-local detail                        |
| Extended Counters | Indicates whether or not the extended counters are enabled for the configured Local VLL instances.                                                                                                                                                                                                                                                                                                        | show mpls vll-local detail                        |

**Examples** The following example shows the output of the **show mpls vll-local** command:

```
device# show mpls vll-local
Name          VLL-ID  End-point1          End-point2          State
foundrylong  1       tag vlan 100 e5/12  undefined            DOWN
villocalfou
ndrylonfvll
localfoundr
ylongvilloc
alfoundry
test         2       tag vlan 200 inner-vlan 50 e2/1 tag vlan 200 e2/2  UP
```

The following example shows detailed information for all Local VLLs in the router. Using the *vll\_name* option limits the display to the specified Local VLL.

```
device# show mpls vll-local detail
VLL-test-1  VLL-ID1  IFL-ID-            State:UP
End-point1:untagged e2/2          COS:-
End-point2:untagged e2/13        COS:- Extended Counters:Enabled

VLL-test-2  VLL-ID2  IFL-ID-            State:UP
End-point1:tagged vlan 2500 e2/10  COS:-
End-point2:tagged vlan 2500 e2/9   COS:- Extended Counters:Enabled

VLL-test-3  VLL-ID3  IFL-ID-            State:UP
End-point1:tagged vlan 2501 e2/10  COS:6
End-point2:tagged vlan 2501 e2/9   COS:5 Extended Counters:Enabled

VLL-test-4  VLL-ID4  IFL-ID4096        state:UP
End-point1:tagged vlan 100 inner-vlan 45 e2/1  COS:-
End-point2:tagged vlan 100 e2/3     COS:- Extended Counters:Enabled
```



# show mpls vpls

Displays information about the VPLS configuration.

**Syntax** `show mpls vpls [ brief [ redundancy ] | detail | down | id vpls_id | local | name vpls_name | summary ]`

**Parameters** **brief**

Displays brief information for each VPLS (default).

**redundancy**

Displays cluster-peer pw redundancy.

**detail**

Displays detailed information for each VPLS.

**down**

Displays brief information for each VPLS that is not completely operational.

**id *vpls\_id***

Displays detailed information for the VPLS specified by its ID.

**local**

Displays detailed information for local entry.

**name *vpls\_name***

Displays detailed information for the VPLS specified by its name.

**summary**

Displays summary information.

**Modes** User EXEC mode

**Usage Guidelines** When both the VC type and MTU are mismatched, only the output from the VC type mismatch is displayed on the console.

This command operates in all modes.

**Command Output**

| Output field    | Description                                                                                                                                |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| VPLS            | The configured name of the VPLS instance.                                                                                                  |
| Max mac entries | The maximum number of MAC entries that can be learned for the VPLS instance.                                                               |
| Total vlans     | The number of VLANs that are translated for this VPLS instance.                                                                            |
| Tagged ports    | The total number of tagged ports that are associated with VLANs in this VPLS instance, as well as the number of these ports that are up.   |
| Untagged ports  | The total number of untagged ports that are associated with VLANs in this VPLS instance, as well as the number of these ports that are up. |
| IFL-ID          | The Internal Forwarding Lookup Identifier (IFL-ID) for dual-tagged ports in the VPLS instance.                                             |
| L2 Protocol     | Layer 2 control protocol configured on the VLAN.                                                                                           |
| Tagged          | The numbers of the tagged ports in each VLAN.                                                                                              |

| Output field                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| VC-Mode                     | <p>The VC mode for the VPLS instance.</p> <ul style="list-style-type: none"> <li>• <b>Raw</b> - The VLAN tag information in the original payload is not carried across the MPLS cloud.</li> <li>• <b>Tagged</b> - The VLAN tag information in the original payload is carried across the MPLS cloud.</li> <li>• <b>Raw pass-through</b> - The VLAN tag information behaves like tagged mode when all endpoints are configured as tagged endpoints.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Total VPLS peers            | The number of VPLS peers this device has for this VPLS instance, as well as the number of these VPLS peers with which this device has an LDP session.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Peer address                | The IP address of the VPLS peer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| State                       | <p>The current state of the connection with the VPLS peer. This can be one of the following states:</p> <ul style="list-style-type: none"> <li>• <b>Operational</b> - The VPLS instance is operational. Packets can flow between the device and the peer.</li> <li>• <b>Wait for functional local ports</b> - The physical endpoint port that must be connected to the Customer Edge device is down due to a link outage or is administratively disabled.</li> <li>• <b>Wait for LSP tunnel to Peer</b> - The device cannot find a working tunnel LSP.</li> <li>• <b>Wait or PW Up (Wait for LDP session to Peer)</b> - The LDP session is not ready.</li> <li>• <b>Wait for PW Up (Wait for remote VC label)</b> - The device has advertised its VC label binding to the VPLS peer, but has not yet received the peer's VC labeling binding.</li> <li>• <b>Wait for PW Up (VC type mismatched)</b> - A session is not formed because the VC type does not match with its peer's VC type.</li> <li>• <b>Wait for PW Up (MTU mismatched)</b> - The MTU sent to a peer is derived from the device's global setting by the following formula: (system-mtu minus 26 bytes). When a system-mtu value is not configured, a default value of 1500 is sent.</li> <li>• <b>Wait for PW Up (Wait for LDP session to Peer)</b> - The LDP session to the peer is down.</li> <li>• <b>Wait for PW Up (No label resource)</b> - When configuring a VPLS peer, the maximum number of VC labels that can be supported may exceed 65536 and cause the configuration to be rejected. The maximum number of VC labels available for VPLS instances is equal to 65536.</li> </ul> |
| Uptime                      | The time, in minutes, that the entry has been operational.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Tnnls in use (load balance) | <p>The tunnel LSP used to reach the VPLS peer.</p> <p>When VPLS traffic to the peer is load balanced across multiple tunnel LSPs, the tunnel LSPs used to reach the peer are displayed.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Local VC lbl                | <p>The VC label value locally allocated for this peer for this VPLS instance. Packets forwarded from the VPLS peer to this device are expected to contain this label.</p> <p>This is the label that is advertised to the VPLS peer through LDP.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Remote VC lbl               | <p>The VC label allocated by the VPLS peer and advertised to this device through LDP.</p> <p>The device applies this label to outbound MPLS packets sent to the VPLS peer.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

| Output field       | Description                                                                                                                                                                                                                                                                                                        |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Local VC MTU       | The MTU value locally configured for this peer.                                                                                                                                                                                                                                                                    |
| Remote VC MTU      | The MTU value configured for the remote VPLS peer.                                                                                                                                                                                                                                                                 |
| Local VC-Type      | The VC type for this peer.                                                                                                                                                                                                                                                                                         |
| Remote VC-Type     | The VC type for the remote VPLS peer.                                                                                                                                                                                                                                                                              |
| CPU-Protection     | Whether CPU protection configured on this VPLS instance is on or off. On Brocade NetIron XMR Series and Brocade NetIron MLX Series devices only: When CPU protection is enabled on this VPLS instance but is temporarily unavailable due to 100% multicast FID usage, this field includes the message shown above. |
| Local Switching    | Whether local switching behavior on a per-VPLS basis is enabled or disabled.                                                                                                                                                                                                                                       |
| Extended Counter   | Indicates whether or not the extended counter is enabled for the configured VPLS.                                                                                                                                                                                                                                  |
| Multicast Snooping | Indicates whether multicast snooping is enabled or disabled.                                                                                                                                                                                                                                                       |

**Examples** The following example displays the output of the **show mpls vpls brief redundancy** command.

```

device# show mpls vpls brief redundancy
Name      Id      Ports  Num  Peers  MCT      MCT FSM
=====  ==      =====  =====  =====  =====  =====
tst       10     2       2    2      Active   OPER

```

The following example displays the output of the **show mpls vpls detail** command.

```

device# show mpls vpls detail
VPLS 1001, Id 1001, Max mac entries: 32000
Total vlans: 2, Tagged ports: 1 (1 Up), Untagged ports 0 (0 Up)
IFL-ID: 4096
  Vlan 1001
    Tagged: ethe 14/3
  Vlan 1001 inner-vlan 1001
    Tagged: ethe 14/3
VC-Mode: Raw
Total VPLS peers: 6 (6 Operational)
Peer address: 10.0.0.1, State: Operational, Uptime: 1 hr 44 min
  LSPs assigned: fl1a1 a1a2 a2a5 a3a8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl0(1217)[RSVP]      Peer Index:0
  Local VC lbl: 983839, Remote VC lbl: 984238
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 10.0.0.2, State: Operational, Uptime: 1 hr 44 min
  LSPs assigned: flb1 alb2 a2b5 a3b8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl4(1075)[RSVP]     Peer Index:1
  Local VC lbl: 983239, Remote VC lbl: 984238
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 10.0.0.3, State: Operational, Uptime: 1 hr 37 min
  LSPs assigned: flc1 alc2 a2c5 a3c8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl8(1193)[RSVP]     Peer Index:2
  Local VC lbl: 983439, Remote VC lbl: 983240
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 10.0.0.7, State: Operational, Uptime: 1 hr 37 min
  LSPs assigned: fld1 ald2 a2d5 a3d8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl12(1355)[RSVP]    Peer Index:3
  Local VC lbl: 984239, Remote VC lbl: 984039
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 10.0.0.4, State: Operational, Uptime: 1 hr 44 min
  LSPs assigned: fle1 ale2 a2e5 a3e8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl16(1071)[RSVP]   Peer Index:4
  Local VC lbl: 983639, Remote VC lbl: 984238
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 10.0.0.6, State: Operational, Uptime: 1 hr 37 min
  LSPs assigned: flg1 alg2 a2g5 a3g8, Tnnls in use (load balance): Candidate count:1
(only 1st 4 is displayed):
  tnl20(1374)[RSVP]   Peer Index:5
  Local VC lbl: 984439, Remote VC lbl: 983840
  Local VC MTU: 9190, Remote VC MTU: 9190
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
CPU-Protection: OFF
Local Switching: Enabled
Extended Counter: ON
Multicast Snooping: Disabled

```

The following example shows when the remote peer is in an operational state. The total VC labels allocated field no longer displays in the output of the **show mpls vpls id vpls\_id** command.

```
device# show mpls vpls id 3
VPLS name_raw, Id 3, Max mac entries: 8192
Total vlans: 1, Tagged ports: 3 (3 Up), Untagged ports 0 (0 Up)
  IFL-ID: 4097
  Vlan 300 inner-vlan 500
    Tagged: ethe 3/1 ethe 3/11 ethe 3/13
  VC-Mode: Raw
  Total VPLS peers: 1 (1 Operational)
  Peer address: 10.200.200.200, State: Operational
, Uptime: 1 hr 10 min
  Tnnl in use: tnl1(4)
  LDP session: Up, Local VC lbl: 983072, Remote VC lbl: 983072
  Local VC MTU: 1500, Remote VC MTU: 1500
  LOCAL VC-Type: Ethernet (0x05), Remote VC-Type: Ethernet (0x05)
  CPU-Protection: OFF
  Local Switching: Enable
```

The following example shows the MCT support for VE over VPLS.

```
device# show mpls vpls id 3
VPLS vevpls, Id 100, Max mac entries: 2048
Routing Interface Id 100
Total vlans: 1, Tagged ports: 1 (1 Up), Untagged ports 0 (0 Up)
IFL-ID: n/a
Vlan 100
  L2 Protocol: NONE
  Tagged: ethe 1/20
VC-Mode: Raw
Total VPLS peers: 2 (2 Operational)
Cluster-Peer address: 13.13.13.13, State: Operational, Uptime: 53 sec
  Tnnl in use: tnl0(2049) [RSVP] Peer Index:0
  Local VC lbl: 983042, Remote VC lbl: 983040
  Local VC MTU: 1500, Remote VC MTU: 1500
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
Peer address: 9.9.9.9, State: Operational, Uptime: 3 min
  Tnnl in use: tnl1(3) [RSVP] Peer Index:1
  Local VC lbl: 983041, Remote VC lbl: 983040
  Local VC MTU: 1500, Remote VC MTU: 1500
  Local PW preferential Status:Active, Remote PW preferential Status:Active
  Local VC-Type: Ethernet(0x05), Remote VC-Type: Ethernet(0x05)
CPU-Protection: OFF
Local Switching: Enabled
Extended Counter: ON
Multicast Snooping: Disabled
Cluster-peer: enabled, Role:Active State: VPLS_MCT_STATE_OPER
Vrrp-MCT-aware: enabled
```

The following example displays the output of the **show mpls vpls name vpls\_name** command.

```
device# show mpls vpls name c1
VPLS c1, Id 10, Max mac entries: 8192
Total vlans: 0, Tagged ports: 0 (0 Up), Untagged ports 0 (0 Up)
Total VPLS peers: 1 (0 Operational)
auto-discovery enabled, RD 10:10
export RT 10:10
import RT 10:10
Peer address: 10.2.2.2 (auto-discovered)
, State: Wait for functional local ports
  Tnnl in use: (load balance)
: None
  LDP session: Up, Local VC lbl: 983040, Remote VC lbl: N/A
  Local VC MTU: 1500, Remote VC MTU: 0
  CPU-Protection: OFF
  Local Switching: Enabled
```

The following example displays the output of the **show mpls vpls summary** command.

```
device# show mpls vpls summary
Virtual Private LAN Service summary:
  Total VPLS configured: 4072, maximum number of VPLS allowed: 4096
  Total number of IFL-ID's allocated by VPLS: 0
  Total VPLS peers configured: 8139, total peers operational: 8138
  Total VPLS Local end-points configured: 0
  Maximum VPLS mac entries allowed: 160000, currently installed: 150530
  VPLS global raw mode VC-Type is Ethernet (0x05)
  VPLS global MTU is 8974, MTU enforcement is OFF
  Global CPU protection: OFF
  VPLS policy parameters:
    vpls-pw-redundancy: 1
  MVIDs in use: 0 of 1 total allocated
  mac-address withdrawal-limit: 500
  MAC age time for local: 300
  MAC age time for remote: 600
```

**History**

| Release version | Command history                                                                                                                                                                                                                             |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5.4.00          | <p>This command output was modified to display VPLS instance ID if RSTP is running on a VPLS VLAN.</p> <p>The total VC labels allocated field is no longer displayed in the output of the <b>show mpls vpls name vpls_name</b> command.</p> |
| 5.5.00          | <p>This command was modified to include the <b>raw pass-through</b> option for the VC-Mode field.</p> <p>The MAC age time for local and MAC age time for remote fields were added.</p>                                                      |
| 5.6.00          | <p>VPLS Manual LSP assignment for a peer can now accept a maximum of eight LSPs instead of four LSPs.</p>                                                                                                                                   |
| 5.9.00          | <p>The <b>show mpls vpls summary</b> command output was modified to include information about the total configured VPLS local endpoints in the system.</p>                                                                                  |

## show mstp

Displays Multiple Spanning Tree Protocol (MSTP) information.

**Syntax** **show mstp** [ **blocked** [ *mstp-id* | **region** *region\_id* ] | *mstp-id* [ **region** *region\_id* ] ]

**Parameters**

**blocked** Specifies the display information in respect of ports blocked by the MSTP only.

*mstp-id* Specifies the display of information for a specific MSTP instance.

**region** *region-id* Specifies the display of information for a specific MSTP region.

**blocked** Specifies the display information in respect of ports blocked by the MSTP only.

**Modes** User EXEC mode

**Usage Guidelines** This command can also be entered in global configuration mode.

### History

---

#### Release Command History

---

|        |                                                                                                |
|--------|------------------------------------------------------------------------------------------------|
| 5.5.00 | The command was modified to display only ports blocked by the Multiple Spanning Tree Protocol. |
|--------|------------------------------------------------------------------------------------------------|

---

## show mvrp

Displays Multiple VLAN Registration Protocol (MVRP) information.

- Syntax** `show mvrp [ ethernet slot/port ]`
- Parameters** `ethernet slot port`  
Displays MVRP information for a specific Ethernet port.
- Modes** User EXEC mode
- Usage Guidelines** MVRP allows the propagation of VLAN information from device to device. With MVRP, an access switch is manually configured with all the desired VLANs for the network, and all other switches on the network learn those VLANs dynamically.
- Examples** The following example displays MVRP information for all interfaces.

```
device> show mvrp
-----
Total configured mvrp ports      : 2
Global Status                    : Enabled
Join-timer(in ms)                : 200
Leave-timer(in ms)                : 1000
Leaveall-timer(in ms)            : 10000
-----
MVRP Port(s): ethe 1/1 to 1/5, ethe 1/7, ethe 1/9 to 1/11
```

The following example displays MVRP information for Ethernet interface 1/1

```
device> show mvrp ethernet 1/1
-----
MVRP Status                      : Enabled
Join-timer(in ms)                : 200
Leave-timer(in ms)                : 1000
Leaveall-timer(in ms)            : 10000
P2p                              : No
Applicant Mode                   : normal-participant
-----
Registered Vlan(s)               : 1 to 60 77 100 to 500 999
Declared Vlan(s)                 : 1 to 60 77 100 to 500 999
Forbidden Vlan(s)                 : 10
-----
```



## show mvrp attributes

Displays Multiple VLAN Registration Protocol (MVRP) attribute information.

**Syntax** `show mvrp attributes [ ethernet slot/port ] [vlan vlan-id ]`

**Parameters** `ethernet slot port`

Displays MVRP attribute information for a specific Ethernet port.

`vlan vlan-id`

Displays MVRP attribute information for a specific virtual LAN (VLAN).

**Modes** User EXEC mode

**Usage Guidelines** MVRP allows the propagation of VLAN information from device to device. With MVRP, an access switch is manually configured with all the desired VLANs for the network, and all other switches on the network learn those VLANs dynamically.

Use this command to display MVRP attribute information for all ports (and optionally, VLANs) that are registered with MVRP on the network. If no keyword options are used, information about all interfaces and VLANs that are registered as MVRP members is displayed.

**Examples** The following example displays MVRP attributes for all ports and VLANs.

```
device> show mvrp attributes
```

```
Port : 1/1          State : Forwarding
-----
VLAN      Registrar      Registrar      Applicant
         State          Mgmt           State
-----
11        IN              FIXED          Very Anxious Observer
12        IN              FIXED          Very Anxious Observer
Port : 1/2          State : Disabled
-----
VLAN      Registrar      Registrar      Applicant
         State          Mgmt           State
-----
11        IN              FIXED          Very Anxious Observer
```

The following example displays MVRP attributes for Ethernet interface 1/1.

```
device> show mvrp attributes ethernet 1/1
```

```
Port : 1/1          State : Blocking
-----
VLAN      Registrar      Registrar      Applicant
         State          Mgmt           State
-----
11        IN              FIXED          Very Anxious Observer
12        IN              FIXED          Very Anxious Observer
```

The following example displays MVRP attributes for VLAN 11

```
device> show mvrp attributes vlan 100
```

```
-----
PORT  VLAN      Registrar      Registrar      Applicant
         State          Mgmt           State
-----
1/1   11        IN              FIXED          Very Anxious Observer
1/2   11        IN              FIXED          Very Anxious Observer
1/3   11        IN              FIXED          Very Anxious Observer
```

## show mvrp config

Displays Multiple VLAN Registration Protocol (MVRP) configuration information.

- Syntax** `show mvrp config`
- Modes** User EXEC mode
- Usage Guidelines** MVRP allows the propagation of VLAN information from device to device. With MVRP, an access switch is manually configured with all the desired VLANs for the network, and all other switches on the network learn those VLANs dynamically.
- Use this command to review the MVRP parameters configured on this device.
- Examples** The following example displays the MVRP parameters configured on this device.

```
device> show mvrp config

mvrp enable
mvrp timer join 400 leave 2000 leave-all 10000
!
interface ethernet 1/5
  mvrp enable
  mvrp registration-mode forbidden vlan 10
  mvrp timer join 400 leave 1500 leave-all 8000
  mvrp point-to-point
  mvrp applicant-mode non-participant
```

## show mvrp statistics

Displays Multiple VLAN Registration Protocol (MVRP) statistics.

**Syntax** `show mvrp statistics [ ethernet slot/port ]`

**Parameters** `ethernet slot port`  
Displays MVRP statistics for a specific Ethernet port.

**Modes** User EXEC mode

**Usage Guidelines** MVRP allows the propagation of VLAN information from device to device. With MVRP, an access switch is manually configured with all the desired VLANs for the network, and all other switches on the network learn those VLANs dynamically.

Use this command to display MVRP statistics for all ports that are registered with MVRP on the network. If no keyword options are used, statistical information about all interfaces that are registered as MVRP members is displayed.

**Examples** The following example displays MVRP statistics for all ports.

```
device> show mvrp statistics
```

```
Port : ethe 1/1
```

| Message type | Received | Transmitted |
|--------------|----------|-------------|
| New          | 0        | 0           |
| In           | 0        | 0           |
| Join In      | 0        | 0           |
| Join Empty   | 0        | 0           |
| Empty        | 0        | 0           |
| Leave        | 0        | 0           |
| Leave-all    | 0        | 0           |
| Total PDUs   | 0        | 0           |

```
Port : ethe 1/2
```

| Message type | Received | Transmitted |
|--------------|----------|-------------|
| New          | 0        | 0           |
| In           | 0        | 0           |
| Join In      | 0        | 0           |
| Join Empty   | 0        | 0           |
| Empty        | 0        | 0           |
| Leave        | 0        | 0           |
| Leave-all    | 0        | 0           |
| Total PDUs   | 0        | 0           |

The following example displays MVRP statistics for Ethernet interface 1/1.

```
device> show mvrp statistics ethernet 1/1
```

```
Port : ethe 1/1
```

| Message type | Received | Transmitted |
|--------------|----------|-------------|
| New          | 0        | 0           |
| In           | 0        | 0           |
| Join In      | 0        | 0           |
| Join Empty   | 0        | 0           |
| Empty        | 0        | 0           |
| Leave        | 0        | 0           |
| Leave-all    | 0        | 0           |
| Total PDUs   | 0        | 0           |

## show nht-table ipsec-based

Displays the NHT entries created for IPsec processing.

**Syntax** `show nht-table ipsec-based`

**Modes** Privileged EXEC mode

**Examples** The following example shows the NHT entries created for IPsec processing.

```
device#show nht-table ipsec-based
Reconcile Done -
      ARP = 0, GRE = 0, MPLS = 0, phase_1 = 0, l2vpn = 0, phase_2 = 0

NHT IP      Index  MAC Address      VLAN   Out I/F  Out Port  TNL CNT  XC CNT  LABEL/
SPIid      EXP/PCP
1.1.1.2    1      0024.38a5.5130   1      2/1      2/1      0         1
0
device#

device#show nht-table ipsec-based
NHT IP      Index  MAC Address      VLAN   Out I/F  Out Port  LABEL/
SPIid      EXP/PCP
1.1.1.2    1      0024.38a5.5130   1      2/1      2/1
0
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

# show openflow

Displays the configured OpenFlow parameters.

**Syntax** `show openflow`

**Modes** User EXEC mode

**Command Output** The `show openflow` command displays the following information:

| Output field          | Description                             |
|-----------------------|-----------------------------------------|
| Administrative Status | Enable or disable status                |
| Controller Type       | OpenFlow 1.0 or OpenFlow 1.3 controller |
| Controller            | Number of controllers                   |

**Examples** The following example displays the results of the `show openflow` command.

```
device#show openflow

Administrative Status:      Enabled
Controller Type:           OFV 130
Number of Controllers: 4

Controller 1:
Connection Mode:           passive, TCP
Listening Address:         0.0.0.0
Connection Port:           6633
Connection Status:         TCP_LISTENING
Role:                       Equal
Asynchronous Configuration: Packet-in (no-match|action|invalid-ttl)
                             Port-status (add|delete|modify)
                             Flow-removed (idle-timeout|hard-timeout|delete|grp-
delete)

Controller 2:
Connection Mode:           active, TCP
Controller Address:        10.25.128.243
Connection Port:           2001
Connection Status:         OPENFLOW_ESABLISHED
Role:                       Master
Asynchronous Configuration: Packet-in (no-match|action|invalid-ttl)
                             Port-status (add|delete|modify)
                             Flow-removed (idle-timeout|hard-timeout|delete|grp-
delete)

Controller 3:
Connection Mode:           active, TCP
Controller Address:        10.25.128.242
Connection Port:           6633
Connection Status:         OPENFLOW_ESABLISHED
Role:                       Slave
Asynchronous Configuration: Port-status (add|delete|modify)

Controller 4:
Connection Mode:           active, TCP
Controller Address:        10.25.128.250
Connection Port:           2002
Connection Status:         OPENFLOW_ESABLISHED
Role:                       Slave
Asynchronous Configuration: Port-status (add|delete|modify)

Match Capability:
Port, Destination MAC, Vlan, Vlan PCP
Openflow Enabled Ports:    e1/1 e1/2
```

| History | Release version | Command history                            |
|---------|-----------------|--------------------------------------------|
|         | 5.5.00          | This command was introduced.               |
|         | 5.7.00          | This command was modified for OpenFlow 1.3 |

# show openflow controller

Displays the controller information in a flow.

**Syntax** `show openflow controller`

**Modes** User EXEC mode

**Command Output** The `show openflow controller` command displays the following information:

| Output field | Description                                                                                     |
|--------------|-------------------------------------------------------------------------------------------------|
| Mode         | Gives the active and passive connection of the controller.                                      |
| IP address   | IP address of the port                                                                          |
| Port         | Port number                                                                                     |
| Status       | After the connection and OpenFlow handshake, the controller gives the role of OpenFlow channel. |
| Role         | Equal, Master and Slave role for the controller.                                                |

**Examples** The following example displays the results of the `show openflow controller` command.

```
device# show openflow controller
-----
Contlr Mode  TCP/SSL IP-address  Port  Status  Role
-----
1  (Equal)  passive TCP    0.0.0.0  6633  TCP_LISTENING
2  (Master)  active  TCP    10.25.128.179  6633  OPENFLOW_ESABLISHED
3  (Slave)  active  TCP    10.25.128.177  6633  OPENFLOW_ESABLISHED
3  (Equal)  active  TCP    10.25.128.165  6633  OPENFLOW_ESABLISHED
```

**History**

| Release version | Command history                                                                 |
|-----------------|---------------------------------------------------------------------------------|
| 5.5.00          | This command was introduced.                                                    |
| 5.7.00          | This command was modified to give information about the role of the controller. |

# show openflow flows

Displays the flows information on the OpenFlow ports.

**Syntax** `show openflow flows`

**Modes** User EXEC mode

**Command Output** The `show openflow flows` command displays the following information:

| Output field | Description                                                   |
|--------------|---------------------------------------------------------------|
| Flow         | Number of flows                                               |
| Packet       | Total Number of data packets trapped to be sent to controller |
| Byte         | Total Number of data bytes trapped to be sent to controller   |

**Examples** The following example displays the output for MP.

```
device# show openflow flows
Total Number of data packets sent to controller: 0
Total Number of data bytes sent to controller : 0

Total Number of Flows: 1
  Total Number of Port based Flows: 1
  Total Number of L2 Generic Flows: 0
  Total Number of L3 Generic Flows: 0
  .....
  .....

Flow ID: 1 Priority: 32768 Status: Active
  Rule:
    In Port: e2/5
  Instructions: Apply-Actions
    Action: FORWARD
      Out Port: e2/1
    Meter id: 1023
  Statistics:
    Total Pkts: 0
    Total Bytes: 0
```

The following example displays the output for LP.

```
device# show openflow flows
Total Number of data packets trapped to be sent to controller: 0
Total Number of data bytes trapped to be sent to controller : 0

Total Number of Flows: 1

Flow Id: 1, Priority: 32768, FD Id: 0, PW Id: 1
  Rule:
    In Port: e2/1
  Action: FORWARD
    Out Port: e2/1, Queue: 4

    FID: -N/A-, MVID: -N/A-
  Hardware Information:
    Port: 2/1 PPCR Id : 3, CAM Index: 0x000576ac (L4) PRAM Index: 0x0003ff5e
Packets: 0
  Statistics:
    Total Pkts: 0
    Total Bytes: 0
```



| History | Release version | Command history                            |
|---------|-----------------|--------------------------------------------|
|         | 5.5.00          | This command was introduced.               |
|         | 5.7.00          | This command was modified for OpenFlow 1.3 |

## show openflow groups

For a group or a range of groups, displays the maximum number of actions in a bucket, the maximum number of buckets in a group, and the maximum number of groups.

**Syntax** **show openflow groups** [ *group-id* ]

**show openflow groups** *group-id to group-id*

**Parameters** **groups** *group-id*

Displays details of an OpenFlow group or range of groups.

**to**

Indicates a range of groups.

**Modes** User EXEC mode

**Command Output** The **show openflow groups** command displays the following information:

| Output field | Description                        |
|--------------|------------------------------------|
| Group        | Maximum number of groups in a flow |
| Bucket       | Number of buckets per group        |
| Action       | Number of actions per bucket       |

**Examples** The following example displays the output from the **show openflow groups** command.

```
device#show openflow groups
Max number of groups           : 512
Max number of buckets per group : 64
Max number of actions per bucket : 1

Max number of SELECT groups      : 64
Max number of buckets in SELECT group: 12
Starting Trunk ID for SELECT groups : 257
Group id 1

Transaction id      4043243760
Type                ALL
Packet Count       0
Byte Count         0
Flow Count         0
Number of buckets  2
bucket #1
  Weight           0
  Number of actions 1
    action 1: out port: 2/3

bucket #2
  Weight           0
  Number of actions 1
    action 1: out port: 2/4

-----

Total no. of entries printed: 1
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

# show openflow interface

Displays the information about the interfaces in a OpenFlow flow.

**Syntax** `show openflow interface`

**Modes** User configuration mode

**Usage Guidelines** The `show openflow interface` command displays the port, up and down links, tag status, MAC addresses, and the modes.

**Command Output** The `show openflow interface` command displays the following information:

| Output field | Description                            |
|--------------|----------------------------------------|
| Port         | Port Number                            |
| Link         | Link status                            |
| Speed        | Configured speed                       |
| Tag          | Tag status                             |
| Mac Address  | MAC address of the port                |
| Mode         | Gives the information about the layers |

**Examples** The following example displays information for all openflow interfaces.

```
device# openflow enable layer3 hybrid
device# show openflow interface
```

Total number of Openflow interfaces: 5

| Port | Link | Speed | Tag | MAC            | OF-portid | Name | Mode          |
|------|------|-------|-----|----------------|-----------|------|---------------|
| 1/1  | Up   | 1G    | Yes | 000c.dbf5.bd00 | 1         |      | Layer2        |
| 1/2  | Up   | 1G    | Yes | 000c.dbf5.bd01 | 2         |      | Layer2        |
| 1/3  | Up   | 1G    | Yes | 000c.dbf5.bd01 | 3         |      | Hybrid-Layer3 |
| 1/4  | Up   | 1G    | Yes | 000c.dbf5.bd01 | 4         |      | Hybrid-Layer3 |
| 1/5  | Up   | 1G    | Yes | 000c.dbf5.bd01 | 5         |      | Hybrid-Layer3 |

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.4.00          | This command was introduced. |

## show openflow meters

Displays all the meters in a OpenFlow flow.

**Syntax** `show openflow meters [ meter-id ]`

**Parameters** `meters meter-id`

Shows details of a specific OpenFlow meter.

**Modes** User EXEC mode

**Command Output** The `show openflow meters` command displays the following information:

| Output field | Description                                    |
|--------------|------------------------------------------------|
| Meter-id     | Meter number                                   |
| Band         | Number of bands in a meter                     |
| Band type    | Band type ( supported type: Drop, DSCP_REMARK) |
| Rate         | Rate of the band                               |
| Counter      | Band specific counter                          |

**Examples** The following example displays output with specific meter in MP.

```
device(config)# show openflow meters 2
Meter id: 2

Transaction id:      1438
Meter Flags:         KBPS BURST STATS
Flow Count:         0
Number of bands:    2
In packet count:    -NA-
In byte count:      0

Band Type:          DSCP-REMARK

Rate:                750000
Burst size:          1500          kb
Prec level:          1
In packet band count: -NA-
In byte band count:  0

Band Type:          DROP

Rate:                1000000
Burst size:          2000          kb
In packet band count: -NA-
In byte band count:  0

-----
Total no. of entries printed: 1
```

The following example displays output with specific meter in LP.

```

device(config)# show openflow meters 1
Meter id: 1023

Meter Flags:
Number of bands:          KBPS BURST
                        2
RL Class Index:          33      33
In packet count:         -NA-
In byte count:           0

Band Type:      DROP

Rate:           3000          Adjusted rate:2996
Burst size:     1250          kb
In packet band count: -NA-
In byte band count: 0

Band Type:      DSCP-REMARK

Rate:           1700          Adjusted rate:1693
Burst size:     1250          kb
Prec level:     27
In packet band count: -NA-
In byte band count: 0

```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

## show openflow queues

Displays the queues on the OpenFlow ports.

**Syntax** `show openflow queues [ ethernet slot / port ]`

`show openflow queues [ ethernet slot / port to slot / port ]`

**Parameters** `ethernet slot / port`

Gives information about a particular slot and port in an ethernet.

`to`

Indicates a range of ports.

**Modes** User EXEC mode

**Usage Guidelines** You can specify additional ports with additional `ethernet slot / port` elements.

You can specify additional ports ranges with additional `ethernet slot / port to slot / port` elements.

**Command Output** The `show openflow queues` command displays the following information:

| Output field | Description                           |
|--------------|---------------------------------------|
| Queue        | Number of queues                      |
| Rate         | Minimum and maximum rate of the queue |
| Packet       | Number of packet in the queue         |
| Bytes        | Number of bytes in the queue          |

**Examples** The following example displays openflow queues on a specified port.

```

device#show openflow queues ethernet 2/1

Openflow Port    2/1
  Queue 0
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 1
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 2
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 3
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 4
    Min Rate: 0           Max Rate: 0
    Tx Packets: 1918620
    Tx Bytes: 168838560
Openflow Port    2/1
  Queue 5
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 6
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0
Openflow Port    2/1
  Queue 7
    Min Rate: 0           Max Rate: 0
    Tx Packets: 0
    Tx Bytes: 0

```

#### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

# show pim interface

Displays the IPv4 or IPv6 PIM interface table.

**Syntax** `show { ip | ipv6 } pim interface`

**Parameters**

- `ip` Displays the IPv4 PIM interface table.
- `ipv6` Displays the IPv6 PIM interface table.

**Modes** User EXEC mode

**Examples** The following is a sample display of the `show ip pim interface` command.

```
device# show ip pim interface
```

```

-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
Interface|Local  |Ver|St |Router      |TTL|Multicast| Filter|VRF | DR |Override
         |Address|   |   |Address Port|Thr|Boundary | ACL   |   | Prio|Interval
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
e1/3     |3.3.3.1|DMv2|Ena|Itself      |1  |None    | 10  default|1  |3000ms
e1/2     |2.2.2.1|DMv2|Ena|2.2.2.2 1/2|1  |None    |  None|default|1  |3000ms
Total Number of Interfaces: 2
    
```

**History**

| Release | Command History                                                        |
|---------|------------------------------------------------------------------------|
| 5.5.00  | This command was modified to display neighbor routers on an interface. |



# show pim multicast-filter

Displays the multicast filters on a interface or globally for the hardware.

**Syntax** `show { ip | ipv6 } pim`

**Modes** User EXEC mode

**Examples** Show output for global.

```
device# show ip pim vrf multicast-filter
-----
Interface|LAG Member |port |vlan | Multicast Filter |CAM Index| ProgTM
-----
*          -          *          *          1.1.1.1, 239.1.1.1  0x343
22:01:33
*          -          *          *          *,          234.1.1.1
0x344    22:01:33
```

Show output for interface .

```
device# show ip pim interface
-----
Interface |LAG Member |port |vlan |Multicast Filter |CAM Index|
ProgTM
-----
ve100     -          *          100   1.1.1.1, 239.1.1.1  0x343    22:01:33
ve102     -          *          100   *,          234.1.1.1  0x344    22:01:33
e1/13     -          142   100   *, 228/8          0x355    22:01:33
Tr1(e1/1) e1/1     e1/1   155   1          *, 228/8          0x356    22:01:33
Tn1       e1/4     -          156   1          *, 228/8          0x357    22:01:33
          -          *          *          *, 228/8          0x358    22:01:33
```

## History

### Release version

### Command history

NI05.7.00

This command was introduced.

## show pki certificates

Displays certificate information associated with a trustpoint or the local router.

**Syntax** `show pki certificates trustpoint trustpoint-name [ detail ]`

`show pki certificates local [ detail ]`

**Parameters** `trustpoint trustpoint-name`

Displays certificate information associated with a trustpoint certificate authority (CA).

`detail`

Displays detailed information about the certificate.

**local**

Displays certificate information associated with a local certificate provided for the device.

`detail`

Displays detailed information about the certificate.

**Modes** User EXEC mode

**Examples** The following example displays output for the trustpoint with the name "brocade".

```
device# show pki certificates trustpoint brocade
-----PKI TRUSTPOINT CERTIFICATE ENTRY-----
Certificate:
  Data:
    Version: 3 (0x00000002)
    Serial Number:
      fe:75:d1:a3:bc:56:28:8e
    Signature Algorithm: ecdsa-with-SHA1
    Issuer: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing, CN=Brocade_CA/
    emailAddress=brocade_ca@brocade.com
    Validity
      Not Before: Aug 29 05:58:13 2014 GMT
      Not After : Aug 29 05:58:13 2019 GMT
    Subject: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing,
    CN=Brocade_CA/emailAddress=brocade_ca@brocade.com
```

The following example displays the detailed output for the trustpoint with the name "brocade".

```
device# show pki certificates trustpoint brocade detail
-----PKI TRUSTPOINT CERTIFICATE ENTRY-----
Certificate:
  Data:
    Version: 3 (0x00000002)
    Serial Number:
      fe:75:d1:a3:bc:56:28:8e
    Signature Algorithm: ecdsa-with-SHA1
    Issuer: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing, CN=Brocade_CA/
    emailAddress=brocade_ca@brocade.com
    Validity
      Not Before: Aug 29 05:58:13 2014 GMT
      Not After : Aug 29 05:58:13 2019 GMT
    Subject: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing,
    CN=Brocade_CA/emailAddress=brocade_ca@brocade.com
    Subject Public Key Info:
      Public Key Algorithm: id-ecPublicKey
      Public-Key: (384 bit)
      pub:
        04:bf:02:57:b0:9e:db:5d:c6:f3:e0:1a:09:c1:ca:
        0f:8b:ed:c0:14:3d:41:ec:d0:a3:98:85:2a:4b:0e:
        74:36:04:c3:c9:51:e6:dd:b6:19:d6:8b:38:99:9a:
        b7:27:89:4b:5f:cf:fe:15:1a:f1:c4:61:ce:b7:c6:
        70:47:4c:4c:b4:57:e6:57:37:71:46:98:84:95:0a:
        47:60:42:35:7b:d3:a1:a7:78:5f:92:68:d0:5a:f8:
        b8:7e:5f:83:01:14:16
      ASN1 OID: secp384r1
    X509v3 extensions:
      X509v3 Subject Key Identifier:
        63:30:96:B1:59:36:FB:B4:07:44:47:28:D6:35:34:5A:80:55:AB:FD
      X509v3 Authority Key Identifier:
        keyid:63:30:96:B1:59:36:FB:B4:07:44:47:28:D6:35:34:5A:80:55:AB:FD

X509v3 Basic Constraints:
X509          CA:TRUE
  Signature Algorithm: ecdsa-with-SHA1
    30:64:02:30:1e:00:81:91:59:c1:ba:5f:ce:fe:c9:ca:98:e7:
    b2:98:3b:f5:e9:7b:35:ea:2e:c6:b1:ba:77:14:ef:d0:46:ff:
    30:cb:da:a7:64:65:f0:18:80:95:b0:a5:f7:f4:c4:28:02:30:
    2a:0a:4f:1f:19:a9:a3:67:99:3e:05:bb:74:ac:b8:2f:e2:75:
    5d:90:b5:18:74:ae:5c:7a:e8:27:93:c4:e2:34:3e:34:9b:4a:
    17:ea:3a:2e:7e:90:a8:1d:ea:45:bd:12
```

The following example displays the output for the local certificate.

```
device# show pki certificates local
-----PKI LOCAL CERTIFICATE ENTRY-----
Certificate:
  Data:
    Version: 3 (0x00000002)
    Serial Number: 1 (0x00000001)
    Signature Algorithm: ecdsa-with-SHA1
    Issuer: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing, CN=Brocade_RA/
    emailAddress=brocade_ra@brocade.com
    Validity
      Not Before: Sep 10 14:55:12 2014 GMT
      Not After : Jun  1 14:55:12 2016 GMT
    Subject: C=IN, ST=Karnataka, L=Bangalore, O=Brocade, OU=Routing,
    CN=Brocade_mlxl1/emailAddress=Brocade_mlxl1@brocade.com
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## show pki counters

Displays the Public Key Infrastructure (PKI) counter information for a certificate authority (CA).

**Syntax** `show pki counters`

**Modes** User EXEC mode

**Examples** The following example displays information about the PKI counter information for a CA.

```
device# show pki counters
PKI Sessions Started: 5
PKI Sessions Ended: 5
PKI Sessions Active: 0
Successful Validations: 1
Failed Validations: 4
Bypassed Validations: 0
Pending Validations: 0
CRLs checked: 3
CRL - fetch attempts: 2
CRL - failed attempts: 0
```

### History

---

| Release version | Command history |
|-----------------|-----------------|
|-----------------|-----------------|

|        |                              |
|--------|------------------------------|
| 5.9.00 | This command was introduced. |
|--------|------------------------------|

---

## show pki crls

Displays the Public Key Infrastructure (PKI) Certification Revocation list (CRL).

**Syntax** `show pki crls trustpoint name`

**Parameters** `trustpoint name`

The specific trustpoint name whose PKI CRLs need to be displayed.

**Modes** User EXEC mode

**Examples** The following example displays the PKI CRL list.

```
device# show pki crls
CRL Issuer Name:
cn=name Cert Manager,ou=pki,o=company.com,c=US
CRL number: 24
CRL Version: V2
LastUpdate: 18:57:42 GMT March 4 2013
NextUpdate: 22:57:42 GMT March 4 2013
Retrieved from CRL Distribution Point:
via SCEP
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## show pki enrollment-profile

Displays the Public Key Infrastructure (PKI) enrollment profile details.

**Syntax** `show pki enrollment-profile profile name`

**Parameters** `profile name`  
Specifies the PKI enrollment profile name.

**Modes** User EXEC mode

**Examples** The following example displays information about the PKI enrollment profiles.

```
device# show pki enrollment-profile
-----PKI ENROLLMENT PROFILE ENTRY-----
  Enrollment Profile: John
  Authentication Command: win-hj98ak136a0.englab.brocade.com_englab-WIN-N6C3R0LUDAJ-
CA-7
  Authentication URL: http://win-hj98ak136a0.englab.brocade.com/CertSrv/mscep/
mscep.dll
  Enrollment URL: http://win-hj98ak136a0.englab.brocade.com/CertSrv/mscep/mscep.dll
  SCEP password: 8A4976CE110A8686

-----PKI ENROLLMENT PROFILE ENTRY-----
  Enrollment Profile: Jane

-----PKI ENROLLMENT PROFILE ENTRY-----
  Enrollment Profile: John
  Authentication Command: win-hj98ak136a0.englab.brocade.com_englab-WIN-N6C3R0LUDAJ-
CA-7
  Authentication URL: http://win-hj98ak136a0.englab.brocade.com/CertSrv/mscep/
mscep.dll
  Enrollment URL: http://win-hj98ak136a0.englab.brocade.com/CertSrv/mscep/mscep.dll
  SCEP password: 8A4976CE110A8686
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## show pki entity

Displays the PKI entity details.

**Syntax** `show pki entity entity-name`

**Parameters** `entity-name`  
The entity name.

**Modes** User EXEC mode

**Examples** The following example displays the output for the entity name "brocade\_entity".

```
device# show pki entity brocade_entity
```

```
-----PKI ENTITY ENTRY-----
Entity Name: brocade_entity
Common Name: brocade_e
Organization Name: Brocade
Organization Unit Name: Routing
State Name: Karnataka
Country Name: India
Email: user@brocade.com
FQDN: brocade-fqdn
Subject Alternative Name: brocade-subject
Location: Bangalore
IP Address: 1.1.1.1
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## show pki key mypubkey

Displays the PKI public keys on the NetIron device.

**Syntax** `show pki key mypubkey ec manual [ label label-string ]`

**Parameters**

- ec** The manually configured Elliptic Curve (EC) key.
- manual** The manually configured key.
- label** The ID given to the key.
- label-string*** The name of the label.

**Modes** User EXEC mode

**Examples** The following example displays the output for the manually generated PKI keys.

```
device# show pki key mypubkey ec manual label xmr-key
-----PKI PUBLIC KEY ENTRY-----
Public key of manual EC key pair:
The key label is xmr-key
Public-Key: (384 bit)
pub:
 04:33:a6:3e:8e:94:ab:49:b8:e4:dd:f1:f9:2d:78:
 28:65:81:43:08:bd:b7:90:e8:90:56:4d:2e:7b:44:
 51:bf:bc:59:78:87:27:51:5c:b6:c0:75:d5:51:28:
 3b:37:3f:71:62:8e:20:98:b5:fe:72:69:ab:a2:69:
 22:eb:de:27:58:d6:00:66:f0:cc:7f:d2:30:4c:c1:
 a8:f8:d2:c9:6b:39:76:1a:66:f0:82:f2:2e:44:e5:
 3e:56:a3:f3:5b:76:81
ASN1 OID: secp384r1
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |



# show pki trustpoint

Displays a PKI Certificate Authority (CA) status and its certificate.

- Syntax** `show pki trustpoint trustpoint-name [ status ]`
- Parameters** *trustpoint-name*  
The name of the CA.
- status**  
The status of the PKI certificate.
- Modes** User EXEC mode
- Examples** The following example displays the output for a CA that is not authenticated.

```
device# show pki trustpoint status
! CA is not authenticated, and is queried
CA Test, VRF: Default
Issuing CA certificate status: pending
Subject Name:
cn=r1 Cert Manager,ou=pki,o=company.com,c=country
Fingerprint: C21514AC 12815946 09F635ED FBB6CF31
Router certificate status: pending
Subject Name:
hostname=host.company.com,o=company.com
Next query attempt: 52 seconds
```

The following example displays the output for a CA that is authenticated but the request has not started.

```
device# show pki trustpoint status
! CA is authenticated, and certificate request is not started
CA Test, VRF: Default
Issuing CA certificate: configured
Subject Name:
cn=r1 Cert Manager,ou=pki,o=company.com,c=country
Fingerprint: C21514AC 12815946 09F635ED FBB6CF31
State:
Keys Generated | CA Authenticated | Certificate Request
No              | Yes                    | None
```

The following example displays the output for a CA that is authenticated but the certificate request is pending.

```
device# show pki trustpoint status
! CA is authenticated, and certificate request is pending
CA Test, VRF: Default
Issuing CA certificate: configured
Subject Name:
cn=r1 Cert Manager,ou=pki,o=company.com,c=country
Fingerprint: C21514AC 12815946 09F635ED FBB6CF31
Router Signature certificate pending:
Requested Subject Name:
hostname=host.company.com
Request Fingerprint: FAE0D74E BB844EA1 54B26698 56AB42EC
Enrollment polling: 1 times (9 left)
Next poll: 32 seconds
Last enrollment status: Pending
State:
Keys Generated | CA Authenticated | Certificate Request
yes(signature) | Yes              | Pending
```

The following example displays the output for a CA that is authenticated and the certificate is granted.

```
device# show pki trustpoint status
! CA is authenticated, and certificate is granted
CA Test, VRF: Default
Issuing CA certificate: configured
Subject Name:
cn=rl Cert Manager,ou=pki,o=company.com,c=country
Fingerprint: C21514AC 12815946 09F635ED FBB6CF31
Router Signature certificate configured:
Subject Name:
hostname=host.company.com,o=company.com
Fingerprint: 8A370B8B 3B6A2464 F962178E 8385E9D6
Router Encryption certificate configured:
Subject Name:
hostname=host.company.com,o=company.com
Fingerprint: 43A03218 COAFF844 AE0C162A 690B414A
Last enrollment status: Granted
State:
Keys Generated | CA Authenticated | Certificate Request
yes(signature) | Yes                | yes
```

The following example displays the output for a CA trustpoint.

```
device# show pki trustpoint
CA test, VRF: Default
Subject Name:
cn=Brocade
o=Company
Serial Number: 0FFEBC1B6F6D9D0EA7875875E4C695
Certificate configured.
Enrollment Protocol:
SCEP, Regenerate at 80%
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## show rate-limit counters bum-drop

Displays the per-port / per-VLAN rate-limiting information for broadcast/unicast/multicast (BUM) traffic.

**Syntax** **show rate-limit counters bum-drop**

**show rate-limit counters bum-dropport-id slot / port [ all | vlan vlan-id ]**

**Parameters** **port-id slot / port**

Displays the information for a specified port.

**all**

Displays the information for all BUM counters on the specified port.

**vlan vlan-id**

Displays the information for all BUM counters on the specified VLAN.

**Modes** User EXEC mode

**Command Output** The **show rate-limit counters bum-drop** command displays the following information:

| Output field               | Description                                                                                                                                                |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| interface                  | Displays the interface information for which the rate-limiting accounting is configured.                                                                   |
| port: Drop:                | Displays information about the BUM traffic (in bytes) that has been dropped as a result of the defined rate limit policy for the specific port defined.    |
| rate-limit input broadcast | Displays information about the BUM traffic (in bytes) that has been dropped as a result of the defined rate limit policy.                                  |
| vlan-id: 100 Drop          | Displays information about the BUM traffic (in bytes) that has been dropped as a result of the defined rate limit policy for the specific VLAN id defined. |

**Examples** The following example for **show rate-limit counters bum-drop** command displays the following information.

```
Brocade(config-if-e10000-5/1)#sh rate-limit counters bum-drop
```

```
interface e 5/1
rate-limit input broadcast 993568 10000
port: Drop: 0 bytes
rate-limit input vlan-id 100 broadcast 993568 100000
vlan-id: 100 Drop: 0 bytes
```

```
Brocade(config-if-e10000-5/1)#sh rate-limit counters bum-drop port-id 5/1
```

```
interface e 5/1
rate-limit input broadcast 993568 10000
port: Drop: 0 bytes
```

```
Brocade(config-if-e10000-5/1)#sh rate-limit counters bum-drop port-id 5/1 vlan-id 100
```

```
interface e 5/1
rate-limit input vlan-id 100 broadcast 993568 100000
vlan-id: 100 Drop: 0 bytes
```

## Show Commands

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.7.00          | This command was introduced. |

## show rate-limit detail

Displays detailed information for all interfaces, including the per-port / per-VLAN rate-limiting information.

**Syntax** `show rate-limit detail`

**Modes** User EXEC mode.

**Examples** The `show rate-limit detail` command displays the following information.

```
Brocade#show rate-limit detail
interface e 8/1
rate-limit input vlan-id 2 broadcast multicast 97728 10000 include- control
rate-limit input broadcast multicast 97728 10000 include-control
rate-limit input access-group name ipv4_acl 100000 10000 include-control
rate-limit input access-group name ipv6_acl 100000 10000 include-control
rate-limit input access-group name ipv6_acl policy ipv6_map include-control
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

## show rate-limit interface

Displays the rate-limiting information for the interface indicated.

**Syntax** `show rate-limit interface [ slot/port ]`

**Modes** User EXEC mode.

**Examples** The `show rate-limit interface` command displays the following information.

```
Brocade#show rate-limit interface
interface e 8/1
rate-limit input vlan-id 2 broadcast multicast 97728 10000 include- control
rate-limit input broadcast multicast 97728 10000 include-control
rate-limit input access-group name ipv4_acl 100000 10000 include-control
```

### History

---

| Release version | Command history |
|-----------------|-----------------|
|-----------------|-----------------|

|        |                              |
|--------|------------------------------|
| 5.7.00 | This command was introduced. |
|--------|------------------------------|

## show rate-limit ipv6 hoplimit-expired-to-cpu

Displays the information about rate-limit configuration on IPv6 hoplimit-not-ok packets.

**Syntax** `show rate-limit ipv6 hoplimit-expired-to-cpu`

**Modes** User EXEC mode

**Command Output** The `show rate-limit ipv6 hoplimit-expired-to-cpu` command displays the following information:

| Output field | Description                                                                                                                                                                                                                                                |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fwd          | The hoplimit-expired-to-cpu traffic in bytes that has been sent to the CPU as a result of the hoplimit-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                          |
| Drop         | The hoplimit-expired-to-cpu traffic in bytes that has been dropped as a result of the hoplimit-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                  |
| Re-mark      | The hoplimit-expired-to-cpu traffic in bytes whose priority have been remarked as a result of exceed the bandwidth available in the CIR bucket for the hoplimit-expired-to-cpu rate limit policy since the device was started up or the counter was reset. |
| Total        | The total hoplimit-expired-to-cpu traffic in bytes that has been subjected to the hoplimit-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                      |

**Examples** This example displays output of the `show rate-limit ipv6 hoplimit-expired-to-cpu` command.

```
device#show rate-limit ipv6 hoplimit-expired-to-cpu
Fwd: 1865392 Drop: 867731400 bytes
Re-mark: 1864800 Total: 871461592 bytes
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## show rate-limit option-pkt-to-cpu

Displays the information about rate-limit configuration on IPv4 option packets.

**Syntax** `show rate-limit option-pkt-to-cpu`

**Modes** User EXEC mode

**Command Output** The `show rate-limit option-pkt-to-cpu` command displays the following information:

| Output field | Description                                                                                                                                                                                                                                              |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fwd          | The IPv4 option-pkt-to-cpu traffic in bytes that has been sent to the CPU as a result of the IPv4 option-pkt-to-cpu rate limit policy since the device was started up or the counter was reset.                                                          |
| Drop         | The IPv4 option-pkt-to-cpu traffic in bytes that has been dropped as a result of the IPv4 option-pkt-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                  |
| Re-mark      | The IPv4 option-pkt-to-cpu traffic in bytes whose priority have been remarked as a result of exceed the bandwidth available in the CIR bucket for the IPv4 option-pkt-to-cpu rate limit policy since the device was started up or the counter was reset. |
| Total        | The total IPv4 option-pkt-to-cpu traffic in bytes that has been subjected to the IPv4 option-pkt-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                      |

**Examples** This example displays of the `show rate-limit option-pkt-to-cpu` command.

```
device# show rate-limit option-pkt-to-cpu
Fwd: 1865392 Drop: 867731400 bytes
Re-mark: 1864800 Total: 871461592 bytes
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |



## show rate-limit ttl-expired-to-cpu

Displays the information about rate-limit configuration on IPv4 ttl-expired-to-cpu packets.

**Syntax** `show rate-limit ttl-expired-to-cpu`

**Modes** User EXEC mode

**Command Output** The `show rate-limit ttl-expired-to-cpu` command displays the following information:

| Output field | Description                                                                                                                                                                                                                                      |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fwd          | The ttl-expired-to-cpu traffic in bytes that has been sent to the CPU as a result of the ttl-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                          |
| Drop         | The ttl-expired-to-cpu traffic in bytes that has been dropped as a result of the ttl-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                  |
| Re-mark      | The ttl-expired-to-cpu traffic in bytes whose priority have been remarked as a result of exceed the bandwidth available in the CIR bucket for the ttl-expired-to-cpu rate limit policy since the device was started up or the counter was reset. |
| Total        | The total ttl-expired-to-cpu traffic in bytes that has been subjected to the ttl-expired-to-cpu rate limit policy since the device was started up or the counter was reset.                                                                      |

**Examples** This example displays output of the `show rate-limit ttl-expired-to-cpu` command.

```
device# show rate-limit ttl-expired-to-cpu
Fwd: 1865392 Drop: 867731400 bytes
Re-mark: 1864800 Total: 871461592 bytes
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## show rmon alarm

Displays the Remote monitoring (RMON) alarm events.

**Syntax** `show rmon alarm [ number ]`

**Parameters** *number*  
Specifies a RMON alarm number.

**Modes** User EXEC mode

**Usage Guidelines** An RMON alarm is designed to monitor configured thresholds. An alarm event is reported each time that a threshold is exceeded. The alarm entry also indicates the action (event) to be taken if the threshold be exceeded.

## show rmon statistics

Displays the Remote monitoring (RMON) agent status and information about RMON statistics.

**Syntax** **show rmon statistics** [ *number* | **ethernet slot/port** | **management port** ]

**Parameters** *number*

Displays the RMON statistics for a specific statistics index identification number. Valid values range from 1 through 65535.

**ethernet slot/port**

Displays the RMON statistics for a specific Ethernet interface.

**management port**

Displays the RMON statistics for a specific management port.

**Modes** User EXEC mode

**Usage Guidelines** Entering the **show rmon statistics** command without any options displays statistics for all ports.

**Command Output** The **show rmon statistics** command displays the following information:

| Output field     | Description                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Octets           | The total number of octets of data received on the network. This number includes octets in bad packets. This number does not include framing bits but does include Frame Check Sequence (FCS) octets.                                                                                                                                                                                                  |
| Drop events      | Indicates an overrun at the port. The port logic could not receive the traffic at full line rate and had to drop some packets as a result. The counter indicates the total number of events in which packets were dropped by the RMON probe due to lack of resources. This number is not necessarily the number of packets dropped, but is the number of times an overrun condition has been detected. |
| Packets          | The total number of packets received. This number includes bad packets, broadcast packets, and multicast packets.                                                                                                                                                                                                                                                                                      |
| Broadcast pkts   | The total number of good packets received that were directed to the broadcast address. This number does not include multicast packets.                                                                                                                                                                                                                                                                 |
| Multicast pkts   | The total number of good packets received that were directed to a multicast address. This number does not include packets directed to the broadcast address.                                                                                                                                                                                                                                           |
| CRC align errors | The total number of packets received that were from 64 - 1518 octets long, but had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). The packet length does not include framing bits but does include FCS octets.                                                                                                    |
| Undersize pkts   | The total number of packets received that were less than 64 octets long and were otherwise well formed. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                         |

| Output field            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fragments               | The total number of packets received that were less than 64 octets long and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for this counter to increment, since it counts both runts (which are normal occurrences due to collisions) and noise hits. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Oversize packets        | The total number of packets received that were longer than 1518 octets and were otherwise well formed. This number does not include framing bits but does include FCS octets.<br><br>48GC modules do not support count information on oversized packets and report 0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Jabbers                 | The total number of packets received that were longer than 1518 octets and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). This number does not include framing bits but does include FCS octets.<br><br>This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.<br><br>This definition of jabber is different from the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms. |
| Collisions              | The best estimate of the total number of collisions on this Ethernet segment.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 64 octets pkts          | The total number of packets received that were 64 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 65 to 127 octets pkts   | The total number of packets received that were 65 - 127 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 128 to 255 octets pkts  | The total number of packets received that were 128 - 255 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 256 to 511 octets pkts  | The total number of packets received that were 256 - 511 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 512 to 1023 octets pkts | The total number of packets received that were 512 - 1023 octets long. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 1024 to Max size        | The total number of packets received that were 1024 octets - the maximum size of octets. This number includes bad packets. This number does not include framing bits but does include FCS octets.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

**Examples** The following example displays statistics for all RMON ports.

```
device(config)# show rmon statistics
Ethernet statistics 1 is active, owned by monitor
Interface 1/1 (ifIndex 1) counters
  Octets 0
  Drop events 0
  Broadcast pkts 0
  CRC alignment errors 0
  Oversize pkts 0
  Jabbers 0
  64 octets pkts 0
  128 to 255 octets pkts 0
  512 to 1023 octets pkts 0
  Packets 0
  Multicast pkts 0
  Undersize pkts 0
  Fragments 0
  Collisions 0
  65 to 127 octets pkts 0
  256 to 511 octets pkts 0
  1024 to 1518 octets pkts 0
```

## show route-map

Displays route map information.

**Syntax** `show route-map name | binding`

**Parameters** *map-name*

Shows details of the matched UDA ACL configured in the route map, along with the IPv4 ACL and IPv6 ACL.

**binding**

Shows the UDA PBR binding along with IPv4 and IPv6 PBR bindings. This command is supported in the LP only.

**Modes** EXEC mode

**Examples** The following example below shows the output of the command.

```
device(config)# show route-map
route-map Test1 permit 1
  match uda udaAcl
  match ip address 101
  set next-hop-flood-vlan 10
```

The following example show the command using the **binding** option.

```
device# show route-map binding
IPv4 Bindings of Test1 :
  4/4
UDA PBR Bindings of Test2 :
  3/1
```

**History**

| Release version | Command history                                           |
|-----------------|-----------------------------------------------------------|
| 5.9.00          | This command was modified to support UDA PBR information. |

# show rstp

Displays Rapid Spanning Tree Protocol (RSTP) information.

**Syntax** `show rstp [ blocked ] [ vlan vlan-id ]`

**Parameters** `blocked`

Displays information in respect of ports blocked by the RSTP only.

`vlan vlan-id`

Displays RSTP information for a specific VLAN.

**Modes** User EXEC mode

**Usage Guidelines** This command can also be entered in global configuration mode.

**Examples** The following example displays a summary of RSTP information for VLAN 10:

```
device> show rstp vlan 10

VLAN 10 - RSTP instance 0
-----
RSTP (IEEE 802.1w) Bridge Parameters:
Bridge          Bridge Bridge Bridge Force   tx
Identifier      MaxAge Hello  FwdDly Version Hold
hex             sec  sec   sec   sec      cnt
0001000480a04000 20   2    15   Default 3
RootBridge      RootPath DesignatedBridge Root  Max Hel Fwd
Identifier      Cost      Identifier      Port  Age lo  Dly
hex             hex             hex      sec sec sec
0001000480a04000 0      0001000480a04000 Root  20  2  15
RSTP (IEEE 802.1w) Port Parameters:
  <--- Config Params -->|<----- Current state ----->
Port  Pri PortPath  P2P Edge Role      State      Designa-  Designated
Num   Cost      Mac Port  State      ted cost  bridge
1/3   128 20000    T  F  DISABLED  DISABLED  0      0000000000000000
1/13  128 20000    T  F  DISABLED  DISABLED  0      0000000000000000
```

The following example displays a summary of ports blocked by RSTP on VLAN 20:

```
device> show rstp blocked vlan 20

VLAN 20 - RSTP instance 0
-----
RSTP (IEEE 802.1w) Bridge Parameters:
Bridge          Bridge Bridge Bridge Force   tx
Identifier      MaxAge Hello  FwdDly Version Hold
hex             sec  sec   sec   sec      cnt
80000024389e2d20 20   2    15   Default 3
RootBridge      RootPath DesignatedBridge Root  Max Hel Fwd
Identifier      Cost      Identifier      Port  Age lo  Dly
hex             hex             hex      sec sec sec
80000024388f6b20 2000    80000024388f6b20 3/5  20  2  15
RSTP (IEEE 802.1w) Port Parameters:
  <--- Config Params -->|<----- Current state ----->
Port  Pri PortPath  P2P Edge Role      State      Designa-  Designated
Num   Cost      Mac Port  State      ted cost  bridge
3/6   128 2000     F  F  ALTERNATE  DISCARDING 0      80000024388f6b20
3/7   128 2000     F  F  ALTERNATE  DISCARDING 0      80000024388f6b20
3/8   128 2000     F  F  ALTERNATE  DISCARDING 0      80000024388f6b20
```

**History**

---

| <b>Release</b> | <b>Command History</b>                                              |
|----------------|---------------------------------------------------------------------|
| 5.5.00         | The command was modified to display only ports blocked by the RSTP. |

---



# show running-config

Displays the current running configuration.

**Syntax** **show running-config**

**Parameters** **interface**

Displays the running-configuration section.

**ethernet** *slot/port*

Displays the specified ethernet port.

**loopback** *num*

Displays the loopback port.

**pos** *slot/port*

Displays the specified POS port.

**tunnel** *num*

Displays the specified tunnel port.

**ve** *num*

Displays the specified Virtual Ethernet (VE) port.

**lag**

Displays the LAG running-configuration section.

**detailed**

Displays the LAG running-configuration information in detail.

**id** *lag\_id*

Displays the specified LAG running-configuration.

**name** *lag\_name*

Displays the specified LAG running-configuration name.

**vlan**

Displays the VLAN running-configuration section.

**Modes** User EXEC mode

**Usage Guidelines** Use this command with filtering for the specific command for which you want to review the current configuration on the device. Most commands are available in this format using either the begin or the include options. See the Example section for examples of each option.

**Examples** The following example displays the **show running-config** command. Notice that the interface bandwidth command is displayed as part of the interface configuration.

```
device#show running-config interface tunnel 2
interface tunnel 2
  tunnel mode gre ip
  tunnel source 169.70.15.2
  tunnel destination 169.70.15.1
  ip address 199.0.0.2/24
  bandwidth 2000
```

The following example displays the **show running-config** command executed on an Ethernet interface.

```
device#show running-config interface ethernet 8/1
interface e 8/1
  rate-limit input vlan-id 2 broadcast multicast 97728 10000 include- control
  rate-limit input broadcast multicast 97728 10000 include-control
  rate-limit input access-group name ipv4_acl 100000 10000 include-control
```

| History | Release version | Command history                                                                                              |
|---------|-----------------|--------------------------------------------------------------------------------------------------------------|
|         | 5.7.00          | This command was modified to include the interface bandwidth command as part of the interface configuration. |

# show sflow statistics

Displays the total count per interface for both sFlow and ACL-based samples in all slots where sFlow is configured.

**Syntax** `show sflow statistics slot/port`

**Parameters** `slot port`  
Displays statistics for the specified port.

**Modes** User EXEC mode

## Usage Guidelines

### History

---

| Release | Command History                                                    |
|---------|--------------------------------------------------------------------|
| 5.5.00  | This command was modified to display sFlow statistics information. |

---

# show spanning-tree

Displays Spanning Tree Protocol (STP) information.

- Syntax** `show spanning-tree [ blocked ] [ vlan vlan-id [ ethernet slot/port ] ]`
- Parameters**
  - blocked** Displays information for ports blocked by the STP only.
  - vlan *vlan-id*** Displays information for a specific port-based VLAN.
  - ethernet *slot port*** Displays information for a specific Ethernet interface on a port-based VLAN.
- Modes** User EXEC mode
- Usage Guidelines** This command is also available in global configuration mode.
- Examples** The following example displays STP information for VLAN 10:

```
device> show spanning-tree vlan 10
VLAN 10 - STP instance 1
-----
STP Bridge Parameters:
Bridge Identifier      Bridge MaxAge Hello FwdDly Time Hold LastTopology Topology
Identifier            MaxAge Hello FwdDly Time Change Change
hex                  sec    sec    sec    sec    sec    cnt
8000000480a04000    20     2     15     1     0     0
RootBridge Identifier  RootPath DesignatedBridge Root Max Hel Fwd
Identifier            Cost      Identifier      Port Age lo Dly
hex                   hex          hex              sec sec sec
8000000480a04000    0          8000000480a04000 Root 20 2 15
STP Port Parameters:
Port Prio Path      State      Designat- Designated Designated
Num  rity Cost        ed Cost    Root      Bridge
1/3  128 4          DISABLED  0          0000000000000000 0000000000000000
1/13 128 4          DISABLED  0          0000000000000000 0000000000000000
```

The following example displays STP information for VLAN 10, listing blocked ports only:

```
device> show spanning-tree blocked vlan 10
VLAN 10 - STP instance 0
-----
STP Bridge Parameters:
Bridge Identifier      Bridge MaxAge Hello FwdDly Time Hold LastTopology Topology
Identifier            MaxAge Hello FwdDly Time Change Change
hex                  sec    sec    sec    sec    sec    cnt
80000024389e2d00    20     2     15     1     718    1
RootBridge Identifier  RootPath DesignatedBridge Root Max Hel Fwd
Identifier            Cost      Identifier      Port Age lo Dly
hex                   hex          hex              sec sec sec
80000024388f6b00    2          80000024388f6b00 3/1 20 2 15
STP Port Parameters:
Port Prio Path      State      Designat- Designated Designated
Num  rity Cost        ed Cost    Root      Bridge
3/2  128 2          BLOCKING  0          80000024388f6b00 80000024388f6b00
3/3  128 2          BLOCKING  0          80000024388f6b00 80000024388f6b00
3/4  128 2          BLOCKING  0          80000024388f6b00 80000024388f6b00
```

## History

| Release | Command History                                                                       |
|---------|---------------------------------------------------------------------------------------|
| 5.5.00  | The command was modified to display only ports blocked by the Spanning Tree Protocol. |

## show statistics

Displays the statistics for a specific option.

**Syntax** **show statistics brief** [ *ethernet* | *lag* | *management* | *pos* | *slot* | *tunnel* ]

**show statistics dos-attack**

**show statistics ethernet** *slot/port*

**show statistics lag** *lag\_name*

**show statistics management** *dec*

**show statistics pos** *slot/port*

**show statistics slot** *dec*

**show statistics tunnel** *ip\_tunnel\_id*

**show statistics ipsec-tunnel** *tunnel-id*

**Parameters** **brief**

Displays the port statistics in brief mode.

*ethernet*

Displays the ethernet port in brief mode.

*lag*

Displays LAG in brief mode.

*management*

Displays the management port in brief mode.

*pos*

Displays the POS port in brief mode.

*slot*

Displays all ports in a slot in brief mode.

*tunnel*

Displays IP tunnel statistics in brief mode.

**dos-attack**

Displays DOS-attack statistics.

**ethernet** *slot/port*

Displays the ethernet port for the specified slot and port.

**lag**

Displays LAG determined by the *lag\_name* variable.

**management**

Displays the management port determined by the *dec* variable.

**pos**

Displays the POS port determined by the *slot/port* variable.

**slot**

Displays all of the ports in a slot determined by the *slot/port* variable.

**tunnel**

Displays the IP tunnel statistics determined by the *ip\_tunnel\_id* variable.

**ipsec-tunnel** *tunnel-id*

Displays the bytes and packets count for the specified IPSec tunnel ID.

**Modes** This command operates under all modes.

**Command Output** The **show statistics ethernet** command displays the following information:

| Output field      | Description                                                                                                                                                                                                                    |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| InOctets          | The total number of good octets and bad octets received.                                                                                                                                                                       |
| OutOctets         | The total number of good and bad octets transmitted.                                                                                                                                                                           |
| InPkts            | The total number of packets received. the count includes rejected and local packets that are not transmitted to the switching core for transmission.                                                                           |
| OutPkts           | The number of good packets received. The count includes unicast, multicast, and broadcast packets.                                                                                                                             |
| InBroadcastPkts   | The total number of good broadcast packets received.                                                                                                                                                                           |
| OutBroadcastPkts  | The total number of good broadcast packets transmitted.                                                                                                                                                                        |
| InMulticastPkts   | The total number of good multicast packets received.                                                                                                                                                                           |
| OutMulticastPkts  | The total number of good multicast packets transmitted.                                                                                                                                                                        |
| InUnicastPkts     | The total number of good unicast packets received.                                                                                                                                                                             |
| OutUnicastPkts    | The total number of good unicast packets transmitted.                                                                                                                                                                          |
| InDiscards        | The total number of packets that were received and then dropped due to a lack of received buffers.                                                                                                                             |
| OutDiscards       | The total number of packets that were transmitted and then dropped due to a lack of transmit buffers.                                                                                                                          |
| InErrors          | The total number of packets received that had Alignment errors or phy errors.                                                                                                                                                  |
| OutErrors         | The total number of packets transmitted that has Alignment errors or phy errors.                                                                                                                                               |
| InCollisions      | The total number of packets received in which a Collision event was detected.                                                                                                                                                  |
| OutCollisions     | The total number of packets transmitted in which a Collision event was detected.                                                                                                                                               |
| OutLateCollisions | The total number of packets transmitted in which a Collision event was detected but for which a <i>receive error (RX error)</i> event was not detected.                                                                        |
| Alignment         | The total number of packets received that were from 64 - 1518 octets long but had either a bad FCS with an integral number of octets (FCS error) or a bad FCS with a non-integral number of octets (Alignment error).          |
| FCS               | The Frame Checksum error.                                                                                                                                                                                                      |
| InFlowCtrlPkts    | The total number of ingress flow control packets. "N/A" indicates that the interface module does not support flow control statistics.                                                                                          |
| OutFlowCtrlPkts   | The total number of egress flow control packets.                                                                                                                                                                               |
| GiantPkts         | The total number of packets for which all of the following is true: <ul style="list-style-type: none"> <li>• The data length was longer than the maximum allowable frame size.</li> <li>• No Rx error was detected.</li> </ul> |

| Output field   | Description                                                                                                                                                                                                                                                     |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ShortPkts      | The total number of packets received for which all of the following is true: <ul style="list-style-type: none"> <li>The data length was less than 64 bytes.</li> <li>No Rx error was detected.</li> <li>No Collision or late Collision was detected.</li> </ul> |
| InBitsPerSec   | The number of bits received per second.                                                                                                                                                                                                                         |
| OutBitsPerSec  | The number of bits transmitted per second.                                                                                                                                                                                                                      |
| InPktsPerSec   | The number of packets received per second.                                                                                                                                                                                                                      |
| OutPktsPerSec  | The number of packets transmitted per second.                                                                                                                                                                                                                   |
| InUtilization  | The percentage of the port's bandwidth used by received traffic.                                                                                                                                                                                                |
| OutUtilization | The percentage of the port's bandwidth used by transmitted traffic.                                                                                                                                                                                             |

**Examples** The following example displays the **show statistics ethernet** command:

```
device# show statistics ethernet 9/1

PORT 9/1 Counters:
InOctets      210753498112   OutOctets      210753550720
InPkts        1646511726       OutPkts        1646512119
InBroadcastPkts  0             OutBroadcastPkts  0
InMulticastPkts  0             OutMulticastPkts  0
InUnicastPkts  1646511726     OutUnicastPkts  1646512142
InDiscards    0             OutDiscards    0
InErrors      0             OutErrors      0
InCollisions  0             OutCollisions  0
              0             OutLateCollisions 0
              0             FCS            0
Alignment     0             InFlowCtrlPkts 0
InFlowCtrlPkts 0             OutFlowCtrlPkts 0
GiantPkts     0             ShortPkts      0
InBitsPerSec  3440829770     OutBitsPerSec  3440686411
InPktsPerSec  3360185        OutPktsPerSec  3360085
InUtilization  39.78%        OutUtilization  39.78%
```

The following example displays the **show statistics brief ipsec-tunnel** command modified to display IPsec tunnel interface packet and byte count.

```
device#show statistics brief ipsec-tunnel
#      Tnnl      RxPkts      RxBytes      TxPkts      TxBytes
1      24         0           0            0           0
2      100        0           0            457         79518
3      101        0           0            0           0
4      102        0           0            0           0
5      103        0           0            1           174
6      104        0           0            0           0
7      105        0           0            0           0
8      106        0           0            0           0
9      107        0           0            0           0
10     108        0           0            0           0
11     109        0           0            0           0
12     110        0           0            0           0
13     123        0           0            0           0
14     124        0           0            0           0
15     125        0           0            0           0
16     150        0           0            0           0
17     254        0           0            0           0
```

The following example shows the bytes and packet count only for the IPsec tunnel interface 100.

```
device# show statistics ipsec-tunnel 100

IPSec tunnel 100 statistics:
  RxPkts:      0          TxPkts:    467
  RxBytes:     0          TxBytes:  81258
```

**History**

| Release version | Command history                                                                    |
|-----------------|------------------------------------------------------------------------------------|
| 05.8.00         | This command was modified to display IPsec tunnel interface packet and byte count. |



# show sysmon config

Displays the system monitoring configuration.

**Syntax** `show sysmon config`

**Modes** User EXEC mode

**Command Output** The `show sysmon config` command displays the following information:

| Output field                   | Description                                                                                          |
|--------------------------------|------------------------------------------------------------------------------------------------------|
| EVENT                          | Name of the diagnostic test.                                                                         |
| ACTION                         | Action to be taken in case of a failure of the test.                                                 |
| POLL PERIOD (SEC)              | The polling period in seconds.                                                                       |
| THRESHOLD #(PER POLL in #POLL) | The number of failed tests out of the number of pollings (applicable only for threshold based test). |
| LOG BACK-OFF                   | The number of event logs to be skipped before logging again.                                         |

**Examples** The following example displays the monitoring configuration.

```
device# show sysmon config
-----+-----+-----+-----+-----
EVENT          | ACTION          | POLL PERIOD | THERESHOLD | LOG BACK-OFF
          |          | (SEC)      | # (PER POLL |
          |          |            | in #POLL) |
-----+-----+-----+-----+-----
TM. Link Monitoring | SHUTDOWN-LINK | 60         | 5 in 10   | 1800
Port CRC Monitoring | SYSLOG         | 60         | 3 in 5    | 1800
FE. Link Monitoring | SHUTDOWN-LINK | 60         | 5 in 10   | 1800
NP Memory Error Monitoring | SYSLOG-AND-TRAP | 10        | N/A       | N/A
-----+-----+-----+-----+-----
```

## History

| Release Version | Command History |
|-----------------|-----------------|
|-----------------|-----------------|

|        |                                                                                          |
|--------|------------------------------------------------------------------------------------------|
| 5.6.00 | This command was modified to display the NP memory error monitoring event configuration. |
|--------|------------------------------------------------------------------------------------------|

## show sysmon results brief

Displays summary information of scheduled test results in brief without providing the instance information.

**Syntax** `show sysmon results test-name brief`

**Parameters** *test-name*

Displays summary results for a specific scheduled test.

**Modes** User EXEC mode

**Command Output** The `show sysmon results brief` command displays the following information:

| Output field                   | Description                                                                                          |
|--------------------------------|------------------------------------------------------------------------------------------------------|
| EVENT                          | Name of the diagnostic test.                                                                         |
| ACTION                         | Action to be taken in case of a failure of the test.                                                 |
| SLOTS                          | Slots on which the test is configured to run.                                                        |
| MODE                           | Mode of running for the test. The modes are Continuously polling or Scheduling.                      |
| POLL PERIOD (SEC)              | The polling period in seconds.                                                                       |
| THRESHOLD #(PER POLL in #POLL) | The number of failed tests out of the number of pollings (applicable only for threshold based test). |
| LOG BACK-OFF                   | The number of event logs to be skipped before logging again.                                         |
| SLOT                           | The slot number.                                                                                     |
| TEST TYPE                      | The specific scheduling test type.                                                                   |
| BRIEF RESULT (LAST RUN/ CYCLE) | The brief results showing only the status (passed/ failed) of the test on each slot.                 |

**Examples** The following example displays results from the port-crc-test.

```

device(config)#show sysmon results port-crc-test brief
Module is(are) not UP in slot(s) 3 4 5
The configuration of port-crc-test is
-----+-----+-----+-----+-----+-----+
EVENT          | ACTION          | SLOTS      | MODE         | POLL PERIOD |
THRESHOLD     | LOGBACK-OFF    |             |              | (SEC)       |
#(PER POLL   |                 |             |              |              |
in #POLL)    |                 |             |              |              |
-----+-----+-----+-----+-----+
Port CRC Monitoring | SYSLOG         | ALL        | SCHEDULING  | 60         |
3 in 4 | 1                 |             |              |              |
-----+-----+-----+-----+
Brief result of port-crc-test is
-----+-----+-----+-----+
SLOT | TEST TYPE          | BRIEF RESULT (LAST RUN/CYCLE)
-----+-----+-----+-----+
Slot 1 | Scheduled at 2014.05.27-10:56:52 | PASSED
-----+-----+-----+-----+
Slot 2 | Scheduled at 2014.05.27-10:56:52 | PASSED
-----+-----+-----+-----+
Slot 6 | Scheduled at 2014.05.27-10:56:52 | PASSED
-----+-----+-----+-----+
Slot 7 | Scheduled at 2014.05.27-10:56:52 | PASSED
-----+-----+-----+-----+
Slot 8 | Scheduled at 2014.05.27-10:56:52 | PASSED
-----+-----+-----+-----+

```

#### History

##### Release version

##### Command history

05.7.00

This command was introduced.

## show sysmon results detail

Displays scheduled test results in detail for a specified slot. Instance information and other details are displayed.

**Syntax** `show sysmon results test-name detail slot-id`

**Parameters** *test-name*

Displays detailed results for specified test name.

*slot-id*

Displays detailed results for a specified slot name of theThe slot numbers to be specified to run the test.

**Modes** User EXEC mode

**Command Output** The `show sysmon results detail` command displays the following information:

| Output field                   | Description                                                                                          |
|--------------------------------|------------------------------------------------------------------------------------------------------|
| EVENT                          | Name of the diagnostic test.                                                                         |
| ACTION                         | Action to be taken in case of a failure of the test.                                                 |
| SLOTS                          | Slots on which the test is configured to run.                                                        |
| MODE                           | Mode of running for the test. The modes are Continuously polling or Scheduling.                      |
| POLL PERIOD (SEC)              | The polling period in seconds.                                                                       |
| THRESHOLD #(PER POLL in #POLL) | The number of failed tests out of the number of pollings (applicable only for threshold based test). |
| LOGBACK-OFF                    | The number of event logs to be skipped before logging again.                                         |
| INSTANCE                       |                                                                                                      |
| TEST TYPE                      | The specific scheduling test type.                                                                   |
| # OF RUNS                      | The number of times test is run.                                                                     |
| # OF FAILURES                  | The number of times the test failed (out of the number of runs).                                     |

**Examples** The following example displays information about the port-crc-test.

```
device(config)#show sysmon results port-crc-test detail 1
The configuration of port-crc-test is
```

```
-----+-----+-----+-----+-----+
+-----+-----+
EVENT          |ACTION          |SLOTS          |MODE          |POLL
PERIOD| THRESHOLD |LOGBACK-OFF    |              |              | (SEC)
| #(PER POLL |              |              |              |              |
| in #POLL) |              |              |              |              |
-----+-----+-----+-----+-----+
Port CRC Monitoring |SYSLOG          |ALL            |SCHEDULING| 60
| 3 in 4 | 1
-----+-----+-----+-----+-----+
```

```
The detail result (LAST RUN/CYCLE) of port-crc-test on LP 1 is
```

```
-----+-----+-----+-----+-----+
INSTANCE          |              TYPE          | # OF | # OF
                  |              | RUNS | FAILURES
-----+-----+-----+-----+-----+
Port 1/1          | Scheduled at 2014.05.27-10:56:52 | 4    | 0
-----+-----+-----+-----+-----+
Port 1/2          | Scheduled at 2014.05.27-10:56:52 | 4    | 0
-----+-----+-----+-----+-----+
Port 1/3          | Scheduled at 2014.05.27-10:56:52 | 4    | 0
-----+-----+-----+-----+-----+
Port 1/4          | Scheduled at 2014.05.27-10:56:52 | 4    | 0
-----+-----+-----+-----+-----+
```

## History

### Release version

### Command history

05.7.00

This command was introduced.

# show sysmon schedule

Displays details of scheduled tests.

**Syntax** `show sysmon sched name of the test`

**Parameters** *name of the test*  
 The name of the scheduled test.

**Modes** User EXEC mode  
 Privileged EXEC mode  
 Global configuration mode

**Command Output** The `show sysmon schedule` command displays the following information:

| Output field        | Description                                                                                                                                                 |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TEST NAME           | Name of the test.                                                                                                                                           |
| SCHEDULED AT        | The scheduled time in hh:mm:ss mm-dd-yy format. Here the first instance of mm is minutes and the second instance is months. For example, 14:30:00 08-20-13. |
| MP/LP               | Type of slot.                                                                                                                                               |
| # OF RUNS           | The number of runs. The range is between 1 and 31.                                                                                                          |
| THRESHOLD           | Threshold value of the diagnostic test.                                                                                                                     |
| TEST INTERVAL (SEC) | The test interval value in seconds.                                                                                                                         |

**Examples** The following example displays information about the port-crc-test.

```
device(config)#show sysmon schedule port-crc-test
+-----+-----+-----+-----+-----+
TEST NAME	SCHEDULED	MP/LP	# OF	THRESHOLD
	AT		RUNS	
INTERVAL				
(SEC)				
+-----+-----+-----+-----+-----+				
Port CRC Monitoring	2014.05.23-06:39:28	LP	4	3
60				
+-----+-----+-----+-----+-----+
```

The following example displays information about the np-memory-errors test.

```
device(config)#show sysmon schedule np-memory-errors
+-----+-----+-----+-----+-----+
TEST NAME	SCHEDULED	MP/LP	# OF	THRESHOLD
TEST	AT		RUNS	
INTERVAL				
(SEC)				
+-----+-----+-----+-----+-----+				
NP Memory Error Monitoring	2014.05.23-06:39:34	LP	4	0
60				
+-----+-----+-----+-----+-----+
```

#### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.7.00         | This command was introduced. |

## show telemetry

Displays information related to the telemetry configuration.

**Syntax** `show telemetry [ detail ] rule-name rule-name`

**Parameters** **detail**

Displays detailed information. The list of ports will be fully expanded and displayed if the ports are LAG or VLAN ports.

**rule-name** *rule-name*

Displays specified rule name information.

**Modes** EXEC mode

**Examples** The following example displays the UDA PBR policy detail along with the IPv4, IPv6 PBR information.

```
device(config)# show telemetry detail rule-name
Rule name: default-rulename
Input: IPv4 - 1/1
Route-map Policy: Test2
IPv4 ACL match: 110
Output:
Input: IPv4 - 3/1
Route-map Policy: Test1
IPv4 ACL match: 100
Output:
Input: UDA - 3/1
Route-map Policy: Test1
UDA ACL match: 2000
Output:
```

The following example displays the UDA PBR policy detail along with the IPv4, IPv6 and PBR information.

```
device(config)# show telemetry rule-name
Paths with leading * are configured but disabled, entries with + are for IPv6 entries
with # are for UDA
```

| Name      | Input | Route-map Policy | ACL Match | Output VLAN | Output Port(s)/IP |
|-----------|-------|------------------|-----------|-------------|-------------------|
| RT_TEST1  | 4/8   | Test1            |           | 100         |                   |
| +RT_TEST1 | 4/8   | Test1            |           | 100         |                   |
| #RT_TEST1 | 4/8   | Test1            |           | 100         |                   |
| *RT_TEST3 | N/A   | Test3            |           | N/A         | N/A               |
| #RT_TEST4 | 3/3   | Test4            |           |             | 2/3               |

---

### Release version

### Command history

5.9.00

This command was modified to display the UDA PBR policy detail along with the IPv4, IPv6 PBR information.

---



# show terminal

Displays terminal settings.

**Syntax** `show terminal`

**Modes** User EXEC mode

**Command Output** The `show terminal` command displays the following information:

| Output field                | Description                                                                                                 |
|-----------------------------|-------------------------------------------------------------------------------------------------------------|
| 2015-08-11T22:20:59+00:00   | Timestamp is displayed in ISO 8601 format: YYYY-MM-DDThh:mm:ssTZD (for example, 1997-07-16T19:20:30+01:00). |
| Length                      | Number of lines configured as the terminal length.                                                          |
| Page display mode (session) | Session page display is either enabled or disabled.                                                         |
| Page display mode (global)  | Global page display is either enabled or disabled.                                                          |
| Timestamp: enabled          | The format in which the timestamp is displayed; system or iso8601.                                          |

**Examples** The following example displays the terminal settings.

```
device# show terminal

Length: 24 lines
Page display mode (session): disabled
Page display mode (global): enabled
Timestamp: enabled (system format)
```

The following example displays the terminal settings with a timestamp and iso8601 format.

```
device# show terminal

2015-08-11T22:20:59+00:00
Length: 24 lines
Page display mode (session): disabled
Page display mode (global): enabled
Timestamp: enabled (iso8601 format)
```

**History**

| Release version | Command history                                                                |
|-----------------|--------------------------------------------------------------------------------|
| 05.4.0          | This command was introduced.                                                   |
| 05.9.0          | This command was modified to include timestamp information in ISO 8601 format. |

## show tm-voq-stat queue-drops

Use **show tm-voq-stat queue-drops** command to display traffic manager statistics.

**Syntax** **show tm-voq-stat queue-drops** *dst\_port destination-port ethernet slot/port*

**Modes** This command operates in the Global configuration mode.

**Command Output** The **show tm-voq-stat queue-drops** command displays the following information:

**TABLE 11** Traffic Manager statistics for queue drops

| This field...               | Displays...                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| EnQue Pkt Count             | A count of all packets entering ingress queues on this traffic manager.                                                                                                                                                                                                                                                                                 |
| EnQue Byte Count            | A count of all bytes entering ingress queues on this traffic manager.                                                                                                                                                                                                                                                                                   |
| DeQue Pkt Count             | A count of all packets dequeued from ingress queues and forwarded on this traffic manager.                                                                                                                                                                                                                                                              |
| DeQue Byte Count            | A count of all bytes dequeued from ingress queues and forwarded on this traffic manager.                                                                                                                                                                                                                                                                |
| TotalQue Discard Pkt Count  | A count of all packets failing to enter ingress queues on this traffic manager. This may be due to: <ul style="list-style-type: none"> <li>the queue reaching its maximum depth, WRED, or other reasons.</li> <li>the network processor deciding to drop packets for reasons including: an unknown Layer-3 route, RPF, or segment filtering.</li> </ul> |
| TotalQue Discard Byte Count | A count of all bytes failing to enter ingress queues on this traffic manager. This may be due to: <ul style="list-style-type: none"> <li>the queue reaching its maximum depth, WRED, or other reasons.</li> <li>the network processor deciding to drop packets for reasons including: an unknown Layer-3 route, RPF, or segment filtering.</li> </ul>   |

### History

| Release version   | Command history               |
|-------------------|-------------------------------|
| NI 5.7.00 release | This command was introduced . |

# show vlan

Displays VLAN information.

**Syntax** `show vlan vlan_id [ statistics ]`  
`show vlan vlan_id brief [ wide ]`  
`show vlan vlan_id [ statistics ] detail`  
`show vlan vlan_id [ statistics ] ethernet [ slot/port ]`  
`show vlan vlan_id [ statistics ] tvf-lag-lb [ detail ]]`

**Parameters** *vlan\_id* VLAN identifier.

**statistics** Displays VLAN extended counters.

**brief** Displays VLAN information in table format.

**wide** Displays full VLAN name.

**detail** Displays VLAN information in a detailed format.

**ethernet** *slot/port* Port configured in the VLAN.

**tvf-lag-lb** Displays transparent VLAN flooding load balancing information

**detail** Displays transparent VLAN flooding load balancing information in detail.

**Modes** Privileged EXEC mode.

**Examples** The following example displays transparent VLAN flooding LAG load balancing information.

```
device# show vlan tvf-lag-lb
****TVF LAG Load Balancing****
TVF LAG Load Balancing is enabled!
TVF FID pool size: 2048, Max FID groups: 512, FID group size: 4
TVF LAG Load balancing groups:
VLAN: 100, group ID: 257, FID base: 0x9800, FID count: 4
VLAN: 200, group ID: 258, FID base: 0x9804, FID count: 4
2TVF LAG Load balancing groups are configured
```

The following example displays the full VLAN name and information in table format.

```
device# show vlan brief wide
```

```
Configured PORT-VLAN entries: 16
Maximum PORT-VLAN entries: 512
Default PORT-VLAN id: 1
```

| VLAN            | Name         | Ports                                                                                         |
|-----------------|--------------|-----------------------------------------------------------------------------------------------|
| 1               | DEFAULT-VLAN | Untagged Ports : ethe 4/1 to 4/8                                                              |
| 100             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 4/1 to 4/8<br>Untagged Ports : ethe 3/1 to 3/24 |
| 200             | [None]       | Statically tagged Ports: ethe 3/1 to 3/24 ethe 4/1 to 4/8<br>Untagged Ports : ethe 1/1 to 1/2 |
| 300             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 400             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 500             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 600             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 700             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 800             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 900             | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 1000            | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 2000            | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 3000            | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 4000            | [None]       | Statically tagged Ports: ethe 1/1 to 1/2 ethe 3/1 to 3/24                                     |
| ethe 4/1 to 4/8 |              |                                                                                               |
| 4090            | [None]       |                                                                                               |
| 4095            | CONTROL-VLAN |                                                                                               |

**History**

| Release version | Command history                                                      |
|-----------------|----------------------------------------------------------------------|
| 5.6.00          | This command is modified to include the <b>tvf-lag-lb</b> parameter. |
| 5.8.00          | This command is modified to include the <b>brief wide</b> parameter. |

# show vlan tvf-lag-lb

Displays transparent VLAN flooding LAG load balancing information.

**Syntax** `show vlan tvf-lag-lb detail`

**Parameters** `detail`

Specifies the detailed VLAN flooding LAG load balancing information in the output.

**Modes** Privileged EXEC mode

**Usage Guidelines** The `show vlan tvf-lag-lb` command displays transparent VLAN flooding LAG load balancing information.

**Examples** The following example displays transparent VLAN flooding LAG load balancing information:

```
device#show vlan tvf-lag-lb
**** TVF LAG Load Balancing ****
TVF LAG Load Balancing is enabled!
TVF FID pool size: 4096, Max FID groups: 1024, FID group size: 4
2 TVF LAG Load balancing groups are configured
TVF LAG Load balancing FID programming is done
```

The following example displays the detailed transparent VLAN flooding LAG load balancing information:

```
device#show vlan tvf-lag-lb detail
**** TVF LAG Load Balancing ****
TVF LAG Load Balancing is enabled!
TVF FID pool size: 4096, Max FID groups: 1024, FID group size: 4
2 TVF LAG Load balancing groups are configured
TVF LAG Load balancing FID programming is done
```

```
TVF LAG Load balancing groups:
VLAN: 100, group ID: 33, FID base: 0x9ffc, FID count: 4
VLAN: 200, group ID: 34, FID base: 0x9ff8, FID count: 4
```

## History

| Release | Command History                                                                    |
|---------|------------------------------------------------------------------------------------|
| 5.6.00  | This command was introduced.                                                       |
| 5.9.00  | This command was modified to include additional information in the command output. |

show vlan tvf-lag-lb

# Commands Si - Z

---

## slow-start

Configures a slow start timer interval to extend the time interval beyond the dead-interval time before a Virtual Router Redundancy Protocol Extended (VRRP-E) master device assumes the role of master device after being offline. When the original master device went offline, a backup VRRP-E device with a lower priority became the master device. The slow start allows for protocol convergence, and can also be used for tracked port state changes.

**Syntax** `slow-start seconds [ use-track-port [ restart ] ]`

`no slow-start seconds [ use-track-port [ restart ] ]`

**Command Default** If the slow start timer is not configured, the master device assumes control from a backup device immediately after the dead interval.

**Parameters** `seconds`

Sets the number of seconds for the slow start timer in a range from 1 to 57600 seconds.

**use-track-port**

Implements the slow start timer for the first tracked port "up" state change, in addition to the VRRP-E initialization state.

**restart**

Restarts the slow start timer for subsequent tracked port "up" state changes after the initial tracked port state change.

**Modes** VRRP-E router configuration mode

**Usage Guidelines** When the VRRP-E slow start timer is enabled, if the master VRRP-E device goes down, the backup device with the highest priority takes over after the expiration of the dead interval. If the original master device subsequently comes back up again, the amount of time specified by the VRRP-E slow start timer elapses before the original master device takes over from the backup device (which became the master device when the original master device went offline).

If the **use-track-port** option is not configured, the slow start timer will be started only for the VRRP-E master device initialization, not for any tracked port state change.

This command is only supported for VRRP-E.

The **no** form removes the slow start configuration.

**Examples** The following example sets the slow-start timer interval to 40 seconds.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# slow-start 40
```

The following example sets the slow-start timer interval to 40 seconds and configures the slow-start timer to run when a tracked port changes state.

```
device# configure terminal
device(config)# router vrrp-extended
device(config-vrrpe-router)# slow-start 30 use-track-port restart
```

## snmp-server community

Configures the SNMP community string and access privileges.

**Syntax** **snmp-server community** *community-string* { **ro** | **rw** } [ *acl-name* | *acl-num* | **ipv6** *ipv6-acl-name* | **view** [ *mib-view* ] ]

**no snmp-server community** *community-string* { **ro** | **rw** } [ *acl-name* | *acl-num* | **ipv6** *ipv6-acl-name* | **view** [ *mib-view* ] ]

**Command Default** The SNMP community string is not configured.

**Parameters** *community-string*

Configures the SNMP community string that you must enter to gain SNMP access. The string is an ASCII string and can have up to 32 characters. The default SNMP community name (string) on a device is "public" with the read-only privilege.

**ro**

Configures the community string to have read-only ("get") access.

**rw**

Configures the community string to have read-write ("set") access.

*acl-name*

Filters incoming packets using a named standard access control list (ACL).

*acl-num*

Filters incoming packets using a numbered ACL.

**ipv6** *ipv6-acl-name*

Filters incoming packets using a named IPv6 ACL.

**view** *mib-view*

Associates a view to the members of the community string. Enter up to 32 alphanumeric characters.

**Modes** Global configuration mode

**Usage Guidelines** The **view** *mib-view* parameter allows you to associate a view to the members of this community string. If no view is specified, access to the full MIB is granted. The view that you want must exist before you can associate it to a community string.

You can set just one access type, either read-only (ro) or read/write (rw) for a single SNMP community instead of setting both access types. The read/write access supersedes read-only configuration and if read/write is configured for a specified community after read only, the running configuration file only saves the rw configuration line.

If you issue the **no snmp-server community public ro** command and then enter the **write memory** command to save the configuration, the "public" community name is removed and will have no SNMP access. If for some reason the device is brought down and then brought up, the **no snmp-server community public ro** command is restored in the system and the "public" community string has no SNMP access.

The **no** form of the command removes an SNMP community string.

**Examples** The following example configures an SNMP community string with read-only access.

```
device# configure terminal
device(config)# snmp-server community private ro
```



The following example configures an ACL to filter SNMP packets.

```
device# configure terminal
device(config)# access-list 25 deny host 10.157.22.98 log
device(config)# access-list 25 deny 10.157.23.0 0.0.0.255 log
device(config)# access-list 25 deny 10.157.24.0 0.0.0.255 log
device(config)# access-list 25 permit any
device(config)# access-list 30 deny 10.157.25.0 0.0.0.255 log
device(config)# access-list 30 deny 10.157.26.0/24 log
device(config)# access-list 30 permit any
device(config)# snmp-server community public ro 25
device(config)# snmp-server community private rw 30
device(config)# write memory
```

The following example associates a view to the members of a community string.

```
device# configure terminal
device(config)# snmp-server community private rw view view1
```

The following example configures a read-only access and a read/write access for the same SNMP community. The output from the **show running-config** command shows that only one access type, the highest access level, is saved in the running configuration.

```
device# configure terminal
device(config)# snmp-server community private ro
device(config)# snmp-server community private rw
device(config)# exit
device# show running-config | inc snmp
snmp-server
snmp-server community private rw
```

#### History

| Release version | Command history                                                                        |
|-----------------|----------------------------------------------------------------------------------------|
| 5.9.00          | This command was modified to allow setting just one access type for an SNMP community. |

## snmp-server context

Creates SNMP context and maps the context name to the name of a VPN routing and forwarding (VRF) instance.

**Syntax** **snmp-server context** *context-name* **vrf** *vrf-name*

**no snmp-server-context** *context-name* **vrf** *vrf-name*

**Parameters** **context**

Enables the specification of a variable *context\_name* that can be passed in the SNMP PDU.

*context\_name*

SNMP context name.

**vrf**

Enables the specification of a variable *vrf\_name* that can be retrieved when an SNMP request is sent with the configured *context\_name*.

*vrf\_name*

VRF instance name.

**Modes** Global configuration mode

**Usage Guidelines** The context-to-VRF mapping is one-to-one and is applicable to all SNMP versions.

**Examples** The following **snmp-server context** command maps the context name "mycontext" to the VRF name "myvrf".

```
switch(config)# snmp-server context mycontext vrf myvrf
```

The following **snmp-server context** command deletes the SNMP context to VRF map.

```
switch(config)# no snmp-server context mycontext vrf myvrf
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |

## snmp-server enable mib

Enables MIB support for SNMP server.

**Syntax** **snmp-server enable mib** *snmp-community-mib*

**no snmp-server enable mib** *snmp-community-mib*

**Command Default** MIB support is disabled by default.

**Parameters** *snmp-community-mib*

Enables access for the SNMP community MIBs.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables access for SNMP-COMMUNITY-MIB.

**Examples** The following example enables the snmpCommunityTable MIB support.

```
device(config)# snmp-server enable mib snmp-community-mib
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |

## snmp-server enable traps

Configures error trap generation for IPsec and IKEv2.

**Syntax** **snmp-server enable traps [ ipsec ] [ ikev2 ]**

**no snmp-server enable traps [ ipsec ] [ ikev2 ]**

**Command Default** By default, IPsec and IKEv2 traps are enabled.

**Parameters** *ipsec*

Configures error trap generation for IPsec.

*ikev2*

Configures error trap generation for IKEv2.

**Modes** Privileged Exec mode

**Usage Guidelines** The **no** form of this command disables the generation of IPsec and IKEv2 error traps.

**Examples** The following example disables error trap generation for IPsec and IKEv2.

```
device# no snmp-server enable traps ipsec ikev2
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## snmp-server enable traps bum-rl-traps

Configures the SNMP rate-limiting traps for BUM traffic on SNMP servers.

**snmp-server enable traps bum-rl-traps**

**no snmp-server enable traps bum-rl-traps**

**Command Default** By default, SNMP rate-limiting traps for BUM traffic on SNMP servers are enabled.

### Usage Guidelines

**Examples** The following example shows how to disable SNMP rate-limiting traps for BUM traffic.

```
device# configure terminal
device(config)# no snmp-server enable traps bum-rl-traps
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00          | This command was introduced. |

## snmp-server host

Configures a trap receiver to ensure that all SNMP traps sent by the Brocade device go to the same SNMP trap receiver or set of receivers, typically one or more host devices on the network.

**Syntax** **snmp-server host** { *host-ipaddr* | **ipv6** *host-ipv6-addr* } [ **version** { **v1** | **v2c** } ] [ *community-string* [ **port** *port-num* ] ] ]

**no snmp-server host** { *host-ipaddr* | **ipv6** *host-ipv6-addr* } [ **version** { **v1** | **v2c** } ] [ *community-string* [ **port** *port-num* ] ] ]

**snmp-server group** { *host-ipaddr* | **ipv6** *host-ipv6-addr* } [ **version** **v3** { **auth** | **noauth** | **priv** } *name* [ **port** *port-num* ] ]

**no snmp-server group** { *host-ipaddr* | **ipv6** *host-ipv6-addr* } [ **version** **v3** { **auth** | **noauth** | **priv** } *name* [ **port** *port-num* ] ]

**Command Default** The SNMP trap receiver is not configured.

**Parameters** *host-ipaddr*

Specifies the IP address of the trap receiver.

**ipv6** *host-ipv6-addr*

Specifies the IPv6 address of the trap receiver.

**version**

Configures the SNMP version or security model.

**v1**

Specifies SNMP version 1.

**v2c**

Specifies SNMP version 2c.

*community-string*

Specifies an SNMP community string configured on the device.

**v3**

Specifies SNMP version 3.

**auth**

Specifies that only authenticated packets with no privacy are allowed to access the specified view. This parameter is available only for SNMPv3 user groups.

**noauth**

Specifies that no authentication and no privacy are required to access the specified view. This parameter is available only for SNMPv3 user groups.

**priv**

Specifies that authentication and privacy are required from the users to access the view. This parameter is available only for SNMPv3 user groups.

*name*

Specifies the SNMP security name or user.

**port** *port-num*

Configures the UDP port to be used by the trap receiver. The default port number is 162.

**Modes** Global configuration mode

**Usage Guidelines** The device sends all the SNMP traps to the specified hosts and includes the specified community string. Administrators can therefore filter for traps from a Brocade device based on IP address or community string. When you add a trap receiver, the software automatically encrypts the community

string you associate with the receiver when the string is displayed by the CLI or Web Management interface. The software does not encrypt the string in the SNMP traps sent to the receiver.

The SNMP community string configured can be a read-only string or a read-write string. The string is not used to authenticate access to the trap host but is instead a useful method for filtering traps on the host. For example, if you configure each of your Brocade devices that use the trap host to send a different community string, you can easily distinguish among the traps from different devices based on the community strings.

The Multiple SNMP Community Names feature introduced the ability to configure one default community string (where a community string is not mapped to any SNMP context) and one community string per SNMP context for a single trap host. One community name per line is allowed. For protocol-specific MIBS, Brocade devices send the trap originating from specific VRF instance and the corresponding community name mapped to the SNMP context associated with that VRF is sent in the trap. When the Brocade devices send the trap originating from a default VRF instance, the default community string is sent in the trap. Using the community string in the trap, administrators can easily distinguish among the traps originated from different VRF instances. If you enter the **show running-config** command it displays multiple **snmp-server host** command instances for each host; one community name per line.

Specifying the port allows you to configure several trap receivers in a system. With this parameter, a network management application can coexist in the same system. Devices can be configured to send copies of traps to more than one network management application.

The **no** form of the command removes the configured SNMP server host.

**Examples** The following example configures 10.10.10.1 as the trap receiver.

```
device(config)# snmp-server host 10.10.10.1 version v2c mypublic port 200
```

The following example configures 2002::2:2 as the trap receiver and specifies that only authenticated packets with no privacy are allowed to access the specified view.

```
device(config)# snmp-server host ipv6 2002::2:2 version v3 auth user-private port 110
```

The following example configures multiple SNMP community names for a single trap host.

```
device(config)# snmp-server host 192.168.2.1 version v1 user-community1
device(config)# snmp-server host 192.168.2.1 version v1 user-community2
device(config)# snmp-server host 192.168.2.1 version v1 user-community3
```

**History**

| Release version | Command history                                                                                           |
|-----------------|-----------------------------------------------------------------------------------------------------------|
| 5.9.00          | This command was modified to allow multiple SNMP community names to be configured for a single trap host. |

## snmp-server mib community-map

Maps an existing SNMP community string with an existing SNMP context.

**Syntax** **snmp-server mib community-map** *community\_name* **context** *context\_name*

**no snmp-server mib community-map** *community\_name* **context** *context\_name*

**Parameters** *community-map*

Maps SNMP community string to any routing instance specified in the variable *community-name*.

*community\_name*

The existing or already configured SNMP community string.

**context**

Enables the specification of a variable *context\_name* that can be passed in the SNMP PDU.

*community\_name*

The existing or already configured SNMP context name.

**Modes** Global configuration mode

**Usage Guidelines** The SNMP community and SNMP context must be configured before mapping.

**Examples** The following example enables the snmpCommunityTable MIB support.

```
device(config)# snmp-server mib community-map <community-name>
context <context-name>
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 05.9.00         | This command was introduced. |



## spanning-tree pvst-protect

Enables or disables Per VLAN Spanning Tree (PVST) protection for all global interfaces running xSTP.

**Syntax** **spanning-tree pvst-protect do-disable**

**spanning-tree pvst-protect re-enable** [ **ethernet slot/port** [ **to slot/port** ] ]

**no spanning-tree pvst-protect do-disable**

**no spanning-tree pvst-protect re-enable** [ **ethernet slot/port** [ **to slot/port** ] ]

**Command Default** By default, PVST protect configuration is independent of spanning tree global configuration.

**Parameters** **do-disable**

Disables the PVST protection globally on VLANs when xSTP is configured and also can coexist with per VLAN xSTP configuration.

**re-enable**

Re-enables the PVST protect disabled interfaces globally.

**ethernet slot/port to slot/port**

Specifies an Ethernet interface or a range of Ethernet interfaces on which PVST protection is re-enabled.

**Modes** Global configuration mode

**Usage Guidelines** PVST is a Cisco proprietary protocol that allows a Cisco device to have multiple spanning trees. The Cisco device can interoperate with spanning trees on other PVST devices but cannot interoperate with IEEE 802.1Q devices. An IEEE 802.1Q device has all its ports running a single spanning tree. PVST+ is an extension of PVST that allows a Cisco device to also interoperate with devices that are running a single spanning tree (IEEE 802.1Q).

Brocade supports PVST plus (PVST+) by allowing a Brocade device to run multiple spanning trees (MSTP) while also interoperating with IEEE 802.1Q devices. Ports automatically detect PVST+ BPDUs and enable support for the BPDUs once detected. The PVST+ support allows a Brocade device to interoperate with PVST spanning trees and the IEEE 802.1Q spanning tree at the same time.

The **no spanning-tree pvst-protect do-disable** command disables the PVST protect feature configuration globally, and enables all the ports which were disabled by this feature.

The **no spanning-tree pvst-protect re-enable** command reenables the PVST protect feature configuration globally, or for a specific or range of Ethernet interfaces and enables the specified ports.

---

### NOTE

PVST protect configuration is not applicable for an Inter-Chassis Link (ICL) port.

---

**Examples** The following example disables the PVST protect feature configuration globally.

```
device# configure terminal
device(config)# spanning-tree pvst-protect do-disable
```

The following example re-enables the PVST protect feature configuration on Ethernet interfaces 1/5 through 1/7

```
device# configure terminal
device(config)# spanning-tree pvst-protect re-enable ethernet 1/5 to 1/7
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.7.00          | This command was introduced. |

## state-name

Configures the state name where the Public Key Infrastructure (PKI) entity resides.

**Syntax** `state-name string`

`no state-name string`

**Command Default** No state is recorded, by default.

**Parameters** `string`

Specifies the name of the state for PKI entity.

**Modes** PKI entity configuration mode

**Examples** The following example configures California as the state where the PKI entity named as Brocade-entity resides.

```
device# configure terminal
device(config)# pki entity brocade-entity
device(config-pki-entity-brocade-entity)# state-name California
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

## static-lsp

Creates a new static label-switched path (LSP) at the transit router or enters into the mode of an existing static transit LSP to modify its parameters and enable or disable the static transit LSP.

- Syntax** **static-lsp transit** *name*
- no static-lsp transit** *name*
- Parameters** **transit** *name*
- Configures a new static LSP at a transit router. If the *name* is an existing static transit LSP name, it enters into the configuration mode for that static transit LSP.
- Modes** MPLS configuration mode
- Usage Guidelines** The LSP name must be unique within that router for static transit LSPs. Use the **no** option to delete the static LSP.
- Examples** The following example configures a static transit LSP named t1.

```
device# configure terminal
device(config)# router mpls
device(config-mpls)# static-lsp transit t1
device(config-mpls-static-transit-lsp-t1)# in-label 16
device(config-mpls-static-transit-lsp-t1)# next-hop 3.3.3.3
device(config-mpls-static-transit-lsp-t1)# out-label 17
device(config-mpls-static-transit-lsp-t1)# enable
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.5.00          | This command was introduced. |

# static-mac-address

Configures the static MAC address on the VPLS endpoints.

**static-mac-address** { *mac-addr* **ethernet** *slot/port* }

**no static-mac-address** { *mac-addr* **ethernet** *slot/port* }

|                   |                  |                                      |
|-------------------|------------------|--------------------------------------|
| <b>Parameters</b> | <i>mac_addr</i>  | Identifies the selected MAC address. |
|                   | <b>ethernet</b>  | Selects the Ethernet MAC address.    |
|                   | <i>slot/port</i> | Ethernet port of the VPLS endpoint.  |

**Usage Guidelines** Multicast, broadcast, and zero-MACs cannot be configured.

**Examples** The following example displays how to configure static MAC address on VPLS endpoints.

```
device(config)# router mpls
device(config-mpls)# vpls vpls-1 1
device(config-mpls-vpls-1)# vlan 900 inner-vlan 800
device(config-mpls-vpls-1-vlan-900)# static-mac-address 0000.1111.3333 ethernet 1/20
```

The following example displays removing a configured static MAC from a tagged/untagged endpoint.

```
device# configure terminal
device(config)# router mpls
device(config-mpls)# vpls vpls-1 1
device(config-mpls-vpls-1)# vlan 900
device(config-mpls-vpls-1-vlan-900)# no static-mac-address 0000.1111.2222 ethernet
1/23
```

## History

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.7.00          | This command is introduced. |

# statistics-load-interval

Configures the load interval parameter for calculating the bit rate and packet count for the access-list accounting statistics.

**Syntax** `statistics-load-interval { seconds | accumulated }`

`no statistics-load-interval { seconds | accumulated }`

**Parameters** *seconds*

Specifies the load interval values. Permitted values are **1**, **60**, or **300**.

**accumulated**

Displays accumulated ACL statistics packets and bit rate counts.

**Modes** ACL-policy sub-configuration mode

**Usage Guidelines** The **no** form of the command removes the configuration of the load interval parameters for calculating the bit rate and packet count for the access-list accounting statistics.

Use the configured load interval value to display the bit rate and packet rate statistics. If the load interval is not configured, statistics of all three intervals *1s/60s/300s* and accumulated statistics display.

This configuration is stored in the configuration file.

---

**NOTE**

This configuration applies only to policy-based routing ACLs.

---

**Examples** The following example uses the load interval option to choose any one of the intervals for statistics display.

```
device(config)# acl-policy
device(config-acl-policy)# statistics-load-interval 60
device(config-acl-policy)# show access-list accounting brief policy-based-routing
Intf      ACL      BitRate      HitRate
3/1       100      2697753600   2634525(1m)
3/3       101      5210585952   4934267(1m)
3/3       102      0             0(1m)
```

The following example shows uses the non-zero statistics option.

```
device(config)# acl-policy
device(config-acl-policy)#
device(config-acl-policy)# show access-list accounting brief policy-based-routing
omit-zero
Intf      ACL      BitRate      HitRate
3/1       100      2697753600   2634525(1m)
3/3       101      5210585952   4934267(1m)
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.8.00          | This command was introduced. |

# subject-alt-name

Configures the alternative subject name for the Public Key Infrastructure (PKI) entity.

**Syntax** **subject-alt-name** *string*  
**no subject-alt-name** *string*

**Parameters** *string*  
 Specifies the alternate name of the subject for the PKI entity.

**Modes** PKI entity configuration mode

**Usage Guidelines** If the IKE peer uses an ID other than the distinguished name (DN), then that should be mentioned in the **subject-alt-name**. If the certificate does not have subject-alt-name then use DN for the IKE ID.

**Examples** The following example configures the alternate name of the subject for the PKI entity.

```
device(config)# pki entity brocade
device(config-pki-entity-brocade)# subject-alt-name red
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

## summary-address (OSPFv3)

Configures route summarization for redistributed routes for an Autonomous System Boundary Router (ASBR).

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>summary-address</b> <i>IPv6-addr/mask</i><br><br><b>no summary-address</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Command Default</b>  | Summary addresses are not configured.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Parameters</b>       | <i>A:B:C:D/LEN</i><br><br>IPv6 address and mask for the summary route representing all the redistributed routes in dotted decimal format.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Modes</b>            | OSPFv3 router configuration mode<br>OSPFv3 VRF router configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Usage Guidelines</b> | <p>Use this command to configure an ASBR to advertise one external route as an aggregate for all redistributed routes that are covered by a specified IPv6 address range. When you configure an address range, the range takes effect immediately. All the imported routes are summarized according to the configured address range. Imported routes that have already been advertised and that fall within the range are flushed out of the AS and a single route corresponding to the range is advertised.</p> <p>If a route that falls within a configured address range is imported by the device, no action is taken if the device has already advertised the aggregate route; otherwise the device advertises the aggregate route. If an imported route that falls within a configured address range is removed by the device, no action is taken if there are other imported routes that fall within the same address range; otherwise the aggregate route is flushed.</p> <p>You can configure up to 32 address ranges.</p> <p>The device sets the forwarding address of the aggregate route to 0 and sets the tag to 0. If you delete an address range, the advertised aggregate route is flushed and all imported routes that fall within the range are advertised individually. If an external link-state-database-overflow condition occurs, all aggregate routes and other external routes are flushed out of the AS. When the device exits the external LSDB overflow condition, all the imported routes are summarized according to the configured address ranges.</p> <p>If you use redistribution filters in addition to address ranges, the Brocade device applies the redistribution filters to routes first, then applies them to the address ranges.</p> <p>If you disable redistribution, all the aggregate routes are flushed, along with other imported routes.</p> <p>This option affects only imported, type 5 external routes. A single type 5 LSA is generated and flooded throughout the AS for multiple external routes.</p> |
| <b>Examples</b>         | <p>This example configures a summary address of 2001:db8::/24 for routes redistributed into OSPFv3.</p> <pre>device# configure terminal device(config)# ipv6 router ospf device(config-ospf6-router)# summary-address 2001:db8::/24</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

---

### NOTE

In this example, the summary prefix 2001:db8::/24 includes addresses 2001:db8::/1 through 2001:db8::/24. Only the address 2001:db8::/24 is advertised in an external link-state advertisement.

---



## suppress-acl-seq

Hides or suppresses the display and storage of sequence numbers for ACL entries.

**Syntax** **suppress-acl-seq**

**no suppress-acl-seq**

**Modes** acl-policy configuration mode

**Usage Guidelines** Use this command if you need to downgrade a device to an earlier version of software that does not support ACL entry sequence numbers, you should configure **suppress-acl-seq** prior to the downgrade. Otherwise, ACL configurations created with the **suppress-acl-seq** parameter will result in an error on previous releases.

The **no** version of this command resets the configuration to display sequence numbers.

**Examples** The following example suppresses ACL entry sequence numbering:

```
device# configure terminal
device(config)# acl-policy
device(config-acl-policy)# suppress-acl-seq
```

### History

| Release | Command History              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

## sysmon fe link auto-tune

Enables auto tuning on the fabric element (FE).

**Syntax** **sysmon fe link auto-tune**

**no sysmon fe link auto-tune**

**Command Default** Auto tuning on the FE is enabled by default.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables auto-tuning on the FE.

**Examples** The following example disables auto-tuning on the FE.

```
device(config)# no sysmon fe link auto-tune
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.6.00         | This command was introduced. |

## sysmon lp-high-cpu enable

Configures high cpu-usage and reporting on interface modules.

**Syntax** `sysmon lp-high-cpu enable [ all | slot-number ]`

`no sysmon lp-high-cpu enable [ all | slot-number ]`

**Parameters** **all**

Specifies CPUs on all slots to be monitored.

**slot-number**

Specifies the slot number for the CPU to be monitored.

**Modes** Privileged EXEC configuration mode.

**Usage Guidelines** Use this command to set up the monitoring on one or all LP CPUs.

The **no** form of this command disables the LP CPU high-usage monitoring.

**Examples** The following example enables monitoring on all CPUs.

```
device(config)# sysmon lp-high-cpu enable all
```

The following example enables monitoring on the CPU in slot 7.

```
device(config)# sysmon lp-high-cpu enable 7
```

**History**

| Release | Command History              |
|---------|------------------------------|
| 05.9.00 | This command was introduced. |

## sysmon lp-high-cpu threshold

Configures high cpu-usage and reporting on interface modules.

**Syntax** `sysmon lp-high-cpu threshold decimal-percent-number`

`no sysmon lp-high-cpu threshold`

**Parameters** `decimal-percent-number`

Specifies the usage threshold for all CPUs to be monitored. Acceptable range of values is from 50 to 100 with 80 as the default value.

**Modes** Privileged EXEC configuration mode.

**Usage Guidelines** Use this command to set up the usage threshold for collecting data on the monitored LP CPUs. The default CPU threshold is 80% unless explicitly specified. The set threshold applies to all LP(s).

The **no** form of this command resets the usage threshold to 80% for all CPUs.

**Examples** The following example sets the usage threshold to 90% for all monitored CPUs.

```
device(config)# sysmon lp-high-cpu threshold 90
```

The following resets the usage threshold to 80% for all monitored CPUs.

```
device(config)# no sysmon lp-high-cpu threshold
```

### History

| Release | Command History              |
|---------|------------------------------|
| 05.9.00 | This command was introduced. |

## sysmon np memory-errors

Configures memory error monitoring and reporting on interface modules.

|                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <pre> <b>sysmon np memory-errors</b> [ <b>action</b> { <b>none</b>   <b>syslog</b>   <b>syslog-and-trap</b>   <b>trap</b> } ] <b>sysmon np memory-errors</b> [ <b>polling-period</b> <i>secs</i> ] <b>sysmon np memory-errors</b> [ <b>schedule</b> { <b>after</b> <i>dd:hh:mm</i>   <b>at</b> <i>hh:mm:ss mm-dd-yy</i>   <b>now</b> } <i>runs</i> ] <b>sysmon np memory-errors</b> [ <b>slot</b> { <b>all</b>   <i>slot</i> } ]  <b>no sysmon np memory-errors</b> [ <b>action</b> { <b>none</b>   <b>syslog</b>   <b>syslog-and-trap</b>   <b>trap</b> } ] <b>no sysmon np memory-errors</b> [ <b>polling-period</b> <i>secs</i> ] <b>no sysmon np memory-errors</b> [ <b>schedule</b> { <b>after</b> <i>dd:hh:mm</i>   <b>at</b> <i>hh:mm:ss mm-dd-yy</i>   <b>now</b> } <i>runs</i> ] <b>no sysmon np memory-errors</b> [ <b>slot</b> { <b>all</b>   <i>slot</i> } ] </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Parameters</b> | <p><b>action</b></p> <p>Specifies the action taken when NP memory errors are detected. The default action is syslog-and-trap.</p> <p><b>none</b></p> <p>No action; reporting of errors is disabled. In the no form of the command, specifying the action as none restores the default action (syslog-and-trap).</p> <p><b>syslog</b></p> <p>Generates a syslog message.</p> <p><b>syslog-and-trap</b></p> <p>Generates a syslog message and a SNMP trap.</p> <p><b>trap</b></p> <p>Sends a SNMP trap.</p> <p><b>polling-period</b> <i>secs</i></p> <p>Specifies the frequency of polling for NP memory errors. The range is from 1 through 65535. The default value is 60 seconds.</p> <p><b>schedule</b></p> <p>Configures the test scheduling.</p> <p><b>after</b> <i>dd:hh:mm</i></p> <p>Specifies that the test is run after the specified amount of time.</p> <p><b>at</b> <i>hh:mm:ss mm-dd-yy</i></p> <p>Specifies that the test is run at the specified time and date.</p> <p><b>now</b></p> <p>Specifies that the test is run immediately. This is defined as on-demand testing.</p> <p><i>runs</i></p> <p>Specifies the number of test runs.</p> <p><b>slot</b></p> <p>Specifies the slots on which the test is run.</p> <p><b>all</b></p> <p>Specifies that the test is run on all slots.</p> <p><i>slot</i></p> |

Specifies the slot number on which the test is to be run. You can specify up to 8 slot numbers.

**Modes** Global configuration mode

**Usage Guidelines** The **action** parameter controls the generation of syslog messages or SNMP traps. These messages cannot be controlled by the **no snmp-server enable traps** command or the **no logging enable** command. If the **action** option is configured as **syslog** followed by a configuration of the **trap** action, the action becomes **syslog-and-trap**.

The **polling-period** parameter determines the interval between checks for NP memory errors. Reporting may not happen within the polling interval; it may be delayed by factors such as a high CPU load on either the interface or management modules, low memory, or other factors.

Memory errors are detected on the interface module. Errors may not be reported if there is a communication problem between the management module and the interface module.

The **no** form of this command disables memory error monitoring on interface modules.

**Examples** The following example specifies polling for NP memory errors at 10 second intervals.

```
device# configure terminal
device(config)# sysmon np memory-errors polling-period 10
```

The following example disables reporting of NP memory errors.

```
device# configure terminal
device(config)# sysmon np memory-errors action none
```

The following example disables monitoring of memory errors on interface modules.

```
device# configure terminal
device(config)# no sysmon np memory-errors
```

The **no** form of the command specifying a **polling-period** value restores the default polling interval. For example, the following example restores the polling interval to the default value of 60 seconds.

```
device# configure terminal
device(config)# no sysmon np memory-errors polling-period 1000
```

The following example removes the **syslog** action.

```
device# configure terminal
device(config)# no sysmon np memory-errors action syslog
```

The following example restores the default action of **syslog-and-trap**. The **no** form of the command specifying the **action none** parameters restores the default action.

```
device# configure terminal
device(config)# no sysmon np memory-errors action none
```

**History**

| Release | Command History              |
|---------|------------------------------|
| 5.6.00  | This command was introduced. |

## sysmon port port-crc-test

Enables the port CRC error monitoring test.

**Syntax** `sysmon port port-crc-test [ action {none | port-disable | syslog } ]`  
`sysmon port port-crc-test [ counter port-crc-counter less-than crc-count ]`  
`sysmon port port-crc-test [ log-backoff num ]`  
`sysmon port port-crc-test [ polling-period seconds ]`  
`sysmon port port-crc-test [ schedule { afterdd:hh:mm runs | at hh:mm:ss mm-dd-yy runs | now } ]`  
`sysmon port port-crc-test [ slot { all | slot } ]`  
`sysmon port port-crc-test [ threshold num-failures num-polls ]`  
`no sysmon port port-crc-test [ action {none | port-disable | syslog } ]`  
`no sysmon port port-crc-test [ counter port-crc-counter less-than crc-count ]`  
`no sysmon port port-crc-test [ log-backoff num ]`  
`no sysmon port port-crc-test [ polling-period seconds ]`  
`no sysmon port port-crc-test [ schedule { afterdd:hh:mm runs | at hh:mm:ss mm-dd-yy runs | now } ]`  
`no sysmon port port-crc-test [ slot { all | slot } ]`  
`no sysmon port port-crc-test [ threshold num-failures num-polls ]`

**Parameters**

**action**  
 Specifies a sysmon action configuration.

**none**  
 No action.

**port-disable**  
 Disable port.

**syslog**  
 Generates a syslog message.

**counter port-crc-counter less-than *crc-count***  
 Specifies the port CRC error count limit for the configured polling period. The range of values is 0 through 65535. The default value is 20.

**polling-period *secs***  
 Specifies the polling period in seconds. The range of values is 0 through 65535. The default value is 60 seconds.

**schedule**  
 Specifies the schedule of the test.

**after *dd:hh:mm runs***  
 Specifies that the test is run after the specified amount of time and for the number of test runs.

**at *hh:mm:ss mm-dd-yy runs***

**now** Specifies that the test is run at the specified time and date and for the number of test runs.

**slot** Specifies that the test is run immediately. This is defined as on-demand testing.

**all** Specifies the slots on which the test is run.

**slot** Specifies that the test is run on all slots.

**threshold** Specifies the slot number on which the test is to be run. You can specify up to 8 slot numbers.

**num-failures** Specifies the threshold of the diagnostic test.

**num-polls** Specifies the number of failed test runs. The range of values is 1 through 31.

Specifies the number of polls (tests). The range of values is 2 through 31.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of this command disables the port CRC error monitoring test.

**Examples** The following example disables the port CRC error monitoring test.

```
device(config)# no sysmon port port-crc-test
```

The following example sets the diagnostic action to disable the port when the port CRC error limit crosses the configured threshold.

```
device(config)# sysmon port port-crc-test action port-disable
```

The following example configures the port CRC error counter limit to 20.

```
device(config)# sysmon port port-crc-test counter port-crc-counter less-than 20
```

**History**

| Release | Command History              |
|---------|------------------------------|
| 5.5.00  | This command was introduced. |



## sysmon sfm walk auto

Enables an option that automatically triggers a high-speed Switch Fabric Module (hSFM) walk automatically upon reaching a configured threshold.

**Syntax** **sysmon sfm walk auto**

**no sysmon sfm walk auto**

**Command Default** The command is disabled by default.

**Modes** Global configuration mode

### Usage Guidelines

---

#### NOTE

Auto-tuning and hSFM auto-walk cannot operate at the same time. To avoid conflict, configure auto-tuning and hSFM auto-walk to trigger consecutively. Whichever triggers first runs, after which the other one runs.

---

The **no** form of this command disables the automatic triggering of **sysmon sfm walk auto**.

**Examples** The following example enables **sysmon sfm walk auto**.

```
device# configure terminal
device(config)# sysmon sfm walk auto
```

### History

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.7.00b         | This command is introduced. |

## sysmon sfm walk polling-period

Configuring a polling period for re-assembly errors located on a high-speed Switch Fabric Module (hSFM).

- Syntax** `sysmon sfm walk polling-period value`
- Command Default** The command is disabled by default.
- Parameters** *value*  
Sets the polling period in a range from 1 to 600 seconds. The default setting is 30 seconds.
- Modes** Global configuration mode
- Usage Guidelines** Use this command to set the interval between polling periods for re-assembly errors.
- Examples** The following example configures the sfm walk polling-period to be 50 seconds.

```
device# configure terminal
device(config)# sysmon sfm walk polling-period 50
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00b         | This command was introduced. |

# sysmon sfm walk redundancy-check

Setting an option to automatically trigger an SFM redundancy check during a high-speed Switch Fabric Module (hSFM) walk.

**Syntax** **sysmon sfm walk redundancy-check**

**no sysmon sfm walk redundancy-check**

**Command Default** The redundancy check option is enabled.

**Modes** Global configuration mode

**Usage Guidelines** For an SFM walk to begin, a redundant SFM is required. The no form of this command will trigger auto hsfm walk if N+1 SFMs are unavailable.

**Examples** The following example enables a **sysmon sfm walk redundancy-check**.

```
device# configure terminal
device(config)# sysmon sfm walk redundancy-check
```

## History

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.7.00b         | This command is introduced. |

## sysmon sfm walk start

Enables a manual high-speed Switch Fabric Module (hSFM) walk.

**Syntax** `sysmon sfm walk start`

**Command Default** By default, sysmon sfm walks are automatically triggered.

**Modes** Global configuration mode.

**Usage Guidelines** Use this command to manually start a sysmon sfm walk.

---

### NOTE

Auto-tuning and hSFM walk cannot operate at the same time. To avoid conflict, auto-tuning and hSFM walk will be performed consecutively. Whichever is triggered first will run and then the other will be performed.

---

**Examples** The following example manually enables sysmon sfm walk.

```
device# configure terminal
device(config)# sysmon sfm walk start
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00b         | This command was introduced. |

# sysmon sfm walk status

Displays the status of a high-speed Switch Fabric Module (hSFM) walk.

**Syntax** `sysmon sfm walk status`

**Command Default** This command will show the status of the current SFM walk. If the **auto sfm walk** is disabled, the status of the last walk will be displayed.

**Modes** Global configuration mode.

**Usage Guidelines** The command is used to display the current status of an active sfm walk or sfm auto-walk.

**Examples** The following example enables **sysmon sfm walk status**.

```
device# configure terminal
device(config)# sysmon sfm walk status

=====
SFM Walk status           : Isolated an SFM
Number of SFM walk done   : 1
Auto walk                 : Enabled
Manual walk               : Not started
Autotune in progress      : 0
Autotunes on isolated SFM : 0
AutoWalk timers          :
    Threshold for re-assembly 1, polling period 30, Counter reset time 10000
Redundancy check         : Enable
AutoWalk result          :
    Isolated SFM 3, Current SFM 3 (SFM range (1-4), FE (1-3))
Re-assembly error count 0, MCAST FID updates 0
Reachability register (0x461) dump :
SFM1/FE1: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM1/FE2: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM1/FE3: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM2/FE1: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM2/FE2: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM2/FE3: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM3/FE1: val=0x01f3f000 : 00000001-11110011-11110000-00000000b [Non-reachable,
autotune 0]
SFM3/FE2: val=0x01f3f000 : 00000001-11110011-11110000-00000000b [Non-reachable,
autotune 0]
SFM3/FE3: val=0x01f3f000 : 00000001-11110011-11110000-00000000b [Non-reachable,
autotune 0]
SFM4/FE1: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM4/FE2: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
SFM4/FE3: val=0x01f3f009 : 00000001-11110011-11110000-00001001b [Reachable, autotune
0]
=====
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.7.00b        | This command was introduced. |

## sysmon sfm walk stop

Stops any currently running high-speed Switch Fabric Module (hSFM) walk.

**Syntax** `sysmon sfm walk stop`

**Command Default** Existing fsm walks run until completed.

**Modes** Global configuration mode

**Usage Guidelines** This command is used to stop a currently running walk or revert an already completed walk. For example, if an SFM walk is completed and an SFM is isolated, **sysmon sfm walk stop** will re-enable the isolated SFM. This command is effective on both manual and auto SFM walks.

**Examples** The following example stops an active sysmon sfm walk.

```
device# configure terminal
device(config)# sysmon sfm walk stop
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00b         | This command was introduced. |

# sysmon sfm walk threshold

Configures the threshold value for a minimum re-assembly count to isolate an SFM during an SFM walk.

**Syntax** `sysmon sfm walk threshold value`

`no sysmon sfm walk threshold`

**Command Default** The default sysmon sfm walk threshold value is 1.

**Parameters** *value*

Configures the minimum threshold value for re-assembly count range in a range from 1 to 65535. The default setting is 1.

**Modes** Global configuration mode

**Usage Guidelines** The `no` form of this command will reset the threshold value to the default.

**Examples** The following example configures the `sysmon sfm walk threshold` to 5.

```
device# configure terminal
device(config)# sysmon sfm walk threshold 5
```

The following is an example of the syslog showing the resulting actions when re-assembly errors cross the configured threshold value of 5.

```
SYSLOG: <9>Oct 14 00:41:18 System: Health Monitoring: TM Egress data errors detected
on LP 15/TM 1
SYSLOG: <14>Oct 14 00:41:18 System: SFM-WALK: Auto SFM walk started
SYSLOG: <14>Oct 14 00:41:18 System: SFM-WALK: Disabling SFM #1
SYSLOG: <9>Oct 14 00:41:32 System: Health Monitoring detects an issue on egress LP
3/TM 1
SYSLOG: <14>Oct 14 00:41:32 System: SFM-WALK: Auto SFM walk started
SYSLOG: <14>Oct 14 00:41:32 System: SFM-WALK: SFM walk in progress
SYSLOG: <9>Oct 14 00:41:46 System: Health Monitoring detects an issue on egress LP
1/TM 1
SYSLOG: <14>Oct 14 00:41:46 System: SFM-WALK: Auto SFM walk started
SYSLOG: <14>Oct 14 00:41:46 System: SFM-WALK: SFM walk in progress
SYSLOG: <9>Oct 14 00:41:48 System: Health Monitoring detects an issue on egress LP
2/TM 2
SYSLOG: <14>Oct 14 00:41:48 System: SFM-WALK: Auto SFM walk started
SYSLOG: <14>Oct 14 00:41:48 System: SFM-WALK: SFM walk in progress
SYSLOG: <14>Oct 14 00:42:01 System: SFM-WALK: Re-assembly errors (125) more than
threshold (5). Move to next SFM #2.
SYSLOG: <14>Oct 14 00:42:42 System: SFM-WALK: Re-assembly errors (126) more than
threshold (5). Move to next SFM #3.
SYSLOG: <14>Oct 14 00:43:22 System: SFM-WALK: Re-assembly errors (0) less than
threshold (5). Isolated SFM #3.
SYSLOG: <14>Oct 14 00:43:22 System: SFM-WALK: SFM walk completed. Faulted SFM #3 and
removed from service.
```

## History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00b         | This command was introduced. |

## sysmon tm link auto-tune

Enables auto tuning on the traffic manager (TM).

**Syntax** **sysmon tm link auto-tune**

**no sysmon tm link auto-tune**

**Command Default** Auto tuning on the TM is enabled by default.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command disables auto-tuning on the TM.

**Examples** The following example disables auto-tuning on the TM.

```
device(config)# no sysmon tm link auto-tune
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.6.00         | This command was introduced. |



## system np control-ram-threshold

Configures the CSRAM error reporting threshold parameter for low level memory events.

**Syntax** **system np control-ram-threshold** *threshold*  
**no system np control-ram-threshold** *threshold*

**Command Default** The default threshold value is 10.

**Parameters** **threshold**  
 Specifies the configurable threshold range when low level memory events are exceeded. The decimal range is from 0 - 120 events. The default value is 10.

**Modes** Global configuration mode

**Usage Guidelines** Use this command to configure the CSRAM threshold parameter when monitoring low level memory events occurring with the internal data path of the network processor. This command is enabled by default. Use the **no** form of the command to reset the threshold value to default. Use the command to disable the monitoring of low level memory events. A syslog message and a trap is generated when the CSRAM error events recorded in the rolling window exceeds the configured threshold parameter for the specified port range.

---

### NOTE

Configuring the CSRAM error reporting threshold parameter is supported only on the Brocade NetIron CER Series and the Brocade NetIron CES Series platforms.

---

**Examples** The following example configures the CSRAM error reporting threshold parameter to 20 events.

```
device# configure terminal
device(config)#system np control-ram-threshold 20
```

Use the **show run** command to display the CSRAM error reporting threshold parameter to 20 events.

```
device(config)#show run
!
ver V5.7.0Txxx
!
!
no spanning-tree
!
!
vlan 1 name DEFAULT-VLAN
!
!
!
system np control-ram-threshold 20
!
!
!
!
!
!
end
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 05.7.00         | This command was introduced. |

## system np lpm-ram-threshold

Configures the LPM memory error reporting threshold parameter for low level memory events.

**Syntax** `system np lpm-ram-threshold threshold`

`no system np lpm-ram-threshold threshold`

**Command Default** Configuring the LPM memory error reporting threshold parameters is enabled by default.

**Parameters** *threshold*

Specifies the configurable threshold range when low level memory events are exceeded. The decimal range is from 0 - 120 events. The default value is 10.

**Modes** Global configuration mode

**Usage Guidelines** Use this command to configure the LPM memory threshold parameter when monitoring low level memory events occurring with the internal data path of the network processor. The command is enabled by default. Use the **no** form of the command to reset the threshold value to default. Use this command to disable the monitoring of low level memory events. A syslog message and a trap is generated when the LPM memory error events recorded in the rolling window exceeds the configured threshold parameter for the specified port range.

---

### NOTE

Configuring the LPM memory error reporting threshold parameter is supported only on the Brocade NetIron CER Series and the Brocade NetIron CES Series platforms.

---

**Examples** The following example configures the LPM memory error reporting threshold parameter to 20 events.

```
device# configure terminal
device(config)# system np lpm-ram-threshold 20
```



# system-init

Sets system initialization value. A reload is required before this command takes effect.

**Syntax**

```

system-init block-g1-sfm
system-init fabric-data-mode { force-normal | force-turbo }
system-init fabric-failure-detection
system-init fe-access-recovery-disable
system-init max-tm-queues num
system-init mlxe32-24x10g-enable [ max-tm-queue-4 ]
system-init tm-credit-size { credit_1024b | credit_256b }
no system-init block-g1-sfm
no system-init fabric-data-mode { force-normal | force-turbo }
no system-init fabric-failure-detection
no system-init fe-access-recovery-disable
no system-init max-tm-queues num
no system-init mlxe32-24x10g-enable [ max-tm-queue-4 ]
no system-init tm-credit-size { credit_1024b | credit_256b }

```

**Parameters**

**block-g1-sfm**  
Configures the system to block the g1 switch fabric module.

**fabric-data-mode**  
Configures the fabric data mode.

**force-normal**  
Forces the fabric to use normal data mode.

**force-turbo**  
Forces the fabric to use turbo data mode.

**fabric-failure-detection**  
Configures the system to automatically detect and shutdown the failure fabric.

**fe-access-recovery-disable**  
Disables a RAS feature that will power-cycle switch fabric module if SW cannot access fabric element.

**max-tm-queues num**  
Configures the maximum number of queues in the traffic manager to 4.

**mlxe32-24x10g-enable**  
Configures the system to accept 24x10G module.

**max-tm-queue-4**  
Configures the 4-priority mode to allow the coexistence of 24x10G and 2x10, 4x10, and 20x1 modules.

**tm-credit-size**

Configures the traffic manager credit size.

**credit\_1024b**

Specifies a credit size of 1024 bytes.

**credit\_256b**

Specifies a credit size of 256 bytes.

**Modes** Global configuration mode

**Usage Guidelines** When using the **fe-access-recovery-disable** option, note that the system does periodic monitoring of FE access and keeps a log for this by code monitoring fabric links and kicks off when number of links down exceeds defined threshold for traffic. However if failure detection configuration is enabled, you need to use these commands for recovery.

**Examples**

```
device# configure terminal
device(config)#system-init fe-access-recovery-disable
device(config)#exit
device# reload
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.7.00a         | This command was introduced. |

## system-max ecmp-pram-block-size

Configures the maximum parameter random-access memory (PRAM) block allocation for Equal-Cost MultiPath (ECMP) routes.

**Syntax** `system-max ecmp-pram-block-size num`

`no system-max ecmp-pram-block-size num`

**Parameters** `num`

Specifies the maximum PRAM block-size value. Valid values are 8, 16, and 32 (default is 32).

**Modes** Global configuration mode

**Usage Guidelines** The control plane (through the IP load-sharing command) supports up to 32 next hops per route. The actual number of next hops which are programmed in hardware is controlled by this command. When configuring the command to a value lesser than the value configured for IP load-sharing or IPv6 load-sharing, a warning message displays and the value is accepted. When configuring IP load-sharing or IPv6 load-sharing to a value greater than that configured for the command, a warning message displays and the value is accepted.

This command is not supported on Brocade NetIron CER Series and Brocade NetIron CES Series devices.

---

### NOTE

Using this command requires a system restart in order for the new setting to take effect.

---

**Examples** The following example sets the maximum PRAM block-size value to 16.

```
device# configure terminal
device(config)# system-max ecmp-pram-block-size 16
Reload required. Please write memory and then reload or power cycle the system.
Failure to reload could cause system instability on failover.
Newly configured system-max will not take effect during hitless-reload.
```

### History

| Release | Command history              |
|---------|------------------------------|
| 5.5.00  | This command was introduced. |

## system-max ip-arp

Sets the ARP scaling number.

| <b>Syntax</b>           | <b>system-max ip-arp</b> <i>num</i>                                                                                                                                                                                                                                                                                                                                             |                 |                 |        |                                                            |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-----------------|--------|------------------------------------------------------------|
| <b>Parameters</b>       | <i>num</i><br>Value range is 2048 - 131072. The default value is 8192.                                                                                                                                                                                                                                                                                                          |                 |                 |        |                                                            |
| <b>Modes</b>            | Global configuration mode                                                                                                                                                                                                                                                                                                                                                       |                 |                 |        |                                                            |
| <b>Usage Guidelines</b> | Use this command to set the maximum number of ARP entries. This command is applicable to the Brocade NetIron MLX Series and Brocade NetIron XMR Series only.<br><br>Requires a reload. Failure to reload causes system instability on failover. A newly configured <b>system-max</b> command does not take effect during a hitless-reload.                                      |                 |                 |        |                                                            |
| <b>Examples</b>         | The following example sets the maximum number of ARP entries at 3005.<br><br><pre>device# configure terminal device(config)# system-max ip-arp 3005 Reload required. Please write memory and then reload or power cycle the system. Failure to reload could cause system instability on failover. Newly configured system-max will not take effect during hitless-reload.</pre> |                 |                 |        |                                                            |
| <b>History</b>          | <table border="1"> <thead> <tr> <th>Release version</th> <th>Command history</th> </tr> </thead> <tbody> <tr> <td>5.8.00</td> <td>This command was modified to scale up to 128K ARP entries.</td> </tr> </tbody> </table>                                                                                                                                                       | Release version | Command history | 5.8.00 | This command was modified to scale up to 128K ARP entries. |
| Release version         | Command history                                                                                                                                                                                                                                                                                                                                                                 |                 |                 |        |                                                            |
| 5.8.00                  | This command was modified to scale up to 128K ARP entries.                                                                                                                                                                                                                                                                                                                      |                 |                 |        |                                                            |



## system-max ipv6-receive-cam

Configures the number of IPv6 rACL entries in CAM. The **no** form of this command removes the configured limit and restores the default value.

**Syntax** `system-max ipv6-receive-cam num`

**no system-max ipv6-receive-cam num**

**Parameters** *num*

Configures the number of IPv6 rACL entries in CAM. The valid range is from 0 through 8192. The default value is 0.

**Modes** Global configuration mode

**Usage Guidelines** This command is applicable to the Brocade NetIron MLX Series and Brocade NetIron XMR Series only. Requires a reload. Failure to reload causes system instability on failover. A newly configured **system-max** command does not take effect during a hitless-reload.

**Examples** The following example sets the number of IPv6 rACL entries in CAM to 4096.

```
device# configure terminal
device(config)# system-max ipv6-receive-cam 4096
Reload required. Please write memory and then reload or power cycle the system.
Failure to reload could cause system instability on failover.
Newly configured system-max will not take effect during hitless-reload.
```

**History**

| Release version | Command History              |
|-----------------|------------------------------|
| 5.6.00          | This command was introduced. |

## system-max ipv6-vrf-route

Configures the maximum number of IPv6 routes that can be created per VRF instance.

**Syntax** `system-max ipv6-vrf-route num`

`no system-max ipv6-vrf-route num`

**Command Default** By default, the maximum number of IPv6 routes per VRF instance is not configured.

**Parameters** *num*

The number of IPv6 routes that can be created per VRF instance. Valid IPv6 route values are 1024 through 131072. The default value is 8192.

**Modes** Global configuration mode.

**Usage Guidelines** This command is applicable to the Brocade NetIron MLX Series and Brocade NetIron XMR Series only. Requires a reload. Failure to reload causes system instability on failover. A newly configured **system-max** command does not take effect during a hitless-reload. Use the **no** form of the command to reset the maximum number of IPv6 routes that was configured for a VRF instance.

**Examples** The following example configures 4000 IPv6 routes per VRF instance.

```
device# configure terminal
device(config)# system-max ipv6-vrf-route 4000
```

**History**

| Release version | Command history            |
|-----------------|----------------------------|
| 5.8.00          | This command was modified. |

## system-max ip-vrf-route

Configures the maximum number of IPv4 routes that can be created per VRF instance.

**Syntax** `system-max ip-vrf-route num`

`no system-max ip-vrf-route num`

**Command Default** By default, the maximum number of IPv4 routes per VRF instance are not configured.

**Parameters** *num*

The number of IPv4 routes that can be created per VRF instance. Valid IPv4 route values are 128 through 524288. The default value is 1024.

**Modes** Global configuration mode.

**Usage Guidelines** This command is applicable to the Brocade NetIron MLX Series and Brocade NetIron XMR Series only. Requires a reload. Failure to reload causes system instability on failover. A newly configured **system-max** command does not take effect during a hitless-reload. Use the **no** form of the command to reset the maximum number of IPv4 routes that was configured for a VRF instance.

**Examples** The following example configures 200 IPv4 routes per VRF instance.

```
device# configure terminal
device(config)# system-max ip-vrf-route 200
```

**History**

| Release version | Command history            |
|-----------------|----------------------------|
| 5.8.00          | This command was modified. |

## system-max rstp

Defines the maximum number of Rapid Spanning Tree Protocol (RSTP) instances that can be configured on the Brocade NetIron XMR and MLX Series devices.

|                         |                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>system-max rstp</b> <i>number-of-instances</i><br><b>no system-max rstp</b> <i>number-of-instances</i>                                                                                                                                                                                                                                               |
| <b>Parameters</b>       | <i>number-of-instances</i><br>Specifies the maximum number of RSTP instances that can be configured on a Brocade device. The valid number of instances are 1 through 256. The default value is 32.                                                                                                                                                      |
| <b>Modes</b>            | Global configuration mode                                                                                                                                                                                                                                                                                                                               |
| <b>Usage Guidelines</b> | This command is applicable to the Brocade NetIron MLX Series and Brocade NetIron XMR Series only.<br>Requires a reload. Failure to reload causes system instability on failover. A newly configured <b>system-max</b> command does not take effect during a hitless-reload.<br>The <b>no</b> form of the command removes the configured RSTP instances. |

---

### NOTE

Before you downgrade from Brocade NetIron Release 5.9 to a lower release and restart the device, it is recommended that you reduce the number of RSTP instances to 128 or a lower value using the **system-max rstp** command. However, if you upgrade from Brocade NetIron Release 5.8 (or previous releases) to 5.9 and restart, there is no change in the RSTP configuration or operation since the lower number of RSTP instances are anyway supported.

---

**Examples** The following example enables configuring a maximum of 48 RSTP instances on the device.

```
device# configure terminal
device(config)# system-max rstp 48
```

### History

| Release version | Command history                                                                         |
|-----------------|-----------------------------------------------------------------------------------------|
| 5.9.00          | This command was modified to increase the maximum valid RSTP instances from 128 to 256. |

---

## system-max trunk-num

Specifies the maximum number of trunks that can be set in the Brocade devices.

**Syntax** `system-max trunk-num value`  
`no system-max trunk-num value`

**Command Default** If this command is not entered, the default number is 128.

**Parameters** *value*  
 Specifies the maximum number of trunks that can be set on a Brocade device. The valid values are 32, 64, 128, and 1024. The default value is 128.

**Modes** Global configuration mode

**Usage Guidelines** The **no** form of the command removes the previously specified maximum number of trunks.

---

### NOTE

Using this command requires a system restart in order for the new setting to take effect.

---

**Examples** The following example sets the maximum number of trunks to 64.

```
device# configure terminal
device(config)# system-max trunk-num 64
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.4.00a         | This command was introduced. |

## system-max tvf-lag-lb-fid-group

Configures maximum FID group size for transparent VLAN flooding LAG load balancing globally.

**Syntax** `system-max tvf-lag-lb-fid-group number`

`no system-max tvf-lag-lb-fid-group`

**Command Default** The default maximum FID group size is 2.

**Parameters** *number*

Specifies the decimal value of the FID number defined per group. Valid values are 2, 4, 8.

**Modes** Global configuration mode

**Usage Guidelines** The system-max tvf-lag-lb-fid-group command configures maximum FID group size for transparent VLAN flooding LAG load balancing globally. Valid values defined per group are 2, 4, 8.

---

### NOTE

After configuring group size, execute the **write memory** command and restart the router. Configuring a new maximum FID group size could cause instability on failover.

---

Use the **no** form of this command to disable the configured max group size.

**Examples** The following example configures a max group size of 4 for transparent VLAN flooding LAG load balancing:

```
device(config)# system-max tvf-lag-lb-fid-group 4
```

To disable the max group size configuration, use the following command:

```
device(config)# no system-max tvf-lag-lb-fid-group
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.6.00          | This command was introduced. |

---

# system-max tvf-lag-lb-fid-pool

Configures maximum FID pool size for transparent VLAN flooding LAG load balancing globally.

**Syntax** `system-max tvf-lag-lb-fid-pool number`

`no system-max tvf-lag-lb-fid-pool`

**Parameters** *number*

Specifies the decimal value of FID pool size defined. The valid values are 0, 512, 1024, 2048, and 4096. The default value is 0. Setting the value as 0 will disable transparent VLAN flooding LAG load balancing globally.

**Modes** Global configuration mode

**Usage Guidelines** Use the `no system-max tvf-lag-lb-fid-pool` command to disable the pool size configuration.

The `system-max tvf-lag-lb-fid-pool` command configures maximum pool size for transparent VLAN flooding LAG load balancing globally.

---

## NOTE

After configuring pool size execute write memory command and restart the router, else it could cause instability on fail over.

---

**Examples** The following example shows how to configure a pool size of 200 for transparent VLAN flooding LAG load balancing:

```
device(config)# system-max tvf-lag-lb-fid-pool 200
```

The following example shows how to configure a max pool size of 4096 for transparent VLAN flooding LAG load balancing:

```
device(config)# system-max tvf-lag-lb-fid-pool 4096
Reload required. Please write memory and then reload or power cycle the system.
Failure to reload could cause system instability on failover.
Newly configured system-max will not take effect during hitless-reload.
```

To disable the max pool size configuration use the following command:

```
device(config)#no system-max tvf-lag-lb-fid-pool
```

## History

| Release version | Command history                                                |
|-----------------|----------------------------------------------------------------|
| 5.6.00          | This command was introduced.                                   |
| 5.9.00          | This command was modified to add a new FID pool value of 4096. |

## te-metric

Configures the TE-metric value for an MPLS interface.

**Syntax** `te-metric`*value*

`no te-metric`*value*

**Command Default** No TE-metric value is configured.

**Parameters** *value*

Specifies a number for the value of the TE-metric. The value ranges between 1 and 65535.

**Modes** MPLS interface configuration mode

**Usage Guidelines**

**Examples** The following example sets the TE-metric configured for an MPLS interface to 5.

```
device# configure terminal
device (config)# router-mpls
device(config-mpls)# mpls-interface ethernet 1/1
device(config-mpls-if-e1000-1/1)# te-metric 5
```

The following example tries to remove the TE-metric but gives an incorrect value. An error message is displayed that specifies the currently configured value. This correct value is then entered in the **no** form to remove the TE-metric value for Ethernet interface 1/1.

```
device# configure terminal
device (config)# router-mpls
device(config-mpls-if-e1000-1/1)#no te-metric 3
Error:TE-metric is configured to a value of 5
device(config-mpls-if-e1000-1/1)#no te-metric 5
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.6.00          | This command was introduced. |



# terminal enable timestamp

Enables and disables the timestamp recording for all show commands for the terminal session of the executed command.

**Syntax** **terminal enable timestamp** [ iso8601-format ]

**no terminal enable timestamp** [ iso8601-format ]

**Parameters** iso8601-format

Displays the timestamp in ISO 8601 format: YYYY-MM-DDThh:mm:ssTZD (for example, 1997-07-16T19:20:30+01:00). The format uses the following conventions:

YYYY = Year, four digits

MM = for example, 01 = January

DD = Day of the month, two digits (01 through 31)

hh = Hour, two digits (00 through 23) (am/pm is not allowed)

mm = Minutes, two digits (00 through 59)

ss = Seconds, two digits (00 through 59)

TZD = Time zone designator (Z or +hh:mm or -hh:mm)

**Modes** Privileged EXEC mode

**Usage Guidelines** Use this command to enable the timestamp recording in the default mode to be displayed at the beginning of each show command output. By default, the timestamp is not displayed in the show command outputs. The timestamp recording is applicable only to the current terminal session, and not saved to the startup configuration. The use of this command can assist with troubleshooting or debugging issues.

The default mode is displayed in the system clock format as HH:MM:SS.MSC TZ Wk Mon Day Year (for example 11:41:45.565 GMT+00 Sat Feb 24 2014). The format uses the following conventions:

HH = Hour, two digits (00 through 23) (in 24- hour format)

MM = Minutes, two digits (00 through 59)

SS = Seconds, two digits (00 through 59)

MSC = Milliseconds, three digits (000 through 999)

TZ = Time zone

Wk = Weekday, three characters (Sat, Sun, Mon, and so on)

Mon = Month, three characters

Day = Day, two digits (01 through 31)

Year = Year, four digits

Prior to NetIron 05.9.00, some existing show commands (for example, **show tasks** and **show cpu utilization**) displayed the timestamp as part of the show command output. When the **terminal enable timestamp** command is enabled, an additional timestamp recording will now appear at the beginning of the show command outputs on the session where the **terminal enable timestamp** command is issued.

The **no** form of the command disables the timestamp recording at the beginning of each show command output.

**Examples** The following example enables the timestamp recording in default mode. The recording is displayed in the **show ip interface** command output.

```
device# terminal enable timestamp
device# show ip interface
11:41:45.565 GMT+00 Sat Feb 24 2014
Flags : U - Unnumbered, S - Secondary, US - Unnumbered Secondary, V - VE over VPLS,
VS - VE over VPLS Secondary
Interface      IP-Address      OK?  Method  Status      Protocol
VRF
eth 1/2        100.1.1.1       YES  NVRAM   up          default-
vrf
eth 2/8        216.1.1.1       YES  NVRAM   admin/down down      default-
vrf
eth 4/2        42.1.1.1        YES  NVRAM   admin/down down      default-
vrf
mgmt 1         10.25.113.41    YES  NVRAM   up         up        default-
vrf
ve 10          110.1.1.1       YES  NVRAM   up         up        default-
vrf
ve 20          120.1.1.1       YES  NVRAM   up         up        default-
vrf
ve 36          36.1.1.1        YES  NVRAM   down       down      default-
vrf
ve 44          44.1.1.1        YES  NVRAM   down       down      default-
vrf
ve 45          45.1.1.1        YES  NVRAM   down       down      default-
vrf
ve 48          48.1.1.1        YES  NVRAM   down       down      default-
vrf
```

The following example enables the timestamp recording in the iso8601 format. The recording is displayed in the **show ip interface** command output.

```
device# terminal enable timestamp iso8601-format
device# show ip interface
2014-01-13T19:20:30+01:00
Flags : U - Unnumbered, S - Secondary, US - Unnumbered Secondary, V - VE over VPLS,
VS - VE over VPLS Secondary
Interface      IP-Address      OK?  Method  Status      Protocol
VRF
eth 2/1        21.1.1.5        YES  NVRAM   up          default-
vrf
eth 4/1        10.1.1.1        YES  manual  admin/down down      default-
vrfl
mgmt 1         10.37.73.171    YES  NVRAM   up         up        default-
vrf
ve 101         11.1.1.1        YES  NVRAM   up         up        default-
vrf
ve 101         11.1.2.1        YES  NVRAM   up         up        default-
vrf
ve 102         12.1.1.1        YES  NVRAM   up         up        default-
vrf
ve 103         13.1.1.1        YES  NVRAM   up         up        default-
vrf
ve 106         16.1.1.1        YES  manual  up         up        default-
vrfl
```

The **show terminal** command is modified to include the terminal timestamp status when the iso8601 format is enabled.

```
device# show terminal
2015-08-03T21:10:59+00:00
Length: 24 lines
Page display mode (session): disabled
Page display mode (global): enabled
Timestamp: enabled (iso8601 format)
```

**History**

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## timers (OSPFv3)

Configures Link State Advertisement (LSA) pacing and Shortest Path First (SPF) timers.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>timers</b> { <b>lsa-group-pacing</b> <i>interval</i>   <b>spf</b> <i>start</i> <i>hold</i> }                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Command Default</b>  | Enabled.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Parameters</b>       | <p><b>lsa-group-pacing</b> <i>interval</i></p> <p>Specifies the interval at which OSPFv3 LSAs are collected into a group and refreshed, check-summed, or aged by the OSPFv3 process. Valid values range from 10 to 1800 seconds. The default is 240 seconds.</p> <p><b>spf</b></p> <p>Specifies start and hold intervals for SPF calculations for performance. The values you enter are in milliseconds.</p> <p><i>start</i></p> <p>Initial SPF calculation delay. Valid values range from 0 to 65535 seconds. The default is 5 seconds.</p> <p><i>hold</i></p> <p>Minimum hold time between two consecutive SPF calculations. Valid values range from 0 to 65535 seconds. The default is 10 milliseconds.</p>                                                                                                                                            |
| <b>Modes</b>            | <p>OSPFv3 router configuration mode</p> <p>OSPFv3 router VRF configuration mode</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Usage Guidelines</b> | <p>The device paces LSA refreshes by delaying the refreshes for a specified time interval instead of performing a refresh each time an individual LSA refresh timer expires. The accumulated LSAs constitute a group, which the device refreshes and sends out together in one or more packets.</p> <p>The LSA pacing interval is inversely proportional to the number of LSAs the device is refreshing and aging. For example, if you have a large database of 10,000 LSAs, decreasing the pacing interval enhances performance. If you have a small database of about 100 LSAs, increasing the pacing interval to 10 to 20 minutes may enhance performance.</p> <p>Enter the <b>no timers lsa-group-pacing</b> to restore the pacing interval to its default value.</p> <p>Enter <b>no timers spf</b> to set the SPF timers back to their defaults.</p> |
| <b>Examples</b>         | <p>This example sets the LSA group pacing interval to 30 seconds.</p> <pre>device# configure terminal device(config)# ipv6 router ospf device(config-ospf6-router)# timers lsa-group-pacing 30</pre> <p>This example sets the SPF delay time to 10 and the hold time to 20.</p> <pre>device# configure terminal device(config)# ipv6 router ospf device(config-ospf6-router)# timers spf 10 20</pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

# tracert

Traces the network path of packets as they are forwarded to an IPv4 or IPv6 destination address.

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>tracert</b> { <i>ipv4-address</i>   <i>hostname</i>   <b>ipv6</b> { <i>ipv6-address</i>   <i>ipv6-hostname</i> } } [ <b>maxttl</b> <i>value</i> ] [ <b>minttl</b> <i>value</i> ] [ <b>numeric</b> ] [ <b>source-ip</b> <i>address</i> ] [ <b>timeout</b> <i>seconds</i> ] [ <b>vrf</b> <i>vrf-name</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Parameters</b>       | <p><i>ipv4-address</i><br/>Specifies the IPv4 address of the destination device.</p> <p><i>hostname</i><br/>Specifies the name of the destination (host) device.</p> <p><b>ipv6</b> <i>ipv6-address</i><br/>Specifies the IPv6 address of the destination device.</p> <p><i>ipv6-hostname</i><br/>Specifies the name of the destination (host) device.</p> <p><b>maxttl</b> <i>value</i><br/>Maximum TTL value in number of hops.</p> <p><b>minttl</b> <i>value</i><br/>Minimum TTL value in number of hops.</p> <p><b>numeric</b><br/>Displays the IP address in numeric format.</p> <p><b>source-ip</b> <i>address</i><br/>Specifies the IPv4 or IPv6 address of the source device.</p> <p><b>timeout</b> <i>seconds</i><br/>The tracert timeout value.</p> <p><b>vrf</b> <i>vrf-name</i><br/>Name of the VRF.</p> |
| <b>Modes</b>            | User EXEC mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Usage Guidelines</b> | <p>Use the <b>tracert</b> command to help troubleshoot networking issues with packets. If no VRF is specified, the default-vrf is used.</p> <p>If the source address is an IPv6 link-local address, the destination address must be no more than one hop away in the network. An IPv6 link-local address cannot be routed.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Examples</b>         | The following example performs an IPv4 tracert.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

```
device# tracert 172.16.4.80

tracert to 172.16.4.80 (172.16.4.80), 64 hops max
 1  10.24.80.1 (10.24.80.1) 0.588ms 0.139ms 0.527ms
 2  10.31.20.61 (10.31.20.61) 0.550ms 0.254ms 0.234ms
 3  10.16.200.113 (10.16.200.113) 0.408ms 0.285ms 0.282ms
 4  10.110.111.202 (10.110.111.202) 5.649ms 0.283ms 0.288ms
 5  10.130.111.38 (10.130.111.38) 1.108ms 0.712ms 0.704ms
 6  10.192.0.42 (10.192.0.42) 37.053ms 32.985ms 41.744ms
 7  172.16.56.10 (172.16.56.10) 33.110ms 33.349ms 33.114ms
 8  172.16.4.9 (172.16.4.9) 34.096ms 33.023ms 33.122ms
 9  172.16.4.80 (172.16.4.80) 76.702ms 83.293ms 79.570ms
```

The following example performs an IPv6 traceroute, with configured minimum and maximum TTL values and a source IP device address.

```
device# traceroute ipv6 fec0:60:69bc:92:218:8bff:fe40:1470 maxttl 128 minttl 30
source-ip fec0:60:69bc:92:205:33ff:fe9e:3f20 timeout 3

traceroute to fec0:60:69bc:92:218:8bff:fe40:1470 (fec0:60:69bc:
92:218:8bff:fe40:1470), 128 hops max, 80 byte packets
30 fec0:60:69bc:92:218:8bff:fe40:1470 (fec0:60:69bc:92:218:8bff:fe40:1470)  2.145
ms  2.118 ms  2.085 ms
```

## History

| Release version | Command history                                                        |
|-----------------|------------------------------------------------------------------------|
| 5.9.00          | This command was modified to add the <b>source-ip</b> option for IPv6. |

## tracert mpls ldp

Sends an MPLS echo request from the ingress to the egress Label Switching Router (LSR).

|                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <b>tracert mpls ldp</b> { <i>ip_addr/mask_length</i> } [ <b>destination</b> <i>ip_addr</i> ] [ [ <b>dsmap</b> ] ] [ [ <b>min-ttl</b> <i>min_num</i> ] ] [ [ <b>max-ttl</b> <i>max_num</i> ] ] [ [ <b>reply-mode</b> <b>router-alert</b> ] ] [ [ <b>reply-tos</b> <i>num</i> ] ] [ [ <b>size</b> <i>bytes</i> ] ] [ [ <b>source</b> <i>ip_addr</i> ] ] [ [ <b>timeout</b> <i>msec</i> ] ] [ [ <b>nexthop</b> <i>ipv4_addr</i> ] ]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Parameters</b> | <p><i>ip_addr mask_length</i><br/>Specifies the LDP IPv4 destination prefix and mask length. If the mask-length is not specified, the default value is 32.</p> <p><b>destination</b> <i>ip_addr</i><br/>Sets the destination IP address within the 127/8 subset. The default address is 127.0.0.1.</p> <p><b>dsmap</b><br/>Enables the Downstream (DS) mapping TLV in the echo request for tracert operation.</p> <p><b>min-ttl</b> <i>min_num</i><br/>Specifies a minimum value in the min-num variable for the outermost label in the tracert operation. The default minimum TTL value is one. Acceptable configuration values are 1 - 255.</p> <p><b>max-ttl</b> <i>max_num</i><br/>Specifies a maximum value in the max-num variable for the outermost label in tracert operation. The default maximum TTL value is 30. Acceptable configuration values are 1 - 255.</p> <p><b>reply-mode</b><br/><b>router-alert</b><br/>Used when the normal IP return path is unreliable.<br/>This option indicates that the reply must be sent as an IPv4 UDP packet with the Router Alert option. This option requires extra overhead processing at each LSR along the return path.</p> <p><b>reply-tos</b> <i>num</i><br/>Specifies to include a TOS value between 0 and 254 in the Reply-TOS-byte TLV. This value copies to the IP header TOS byte of the echo reply. By default, the reply-tos TLV is not included in the Echo Request.</p> <hr/> <p><b>NOTE</b><br/>The last bit of the TOS byte is always zero.</p> <hr/> <p><b>size</b> <i>bytes</i><br/>Specifies that the size of the echo request, including the label stack to be sent, and will be the value of the variable bytes. The pad TLV is used to fill the echo request message to the specified size. The minimum size is 92 bytes for an MPLS Echo Request. The maximum size is the size of the LSP MTU.</p> <p><b>source</b> <i>ip_addr</i><br/>Specifies the IP address of any interface. This address is used as the destination address for the echo reply address. The default address is the LSR ID.</p> <p><b>timeout</b> <i>msec</i><br/>Specifies an interval in milliseconds for the echo request message. The default timeout is five seconds. The maximum timeout value is five minutes.</p> <p><b>nexthop</b> <i>ipv4_addr</i></p> |

Specifies the nexthop IPv4 address that will be used to send the traceroute request. If there is no matching interface for the specified IPv4 address, the traceroute request fails.

**Modes** Privileged EXEC mode

**Usage Guidelines** You can specify the next hop IPv4 address used to send the traceroute request. If there is no matching interface for the specified IPv4 address, the traceroute request fails. When an address that does not match the outgoing path for the tunnel is given, the following error message appears as a response:  
Traceroute fails: LDP next-hop does not exist.

**Examples** The following example displays the output returned when using the **traceroute mpls ldp** command.

```
device# traceroute mpls ldp 10.22.22.22
Trace LDP LSP to 10.22.22.22/32, timeout 5000 msec, TTL 1 to 30
Type Control-c to abort
1 10ms 10.22.22.22 return code 3 (Egress)
```

#### History

| Release Version | Command history                                                  |
|-----------------|------------------------------------------------------------------|
| 5.5.00          | This command was modified to include the <b>nexthop</b> keyword. |

## track-port

Configures link-state tracking for a specific Virtual Router Redundancy Protocol (VRRP) or VRRP Extended (VRRP-E) interface.

**Syntax** `track-port { ethernet slot/port | ve num [ priority num ] }`

`no track-port { ethernet slot/port | ve num [ priority num ] }`

**Command Default** Priority range is 2.

**Parameters** `ethernet slot port`

Configures link-state tracking for a valid Ethernet slot and port number.

`ve number`

Configures link-state tracking for a virtual Ethernet interface. Valid values range from 1 through 255.

`priority num`

Sets the track priority to a number from 1 through 254. The tracking priority number is used when a tracked interface up or down event is detected. For VRRP, if the tracked interface becomes disabled, the current router priority is reduced to the track-port priority, (For VRRP only, interface tracking does not have any effect on an owner router; the owner priority can not be changed from 255.) For VRRP-E, if the tracked interface becomes disabled, the current router priority is reduced by the track-port priority.

**Modes** Virtual-router-group configuration mode

**Usage Guidelines** This command can be used for VRRP or VRRP-E.

For VRRP, the tracked interface can be any valid Ethernet, or virtual Ethernet interface other than the one on which this command is issued. The maximum number of interfaces you can track per virtual router is 16.

Enter **no track-port** with the specified interface to remove the tracked port configuration.

**Examples** The following example configures link-state tracking on interface 2/4 and sets the track priority to 60:

```
device(config)# configure terminal
device(config)# interface ethernet 1/6
device(config-if-e1000-1/6)# ip vrrp vrid 1
device(config-if-e1000-1/6-vrid-1)# track-port ethernet 2/4 priority 60
```



# transparent-hw-flooding lag-load-balancing

Configures transparent VLAN flooding LAG load balancing on a specific VLAN when there is PBR to TVF VLAN flooding.

**Syntax** `transparent-hw-flooding lag-load-balancing`

**Command Default** By default, transparent VLAN flooding LAG load balancing is not configured on a specific VLAN with flooding.

**Modes** VLAN configuration mode

**Usage Guidelines** The `transparent-hw-flooding lag-load-balancing` command configures transparent VLAN flooding LAG load balancing on a specific VLAN when there is PBR to TVF VLAN flooding. The command supports 480 TVF LAG instances.

Use the **no** form of the command to disable the transparent VLAN flooding LAG load balancing on a specific VLAN.

**Examples** The following example enables transparent VLAN flooding LAG load balancing on VLAN 100:

```
device(config)# vlan 100
device(config-vlan-100)# transparent-hw-flooding lag-load-balancing
```

To disable transparent VLAN flooding LAG load balancing on VLAN 100, use the following command:

```
device(config)# vlan 100
device(config-vlan-100)# no transparent-hw-flooding lag-load-balancing
```

## History

| Release Version | Command History              |
|-----------------|------------------------------|
| 5.6.00          | This command was introduced. |

## tunnel destination

Configures the tunnel destination of the tunnel to the specified IPv6 address. IPv6 packets transmitted across the tunnel are received by this address.

**Syntax** `tunnel destination ipv6-address`

`no tunnel destination ipv6-address`

**Command Default** This command is not configured.

**Parameters** `ipv6-address`

Specifies the IPv6 address to be the destination of the IPsec IPv6 tunnel.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** The `no` form of this command removes the specified IPv6 address as the tunnel destination. Link-local address cannot be used as the destination of the tunnel.

**Examples** This example shows configuring the tunnel destination for tunnel number 1 (one) to the IPv6 address of 10:1:1::2/64.

```
device(config) interface tunnel 1
device(config-tnif-1)# tunnel source 10:1:1::2/64
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## tunnel mode ipsec ipv4

Configures the tunnel mode for the specified tunnel to be IPsec IPv4. This enables support for IPsec on the IPv4 packets transmitted across the tunnel.

**Syntax** **tunnel mode ipsec ipv4**

**no tunnel mode ipsec ipv4**

**Command Default** IPsec is not supported on IPv4 packets transmitted across a tunnel.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** While this command sets IPsec support for IPv4 packets across a tunnel, use the related **tunnel mode ipsec ipv6** command to set IPsec support for IPv6 packets across a tunnel.

The **no** form of this command disables the IPsec IPv4 support on the specified tunnel.

**Examples** The following example configures the tunnel mode for tunnel number 1 (one) to IPsec IPv4.

```
device# configure terminal
device(config) interface tunnel 1
device(config-tnif-1)# tunnel mode ipsec ipv4
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

## tunnel mode ipsec ipv6

Configures the tunnel mode for the specified tunnel to be IPsec IPv6. This enables support for IPsec on the IPv6 packets transmitted across the tunnel.

**Syntax** **tunnel mode ipsec ipv6**

**[no] tunnel mode ipsec ipv6**

**Command Default** This command is not configured.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** The **no** form of this command disables the IPsec IPv6 support on the specified tunnel. Use the **tunnel mode ipsec ipv4** command to set the tunnel mode to IPsec IPv4.

**Examples** The following example configures the tunnel mode for tunnel number 1 (one) to IPsec IPv6.

```
device(config) interface tunnel 1
device(config-tnif-1)# tunnel mode ipsec ipv6
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## tunnel override-pkt-tos-ttl

Configures the IPsec tunnel to copy the configured TOS and TTL values to the outer IP header.

**Syntax** **tunnel override-pkt-tos-ttl**

**no tunnel override-pkt-tos-ttl**

**Command Default** By default, when a packet goes out on an IPsec tunnel, the TOS and TTL values are copied from the inner IP header to the outer IP header.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** The **no** form of the command disables the IPsec tunnel from copying the TOS and TTL values.

**Examples** The following example configures the IPsec tunnel interface to copy the TOS and TTL values.

```
device(config)# interface ethernet 3/1
device(config-int-e10000-3/1)# ip address 36.0.8.108/32
device(config-int-e10000-3/1)# interface tunnel 1
device(config-tnif-1)# tunnel override-pkt-tos-ttl
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

## tunnel protection ipsec profile

Configures the IPsec profile for the specified tunnel. The profile is used to encapsulate the IP packets being forwarded by the specified interface. This command supports IPsec IPv4 and IPsec IPv6 tunnels.

**Syntax** `tunnel protection ipsec profile ipsec-profile-name`

`no tunnel protection ipsec profile ipsec-profile-name`

**Command Default** By default, an IPsec profile is not configured.

**Parameters** *ipsec-profile-name*

Specifies the IPsec profile used to encapsulate the packets going out of this interface.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** This command can be used for both IPsec IPv4 and IPsec IPv6 tunnels.

The **no** form of the command disables the IPsec profile previously configured on the interface.

**Examples** The following example configures an IPsec profile named ipsec1 on interface 3/1 (the tunnel is tunnel number 1).

This example is for an IPsec IPv4 tunnel.

```
device# configure terminal
device(config)# interface ethernet 3/1
device(config-int-e10000-3/1)# ip address 36.0.8.108/32
device(config-int-e10000-3/1)# interface tunnel 1
device(config-tnif-1)# tunnel protection ipsec profile ipsec1
```

### History

| Release version | Command history                                          |
|-----------------|----------------------------------------------------------|
| 05.8.00         | This command was introduced.                             |
| 05.9.00         | This command was modified to support IPsec IPv6 tunnels. |

## tunnel source

Configures the tunnel source of the tunnel to the specified IPv6 address. IPv6 packets are forwarded from this address across the tunnel.

**Syntax** `tunnel source ipv6-address`

`no tunnel source ipv6-address`

**Command Default** This command is not configured.

**Parameters** `ipv6-address`

Specifies the IPv6 address to be the source of the IPsec IPv6 tunnel.

**Modes** Tunnel interface configuration mode

**Usage Guidelines** The **no** form of this command removes the specified IPv6 address as the tunnel source. Link-local address cannot be used as the source of the tunnel.

**Examples** This example shows configuring the tunnel source for tunnel number 1 (one) to the IPv6 address of 10:1:1::1/64.

```
device(config) interface tunnel 1
device(config-tnif-1)# tunnel source 10:1:1::1/64
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## tunnel-interface

Configures the LSP tunnel's interface index.

**Syntax** `tunnel-interface { index }`

`no tunnel-interface { index }`

**Command Default** There is no specific default for this command. If not configured, an unused value is chosen.

**Parameters** *index*

Decimal value. The range is system dependent. For XMR/MLXe-MR2 systems, the range is 1 - 16384. For CES/CER systems, the range is 1 - 1024.

**Modes** MPLS LSP and MPLS bypass LSP modes (config-mpls-lsp).

**Usage Guidelines** The `no` option frees the tunnel-interface configured for this node and has a new value dynamically allocated. If the next available index value is the same as that just removed by the user, the same value is still allocated. This is not an error condition. The main purpose of this command is for scenarios where the user wants to allocate any value to the LSP and not something chosen by the user.

The picking algorithm uses the least index that is unused. If none are available (in cases where the number of LSPs supported has been exceeded), the LSP is not allowed to be created. If the user configures a value, there is a check to see if the value is unused or is in use by this tunnel already. If it is in use by another LSP, an error displays and the user will have to configure another value. If it is free, the current value is freed up to be used by any other LSP and the configured value is taken up by this LSP.

This command can be executed irrespective of the state of the LSP - enabled or disabled. It does not depend on adaptive and does not need a commit. The interface index value is for the tunnel and is shared by all the paths - secondary or primary.

Special case handling:

Error handling in the special cases that the user loads a startup-configuration that have the following errors:

1. Multiple LSPs configured with the same tunnel-interface index.
  1. In this scenario, the LSPs that comes up later will come up as before.
  2. These LSPs do not have a valid tunnel-interface value and cannot be queried using SNMP.
  3. In the **show mpls lsp** detail view, the tunnel-interface index is shown as "Invalid". LSP c2, to 3.3.3.3, tunnel-interface index: Invalid.
  4. Only the first LSP to get the value has the valid tunnel-interface index.
  5. The configuration continues to show the configured incorrect value, and the user can change it to a valid unused value.
  6. The user can list all LSPs that have an invalid tunnel-interface index using the command - **show mpls lsp invalid-tunnel-interface**.
2. Multiple LSPs without a tunnel-interface configured.
  - a. LSPs that do not have a value configured in the Configuration are allocated to a tunnel-interface index.
  - b. It is possible that a later LSP might have configured on it the same value allocated to an LSP as in step 2a.
  - c. In such a scenario, de-allocate the index of the first LSP and allocate that value to the later LSP. The former is then allocated a new value from the free indexes.



**NOTE**

The above cases apply *only* to errors in the startup-configuration, not in the case of execution of the CLI during normal running.

**Examples** The following example shows how to configure the LSP tunnel interface index:

```
device#configure terminal
device(config)#router mpls
device(config-mpls)#lsp lsp1
device(config-mpls-lsp1)#tunnel-interface 100
device(config-mpls-lsp1)#to 3.3.3.3
device(config-mpls-lsp1)#enable

device#configure terminal
device(config)#router mpls
device(config-mpls)#bypass-lsp bypl
device(config-mpls-bypasslsp-bypl)#tunnel-interface 102
device(config-mpls-bypasslsp-bypl)#to 3.3.3.3
device(config-mpls-bypasslsp-bypl)#exclude-interface eth 2/1
device(config-mpls-bypasslsp-bypl)#enable
```

**History**

| Release version | Command history             |
|-----------------|-----------------------------|
| 5.9.00          | This command is introduced. |

## uda access-group

Binds the user defined ACL table to any physical port.

**Syntax** `uda access-group { [ access-list_name | uda-acl num ] [ in ] | enable-deny-logging [ hw-drop ] }`

`no uda access-group { [ access-list_name | uda-acl num ] [ in ] | enable-deny-logging [ hw-drop ] }`

**Parameters** *access-list\_name*

Specifies the selected access list by name.

*uda-acl num*

Specifies the selected UDA access list by the UDA ACL number. The numbers must be between 2000 - 2999.

**in**

Specifies inbound packets.

**enable-deny-logging**

Enables UDA ACL logging on the port.

**hw-drop**

Drops the ACL deny log packet in the hardware.

**Modes** User sub-configuration mode (configuration-interface-ethernet).

**Usage Guidelines** The user defined ACL created must be passed to this CLI command.

Only the user defined ACLs are supported in the ingress side. The UDA offsets must be defined for the access list before binding the ACL to any physical port. If not, the error message **"UDA offsets are not defined for this port"** displays and binding fails.

All the UDA ACL clauses defined in the UDA ACL table are programmed into the hardware. The UDA offsets configured as "ignore" are masked in the ACL rule while programming in the hardware.

If the empty UDA ACL is bound to a physical port, the UDA ACL lookup will not happen until additional rules are added.

The **no** form of the command removes the binding of the user defined ACL table to any physical port.

**Examples** The following example displays the output by number.

```
device (config)# show access-list uda
UDA Access List 2000:
10: access-list 2000 permit 100 any any 00001122 0000ffff 00003344 0000ffff
20: access-list 2000 permit any any any any any
!
UDA Access List 2001:
10: access-list 2001 permit 200 any any 00001122 0000ffff 00003344 0000ffff
20: access-list 2001 permit any any any any any
!
```

The following example displays the output by name.

```
device (config)# show access-list uda TestUdaAcl
UDA Access List TestUdaAcl:
access-list 2000 uda-offsets 12      20      36      72
10: access-list 2000 permit 100 any any 00001122 0000ffff 00003344 0000ffff
20: access-list 2000 permit any any any any any
!
```

| History | Release version | Command history              |
|---------|-----------------|------------------------------|
|         | 5.9.00          | This command was introduced. |

## uda-offsets

Defines the User Defined fields offset values. This is configured in the physical interface.

**Syntax**    **uda-offsets** [ **offset0** | **ignore** ] [ **offset1** **ignore** ] [ **offset2** **ignore** ] [ **offset3** **ignore** ]  
**no uda-offsets** [ **offset0** | **ignore** ] [ **offset1** **ignore** ] [ **offset2** **ignore** ] [ **offset3** **ignore** ]

### Command Default

#### Parameters

##### offset1

The offset specified is the offset from the beginning of the normalized packet. The maximum value of the offset is 116.

##### ignore

Ignore offset1.

#### Modes

User configuration mode (interface-ethernet).

#### Usage Guidelines

If the offsets are not in the 4 byte boundary or greater than 116, an error message "UDA Offset0 'value' is invalid. The Specify Value is in 32-bit boundary and < 116" displays.

The UDA offsets can be modified when the UDA ACL is bound to the physical port. The UDA ACL rules dynamically update to mask the "ignored" UDA fields.

Deleting uda-offsets when some UDA ACL bound to the physical port is not allowed and an error is displayed (**UDA ACL <id> is bound to this port <slot/port>. Unbind UDA ACL before modifying uda-offsets**).

The **no** form of the command removes the uda-offset configuration on the specified UDA Table.

#### Examples

The following example displays how to define up to four offsets.

```
device configure terminal
device(config)# interface ethernet 1/1
device(config-intf-e1000-1/1)# uda-offsets 0 4 8 12
```

The following example displays how to define two offsets.

```
device configure terminal
device(config)# interface ethernet 1/1
device(config-intf-e1000-1/1)# uda-offsets 0 4 ignore ignore
```

The following example displays how to remove the uda-offset configuration on the specified UDA table.

```
device configure terminal
device(config)# interface ethernet 1/1
device(config-intf-e1000-1/1)# no uda-offsets
```

#### History

| Release version | Command history                                                          |
|-----------------|--------------------------------------------------------------------------|
| 5.9.00          | This command was modified to define a User Defined fields offset values. |

# underflow-limit

Sets the number of consecutive samples which have to be below the threshold value to trigger a premature adjustment to the reserved bandwidth of the label-switched path (LSP).

**Syntax** `underflow-limit value`

`no underflow-limit value`

**Command Default** The default is that there is no premature adjustment because of underflow.

**Parameters** *value*

Defines the number of consecutive samples. Default is 0.

**Modes** MPLS autobw-template config mode

MPLS LSP mode

**Usage Guidelines** In the auto-bandwidth feature, the traffic rate through an LSP is sampled and the reserved bandwidth of the LSP is automatically changed through a make-before-break mechanism. This is done in order to keep the reserved bandwidth close to the actual traffic rate. It is beneficial to have an optimum bandwidth reservation for an LSP. Auto-bandwidth allows for a very efficient use of network-bandwidth. Use the **underflow-limit** command to reduce the reserved bandwidth prematurely, when the actual traffic rate is consistently much lower than the current reserved bandwidth.

This command can be entered in several modes, under MPLS auto-bandwidth template configuration mode or in MPLS LSP mode as shown in the examples section.

The **no** function of the command sets the underflow-limit back to the default value.

**Examples** The following example sets the underflow-limit in an auto-bandwidth template.

```
device(config)# router mpls
device(config-mpls)# autobw-template template1
device(config-mpls-autobw-template-template1)# underflow-limit 10
```

The following example sets the underflow-limit for an individual LSP.

```
device(config)# router mpls
device(config-mpls)# lsp lsp1
device(config-mpls-lsp-lsp1)# autobw-threshold-table
device(config-mpls-lsp-lsp1-autobw)# underflow-limit 10
```

The following example clears the underflow-limit configuration. The user issues the same command with the **no** option. The underflow-limit configuration is set back to the default value of zero (0).

```
device(config-mpls-autobw-template-template1)# no underflow-limit 10
device(config-mpls-lsp-lsp1-autobw)# no underflow-limit 10
```

## History

| Release | Command history             |
|---------|-----------------------------|
| 5.6.00  | The command was introduced. |

## update-lag-name

Modifies an existing Link Aggregation Group (LAG) name without deleting and recreating the configured LAG.

|                         |                                                                                                                                                                        |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>update-lag-name</b> <i>new-name</i>                                                                                                                                 |
| <b>Parameters</b>       | <i>new-name</i><br>Specifies the new LAG name for an existing LAG name. The LAG name can contain up to 64 characters.                                                  |
| <b>Modes</b>            | LAG configuration mode                                                                                                                                                 |
| <b>Usage Guidelines</b> | The modified LAG name should be unique across all the LAG names that are available. This command works for all LAG types, such as static, dynamic, and keepalive LAGs. |
| <b>Examples</b>         | The following example changes the existing LAG name from "blue" to "brocade."                                                                                          |

```
device# configure terminal
device(config)# show run
device(config)# lag blue
device(config-lag-blue)# update-lag-name brocade
```

The following partial output verifies the update of the existing LAG name from "blue" to "brocade."

```
device(config)# show run
!Current configuration:
module 3 br-mlx-24-port-lgc-x
!
!
lag "blue" static id 2
  ports ethernet 3/1
  primary-port 3/1
  deploy
!
!
device(config)# lag blue
device(config-lag-blue)# update-lag-name brocade
device(config-lag-brocade)# show run
!Current configuration:
!
!
module 3 br-mlx-24-port-lgc-x
!
!
!
lag "brocade" static id 2
  ports ethernet 3/1
  primary-port 3/1
  deploy
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 5.9.00          | This command was introduced. |

## use-v2-checksum

Enables the v2 checksum computation method for an IPv4 Virtual Router Redundancy Protocol version 3 (VRRPv3) session.

**Syntax** **use-v2-checksum**

**no use-v2-checksum**

**Command Default** VRRPv3 uses v3 checksum computation method.

**Modes** VRRP configuration mode

**Usage Guidelines** The **no** form of this command enables the default v3 checksum computation method in VRRPv3 sessions.

Some non-Brocade devices only use the v2 checksum computation method in VRRPv3. This command enables v2 checksum computation method in VRRPv3 and provides interoperability with these non-Brocade devices.

**Examples** The following example shows the v2 checksum computation method enabled for an VRRPv3 IPv4 session on a Brocade device.

```
device# config
device(config)# router vrrp
device(config)# ethernet 2/4
device(config-if-e1000-2/4)# ip vrrp vrid 14
device(config-if-e1000-2/4-vrid-14)# version v3
device(config-if-e1000-2/4-vrid-14)# use-v2-checksum
device(config-if-e1000-2/4-vrid-14)# ip-address 10.14.14.99
device(config-if-e1000-2/4-vrid-14)# activate
```

### History

| Release version | Command history                                                                                      |
|-----------------|------------------------------------------------------------------------------------------------------|
| 5.7.00          | This command was introduced for VRRPv3 IPv6 sessions running on NetIron device images.               |
| 5.8.00          | This command was modified to support VRRPv3 IPv4 and IPv6 sessions running on NetIron device images. |

## use-vrrp-path

Suppresses RIP advertisements for interfaces on which Virtual Router Redundancy Protocol (VRRP) or VRRP Extended (VRRP-E) backup routers are configured.

**Syntax**    **use-vrrp-path**

**no use-vrrp-path**

**Command Default**    RIP advertisements are sent from the backup router interface.

**Modes**            RIP router configuration mode

**Usage Guidelines**    A VRRP backup router includes route information for the interface it is backing up in RIP advertisements. As a result, other routers receive multiple paths for the interface and might unsuccessfully use the path to the backup router rather than the path to the master router. If the VRRP backup routers are suppressed from advertising the backed-up interface in RIP, other routers learn only the path to the master router for the backed-up interface.

The **no** form of this command resets the default behavior and RIP advertisements are sent from the backup router interface.

**Examples**            The following example enables RIP advertisement suppression for information about interfaces on VRRP or VRRP-E backup routers.

```
device# configure terminal
device(config)# router rip
device(config-rip-router)# use-vrrp-path
```

The following example disables the RIP advertisement suppression.

```
device# configure terminal
device(config)# router rip
device(config-rip-router)# no use-vrrp-path
```



## version

Sets the version number for a Virtual Router Redundancy Protocol (VRRP) session.

**Syntax** `version { v2 | v3 }`

`no version { v2 | v3 }`

**Command Default** VRRP version 2 is the default.

**Parameters** `v2`

Configures VRRP version 2 for this session.

`v3`

Configures VRRP version 3 for this session.

**Modes** Virtual routing ID interface configuration mode

**Usage Guidelines** The **no** form of this command resets the VRRP session to the default of version 2. VRRP version 2 supports IPv4 addresses and VRRP version 3 supports both IPv4 and IPv6 addresses.

---

**NOTE**

Mixed mode VRRP v2 and VRRP v3 is not supported in the same VRRP virtual routing ID (VRID) session.

---

**Examples** The following example sets the VRRP routing instance VRID 1 to version 3.

```
device# configure terminal
device(config)# router vrrp
device(config)# interface ethernet 1/6
device(conf-if-e1000-1/6)# ip address 10.53.5.1/24
device(conf-if-e1000-1/6)# ip vrrp vrid 1
device(conf-if-e1000-1/6-vrid-1)# version v3
```

## virtual-mac

Enables manual generation of a virtual MAC address for a Virtual Router Redundancy Protocol (VRRP) or VRRP Extended (VRRP-E) instance.

|                         |                                                                                                                                                                                                                                                          |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>virtual-mac</b> { <i>mac-address</i>   <i>ipv6-mac-address</i> }                                                                                                                                                                                      |
| <b>Command Default</b>  | If there is no manually configured virtual MAC address for a VRRP or VRRP-E instance, the system automatically assigns a virtual MAC address.                                                                                                            |
| <b>Parameters</b>       | <p><i>mac-address</i></p> <p>Configures a unique virtual MAC address for a VRRP or VRRP-E instance using hexadecimal.</p> <p><i>ipv6-mac-address</i></p> <p>Configures a unique virtual MAC address for a VRRP or VRRP-E instance using hexadecimal.</p> |
| <b>Modes</b>            | VRRP-Extended group configuration mode                                                                                                                                                                                                                   |
| <b>Usage Guidelines</b> | By default, the VRRP or VRRP-E virtual MAC is derived as 02:e0:52:<2-byte-ip-hash>:<1-byte-vrid>                                                                                                                                                         |

---

### NOTE

System-assigned virtual MAC addresses and manually configured virtual MAC addresses can exist at the same time on the device under the same VRID, but the configured value takes precedence. When the configured value is deleted, the assigned value again applies.

---

**Examples** To enable the generation of a virtual MAC with 0 IP hash:

```
device# configure terminal
device(config)# int ve 10
device(config-ve-10)# vrrp-extended-group 100
device(config-vrrp-extended-group-100)# virtual-mac aaa.bbbb.cccc
```

# vll

Defines virtual leased line service and supports inter-operation between vendors.

**Syntax** `vll name vll_id [ cos num | raw-mode [ cos num ] | raw-pass-through-mode [ cos num ] ]`  
`no vll name vll_id [ cos num | raw-mode [ cos num ] | raw-pass-through-mode [ cos num ] ]`

**Command Default** A virtual leased line service is not configured.

**Parameters**

*name*

The name of the VLL. The name may be up to 64 characters.

*vll\_id*

The VLL identifier. The range is from 1 - 4294967294.

*cos num*

Optional COS selection.

**raw-mode**

Raw-mode Ethernet type (VC type 5) ( Default is the Tagged mode with VC type 4 ).

**raw-pass-through-mode**

Raw-pass-through-mode Ethernet type (VC type 5 if untagged endpoint and VC type 4 if tagged endpoint).

**Modes** MPLS configuration mode

**Usage Guidelines** The raw-mode and tagged-mode supports are for both CES and XMR platforms. In the raw-pass-through mode, VLL instance behaves similarly to either tagged-mode or raw-mode based on the VLL endpoint configuration and similar to tagged-mode for a tagged endpoint and raw-mode for an untagged endpoint.

**Examples** The following example configures the **raw-pass-through-mode** option.

```
device(config)#
device(config)# router mpls
device(config-mpls)# soft-preemption cleanup-timer
device(config-mpls)# vll test 1
device(config-mpls)# vll test 1 raw-pass-through-mode
device(config-mpls-vll-test)# vll-peer 10.0.0.1
device(config-mpls-vll-test)# vlan 100
device(config-mpls-vll-test-vlan-100)# tagged ethernet 1/12
device(config-mpls-vll-test-vlan-100)#
```

| History | Release version | Command history                                                                |
|---------|-----------------|--------------------------------------------------------------------------------|
|         | 5.5.00          | This command was modified to include the <b>raw-pass-through-mode</b> keyword. |

## vll-peer

Defines the far-end router IP address of the virtual leased line (VLL).

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>           | <b>vll-peer</b> <i>ip_address</i> [ <i>ip_address</i>   <b>lsp</b> <i>lsp_name...</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                           |
|                         | <b>no vll-peer</b> <i>ip_address</i> [ <i>ip_address</i>   <b>lsp</b> <i>lsp_name...</i> ]                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Parameters</b>       | <p><i>ip_address</i></p> <p>Specifies the IP address of the VLL peer.</p> <p><b>lsp</b> <i>lsp_name...</i></p> <p>Specifies LSP assignment for the vll-peer. Up to eight LSP names to a peer can be configured using this command. All eight LSPs are optional. When a VLL peer is not assigned to any LSPs, the default mechanisms for selecting an LSP for the VLL peer are used.</p>                                                                                                                           |
| <b>Modes</b>            | MPLS VLL configuration mode                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Usage Guidelines</b> | <p>To verify the configuration of this command use the <b>show mpls config vll</b> command with the name of the VLL for which you want to display the configuration.</p> <p>Use the <b>lsp</b> option to provide similar user experience as compared to VPLS LSP mapping and at the same time preserving the constructs of VLL peer configurations corresponding to Pseudowire Emulation (PWE) redundancy and MCT-VLL. This approach is backward compatible. Incremental additions and deletions are allowed.</p> |
| <b>Examples</b>         | The following example configures a single VLL peer with a set of LSPs. The <b>show mpls config vll</b> command is used to verify the configuration.                                                                                                                                                                                                                                                                                                                                                               |

---

### NOTE

Configuring the VLL peer and assigning LSPs can be done in the same line.

---

```
device# configure terminal
device(conf)# router mpls
device(config-mpls)# vll test 1000
device(config-mpls-vll-test)# vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3 lsp4
device# show mpls config vll test
vll test 1000
  vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3 lsp4
  vlan 1000
  tagged e 4/5
```

The following example appends an LSP to existing list of LSP mapped to VLL Peer.

```
device# configure terminal
device(conf)# router mpls
device(config-mpls)# vll test 1000
device(config-mpls-vll-test)# vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3 lsp4
device(config-mpls-vll-test)# vll-peer 1.1.1.1 lsp lsp5
```

The following example removes an LSP from an existing list of LSPs for a VLL peer. The **show mpls config vll** command is used to verify the configuration.

```
device# configure terminal
device(conf)# router mpls
device(config-mpls)# vll test 1000
device(config-mpls-vll-test)# vll-peer 1.1.1.1
device(config-mpls-vll-test)# vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3 lsp4
device(config-mpls-vll-test)# no vll-peer 1.1.1.1 lsp lsp4
device(config-mpls-vll-test)# end
device# show mpls config vll test
vll test 45000
  vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3
  vlan 1000
  tagged e 4/5
```

The following example configures a primary and standby VLL Peers with a set of LSPs.

---

#### NOTE

When configuring LSPs for primary or standby peers it is mandatory to configure the peers in advance and then proceed to configure the respective LSPs.

---

```
device# configure terminal
device(conf)# router mpls
device(config-mpls)# vll test 1000
device(config-mpls-vll-test)# vll-peer 1.1.1.1 2.2.2.2
device(config-mpls-vll-test)# vll-peer 1.1.1.1 lsp lsp1 lsp2 lsp3 lsp4
device(config-mpls-vll-test)# vll-peer 2.2.2.2 lsp lsp1 lsp2 lsp3 lsp4
```

The following example un-configures an LSP from the list of LSPs mapped to a standby VLL Peers.

```
device# configure terminal
device(conf)# router mpls
device(config-mpls)# vll test 1000
device(config-mpls-vll-test)# vll-peer 1.1.1.1 2.2.2.2
device(config-mpls-vll-test)# vll-peer 2.2.2.2 lsp lsp1 lsp2 lsp3 lsp4
device(config-mpls-vll-test)# no vll-peer 2.2.2.2 lsp lsp4
```

#### History

| Release version | Command history                                                                                                               |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------|
| 5.7.00          | This command was modified to add the <b>lsp</b> keyword to assign mapped LSPs to the VLL. Up to eight LSPs are now available. |

## vrf forwarding

Enables VRF forwarding by configuring a port as a VRF port.

- Syntax** `vrf forwarding forwarding-vrf-name`
- Parameters** `forwarding-vrf-name`  
Specifies the VRF name.
- Modes** Interface tunnel configuration mode
- Usage Guidelines** Only GRE IP and IPsec tunnel interfaces are supported as ports that can forward VRF traffic.
- Examples** The following example configures VRF forwarding on a device.

```
device(config)# interface ethernet 3/1
device(config-int-e10000-3/1)# ip address 36.0.8.108/32
device(config-int-e10000-3/1)# interface tunnel 1
device(config-tnif-1)# vrf forwarding red
```

### History

| Release version | Command history              |
|-----------------|------------------------------|
| 05.8.00         | This command was introduced. |

# write memory

Saves the current running configuration information to the startup configuration file.

**Syntax** `write memory`

**Command Default** Configuration information is not saved to the startup-config file until a **write memory** is performed.

**Modes** Privileged EXEC mode

**Usage Guidelines** This command saves a configuration change permanently so that the change remains in effect following a system reset or software reload. This command can be entered in any configuration mode, as well as in Privileged EXEC mode.

Some configuration changes like memory allocation changes, require you to reload the software after you save the changes to the startup configuration file.

You should always execute the **write memory** command after making extensive configuration changes. For example, on devices that support stacking any stacking-related configuration changes such as changing priority or stacking ports should be saved to the startup-config file.

---

## NOTE

Keep a backup copy of the startup configuration file in the event of system reset.

---

**Examples** The following example configures a new priority of 255 for stack unit 1, enables the priority, and saves the configuration change to the startup configuration file.

```
device# config terminal
device(config)# stack unit 1
device(config-unit-1)# priority 255
device(config-unit-1)# stack enable
Enable stacking. This unit actively participates in stacking
device(config-unit-1)# write memory
Write startup-config done.
Flash Memory Write (8192 bytes per dot) .Flash to Flash Done.
device(config-unit-1)# end
```

write memory