

53-1004079-01
17 February 2016

Network OS

Software Licensing Guide

Supporting Network OS 7.0.0

BROCADE 

© 2016, Brocade Communications Systems, Inc. All Rights Reserved.

Brocade, Brocade Assurance, the B-wing symbol, ClearLink, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision is a trademark of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

Contents

Preface.....	5
Document conventions.....	5
Object Missing.....	5
Command syntax conventions.....	5
Notes, cautions, and warnings.....	6
Brocade resources.....	6
Contacting Brocade Technical Support.....	7
Document feedback.....	7
About This Document.....	9
Supported hardware and software.....	9
Using the Network OS CLI	10
What's new in this document.....	10
Software Licensing Overview.....	11
Licensing overview.....	11
How software licensing works.....	11
License types.....	12
Software licensing terminology.....	12
License requirements.....	13
Licensing restrictions and considerations.....	16
Usage restrictions for time-based licenses.....	16
Configuration management considerations.....	16
Upgrade and downgrade considerations.....	16
Obtaining a license.....	17
Viewing software license information from the Brocade software portal.....	19
Licensing Tasks.....	21
Installing a license.....	21
Adding an FCoE license.....	22
Displaying a license	22
Displaying the switch license ID.....	23
Removing licenses.....	23
Extending a time-based license.....	24
Troubleshooting licensing issues.....	24
License is not properly installed.....	25
Dynamic Ports on Demand Licensing.....	27
Dynamic Ports on Demand overview.....	27
Managing automatic POD port assignments.....	28
Mapping port assignments to a POD port set.....	28
Activating the Dynamic POD feature	28
Adding a Dynamic POD license.....	29
Displaying the Dynamic POD assignments.....	30
Overriding Dynamic POD assignments.....	31
Reserving a port assignment.....	31

Releasing a port from a POD set.....	31
Configuring dual personality ports.....	32
Index.....	35

Preface

- Document conventions.....5
- Brocade resources.....6
- Contacting Brocade Technical Support.....7
- Document feedback.....7

Document conventions

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Brocade technical documentation.

Object Missing

This object is not available in the repository.

Command syntax conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example, --show WWN.
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x y z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options. In Fibre Channel products, square brackets may be used instead for this purpose.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member</i> [<i>member</i> ...].
\	Indicates a "soft" line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.



CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Brocade resources

Visit the Brocade website to locate related documentation for your product and additional Brocade resources.

You can download additional publications supporting your product at www.brocade.com. Select the Brocade Products tab to locate your product, then click the Brocade product name or image to open the individual product page. The user manuals are available in the resources module at the bottom of the page under the Documentation category.

To get up-to-the-minute information on Brocade products and resources, go to [MyBrocade](#). You can register at no cost to obtain a user ID and password.

Release notes are available on [MyBrocade](#) under Product Downloads.

White papers, online demonstrations, and data sheets are available through the [Brocade website](#).

Contacting Brocade Technical Support

As a Brocade customer, you can contact Brocade Technical Support 24x7 online, by telephone, or by e-mail. Brocade OEM customers contact their OEM/Solutions provider.

Brocade customers

For product support information and the latest information on contacting the Technical Assistance Center, go to <http://www.brocade.com/services-support/index.html>.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7.

Online	Telephone	E-mail
<p>Preferred method of contact for non-urgent issues:</p> <ul style="list-style-type: none"> • My Cases through MyBrocade • Software downloads and licensing tools • Knowledge Base 	<p>Required for Sev 1-Critical and Sev 2-High issues:</p> <ul style="list-style-type: none"> • Continental US: 1-800-752-8061 • Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33) • For areas unable to access toll free number: +1-408-333-6061 • Toll-free numbers are available in many countries. 	<p>support@brocade.com</p> <p>Please include:</p> <ul style="list-style-type: none"> • Problem summary • Serial number • Installation details • Environment description

Brocade OEM customers

If you have purchased Brocade product support from a Brocade OEM/Solution Provider, contact your OEM/Solution Provider for all of your product support needs.

- OEM/Solution Providers are trained and certified by Brocade to support Brocade® products.
- Brocade provides backline support for issues that cannot be resolved by the OEM/Solution Provider.
- Brocade Supplemental Support augments your existing OEM support contract, providing direct access to Brocade expertise. For more information, contact Brocade or your OEM.
- For questions regarding service levels and response times, contact your OEM/Solution Provider.

Document feedback

To send feedback and report errors in the documentation you can use the feedback form posted with the document or you can e-mail the documentation team.

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. You can provide feedback in two ways:

- Through the online feedback form in the HTML documents posted on www.brocade.com.
- By sending your feedback to documentation@brocade.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

About This Document

- [Supported hardware and software.....](#) 9
- [Using the Network OS CLI](#) 10
- [What's new in this document.....](#) 10

Supported hardware and software

In those instances in which procedures or parts of procedures documented here apply to some switches but not to others, this guide identifies exactly which switches are supported and which are not.

Although many different software and hardware configurations are tested and supported by Brocade Communications Systems, Inc. for Network OS, documenting all possible configurations and scenarios is beyond the scope of this document.

The following hardware platforms are supported by this release of Network OS:

- Brocade VDX 2741
- Brocade VDX 2746
- Brocade VDX 6740
 - Brocade VDX 6740-48
 - Brocade VDX 6740-64
- Brocade VDX 6740T
 - Brocade VDX 6740T-48
 - Brocade VDX 6740T-64
 - Brocade VDX 6740T-1G
- Brocade VDX 6940-36Q
- Brocade VDX 6940-144S
- Brocade VDX 8770
 - Brocade VDX 8770-4
 - Brocade VDX 8770-8

To obtain information about a Network OS version other than this release, refer to the documentation specific to that version.

Using the Network OS CLI

For complete instructions and support for using the Network OS command line interface (CLI), refer to the *Network OS Command Reference*.

What's new in this document

This document supports Network OS 7.0.0; and the following changes are made in this release:

- Added 100 Gb ports support for Brocade VDX 6940-144S.
- Added dual personality port feature for Brocade VDX 6940-144S.

For complete information, refer to the Release Notes.

Software Licensing Overview

- [Licensing overview](#)..... 11
- [How software licensing works](#)..... 11
- [License types](#)..... 12
- [Software licensing terminology](#)..... 12
- [License requirements](#)..... 13
- [Licensing restrictions and considerations](#)..... 16
- [Obtaining a license](#)..... 17
- [Viewing software license information from the Brocade software portal](#)..... 19

Licensing overview

The Brocade Network Operating System (Network OS) includes platform support in Brocade VCS Fabric modes as well as optional features that are enabled by license keys. You can purchase Brocade licenses per product or per feature. Each switch in a fabric must have its own licenses, but universal licenses for multiple switches are available for trial purposes along with individual trial licenses. Licenses may be part of the licensed paperpack supplied with your switch software, or you can purchase them separately from your switch vendor.

NOTE

The VCS Fabric license is enabled on all VDX platforms by default starting with Network OS 4.1.0; a VCS Fabric license does not need to be installed to enable VCS Fabric functionality.

How software licensing works

A permanent license (for select features on specific units) can be ordered pre-installed in a Brocade switch when first shipped from the factory, or later ordered and installed. In either case, additional licenses can be ordered as needed.

When a license is ordered separately (not pre-installed), an entitlement certificate or e-mail message along with a transaction key are issued to you by Brocade as proof of purchase. The transaction key and license ID (LID) of the Brocade switch are used to generate a license key from the Brocade software licensing portal. The license key is contained within the license file, which is downloaded to your PC. You can add the license key to a switch using the **license add** command. Once a license is installed on the Network OS switch, you may be prompted to reload the switch or to disable and re-enable the chassis or specific ports to activate the license.

When a time-based license expires, the commands and CLI related to the feature are disabled, but the feature itself cannot be disabled until the system reloads. You can display expired licenses with the **show license** command. Expired licenses display a "License has expired" message. RASLog warning messages are generated every hour for licenses that have expired or will expire in the next five days.

License types

The following license types are supported in Network OS:

- Permanent licenses - A permanent license (also referred to as a chassis-wide license) has no expiration date and is locked to a single switch identified by the switch license ID. The switch license ID is initially the same as the switch World Wide Name (WWN). The switch WWN may change through configuration changes on the product, but the switch license ID remains unchanged.
- Temporary licenses - A temporary license (also known as a time-based license) allows you to evaluate a feature for a limited time prior to buying a permanent license. Brocade offers the following types of temporary licenses:
 - Individual time-based licenses - An individual time-based license is locked to a single switch and has a fixed expiration date. You cannot install this license on multiple switches.
 - Universal time-based licenses - A universal time-based license allows you to use a given feature for a limited trial period defined in days, for example, 30, 60, or 90 days from the date you install the license key on the switch. Each universal license key is valid for a single feature and can be used on any product that supports the feature. In addition, each universal time-based license has an absolute shelf life after which it expires. You cannot install a license with an expired shelf life. The expiration date is based on the system time at the installation of the license plus the number of days that the universal time-based license is valid. For this reason, you cannot remove and re-install a universal time-based license.

Software licensing terminology

The following terms are used in this document:

- Entitlement certificate - The proof-of-purchase certificate (*paperpack or e-license*) issued by Brocade when a license is purchased. The certificate contains a unique transaction key that is used in conjunction with the license ID (LID) of the Brocade device to generate and download a software license from the Brocade software portal.
- License file - The file produced by the Brocade software portal when the license is generated. The file is uploaded to the Brocade device and controls access to a licensed feature or feature set.
- License ID (LID) - The identification number that uniquely identifies the Brocade device. The LID is used in conjunction with a transaction key to generate and download a software license from the Brocade software portal. The software license is tied to the LID of the Brocade device for which the license was ordered and generated.

NOTE

The License ID is not applicable for non-node locked licenses.

- Licensed feature - Any hardware or software feature or set of features that require a valid software license in order to operate on the device.
- Transaction key - A unique key, along with the LID, used to generate a software license from the Brocade software portal. The transaction key is issued by Brocade when a license is purchased. The transaction key is delivered according to the method specified when the order is placed:
 - Paperpack - The transaction key is recorded on an entitlement certificate, which is mailed to the customer.
 - Electronic - The transaction key is contained in an e-mail message, which is sent instantly to the customer after the order is placed. The customer receives the e-mail message within a few

minutes after the order is placed, though the timing will vary depending on the network, Internet connection, and so on.

If a delivery method is not specified at the time of the order, the key will be delivered by the way of paperpack.

License requirements

The following table lists the license requirements by platform.

TABLE 1 License requirements by platform

Platform	100 Gb DCB ports	40 Gb DCB ports	10 Gb DCB ports	1 Gb DCB ports	16 Gb FC ports	License type	POD sets and sizes	Notes
VDX 6740 and 6740T	N/A	4	48	N/A	N/A	FCoE, 10 GbE Port Upgrade, 40 GbE Port Upgrade	8 + 8 + 8 (10 Gb ports) 2 + 2 (40 Gb ports)	10 GbE Port Upgrade adds ports in 8-port increments to the standard 24 10 GbE ports. 40 GbE Port Upgrade adds ports in 2-port increments.
VDX 6740T-1G	N/A	4	0	48	N/A	FCoE, 10GbE Port Upgrade, 40 GbE Port Upgrade	8 + 8 + 8 (10 Gb ports) 2 (40 Gb ports)	10 GbE Port Upgrade converts 1 GbE ports to 10 GbE operation in 8-port increments to the standard 24 10 GbE ports. 40 GbE Port Upgrade license increments the standard two 40 GbE ports to four 40 GbE ports.
VDX 6940-36Q	N/A	36	0	N/A	N/A	FCoE, 40 GbE Port Upgrade	12 (40 Gb ports)	40 GbE Port Upgrade license increments the standard 24 40 GbE ports to 36 40 GbE ports.

TABLE 1 License requirements by platform (Continued)

Platform	100 Gb DCB ports	40 Gb DCB ports	10 Gb DCB ports	1 Gb DCB ports	16 Gb FC ports	License type	POD sets and sizes	Notes
VDX 6940-144S	4	12	96	N/A	N/A	FCoE, 10GbE Port Upgrade, 40 GbE Port Upgrade	16 + 16 (10 Gb ports) 6 + 6 (40 Gb ports)	10 GbE Port Upgrade adds ports in 16-port increments to the standard 64 10 GbE ports. 40 GbE Port Upgrade adds ports in 6-port increments. The dual personality port feature for the Brocade VDX 6940-144S allows ports 97, 98, 103, and 104 to be configured as 40 GbE QSFP+ or 100 GbE QSFP28 ports provided appropriate transceivers are installed. 100 Gb ports are licensed using the 40 GbE Port Upgrade license.
VDX 8770-4	N/A	48	192	288	N/A	FCoE, Layer 3, Advanced Services, 100G Port Upgrade	N/A	
VDX 8770-8	N/A	96	384	576	N/A	FCoE, Layer 3, Advanced Services, 100G Port Upgrade	N/A	

The following table provides descriptive details for each license type.

TABLE 2 Brocade licenses for optional Network OS features

License	Description
FCoE • FCOE_BASE	<p>A Brocade FCoE license is required to enable Fibre Channel over Ethernet functionality. You can use this license on a single switch, but the FCoE capabilities will be limited to that node only. To support multi-hop FCoE traffic, you must enable VCS Fabric mode and install a Brocade FCoE license on each node. A VCS fabric in excess of two nodes requires the FCoE license on each node to allow FCoE traffic to traverse all nodes in the fabric.</p> <p>Without an FCoE license, Fibre Channel ports cannot be enabled, FCoE logins are not permitted, FCoE traffic does not transit the switch, and most FCoE commands return an error of "No FCoE license present" when executed.</p>

TABLE 2 Brocade licenses for optional Network OS features (Continued)

License	Description
Layer 3 • LAYER_3	<p>On all Brocade VDX compact switches, Layer 3 features are automatically enabled and do not require a license. On modular switches (Brocade VDX 8770-4 and Brocade VDX 8770-8), you must install a Layer 3 or Advanced Services license to activate the following Layer 3 features:</p> <ul style="list-style-type: none"> • OSFP • VRRP • PIM-SM • Route-maps • Prefix-List • Virtual Routing and Forwarding (VRF) <p>No license is required for the following Layer 3 features:</p> <ul style="list-style-type: none"> • IGMP Snooping • Layer 3 ACL • Layer 3 QoS • RTM/Static routes • Interface IP address • ARP • IP Services (ping/Telnet/FTP) <p>Brocade Layer 3 licenses are independent of any other licenses or operating modes in the fabric. Brocade Layer 3 licenses are required only on modular switches, and only on those switches in the fabric that have interfaces attached that will use the additional licensed Layer 3 features. Any intermediate switches in the fabric between interfaces do not require the license to be installed.</p> <p>Layer 3 features are only supported in VCS mode.</p>
Advanced Services • ADVANCED_SERVICES	<p>For the Brocade VDX 8770 platforms, you have the option of purchasing and installing a single license key that will activate FCoE and Layer 3 features in one convenient bundle. You may also purchase and install each license separately.</p>
10 GbE Port Upgrade • PORT_10G_UPGRADE	<p>License function depends on the switch model:</p> <ul style="list-style-type: none"> • For the Brocade VDX 6740 and VDX 6740T, this license adds 10 GbE ports in increments of eight ports (8, 16, 24) per license. For Brocade VDX 6740, the SFP+ ports operate at 1 Gbps, 10 Gbps, or auto-sensing mode and VDX 6740T RJ45 ports operate at 100 Mbps, 1 Gbps, 10 Gbps, or auto-sensing mode. • For the Brocade VDX 6740T-1G, this license upgrades existing 1 GbE ports to 1/10 GbE operation in increments of 8 ports (8, 16, 24) per license. VDX 6740T-1G ports operate at 100 Mbps, 1 Gbps, or auto-sensing mode. When upgraded with the 10 GbE Port Upgrade license, 6740T-1G ports operate at 100 Mbps, 1 Gbps, 10 Gbps. • For the Brocade VDX 6940-144S, as the switch ships with 64 10 GbE ports, the license is available in two 16-port increments to provide 96 total ports.
40 GbE Port Upgrade • PORT_40G_UPGRADE	<p>License function depends on the switch model:</p> <ul style="list-style-type: none"> • For the Brocade VDX 6740 and VDX 6740T, this license adds 40 GbE ports in increments of two ports (2, 4) per license to provide four total ports. • For the Brocade VDX 6740T-1G, as the switch ships with two 40 GbE ports, the license is available in a single two-port increment to provide four total ports. • For the Brocade VDX 6940-36Q, as the switch ships with twenty four 40 GbE ports, the license is available in a single 12-port increment to provide 36 total ports. • For the Brocade VDX 6940-144S, this license adds 40 GbE ports in increments of six ports (6, 12) per license to provide 12 total ports.
100G Port Upgrade • PORT_100G_UPGRADE	<p>For the 100G line card with two base 100 GbE ports enabled, the 100G Port Upgrade license enables the remaining four ports for a total of six 100 GbE ports.</p>

Licensing restrictions and considerations

This section lists the generic rules, restrictions, and considerations related to the software licensing:

- A license is tied to the unique LID of the blade or the switch for which the license was generated. Therefore, a license can be used on one switch only. It cannot be used on any other switch.
- More than one license for multiple features can be installed per switch.
- Only one permanent or temporary license at a time can be in effect for a licensed feature.
- More than one trial license can be in effect at the same time, as long as each trial license applies to a unique licensed feature.
- A trial license cannot replace or supersede a normal license.
- Licenses are not interchangeable between units.
- License management in Network OS v3.0.0 and earlier is supported only on the local RBridge. You cannot configure or display licenses on remote nodes in the fabric. Later Network OS releases that support Logical Fabric mode allow fabric-wide license configuration and display.

Usage restrictions for time-based licenses

The following restrictions apply to all time-based licenses:

- Time-based licenses are always retained in the license database and cannot be deleted.
- Once you have installed a time-based license, you cannot change the system date or time.
- Other mechanisms for changing date and time, such as Network Time Protocol (NTP), are not blocked. If you are using NTP to synchronize the time between your network devices, including switches or enterprise-class platforms, do not attempt to change the system date and time when a time-based license is installed.

Configuration management considerations

Licenses are independent of configuration files and are therefore not affected when you make changes to a configuration file or restore the default configuration. The only exceptions are Dynamic POD configurations. When you download a configuration from another switch or you restore the default configuration, the Dynamic POD configuration is moderated and restricted by whatever POD licenses are present on the switch.

For example, if you download a configuration file from a switch that has POD assignments beyond the base number of allowed Dynamic POD ports and there is no POD license installed, then the additional ports beyond the number of ports in the base Dynamic POD set will not be allowed. When the configuration is played back as part of the copy (or reboot) operation, the licenses are checked for each additional Dynamic POD port that attempts to be assigned a reservation.

Upgrade and downgrade considerations

Downgrading from Network OS v4.1.0 to previous versions without a VCS Fabric license results in loss of VCS functionality.

Downgrading from Network OS v5.0.0 to a previous version is applicable to the Brocade VDX 6740. The Brocade VDX 8770 chassis only supports Network OS v3.0.0 and later. The Brocade VDX 6940-36Q chassis only supports Network OS v6.0.0 and later. There are no downgrade pre-installation requirements for any of the licensed features in Network OS v5.0.0.

You cannot downgrade to Network OS v2.x when the switch is in Brocade VCS Fabric mode without full POD licenses installed. Network OS v2.x requires full POD licenses to be installed when the switch is in Brocade VCS Fabric mode.

If Dynamic POD reserve port configuration data is stored in the running-config file before you downgrade to Network OS v2.x, restoring that running-config file after downgrade does not restore the Dynamic POD reserve port information.

Obtaining a license

Use the following procedure to generate and obtain a software license.

1. Order a license for the desired licensed feature.

NOTE

To obtain a trial license, contact your Brocade representative.

2. When you receive the paperpack or electronic transaction key, retrieve the LID of your Brocade device by entering the **show license id** command on the device or by reading the LID from the label on the unit. If you received a paperpack transaction key, write the LID in the space provided on the entitlement certificate.

NOTE

Do not discard the entitlement certificate or e-mail with the electronic key. Keep it in a safe place in case it is needed for technical support or product replacement (RMAs).

3. Log in to the Brocade software licensing portal at <http://swportal.brocade.com> and complete the software license request. If you do not have a login ID and password, request access by following the instructions on the screen.

The following figure shows the software licensing portal login window.

FIGURE 1 Brocade software licensing portal login window

4. From the **License Management** menu, select **Brocade NOS > License Generation with Transaction key**.

The **Brocade NOS License Generation** window displays.

FIGURE 2 Brocade Network OS License Generation window

Brocade NOS License Generation

Please check the Unique ID to make sure it is correct! License install failure may result!

Customer Information	
* Indicates required field	
Customer email ID *	<input type="text"/>
Site Name	<input type="text"/>
Technical Contact	<input type="text"/>
Company Name	<input type="text"/>
City	<input type="text"/>
State/Province	<input type="text"/>
Zip/Postal Code	<input type="text"/>
Country	Select Country ▼
Phone	<input type="text"/>

Unit Information	
Unique ID Type*	License ID(LID) ▼
Unit's Unique ID*	<input type="text"/>
Transaction Key*	<input type="text"/>
<input type="button" value="Add"/>	

I have read and accept the [Brocade End User License Agreement](#)

- Enter the requested information in the required fields. An asterisk (*) next to a field indicates that the information is required.

NOTE

You can generate more than one license at a time. For each license request, enter the **Unit's Unique ID** and **Transaction Key**, and click **Add**.

- When you have finished entering the required information, read the Brocade End User License Agreement, and select the **I have read and accept** check box.
- Click the **Generate** button to generate the license.

The results window displays an order summary and the results of the license request.

 - If the license request is successful, the **Status** field shows "Success" and the **License File** field contains a hyperlink to the generated license file. The license file is automatically sent by e-mail to the specified customer e-mail address.
 - If the license request fails, the **Status** field indicates the reason it failed and the action to be taken.
- Download the license file to your PC by either clicking the hyperlink in the **License File** field or saving the license file from the e-mail attachment.
- Install the license on the Network OS switch by following the procedure in [Installing a license](#) on page 21.

Viewing software license information from the Brocade software portal

This section describes other software licensing tasks supported from the Brocade software portal. You can use the **Unit License Query** option to view software license information for a particular unit, transaction key, or both. You can export the report to Excel for sharing or archiving purposes.

Depending on the status of the license (for example, whether or not the license was generated), the report will include the following information:

- Hardware part number, serial number, and description
- Software part number, serial number, and description
- Date the license was installed
- Transaction key
- LID
- Feature name
- Product line

Use the following procedure to view the license information from the Brocade software portal.

1. To view the license information, select **License Management > Brocade NOS > Unit License Query**.

The **NOS Unit License Query** window displays.

FIGURE 3 License Query window

The screenshot shows the Brocade NOS Unit License Query window. The window has a header with the Brocade logo and navigation tabs for License Management, Reports, and Administration. The main content area is titled "NOS Unit License Query" and contains a form with three input fields: "ID Type" (a dropdown menu set to "License ID(LID)"), "Unit ID", and "Transaction key". Below the form are "Search" and "Cancel" buttons.

2. Enter the LID in the **Unit ID** field and the unique number in the **Transaction key** field, and click **Search**.

In the **NOS Unit License Query** results window, the line items for Level 1 display hardware-related information and the line items for Level 2 display software-related information. If the query was performed before the license key was generated, the first row (Level 1) would not appear as part of the search results. Similarly, if the query was performed before the license was generated, some of the information in the second row would not be displayed.

Viewing software license information from the Brocade software portal

Licensing Tasks

- Installing a license..... 21
- Displaying a license 22
- Displaying the switch license ID..... 23
- Removing licenses..... 23
- Extending a time-based license..... 24
- Troubleshooting licensing issues..... 24

Installing a license

Use the following procedures to install licenses on a Network OS switch.

1. Install the license on the switch using one of the following commands:

- Enter the **license add [FTP-URL *ftpPath* | SCP-URL *scpPath*]** command and optionally, an RBridge ID if you are installing the license on a remote switch. This command adds licenses from an XML-tagged license file.

```
switch# license add FTP-URL ftp://fvt:brocadeserver@10.10.2.7/license.xml
rbridge-id 1
```

```
License Added [*B
UpXEbpegY7wCm0VfViqXLK:vdAFbcIVcEmVuTaiih3V8wzTPV7TCDq8WMHLRPPbifU5ZSVppjMLE, sb9A
ZeDTtfxKS5gKvRWgMN37xAMJuunVJ#]
```

- Enter the **license add licstr** command followed by the license key and, optionally, an RBridge ID if you are installing the license on a remote switch. The license key is printed between the XML start `<licKey>` and end `</licKey>` tags in the license file. Be sure to copy the entire string, including spaces and non-alphanumeric characters. If the license key includes spaces, you must enclose the entire string in double quotation marks. Repeat this command for each software license key found in the license file.

```
switch# license add licstr
"*B :YFGuJSHxbhlWVwBHjmjFAO20R6QzolkyVR4oqJAU0fghJRCTioav1A:
HMah2E7uL4d8px4ySTAWSg809etcLwfpLjgXZ11vWiiKEWcfcZMefx#"
```

```
License Added [*B :YFGuJSHxbhlWVwBHjmjFAO20R6QzolkyVR4oqJAU0fghJRCTioav1A:
HMah2E7uL4d8px4ySTAWSg809etcLwfpLjgXZ11vWiiKEWcfcZMefx#]
```

NOTE

Remote management of licenses is supported in Logical Chassis mode.

2. Verify that you added the license by entering the **show license** command. The command lists all licensed features currently installed on the switch. If the feature is not listed, enter the **license add licstr** command again.

Depending on the license type, you may be prompted to reload the switch or to disable and re-enable the chassis or specific ports. The following table indicates the minimal steps you may need to take to make the installed features fully functional after the license add operation is complete. Take the appropriate action as indicated by the command output.

TABLE 3 Requirements for activating a license after installation

License	Description
FCOE_BASE	You must enable any Fibre Channel (FC) ports that you wish to use (applicable only if the product includes FC ports). After installing a license, configure the FC port with the no shutdown command for the port to come online.
LAYER_3	One of the following actions may be required depending on the configuration: <ul style="list-style-type: none"> Enabling the ports or the chassis Disabling and then re-enabling the ports or the chassis
ADVANCED_SERVICES	Combines requirements for FCoE, Layer 3, and VCS licenses.
PORT_10G_UPGRADE	For all applicable platforms, may require enabling the added ports or disabling and then re-enabling the added ports.
PORT_40G_UPGRADE	For all applicable platforms, may require enabling the added ports or disabling and then re-enabling the added ports.
PORT_100G_UPGRADE	Requires enabling the added ports.

Adding an FCoE license

The following example adds an FCoE license on the local switch and verifies the transaction.

```
switch# license add licstr
"*B :YFGuJSHxbhlWVwBHjmjFAO20R6QzolkYVR4oqJAU0fghJRCTioav1A:
HMah2E7uL4d8px4ySTAWsg809etcLwfpLjgXZ11vWiiKEWcfcZMefx#"

License Added [*B :YFGuJSHxbhlWVwBHjmjFAO20R6QzolkYVR4oqJAU0fghJRCTioav1A:
HMah2E7uL4d8px4ySTAWsg809etcLwfpLjgXZ11vWiiKEWcfcZMefx#]
switch# show license
Rbridge-Id: 2
xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
FCoE Base license
Feature name:FCOE_BASE
License is valid
```

Displaying a license

You display installed licenses with the **show license** command.

The following example displays a Brocade VDX 8770 licensed for a Layer 3 VCS fabric. This configuration does not include FCoE features.

```
switch# show license
rbridge-id: 60
xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
Layer 3 license
Feature name:LAYER_3
License is valid
```

The following example displays a Brocade VDX 8770 licensed for Advanced Services. This configuration enables the use of Layer 3, FCoE, and VCS features.

```
switch# show license
rbridge-id: 60
```

```

XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
Advanced Services license
Feature name:ADVANCED_SERVICES

```

Displaying the switch license ID

The switch license ID identifies the switch for which the license is valid. You will need the switch license ID when you activate a license key.

To display the switch license ID, enter the **show license id** command in privileged EXEC mode.

```

switch# show license id
Rbridge-Id          License ID
=====
2                   10:00:00:05:33:54:C6:3E

```

Removing licenses

Depending on the license type, you may be prompted to clear license-dependent configurations, reload the switch, or disable and re-enable the chassis or specific ports. The following table indicates the minimal steps you may need to take to remove specific licenses. Take the appropriate action as indicated by the command output.

TABLE 4 Requirements for deactivating a license after removal

License	Description
FCOE_BASE	Disabling all Fibre Channel (FC) ports is required before you can remove the license (applicable only if the product includes FC ports).
LAYER_3	Clearing of Layer 3 configurations on all ports is required before you can remove the license.
ADVANCED_SERVICES	Combines requirements for FCoE and Layer 3 licenses.
PORT_10G_UPGRADE	Port reservations for non-Base ports provisioned by the license must be released first. Removal of a port reservation provisioned by this license is blocked if the port is in a configuration not allowed on a 1 GbE port, such as Brocade Trunking or FCoE.
PORT_40G_UPGRADE	Port reservations for non-Base ports provisioned by the license must be released first.
PORT_100G_UPGRADE	You must manually disable all except two 100G ports on each of the 2x100G Line Cards for which the license was installed.

For some licensed features, you must clear all configurations related to a the feature before you can remove the license for that feature. Some features may require that you reboot the switch and others require you to disable and re-enable selected ports or the entire switch.

For example, removing an FCoE license requires both explicit reset to default of FCoE settings that depend on the license, as well as disabling all FC ports on the platform; all FC ports must be set to a "shut" interface configuration state before the license can be removed.

Refer to the console output for other specific requirements.

Do the following to remove a license.

1. Enter the **show license** command to display the active licenses.
2. Issue the **license remove** command followed by the license key or the feature name.

The license key is case-sensitive and must be entered exactly as shown. If the license key includes spaces, you must enclose the entire string in double quotation marks.

3. Take the appropriate action as indicated by the command output.

Depending on the license type, you may be prompted to clear license-related features, to reboot the switch, or to disable and re-enable the chassis or specific ports.

4. Enter the **show license** command to verify that the license is removed. If there are no license keys, the command output displays "No licenses."

NOTE

You must remember the original license string to use the **license remove** command with the *licenseString* operand. You cannot display the license key with the **show license** command.

The following example illustrates the display and removal of an FCoE license by its feature name.

```
switch# show license
Rbridge-Id: 2
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
  FCoE Base license
  Feature name:FCOE_BASE
  License is valid
switch# license remove licstr "FCOE_BASE"
License Removed [FCOE_BASE]
For license to take effect, enable the switch and any disabled ports...
```

The remaining licenses are displayed as shown in the following example.

```
switch# show license
Rbridge-Id: 2
No entries available for rbridge-id 2
```

Extending a time-based license

You extend a time-based license by adding another temporary license or by installing a permanent license. Re-installing a temporary license that has expired is not permitted. When you replace an expired license, the warning messages cease.

Troubleshooting licensing issues

Some features require licenses in order to work properly. Licenses are created using a switch license identifier (LID), so you cannot apply one license to different switches. Before calling your switch support provider, verify that you have the correct licenses installed by using the **show license** command.

License is not properly installed

If a licensed feature is not functioning, a probable reason is that the license for that feature has not been installed correctly. Either the license was not installed, or it was installed and a required system reboot was not performed.

If you are unable to connect an FCoE device or unable to use Fibre Channel ports on a Brocade VDX switch, it is likely that the FCoE license is not installed.

If you suspect a license is not properly installed, complete the following steps.

1. In privileged EXEC mode, enter the **show license** command to display the currently installed licenses.

```
switch# show license
rbridge-id: 66
xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx
  FCoE Base license
  Feature name:FCOE_BASE
  License is valid
```

2. If the FCoE or DPOD license appears in the **show license** command output, but the feature does not work for the expected ports, the probable cause is that the affected ports were not re-enabled after installing the license.

NOTE

After adding an FCoE or DPOD license, you must disable and re-enable all affected ports.

You can disable and then enable each affected port, or you can enter the **chassis disable** command followed by the **chassis enable** command to re-enable the entire chassis.

```
switch# chassis disable
switch# chassis enable
```

3. If the license does not appear in the **show license** command output, then it was not installed. In privileged EXEC mode, enter the **license add licstr** command to install the license. For FCoE and DPOD licenses, you must also disable and enable the switch or port.

```
switch# license add licstr "*"B
s1SETgzTgeVGUDeQR4WIfrx7mmXODdSwENoRGEAmX3Ca3uHeZgXK0b,jzxyzfzKLrMsPN8ClSxvDQRRT8V
yuULyyKT00ryU6qm4s1jjiSAeV,COedzCxl6ycQgnYMeSVp#"
License Added [*B
s1SETgzTgeVGUDeQR4WIfrx7mmXODdSwENoRGEAmX3Ca3uHeZgXK0b,jzxyzfzKLrMsPN8ClSxvDQRRT8V
yuULyyKT00ryU6qm4s1jjiSAeV,COedzCxl6ycQgnYMeSVp# ]
For license change to take effect, please disable/enable port or switch...
switch# chassis disable
switch# chassis enable
```

License is not properly installed

Dynamic Ports on Demand Licensing

- [Dynamic Ports on Demand overview](#)..... 27
- [Managing automatic POD port assignments](#)..... 28
- [Mapping port assignments to a POD port set](#)..... 28
- [Activating the Dynamic POD feature](#) 28
- [Adding a Dynamic POD license](#)..... 29
- [Displaying the Dynamic POD assignments](#)..... 30
- [Overriding Dynamic POD assignments](#)..... 31
- [Configuring dual personality ports](#)..... 32

Dynamic Ports on Demand overview

Dynamic Ports on Demand (POD) provides a flexible mechanism for allocating port licenses that you can purchase to extend the base functionality of the Brocade VDX 6740 and 6940-family switches. The additional ports can be enabled after you install the appropriate license keys. The Dynamic POD feature assigns port licenses based on your connectivity choices. Any port on the switch can claim a free assignment from the pool of available POD licenses.

NOTE

Dynamic POD licenses are not supported on the Brocade VDX 8770. The Dynamic POD licenses are not used to manage FC ports on the VDX platform either (only the Base FCOE is used to license these ports). When adding a Dynamic POD license to a platform that does not support Dynamic POD, you will be allowed to add the license, but the license display will show that the Dynamic POD license is not supported on the platform.

In a Dynamic POD system, each port can be associated with one of two port sets:

- Base port set — Ports that can be enabled without any Port Upgrade license.
- Port Upgrade license port set — Ports that are assigned after all the Base port set have been used or assigned; these are associated with the existence of a Port Upgrade license.

NOTE

The 10 GbE and 40 GbE Port Upgrade licenses are supported using a base port set plus the ports that are available as specified by the port capacity in the respective port upgrade. These licenses are supported only on the Brocade VDX 6740, VDX 6740T, VDX 6740T-1G, VDX 6940-36Q, and VDX 6940-144S switches.

NOTE

Licenses are based on the license ID and are not interchangeable between units.

You can purchase the Brocade VDX 6740T-1G switches with the port options listed in the following table. You can activate unlicensed ports up to the maximum supported per switch by purchasing and installing additional POD licenses.

Managing automatic POD port assignments

With the Dynamic POD feature, you can use the base port set plus the number of additional ports you purchased. All ports that do not receive a POD assignment and are trying to come online will go offline. The **show ip interface brief** and **show interface tengigabitethernet rbridge-id/slot/port** commands display the reason for the port-disabled status as related to POD licensing.

The Dynamic POD mechanism detects the ports that have active links, and makes assignments based on the remaining pool of vacancies:

- If the count of assigned ports is below the number of ports in the purchased POD set, additional dynamic assignments can be made at a later time as new links are established. If a port comes online, that port can get assigned if you still have vacancies in your POD set.
- If the number of detected active links is greater than the number of ports in the purchased POD set, port assignments are made in the order in which the ports come online until the purchased limit is reached. Because the time it takes for each port to come online varies, the order in which ports are assigned to a given POD set cannot be guaranteed.

If the given assignment order does not align with your intended use of the ports, you can make adjustments using the **dpod rbridge-id/slot/port reserve** or the **dpod rbridge-id/slot/port release** commands. Refer to [Overriding Dynamic POD assignments](#) on page 31 for more information.

Mapping port assignments to a POD port set

For all platforms that support DPOD, except the 6740T-1G, ports are associated with the Port Upgrade license in the order in which they come online and automatically receive a license assignment from the pool of unassigned ports in the POD set. The first ports that receive a POD assignment are associated with the base port set. When all ports in the base port set are assigned, the next ports that come online receive assignments from the Port Upgrade license port set.

The association of a specific port to a POD set matters only when you want to remove a Port Upgrade license from the system. Sufficient assigned ports must be released from the DPOD Port Upgrade reservations before the license can be removed. Refer to [Releasing a port from a POD set](#) on page 31 for more information.

Activating the Dynamic POD feature

Use the following procedure to activate the Dynamic POD feature.

1. Verify the current states of the ports with the **show ip interface brief** command.

The command output indicates whether a port is licensed.

2. Install the Brocade Dynamic POD license.
3. Use the **shutdown** and **no shutdown** commands to disable and re-enable the ports.

Alternatively, you can disable and re-enable the chassis to activate ports.

4. Use the **show ip interface brief** command to verify the newly activated ports.
5. Use the **show interface tengigabitethernet rbridge-id/slot/port** command to display port details.

The following example shows a Brocade VDX 6720-24 without a Dynamic POD license installed. The 16 ports in the base port set are online and assigned. The remaining 8 ports are unassigned and are down.

```
switch# show ip interface brief
Interface          IP-Address      Status          Protocol
=====          =
TengigabitEthernet 5/0/1  unassigned    up              up
TengigabitEthernet 5/0/2  unassigned    up              up
TengigabitEthernet 5/0/3  unassigned    up              up
TengigabitEthernet 5/0/4  unassigned    up              up
TengigabitEthernet 5/0/5  unassigned    up              up
TengigabitEthernet 5/0/6  unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/7  unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/8  unassigned    up              up
TengigabitEthernet 5/0/9  unassigned    up              up
TengigabitEthernet 5/0/10 unassigned    up              up
TengigabitEthernet 5/0/11 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/12 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/13 unassigned    up              up
TengigabitEthernet 5/0/14 unassigned    up              up
TengigabitEthernet 5/0/15 unassigned    up              up
TengigabitEthernet 5/0/16 unassigned    up              up
TengigabitEthernet 5/0/17 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/18 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/19 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/20 unassigned    administratively down down (No DPOD License)
TengigabitEthernet 5/0/21 unassigned    up              up
TengigabitEthernet 5/0/22 unassigned    up              up
TengigabitEthernet 5/0/23 unassigned    up              up
TengigabitEthernet 5/0/24 unassigned    up              up
```

The following example displays details for a single port that is offline because it does not have a Dynamic POD license.

```
switch# show interface tengigabitethernet 5/0/6
TengigabitEthernet 5/0/6 is down, line protocol is down (No DPOD License)
Hardware is Ethernet, address is 0005.1eb6.0a25
Current address is 0005.1eb6.0a25
Tracking status: Disabled
Tracked interfaces: None
Pluggable media present, Media type is sfp
Interface index (ifindex) is 1744896001
MTU 2500 bytes
LineSpeed: Auto - 10000 Mbit, Duplex: Full
Flowcontrol rx: on, tx: on
```

Adding a Dynamic POD license

The following example adds a second Dynamic POD license on the local switch and verifies the transaction. The command prompts you to disable and then re-enable the port or the switch.

```
switch# license add licstr "*"B s1SETgzTgeVGUDeQR4WIfRx7mmXODdSwENoRGENAmX3Ca3uHeZgXK0b,
jzxyzfzKLRmSPN8ClSxvDQRRt8VyuULyyKTO0ryU6qm4s1jjiSAeV,COoedzCx1v6ycQgnYMeSVp#"
License Added [*B s1SETgzTgeVGUDeQR4WIfRx7mmXODdSwENoRGENAmX3Ca3uHeZgXK0b,
jzxyzfzKLRmSPN8ClSxvDQRRt8VyuULyyKTO0ryU6qm4s1jjiSAeV,COoedzCx1v6ycQgnYMeSVp# ]
For license change to take effect, please disable/enable port or switch...
switch# chassis disable
switch# chassis enable
switch# show license
Rbridge-Id: 2
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
  First Ports on Demand license - additional 10 port upgrade license
  Feature name:PORTS_ON_DEMAND_1
  License is valid
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
  Second Ports on Demand license - additional 10 port upgrade license
  Feature name:PORTS_ON_DEMAND_2
  License is valid
```

Displaying the Dynamic POD assignments

To display the Dynamic POD assignments, enter the **show dpod** command.

The **show dpod** command provides a summary of POD license status and POD license assignments.

In the following example from VDX 6720-24, all 24 ports are licensed and potentially available. The three unassigned ports are currently persistently disabled and therefore are not assigned to any Dynamic POD license port set.

```
switch# show dpod
rbridge-id: 1
24 ports are available in this switch
 1 POD license is installed
   Dynamic POD method is in use
24 port assignments are provisioned for use in this switch:
 16 port assignments are provisioned by the base switch license
  8 port assignments are provisioned by the first POD license
 * 0 more assignments are added if the second POD license is installed
21 ports are assigned to installed licenses:
 16 ports are assigned to the base switch license
  5 ports are assigned to the first POD license
Ports assigned to the base switch license:
 Te 1/0/1, Te 1/0/10, Te 1/0/11, Te 1/0/12, Te 1/0/13, Te 1/0/14, Te 1/0/15, Te 1/0/16, Te 1/0/17,
Te 1/0/18, Te 1/0/19, Te 1/0/20, Te 1/0/21, Te 1/0/22, Te 1/0/23, Te 1/0/24
Ports assigned to the first POD license:
 Te 1/0/5, Te 1/0/6, Te 1/0/7, Te 1/0/8, Te 1/0/9
Ports assigned to the second POD license:
 None
Ports not assigned to a license:
 Te 1/0/2, Te 1/0/3, Te 1/0/4
 3 license reservations are still available for use by unassigned ports
```

The following **show dpod** example is for VDX 6740.

```
switch# show dpod
rbridge-id: 1
 48 10G ports are available in this switch
  4 40G ports are available in this switch
 10G Port Upgrade license is installed
No 40G Port Upgrade license is installed
   Dynamic POD method is in use

48 10G port assignments are provisioned for use in this switch:
 24 10G port assignments are provisioned by the base switch license
 24 10G port assignments are provisioned by the 10G Port Upgrade license
 1 10G port is assigned to installed licenses:
   1 10G port is assigned to the base switch license
   0 10G ports are assigned to the 10G Port Upgrade license
10G ports assigned to the base switch license:
 1/0/48
10G ports assigned to the 10G Port Upgrade license:
 None
10G ports not assigned to a license:
 1/0/1, 1/0/2, 1/0/3, 1/0/4, 1/0/5, 1/0/6, 1/0/7, 1/0/8, 1/0/9, 1/0/10
 1/0/11, 1/0/12, 1/0/13, 1/0/14, 1/0/15, 1/0/16, 1/0/17, 1/0/18, 1/0/19, 1/0/20
 1/0/21, 1/0/22, 1/0/23, 1/0/24, 1/0/25, 1/0/26, 1/0/27, 1/0/28, 1/0/29, 1/0/30
 1/0/31, 1/0/32, 1/0/33, 1/0/34, 1/0/35, 1/0/36, 1/0/37, 1/0/38, 1/0/39, 1/0/40
 1/0/41, 1/0/42, 1/0/43, 1/0/44, 1/0/45, 1/0/46, 1/0/47
47 license reservations are still available for use by unassigned ports

 0 40G port assignments are provisioned for use in this switch:
   0 40G port assignments are provisioned by the base switch license
 0 40G ports are assigned to installed licenses:
   0 40G ports are assigned to the base switch license
40G ports assigned to the base switch license:
 None
40G ports assigned to the 40G Port Upgrade license:
 None
40G ports not assigned to a license:
 1/0/49, 1/0/50, 1/0/51, 1/0/52
 0 license reservations are still available for use by unassigned ports
```

Overriding Dynamic POD assignments

You can override the automatic port license assignments by releasing Dynamic POD assignments from a port and by reserving an assignment for a specific port.

Reserving a port assignment

Reserving an assignment for a port assigns that port to a Ports on Demand (POD) license regardless of whether the port is online or offline. Reserving assignments allocates the POD license to specified ports. This operation overrides automatic port assignments. The reserved assignment will not be available to other ports that come online. To reserve an assignment for a port, a free assignment must be available.

1. Enter the **show dpod** command to determine the unassigned ports.

If all ports are assigned, select a port to release its POD assignment. Follow the instructions in [Releasing a port from a POD set](#) on page 31 to release a port from its POD assignment. Once the port is released, you can reuse the assignment for another port.

2. Enter the global configuration mode by issuing the **configure terminal** command.
3. Select the port for which you want to reserve an assignment and enter the **dpod reserve** command.
4. Enter the **exit** command to return to the global configuration mode before you reserve another port.

```
switch# configure terminal
Entering configuration mode terminal
switch(config)# dpod 5/0/10 reserve
switch(config-dpod-5/0/10)# exit
switch(config)# dpod 5/0/11 reserve
switch0(config-dpod-5/0/11)# exit
```

NOTE

License reservations or removals do not persist across switch reboots and power cycles when the switch is not in Logical Fabric mode. To make them persistent, save the configuration changes by issuing the use **copy running-config startup-config** command before you reboot the switch. In Logical Fabric mode reservations are automatically saved and persisted across reboots and power cycles.

5. Save the configuration changes.
6. Reboot the switch.
7. Enter the **show running-config dpod** command to verify the port is reserved.

```
switch# show running-config dpod 5/0/10
dpod 5/0/10
  reserve
  !
switch# show running-config dpod 5/0/11
dpod 5/0/11
  reserve
```

Releasing a port from a POD set

Once a port has been assigned to a Dynamic POD license port set, it remains licensed (or "reserved") until you remove the port from the port set. You remove a port from the port set by releasing the port with the **dpod release** command. Releasing a port removes it from the Dynamic POD license port set; the port appears as unassigned until it comes back online.

To prevent a port from coming back online and taking a POD assignment, disable the port and save the running configuration. This action will disable the port persistently.

A port POD assignment can only be released if the port is currently offline. Use the **shutdown** command to disable the port or use the **chassis disable** command to disable the switch if you plan to release multiple ports.

1. Enter the global configuration mode by issuing the **configure terminal** command.
2. Select the interface for the port that you wish to disable using the **interface** *rbridge-id/slot/port* command.
3. Enter the **shutdown** command to take the port offline.
4. Enter the **exit** command to return to the global configuration mode before you release the port.
5. Enter the **dpod release** command to remove the port from the POD license.
6. Enter the **exit** command to return to the global configuration mode before you reserve another port.

```
switch# configure terminal
Entering configuration mode terminal
switch(config)# interface 1/0/10
switch(conf-if-te-1/0/10)# shutdown
switch(conf-if-te-1/0/10)# exit
switch(config)# dpod 1/0/10 release
switch(config-dpod-1/0/10)# exit
```

7. Enter **exit** to return to privileged EXEC mode.
8. Enter the **show dpod** command to verify that the port is no longer assigned to a POD set.
9. Enter the **enable chassis** command to bring the switch back online.
10. Save the configuration changes (if not in Logical Chassis mode).

```
switch# copy running-config startup-config
```

NOTE

Do not release a port unless you plan to disconnect the optical link or disable the port persistently. If you leave the link in a state where the port could be brought online, the POD mechanism will detect this unassigned port and attempt to reassign it to a port set.

Configuring dual personality ports

The dual personality port feature for the Brocade VDX 6940-144S allows ports 97, 98, 103, and 104 to be configured as 40 GbE QSFP+ or 100 GbE QSFP28 ports provided appropriate transceivers are installed.

A dual personality port group consists of a row of 40 GbE ports located on the right side of the Brocade VDX 6940-144S front panel. There are four rows of ports, each row containing three ports. Although only the left-most port in each row operates as a dual personality port (100 GbE or 40 GbE), you configure the entire row for either 100 GbE or 40 GbE operation using the **mode** command. After enabling 100 GbE mode for a port group, the dual personality port operates at 100 GbE, while the remaining two ports in the row are disabled. After you enable 40 GbE mode for a port group, all ports in the row can operate at 40 GbE. For more details, refer to *Brocade VDX 6940 Hardware Installation Guide*.

The following example enables 100 GbE operation for port group 1 through 4:

1. Enter the global configuration mode by issuing the **configure terminal** command.
2. Select the interface for the port group using the **port-group** command.
3. Enter the **mode 100g** command to enable 100 GbE operation for the port group.

```
switch# configure terminal
Entering configuration mode terminal
switch(config)# hardware
switch(config-hardware)# port-group 1/0/1
```



```
switch(config-port-group-1/0/1)# mode 100g
2015/12/16-15:27:07, [NSM-1010], 13849, SW/0 | Active | DCE, INFO, sw0,
InterfaceMode
changed from None to L2 for interface FortyGigabitEthernet 1/0/97.
%Warning: port-group mode change is a disruptive command.
Please do linecard power-on or switch reload for the changes to take place.
```


Index

10 GbE Port Upgrade [13](#)
40 GbE Port Upgrade [13](#)

A

activating a license after installation [21](#)
activating POD [28](#)
Advanced Services [13](#)

B

Base Port Set [27](#)

C

configuration managemet [16](#)

D

display licenses [22](#)
Double POD License [27](#)
downgrade considerations [16](#)
Dynamic POD [16](#)
Dynamic POD license [13](#)
Dynamic Ports on Demand [27](#)

E

electronic transaction key [17](#)
extending a temporary license [24](#)

F

FCoE license [13](#)

G

generic rules [16](#)

I

individual time-based license [12](#)
installation example [22](#)
installing a POD license [29](#)
Installing licenses [21](#)

L

Layer 3 license [13](#)
license
 Dynamic Ports on Demand [13](#)
 permanent [13](#)
 platform requirements [13](#)
 removing [23](#)
 reservation [31](#)
 temporary [13](#)
 time-based [13](#)
license add [11](#), [21](#)
license file [11](#), [21](#)
License file [17](#)
license key [21](#)
license remove [23](#)
license remove feature [23](#)
License types [12](#)
licensing [11](#)

N

Network Time Protocol [16](#)

O

obtaining a software license [17](#)

P

paperpack [11](#), [17](#)
permanent license [11](#), [12](#)
POD, activating [28](#)
POD licenses [16](#)
port, activating POD [28](#)
port assignments

- display [30](#)
- override [31](#)
- release [31](#)
- reserve [31](#)
- Ports on Demand
 - Base port set [27](#)
 - Double POD set [27](#)
 - port assignments [28](#)
 - Single POD set [27](#)

R

- remove feature [23](#)
- removing
 - licensed feature [23](#)
- requirements for deactivating a license [23](#)

S

- shelf life of temporary licenses [12](#)
- show license [11](#), [21–24](#)
- show license id [17](#), [23](#)
- Single POD License [27](#)
- software license
 - terminology [12](#)
- software licensing portal [11](#), [17](#), [19](#)

T

- temporary license [12](#)
- temporary license types [12](#)
- time-based license [11](#), [12](#)
- time-based licenses [13](#), [16](#)
- transaction key [11](#)
- troubleshooting [24](#)

U

- universal time-based license [12](#)
- upgrade considerations [16](#)
- usage restrictions [16](#)

V

- viewing license information [19](#)
- view license ID [23](#)