

# Extreme SLX-OS NETCONF Operations Guide, 17r.2.01

Supporting the Extreme SLX 9850 and 9540 Devices

© 2018, Extreme Networks, Inc. All Rights Reserved.

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries. All other names are the property of their respective owners. For additional information on Extreme Networks Trademarks please see [www.extremenetworks.com/company/legal/trademarks](http://www.extremenetworks.com/company/legal/trademarks). Specifications and product availability are subject to change without notice.

# Contents

---

<b>Preface</b> .....	<b>13</b>
Document conventions.....	13
Notes, cautions, and warnings.....	13
Text formatting conventions.....	13
Command syntax conventions.....	14
Extreme resources.....	14
Document feedback.....	14
Contacting Extreme Technical Support.....	15
<b>About This Document</b> .....	<b>17</b>
Interface module capabilities.....	17
Supported hardware and software.....	17
Interface module capabilities.....	17
What's new in this document.....	18
<b>NETCONF Overview</b> .....	<b>19</b>
NETCONF and YANG.....	19
NETCONF in client/server architecture.....	19
RPC request.....	19
RPC reply.....	20
RPC and error handling.....	20
SSH subsystem.....	20
RFC references.....	20
<b>Using NETCONF</b> .....	<b>21</b>
Establishing a NETCONF session.....	21
Hello messages exchange.....	21
Server capabilities.....	22
Client capabilities.....	23
Retrieving configuration data.....	23
Subtree filtering.....	23
xpath filtering.....	25
Retrieving operational data.....	26
Using custom RPCs.....	26
Using the custom action mechanism.....	28
Editing the configuration.....	29
Managing the configuration.....	30
Disconnecting from a NETCONF session.....	31
<b>Basic switch management with NETCONF overview</b> .....	<b>33</b>
Connecting to the switch through an SSH session.....	33
Connecting to the switch through an SSH session.....	34
<b>Sample use cases for SLX-OS NETCONF</b> .....	<b>35</b>
STP overview.....	35
Configuring STP.....	35
Configuring RSTP.....	36
VRF configuration.....	37
Configuring VRF.....	38

<b>NETCONF Statements.....</b>	<b>41</b>
aaa.....	49
aaa/accounting.....	50
aaa/authentication.....	51
aaa/authentication/login.....	53
aaa/authentication/login/first.....	54
aaa/authentication/login/second.....	55
aaa/username.....	56
aaa/username/desc.....	57
aaa/username/encryption-level.....	58
aaa/username/role.....	59
acl-policy.....	60
acl-policy/allow-conflicting-rules.....	61
acl-policy/allow-duplicate-rules.....	62
arp.....	63
bridge-domain.....	64
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/bpdu-drop-enable.....	65
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/logical-interface.....	66
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/local-switching.....	67
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/cos.....	68
bridge-domain-id/(bridge-domain-type)/peer/(peer-ip)/load-balance.....	69
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/lsp.....	70
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/pw-profile.....	71
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/statistics.....	72
bridge-domain/(bridge-domain-id)/(bridge-domain-type)/vc-id.....	73
chassis.....	74
chassis/virtual-ip.....	75
chassis/virtual-ipv6.....	76
clock.....	77
clock/time-zone.....	78
cluster/{cluster-name}/{cluster-id}.....	79
dai.....	80
dai/arp/access-list.....	81
delay-link-event.....	82
dot1x.....	83
dot1x/test.....	84
dot3ah.....	85
event-handler.....	86
event-handler/{event-handler-name}/action.....	87
hardware.....	88
interface/{interface-type}/{interface-name}/ip/access-group.....	89
interface/{interface-type}/{interface-name}/ip/arp-aging-timeout.....	90
interface/{interface-type}/{interface-name}/ip/dhcp/relay/gateway.....	91
interface/{interface-type}/{interface-name}/ip/igmp/immediate-leave.....	92
interface/{interface-type}/{interface-name}/ip/igmp/last-member-query-count.....	93
interface/{interface-type}/{interface-name}/ip/igmp/last-member-query-interval.....	94
interface/{interface-type}/{interface-name}/ip/igmp/query-interval.....	95
interface/{interface-type}/{interface-name}/ip/igmp/query-max-response-time.....	96
interface/{interface-type}/{interface-name}/ip/igmp/robustness-variable.....	97
interface/{interface-type}/{interface-name}/ip/igmp/startup-query-count.....	98

interface/{interface-type}/{interface-name}/ip/igmp/startup-query-interval.....	99
interface/{interface-type}/{interface-name}/ip/pim/dr-priority.....	100
interface/{interface-type}/{interface-name}/ip/pim/neighbor-filter.....	101
interface/{interface-type}/{interface-name}/ip/pim-sparse.....	102
interface/{interface-type}/{interface-name}/ip/policy.....	103
interface/{interface-type}/{interface-name}/ip/proxy-arp.....	104
interface/{interface-type}/{interface-name}/ip/router/isis.....	105
interface/{interface-type}/{interfacename}/ipv6/router/isis.....	106
interface/{interface-type}/{interface-name}/isis.....	107
interface/{interface-type}/{interface-name}/link-error-disable.....	108
interface/{interface-type}/{interface-name}/link-fault-signaling.....	109
interface/{interface-type}/{interface-name}/ipv6/access-group.....	110
interface/{interface-type}/{interface-name}/ipv6/dhcp/relay/address.....	111
interface/{interface-type}/{interface-name}/ipv6/nd/broadcast-mac-trap.....	113
interface/{interface-type}/{interface-name}/ipv6/nd/cache.....	114
interface/{interface-type}/{interface-name}/ipv6/nd/dad.....	115
interface/{interface-type}/{interface-name}/ipv6/nd/hoplimit.....	116
interface/{interface-type}/{interface-name}/ipv6/nd/managed-config-flag.....	117
interface/{interface-type}/{interface-name}/ipv6/nd/mtu.....	118
interface/{interface-type}/{interface-name}/ipv6/nd/ns-interval.....	119
interface/{interface-type}/{interface-name}/ipv6/nd/other-config-flag.....	120
interface/{interface-type}/{interface-name}/ipv6/nd/prefix.....	121
interface/{interface-type}/{interface-name}/ipv6/nd/ra-interval.....	122
interface/{interface-type}/{interface-name}/ipv6/nd/ra-lifetime.....	123
interface/{interface-type}/{interface-name}/ipv6/nd/reachable-time.....	124
interface/{interface-type}/{interface-name}/ipv6/nd/retrans-timer.....	125
interface/{interface-type}/{interface-name}/ipv6/nd/suppress-ra.....	126
interface/{interface-type}/{interface-name}/ipv6/ra-dns-server.....	127
interface/{interface-type}/{interface-name}/ra-dns-server/hoplimit.....	128
interface/{interface-type}/{interface-name}/ra-dns-server/mtu.....	129
interface/{interface-type}/{interface-name}/ra-dns-server/other-config-flag.....	130
interface/{interface-type}/{interface-name}/ipv6/ra-domain-name.....	131
interface/{interface-type}/{interface-name}/lldp/dcbx-version.....	132
interface/{interface-type}/{interface-name}/lldp/disable.....	133
interface/{interface-type}/{interface-name}/lldp/iscsi-priority.....	134
interface/{interface-type}/{interface-name}/lldp/profile.....	135
interface/{interface-type}/{interface-name}/isis/reverse-metric.....	136
interface/{interface-type}/{interface-name}/isis/priority.....	137
interface/{interface-type}/{interface-name}/isis/point-to-point.....	138
interface/{interface-type}/{interface-name}/isis/passive.....	139
interface/{interface-type}/{interface-name}/isis/metric.....	140
interface/{interface-type}/{interface-name}/isis/ldp-sync.....	141
interface/{interface-type}/{interface-name}/isis/ipv6-metric.....	142
interface/{interface-type}/{interface-name}/isis/hello-multiplier.....	143
interface/{interface-type}/{interface-name}/isis/hello-interval.....	144
interface/{interface-type}/{interface-name}/isis/hello-padding.....	145
interface/{interface-type}/{interface-name}/isis/circuit-type.....	146
interface/{interface-type}/{interface-name}/isis/auth-mode.....	147
interface/{interface-type}/{interface-name}/isis/auth-key.....	148
interface/{interface-type}/{interface-name}/isis/auth-check.....	149

interface/{interface-type}/{interface-name}/link-oam-interface.....	150
interface/{interface-type}/{interface-name}/link-oam/link-fault/action.....	151
interface/{interface-type}/{interface-name}/link-oam-interface/allow-loopback .....	152
interface/{interface-type}/{interface-name}/rmon/collection/history.....	153
interface/{interface-type}/{interface-name}/rmon/collection/stats.....	154
interface/{interface-type}/{interface-name}/sflow/enable.....	155
interface/{interface-type}/{interface-name}/sflow/polling-interval.....	156
interface/{interface-type}/{interface-name}/sflow/sample-rate.....	157
interface/{interface-type}/{interface-name}/spanning-tree/autoedge.....	158
interface/{interface-type}/{interface-name}/spanning-tree/bpdu-mac.....	159
interface/{interface-type}/{interface-name}/spanning-tree/cost.....	160
interface/{interface-type}/{interface-name}/spanning-tree/edgeport.....	161
interface/{interface-type}/{interface-name}/spanning-tree/edgeport/bpdu-filter.....	162
interface/{interface-type}/{interface-name}/spanning-tree/edgeport/bpdu-guard.....	163
interface/{interface-type}/{interface-name}/spanning-tree/guard/root.....	164
interface/{interface-type}/{interface-name}/spanning-tree/hello-time.....	165
interface/{interface-type}/{interface-name}/spanning-tree/instance/priority.....	166
interface/{interface-type}/{interface-name}/spanning-tree/instance/cost.....	167
interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-role.....	168
interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-tcn.....	169
interface/{interface-type}/{interface-name}/spanning-tree/link-type.....	170
interface/{interface-type}/{interface-name}/spanning-tree/peer-switch.....	171
interface/{interface-type}/{interface-name}/spanning-tree/portfast.....	172
interface/{interface-type}/{interface-name}/spanning-tree/portfast/bpdu-filter.....	173
interface/{interface-type}/{interface-name}/spanning-tree/portfast/bpdu-guard.....	174
interface/{interface-type}/{interface-name}/spanning-tree/priority.....	175
interface/{interface-type}/{interface-name}/spanning-tree/restricted-role.....	176
interface/{interface-type}/{interface-name}/spanning-tree/restricted-tcn.....	177
interface/{interface-type}/{interface-name}/spanning-tree/shutdown.....	178
interface/{interface-type}/{interface-name}/spanning-tree/vlan.....	179
interface/{interface-type}/{interface-name}/storm-control/ingress.....	180
interface/{interface-type}/{interface-name}/switchport.....	182
interface/{interface-type}/{interface-name}/switchport/access.....	183
interface/{interface-type}/{interface-name}/switchport/mode.....	184
interface/{interface-type}/{interface-name}/switchport/mode/private-vlan.....	185
interface/{interface-type}/{interface-name}/switchport/mode/trunk-no-default-native.....	187
interface/{interface-type}/{interface-name}/switchport/port-security.....	188
interface/{interface-type}/{interface-name}/switchport/port-security/mac-address.....	189
interface/{interface-type}/{interface-name}/switchport/port-security/max.....	190
interface/{interface-type}/{interface-name}/switchport/port-security/oui.....	191
interface/{interface-type}/{interface-name}/switchport/port-security/shutdown-time.....	192
interface/{interface-type}/{interface-name}/switchport/port-security/sticky.....	193
interface/{interface-type}/{interface-name}/switchport/port-security/violation.....	195
ip/access-list/extended.....	196
ip/access-list/extended/{acl-name}/seq.....	197
ip/access-list/standard.....	199
ip/access-list/standard.....	200
ip/access-list/standard/{acl-name}/seq.....	201
ip/dhcp/relay/servers.....	203
ipv6/access-list/extended.....	204

ipv6/access-list/extended/{acl-name}/seq.....	205
ipv6/access-list/standard/{acl-name}/seq.....	207
mac/access-list/extended/{acl-name}/seq.....	209
mac/access-list/standard.....	211
mac/access-list/standard/{acl-name}/seq.....	212
mac-address-table/aging-time.....	214
ntp/authentication-key.....	215
ntp/disable.....	216
ntp/master.....	217
ntp/peer.....	218
ntp/server.....	219
ntp/source-ip.....	220
ntp/trusted-key.....	221
overlay-gateway.....	222
overlay-gateway/{gateway-name}/activate.....	223
overlay-gateway/{gateway-name}/attach/vlan.....	224
overlay-gateway/{gateway-name}/enable.....	225
overlay-gateway/{gateway-name}/ip/access-group.....	226
overlay-gateway/{gateway-name}/ip/interface/loopback.....	227
overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/fabric-virtual-gateway.....	228
overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/vrrp-extended-group.....	229
overlay-gateway/{gateway-name}/ipv6/access-group.....	230
overlay-gateway/{gateway-name}/mac.....	231
overlay-gateway/{gateway-name}/map.....	232
overlay-gateway/{gateway-name}/monitor.....	233
overlay-gateway/{gateway-name}/sflow.....	234
overlay-gateway/{gateway-name}/site.....	235
overlay-gateway/{gateway-name}/site/{site-name}/bfd.....	236
overlay-gateway/{gateway-name}/site/{site-name}/extend.....	237
overlay-gateway/{gateway-name}/site/{site-name}/ip.....	238
overlay-gateway/{gateway-name}/site/{site-name}/mac-learning/protocol/bgp.....	239
overlay-gateway/{gateway-name}/site/{site-name}/shutdown.....	240
overlay-gateway/{gateway-name}/type.....	241
protocol/cfm.....	242
protocol/link-oam.....	243
protocol/lldp/advertise/dcbx-fcoe-app-tlv.....	244
protocol/lldp/advertise/dcbx-fcoe-logical-link-tlv.....	245
protocol/lldp/advertise/dcbx-iscsi-app-tlv.....	246
protocol/lldp/advertise/dcbx-tlv.....	247
protocol/lldp/advertise/dot1-tlv.....	248
protocol/lldp/advertise/dot3-tlv.....	249
protocol/lldp/advertise/optional-tlv.....	250
protocol/lldp/description.....	251
protocol/lldp/disable.....	252
protocol/lldp/hello.....	253
protocol/lldp/iscsi-priority.....	254
protocol/lldp/mode.....	255
protocol/lldp/multiplier.....	256
protocol/lldp/profile/{profile-name}/advertise.....	257
protocol/lldp/profile/{profile-name}/hello.....	258

protocol/lldp/profile/{profile-name}/mode.....	259
protocol/lldp/profile/{profile-name}/multiplier.....	260
protocol/lldp/system-description.....	261
protocol/lldp/system-name.....	262
protocol/spanning-tree/mstp/bridge-priority.....	263
protocol/spanning-tree/mstp/cisco-interoperability.....	264
protocol/spanning-tree/mstp/description.....	265
protocol/spanning-tree/mstp/error-disable-timeout/enable.....	266
protocol/spanning-tree/mstp/error-disable-timeout/interval.....	267
protocol/spanning-tree/mstp/forward-delay.....	268
protocol/spanning-tree/mstp/hello-time.....	269
protocol/spanning-tree/mstp/instance/priority.....	270
protocol/spanning-tree/mstp/instance/vlan.....	271
protocol/spanning-tree/mstp/max-age.....	272
protocol/spanning-tree/mstp/max-hops.....	273
protocol/spanning-tree/mstp/port-channel.....	274
protocol/spanning-tree/mstp/region.....	275
protocol/spanning-tree/mstp/revision.....	276
protocol/spanning-tree/mstp/shutdown.....	277
protocol/spanning-tree/mstp/transmit-holdcount.....	278
protocol/spanning-tree/pvst/bridge-priority.....	279
protocol/spanning-tree/pvst/description.....	280
protocol/spanning-tree/pvst/error-disable-timeout/enable.....	281
protocol/spanning-tree/pvst/error-disable-timeout/interval.....	282
protocol/spanning-tree/pvst/forward-delay.....	283
protocol/spanning-tree/pvst/hello-time.....	284
protocol/spanning-tree/pvst/max-age.....	285
protocol/spanning-tree/pvst/port-channel.....	286
protocol/spanning-tree/pvst/shutdown.....	287
protocol/spanning-tree/pvst/vlan/forward-delay.....	288
protocol/spanning-tree/pvst/vlan/hello-time.....	289
protocol/spanning-tree/pvst/vlan/max-age.....	290
protocol/spanning-tree/pvst/vlan/priority.....	291
protocol/spanning-tree/rpvst/bridge-priority.....	292
protocol/spanning-tree/rpvst/description.....	293
protocol/spanning-tree/rpvst/error-disable-timeout/enable.....	294
protocol/spanning-tree/rpvst/error-disable-timeout/interval.....	295
protocol/spanning-tree/rpvst/forward-delay.....	296
protocol/spanning-tree/rpvst/hello-time.....	297
protocol/spanning-tree/rpvst/max-age.....	298
protocol/spanning-tree/rpvst/port-channel.....	299
protocol/spanning-tree/rpvst/shutdown.....	300
protocol/spanning-tree/rpvst/transmit-holdcount.....	301
protocol/spanning-tree/rpvst/vlan/forward-delay.....	302
protocol/spanning-tree/rpvst/vlan/hello-time.....	303
protocol/spanning-tree/rpvst/vlan/max-age.....	304
protocol/spanning-tree/rpvst/vlan/priority.....	305
protocol/spanning-tree/rstp/bridge-priority.....	306
protocol/spanning-tree/rstp/description.....	307
protocol/spanning-tree/rstp/error-disable-timeout/enable.....	308



protocol/spanning-tree/rstp/error-disable-timeout/interval.....	309
protocol/spanning-tree/rstp/forward-delay.....	310
protocol/spanning-tree/rstp/hello-time.....	311
protocol/spanning-tree/rstp/max-age.....	312
protocol/spanning-tree/rstp/port-channel.....	313
protocol/spanning-tree/rstp/shutdown.....	314
protocol/spanning-tree/rstp/transmit-holdcount.....	315
protocol/spanning-tree/stp/bridge-priority.....	316
protocol/spanning-tree/stp/description.....	317
protocol/spanning-tree/stp/error-disable-timeout/enable.....	318
protocol/spanning-tree/stp/error-disable-timeout/interval.....	319
protocol/spanning-tree/stp/forward-delay.....	320
protocol/spanning-tree/stp/hello-time.....	321
protocol/spanning-tree/stp/max-age.....	322
protocol/spanning-tree/stp/port-channel.....	323
protocol/spanning-tree/stp/shutdown.....	324
radius-server.....	325
ras.....	327
rmon/alarm.....	328
rmon/event.....	330
interface/{interface-type}/{interface-name}/isis.....	331
router/isis/is-type.....	332
route-map.....	333
router/mpls.....	334
router/mpls/ldp.....	335
router/mpls/rsvp.....	337
router/mpls/policy.....	338
router/mpls/policy/transit-session-accounting.....	339
router/mpls/policy/ingress-tunnel-accounting.....	340
router/mpls/policy/qos-ttl-mode.....	341
router/mpls/policy/traffic-engineering/isis.....	342
router/mpls/policy/soft-preemption/cleanup-timer .....	343
router/mpls/policy/cspf-computation-mode/rsvp-periodic-flooding-time.....	344
router/mpls/policy/qos-ttl-mode.....	345
router/mpls/policy/cspf-computation-mode/rapid-retry.....	346
router/mpls/policy/cspf-computation-mode/retry-time.....	347
router/mpls/policy/cspf-computation-mode/handle-ospf-neighbor-down.....	348
router/mpls/policy/cspf-computation-mode/handle-isis-neighbor-down.....	349
router/mpls/policy/cspf-computation-mode/cspf-interface-constraint.....	350
router/mpls/policy/cspf-computation-mode/add-penalty.....	351
router/mpls/policy/cspf-computation-mode/metric-type.....	352
router/mpls/policy/cspf-computation-mode/ignore-overload-bit.....	353
router/mpls/policy/backup-retry-time.....	354
router/mpls/cspf-group/(cspf-group-name)/penalty.....	355
router/mpls/lsp-xc-traps/enable.....	356
router/mpls/cspf-group/(cspf-groupname)/penalty.....	357
router/mpls/lsp-xc-traps/enable.....	358
router/mpls/rsvp.....	359
router/mpls/rsvp/reliable-messaging/rapid-retry-limit.....	360
router/mpls/rsvp/reliable-messaging/rapid-retrans-interval.....	361

router/mpls/rsvp/reliable-messaging/rapid-retrans-decay.....	362
router/mpls/rsvp/refresh-reduction/bundle-message/bundle-send-delay.....	363
router/mpls/rsvp/refresh-multiple.....	364
router/mpls/rsvp/refresh-interval.....	365
router/mpls/rsvp/g-rsvp-backup-bw-guarantee.....	366
router/mpls/rsvp/global-rsvp-hello-acknowledgements.....	367
router/mpls/rsvp/global-rsvp-hello/tolerance.....	368
router/mpls/rsvp/global-rsvp-hello.....	369
router/mpls/rsvp/refresh-reduction/summary-refresh.....	370
qos-mpls.....	371
sflow/agent-address.....	372
sflow/collector.....	373
sflow/enable.....	374
sflow/polling-interval.....	375
sflow/sample-rate.....	376
sflow/source-ip.....	377
sflow-profile.....	378
system-monitor.....	379
system-monitor-mail/fru (email).....	380
system-monitor-mail/fru/enable.....	381
system-monitor-mail/interface (email).....	382
system-monitor-mail/interface/enable.....	383
system-monitor-mail/relay.....	384
system-monitor-mail/security (email).....	385
system-monitor-mail/security/enable.....	386
system-monitor-mail/sfp (email).....	387
system-monitor-mail/sfp/enable.....	388
system-watermark.....	389
topology-group.....	390
uda-access-list.....	391
vlan/{vlan-name}/mac.....	392
vlan/classifier/group.....	393
vlan/classifier/rule/mac.....	394
vlan/classifier/rule/proto.....	395
vlan/dot1q.....	396
vrf.....	397
vrf/{vrf-name}/address-family/ipv4/unicast.....	398
vrf/{vrf-name}/address-family/ipv4/unicast/max-route.....	399
vrf/{vrf-name}/address-family/ipv6/unicast.....	400
vrf/{vrf-name}/address-family/ipv6/unicast/max-route.....	401
vrf/{vrf-name}/ip/router-id.....	402
vxlan-visibility.....	403
bnacfg-cmd.....	404
clear-mpls-ldp-statistics.....	405
clear-mpls-lsp.....	406
clear-mpls-rsvp-statistics.....	407
clear-mpls-rsvp-statistics-neighbor-address.....	408
clear-mpls-rsvp-statistics-neighbor-all.....	409
dad-status.....	410
fwdl-status.....	411

get-arp.....	415
get-contained-in-ID.....	416
get-interface-detail.....	417
get-interface-switchport.....	421
get-ip-interface.....	422
get-last-config-update-time.....	423
get-lldp-neighbor-detail.....	424
get-mac-acl-for-intf.....	426
get-mac-address-table.....	427
get-media-detail.....	429
get-nameserver-detail.....	431
get-netconf-client-capabilities.....	433
get-port-channel-detail.....	434
get-stp-brief-info.....	436
get-system-uptime.....	438
get-vlan-brief.....	439
mpls-clear-all-ldp-sessions.....	441
mpls-clear-one-ldp-sessions.....	442
mpls-clear-statistics-type.....	443
mpls-reopt-lsp.....	444
reload.....	445
set-http-application-url.....	446
show-clock.....	447
show-ntp.....	448
show-raslog.....	449
show-system-monitor.....	451
show-zoning-enabled-configuration.....	453
user-session-info.....	454



# Preface

---

- Document conventions..... 13
- Extreme resources..... 14
- Document feedback..... 14
- Contacting Extreme Technical Support..... 15

## Document conventions

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Extreme technical documentation.

## Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

### NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

### ATTENTION

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.



### CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



### DANGER

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

## Text formatting conventions

Text formatting conventions such as boldface, italic, or Courier font may be used to highlight specific words or phrases.

Format	Description
<b>bold text</b>	Identifies command names. Identifies keywords and operands. Identifies the names of GUI elements.
<i>italic text</i>	Identifies text to enter in the GUI. Identifies emphasis. Identifies variables.
Courier font	Identifies document titles. Identifies CLI output.

Format	Description
	Identifies command syntax examples.

## Command syntax conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
<b>bold text</b>	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example, <code>--show WWN</code> .
[ ]	Syntax components displayed within square brackets are optional.  Default responses to system prompts are enclosed in square brackets.
{ x   y   z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.  In Fibre Channel products, square brackets may be used instead for this purpose.
x   y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <code>member[member...]</code> .
\	Indicates a "soft" line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

## Extreme resources

Visit the Extreme website to locate related documentation for your product and additional Extreme resources.

White papers, data sheets, and the most recent versions of Extreme software and hardware manuals are available at [www.extremenetworks.com](http://www.extremenetworks.com). Product documentation for all supported releases is available to registered users at [www.extremenetworks.com/support/documentation](http://www.extremenetworks.com/support/documentation).

## Document feedback

Quality is our first concern at Extreme, and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you.

You can provide feedback in two ways:

- Use our short online feedback form at <http://www.extremenetworks.com/documentation-feedback-pdf/>
- Email us at [internalinfodev@extremenetworks.com](mailto:internalinfodev@extremenetworks.com)

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

# Contacting Extreme Technical Support

As an Extreme customer, you can contact Extreme Technical Support using one of the following methods: 24x7 online or by telephone. OEM customers should contact their OEM/solution provider.

If you require assistance, contact Extreme Networks using one of the following methods:

- [GTAC \(Global Technical Assistance Center\)](#) for immediate support
  - Phone: 1-800-998-2408 (toll-free in U.S. and Canada) or +1 408-579-2826. For the support phone number in your country, visit: [www.extremenetworks.com/support/contact](http://www.extremenetworks.com/support/contact).
  - Email: [support@extremenetworks.com](mailto:support@extremenetworks.com). To expedite your message, enter the product name or model number in the subject line.
- [GTAC Knowledge](#) - Get on-demand and tested resolutions from the GTAC Knowledgebase, or create a help case if you need more guidance.
- [The Hub](#) - A forum for Extreme customers to connect with one another, get questions answered, share ideas and feedback, and get problems solved. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.
- [Support Portal](#) - Manage cases, downloads, service contracts, product licensing, and training and certifications.

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number and/or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any action(s) already taken to resolve the problem
- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- Any related RMA (Return Material Authorization) numbers





# About This Document

- [Interface module capabilities.....](#) 17
- [Supported hardware and software.....](#) 17
- [What's new in this document.....](#) 18

This document is released in conjunction with SLX-OS 17r.2.01.

## Interface module capabilities

The following table lists the supported capabilities for the following Brocade SLX 9850 interface modules:

- BR-SLX9850-10Gx72S-M
- BR-SLX9850-100Gx36CQ-M
- BR-SLX9850-10Gx72S-D
- BR-SLX9850-100Gx36CQ-D

**TABLE 1** Brocade SLX 9850 interface modules capabilities

Capability	Modular interface module
MPLS	Yes
Packet Buffers per interface module	12 GB (72x10G) 36 GB (Flex)

## Supported hardware and software

In those instances in which procedures or parts of procedures documented here apply to some devices but not to others, this guide identifies exactly which devices are supported and which are not.

Although many different software and hardware configurations are tested and supported by Extreme Networks for SLX-OS Release 17r.2.01, documenting all possible configurations and scenarios is beyond the scope of this document.

The following hardware platforms are supported by this release:

- Extreme SLX 9850-4 router
- Extreme SLX 9850-8 router
- Extreme SLX 9540 switch

To obtain information about other releases, refer to the documentation specific to that release.

## Interface module capabilities

The following table lists the supported capabilities for the following SLX 9850 interface modules:

- BR-SLX9850-10Gx72S-M
- BR-SLX9850-100Gx36CQ-M
- BR-SLX9850-10Gx72S-D
- BR-SLX9850-100Gx36CQ-D

- BR-SLX9850-100Gx12CQ-M

**TABLE 2** SLX 9850 interface modules capabilities

Capability	Modular interface module
MPLS	Yes
Packet Buffer memory per interface module	12GB (BR-SLX9850-10Gx72S-M) 36GB (BR-SLX9850-100Gx36CQ-M) 8GB (BR-SLX9850-10Gx72S-D) 24GB (BR-SLX9850-100Gx36CQ-D)

## What's new in this document

This document is released in conjunction with SLX-OS 17r.2.01.

On October 30, 2017, Extreme Networks, Inc. acquired the SLX-OS product line from Brocade Communications Systems, Inc. This transitional release includes references to both companies.

# NETCONF Overview

---

- NETCONF and YANG..... 19
- NETCONF in client/server architecture.....19
- RPC request.....19
- RPC reply.....20
- RPC and error handling.....20
- SSH subsystem.....20
- RFC references.....20

## NETCONF and YANG

Brocade SLX-OS provides support for the Network Configuration Protocol (NETCONF) and the YANG data modeling language. Using Extensible Markup Language (XML) constructs, the NETCONF protocol provides the ability to manipulate configuration data and view state data modeled in YANG. NETCONF uses a client/server architecture in which remote procedure calls (RPCs) manipulate the modeled data across a secure transport, such as Secure Shell version 2 (SSHv2).

NETCONF provides mechanisms through which you can perform the following operations:

- Manage network devices
- Retrieve configuration data and operational state data
- Upload and manipulate configurations

NETCONF is partitioned conceptually into four layers.

## NETCONF in client/server architecture

The NETCONF protocol uses RPCs to facilitate communication between the client (NETCONF Manager or application) and the server (NETCONF Agent or managed device).

A client encodes an RPC request in XML and sends it to a server using a secure, connection-oriented session. The server responds with a reply encoded in XML.

The communication between the client and server consists of a series of alternating request and reply messages. The NETCONF peers use `<rpc>` and `<rpc-reply>` elements to provide transport protocol-independent framing of NETCONF requests and responses. The NETCONF server processes the RPC requests sequentially in the order in which they are received.

## RPC request

The `<rpc>` element is used for enclosing a NETCONF request sent from the client to the server.

Every `<rpc>` element contains a mandatory attribute, the `message-id`. This attribute has a unique value for every RPC request, and is used to associate every RPC request with the corresponding response. The `message-id` value is a monotonically increasing integer string. The maximum length of the string is 4095 characters. If the `message-id` is not present in the RPC request, the server rejects the request by returning an `<rpc-error>` with an `<error-tag>` element set to "missing-attribute".

If there are any additional attributes present in the RPC request, the NETCONF server returns them unmodified in the corresponding RPC reply.

## RPC reply

An `<rpc-reply>` element is sent in response to every RPC request.

The `<rpc-reply>` element contains the mandatory attribute `message-id` copied from the corresponding RPC request, along with any additional attributes that are present in the RPC request.

For successfully processed `<get>` or `<get-config>` requests, the response data is encoded as the content of the `<rpc-reply>` element.

For successfully processed `<edit-config>` or `<close-session>` requests, the `<ok>` element is encoded as the content of the `<rpc-reply>` element.

For unsuccessful RPC requests, one or more `<rpc-error>` elements are encoded inside the `<rpc-reply>` element.

## RPC and error handling

If the RPC request fails, an `<rpc-error>` element is encoded inside the `<rpc-reply>` element and sent to the client.

The `<rpc-error>` element indicates the first detected error. The server is not required to detect or report multiple errors. If the server detects multiple errors then the order of the error detection and reporting is at the discretion of the server.

## SSH subsystem

The NETCONF client must use Secure Shell Version 2 (SSHv2) as the network transport to connect to the NETCONF server. Only the SSHv2 protocol is supported as the NETCONF transport protocol.

To run NETCONF over SSHv2, the client establishes an SSH transport connection using the SSH transport protocol to the NETCONF port. The default NETCONF port is 830. The underlying SSH client and server exchange keys for message integrity and encryption.

The SSHv2 client invokes the `ssh-userauth` service to authenticate the user. All currently supported SSH user authentication methods such as the public-key, password, and keyboard-interactive authentications are supported for a NETCONF session also. If the SSH user authentication is disabled, the user is allowed full access.

On successful user authentication, the client invokes the `ssh-connection` service, also known as the SSH connection protocol. After the SSH session is established, the NETCONF client invokes NETCONF as an SSH subsystem called `netconf`.

## RFC references

For details about NETCONF and YANG as defined by the Internet Engineering Task Force (IETF), refer to the following documents:

- RFC 6241, "NETCONF Configuration Protocol."
- RFC 4742 "Using the NETCONF Configuration Protocol over Secure Shell (SSH)."
- RFC 6020, "YANG - A Data Modeling Language for the Network Configuration Protocol (NETCONF)"
- RFC 6021, "Common YANG Data Types"

# Using NETCONF

- Establishing a NETCONF session..... 21
- Retrieving configuration data..... 23
- Retrieving operational data..... 26
- Editing the configuration..... 29
- Managing the configuration..... 30
- Disconnecting from a NETCONF session..... 31

## Establishing a NETCONF session

Up to 16 concurrent sessions can be established with a NETCONF server. A session times out if it is idle for 30 minutes.

Each NETCONF session begins with a handshake in which the NETCONF server and the client specify the NETCONF capabilities they support. The following sections describe the message exchange on starting a NETCONF session.

### Hello messages exchange

After establishing a secure transport connection, both the NETCONF server and client send a <hello> element simultaneously to announce their capabilities and session identifier.

The NETCONF server must include the <session-id> element in the <hello> element. The <session-id> element contains the unique session value for the NETCONF session. If the client receives the <hello> element without the <session-id>, the client aborts the NETCONF session by closing the underlying SSH session.

The NETCONF client must not include the <session-id> element in the <hello> element. If the server receives the <hello> element with the <session-id>, the server aborts the NETCONF session by closing the underlying SSH session.

The NETCONF client must include a valid xmlns attribute in the <hello> element. If the server receives the <hello> element without a valid xmlns attribute, the server aborts the NETCONF session by closing the underlying SSH session.

The NETCONF client must include a base capability. The server receiving the <hello> element without a NETCONF base capability aborts the NETCONF session by closing the underlying SSH session.

The server receiving an <rpc> element without first receiving a <hello> element aborts the NETCONF session by closing the underlying SSH session.

The following example shows a <hello> element from the NETCONF server.

```
<hello xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <capabilities>
    <capability>urn:ietf:params:netconf:base:1.0</capability>
    <capability>urn:ietf:params:netconf:capability:writable-running:1.0 </capability>
    <capability>urn:ietf:params:netconf:capability:startup:1.0</capability>
    <capability>urn:ietf:params:netconf:capability:xpath:1.0</capability>
    <capability>urn:ietf:params:netconf:capability:validate:1.0</capability>
    <capability>http://tail-f.com/ns/netconf/actions/1.0</capability>
    <capability>http://tail-f.com/ns/aaa/1.1?revision=2010-06-17&module=tailfaaa</capability>
    <capability>urn:brocade.com:mgmt:brocade-aaa?revision=2010-10-21&module=brocade-aaa</capability>
    <capability>urn:brocade.com:mgmt:brocade-aaa-ext?revision=2010-09-21&module=brocade-aaa-ext</
capability>
    <capability>urn:brocade.com:mgmt:brocade-cdp?revision=2010-08-17&module=brocade-cdp</capability>
    <capability>urn:brocade.com:mgmt:brocade-cee-map?revision=2011-04-18&module=brocade-cee-map</
capability>
    <capability>urn:brocade.com:mgmt:brocade-chassis?revision=2011-04-11&module=brocade-chassis</
capability>
```

```

    </capabilities>
    (output truncated)
    <session-id>4</session-id>
</hello>

```

## Server capabilities

A NETCONF capability is a set of protocol extensions that supplements the base NETCONF specification.

A NETCONF capability is identified with a Uniform Resource Identifier (URI). Capabilities augment the base operations of the NETCONF server, describing both the additional operations and the contents allowed inside the operations. To support a capability, the NETCONF server must support all the dependent capabilities.

The following capabilities are supported on SLX-OS switches:

- Base capability—The set of operations and contents that any NETCONF implementation must support. The URI for the base capability is `urn:ietf:params:xml:ns:netconf:base:1.0`. Both the NETCONF client and server must support the base capability.
- Writable-running capability—Indicates that the device supports `<edit-config>` and `<copy-config>` operations where the `<running>` configuration is the target. The URI is `urn:ietf:params:netconf:capability:writable-running:1.0`.
- Startup capability—Supports separate datastores for the running and startup configuration. Operations performed on the running-config datastore do not affect the startup configuration until a `<copy-config>` operation is performed to explicitly copy the running configuration to the startup configuration. The URI for the startup capability is `urn:ietf:params:netconf:capability:startup:1.0`.
- Xpath capability—Supports XPath expressions in `<filter>` elements. `<filter>` elements are used in `<get>` and `<get-config>` operations to limit the scope of the retrieved data. The URI for the xpath capability is `urn:ietf:params:netconf:capability:xpath:1.0`.
- Validate capability—Allows validation to be performed on a configuration. The URI for the validate capability is `urn:ietf:params:netconf:capability:validate:1.0`.
- Actions capability—Allows operations to be performed on the datastore using the custom action mechanism for features that are supported by this mechanism in the YANG code. Refer to “Using the custom action mechanism” on page 17 for details. The URI for the actions capability is `http://tail-f.com/ns/netconf/actions/1.0`.
- tailf-aaa capability—Supports proprietary authentication, authorization, and accounting (AAA). The URI for the tailf-aaa capability is `http://tail-f.com/ns/aaa/1.1?revision=2010-06-17&module=tailf-aaa`.
- Brocade proprietary capabilities—A set of capabilities that support Brocade SLX-OS features. Each capability references a namespace containing instance data. Each namespace corresponds to a file containing the YANG module that models the data. For example the `brocade-cee-map` capability at URI `urn:brocade.com:mgmt:brocade-cee-map?revision=2011-04-18&module=brocade-cee-map` provides support for the features modeled in the `brocade-cee-map` module.

For an overview of each YANG module and structural details, refer to the Brocade SLX-OS YANG Reference Manual. For element definitions, refer to the specific YANG file .

### NOTE

The Candidate Configuration capability and Confirmed Commit capability are not supported.

## Client capabilities

The client must support the base capability.

In addition, Brocade recommends that the client specify the identification capability with URI `http://tail-f.com/ns/netconf/identification/1.0` while establishing a session with the server. This capability provides client information to the server, including the vendor, product name, and version of the client application in addition to user information. Server administrators can subsequently gather information about who is accessing the server using the `show netconf client-capabilities` command or the `<get-netconf-client-capabilities>` custom RPC. Refer to Appendix A, "Managing NETCONF," for details.

The following example shows a `<hello>` element from the NETCONF client.

```
<hello xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <capabilities>
    <capability>urn:ietf:params:netconf:base:1.0</capability>
    <capability>http://tail-f.com/ns/netconf/identification/1.0?
vendor=brocade&product=bn&version=3.0&client-identity=adminUser</capability>
  </capabilities>
</hello>
```

## Retrieving configuration data

You can retrieve configuration data using either the `<get-config>` or `<get>` RPC. RFC 4741, NETCONF Configuration Protocol specifies that the `<get-config>` RPC returns only configuration data while the `<get>` RPC returns configuration data and operational state data.

In the Brocade implementation, the `<get>` RPC does not return operational state data; Brocade instead provides a set of Custom RPCs and actions for returning operational state data. In the Brocade implementation, the `<get-config>` and `<get>` operations are essentially the same. This document will typically refer to the `<get-config>` operation, though `<get>` can be used equally.

The following example shows a client message that issues the `<get-config>` operation in its most basic form. It retrieves the entire running configuration.

```
<?xml version="1.0" encoding="UTF-8"?>
<rpc message-id="200" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
      <running/>
    </source>
  </get-config>
</rpc>
```

Such a request, however, typically results in an unwanted or unmanageable amount of output. To restrict the output to the portion of the configuration you want, Brocade supports two types of filtering: subtree filtering and xpath filtering.

For complete details about subtree filtering and xpath filtering, refer to the RFC 4741, The NETCONF Protocol. The following sections provide some examples.

## Subtree filtering

Subtree filtering defines a point in the configuration hierarchy that limits the returned configuration data.

Only data at this point and the subtrees below it are returned. For example, to retrieve the loopback configuration for all loopback interfaces configured on the device, use the following filter. This operation returns all configuration data for all loop ports on the managed device.

```
<?xml version="1.0" ?>
<rpc message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
```

```

    <running/>
  </source>
  <filter type="subtree">
    <routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
      <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
        <loopback xmlns="urn:brocade.com:mgmt:brocade-intf-loopback">
          <id>1</id>
        </loopback>
      </interface>
    </routing-system>
  </filter>
</get-config>
</rpc>

```

The purpose of each filter element is as follows:

- The <filter> element tag contains a type statement that identifies the filter type as a subtree filter.
- The <interface> element constrains the output to the interface configuration in the urn:brocade.com:mgmt:brocade-interface namespace.
- The <loopback> element further constrains the output to the information under the <loopback> node. Used in this way, <loopback> is termed a containment node.

To further restrict the output and retrieve loopback configuration data for only one specific loopback interface, use the following filter. In this example, the <id> element is termed a content match node; the filter returns the values of all loopback attributes for the specified port.

```

<?xml version="1.0" ?>
<rpc message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
      <running/>
    </source>
    <filter type="subtree">
      <routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
        <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
          <loopback xmlns="urn:brocade.com:mgmt:brocade-intf-loopback">
            <id>1</id>
            <vrf/>
          </loopback>
        </interface>
      </routing-system>
    </filter>
  </get-config>
</rpc>

```

If all you want to know is the setting of one specific loopback port attribute, such as the name of VRF, use a filter such as the following. In this case, <vrf> suppresses the inclusion of all its sibling nodes. It is termed a selection node.

```

<?xml version="1.0" ?>
<rpc message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
      <running/>
    </source>
    <filter type="subtree">
      <routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
        <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
          <loopback xmlns="urn:brocade.com:mgmt:brocade-intf-loopback">
            <id>1</id>
            <vrf>
              <forwarding/>
            </vrf>
          </loopback>
        </interface>
      </routing-system>
    </filter>

```



```

    </get-config>
</rpc>

```

The following example retrieves the configuration for the loopback interface.

```

<?xml version="1.0" ?>
<rpc message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
      <running/>
    </source>
    <filter type="subtree">
      <routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
        <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
          <loopback xmlns="urn:brocade.com:mgmt:brocade-intf-loopback">
            <id>1</id>
            <shutdown/>
          </loopback>
        </interface>
      </routing-system>
    </filter>
  </get-config>
</rpc>

```

## xpath filtering

Sometimes the data element that qualifies the information you want is at a lower level in the data hierarchy than the information you need.

For example, if you want to return a list of interfaces that are bound to a CoS-to-CoS mutation QoS map, the element to be used for the selection criteria (<cos-mutation>name</cos-mutation>) resides at a lower level in the hierarchy than the information to be retrieved (the interface name), as shown in the following representation of the QoS map structure. In such cases, you must use an xpath filter and not a subtree filter.

```

| +--rw ethernet [name]
+--rw name                interface-type
.
.
.
+--rw qos:qos
+--rw qos:default-cos?    int32
+--rw qos:cos-mutation?  map-name-type
+--rw qos:cos-traffic-class? map-name-type
+--rw qos:dscp-mutation?  map-name-type

```

The following example returns the interface names to which the CoS-to-CoS mutation QoS map named "test" is bound. In this case, the map named "test" is bound to interfaces 2/5 and 2/6. The <filter> element tag specifies that the filter type is xpath and also specifies the data path and selection criteria.

```

<?xml version="1.0" encoding="UTF-8"?>
<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="205">
  <get-config>
    <source>
      <running></running>
    </source>
    <filter type="xpath" select="/interface/ethernet/qos[cos-mutation='test']"></filter>
  </get-config>
</rpc>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
message-id="205">
  <data>
    <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
      <ethernet>
        <name>0/5</name>
        <qos xmlns="urn:brocade.com:mgmt:brocade-qos">

```

```

        <default-cos>0</default-cos>
        <cos-mutation>test</cos-mutation>
    </qos>
</ethernet>
<ethernet>
    <name>0/6</name>
    <qos xmlns="urn:brocade.com:mgmt:brocade-qos">
        <default-cos>0</default-cos>
        <cos-mutation>test</cos-mutation>
    </qos>
</ethernet>
</interface>
</data>
</rpc-reply>

```

## Retrieving operational data

In the Brocade SLX-OS implementation of NETCONF, two mechanisms are used for retrieving operational data: Brocade custom RPCs and custom actions.

Custom RPC and action support is added to some of the YANG modules to support the return of specific operational data.

For a complete list of the Brocade Custom RPCs and actions, and their locations, refer to the *Brocade SLX-OS YANG Reference Manual*.

Brocade SLX-OS does not support retrieving operational data using the standard <get> RPC.

## Using custom RPCs

If an RPC is defined in a YANG module, you can use that RPC to return the associated namespace information defined in its output elements.

For example, to return information about port-profiles to which interfaces are applied, you can use the <get-port-profile-for-intf> RPC defined in the `brocade-port-profile-ext.yang` file.

The `brocade-port-profile-ext.yang` file defines the structure of the <get-port-profile-for-intf> RPC as follows:

```

+---x get-port-profile-for-intf
  +--ro input
    +--ro interface-type? enumeration
    +--ro interface-name? union
  +--ro output
    +--ro interface
      +--ro interface-type? enumeration
      +--ro interface-name? union
    +--ro port-profile
      +--ro name? common-def:name-string64

```

The following example shows the <rpc> message and reply. The <get-port-profile-for-intf> element contains an xmlns attribute that identifies the corresponding namespace.

```

<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="206">
  <get-port-profile-for-intf xmlns="urn:brocade.com:mgmt:brocade-interface-ext"/>
</rpc>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="206">
  <interface xmlns="urn:brocade.com:mgmt:brocade-port-profile-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/5</interface-name>
    <port-profile>
      <name>auto-VM_Network</name>
    </port-profile>
  </interface>

```

```

<interface xmlns="urn:brocade.com:mgmt:brocade-port-profile-ext">
  <interface-type>ethernet</interface-type>
  <interface-name>2/5</interface-name>
  <port-profile>
    <name>auto-for_iscsi</name>
  </port-profile>
</interface>
</rpc-reply>

```

Refer to the *Brocade SLX-OS YANG Reference Manual* for a list of Custom RPCs, a brief description of their function, and their location.

## Retrieving operational data with pagination

Some RPCs return operational data that consists of lists of entities. For example, an RPC might return detailed information about every interface. For these kinds of applications, to make the output manageable, pagination is supported by providing a <has-more> element in the output of the RPC.

The following example shows how the <has-more> element works to provide pagination for the <get-vlan-brief> RPC. In the input, you can request information about a specific VLAN, or about all VLANs by not providing an input parameter. If you request input about all VLANs, you will first receive information about the VLAN with the lowest VLAN ID. You can then check the <has-more> element in the output to determine whether information is available for additional VLANs. If <has-more> is true, use the value returned in <last-vlan-id> as the <last-rcvd--vlan-id> input parameter to the next call to <get-vlan-brief>. The <get-vlan-brief> RPC then returns the next available VLAN. Continue until <has-more> returns false.

```

+---x get-vlan-brief
  +--ro input
  | +--ro (request-type)?
  | +--:(get-request)
  | | +--ro vlan-id? interface:vlan-type
  | +--:(get-next-request)
  | +--ro last-rcvd-vlan-id? interface:vlan-type
  +--ro output
  +--ro vlan [vlan-id]
  | +--ro vlan-id interface:vlan-type
  | +--ro vlan-type? enumeration
  | +--ro vlan-name? string
  | +--ro vlan-state? enumeration
  | +--ro interface [interface-type interface-name]
  | +--ro interface-type enumeration
  | +--ro interface-name union
  | +--ro tag? enumeration
  +--ro last-vlan-id? interface:vlan-type
  +--ro has-more? boolean

```

The following example uses the <get-interface-brief> RPC to return information about the first VLAN. In this case, the first VLAN is VLAN 20.

```

<rpc message-id="207" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-vlan-brief xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    </get-vlan-brief>
  </rpc>

<rpc-reply message-id="207" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <vlan xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <vlanid>20</vlanid>
    <vlan-type>static</vlan-type>
    <vlan-name>vlan-20</vlan-name>
    <vlan-state>active</vlan-state>
    <interface>
      <interface-type>ethernet</interface-type>
      <interface-name>2/5</interface-name>
      <tag>tagged</tag>
    </interface>
  </vlan>
  <last-vlan-id>20</last-vlan-id>

```

```

    <has-more>true</has-more>
  </rpc-reply>

```

The `<has-more>` field is true, so use the value returned in `<last-vlan-id>` as the `<last-rcvd-vlan-id>` in the next call to `<get-vlan-brief>` to return information about the next VLAN.

```

<rpc message-id="208" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-vlan-brief xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <last-rcvd-vlan-id>20</last-rcvd-vlan-id>
  </get-vlan-brief>
</rpc>

<rpc-reply message-id="208" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <vlan xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <vlanid>30</vlanid>
    <vlan-type>static</vlan-type>
    <vlan-name>vlan-30</vlan-name>
    <vlan-state>active</vlan-state>
    <interface>
      <interface-type>ethernet</interface-type>
      <interface-name>2/5</interface-name>
      <tag>tagged</tag>
    </interface>
  </vlan>
  <last-vlan-id>30</last-vlan-id>
  <has-more>false</has-more>
</rpc-reply>

```

If the `<has-more>` field returns false, no more VLAN data can be retrieved.

## Using the custom action mechanism

An action is a proprietary mechanism used for implementing operations that do not affect the configuration datastore. Several implementations of actions exist in the Brocade SLX-OS implementation for retrieving operational information.

The following structure is defined in the `brocade-zone.yang` module for displaying operational data related to zoning.

```

+--rw common-def:show
  +--rw brocade-zone:zoning
    +--action brocade-zone:operation-info
      +--input
      +--output
        +--ro brocade-zone:db-max
        +--ro brocade-zone:db-avail
        +--ro brocade-zone:db-committed
        +--ro brocade-zone:db-transaction
        +--ro brocade-zone:transaction-token
        +--ro brocade-zone:last-zone-changed-timestamp
        +--ro brocade-zone:last-zone-committed-timestamp

```

The following example shows use of the `<zoning>/<operation-info>` action.

```

<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="209">
  <nca:action xmlns:nca="http://tail-f.com/ns/netconf/actions/1.0">
    <nca:data>
      <show xmlns="urn:brocade.com:mgmt:brocade-common-def">
        <zoning xmlns="urn:brocade.com:mgmt:brocade-zone"/>
      </show>
    </nca:data>
  </nca:action>
</rpc>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
message-id="209">
  <zoning xmlns="urn:brocade.com:mgmt:brocade-zone">
    <db-max>1045274</db-max>
    <db-avail>1043895</db-avail>

```

```

    <db-committed>367</db-committed>
    <db-transaction>373</db-transaction>
    <transaction-token>1</transaction-token>
    <last-zone-changed-timestamp>2011-11-16 16:54:31 GMT-7:00</last-zone-changed-timestamp>
    <last-zone-committed-timestamp>2011-11-16 16:23:44 GMT-7:00</last-zone-committed-timestamp>
  </zoning>
</rpc-reply>

```

For a list of available actions and their locations, refer to the *Brocade SLX-OS YANG Reference Manual*.

## Editing the configuration

All configuration editing is done using the merge or delete operations of the <edit-config> RPC. The create and replace operations are not supported.

Refer to RFC 4741, The NETCONF Protocol, for details about these operations.

### NOTE

Every NETCONF <edit-config> request should have a one-to-one mapping with a Brocade SLX-OS CLI command. You cannot combine two CLI operations into one NETCONF request.

The following example of the default merge operation adds a static address to the MAC address table. The operation is performed on the running configuration and configures the <mac-address-table> node in the urn:brocade.com:mgmt:brocade-mac-address-table namespace.

```

<?xml version="1.0" encoding="UTF-8"?>
<rpc message-id="210" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <edit-config>
    <target>
      <running/>
    </target>
    <config>
      <mac-address-table xmlns="urn:brocade.com:mgmt:brocade-mac-address-table">
        <static>
          <mac-address>0011.2222.3333</mac-address>
          <forward>forward</forward>
          <interface-type>ethernet</interface-type>
          <interface-name>2/5</interface-name>
          <vlan>vlan</vlan>
          <vlanid>100</vlanid>
        </static>
      </mac-address-table>
    </config>
  </edit-config>
</rpc>

<rpc-reply message-id="210" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <ok/>
</rpc-reply>

```

The delete operation is used to remove or disable part of the configuration. The following example disables MSTP on the managed device.

```

<?xml version="1.0" encoding="UTF-8"?>
<rpc message-id="211" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <edit-config>
    <target>
      <running/>
    </target>
    <config>
      <protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
        <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
          <mstp xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" Operation="delete"/>
        </spanning-tree>
      </protocol>
    </config>
  </edit-config>
</rpc>

```

```

        </protocol>
    </config>
</edit-config>
</rpc>

<rpc-reply message-id="211" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
    <ok/>
</rpc-reply>

```

## Managing the configuration

Brocade SLX-OS provides the custom `<bna-config-cmd>` PRC for performing any of the following operations:

- Copy the *running-config* file to a remote file.
- Copy a remote file to the *running-config* file.

Some simple examples are provided here. Refer to the *Brocade SLX-OS Administrator's Guide* for the following related information:

- General configuration management concepts
- Details and recommendations about how to apply these operations in a modular chassis or a Brocade VCS Fabric or a IP Fabric
- How to perform management configuration using the Brocade SLX-OS command line interface (CLI)

To monitor the progress of the copy operation, issue the `<bna-config-cmd-status>` custom RPC. Provide the session-ID returned by the corresponding `<bna-config-cmd>` as the input parameter.

```

<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="212">
    <bna-config-cmd-status xmlns="urn:brocade.com:mgmt:brocade-ras">
        <session-id>5</session-id>
    </bna-config-cmd-status>
</rpc>

<rpc-reply message-id="212" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
    <status xmlns="urn:brocade.com:mgmt:brocade-ras">completed</status>
</rpc-reply>

```

To archive or back up the *running-config* file, specify `<running/>` as the `<src>` parameter, and the URL of the archive as the `<dest>` parameter. The following example archives the *running-config* file.

```

<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="212">
    <bna-config-cmd xmlns="urn:brocade.com:mgmt:brocade-ras">
        <src>running-config</src>
        <dest>https://user@brocade.com:passphrase/cfg/archiveMay7.txt</dest>
    </bna-config-cmd>
</rpc>

<rpc-reply message-id="212" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
    <session-id xmlns="urn:brocade.com:mgmt:brocade-ras">6</session-id>
    <status xmlns="urn:brocade.com:mgmt:brocade-ras">in-progress</status>
</rpc-reply>

```

To restore an archived configuration, specify the archive URL as the `<source>` parameter and `<running/>` as the `<target>`.

```

<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="212">
    <bna-config-cmd xmlns="urn:brocade.com:mgmt:brocade-ras">
        <src>https://user@brocade.com:passphrase/cfg/archiveMay7.txt</src>
        <dest>running-config</dest>
    </bna-config-cmd>
</rpc>

<rpc-reply message-id="212" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
    <session-id xmlns="urn:brocade.com:mgmt:brocade-ras">6</session-id>
    <status xmlns="urn:brocade.com:mgmt:brocade-ras">in-progress</status>
</rpc-reply>

```

## Disconnecting from a NETCONF session

To disconnect from a NETCONF session, issue the standard `<close-session>` RPC.

This operation causes the server to release any resources associated with the session and gracefully close any associated connections.

```
<rpc message-id="215" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <close-session/>
</rpc>

<rpc-reply message-id="215" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <ok/>
</rpc-reply>
```

The `<kill-session>` RPC is also supported. Issuing `<kill-session>` aborts all operations and closes the session.





# Basic switch management with NETCONF overview

---

- Connecting to the switch through an SSH session..... 33
- Connecting to the switch through an SSH session..... 34

This chapter provides procedures for performing some basic switch operations using the NETCONF interface.

Refer to the *Brocade SLX-OS Administrator's Guide* for the following related information:

- Conceptual and overview information
- Using DHCP Automatic Deployment (DAD)
- Procedures for configuring the Ethernet management interface
- Basic switch configuration using the Brocade SLX-OS command line interface (CLI)

Using the NETCONF interface, you can perform the following basic switch configuration operations described in this chapter:

- Use the <edit-config> RPC to set host attributes, configure a line card type on a chassis slot, configure a switch banner, enable or disable first failure data capture (FFDC), and configure logging.
- Use custom actions to enable or disable a chassis, reboot a switch, power on/off a line card, obtain slot and module status, and upload supportSave data.
- Use the <show-raslog> custom RPC to return RASlog messages.

Switch management parameters described in this chapter are defined mostly in the *brocade-ras*, *brocade-linecard-management*, and *brocade-chassis* YANG modules. For structural maps of these YANG modules, refer to the *Brocade SLX-OS YANG Reference Manual*. For definitions and explanations of parameters, refer to the corresponding.yang file.

## Connecting to the switch through an SSH session

For NETCONF operations, you must connect to the device using SSH.

1. Connect through a serial port to the device
2. Verify that the network interface of the device is configured and that it is connected to the IP network through the RJ-45 Ethernet port.
3. Log off from the serial port of the device.
4. From a management station, open an SSH connection using the management IP address of the device to which you want to connect.
5. Enter the account user name at the login prompt.
6. Enter the password.

Brocade recommends that you change the default account password when you log in for the first time. For more information on changing the default password, refer to the *Brocade SLX Hardware Installation Guide*.

7. Verify that the login was successful.

The prompt displays the host name followed by a pound sign (#).

```
login as: admin
admin@10.20.49.112's password:*****

Welcome to the Brocade SLX-OS Software
admin connected from 10.1.1.1 using console on F115
```

## Connecting to the switch through an SSH session

For NETCONF operations, you must connect to the device using SSH.

1. Connect through a serial port to the device
2. Verify that the network interface of the device is configured and that it is connected to the IP network through the RJ-45 Ethernet port.
3. Log off from the serial port of the device.
4. From a management station, open an SSH connection using the management IP address of the device to which you want to connect.
5. Enter the account user name at the login prompt.
6. Enter the password.

Brocade recommends that you change the default account password when you log in for the first time. For more information on changing the default password, refer to the Brocade SLX Hardware Installation Guide.

7. Verify that the login was successful.

The prompt displays the host name followed by a pound sign (#).

```
login as: admin
admin@10.20.49.112's password:*****

Welcome to the Brocade SLX-OS Software
admin connected from 10.1.1.1 using console on F115
```

# Sample use cases for SLX-OS NETCONF

- STP overview.....35
- VRF configuration..... 37

This chapter discusses common use cases for the Brocade SLX-OS NETCONF.

## NOTE

The information provided in this chapter may not cover the end-to-end configuration. Refer to the *Brocade SLX-OS Administrator's Guide* for the complete set of configuration tasks.

## STP overview

A network topology of bridges typically contains redundant connections to provide alternate paths in case of link failures. However, because there is no concept of TTL in Ethernet frames, this could result in the permanent circulation of frames if there are loops in the network. To prevent loops, a spanning tree connecting all the bridges is formed in real time.

The redundant ports are put in a blocking (nonforwarding) state. They are enabled when required. In order to build a spanning tree for the bridge topology, the bridges must exchange control frames (BPDUs - Bridge Protocol Data Units). The protocols define the semantics of the BPDUs and the required state machine. The first Spanning Tree Protocol (STP) became part of the IEEE 802.1d standard.

The STP interface states for every Layer 2 interface running STP are as follows:

- *Blocking* - The interface does not forward frames.
- *Listening* - The interface is identified by the spanning tree as one that should participate in frame forwarding. This is a transitional state after the blocking state.
- *Learning* - The interface prepares to participate in frame forwarding.
- *Forwarding* - The interface forwards frames.
- *Disabled* - The interface is not participating in spanning tree because of a shutdown port, no link on the port, or no spanning tree instance running on the port.

A port participating in spanning tree moves through these states:

- From initialization to blocking
- From blocking to listening or to disabled
- From listening to learning or to disabled
- From learning to forwarding, blocking, or disabled
- From forwarding to disabled

## Configuring STP

The process for configuring STP is as follows:

1. Enable STP using the below NETCONF statement.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp></stp>
  </spanning-tree>
</protocol>
```

- Designate the root switch by using the `bridge-priority` command. The range is 0 through 61440 and the priority values can be set only in increments of 4096.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <bridge-priority>32768</bridge-priority>
    </stp>
  </spanningtree>
</protocol>
```

- Enable port fast on switch ports by using the `spanning-tree portfast` command.

#### NOTE

Note the following conditions:

- Port fast only needs to be enabled on ports that connect to workstations or PCs. Repeat these commands for every port connected to workstations or PCs. Do not enable port fast on ports that connect to other switches.
- If BPDUs are received on a port fast enabled interface, the interface loses the edge port status unless it receives a shut/no shut.
- Enabling port fast on ports can cause temporary bridging loops, in both trunking and nontrunking mode.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/5</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <portfastbasic></portfastbasic>
      </portfast>
    </spanning-tree>
  </ethernet>
</interface>
```

## Configuring RSTP

The process for configuring RSTP is as follows.

- Enable RSTP by using the global `protocol spanning-tree` command.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp></rstp>
  </spanning-tree>
</protocol>
```

- Designate the root switch by using the `bridge-priority` command. The range is 0 through 61440 and the priority values can be set only in increments of 4096.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <bridge-priority>32768</bridge-priority>
    </rstp>
  </spanning-tree>
</protocol>
```

- Configure the bridge forward delay value to set the time an interface spends in each of the listening and learning states.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <forward-delay>30</forward-delay>
    </rstp>
  </spanning-tree>
</protocol>
```

- Configure the bridge maximum aging time value to set the interval time in seconds between messages that the spanning tree receives from the interface.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <max-age>40</max-age>
    </rstp>
  </spanning-tree>
</protocol>
```

- Enable the error-disable-timeout timer.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </rstp>
  </spanning-tree>
</protocol>
```

- Configure the error-disable-timeout interval value to set the timeout for errors on an interface.

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <error-disable-timeout>
        <interval>500</interval>
      </error-disable-timeout>
    </rstp>
  </spanning-tree>
</protocol>
```

## VRF configuration

VRF (Virtual Routing and Forwarding) is a technology that controls information flow within a network by isolating the traffic by partitioning the network into different logical VRF domains.

Every VRF-capable router supports one routing table for each VRF instance. Each VRF-capable router can function as a group of multiple virtual routers on the same physical router. VRF, in conjunction with virtual private network (VPN) solutions, guarantees privacy of information and isolation of traffic within its logical VRF domain.

This chapter provides procedures and examples for configuring VRF using the NETCONF interface.

Using the NETCONF interface, you can perform the following VRF configuration operations:

- Use the `<edit-config>` remote procedure call (RPC) to activate and deactivate VRF globally, set global VRF parameters, activate and deactivate VRF on a port, and to set interface parameters on a specific port.
- Use the `<get-config>` RPC to verify all or part of the VRF configuration.

VRF parameters are defined in the *brocade-vrf* YANG module. For a structural map of the YANG module, refer to the *Brocade SLX-OS YANG Reference Manual*. For definitions and explanations of all VRF parameters, refer to the *brocade-vrf.yang* file.

## Configuring VRF

This chapter provides procedures and examples for configuring VRF using the NETCONF interface.

1. Configure VRF "red".

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>red</vrf-name>
</vrf>
```

2. Enable the IPv4 or IPv6 address-family support to configure a variety of VRF unicast routing options.

The below example shows how to enable IPv4 address-family support

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>Red</vrf-name>
  <address-family>
    <ip>
      <unicast></unicast>
    </ip>
  </address-family>
</vrf>
```

3. Configure the maximum number of routes to be used for the VRF

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>red</vrf-name>
  <address-family>
    <ip>
      <unicast>
        <max-route>200</max-route>
      </unicast>
    </ip>
  </address-family>
</vrf>
```

4. Enable the Open Shortest Path First (OSPF) routing protocol over virtual forward and routing (VRF).

```
<router>
  <ospf xmlns="urn:brocade.com:mgmt:brocade-ospf">
    <vrf>red</vrf>
  </ospf>
</router>
```

5. Assign it to an area

```
<router>
  <ospf xmlns="urn:brocade.com:mgmt:brocade-ospfv3">
    <vrf>red</vrf>
    <area>
      <area-id>0</area-id>
    </area>
  </ospf>
</router>
```

## 6. Bind the interface to the VRF instance

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ve>
    <name>1</name>
    <vrf xmlns="urn:brocade.com:mgmt:brocade-ip-config">
      <forwarding>red</forwarding>
    </vrf>
  </ve>
</interface>
```





# NETCONF Statements

---

• aaa.....	49
• aaa/accounting.....	50
• aaa/authentication.....	51
• aaa/authentication/login.....	53
• aaa/authentication/login/first.....	54
• aaa/authentication/login/second.....	55
• aaa/username.....	56
• aaa/username/desc.....	57
• aaa/username/encryption-level.....	58
• aaa/username/role.....	59
• acl-policy.....	60
• acl-policy/allow-conflicting-rules.....	61
• acl-policy/allow-duplicate-rules.....	62
• arp.....	63
• bridge-domain.....	64
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/bpdu-drop-enable.....	65
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/logical-interface.....	66
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/local-switching.....	67
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/cos.....	68
• bridge-domain-id/(bridge-domain-type)/peer/(peer-ip)/load-balance.....	69
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/lsp.....	70
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/pw-profile.....	71
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/statistics.....	72
• bridge-domain/(bridge-domain-id)/(bridge-domain-type)/vc-id.....	73
• chassis.....	74
• chassis/virtual-ip.....	75
• chassis/virtual-ipv6.....	76
• clock.....	77
• clock/time-zone.....	78
• cluster/{cluster-name}/{cluster-id}.....	79
• dai.....	80
• dai/arp/access-list.....	81
• delay-link-event.....	82
• dot1x.....	83
• dot1x/test.....	84
• dot3ah.....	85
• event-handler.....	86
• event-handler/{event-handler-name}/action.....	87
• hardware.....	88
• interface/{interface-type}/{interface-name}/ip/access-group.....	89
• interface/{interface-type}/{interface-name}/ip/arp-aging-timeout.....	90
• interface/{interface-type}/{interface-name}/ip/dhcp/relay/gateway.....	91
• interface/{interface-type}/{interface-name}/ip/igmp/immediate-leave.....	92
• interface/{interface-type}/{interface-name}/ip/igmp/last-member-query-count.....	93
• interface/{interface-type}/{interface-name}/ip/igmp/last-member-query-interval.....	94
• interface/{interface-type}/{interface-name}/ip/igmp/query-interval.....	95
• interface/{interface-type}/{interface-name}/ip/igmp/query-max-response-time.....	96
• interface/{interface-type}/{interface-name}/ip/igmp/robustness-variable.....	97

• interface/{interface-type}/{interface-name}/ip/igmp/startup-query-count.....	98
• interface/{interface-type}/{interface-name}/ip/igmp/startup-query-interval.....	99
• interface/{interface-type}/{interface-name}/ip/pim/dr-priority.....	100
• interface/{interface-type}/{interface-name}/ip/pim/neighbor-filter.....	101
• interface/{interface-type}/{interface-name}/ip/pim-sparse.....	102
• interface/{interface-type}/{interface-name}/ip/policy.....	103
• interface/{interface-type}/{interface-name}/ip/proxy-arp.....	104
• interface/{interface-type}/{interface-name}/ip/router/isis.....	105
• interface/{interface-type}/{interfacename}/ipv6/router/isis.....	106
• interface/{interface-type}/{interface-name}/isis.....	107
• interface/{interface-type}/{interface-name}/link-error-disable.....	108
• interface/{interface-type}/{interface-name}/link-fault-signaling.....	109
• interface/{interface-type}/{interface-name}/ipv6/access-group.....	110
• interface/{interface-type}/{interface-name}/ipv6/dhcp/relay/address.....	111
• interface/{interface-type}/{interface-name}/ipv6/nd/broadcast-mac-trap.....	113
• interface/{interface-type}/{interface-name}/ipv6/nd/cache.....	114
• interface/{interface-type}/{interface-name}/ipv6/nd/dad.....	115
• interface/{interface-type}/{interface-name}/ipv6/nd/hoplimit.....	116
• interface/{interface-type}/{interface-name}/ipv6/nd/managed-config-flag.....	117
• interface/{interface-type}/{interface-name}/ipv6/nd/mtu.....	118
• interface/{interface-type}/{interface-name}/ipv6/nd/ns-interval.....	119
• interface/{interface-type}/{interface-name}/ipv6/nd/other-config-flag.....	120
• interface/{interface-type}/{interface-name}/ipv6/nd/prefix.....	121
• interface/{interface-type}/{interface-name}/ipv6/nd/ra-interval.....	122
• interface/{interface-type}/{interface-name}/ipv6/nd/ra-lifetime.....	123
• interface/{interface-type}/{interface-name}/ipv6/nd/reachable-time.....	124
• interface/{interface-type}/{interface-name}/ipv6/nd/retrans-timer.....	125
• interface/{interface-type}/{interface-name}/ipv6/nd/suppress-ra.....	126
• interface/{interface-type}/{interface-name}/ipv6/ra-dns-server.....	127
• interface/{interface-type}/{interface-name}/ra-dns-server/hoplimit.....	128
• interface/{interface-type}/{interface-name}/ra-dns-server/mtu.....	129
• interface/{interface-type}/{interface-name}/ra-dns-server/other-config-flag.....	130
• interface/{interface-type}/{interface-name}/ipv6/ra-domain-name.....	131
• interface/{interface-type}/{interface-name}/lldp/dcbx-version.....	132
• interface/{interface-type}/{interface-name}/lldp/disable.....	133
• interface/{interface-type}/{interface-name}/lldp/iscsi-priority.....	134
• interface/{interface-type}/{interface-name}/lldp/profile.....	135
• interface/{interface-type}/{interface-name}/isis/reverse-metric.....	136
• interface/{interface-type}/{interface-name}/isis/priority.....	137
• interface/{interface-type}/{interface-name}/isis/point-to-point.....	138
• interface/{interface-type}/{interface-name}/isis/passive.....	139
• interface/{interface-type}/{interface-name}/isis/metric.....	140
• interface/{interface-type}/{interface-name}/isis/ldp-sync.....	141
• interface/{interface-type}/{interface-name}/isis/ipv6-metric.....	142
• interface/{interface-type}/{interface-name}/isis/hello-multiplier.....	143
• interface/{interface-type}/{interface-name}/isis/hello-interval.....	144
• interface/{interface-type}/{interface-name}/isis/hello-padding.....	145
• interface/{interface-type}/{interface-name}/isis/circuit-type.....	146
• interface/{interface-type}/{interface-name}/isis/auth-mode.....	147
• interface/{interface-type}/{interface-name}/isis/auth-key.....	148
• interface/{interface-type}/{interface-name}/isis/auth-check.....	149
• interface/{interface-type}/{interface-name}/link-oam-interface.....	150

- interface/{interface-type}/{interface-name}/link-oam/link-fault/action..... 151
- interface/{interface-type}/{interface-name}/link-oam-interface/allow-loopback ..... 152
- interface/{interface-type}/{interface-name}/rmon/collection/history..... 153
- interface/{interface-type}/{interface-name}/rmon/collection/stats..... 154
- interface/{interface-type}/{interface-name}/sflow/enable..... 155
- interface/{interface-type}/{interface-name}/sflow/polling-interval..... 156
- interface/{interface-type}/{interface-name}/sflow/sample-rate..... 157
- interface/{interface-type}/{interface-name}/spanning-tree/autoedge..... 158
- interface/{interface-type}/{interface-name}/spanning-tree/bpdu-mac..... 159
- interface/{interface-type}/{interface-name}/spanning-tree/cost..... 160
- interface/{interface-type}/{interface-name}/spanning-tree/edgeport..... 161
- interface/{interface-type}/{interface-name}/spanning-tree/edgeport/bpdu-filter..... 162
- interface/{interface-type}/{interface-name}/spanning-tree/edgeport/bpdu-guard..... 163
- interface/{interface-type}/{interface-name}/spanning-tree/guard/root..... 164
- interface/{interface-type}/{interface-name}/spanning-tree/hello-time..... 165
- interface/{interface-type}/{interface-name}/spanning-tree/instance/priority..... 166
- interface/{interface-type}/{interface-name}/spanning-tree/instance/cost..... 167
- interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-role..... 168
- interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-tcn..... 169
- interface/{interface-type}/{interface-name}/spanning-tree/link-type..... 170
- interface/{interface-type}/{interface-name}/spanning-tree/peer-switch..... 171
- interface/{interface-type}/{interface-name}/spanning-tree/portfast..... 172
- interface/{interface-type}/{interface-name}/spanning-tree/portfast/bpdu-filter..... 173
- interface/{interface-type}/{interface-name}/spanning-tree/portfast/bpdu-guard..... 174
- interface/{interface-type}/{interface-name}/spanning-tree/priority..... 175
- interface/{interface-type}/{interface-name}/spanning-tree/restricted-role..... 176
- interface/{interface-type}/{interface-name}/spanning-tree/restricted-tcn..... 177
- interface/{interface-type}/{interface-name}/spanning-tree/shutdown..... 178
- interface/{interface-type}/{interface-name}/spanning-tree/vlan..... 179
- interface/{interface-type}/{interface-name}/storm-control/ingress..... 180
- interface/{interface-type}/{interface-name}/switchport..... 182
- interface/{interface-type}/{interface-name}/switchport/access..... 183
- interface/{interface-type}/{interface-name}/switchport/mode..... 184
- interface/{interface-type}/{interface-name}/switchport/mode/private-vlan..... 185
- interface/{interface-type}/{interface-name}/switchport/mode/trunk-no-default-native..... 187
- interface/{interface-type}/{interface-name}/switchport/port-security..... 188
- interface/{interface-type}/{interface-name}/switchport/port-security/mac-address..... 189
- interface/{interface-type}/{interface-name}/switchport/port-security/max..... 190
- interface/{interface-type}/{interface-name}/switchport/port-security/oui..... 191
- interface/{interface-type}/{interface-name}/switchport/port-security/shutdown-time..... 192
- interface/{interface-type}/{interface-name}/switchport/port-security/sticky..... 193
- interface/{interface-type}/{interface-name}/switchport/port-security/violation..... 195
- ip/access-list/extended..... 196
- ip/access-list/extended/{acl-name}/seq..... 197
- ip/access-list/standard..... 199
- ip/access-list/standard/{acl-name}/seq..... 201
- ip/dhcp/relay/servers..... 203
- ipv6/access-list/extended..... 204
- ipv6/access-list/extended/{acl-name}/seq..... 205
- ipv6/access-list/standard/{acl-name}/seq..... 207
- mac/access-list/extended/{acl-name}/seq..... 209

• mac/access-list/standard.....	211
• mac/access-list/standard/{acl-name}/seq.....	212
• mac-address-table/aging-time.....	214
• ntp/authentication-key.....	215
• ntp/disable.....	216
• ntp/master.....	217
• ntp/peer.....	218
• ntp/server.....	219
• ntp/source-ip.....	220
• ntp/trusted-key.....	221
• overlay-gateway.....	222
• overlay-gateway/{gateway-name}/activate.....	223
• overlay-gateway/{gateway-name}/attach/vlan.....	224
• overlay-gateway/{gateway-name}/enable.....	225
• overlay-gateway/{gateway-name}/ip/access-group.....	226
• overlay-gateway/{gateway-name}/ip/interface/loopback.....	227
• overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/fabric-virtual-gateway.....	228
• overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/vrrp-extended-group.....	229
• overlay-gateway/{gateway-name}/ipv6/access-group.....	230
• overlay-gateway/{gateway-name}/mac.....	231
• overlay-gateway/{gateway-name}/map.....	232
• overlay-gateway/{gateway-name}/monitor.....	233
• overlay-gateway/{gateway-name}/sflow.....	234
• overlay-gateway/{gateway-name}/site.....	235
• overlay-gateway/{gateway-name}/site/{site-name}/bfd.....	236
• overlay-gateway/{gateway-name}/site/{site-name}/extend.....	237
• overlay-gateway/{gateway-name}/site/{site-name}/ip.....	238
• overlay-gateway/{gateway-name}/site/{site-name}/mac-learning/protocol/bgp.....	239
• overlay-gateway/{gateway-name}/site/{site-name}/shutdown.....	240
• overlay-gateway/{gateway-name}/type.....	241
• protocol/cfm.....	242
• protocol/link-oam.....	243
• protocol/lldp/advertise/dcbx-fcoe-app-tlv.....	244
• protocol/lldp/advertise/dcbx-fcoe-logical-link-tlv.....	245
• protocol/lldp/advertise/dcbx-iscsi-app-tlv.....	246
• protocol/lldp/advertise/dcbx-tlv.....	247
• protocol/lldp/advertise/dot1-tlv.....	248
• protocol/lldp/advertise/dot3-tlv.....	249
• protocol/lldp/advertise/optional-tlv.....	250
• protocol/lldp/description.....	251
• protocol/lldp/disable.....	252
• protocol/lldp/hello.....	253
• protocol/lldp/iscsi-priority.....	254
• protocol/lldp/mode.....	255
• protocol/lldp/multiplier.....	256
• protocol/lldp/profile/{profile-name}/advertise.....	257
• protocol/lldp/profile/{profile-name}/hello.....	258
• protocol/lldp/profile/{profile-name}/mode.....	259
• protocol/lldp/profile/{profile-name}/multiplier.....	260
• protocol/lldp/system-description.....	261
• protocol/lldp/system-name.....	262
• protocol/spanning-tree/mstp/bridge-priority.....	263

- protocol/spanning-tree/mstp/cisco-interoperability.....264
- protocol/spanning-tree/mstp/description.....265
- protocol/spanning-tree/mstp/error-disable-timeout/enable.....266
- protocol/spanning-tree/mstp/error-disable-timeout/interval.....267
- protocol/spanning-tree/mstp/forward-delay.....268
- protocol/spanning-tree/mstp/hello-time.....269
- protocol/spanning-tree/mstp/instance/priority.....270
- protocol/spanning-tree/mstp/instance/vlan.....271
- protocol/spanning-tree/mstp/max-age.....272
- protocol/spanning-tree/mstp/max-hops.....273
- protocol/spanning-tree/mstp/port-channel.....274
- protocol/spanning-tree/mstp/region.....275
- protocol/spanning-tree/mstp/revision.....276
- protocol/spanning-tree/mstp/shutdown.....277
- protocol/spanning-tree/mstp/transmit-holdcount.....278
- protocol/spanning-tree/pvst/bridge-priority.....279
- protocol/spanning-tree/pvst/description.....280
- protocol/spanning-tree/pvst/error-disable-timeout/enable.....281
- protocol/spanning-tree/pvst/error-disable-timeout/interval.....282
- protocol/spanning-tree/pvst/forward-delay.....283
- protocol/spanning-tree/pvst/hello-time.....284
- protocol/spanning-tree/pvst/max-age.....285
- protocol/spanning-tree/pvst/port-channel.....286
- protocol/spanning-tree/pvst/shutdown.....287
- protocol/spanning-tree/pvst/vlan/forward-delay.....288
- protocol/spanning-tree/pvst/vlan/hello-time.....289
- protocol/spanning-tree/pvst/vlan/max-age.....290
- protocol/spanning-tree/pvst/vlan/priority.....291
- protocol/spanning-tree/rpvst/bridge-priority.....292
- protocol/spanning-tree/rpvst/description.....293
- protocol/spanning-tree/rpvst/error-disable-timeout/enable.....294
- protocol/spanning-tree/rpvst/error-disable-timeout/interval.....295
- protocol/spanning-tree/rpvst/forward-delay.....296
- protocol/spanning-tree/rpvst/hello-time.....297
- protocol/spanning-tree/rpvst/max-age.....298
- protocol/spanning-tree/rpvst/port-channel.....299
- protocol/spanning-tree/rpvst/shutdown.....300
- protocol/spanning-tree/rpvst/transmit-holdcount.....301
- protocol/spanning-tree/rpvst/vlan/forward-delay.....302
- protocol/spanning-tree/rpvst/vlan/hello-time.....303
- protocol/spanning-tree/rpvst/vlan/max-age.....304
- protocol/spanning-tree/rpvst/vlan/priority.....305
- protocol/spanning-tree/rstp/bridge-priority.....306
- protocol/spanning-tree/rstp/description.....307
- protocol/spanning-tree/rstp/error-disable-timeout/enable.....308
- protocol/spanning-tree/rstp/error-disable-timeout/interval.....309
- protocol/spanning-tree/rstp/forward-delay.....310
- protocol/spanning-tree/rstp/hello-time.....311
- protocol/spanning-tree/rstp/max-age.....312
- protocol/spanning-tree/rstp/port-channel.....313
- protocol/spanning-tree/rstp/shutdown.....314
- protocol/spanning-tree/rstp/transmit-holdcount.....315

• protocol/spanning-tree/stp/bridge-priority.....	316
• protocol/spanning-tree/stp/description.....	317
• protocol/spanning-tree/stp/error-disable-timeout/enable.....	318
• protocol/spanning-tree/stp/error-disable-timeout/interval.....	319
• protocol/spanning-tree/stp/forward-delay.....	320
• protocol/spanning-tree/stp/hello-time.....	321
• protocol/spanning-tree/stp/max-age.....	322
• protocol/spanning-tree/stp/port-channel.....	323
• protocol/spanning-tree/stp/shutdown.....	324
• radius-server.....	325
• ras.....	327
• rmon/alarm.....	328
• rmon/event.....	330
• interface/{interface-type}/{interface-name}/isis.....	331
• router/isis/is-type.....	332
• route-map.....	333
• router/mpls.....	334
• router/mpls/ldp.....	335
• router/mpls/rsvp.....	337
• router/mpls/policy.....	338
• router/mpls/policy/transit-session-accounting.....	339
• router/mpls/policy/ingress-tunnel-accounting.....	340
• router/mpls/policy/qos-ttl-mode.....	341
• router/mpls/policy/traffic-engineering/isis.....	342
• router/mpls/policy/soft-preemption/cleanup-timer.....	343
• router/mpls/policy/cspf-computation-mode/rsvp-periodic-flooding-time.....	344
• router/mpls/policy/qos-ttl-mode.....	345
• router/mpls/policy/cspf-computation-mode/rapid-retry.....	346
• router/mpls/policy/cspf-computation-mode/retry-time.....	347
• router/mpls/policy/cspf-computation-mode/handle-ospf-neighbor-down.....	348
• router/mpls/policy/cspf-computation-mode/handle-isis-neighbor-down.....	349
• router/mpls/policy/cspf-computation-mode/cspf-interface-constraint.....	350
• router/mpls/policy/cspf-computation-mode/add-penalty.....	351
• router/mpls/policy/cspf-computation-mode/metric-type.....	352
• router/mpls/policy/cspf-computation-mode/ignore-overload-bit.....	353
• router/mpls/policy/backup-retry-time.....	354
• router/mpls/cspf-group/(cspf-group-name)/penalty.....	355
• router/mpls/lsp-xc-traps/enable.....	356
• router/mpls/cspf-group/(cspf-groupname)/penalty.....	357
• router/mpls/lsp-xc-traps/enable.....	358
• router/mpls/rsvp.....	359
• router/mpls/rsvp/reliable-messaging/rapid-retry-limit.....	360
• router/mpls/rsvp/reliable-messaging/rapid-retrans-interval.....	361
• router/mpls/rsvp/reliable-messaging/rapid-retrans-decay.....	362
• router/mpls/rsvp/refresh-reduction/bundle-message/bundle-send-delay.....	363
• router/mpls/rsvp/refresh-multiple.....	364
• router/mpls/rsvp/refresh-interval.....	365
• router/mpls/rsvp/g-rsvp-backup-bw-guarantee.....	366
• router/mpls/rsvp/global-rsvp-hello-acknowledgements.....	367
• router/mpls/rsvp/global-rsvp-hello/tolerance.....	368
• router/mpls/rsvp/global-rsvp-hello.....	369
• router/mpls/rsvp/refresh-reduction/summary-refresh.....	370

• qos-mpls.....	371
• sflow/agent-address.....	372
• sflow/collector.....	373
• sflow/enable.....	374
• sflow/polling-interval.....	375
• sflow/sample-rate.....	376
• sflow/source-ip.....	377
• sflow-profile.....	378
• system-monitor.....	379
• system-monitor-mail/fru (email).....	380
• system-monitor-mail/fru/enable.....	381
• system-monitor-mail/interface (email).....	382
• system-monitor-mail/interface/enable.....	383
• system-monitor-mail/relay.....	384
• system-monitor-mail/security (email).....	385
• system-monitor-mail/security/enable.....	386
• system-monitor-mail/sfp (email).....	387
• system-monitor-mail/sfp/enable.....	388
• system-watermark.....	389
• topology-group.....	390
• uda-access-list.....	391
• vlan/{vlan-name}/mac.....	392
• vlan/classifier/group.....	393
• vlan/classifier/rule/mac.....	394
• vlan/classifier/rule/proto.....	395
• vlan/dot1q.....	396
• vrf.....	397
• vrf/{vrf-name}/address-family/ipv4/unicast.....	398
• vrf/{vrf-name}/address-family/ipv4/unicast/max-route.....	399
• vrf/{vrf-name}/address-family/ipv6/unicast.....	400
• vrf/{vrf-name}/address-family/ipv6/unicast/max-route.....	401
• vrf/{vrf-name}/ip/router-id.....	402
• vxlan-visibility.....	403
• bna-config-cmd.....	404
• clear-mpls-ldp-statistics.....	405
• clear-mpls-lsp.....	406
• clear-mpls-rsvp-statistics.....	407
• clear-mpls-rsvp-statistics-neighbor-address.....	408
• clear-mpls-rsvp-statistics-neighbor-all.....	409
• dad-status.....	410
• fwdl-status.....	411
• get-arp.....	415
• get-contained-in-ID.....	416
• get-interface-detail.....	417
• get-interface-switchport.....	421
• get-ip-interface.....	422
• get-last-config-update-time.....	423
• get-lldp-neighbor-detail.....	424
• get-mac-acl-for-intf.....	426
• get-mac-address-table.....	427
• get-media-detail.....	429
• get-nameserver-detail.....	431

- get-netconf-client-capabilities..... 433
- get-port-channel-detail..... 434
- get-stp-brief-info..... 436
- get-system-uptime..... 438
- get-vlan-brief..... 439
- mpls-clear-all-ldp-sessions..... 441
- mpls-clear-one-ldp-sessions..... 442
- mpls-clear-statistics-type..... 443
- mpls-reopt-lsp..... 444
- reload..... 445
- set-http-application-url..... 446
- show-clock..... 447
- show-ntp..... 448
- show-raslog..... 449
- show-system-monitor..... 451
- show-zoning-enabled-configuration..... 453
- user-session-info..... 454



# aaa

Configures AAA authentication.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">  
  <aaa/>  
</aaa-config>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/accounting

Configures login or command accounting; either commands or login information are forwarded to accounting servers.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <aaa>
    <accounting/>
  </aaa>
</aaa-config>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/authentication

Configures the AAA login sequence.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <aaa>
    <authentication>
      <login>
        <first>local</first>
      </login>
    </authentication>
  </aaa>
</aaa-config>
```

## Parameters

*first*

Specifies the type of server that will be used for authentication, authorization, and accounting (AAA) on the switch. The local server is the default. Specify one of the following options:

### default

Specifies the default mode (local server). Authenticates the user against the local database only. If the password does not match or the user is not defined, the login fails

### ldap

Specifies the Lightweight Directory Access Protocol (LDAP) servers

### local

Specifies to use the local switch database if prior authentication methods are inactive

### local-auth-fallback

Specifies to use the local switch database if prior authentication methods are not active or if authentication fails

### local

Specifies the local switch database

### radius

Specifies the RADIUS servers

### local

Specifies to use the local switch database if prior authentication methods are inactive

### local-auth-fallback

Specifies to use the local switch database if prior authentication methods are not active or if authentication fails.

### tacacs+

Specifies the TACACS+ servers

### local

Specifies to use the local switch database if prior authentication methods are inactive

**local-auth-fallback**

Specifies to use the local switch database if prior authentication methods are not active or if authentication fails

# aaa/authentication/login

Configures the AAA login sequence.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <aaa>
    <authentication>
      <login/>
    </authentication>
  </aaa>
</aaa-config>
```

## Parameters

### authentication

Specifies the authentication, authorization, and accounting (AAA) on the switch.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/authentication/login/first

Configures the primary source of authentication.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <aaa>
    <authentication>
      <login>
        <first/>
      </login>
    </authentication>
  </aaa>
</aaa-config>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/authentication/login/second

Configures the secondary source of authentication.

## Usage

```
<aaa-config xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <aaa>
    <authentication>
      <login>
        <second/>
      </login>
    </authentication>
  </aaa>
</aaa-config>
```

## Parameters

### **authentication**

Specifies authentication.

### **login**

Specifies login.

### *second*

Specifies second.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/username

Configures a username for AAA login.

## Usage

```
<username xmlns="urn:brocade.com:mgmt:brocade-aaa">  
  <name>{req_val}</name>  
</username>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# aaa/username/desc

Adds describes for the username.

## Usage

```
<username xmlns="urn:brocade.com:mgmt:brocade-aaa">  
  <name>{req_val}</name>  
  <desc/>  
</username>
```

## Parameters

*name*

Specifies the username.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/username/encryption-level

Configures the encryption level for a username.

## Usage

```
<username xmlns="urn:brocade.com:mgmt:brocade-aaa">  
  <name>{req_val}</name>  
  <encryption-level/>  
</username>
```

## Parameters

*name*

Specifies the username.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# aaa/username/role

Configures the role of the user.

## Usage

```
<username xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <name>{req_val}</name>
  <role/>
</username>
```

## Parameters

*name*

Specifies the username.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# acl-policy

Configures, modifies, or retrieves the ACL configuration.

## Usage

```
<acl-policy xmlns="urn:brocade.com:mgmt:brocade-acl-policy">
  <global-acl-policy-conf-cmds/>
</acl-policy>
```

## Parameters

*global-acl-policy-conf-cmds*

Enters the global ACL policy commands mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# acl-policy/allow-conflicting-rules

Allows conflicting rules in an ACL table.

## Usage

```
<acl-policy xmlns="urn:brocade.com:mgmt:brocade-acl-policy">
  <global-acl-policy-conf-cmds>
    <allow-conflicting-rules/>
  </global-acl-policy-conf-cmds>
</acl-policy>
```

## Parameters

*global-acl-policy-conf-cmds*

Enters the global ACL policy commands mode.

*allow-conflicting-rules*

Allows conflicting rules in an ACL table.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# acl-policy/allow-duplicate-rules

Allows duplicate rules in an ACL table..

## Usage

```
<acl-policy xmlns="urn:brocade.com:mgmt:brocade-acl-policy">
  <global-acl-policy-conf-cmds>
    <allow-duplicate-rules/>
  </global-acl-policy-conf-cmds>
</acl-policy>
```

## Parameters

*global-acl-policy-conf-cmds*

Enters the global ACL policy commands mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# arp

Configures, modifies, or retrieves Address Resolution Protocol (ARP).

## Usage

```
<arp-entry xmlns="urn:brocade.com:mgmt:brocade-arp">  
  <arp-ip-address>{req_val}</arp-ip-address>  
</arp-entry>
```

## Parameters

*arp-ip-address*  
The IP address of the ARP entry.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain

Configures a bridge domain.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
</bridge-domain>
```

## Parameters

*bridge-domain-id*

Specifies the bridge domain ID.

*bridge-domain-type*

Specifies the bridge domain type..

**peer**

Specifies the peer.

Specifies the peer IP address.

**load-balance**

Specifies load-balance.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/bpdu-drop-enable

Enables the Bridge Protocol Data Units (BPDU)-drop feature.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <bpdu-drop-enable/>
</bridge-domain>
```

## Parameters

*bridge-domain-id*

Specifies the bridge-domain ID.

*bridge-domain-type*

Specifies the bridge domain type.

*bpdu-drop-enable*

Enables the BPDU drop.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/logical-interface

Configures the logical interface.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <logical-interface>
    <port-channel>
      <pc-lif-bind-id>{req_val}</pc-lif-bind-id>
    </port-channel>
  </logical-interface>
</bridge-domain>
```

## Parameters

*port-channel*

Specifies Port Channel as the logical interface.

*pc-lif-bind-id*

Specifies the Port Channel LIF bind ID.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/local-switching

Configures local switching.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <local-switching/>
</bridge-domain>
```

## Parameters

*bridge-domain-id*

Specifies the bridge-domain ID.

*bridge-domain-type*

Specifies the bridge domain type.

*local-switching*

Configures local switching.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/cos

Sets the cos value in the range 0 to 7.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <peer>
    <peer-ip>{req_val}</peer-ip>
    <cos/>
  </peer>
</bridge-domain>
```

## Parameters

**cos**

Specifies the CoS. The range is from 0 through 7.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain-id/(bridge-domain-type)/peer/(peer-ip)/load-balance

Retrieves load-balancing details.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <peer>
    <peer-ip>{req_val}</peer-ip>
    <load-balance/>
  </peer>
</bridge-domain>
```

## Parameters

### **peer**

Specifies the peer.

### *peer-ip*

Specifies the peer IP address.

### *load-balance*

Specifies load balance.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/peer/(peer-ip)/lsp

Configures label-switched paths (LSPs).

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <peer>
    <peer-ip>{req_val}</peer-ip>
    <lsp/>
  </peer>
</bridge-domain>
```

## Parameters

*bridge-domain-id*

Specifies the bridge domain ID.

*bridge-domain-id*

Specifies the bridge domain type.

**peer**

Specifies the peer.

*peer-ip*

Specifies the peer IP address.

**lsp**

Specifies the LSP.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/pw-profile

Sets the Pw-profile name.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <pw-profile-name/>
</bridge-domain>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/statistics

Configures statistics for a bridge domain?

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">  
  <bridge-domain-id>{req_val}</bridge-domain-id>  
  <bridge-domain-type>{req_val}</bridge-domain-type>  
  <statistics/>  
</bridge-domain>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# bridge-domain/(bridge-domain-id)/(bridge-domain-type)/vc-id

Configures the VC ID for the bridge domain.

## Usage

```
<bridge-domain xmlns="urn:brocade.com:mgmt:brocade-bridge-domain">
  <bridge-domain-id>{req_val}</bridge-domain-id>
  <bridge-domain-type>{req_val}</bridge-domain-type>
  <vc-id-num/>
</bridge-domain>
```

## Parameters

*vc-id-num*

Specifies the VC ID.

*bridge-domain-type*

Specifies the bridge domain type.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# chassis

Configures, modifies, or retrieves the IP address of the virtual chassis.

## Usage

```
<hide-virtual-ip-holder xmlns="urn:brocade.com:mgmt:brocade-chassis">
  <chassis>
    <virtual-ip> 10.1.1.1</virtual-ip/>
  </chassis>
</hide-virtual-ip-holder>
```

## Parameters

*virtual-ip*

The IP address of the virtual chassis.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# chassis/virtual-ip

Configures the chassis the virtual IPv4 address.

## Usage

```
<hide-virtual-ip-holder xmlns="urn:brocade.com:mgmt:brocade-chassis">
  <chassis>
    <virtual-ip/>
  </chassis>
</hide-virtual-ip-holder>
```

## Parameters

*virtual-ip*

Specifies the IP address of the virtual chassis.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# chassis/virtual-ipv6

Configures the chassis the virtual IPv4 address.

## Usage

```
<hide-virtual-ip-holder xmlns="urn:brocade.com:mgmt:brocade-chassis">
  <chassis>
    <virtual-ipv6/>
  </chassis>
</hide-virtual-ip-holder>
```

## Parameters

*virtual-ipv6*

Specifies the IPv6 address of the virtual chassis.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# clock

Configures, modifies, or retrieves the system time zone.

## Usage

```
<clock-sa xmlns="urn:brocade.com:mgmt:brocade-clock">  
  <clock/>  
</clock-sa>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# clock/time-zone

Configures, modifies, or retrieves the system time zone.

## Usage

```
<clock-sa xmlns="urn:brocade.com:mgmt:brocade-clock">
  <clock>
    <timezone/>
  </clock>
</clock-sa>
```

## Parameters

*timezone*

Specifies the time zone.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# cluster/{cluster-name}/{cluster-id}

Configures, retrieves, and modifies Multi-Chassis Trunking (MCT) cluster.

## Usage

```
<cluster xmlns="urn:brocade.com:mgmt:brocade-mct">
  <cluster-name>{req_val}</cluster-name>
  <cluster-id>{req_val}</cluster-id>
</cluster>
```

## Parameters

*cluster-name*

Specifies the MCT cluster name .

*cluster-id*

Specifies the MCT cluster ID.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# dai

Manages the IP access list.

## Usage

```
<dai-config xmlns="urn:brocade.com:mgmt:brocade-dai">  
  <arp/>  
</dai-config>
```

## Parameters

*arp*

Specifies the ARP.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.



# dai/arp/access-list

Manages the IP access list.

## Usage

```
<dai-config xmlns="urn:brocade.com:mgmt:brocade-dai">
  <arp>
    <access-list>
      <acl-name>{req_val}</acl-name>
    </access-list>
  </arp>
</dai-config>
```

## Parameters

*acl-name*

Specifies the access control list (ACL) name.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.

# delay-link-event

Manages the delay link event (DLE).

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <delay-link-event xmlns="urn:brocade.com:mgmt:brocade-dle">
      <delay-link operation="delete"/>
    </delay-link-event>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the Physical ethernet interface.

### *name*

Specifies the interface name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# dot1x

Configures, retrieves, and modifies 802.1X authentication.

## Usage

```
<dot1x xmlns="urn:brocade.com:mgmt:brocade-dot1x">
  <test>
    <timeout/>
  </test>
</dot1x>
```

## Parameters

*test* timeout

The readiness test interval value in seconds. Valid values range from 1 through 65535. The default readiness test interval is 10 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

## dot1x/test

Configures the 802.1X readiness test timeout.

### Usage

```
<dot1x xmlns="urn:brocade.com:mgmt:brocade-dot1x">  
  <test>  
    <timeout>20</timeout>  
  </test>  
</dot1x>
```

### Parameters

*timeout*

Specifies the interval value in seconds. The value can range from 1 through 65535

# dot3ah

Manages the Link OAM Protocol.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <link-oam xmlns="urn:brocade.com:mgmt:brocade-dot3ah"/>
</protocol>
```

## Parameters

*protocol*

Specifies the protocol.

## History

Release version	History
17r.1.01	This NETCONF call was introduced.

# event-handler

Creates an event-handler profile.

## Usage

```
<event-handler xmlns="urn:brocade.com:mgmt:brocade-event-handler">
  <event-handler-list>
    <name>{req_val}</name>
  </event-handler-list>
</event-handler>
```

## Parameters

*name*

Specifies the name of the event-handler profile. The value can range from 1 through 32 characters. The first character must be alphabetic.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.

# event-handler/{event-handler-name}/action

Creates or accesses an event-handler profile, which can execute a Python script when a specified trigger occurs.

## Usage

```
<event-handler xmlns="urn:brocade.com:mgmt:brocade-event-handler">
  <activate>
    <name>
      <name>{req_val}</name>
      <action-timeout/>
    </name>
  </activate>
</event-handler>
```

## Parameters

*name*

Specifies the name of the event-handler profile.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.

# hardware

Configures, modifies, or retrieves the hardware management configuration.

## Usage

```
<hardware xmlns="urn:brocade.com:mgmt:brocade-hardware">
  <connector>
    <name>{req_val}</name>
    <breakout>
      <cage-mode/>
    </breakout>
  </connector>
</hardware>
```

## Parameters

**connector** *name*

Specifies the hardware connector name.

**breakout** *name*

Specifies breakout and enters cage-mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/ip/ access-group

Applies rules specified in an access control list (ACL) to traffic entering or exiting an interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <fortygigabitethernet>
    <name>1/0/50</name>
    <ip-acl-interface xmlns="urn:brocade.com:mgmt:brocade-ip-access-list">
      <ip>
        <access-group>
          <ip-access-list>acl11</ip-access-list>
          <ip-direction>out</ip-direction>
        </access-group>
      </ip>
    </ip-acl-interface>
  </fortygigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*ip-access-list*

Specifies the ACL name

*ip-direction*

Specifies the IP direction.

**in**

Specifies the ACL binding direction as ingress.

**out**

Specifies the ACL binding direction as egress.

# interface/{interface-type}/{interface-name}/ip/arp-aging-timeout

Configures how long an ARP entry stays in cache before the cache refreshes.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <ip-config xmlns="urn:brocade.com:mgmt:brocade-ip-config">
        <arp-aging-timeout>220</arp-aging-timeout>
      </ip-config>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*arp-aging-timeout*

Determines how long an ARP entry stays in cache. The timeout value can range from 0 through 240 minutes.

# interface/{interface-type}/{interface-name}/ip/dhcp/relay/gateway

Configures the IP DHCP Relay on a Layer 3 gateway interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <interface-te-dhcp-conf xmlns="urn:brocade.com:mgmt:brocade-dhcp">
        <dhcp>
          <relay>
            <gateway>1.1.1.1</gateway>
          </relay>
        </dhcp>
      </interface-te-dhcp-conf>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*gateway*

Specifies the IPv4 gateway address of the DHCP server where the DHCP client requests are to be forwarded

# interface/{interface-type}/{interface-name}/ip/igmp/immediate-leave

Removes a group from the IGMP table immediately following receipt of a Leave Group request.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <igmp-phy-intf-cfg xmlns="urn:brocade.com:mgmt:brocade-igmp">
        <igmp>
          <immediate-leave></immediate-leave>
        </igmp>
      </igmp-phy-intf-cfg>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**immediate-leave**

Enables immediate leave processing

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/ last-member-query-count

Sets the last-member query count.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface-vlan xmlns="urn:brocade.com:mgmt:brocade-interface">
  <interface>
    <vlan>
      <name>1</name>
      <ip>
        <igmp xmlns="urn:brocade.com:mgmt:brocade-igmp-snooping">
          <last-member-query-count>3</last-member-query-count>
        </igmp>
      </ip>
    </vlan>
  </interface>
</interface-vlan>
```

## Parameters

*name*

Specifies the interface name

*last-member-query-count*

Specifies the last member query count value. The value can range from 2 through 10. The default value is 2

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/ last-member-query-interval

Configures last member query interval.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <igmp-phy-intf-cfg xmlns="urn:brocade.com:mgmt:brocade-igmp">
        <igmp>
          <last-member-query-interval>1500</last-member-query-interval>
        </igmp>
      </igmp-phy-intf-cfg>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*last-member-query-interval*

Specifies last member query interval in milliseconds. The interval can range from 100 through 25500. The default value is 1000 milliseconds

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/ query-interval

Configures the query interval for a VLAN. The query interval is the amount of time between IGMP query messages sent by the switch.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <igmp-phy-intf-cfg xmlns="urn:brocade.com:mgmt:brocade-igmp">
        <igmp>
          <query-interval>150</query-interval>
        </igmp>
      </igmp-phy-intf-cfg>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*query-interval*

Specifies the response time in seconds. The interval can range from 1 through 18000 seconds. The default value is 125 seconds.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/ query-max-response-time

Configures the maximum response time for IGMP queries

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <igmp-phy-intf-cfg xmlns="urn:brocade.com:mgmt:brocade-igmp">
        <igmp>
          <query-max-response-time>15</query-max-response-time>
        </igmp>
      </igmp-phy-intf-cfg>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*query-max-response-time*

Specifies IGMP query max response time in seconds. The response time can range from 1 through 25 seconds. By default, the response time is set to 10 seconds.

## History

Release version	History
7.0.0	This Netconf call was introduced.



# interface/{interface-type}/{interface-name}/ip/igmp/ robustness-variable

Configures the robustness variable.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface-vlan xmlns="urn:brocade.com:mgmt:brocade-interface">
  <interface>
    <vlan>
      <name>1</name>
      <ip>
        <igmp xmlns="urn:brocade.com:mgmt:brocade-igmp-snooping">
          <robustness-variable>3</robustness-variable>
        </igmp>
      </ip>
    </vlan>
  </interface>
</interface-vlan>
```

## Parameters

*name*

Specifies the interface name.

*robustness-variable*

Specifies the robustness value. The value can range from 2 through 10. The default value is 2.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/startup-query-count

Configures the start up query count.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface-vlan xmlns="urn:brocade.com:mgmt:brocade-interface">
  <interface>
    <vlan>
      <name>1</name>
      <ip>
        <igmp>
          <startup-query-count>3</startup-query-count>
        </igmp>
      </ip>
    </vlan>
  </interface>
</interface-vlan>
```

## Parameters

*name*

Specifies the interface name.

*startup-query-count*

Specifies the startup query count value. The value can range from 1 through 10. The default value is 2.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/igmp/startup-query-interval

Configures the start up query interval.

## Usage

Supported interface types are: Port-Channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface-vlan xmlns="urn:brocade.com:mgmt:brocade-interface">
  <interface>
    <vlan>
      <name>1</name>
      <ip>
        <igmp xmlns="urn:brocade.com:mgmt:brocade-igmp-snooping">
          <startup-query-interval>10</startup-query-interval>
        </igmp>
      </ip>
    </vlan>
  </interface>
</interface-vlan>
```

## Parameters

*name*

Specifies the interface name.

*startup-query-interval*

Specifies the start up query interval value. The value can range from 1 through 450. The default value is 1.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/pim/dr-priority

Configures the designated router (DR) priority of a protocol Independent Multicast (PIM) enabled interface.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <fortygigabitethernet>
    <name>1/0/50</name>
    <ip>
      <pim-intf-phy-cont xmlns="urn:brocade.com:mgmt:brocade-pim">
        <pim-int-cmd>
          <pim>
            <dr-priority>1</dr-priority>
          </pim>
        </pim-int-cmd>
      </pim-intf-phy-cont>
    </ip>
  </fortygigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*dr-priority*

Specifies the DR priority value. The value can range from 0 through 65535. The default value is 1

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/pim/neighbor-filter

By default, directly connected routers under protocol-independent multicast (PIM) form neighborhood with one another. Using this command, you can block specified routers from neighborhood.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <fortygigabitethernet>
    <name>1/0/50</name>
    <ip>
      <pim-intf-phy-cont xmlns="urn:brocade.com:mgmt:brocade-pim">
        <pim-int-cmd>
          <pim>
            <neighbor-filter>prefix1</neighbor-filter>
          </pim>
        </pim-int-cmd>
      </pim-intf-phy-cont>
    </ip>
  </fortygigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*neighbor-filter*

Specifies the name of a prefix list defined by the ip prefix-list command. Permitted values are between 1 and 63 characters. Although the first character must be alphabetic, the others can be alphanumeric, underscores (\_), or minus signs (-).

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/pim-sparse

Enables Protocol Independent Multicast Sparse Mode.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <fortygigabitethernet>
    <name>1/0/50</name>
    <ip>
      <pim-intf-phy-cont xmlns="urn:brocade.com:mgmt:brocade-pim">
        <pim-int-cmd>
          <pim-sparse></pim-sparse>
        </pim-int-cmd>
      </pim-intf-phy-cont>
    </ip>
  </fortygigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**pim-sparse**

Enables PIM sparse mode.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/policy

Enables policy-based routing (PBR) on any Layer 3 interface after ACLs and route map entries are configured.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <fortygigabitethernet>
    <name>1/0/50</name>
    <ip-pbr-interface xmlns="urn:brocade.com:mgmt:brocade-ip-policy">
      <ip>
        <policy>
          <route-map>
            <route-map-name>map1</route-map-name>
          </route-map>
        </policy>
      </ip>
    </ip-pbr-interface>
  </fortygigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*route-map-name*

Specifies the name of the route-map

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ip/proxy-arp

Enables proxy ARP on an interface.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <ip>
      <ip-config xmlns="urn:brocade.com:mgmt:brocade-ip-config">
        <proxy-arp></proxy-arp>
      </ip-config>
    </ip>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**proxy-arp**

Enables proxy ARP.

## History

Release version	History
7.0.0	This Netconf call was introduced.



# interface/{interface-type}/{interface-name}/ip/router/isis

Configures the Intermediate System-to-Intermediate System (IS-IS) routing at the interface level.

## Usage

```
<router xmlns="urn:brocade.com:mgmt:brocade-isis" xmlns:y="http://brocade.com/ns/rest" y:self="/rest/
config/running/interface/Ve/101/ip/router">
<isis>true</isis>
</router>
</interface>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interfacename}/ipv6/router/isis

Configures the IS-IS routing protocol.

## Usage

```
<router xmlns="urn:brocade.com:mgmt:brocade-isis" xmlns:y="http://brocade.com/ns/rest" y:self="/rest/config/running/interface/Ve/101/ipv6/router">  
<isis>true</isis>  
</router>  
</interface>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis

Configures the Intermediate System-to-Intermediate System (IS-IS) routing at the interface level.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">1
  <ethernet>
    <name>{req_val}</name>
    <ip>
      <intf-router-isis xmlns="urn:brocade.com:mgmt:brocade-isis"/>
    </ip>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**ip**

Specifies the IP address.

**ethernet**

Specifies the physical Ethernet interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/link-error-disable

Configures port link dampening (PLD).

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <link-error-disable xmlns="urn:brocade.com:mgmt:brocade-pld">
      <wait-time-in-sec/>
    </link-error-disable>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies Ethernet interface.

### *name*

Specifies the interface name.

### *link-error-disable-entry*

Specifies the link error disable entry.

### *wait-time-in-sec*

Specifies the wait time.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/link-fault-signaling

Configures, retrieves, and modifies Link Fault Signaling (LFS).

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <link-fault-signaling xmlns="urn:brocade.com:mgmt:brocade-lfs">
      <tx/>
    </link-fault-signaling>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies Ethernet interface.

### name

Specifies the interface name.

### tx

Specifies the tx direction.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/ access-group

Applies rules specified in an IPv6 access control list (ACL) to traffic entering or exiting an interface.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <access-group xmlns="urn:brocade.com:mgmt:brocade-ipv6-access-list">
        <ipv6-access-list>acl12</ipv6-access-list>
        <ip-direction>in</ip-direction>
        <traffic-type>routed</traffic-type>
      </access-group>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*ipv6-access-list*

Specifies the name of the standard or extended IP access list

*ip-direction*

Specifies the binding direction

**ingress**

Ingress direction

**egress**

Egress direction

*traffic-type*

Specifies the traffic type

**routed**

Filter only routed traffic. This parameter is not valid for management or overlaygateway interfaces

**switched**

Filter only switched traffic. This parameter is not valid for management or overlay-gateway interfaces.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/dhcp/relay/address

Configures the IPv6 DHCP Relay on a Layer 3 interface.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <interface-phy-dhcp-conf xmlns="urn:brocade.com:mgmt:brocade-dhcpv6">
        <dhcp>
          <relay>
            <servers>
              <relay-ip-addr>2001:db8::12d:1300</relay-ip-addr>
              <use-vrf>mgmt-vrf</use-vrf>
              <interface>
                <interface-type>tengigabitethernet</interface-type>
                <interface-name>1/0/2</interface-name>
              </interface>
            </servers>
          </relay>
        </dhcp>
      </interface-phy-dhcp-conf>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*relay-ip-addr*

Specifies the IPv6 address of the DHCP server where the DHCP client requests are to be forwarded

*use-vrf*

Use this option if the VRF where the DHCP server is located is different from the VRF of the interface where the client is connected. Specifies the VRF name

*interface-type*

The type of interface, such as gigabitEthernet, TengigabitEthernet, FortygigabitEthernet, HundredgigabitEthernet, or Ve interface.

*interface-type*

The type of interface, such as Ethernet or Ve interface.

*interface-name*

The interface number

interface/{interface-type}/{interface-name}/ipv6/dhcp/relay/address

## History

Release version	History
7.0.0	This Netconf call was introduced.



# interface/{interface-type}/{interface-name}/ipv6/nd/ broadcast-mac-trap

Enables the trap for all the IPv6 packets with broadcast mac.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <broadcast-mac-trap></broadcast-mac-trap>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**broadcast-mac-trap**

Enables the trap for all the IPv6 packets with broadcast mac

# interface/{interface-type}/{interface-name}/ipv6/nd/cache

Configures the time interval after which the IPv6 Neighbor Discovery cache is deleted or refreshed.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <cache>
              <expire>14000</expire>
            </cache>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*expire*

Specifies the time interval in minutes. The interval can range from 1 through 240 minutes. The default value is 240 minutes

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ ipv6/nd/dad

Configures the number of IPv6 Neighbor Discovery Neighbor Solicitation (NS) messages to be sent as part of duplicate address detection (DAD).

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <dad>
              <attempts>3</attempts>
              <time>2</time>
            </dad>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*attempts*

Specifies the number of solicitations. The value can range from 0 through 10. By default, the value is set to 2.

*time*

Specifies the time in seconds. The value can range from 1 through 5. The default value is 1

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/nd/hoplimit

Configures the number of hops to be advertised in IPv6 Neighbor Discovery Router Advertisement (RA) messages.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <hoplimit>65</hoplimit>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*hoplimit*

Specifies the number of hops to be advertised. The number can range from 0 through 255. The default value is 64

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/nd/managed-config-flag

In IPv6 Neighbor Discovery, indicates to hosts on a local link that they must use the stateful autoconfiguration feature to obtain IPv6 addresses for their interfaces.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <managed-config-flag></managed-config-flag>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

### **managed-config-flag**

Indicates to hosts on a local link that they must use the stateful autoconfiguration feature to obtain IPv6 addresses for their interfaces

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ ipv6/nd/mtu

Sets the size of the maximum transmission unit (MTU) that is advertised in Neighbor Discovery Router Advertisement (RA) messages.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <mtu>1550</mtu>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the name of the interface

*mtu*

Specifies the size, in bytes, of the MTU that is advertised. The value can range from 1280 through 65535. The default value is 1500

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ ipv6/nd/ns-interval

Configures the interval for address resolution between IPv6 Neighbor Discovery Neighbor Solicitation (NS) messages.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <ns-interval>2</ns-interval>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*ns-interval*

Specifies the number of seconds between neighbor solicitation messages. The value can range from 1 through 5 seconds. The default value is 1 second

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/nd/ other-config-flag

In IPv6 Neighbor Discovery, indicates to hosts on a local link that they can use the stateful autoconfiguration feature to obtain configuration settings other than IPv6 address information for their interfaces.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <other-config-flag></other-config-flag>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

### **other-config-flag**

indicates to hosts on a local link that they can use the stateful autoconfiguration feature to obtain configuration settings other than IPv6 address information for their interfaces

## History

Release version	History
7.0.0	This Netconf call was introduced.



# interface/{interface-type}/{interface-name}/ipv6/nd/prefix

Configures which IPv6 prefixes are included in IPv6 Neighbor Discovery Router Advertisement (RA) messages.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <prefix>
              <prefix-ipv6-address>2001:db8:12d:1300::/64</prefix-ipv6-address>
              <lifetime>
                <no-advertise></no-advertise>
              </lifetime>
            </prefix>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*prefix-ipv6-address*

Specifies the IPv6 prefix in hexadecimal with 16-bit values between colons

**no-advertise**

Specifies no advertisement.

## History

Release version	History
7.0.0	This Netconf call was introduced.

# interface/{interface-type}/{interface-name}/ ipv6/nd/ra-interval

Configures the maximum interval range and minimum interval at which IPv6 Neighbor Discovery Router Advertisement (RA) messages are sent.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <ra-interval>
              <max-interval>650</max-interval>
              <min>250</min>
            </ra-interval>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*max-interval*

Specifies the maximum interval range in seconds. The interval can range from 4 through 1800 seconds. The default interval is set from 200 through 600, with messages sent randomly within that interval

*min*

Specifies the minimum interval in seconds. The interval can range from 0 through 1800. The default interval is set to 200 seconds

# interface/{interface-type}/{interface-name}/ ipv6/nd/ra-lifetime

Configures the amount of time in IPv6 Neighbor Discovery that a router is considered a valid default router.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <ra-lifetime>2000</ra-lifetime>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*ra-lifetime*

Specifies the time in seconds. The time can range from 0 through 9000. The default value is 1800

# interface/{interface-type}/{interface-name}/ipv6/nd/reachable-time

Configures the amount of time in IPv6 Neighbor Discovery that a device considers a remove IPv6 node reachable.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <reachable-time>1</reachable-time>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*reachable-time*

Specifies the time in milliseconds. The value can range from 0 through 3600000 milliseconds. The default time is set to 0

# interface/{interface-type}/{interface-name}/ipv6/nd/retrans-timer

Configures the time advertised between IPv6 Neighbor Discovery Neighbor Solicitation (NS) messages.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <retrans-timer>1</retrans-timer>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*retrans-timer*

Specifies the interval in milliseconds, at which NS messages are sent. The interval can range from 0 through 4294967295. The default interval is set to 0

# interface/{interface-type}/{interface-name}/ipv6/nd/suppress-ra

Disables the sending of ICMPv6 Router Advertisement (RA) messages, including those sent in response to a solicitation as well as MTUs.

## Usage

Supported interface types are: Port-channel, Management, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/1</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <suppress-ra>
              <suppress-ra-all></suppress-ra-all>
            </suppress-ra>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*suppress-ra*

Disables the sending of ICMPv6 Router Advertisement (RA) messages

**all**

Disables the sending of all RA messages, including those sent in response to a solicitation

**mtu**

Disables the sending of MTUs in RA messages

# interface/{interface-type}/{interface-name}/ipv6/ra-dns-server

Configures, modifies, or retrieves the Domain Name System (DNS) server address and the lifetime multiplier information to IPv6 hosts in the Router Advertisement (RA) message.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <ra-dns-server>
              <dns-server-prefix>{req_val}</dns-server-prefix>
            </ra-dns-server>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies Ethernet interface.

### name

Specifies the interface name.

### ipv6

Specifies IPv6 address.

### nd

Specifies the neighbor discovery protocol.

### dns-server-prefix

Specifies the prefix of the DNS server.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ra-dns-server/hoplimit

Configures the number of hops to be advertised in IPv6 neighbor discovery router advertisement (RA) messages.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <hoplimit/>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies Ethernet interface.

### name

Specifies the interface name.

### ipv6

Specifies IPv6 address.

### number

Specifies the number of hops to be advertised.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/ra-dns-server/mtu

Sets the size of the maximum transmission unit (MTU) that is advertised in Neighbor Discovery Router Advertisement (RA) messages.

## Usage

```
<routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
    <ve>
      <name>{req_val}</name>
      <ipv6 xmlns="urn:brocade.com:mgmt:brocade-ipv6-config">
        <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
          <ipv6-intf-cmds>
            <nd>
              <mtu/>
            </nd>
          </ipv6-intf-cmds>
        </ipv6-nd-ra>
      </ipv6>
    </ve>
  </interface>
</routing-system>
```

## Parameters

- ve**  
Specifies virtual Ethernet interface.
- name**  
Specifies the interface name.
- ipv6**  
Specifies IPv6 address.
- mtu number**  
Specifies the size, in bytes, of the MTU that is advertised.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ra-dns-server/other-config-flag

In IPv6 Neighbor Discovery, indicates to hosts on a local link that they can use the stateful autoconfiguration feature to obtain configuration settings other than IPv6 address information for their interfaces.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ve>
    <name>{req_val}</name>
    <ipv6 xmlns="urn:brocade.com:mgmt:brocade-ipv6-config">
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <other-config-flag/>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </ve>
</interface>
```

## Parameters

- ve**  
Specifies virtual Ethernet interface.
- name*  
Specifies the interface name.
- ipv6**  
Specifies IPv6 address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ipv6/ra-domain-name

Configures the domain name of the Domain Name System (DNS) suffix and the lifetime multiplier information to IPv6 hosts in the Router Advertisement (RA) message.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <ipv6>
      <ipv6-nd-ra xmlns="urn:brocade.com:mgmt:brocade-ipv6-nd-ra">
        <ipv6-intf-cmds>
          <nd>
            <ra-domain-name>
              <domain-name-string>{req_val}</domain-name-string>
              <domain-name-lifetime-multiplier/>
            </ra-domain-name>
          </nd>
        </ipv6-intf-cmds>
      </ipv6-nd-ra>
    </ipv6>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies Ethernet interface.

### name

Specifies the interface name.

### ipv6

Specifies IPv6.

### ra-domain-name

Specifies the RA domain name.

### domain-name-string

Specifies the domain name.

### domain-name-lifetime-multiplier

Specifies domain name option and lifetime multiplier for DNS search list option.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/lldp/dcbx-version

Specifies which version of the Data Center Bridging Exchange (DCBX) protocol to use.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
      <dcbx-version>cee</dcbx-version>
    </lldp>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*dcbx-version*

Specifies the version

**auto**

Auto-adjusts the DCBX protocol version. This is the default setting

**cee**

Uses the Converged Enhanced Ethernet (CEE) DCBX version.

# interface/{interface-type}/{interface-name}/lldp/disable

Disables the Link Layer Discovery Protocol (LLDP) on the interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
      <disable></disable>
    </lldp>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/5</name>
    <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
      <disable></disable>
    </lldp>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**disable**

Disables the Link Layer Discovery Protocol (LLDP) on the interface

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/lldp/iscsi-priority

Configures the priority that will be advertised in the DCBX iSCSI TLV for a specified interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
      <iscsi-priority>3</iscsi-priority>
    </lldp>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*iscsi-priority*

Specifies the priority value. The value can range from 0 through 7

# interface/{interface-type}/{interface-name}/lldp/profile

Applies a Link Layer Discovery Protocol (LLDP) profile to an interface

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
      <profile>profile1</profile>
    </lldp>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*profile*

Specifies the profile name

# interface/{interface-type}/{interface-name}/isis/reverse-metric

Configures the reverse metric value on a single IS-IS interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-reverse-metric/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the interface name.

### intf-isis

Specifies the ISIS interface.

### interface-reverse-metric

Specifies interface reverse metric.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/isis/priority

Determines the priority of the interface for being elected as a designated IS.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-priority/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the name of Ethernet interface.

### intf-isis

Specifies the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/ point-to-point

Configures the network type for the IS-IS interface as point-to-point.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-point-to-point/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the ISIS interface name.

### intf-isis

Configures the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/passive

Disables adjacency formation and advertisements on an IS-IS interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-passive/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the physical Ethernet interface.

### *name*

Specifies the ISIS interface name.

### *intf-isis*

Configures the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/metric

Configures the value of an IS-IS metric.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-metric>
            <interface-metric-level>{req_val}</interface-metric-level>
          </interface-metric>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the physical Ethernet interface.

### *name*

Specifies the ISIS interface name.

### *intf-isis*

Configures the ISIS interface.

### *interface-metric*

Specifies the ISIS interface.

### *interface-metric-level*

Specifies the metric level for the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/ldp-sync

Enables synchronization with IS-IS for an interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-ldp-sync/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the ISIS interface name.

### intf-isis

Configures the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/ipv6-metric

Configures the metric value for an interface under IPv6 IS-IS MT.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-ipv6>
            <interface-ipv6-metric>
              <interface-ipv6-metric-level>{req_val}</interface-ipv6-metric-level>
            </interface-ipv6-metric>
          </interface-ipv6>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the ISIS interface name.

### intf-isis

Configures the ISIS interface.

### interface-ipv6

Specifies the IPv6 ISIS interface.

### interface-ipv6-metric

Specifies the IPv6 ISIS interface metric.

### interface-ipv6-metric-level

Specifies the metric level for the ISIS IPv6 interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/hello-multiplier

Specifies the number of IS-IS hello packets a neighbor must miss before a device declares adjacency as down.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-hello-multiplier>
            <interface-hello-multiplier-level>{req_val}</interface-hello-multiplier-level>
          </interface-hello-multiplier>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### *name*

Specifies the interface name.

### intf-isis

Specifies the ISIS interface.

### interface-hello-multiplier

Specifies interface hello multiplier.

### *interface-hello-multiplier-level*

Specifies the hello interval multiplier level .

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/hello-interval

Specifies how often an IS-IS interface sends hello messages to its IS-IS neighbors.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-hello-interval>
            <interface-hello-interval-level>{req_val}</interface-hello-interval-level>
          </interface-hello-interval>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### *name*

Specifies the interface name.

### intf-isis

Specifies the ISIS interface.

### interface-hello-interval

Specifies interface hello interval.

### *interface-hello-interval-level*

Specifies the hello interval level.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/isis/hello-padding

Re-enables IS-IS hello padding at the interface level.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-hello>
            <interface-hello-padding/>
          </interface-hello>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the physical Ethernet interface.

### name

Specifies the interface name.

### intf-isis

Specifies the ISIS interface.

### interface-hello

Specifies interface hello.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.
Release version	History
17s.1.00	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/ circuit-type

Configures the type of adjacency used for an IS-IS interface.

## Usage

```
<routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
    <loopback xmlns="urn:brocade.com:mgmt:brocade-intf-loopback">
      <id>{req_val}</id>
      <intf-isis xmlns="urn:brocade.com:mgmt:brocade-isis">
        <interface-isis>
          <circuit-type/>
        </interface-isis>
      </intf-isis>
    </loopback>
  </interface>
```

## Parameters

*id*

Specifies the ID.

**interface-isis**

Configures the ISIS interface.

**circuit-type**

Specifies the circuit type.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/auth-mode

Specifies the type of authentication used for an IS-IS interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-auth-mode/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the physical Ethernet interface.

### *name*

Specifies the interface name.

### *interface-auth-mode*

Specifies the authorization mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/auth-key

Configures an authentication key for a specified IS-IS interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <interface-auth-key>
            <interface-auth-key-level>{req_val}</interface-auth-key-level>
          </interface-auth-key>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the physical Ethernet interface.

### *name*

Specifies the interface name.

### *interface-isis*

Specifies the ISIS interface.

### **interface-auth-key**

Configures the ISIS interface authorization key.

### *interface-auth-key-level*

Specifies the authorization key level for the ISIS interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis/auth-check

Enables authentication checking for an IS-IS interface.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <interface-eth-isis-conf xmlns="urn:brocade.com:mgmt:brocade-isis">
      <intf-isis>
        <interface-isis>
          <auth-check/>
        </interface-isis>
      </intf-isis>
    </interface-eth-isis-conf>
  </ethernet>
</interface>
```

## Parameters

### **ethernet**

Specifies the physical Ethernet interface.

### *name*

Specifies the interface name.

### *interface-isis*

Specifies the ISIS interface.

### *auth-check-level1*

Specifies the authorization check level 1.

### *interface-auth-check-level1-disable*

Disables the interface authorization check level 1.

### *auth-check-level2*

Specifies the authorization check level 2.

### *interface-auth-check-level2-disable*

Disables the interface authorization check level 2.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/link-oam-interface

Configures the Link OAM protocol on an Ethernet interface.

## Usage

```
interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <link-oam-interface xmlns="urn:brocade.com:mgmt:brocade-dot3ah">
      <enable/>
    </link-oam-interface>
  </ethernet>
</interface>
```

## History

Release version	History
17r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/link-oam/link-fault/action

Sets action for a Link Fault event .

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <link-oam-interface xmlns="urn:brocade.com:mgmt:brocade-dot3ah">
      <remote-failure>
        <link-fault>
          <link-fault-action/>
        </link-fault>
      </remote-failure>
    </link-oam-interface>
  </ethernet>
</interface>
```

## History

Release version	History
17r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/link-oam-interface/allow-loopback

Enables or disables loopback.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <ethernet>  
    <name>{req_val}</name>  
    <link-oam-interface xmlns="urn:brocade.com:mgmt:brocade-dot3ah">  
      <allow-loopback/>  
    </link-oam-interface>  
  </ethernet>  
</interface>
```

## History

Release version	History
17r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/rmon/collection/history

Collects Ethernet group statistics for later retrieval

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <rmon xmlns="urn:brocade.com:mgmt:brocade-rmon">
      <collection>
        <history-control-entry>
          <history-control-index>25</history-control-index>
          <history-control-buckets-requested>10</history-control-buckets-requested>
          <history-control-interval>2000</history-control-interval>
          <history-control-owner>admin</history-control-owner>
        </history-control-entry>
      </collection>
    </rmon>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*history-control-index*

Specifies the RMON collection control index value. The value can range from 1 through 65535.

*history-control-buckets-requested*

Specifies the maximum number of buckets for the RMON collection history. The value can range from 1 through 65535.

*history-control-interval*

Specifies the alarm sample interval in seconds. The value can range from 1 through 3600. The default value is 1800.

*history-control-owner*

Specifies the identity of the owner. The maximum number of characters is 15.

# interface/{interface-type}/{interface-name}/rmon/collection/stats

Collects Ethernet group statistics n a specific interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <rmon xmlns="urn:brocade.com:mgmt:brocade-rmon">
      <collection>
        <ether-stats-entry>
          <ether-stats-index>3</ether-stats-index>
          <ether-stats-owner>owner1</ether-stats-owner>
        </ether-stats-entry>
      </collection>
    </rmon>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/5</name>
    <rmon xmlns="urn:brocade.com:mgmt:brocade-rmon">
      <collection>
        <history-control-entry>
          <history-control-index>25</history-control-index>
          <history-control-buckets-requested>10</history-control-buckets-requested>
          <history-control-interval>2000</history-control-interval>
          <history-control-owner>admin</history-control-owner>
        </history-control-entry>
      </collection>
    </rmon>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*ether-stats-index*

Specifies the RMON collection control index value. The value can range from 1 through 65535

*ether-stats-owner*

Specifies the identity of the owner

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/sflow/enable

Enables sFlow on an interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
      <enable></enable>
    </sflow>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**enable**

Enables sFlow on the interface.

# interface/{interface-type}/{interface-name}/sflow/polling-interval

Configures the polling interval globally.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
      <polling-interval>25</polling-interval>
    </sflow>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*polling-interval*

Specifies the polling interval in seconds. The value can range from 1 through 65535 seconds.

# interface/{interface-type}/{interface-name}/sflow/sample-rate

Sets the default sampling rate for an interface.

## Usage

Supported interface types are: FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
      <sample-rate>33300</sample-rate>
    </sflow>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/5</name>
    <sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
      <sample-rate>33300</sample-rate>
    </sflow>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*sample-rate*

Specifies the sampling rate. The value can range from 2 through 16777215 packets

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ spanning-tree/autoedge

Enables automatic edge detection.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <autoedge></autoedge>
    </spanning-tree>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**autoedge**

Enables automatic edge detection.

# interface/{interface-type}/{interface-name}/spanning-tree/bpdu-mac

Sets the MAC address of the Bridge Protocol Data Unit (BPDU).

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <bpdu-mac>0304.0800.0700</bpdu-mac>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <bpdu-mac>0304.0800.0700</bpdu-mac>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*bpdu-mac*

Specifies the MAC address of the Bridge Protocol Data Unit

**0100.0ccc.cccd**

Cisco Control Mac

**0304.0800.0700**

Brocade Control Mac

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/cost

Changes an interface's spanning-tree port path cost.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <cost>10000</cost>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <cost>10000</cost>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*cost*

Specifies the path cost for the Spanning Tree Protocol (STP) calculations. The value can range from 1 through 2000000000.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

## History

Release version	History
17s.1.00	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/ spanning-tree/edgeport

Enables the edge port on an interface to allow the interface to quickly transition to the forwarding state.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <edgeport>
        <edgeportbasic></edgeportbasic>
      </edgeport>
    </spanning-tree>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

*edgeportbasic*

Enables the edge port on an interface.

# interface/{interface-type}/{interface-name}/ spanning-tree/edgeport/bpdu-filter

Sets the edge port Bridge Protocol Data Unit (BPDU) filter for the port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <edgeport>
        <bpdu-filter></bpdu-filter>
      </edgeport>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <edgeport>
        <bpdu-filter></bpdu-filter>
      </edgeport>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**bpdu-filter**

Sets the edge port Bridge Protocol Data Unit (BPDU) filter for the port

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ spanning-tree/edgeport/bpdu-guard

Guards the port against the reception of BPDUs.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <edgeport>
        <bpdu-guard</bpdu-guard>
      </edgeport>
    </spanning-tree>
  </tengigabitethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name.

**bpdu-guard**

Guards the port against the reception of BPDUs.

# interface/{interface-type}/{interface-name}/ spanning-tree/guard/root

Enables the guard root to restrict which interface is allowed to be the spanning-tree root port or the path-to-the-root for the switch.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <guard>
        <root></root>
      </guard>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <guard>
        <root></root>
      </guard>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**root**

Enables the guard root

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/hello-time

Configures the hello-time in seconds on the interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <hello-time>5</hello-time>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <hello-time>5</hello-time>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*hello-time*

Sets the interval between the hello Bridge Protocol Data Units (BPDUs) sent by the root switch configuration messages. The value can range from 1 through 10.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/instance/priority

Sets restrictions for the port of particular MSTP instances.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <priority>240</priority>
      </instance>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <priority>240</priority>
      </instance>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*id*

Specifies the MSTP instance. The value can range from 1 through 32

*priority*

Specifies the port priority for a bridge in increments of 16. The value can range from 0 through 240

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/instance/cost

Configures the path-cost for a port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <cost>60</cost>
      </instance>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <cost>60</cost>
      </instance>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*id*

Specifies the MSTP instance. The value can range from 1 through 32

*cost*

Specifies the path-cost for a port. The value can range from 1 through 20000000

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-role

Specifies to restrict the role of a port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <restricted-role></restricted-role>
      </instance>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <restricted-role></restricted-role>
      </instance>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*id*

Specifies the MSTP instance. The value can range from 1 through 32

**restricted-role**

Specifies to restrict the role of a port

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/spanning-tree/instance/restricted-tcn

Specifies to restrict the propagation of the topology change notifications from a port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <restricted-tcn></restricted-tcn>
      </instance>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <instance>
        <id>5</id>
        <restricted-tcn></restricted-tcn>
      </instance>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*id*

Specifies the MSTP instance. The value can range from 1 through 32

**restricted-tcn**

Specifies to restrict the propagation of the topology change notifications from a port

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/link-type

Enables and disables the rapid transition for the Spanning Tree Protocol (STP).

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <link-type>shared</link-type>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <link-type>shared</link-type>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*link-type*

Enables and disables the rapid transition

**point-to-point**

Enables rapid transition

**shared**

Disables rapid transition

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/peer-switch

When the Peer-Switch feature is enabled on a Cisco vPC domain, it broadcasts the same BPDUs from both vPC primary and secondary nodes to peer devices. But a VCS on a VLAG assumes that any logical interface receives only one BPDU from any of its member ports, so when it receives the two BPDUs from a Cisco vPC domain it creates a churn of VLAG mastership, and this increases the CPU load on a Brocade VDX. To avoid these problem, BPDUs received on the VLAG non-master are dropped. When the Peer-Switch functionality is enabled and the the VLAG Master is selected, BPDUs received on VLAG Non-Master are dropped unless there is a change in the status of the VLAG Master.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <peer-switch></peer-switch>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <peer-switch></peer-switch>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**peer-switch**

Enables the Peer-Switch functionality on a portchannel

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/portfast

Enables the Port Fast feature on an interface to allow the interface to quickly transition to forwarding state.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <portfastbasic></portfastbasic>
      </portfast>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <portfastbasic></portfastbasic>
      </portfast>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ spanning-tree/portfast/bpdu-filter

Sets the Port Fast BPDU filter for the port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <bpdu-filter></bpdu-filter>
      </portfast>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <bpdu-filter></bpdu-filter>
      </portfast>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**bpdu-filter**

Sets the Port Fast BPDU filter for the port

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ spanning-tree/portfast/bpdu-guard

Guards the port against the reception of BPDUs.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <bpdu-guard></bpdu-guard>
      </portfast>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>22/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <portfast>
        <bpdu-guard></bpdu-guard>
      </portfast>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**bpdu-guard**

Guards the port against the reception of BPDUs

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/priority

Changes an interface's spanning-tree port priority.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <priority>32</priority>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <priority>32</priority>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*priority*

Specifies the interface priority for the spanning tree. The value can range from 0 through 240. Port priority is in increments of 16

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/restricted-role

Restricts the role of the port from becoming a root port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <restricted-role></restricted-role>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <restricted-role></restricted-role>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**restricted-role**

Restricts the role of the port from becoming a root port

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/spanning-tree/restricted-tcn

Restricts the Topology Change Notification (TCN) Bridge Protocol Data Units (BPDUs) sent on the port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <restricted-tcn></restricted-tcn>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <restricted-tcn></restricted-tcn>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**restricted-tcn**

Restricts the Topology Change Notification

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/shutdown

Disables spanning tree on the interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <shutdown></shutdown>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <shutdown></shutdown>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**shutdown**

Disables spanning tree on the interface

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/spanning-tree/vlan

Configures the VLAN identifier for the spanning tree interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <vlan>
        <id>200</id>
        <cost>10000</cost>
      </vlan>
    </spanning-tree>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
      <vlan>
        <id>200</id>
        <cost>10000</cost>
      </vlan>
    </spanning-tree>
  </ethernet>
</interface>
```

## Parameters

<i>name</i>	Specifies the interface name
<i>id</i>	Specifies the VLAN identifier for the spanning tree interface
<i>cost</i>	Specifies cost.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/storm-control/ingress

Limits ingress traffic on a specified interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet, TenGigabitEthernet and VLAN.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/5</name>
    <storm-control xmlns="urn:brocade.com:mgmt:brocade-bum-storm-control">
      <ingress>
        <protocol-type>broadcast</protocol-type>
        <rate-format>limit-bps</rate-format>
        <rate-bps>100</rate-bps>
        <rate-percent>458632240</rate-percent>
        <bum-action>monitor</bum-action>
      </ingress>
    </storm-control>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/5</name>
    <storm-control xmlns="urn:brocade.com:mgmt:brocade-bum-storm-control">
      <ingress>
        <protocol-type>broadcast</protocol-type>
        <rate-format>limit-bps</rate-format>
        <rate-bps>100</rate-bps>
        <rate-percent>458632240</rate-percent>
        <bum-action>monitor</bum-action>
      </ingress>
    </storm-control>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*protocol-type*

Specifies the protocol type

**broadcast**

Specifies that the command will operate on broadcast traffic only

**unknown-unicast**

Specifies that the command will operate on unknown-unicast traffic only

**multicast**

Specifies that the command will operate on multicast traffic only

*rate-format*

Specifies the rate format

**limit-bps**

Specifies that the value given to the rate parameter is in bits per second

**limit-percent**

Specifies that the value given to the rate parameter is in percentage of capacity of the interface

*rate-bps*

Specifies the amount of traffic allowed, either in bits per second or a percentage of the capacity of the interface, depending on which parameter was chosen with the rate

**monitor**

Specifies that, if a rate limit is reached within a five-second sampling period, a log message gets sent

**shutdown**

Specifies that, if a rate limit is exceeded within a five-second sampling period, the interface will be shut down

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport

Puts the interface in Layer 2 mode and sets the switching characteristics of the Layer 2 interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <switchport></switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2//1</name>
    <switchport></switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**switchport**

Enables switching characteristics of the Layer 2 interface

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport/access

Sets the Layer 2 interface as access.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>22/0/1</name>
    <switchport>
      <access>
        <accessvlan>20</accessvlan>
      </access>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>2/1</name>
    <switchport>
      <access>
        <accessvlan>20</accessvlan>
      </access>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*accessvlan*

Specifies the VLAN ID

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport/mode

Sets the mode of the Layer 2 interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <mode>
        <vlan-mode>trunk-no-default-native</vlan-mode>
      </mode>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <oui>1122.2233.3322</oui>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*vlan-mode*

Sets the mode

*access*

Sets the Layer 2 interface as access. Access mode assigns the port to a VLAN

*trunk*

Sets the Layer 2 interface as trunk. Trunk mode makes the port linkable to other switches and routers

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/switchport/mode/private-vlan

Sets the private VLAN (PVLAN) mode of the Layer 2 interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <mode>
        <pvlan>trunk</pvlan>
      </mode>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <mode>
        <pvlan>trunk</pvlan>
      </mode>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*pvlan*

Sets the private VLAN mode

**host**

Sets the port mode to host (community or isolated) mode. It accepts the untagged or priority tagged packet, and the outgoing packet is untagged

**promiscuous**

Sets the port mode to promiscuous mode

**trunk**

Sets the port mode to PVLAN trunk port. This port can carry multiple VLANs. The outgoing packets carry all VLANs, except for native VLANs

**trunk host**

Sets the port mode to host (community or isolated) mode. The trunk operand means the outgoing packet will be tagged "accept"

**trunk promiscuous**

Sets the trunk to promiscuous mode

interface/{interface-type}/{interface-name}/switchport/mode/private-vlan

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ switchport/mode/trunk-no-default-native

Configures a port to trunk mode without the implicit creation of default native VLAN 1 in a Virtual Fabrics context.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <mode>
        <trunk-no-default-native></trunk-no-default-native>
      </mode>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <mode>
        <trunk-no-default-native></trunk-no-default-native>
      </mode>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**trunk-no-default-native**

Enables a port to trunk mode

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport/port-security

Enables port security on an interface port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security></port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security></port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

**port-security**

Enables port security

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ switchport/port-security/mac-address

Configures the MAC address option for port security on an interface port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <port-secutiry-mac-address>
          <mac-address>1122.2233.3322</mac-address>
          <port-sec-vlan>1</port-sec-vlan>
        </port-secutiry-mac-address>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security>
        <port-secutiry-mac-address>
          <mac-address>1122.2233.3322</mac-address>
          <port-sec-vlan>1</port-sec-vlan>
        </port-secutiry-mac-address>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*mac-address*

Specifies the MAC address-based VLAN classifier rule used to map to a specific VLAN

*port-sec-vlan*

Specifies a VLAN

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport/port-security/max

Configures the maximum number of MAC addresses used for port security on an interface port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <port-sec-max>12</port-sec-max>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security>
        <port-sec-max>12</port-sec-max>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*port-sec-max*

Specifies the maximum number of secure MAC addresses. The value can range is from 1 through 8192

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ switchport/port-security/oui

Configures an Organizationally Unique Identifier (OUI) MAC address for port security on an interface port. All other addresses are ignored.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <oui>1122.2233.3322</oui>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security>
        <oui>1122.2233.3322</oui>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*oui*

Specifies the OUI MAC address from which to accept vendor traffic, in the format xxxx.xxxx.xxxx

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/ switchport/port-security/shutdown-time

Configures the shutdown-time option for port security on an interface port.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <shutdown-time>15</shutdown-time>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security>
        <shutdown-time>15</shutdown-time>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*shutdown-time*

Specifies the amount of time to shut down the interface port, in minutes. The value can range from 1 through 15

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# interface/{interface-type}/{interface-name}/ switchport/port-security/sticky

Converts dynamic MAC addresses to sticky secure MAC addresses.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <sticky>
          <sticky-flag></sticky-flag>
          <port-secutiry-mac-address>
            <mac-address>1122.2255.5544</mac-address>
            <port-sec-vlan>100</port-sec-vlan>
          </port-secutiry-mac-address>
        </sticky>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <sticky>
          <sticky-flag></sticky-flag>
          <port-secutiry-mac-address>
            <mac-address>1122.2255.5544</mac-address>
            <port-sec-vlan>100</port-sec-vlan>
          </port-secutiry-mac-address>
        </sticky>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*mac-address*

Specifies the MAC address-based VLAN classifier rule used to map to a specific VLAN

*port-sec-vlan*

Specifies a VLAN ID

interface/{interface-type}/{interface-name}/switchport/port-security/sticky

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/switchport/port-security/violation

Configures the violation response options for port security on an interface.

## Usage

Supported interface types are: Port-channel, FortyGigabitEthernet, GigabitEthernet, HundredGigabitEthernet and TenGigabitEthernet.

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <tengigabitethernet>
    <name>1/0/2</name>
    <switchport>
      <port-security>
        <port-sec-violation>restrict</port-sec-violation>
      </port-security>
    </switchport>
  </tengigabitethernet>
</interface>

<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>1/2</name>
    <switchport>
      <port-security>
        <port-sec-violation>restrict</port-sec-violation>
      </port-security>
    </switchport>
  </ethernet>
</interface>
```

## Parameters

*name*

Specifies the interface name

*port-sec-violation*

Specifies the violation response

**restrict**

Drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value

**shutdown**

Puts the interface into the error-disabled state for a predetermined amount of time

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ip/access-list/extended

Configures extended IP access list.

## Usage

```
<ip-acl xmlns="urn:brocade.com:mgmt:brocade-ip-access-list">
  <ip>
    <access-list>
      <extended>
        <name>acl5</name>
      </extended>
    </access-list>
  </ip>
</ip-acl>
```

## Parameters

*name*

Specifies the access list name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ip/access-list/extended/{acl-name}/seq

Configures the sequence number.

## Usage

```
<ip-acl xmlns="urn:brocade.com:mgmt:brocade-ip-access-list">
  <ip>
    <access-list>
      <extended>
        <name>acl15</name>
        <hide-ip-acl-ext>
          <seq>
            <seq-id>14</seq-id>
            <action>deny</action>
            <protocol-type>ip</protocol-type>
            <src-host-any-sip>any</src-host-any-sip>
            <dst-host-any-dip>host</dst-host-any-dip>
            <dst-host-ip>1.1.1.1</dst-host-ip>
            <vlan>1</vlan>
            <count></count>
            <log></log>
          </seq>
        </hide-ip-acl-ext>
      </extended>
    </access-list>
  </ip>
</ip-acl>
```

## Parameters

*name*

Access list name

*seq-id*

Specifies the sequence number for the rule

*action*

Specifies the action to be performed. The following actions can be performed.

**deny**

Drops traffic.

**hard-drop**

Forces to drop traffic.

**permit**

Allows traffic.

*protocol-type*

The type of protocol used.

*src-host-any-sip*

Specifies any source host IP address.

*dst-host-any-dip*

Specifies any destination host IP address.

*dst-host-ip*

Specifies the destination host IP address.

*vlan*

VLAN interface numbe.

**count**

Enables the counting of the packets matching the rule.

**log**

Packets matching the filter are sent to the CPU and a corresponding log entry is generated by enabling the logging mechanism. This parameter is only available with permit and deny.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ip/access-list/standard

Configures a standard IP access list.

## Usage

```
<ip-acl xmlns="urn:brocade.com:mgmt:brocade-ip-access-list">
  <ip>
    <access-list>
      <standard>
        <name>acl20</name>
      </standard>
    </access-list>
  </ip>
</ip-acl>
```

## Parameters

*name*

Specifies the access list name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ip/access-list/standard

Configures IPv6 standard access list.

## Usage

```
<ipv6-acl xmlns="urn:brocade.com:mgmt:brocade-ipv6-access-list">
  <ipv6>
    <access-list>
      <standard>
        <name>acl24</name>
      </standard>
    </access-list>
  </ipv6>
</ipv6-acl>
```

## Parameters

*name*

Specifies the access list name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# ip/access-list/standard/{acl-name}/seq

Configures sequence number.

## Usage

```
<ip-acl xmlns="urn:brocade.com:mgmt:brocade-ip-access-list">
  <ip>
    <access-list>
      <standard>
        <name>acl120</name>
        <hide-ip-acl-std>
          <seq>
            <seq-id>20</seq-id>
            <action>permit</action>
            <src-host-any-sip>host</src-host-any-sip>
            <src-host-ip>1.1.1.1</src-host-ip>
            <count></count>
            <log></log>
          </seq>
        </hide-ip-acl-std>
      </standard>
    </access-list>
  </ip>
</ip-acl>
```

## Parameters

*name*

Accesses the list name.

*seq-id*

Specifies the sequence number for the rule.

*action*

Specifies the action to be performed. The following actions can be performed.

**deny**

Drops traffic.

**hard-drop**

Forces to drop traffic.

**permit**

Allows traffic.

*src-host-any-sip*

Specifies any source host IP address.

*src-host-ip*

Specifies the source host IP address.

**count**

Enables the counting of the packets matching the rule.

**log**

Packets matching the filter are sent to the CPU and a corresponding log entry is generated by enabling the logging mechanism. This parameter is only available with permit and deny.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ip/dhcp/relay/servers

Configures DHCP relay servers.

## Usage

```
<ip xmlns="urn:brocade.com:mgmt:brocade-ip-config">
  <interface-ve-dhcp-conf xmlns="urn:brocade.com:mgmt:brocade-dhcp">
    <dhcp>
      <relay>
        <servers>
          <relay-ip-addr>{req_val}</relay-ip-addr>
          <server-vrf-name>{req_val}</server-vrf-name>
        </servers>
      </relay>
    </dhcp>
  </interface-ve-dhcp-conf>
</ip>
```

## Parameters

*relay-ip-addr*

Specifies the IP address of the relay server.

*server-vrf-name*

Specifies the VRF name of the server.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ipv6/access-list/extended

Configure IPv6 extended access list.

## Usage

```
<ipv6-acl xmlns="urn:brocade.com:mgmt:brocade-ipv6-access-list">
  <ipv6>
    <access-list>
      <extended>
        <name>acl114</name>
      </extended>
    </access-list>
  </ipv6>
</ipv6-acl>
```

## Parameters

*name*

Specifies the list name.

# ipv6/access-list/extended/{acl-name}/seq

Configures the sequence number.

## Usage

```
<ipv6-acl xmlns="urn:brocade.com:mgmt:brocade-ipv6-access-list">
  <ipv6>
    <access-list>
      <extended>
        <name>acl114</name>
        <seq>
          <seq-id>14</seq-id>
          <action>deny</action>
          <protocol-type>ipv6</protocol-type>
          <src-host-any-sip>any</src-host-any-sip>
          <dst-host-any-dip>host</dst-host-any-dip>
          <dst-host-ip>2004:384d::24:23</dst-host-ip>
          <vlan>1</vlan>
          <count></count>
          <log></log>
        </seq>
      </extended>
    </access-list>
  </ipv6>
</ipv6-acl>
```

## Parameters

*name*

Specifies the access list name.

*seq-id*

Specifies the sequence number for the rule.

*action*

Specifies the action to be performed. The following actions can be performed.

**deny**

Drops traffic.

**hard-drop**

Forces to drop traffic.

**permit**

Allows traffic.

*protocol-type*

Specifies the type of protocol used.

*src-host-any-sip*

Specifies any source host IP address.

*dst-host-any-dip*

Specifies any destination host IP address.

*dst-host-ip*

Specifies the destination host IP address.

*vlan*

VLAN interface number

**count**

Enables the counting of the packets matching the rule.

**log**

Packets matching the filter are sent to the CPU and a corresponding log entry is generated by enabling the logging mechanism. This parameter is only available with permit and deny.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ipv6/access-list/standard/{acl-name}/seq

Configures the sequence number.

## Usage

```
<ipv6-acl xmlns="urn:brocade.com:mgmt:brocade-ipv6-access-list">
  <ipv6>
    <access-list>
      <standard>
        <name>acl24</name>
        <seq>
          <seq-id>24</seq-id>
          <action>permit</action>
          <src-host-any-sip>any</src-host-any-sip>
          <count></count>
          <log></log>
        </seq>
      </standard>
    </access-list>
  </ipv6>
</ipv6-acl>
```

## Parameters

*name*

Specifies the access list name.

*seq-id*

Specifies the sequence number for the rule.

*action*

Specifies the action to be performed. The following actions can be performed.

**deny**

Drops traffic.

**hard-drop**

Forces to drop traffic.

**permit**

Allows traffic.

*src-host-any-sip*

Specifies any source host IP address.

**count**

Enables the counting of the packets matching the rule.

**log**

Packets matching the filter are sent to the CPU and a corresponding log entry is generated by enabling the logging mechanism. This parameter is only available with permit and deny.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# mac/access-list/extended/{acl-name}/seq

Configures the sequence number

## Usage

```
<mac xmlns="urn:brocade.com:mgmt:brocade-mac-access-list">
  <access-list>
    <extended>
      <name>acl21</name>
      <hide-mac-acl-ext>
        <seq>
          <seq-id>25</seq-id>
          <action>hard-drop</action>
          <source>0011.1122.2233</source>
          <src-mac-addr-mask>1212.2323.3131</src-mac-addr-mask>
          <dst>any</dst>
          <ethertype>arp</ethertype>
          <vlan>1</vlan>
          <count></count>
          <log></log>
        </seq>
      </hide-mac-acl-ext>
    </extended>
  </access-list>
</mac>
```

## Parameters

*name*

Specifies the access list name.

*seq-id*

Specifies the sequence ID.

*action*

Displays all rules with the specified action. The following actions are allowed.

### **deny**

Drops traffic.

### **hard-drop**

Forces to drop traffic.

### **permit**

Allows traffic.

*source*

Specifies the source details.

*src-mac-addr-mask*

Specifies the source MAC address mask.

**dst**

Specifies details on the destination

*ethertype*

Filters extended ACLs traffic based on ethertype.

mac/access-list/extended/{acl-name}/seq

*vlan*

Specifies the VLAN number.

**count**

Displays the count of forwarding entries.

**log**

Specifies log.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mac/access-list/standard

Configures standard MAC access-list.

## Usage

```
<mac xmlns="urn:brocade.com:mgmt:brocade-mac-access-list">  
  <access-list>  
    <standard>  
      <name>acl25</name>  
    </standard>  
  </access-list>  
</mac>
```

## Parameters

*name*

Specifies the access list name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mac/access-list/standard/{acl-name}/seq

Configures the sequence number.

## Usage

```
<mac xmlns="urn:brocade.com:mgmt:brocade-mac-access-list">
  <access-list>
    <standard>
      <name>acl25</name>
      <hide-mac-acl-std>
        <seq>
          <seq-id>21</seq-id>
          <action>permit</action>
          <source>0011.1122.2233</source>
          <src-mac-addr-mask>0101.0202.0303</src-mac-addr-mask>
          <count></count>
          <log></log>
        </seq>
      </hide-mac-acl-std>
    </standard>
  </access-list>
</mac>
```

## Parameters

*name*

Specifies the access list name.

*seq-id*

Specifies the sequence ID.

*action*

Displays all rules with the specified action. The following actions are allowed.

**deny**

Drops traffic.

**hard-drop**

Forces to drop traffic.

**permit**

Allows traffic.

*source*

Specifies the source details.

*src-mac-addr-mask*

Specifies the source MAC address mask.

**count**

Displays the count of forwarding entries.

**log**

Specifies log.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mac-address-table/aging-time

Configures mac-address-table aging time.

## Usage

```
<mac-address-table xmlns="urn:brocade.com:mgmt:brocade-mac-address-table">  
  <aging-time>  
    <legacy-time-out>350</legacy-time-out>  
  </aging-time>  
</mac-address-table>
```

## Parameters

*legacy-time-out*

Specifies the aging time in seconds. The value can range from 60 through 100000 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ntp/authentication-key

Configures NTP authentication key parameters.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">
  <authentication-key>
    <keyid>650</keyid>
    <sha1>sha1</sha1>
    <encryption-level>0</encryption-level>
  </authentication-key>
</ntp>
```

## Parameters

*keyid*

Specifies authentication key ID. The value can range from 65535

*encryption-type*

Specifies the encryption type. Two types of encryption are allowed:

**sha1**

SHA1 encryption

**md5**

MD5 encryption

*encryption-level*

Specifies the encryption level. There are two encryption levels

**0**

Stores the key in clear-text format

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ntp/disable

Disables the NTP server/client mode.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">  
  <disable/>  
</ntp>>
```

## Parameters

### serve

If this keyword is specified, then NTP will not serve the time to downstream devices. This keyword disables the NTP server mode functionalities. If this keyword is not specified, then both NTP client mode and NTP server mode functionalities will be disabled.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.



# ntp/master

Configures the device as an authoritative NTP Server.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">  
  <master/>  
</ntp>
```

## Parameters

**startumnumber**

The NTP stratum number.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# ntp/peer

Configures the NTP peers and specify the peers to synchronize the system clock.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">
  <peer>
    <peer-ip>%req_val%</peer-ip>
    <peer-maxpoll/>
  </peer>
```

## Parameters

### ipv4 address | ipv6 address

IPv4 or IPv6 address of the NTP peer.

### use-vrf name

Use VRF name to synchronize the time with server. If this option is not specified, it defaults to **mgmt-vrf**.

### key

The symmetric key ID. By default, no symmetric key is configured. The range is 1 to 65,534.

### version3 / 4

The NTP version supported by peer. If this option is not specified, then defaults to 4.

### minpollinterval

The shortest polling interval. The range is 4 to 17. Default is 6. The interval argument is power of 2: 3=8s, 4=16s, 5=32s, 6=64s, 7=128s, 8=256s, 9=512s etc.

### maxpollinterval

The longest polling interval. The range is 4 to 17. Default is 10. The interval argument is power of 2: 3=8s, 4=16s, 5=32s, 6=64s, 7=128s, 8=256s, 9=512s etc.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# ntp/server

Configures Network Time Protocol (NTP) server IP address.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">
  <server>
    <ip>1.1.1.1</ip>
    <key>1</key>
  </server>
</ntp>
```

## Parameters

*ip*

NTP server IPv4 or IPv6 IP address.

*key*

Key from the key list to be associated with the specified server. The value can range from 1 through 65535.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ntp/source-ip

Configures the source IP to be used for Network Time Protocol (NTP).

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">  
  <source-ip>chassis-ip</source-ip>  
</ntp>
```

## Parameters

### *source-ip*

Specifies the source IP to be used for NTP. The following source IP can be configured.

### **chassis-ip**

Uses chassis IP as source address.

### **mm-ip**

Uses local MM IP as source address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# ntp/trusted-key

configures additional subset of trusted key-IDs which can be used for NTP and client authentication.

## Usage

```
<ntp xmlns="urn:brocade.com:mgmt:brocade-ntp">  
  <trusted-key/>  
</ntp>
```

## Parameters

*key-id-1key-id-2key-id-n*

List of authentication keys.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# overlay-gateway

Configures overlay gateway instances.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">  
  <name>ogl</name>  
</overlay-gateway>
```

## Parameters

*name*

Overlay Gateway name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/activate

Activates the Overlay Gateway instance.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">  
  <name>ogl</name>  
  <activate></activate>  
</overlay-gateway>
```

## Parameters

*name*

Specifies the Overlay Gateway name.

*activate*

Activates the overlay gateway instance.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/attach/vlan

Configures VLAN attachment for this gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <attach>
    <vlan>
      <vid>1</vid>
      <mac>0011.1122.2233</mac>
    </vlan>
  </attach>
</overlay-gateway>
```

## Parameters

*vid*

Specifies the range of VLAN ids to add.

*mac*

Specifies MAC address in HHHH.HHHH.HHHH format.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# overlay-gateway/{gateway-name}/enable

Enables per VLAN statistics.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <enable>
    <statistics>
      <stats-direction>both</stats-direction>
      <vlan-action>add</vlan-action>
      <vlan-list>1</vlan-list>
    </statistics>
  </enable>
</overlay-gateway>
```

## Parameters

### *stats-direction*

Specifies the flow direction. The flow direction can be set to any one of the following.

#### **both**

Both transmitted and received packets.

#### **rx**

Received packets.

#### **tx**

Transmitted packets.

### *vlan-action*

Specifies the action. Two actions are allowed.

#### **add**

Specifies the VLANs to add.

#### **remove**

Specifies the VLANs to remove.

### *vlan-list*

Specifies the range of VLAN IDs.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/ip/access-group

Configures IPv4 access-group for the Overlay Gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <access-lists>
    <ipv4>
      <in>
        <ipv4-acl-in-name>acl4</ipv4-acl-in-name>
        <ipv4-acl-in-dir></ipv4-acl-in-dir>
      </in>
    </ipv4>
  </access-lists>
</overlay-gateway>
```

## Parameters

*ipv4-acl-in-name*

Specifies the access list name.

*ipv4-acl-in-dir*

Configures IPv4 access group in ingress direction.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/ip/interface/loopback

Configures Loopback interface for the Overlay Gateway

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <ip>
    <interface>
      <loopback>
        <loopback-id>1</loopback-id>
      </loopback>
    </interface>
  </ip>
</overlay-gateway>
```

## Parameters

*loopback-id*  
Specifies loopback port number.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/fabric-virtual-gateway

Uses Fabric-Virtual-Gateway IP address.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <ip>
    <interface>
      <ve>
        <ve-id>1</ve-id>
        <fabric-virtual-gateway></fabric-virtual-gateway>
      </ve>
    </interface>
  </ip>
</overlay-gateway>
```

## Parameters

*ve-id*

Specifies VE interface number.

**fabric-virtual-gateway**

Enables use of Fabric-Virtual-Gateway IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/ip/interface/ve/{ve-id}/vrrp-extended-group

Configures virtual router

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <ip>
    <interface>
      <ve>
        <ve-id>1</ve-id>
        <vrrp-extended-group>1</vrrp-extended-group>
      </ve>
    </interface>
  </ip>
</overlay-gateway>
```

## Parameters

*ve-id*

Specifies VE interface number.

*vrrp-extended-group*

Specifies Virtual Router Identifier. The value can range from 1 through 255.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/ipv6/access-group

Configures IPv6 access-group for the Overlay Gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <access-lists>
    <ipv6>
      <in>
        <ipv6-acl-in-name>acl12</ipv6-acl-in-name>
        <ipv6-acl-in-dir></ipv6-acl-in-dir>
      </in>
    </ipv6>
  </access-lists>
</overlay-gateway>
```

## Parameters

*ipv6-acl-in-name*

Specifies IPv6 access group name.

*ipv6-acl-in-dir*

Configures IPv6 access group in ingress direction.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/mac

Configures MAC access-group for the Overlay Gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <access-lists>
    <mac>
      <in>
        <mac-acl-in-name>acl10</mac-acl-in-name>
        <mac-acl-in-dir></mac-acl-in-dir>
      </in>
    </mac>
  </access-lists>
</overlay-gateway>
```

## Parameters

*mac-acl-in-name*

Specifies the name of the MAC access list.

*mac-acl-in-dir*

Configures MAC access-group in ingress direction.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/map

Configures the VLAN to VNI mappings for the Overlay Gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>gateway2</name>
  <map>
    <vlan>
      <vni>
        <auto/>
      </vni>
    </vlan>
  </map>
</overlay-gateway>
```

## Parameters

- vlan**  
Specifies the VLAN.
- vni**  
Specifies the VNI.
- auto*  
Specifies automatic mapping.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# overlay-gateway/{gateway-name}/monitor

Configures SPAN for the tunnels of this gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>name1</name>
  <monitor>
    <session>1</session>
    <direction>both</direction>
    <remote-endpoint>any</remote-endpoint>
    <vlan-add-remove>add</vlan-add-remove>
    <vlan-range>5,14-17</vlan-range>
  </monitor>
</overlay-gateway>
```

## Parameters

*session*

Specifies session number.

*direction*

Specifies flow direction. Flow direction can be set to the following.

**both**

Both transmitted and received packets.

**rx**

Received packets.

**tx**

Transmitted packets.

*remote-endpoint*

Specifies tunnel destination end point address. The destination end point address can be set to.

<A.B.C.D>

Specifies IP address of specific tunnel end point.

**any**

Specifies all tunnel end points.

*vlan-add-remove*

Adds or removes target VLAN IDs.

*vlan-range*

Specifies range of VLAN IDs to add or remove.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/sflow

Configures SFLOW for the tunnels of this gateway.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <sflow>
    <sflow-profile-name>sflow1</sflow-profile-name>
    <sflow-remote-endpoint>any</sflow-remote-endpoint>
    <sflow-vlan-action>add</sflow-vlan-action>
    <sflow-vlan-range>100</sflow-vlan-range>
  </sflow>
</overlay-gateway>
```

## Parameters

### *sflow-profile-name*

Specifies Sflow profile name.

### *sflow-remote-endpoint*

Specifies tunnel destination end point address. The destination end point address can be set to.

<A.B.C.D>

Specifies IP address of specific tunnel end point.

**any**

Specifies all tunnel end points.

### *sflow-vlan-action*

Specifies the action on target VLAN IDs. There are two action.

**add**

Specifies target VLAN IDs to add.

**remove**

Specifies target VLAN IDs to remove.

### *sflow-vlan-range*

Specified the range of VLAN IDs to add or remove.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site

Configures remote extension site.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">  
  <name>ogl</name>  
  <site>  
    <name>site1</name>  
  </site>  
</overlay-gateway>
```

## Parameters

*name*

Specifies the site name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site/{site-name}/bfd

Creates BFD session for the tunnels to the remote site.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>ogl</name>
  <site>
    <name>site1</name>
    <bfd>
      <params>
        <interval>
          <min-tx>110</min-tx>
          <min-rx>330</min-rx>
          <multiplier>3</multiplier>
        </interval>
      </params>
    </bfd>
  </site>
</overlay-gateway>
```

## Parameters

*name*

Specifies the site name

*min-tx*

Specifies BFD desired minimum transmit interval in milliseconds. The value can range from 100 through 30000. The default value is 100.

*min-rx*

Specifies BFD desired minimum receive interval in milliseconds. The value can range from 300 through 30000. The default value is 300.

*multiplier*

Specifies BFD detection time multiplier. The value can range from 3 through 50. The default value is 3.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site/{site-name}/ extend

Configures Layer2 domains to be extended towards this site.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>gateway2</name>
  <site>
    <name>sanjose</name>
    <extend>
      <vlan>
        <add>1-10</add>
      </vlan>
    </extend>
  </site>
</overlay-gateway>
```

## Parameters

*name*

Specifies site name.

**add**

Specifies VLAN IDs to add.

**remove**

Specifies VLAN IDs to remove.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site/{site-name}/ip

Configures tunnel destination IP address.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">  
  <name>gateway2</name>  
  <site>  
    <name>sanjose</name>  
    <tunnel-dst>  
      <address>10.10.10.1</address>  
    </tunnel-dst>  
  </site>  
</overlay-gateway>
```

## Parameters

*name*

Specifies site name.

*address*

Specifies tunnel destination IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site/{site-name}/mac-learning/protocol/bgp

By default, MAC address learning is enabled on VXLAN Layer 2 extension tunnels. Use this command to delegate the responsibility for MAC learning on a tunnel to the Layer 3 control-plane protocol, such as BGP EVPN.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>overlaygateway1</name>
  <site>
    <name>site1</name>
    <mac-learning>
      <protocol>bgp</protocol>
    </mac-learning>
  </site>
</overlay-gateway>
```

## Parameters

*name*

Specifies the site name.

*protocol*

Specifies control plane MAC learning protocol.

**bgp**

Sets BGP-EVPN based MAC learning

## History

Release version	History
7.0.0	This Netconf call was introduced.

Release version	History
16r.1.01	This NETCONF call was introduced.

# overlay-gateway/{gateway-name}/site/{site-name}/shutdown

Disables tunnel to the remote site.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">  
  <name>gateway2</name>  
  <site>  
    <name>sanjose</name>  
    <shutdown></shutdown>  
  </site>  
</overlay-gateway>
```

## Parameters

*name*

Specifies the name of the site.

**shutdown**

Disables tunnels to the remote site.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# overlay-gateway/{gateway-name}/type

pecifies whether a VXLAN overlay gateway uses NSX Controller or OpenStack integration, or Layer 2 extension.

## Usage

```
<overlay-gateway xmlns="urn:brocade.com:mgmt:brocade-tunnels">
  <name>overlaygateway1</name>
  <gw-type>hardware-vtep</gw-type>
</overlay-gateway>
```

## Parameters

*name*

Specifies the overlay gateway name

*gw-type*

Specifies the type of Overlay Gateway. There are two types of Overlay Gateway

**hardware-vtep**

Specifies NSX Controller/OpenStack integration

**layer2-extension**

Specifies Layer 2 extension

## History

Release version	History
7.0.0	This Netconf call was modified to deprecate the <b>nsx</b> keyword and replace it with the <b>hardware-vtep</b> keyword, supporting both NSX Controller and OpenStack deployments.

# protocol/cfm

Configures the CFM protocol.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <cfm xmlns="urn:brocade.com:mgmt:brocade-dotlag">
    <domain-name>
      <domain-name>{req_val}</domain-name>
      <ma-name>
        <ma-name>{req_val}</ma-name>
        <cfm-ma-sub-commands>
          <mep>
            <mep-id>{req_val}</mep-id>
          </mep>
        </cfm-ma-sub-commands>
      </ma-name>
    </domain-name>
  </cfm>
</protocol>
```

## Parameters

*domain-name*

Specifies the maintenance domain name.

*ma-name*

Specifies the maintenance association name.

*mep-id*

Specifies maintenance endpoint ID.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/link-oam

Configures the Link OAM protocol.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <link-oam xmlns="urn:brocade.com:mgmt:brocade-dot3ah">  
    <shutdown/>  
  </link-oam>  
</protocol>
```

## History

Release version	History
17r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/dcbx-fcoe-app-tlv

Enables IEEE data centre bridging exchange FCoE Application TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <advertise>  
      <dcbx-fcoe-app-tlv></dcbx-fcoe-app-tlv>  
    </advertise>  
  </lldp>  
</protocol>
```

## Parameters

### dcbx-fcoe-app-tlv

Enables IEEE data centre bridging exchange FCoE Application TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/dcbx-fcoe-logical-link-tlv

Enables IEEE data centre bridging exchange FCoE logical link TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <advertise>
      <dcbx-fcoe-logical-link-tlv></dcbx-fcoe-logical-link-tlv>
    </advertise>
  </lldp>
</protocol>
```

## Parameters

### **dcbx-fcoe-logical-link-tlv**

Enables IEEE data centre bridging exchange FCoE logical link TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/dcbx-iscsi-app-tlv

Enables IEEE data centre bridging exchange iSCSI application TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <advertise>  
      <dcbx-iscsi-app-tlv></dcbx-iscsi-app-tlv>  
    </advertise>  
  </lldp>  
</protocol>
```

## Parameters

### dcbx-iscsi-app-tlv

Enables IEEE data centre bridging exchange iSCSI application TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/dcbx-tlv

Enables IEEE data centre bridging exchange TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <advertise>
      <dcbx-tlv></dcbx-tlv>
    </advertise>
  </lldp>
</protocol>
```

## Parameters

### dcbx-tlv

Enables IEEE data centre bridging exchange TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/dot1-tlv

Enables IEEE 802.1 organizationally specific TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <advertise>  
      <dot1-tlv></dot1-tlv>  
    </advertise>  
  </lldp>  
</protocol>
```

## Parameters

### dot1-tlv

Enables IEEE 802.1 organizationally specific TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/ldp/advertise/dot3-tlv

Enables IEEE 802.3 organizationally specific TLV.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-ldp">
    <advertise>
      <dot3-tlv></dot3-tlv>
    </advertise>
  </lldp>
</protocol>
```

## Parameters

### dot3-tlv

Enables IEEE 802.3 organizationally specific TLV.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/advertise/optional-tlv

Enables the optional TLVs.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <advertise>
      <optional-tlv>
        <management-address></management-address>
        <port-description></port-description>
        <system-capabilities></system-capabilities>
        <adv-tlv-system-description></adv-tlv-system-description>
        <adv-tlv-system-name></adv-tlv-system-name>
      </optional-tlv>
    </advertise>
  </lldp>
</protocol>
```

## Parameters

### management-address

Enables management address TLV.

### port-description

Enables port description TLV.

### system-capabilities

Enables system capabilities TLV.

### *adv-tlv-system-description*

Specifies the system description .

### *adv-tlv-system-name*

Specifies the system name .

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/description

Configures user description for LLDP.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <description>lldpconfig</description>  
  </lldp>  
</protocol>
```

## Parameters

*description*

Specifies user description for LLDP.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/disable

Disable LLDP configuration.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <disable></disable>  
  </lldp>  
</protocol>
```

## Parameters

**disable**

Disables LLDP configuration.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/ldp/hello

Configures the hello transmit interval.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <ldp xmlns="urn:brocade.com:mgmt:brocade-ldp">  
    <hello>35</hello>  
  </ldp>  
</protocol>
```

## Parameters

*hello*

Specifies the hello transmit interval. The value can range from 4 through 180 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/iscsi-priority

Configures the Ethernet priority to advertise for iSCSI.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <iscsi-priority>3</iscsi-priority>
  </lldp>
</protocol>
```

## Parameters

*iscsi-priority*

Specifies the iSCSI Ethernet priority value. The value can range from 0 through 7.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/mode

Configures the LLDP mode.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <mode>rx</mode>  
  </lldp>  
</protocol>
```

## Parameters

*mode*

Specifies the LLDP mode.

**rx**

LLDP receive only mode.

**tx**

LLDP transmit only mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/multiplier

Configures the timeout multiplier.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <multiplier>3</multiplier>  
  </lldp>  
</protocol>
```

## Parameters

*multiplier*

Specifies the timeout multiplier value. The value can range from 2 through 10.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/lldp/profile/{profile-name}/advertise

Applies a Link Layer Discovery Protocol (LLDP) profile to an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <profile>
      <profile-name>profile1</profile-name>
      <advertise>
        <dcbx-tlv></dcbx-tlv>
      </advertise>
    </profile>
  </lldp>
</protocol>
```

## Parameters

*profile-name*

Specifies the profile name.

*advertise*

Specifies the advertise TLV configuration.

### **dcbx-fcoe-app-tlv**

Advertises application Type, Length, Values (TLVs) to ensure interoperability of traffic over the Data Center Bridging eXchange protocol (DCBX), which runs over LLDP to negotiate an FCoE application TLV.

### **dcbx-fcoe-logical-link-tlv**

Advertises to any attached device the FCoE status of the logical link.

### **dcbx-iscsi-app-tlv**

Advertises the iSCSI traffic configuration parameters for Type, Length, Values (TLV) values.

### **dcbx-tlv**

Advertises to any attached device mandatory Data Center Bridging eXchange protocol (DCBX) Type, Length, Values (TLV) values.

### **dot1-tlv**

Advertises to any attached device IEEE 802.1 organizationally specific Type, Length, Values (TLV) values.

### **dot3-tlv**

Advertises to any attached device IEEE 802.3 organizationally specific Type, Length, Values (TLV) values.

### **optional-tlv**

Advertises the optional Type, Length, and Values (TLV) values.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/profile/{profile-name}/hello

Sets the interval between LLDP hello messages.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <profile>
      <profile-name>profile1</profile-name>
      <hello>100</hello>
    </profile>
  </lldp>
</protocol>
```

## Parameters

*profile-name*

Specifies the profile name.

*hello*

Specifies the interval between hello messages. The value can range from 4 through 180 seconds. The default interval is 30 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/profile/{profile-name}/mode

Sets the LLDP mode on the switch.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <profile>
      <profile-name>profile1</profile-name>
      <mode>rx</mode>
    </profile>
  </lldp>
</protocol>
```

## Parameters

*profile-name*

Specifies the profile name.

*mode*

Specifies the LLDP mode on the switch.

**tx**

Specifies to enable only the transmit mode.

**rx**

Specifies to enable only the receive mode.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/profile/{profile-name}/multiplier

Sets the number of consecutive misses of hello messages before LLDP declares the neighbor as dead.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <profile>
      <profile-name>profile1</profile-name>
      <multiplier>2</multiplier>
    </profile>
  </lldp>
</protocol>
```

## Parameters

*profile-name*

Specifies the profile name

*multiplier*

Specifies a multiplier value to use. The values can range from 2 through 10. The default value is 4.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/system-description

Configures the system description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">  
    <system-description>Brocade-VDX-VCS 1</system-description>  
  </lldp>  
</protocol>
```

## Parameters

*system-description*

Specifies the system description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/lldp/system-name

Configures the system name.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <lldp xmlns="urn:brocade.com:mgmt:brocade-lldp">
    <system-name>client</system-name>
  </lldp>
</protocol>
```

## Parameters

*system-name*

Specifies the system-name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/bridge-priority

Configures bridge priority commands for multiple spanning tree protocol.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <bridge-priority>32768</bridge-priority>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*bridge-priority*

Specifies the bridge priority. The value can range from 0 through 61440 and bridge priority must be set in increments of 4096.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/cisco-interoperability

Configures Cisco interoperability.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <cisco-interoperability>disable</cisco-interoperability>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*cisco-interoperability*

Enables or disables cisco interoperability.

**disable**

Disables cisco interoperability.

**enable**

Enables cisco interoperability.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/mstp/description

Configures spanning tree description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <description>mstpsan</description>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*description*

Specifies spanning tree description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/error-disable-timeout/enable

Enables timeout for the port to be enabled back.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

### enable

Enables timeout for the port to be enabled back.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/error-disable-timeout/interval

Configures time interval after which port will be enabled.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <error-disable-timeout>
        <interval>350</interval>
      </error-disable-timeout>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*interval*

Specifies time interval after which port will be enabled. The value can range from 10 through 1000000 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/forward-delay

Configures the forward delay time for the spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <forward-delay>20</forward-delay>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies forward delay time. The delay time can range from 4 through 30 seconds. The default delay time is set to 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/hello-time

Configures the hello time interval for the spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <hello-time>3</hello-time>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*hello-time*

Specifies the hello time. The hello time can range from 1 through 20 seconds. The default hello time is set to 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/instance/priority

Configures bridge priority for the common instance.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <instance>
        <id>1</id>
        <priority>4096</priority>
      </instance>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies MSTP instance Id. The value can range from 1 through 31.

*priority*

Specifies the bridge priority. The value can range from 0 through 61440.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/instance/vlan

Configures VLAN for MSTP.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <instance>
        <id>1</id>
        <vlan>1</vlan>
      </instance>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*id*  
Specifies MSTP instance ID.

*vlan*  
Specifies VLAN.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/max-age

Configures the max age for the spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <max-age>25</max-age>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*max-age*

Specifies the maximum time to listen for root bridge in seconds. The value can range from 6 through 40 seconds. The default time is set to 20. seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/mstp/max-hops

Configures the maximum hops the BPDU will be valid for.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <max-hops>25</max-hops>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*max-hops*

Specifies the maximum hops the BPDU will be valid for. The value can range from 1 through 40.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/port-channel

Controls port channel behavior for spanning tree

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <port-channel>
        <path-cost>standard</path-cost>
      </port-channel>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

### *path-cost*

Sets the path cost behavior.

#### **custom**

Custom behavior - pathcost will change according to bandwidth.

#### **standard**

Standard behavior - pathcost will not change according to bandwidth.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/region

Sets the MST region.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <region>region1</region>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*region*

Specifies the name of the region.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/revision

Sets the revision number.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <revision>1</revision>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*revision*

Specifies the revision number. The value can range from 0 through 255.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/shutdown

Disables the Multiple Spanning Tree Protocol (MSTP) globally.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <shutdown></shutdown>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

### shutdown

Shuts down the spanning tree protocol.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/mstp/transmit-holdcount

Configures transmit hold count of the bridge.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <mstp>
      <transmit-holdcount>7</transmit-holdcount>
    </mstp>
  </spanning-tree>
</protocol>
```

## Parameters

*transmit-holdcount*

Specifies the transmit hold count. The value can range from 1 through 10.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/bridge-priority

Configures bridge priority for PVST Spanning-tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <bridge-priority>32768</bridge-priority>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*bridge-priority*

Specifies the bridge priority. Valid values range from 0 through 61440 in increments of 4096.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/description

Configures the PVST spanning-tree description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <description>pvstspan</description>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*decsription*

Specifies the PVST spanning-tree description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/pvst/error-disable-timeout/enable

Enables the timeout mechanism for the port to be enabled back.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*enable*

Enables timeout for PVST spanning tree.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/error-disable-timeout/interval

Configures interval after which port shall be enabled.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <error-disable-timeout>
        <interval>350</interval>
      </error-disable-timeout>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*interval*

Specifies the time for the interface to time out. The interval can range from 10 through 1000000 seconds. The default interval is 300 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/forward-delay

Specifies the time an interface spends in each of the listening and learning states.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <forward-delay>20</forward-delay>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies the time that an interface spends in the Spanning Tree Protocol (STP) learning and listening states. Valid values range from 4 through 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/hello-time

Sets the interval between the hello Bridge Protocol Data Units (BPDUs) sent on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <hello-time>3</hello-time>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*hello-time*

Specifies the time interval between the hello BPDUs sent on an interface. The value can range from 1 through 10 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/max-age

Sets the interval time in seconds between messages that the PVST spanning tree receives from the interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <max-age>25</max-age>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*max-age*

Specifies the PVST Spanning Tree Protocol interface maximum age. The value can range from 6 through 40. The default value is 20 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/port-channel

Sets the path-cost behavior.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <port-channel>
        <path-cost>standard</path-cost>
      </port-channel>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

### *path-cost*

Sets the path cost behaviour

#### **custom**

Specifies to use the custom behavior, which sets the path-cost changes according to the port-channel's bandwidth.

#### **standard**

Specifies to use the standard behavior, which sets that the path-cost does not change according to port-channel's bandwidth.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/shutdown

Disables the Rapid Spanning Tree Protocol (RSTP) globally.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <shutdown></shutdown>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

### shutdown

Disables the Rapid Spanning Tree Protocol (RSTP) globally.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/vlan/forward-delay

Configures the forward-delay for PVST spanning tree

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <vlan>
        <id>1</id>
        <forward-delay>20</forward-delay>
      </vlan>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies the forward delay time in seconds. The value can range from 4 to 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/pvst/vlan/hello-time

Configures the hello interval for the PVST spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <vlan>
        <id>1</id>
        <hello-time>3</hello-time>
      </vlan>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*hello-time*

Specifies the hello interval. The interval can range from 4 to 30 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/vlan/max-age

Configures the max-age for the PVST spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <vlan>
        <id>1</id>
        <max-age>25</max-age>
      </vlan>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*max-age*

Specifies the max-age for the PVST spanning tree.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/pvst/vlan/priority

Configures the bridge priority.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <pvst>
      <vlan>
        <id>1</id>
        <priority>4096</priority>
      </vlan>
    </pvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*priority*

Specifies the bridge priority in increments of 4096.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/bridge-priority

Specifies the bridge priority for the common instance.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <bridge-priority>32768</bridge-priority>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*bridge-priority*

Specifies the bridge priority. The values can range from 0 through 61440 in increments of 4096. The default value is 32768.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/description

Configures the RPVST Spanning tree description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <description>rpvstspan</description>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*decription*

Specifies the RPVST Spanning tree description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/error-disable-timeout/enable

Enables the timer to bring the interface out of the error-disabled state.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

### enable

Enables the timer to bring the interface out of the error-disabled state.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/error-disable-timeout/interval

Configures the timeout for errors on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <error-disable-timeout>
        <interval>400</interval>
      </error-disable-timeout>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*interval*

Specifies the time for the interface to time out. The value can range from 10 through 1000000 seconds. The default value is 300 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/forward-delay

Specifies the time an interface spends in each of the listening and learning states.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <forward-delay>20</forward-delay>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies the time that an interface spends in the RPVST Spanning Tree Protocol (STP) learning and listening states.

Valid values range from 4 through 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/rpvst/hello-time

Sets the interval between the hello Bridge Protocol Data Units (BPDUs) sent on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <hello-time>3</hello-time>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*hello-time*

Specifies the time interval between the hello BPDUs sent on an interface. The value can range from 1 through 10 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/max-age

Sets the interval time in seconds between messages that the spanning tree receives from the interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <max-age>35</max-age>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*max-age*

Configures the Spanning Tree Protocol interface maximum age. The valid value can range from 6 through 40. The default value is 20 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/port-channel

Sets the path-cost behavior.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <port-channel>
        <path-cost>standard</path-cost>
      </port-channel>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

### *path-cost*

Sets the path cost priority.

#### **custom**

Specifies to use the custom behavior, which sets the path-cost changes according to the port-channel's bandwidth.

#### **standard**

Specifies to use the standard behavior, which sets that the path-cost does not change according to port-channel's bandwidth.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/shutdown

Disables the Rapid PVST(RPVST) globally.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <shutdown></shutdown>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

### shutdown

Disables the Rapid PVST(RPVST) globally.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/transmit-holdcount

Configures the maximum number of Bridge Protocol Data Units (BPDUs) transmitted per second for the R-PVST+.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <transmit-holdcount>5</transmit-holdcount>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*transmit-holdcount*

Specifies the number of BPDUs than can be sent before pausing for 1 second. The value can range from 1 through 10. The default value is 6 units.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/vlan/forward-delay

Configures the forward-delay for RPVST spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <vlan>
        <id>1</id>
        <forward-delay>20</forward-delay>
      </vlan>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*forward-delay*

Specifies the forward delay time in seconds. The value can range from 4 to 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/vlan/hello-time

Configures the hello interval for the RPVST spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <vlan>
        <id>1</id>
        <hello-time>3</hello-time>
      </vlan>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*hello-time*

Specifies the hello interval. The interval can range from 4 to 30 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rpvst/vlan/max-age

Configures the max-age for the RPVST spanning tree.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <vlan>
        <id>1</id>
        <max-age>25</max-age>
      </vlan>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID.

*max-age*

Specifies the max-age for the RPVST spanning tree.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/rpvst/vlan/priority

Configures the bridge priority.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <vlan>
        <id>1</id>
        <priority>4096</priority>
      </vlan>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*id*

Specifies the VLAN ID

*priority*

Specifies the bridge priority in increments of 4096. The value can range from.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/bridge-priority

Specifies the bridge priority for the common instance.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <bridge-priority>32768</bridge-priority>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*bridge-priority*

Specifies the bridge priority. The values can range from 0 through 61440 in increments of 4096. The default value is 32768.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/description

Configures the Rapid Spanning tree (RSTP) description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <description>rstpspan</description>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*description*

Specifies the RPVST Spanning tree description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/error-disable-timeout/enable

Enables the timer to bring the interface out of the error-disabled state.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*enable*

Enables the timer to bring the interface out of the error-disabled state.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/error-disable-timeout/interval

Configures the timeout for errors on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <error-disable-timeout>
        <interval>500</interval>
      </error-disable-timeout>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*interval*

Specifies the time for the interface to time out. The value can range from 10 through 1000000 seconds. The default value is 300 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/forward-delay

Specifies the time an interface spends in each of the listening and learning states.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <forward-delay>30</forward-delay>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies the time that an interface spends in the RPVST Spanning Tree Protocol (STP) learning and listening states.

Valid values range from 4 through 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/hello-time

Sets the interval between the hello Bridge Protocol Data Units (BPDUs) sent on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <hello-time>4</hello-time>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*hello-time*

Specifies the time interval between the hello BPDUs sent on an interface. The value can range from 1 through 10 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/max-age

Sets the interval time in seconds between messages that the spanning tree receives from the interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <max-age>40</max-age>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*max-age*

Specifies the Rapid Spanning Tree Protocol interface maximum age. The valid value can range from 6 through 40. The default value is 20 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/rstp/port-channel

Sets the path-cost behavior.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <port-channel>
        <path-cost>standard</path-cost>
      </port-channel>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

### *path-cost*

Sets the path cost priority

#### **custom**

Specifies to use the custom behavior, which sets the path-cost changes according to the port-channel's bandwidth .

#### **standard**

Specifies to use the standard behavior, which sets that the path-cost does not change according to port-channel's bandwidth.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/shutdown

Disables the Rapid Spanning Tree Protocol (RSTP) globally.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <shutdown></shutdown>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

### shutdown

Disables the Rapid Spanning Tree Protocol (RSTP) globally.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/rstp/transmit-holdcount

Configures the maximum number of Bridge Protocol Data Units (BPDUs) transmitted per second for the RSTP.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rpvst>
      <transmit-holdcount>5</transmit-holdcount>
    </rpvst>
  </spanning-tree>
</protocol>
```

## Parameters

*transmit-holdcount*

Specifies the number of BPDUs than can be sent before pausing for 1 second. The value can range from 1 through 10. The default value is 6 units.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/bridge-priority

Specifies the bridge priority for the common instance.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <bridge-priority>32768</bridge-priority>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

*bridge-priority*

Specifies the bridge priority. The values can range from 0 through 61440 in increments of 4096. The default value is 32768.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/description

Configures the STP Spanning tree description.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <description>stpspan</description>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

*description*

Specifies the STP Spanning tree description.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/error-disable-timeout/enable

Enables the timer to bring the interface out of the error-disabled state.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <error-disable-timeout>
        <enable></enable>
      </error-disable-timeout>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

### enable

Enables the timer to bring the interface out of the error-disabled state.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/error-disable-timeout/interval

Configures the timeout for errors on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <rstp>
      <error-disable-timeout>
        <interval>550</interval>
      </error-disable-timeout>
    </rstp>
  </spanning-tree>
</protocol>
```

## Parameters

*interval*

Specifies the time for the interface to time out. The value can range from 10 through 1000000 seconds. The default value is 300 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/forward-delay

Specifies the time an interface spends in each of the listening and learning states.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <forward-delay>30</forward-delay>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

*forward-delay*

Specifies the time that an interface spends in the RPVST Spanning Tree Protocol (STP) learning and listening states.

Valid values range from 4 through 30 seconds. The default value is 15 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# protocol/spanning-tree/stp/hello-time

Sets the interval between the hello Bridge Protocol Data Units (BPDUs) sent on an interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <hello-time>5</hello-time>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

*hello-time*

Specifies the time interval between the hello BPDUs sent on an interface. The value can range from 1 through 10 seconds. The default value is 2 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/max-age

Sets the interval time in seconds between messages that the spanning tree receives from the interface.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <max-age>40</max-age>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

*max-age*

Specifies the Rapid Spanning Tree Protocol interface maximum age. The valid value can range from 6 through 40. The default value is 20 seconds.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/port-channel

Sets the path-cost behavior.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">
    <stp>
      <port-channel>
        <path-cost>standard</path-cost>
      </port-channel>
    </stp>
  </spanning-tree>
</protocol>
```

## Parameters

### *path-cost*

Sets the path cost priority

#### **custom**

Specifies to use the custom behavior, which sets the path-cost changes according to the port-channel's bandwidth.

#### **standard**

Specifies to use the standard behavior, which sets that the path-cost does not change according to port-channel's bandwidth.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# protocol/spanning-tree/stp/shutdown

Disables the STP Spanning Tree Protocol globally.

## Usage

```
<protocol xmlns="urn:brocade.com:mgmt:brocade-interface">  
  <spanning-tree xmlns="urn:brocade.com:mgmt:brocade-xstp">  
    <stp>  
      <shutdown></shutdown>  
    </stp>  
  </spanning-tree>  
</protocol>
```

## Parameters

### shutdown

Disables the STP Spanning Tree Protocol globally.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# radius-server

Configures a RADIUS server for AAA.

## Usage

```
<radius-server xmlns="urn:brocade.com:mgmt:brocade-aaa">
  <host>
    <hostname>1.1.1.1</hostname>
    <auth-port>1812</auth-port>
    <protocol>chap</protocol>
    <key>Yf0BKEhsc83gp+kIoGMQ/g==</key>
    <encryption-level>7</encryption-level>
    <retries>6</retries>
    <timeout>10</timeout>
  </host>
</radius-server>
```

## Parameters

### *hostname*

Specifies the domain name or the IP address of this radius server

### *auth-port*

Specifies UDP authentication port. The value can range from 1 through 65535. The default value is 1812

### *protocol*

Specifies the authentication protocol to be used. Three protocol options are available

### *key*

Specifies the secret shared with this server. The secret entered overrides the default secret

### *encryption-level*

Specifies the encryption level. Encryption level can be set to

**0**

Stores the key in clear text format

**7**

Stores the key in encrypted format

### *retries*

Specifies number of retries for this server connection. The value can range from 0 through 100. The default number of retries is set to 5

### *timeout*

Specifies the wait time for this server to respond. The value can range from 1 through 60 seconds. The default value is 5 seconds

## History

Release version	History
7.0.0	This Netconf call was introduced.

Release version	History
16r.1.01	This NETCONF call was introduced.

# ras

Collects data for SupportSave.

## Usage

```
<copy xmlns="urn:brocade.com:mgmt:brocade-ras">
  <support>
    <scp>
      <user>{req_val}</user>
      <host>{req_val}</host>
      <directory>{req_val}</directory>
      <password>{req_val}</password>
      <timeout>{req_val}</timeout>
    </scp>
  </support>
```

## Parameters

### **support**

Specifies support.

### **scp**

Specifies secure copy (SCP).

### *user*

Specifies the username.

### *host*

Specifies the IP address of the host.

### *directory*

Specifies the directory.

### *password*

Specifies the password.

### *timeout*

Specifies the value for timeout.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.

# rmon/alarm

Configures Remote Monitoring Protocol (RMON) alarm.

## Usage

```
<rmon xmlns="urn:brocade.com:mgmt:brocade-rmon">
  <alarm-entry>
    <alarm-index>5</alarm-index>
    <snmp-oid>1.3.6.1.2.1.16.1.1.1.5.65535</snmp-oid>
    <alarm-interval>30</alarm-interval>
    <alarm-sample>absolute</alarm-sample>
    <alarm-rising-threshold>195</alarm-rising-threshold>
    <alarm-rising-event-index>25</alarm-rising-event-index>
    <alarm-falling-threshold>95</alarm-falling-threshold>
    <alarm-falling-event-index>27</alarm-falling-event-index>
    <alarm-owner>john_smith</alarm-owner>
  </alarm-entry>
</rmon>
```

## Parameters

### *alarm-index*

Specifies the alarm index. The value can range from 1 through 65535.

### *snmp-oid*

Specifies sampling object SNMP OID.

### *alarm-interval*

Specifies alarm interval. The interval can range from 1 through 2147483648 seconds.

### *alarm-sample*

Specifies alarm sample type.

#### **absolute**

Sample type absolute.

#### **delta**

Sample type delta.

### *alarm-rising-threshold*

Specifies alarm rising threshold value. The value can range from 0 through 4294967295.

### *alarm-rising-event-index*

Specifies event index for rising threshold. The value can range from 1 through 65535.

### *alarm-falling-threshold*

Specifies alarm falling threshold value. The value can range from 0 through 4294967295.

### *alarm-falling-event-index*

Specifies event index for falling threshold. The value can range from 1 through 65535.

### *alarm-owner*

Specifies the owner identity.



## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# rmon/event

Configures Remote Monitoring Protocol (RMON) event.

## Usage

```
<rmon xmlns="urn:brocade.com:mgmt:brocade-rmon">
  <event-entry>
    <event-index>23</event-index>
    <event-description>event1</event-description>
    <log></log>
    <event-community>default</event-community>
    <event-owner>owner1</event-owner>
  </event-entry>
</rmon>
```

## Parameters

*event-index*

Specifies event index. The value can range from 1 through 65535.

*event-description*

Specifies event description.

**log**

Logs the event.

*event-community*

Sends traps for the event.

*event-owner*

Specifies owner name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# interface/{interface-type}/{interface-name}/isis

Configures the IS-IS protocol.

## Usage

```
<interface xmlns="urn:brocade.com:mgmt:brocade-interface">
  <ethernet>
    <name>{req_val}</name>
    <ip>
      <intf-router-isis xmlns="urn:brocade.com:mgmt:brocade-isis">
        <int-router-isis>
          <interface-ip-router-isis/>
        </int-router-isis>
      </intf-router-isis>
    </ip>
  </ethernet>
</interface>
```

## Parameters

### ethernet

Specifies the Ethernet interface.

### name

Specifies the interface name.

### int-router-isis

Specifies the ISIS router interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/isis/is-type

Changes the IS-IS level globally.

## Usage

```
<routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
  <router>
    <isis xmlns="urn:brocade.com:mgmt:brocade-isis">
      <router-isis-cmds-holder>
        <router-isis-attributes>
          <is-type/>
        </router-isis-attributes>
      </router-isis-cmds-holder>
    </isis>
  </router>
</routing-system>
```

## Parameters

### router-isis-attributes

Configures the ISIS router attributes.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# route-map

Configures, retrieves, and modifies route-map instance.

## Usage

```
<routing-system xmlns="urn:brocade.com:mgmt:brocade-common-def">
  <route-map xmlns="urn:brocade.com:mgmt:brocade-ip-policy">
    <name>{req_val}</name>
    <action-rm>{req_val}</action-rm>
    <instance>{req_val}</instance>
  </route-map>
</routing-system>
```

## Parameters

*name*

Specifies route-map name.

*action-rm*

Specifies the action.

*instance*

Specifies the route-map instance ID.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls

Configures the MPLS protocol.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">  
  <router>  
    <mpls/>  
  </router>  
</mpls-config>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/ldp

Configures the Label Distribution Protocol (LDP).

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <ldp/>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*ldp-session-ip*

Specifies the LDP peer ip address.

*ldp-targeted-peer-ip*

Specifies the peer IP Address.

*load-sharing*

Specifies the number of load-sharing paths.

*hello-interval-link*

In seconds (1-32767, default 5).

*hello-interval-target*

In seconds (1-32767, default 15).

*hello-timeout-link*

In seconds (2-65535, default 15).

*hello-timeout-target*

In seconds (2-65535, default 45).

*ka-interval*

In seconds (1-65535 default 6).

*ka-int-count*

In seconds (1-65535 default 6).

*ka-timeout*

In seconds (1-65535).

*filter-fec-in*

Apply filtering on inbound FECs.

*filter-fec-out*

Apply filtering on inbound FECs.

*advertise-fec*

In seconds (1-65535).

*lsr-id*

IP address to be used as LSR id for LDP.

*filter-fec-out*

Apply filtering on outbound FECs.

*rx-label-silence-timer*

Specifies the receive label silence time (100-60000 ms). The default is 1000.

*key*

Enables TCP-MD5 authentication.

*rx-label-silence-timer*

Specifies the receive label silence time (100-60000 ms). The default value is 1000.

*max-neighbor-reconnect-time*

Specifies the maximum time to wait for neighbor to reconnect (60-300 sec). The default value is 120.

*max-neighbor-recovery-time*

Specifies the maximum time to wait for neighbor to recover (60-3600 sec). The default value is 120.

*reconnect-time*

Specifies the session reconnect time (60-300 sec). The default value is 120.

*recovery-time*

Recovery time (60-3600 sec). The default value is 120.

*tx-label-silence-timer*

Specifies the transmit label silence timer (100-60000 msec).The default value is 1000.

*notification-timer*

Specifies the notification timer (100-120000 msec). The default value is 60000.

*tunnel-metric*

Specifies the LDP tunnel metric value (1-65535; default 0).

*label-withdrawal-delay*

Specifies the label withdrawal delay. The range is from 0 to 300. The default value is 60.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# router/mpls/rsvp

Configures the MPLS RSVP.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <rsvp-periodic-flooding-time/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### policy

Specifies the MPLS policy.

### *rsvp-periodic-flooding-tim*

Specifies the periodic flooding time.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy

Configures an MPLS policy.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy/>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/transit-session-accounting

Enables traffic statistics for transit sessions.

## Usage

```
mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <transit-session-accounting/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*transit-session-accounting*

Specifies transit session account.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/ingress-tunnel-accounting

Enables traffic statistics for tunnel interfaces.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <ingress-tunnel-accounting/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>>
```

## Parameters

*policy*

Specifies the MPLS policy.

*ingress-tunnel-accounting*

Enables traffic statistics for tunnel interfaces

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/qos-ttl-mode

Configures the MPLS TTL and QOS propagation model.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <qos-ttl-mode/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
</filter>
</get-config>
</rpc>
```

## Parameters

*policy*

Specifies the MPLS policy.

*qos-ttl-mode*

Configures the MPLS TTL and QOS propagation model.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/traffic-engineering/isis

Defines timer value for soft preemption to happen.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <traffic-engineering>
            <isis-set-level/>
          </traffic-engineering>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*traffic-engineering*

Specifies traffic engineering.

*isis-set-level*

Sets level for ISIS.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/soft-preemption/cleanup-timer

Defines timer value for soft preemption to happen.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <soft-preemption>
            <cleanup-timer/>
          </soft-preemption>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*soft-preemption*

Specifies the soft preemption.

*cleanup-timer*

Specifies the cleanup timer.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/rsvp-periodic-flooding-time

Sets the interval for RSVP TE periodic flooding.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <rsvp-periodic-flooding-time/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*rsvp-periodic-flooding-time*

Specifies the RSVP periodic flooding time.

*cspf-metric-type*

Specifies the metric type.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# router/mpls/policy/qos-ttl-mode

Configures the MPLS TTL and QOS propagation model.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <qos-ttl-mode/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*qos-ttl-mode*

Configures the MPLS TTL and QOS propagation model.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/rapid-retry

Configures the rapid retry option.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <rapid-retry/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*rapid-retry*

Specifies rapid retry.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/retry-time

Configures LSP retry time.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <retry-time/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*rapid-retry*

Specifies the retry time.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/handle-ospf-neighbor-down

Configures MPLS to handle OSPF neighbor down event.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <handle-ospf-neighbor-down/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*handle-ospf-neighbor-down*

Handles a down OSPF neighbor.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/handle-isis-neighbor-down

Configures MPLS to handle ISIS neighbor down event.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <handle-isis-neighbor-down/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*handle-isis-neighbor-down*

Handles a down ISIS neighbor.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/cspf-interface-constraint

Uses interface IP address for Constrained Shortest Path First (CSPF) computation.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <cspf-interface-constraint/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*cspf-interface-constraint*

Specifies CSPF interface constraint.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/add-penalty

Adds penalty of all matching Constrained Shortest Path First (CSPF)-groups to TE metric of TE link.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <cspf-group-computation>
            <add-penalty/>
          </cspf-group-computation>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*cspf-group-computation*

Specifies CSPF group computation.

*add-penalty*

Adds penalty.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/cspf-computation-mode/metric-type

Selects metric type for CSPF computation..

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <cspf-computation-mode>
            <cspf-metric-type/>
          </cspf-computation-mode>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*cspf-computation-mode*

Specifies the CSPF computation mode.

*cspf-metric-type*

Specifies the metric type.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# router/mpls/policy/cspf-computation-mode/ignore-overload-bit

Ignores overload bit during CSPF computation.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <cspf-computation-mode>
            <ignore-overload-bit/>
          </cspf-computation-mode>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*cspf-computation-mode*

Specifies the CSPF computation mode.

*ignore-overload-bit*

Ignore the overload bit.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/policy/backup-retry-time

Configures the backup retry time.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <backup-retry-time/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

*policy*

Specifies the MPLS policy.

*backup-retry-time*

Specifies the backup retry time.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/cspf-group/(cspf-group-name)/penalty

Configures the Constrained Shortest Path First (CSPF) group penalty value.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <cspf-group>
          <cspf-group-name>{req_val}</cspf-group-name>
          <cspf-group-penalty-n>
            <cspf-group-penalty/>
          </cspf-group-penalty-n>
        </cspf-group>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### **cspf-group**

Configures a CSPF group.

### *cspf-group-name*

Specifies the CSPF group name.

### *cspf-group-penalty-n*

Specifies the CSPF group penalty name.

### *cspf-group-penalty*

Specifies the CSPF group penalty.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mppls/lsp-xc-traps/enable

Enable the LSP XC up, down logging and traps.

## Usage

```
<rpc message-id="101" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <get-config>
    <source>
      <running/>
    </source>
    <filter type="subtree">
      <mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
        <router>
          <mpls>
            <mpls-cmds-holder>
              <lsp-xc-traps>
                <lsp-xc-traps-enable/>
              </lsp-xc-traps>
            </mpls-cmds-holder>
          </mpls>
        </router>
      </mpls-config>
    </filter>
  </get-config>
</rpc>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/cspf-group/(cspf-groupname)/penalty

Configures the CSPF group penalty value.

## Usage-DELETE

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <cspf-group-computation>
            <add-penalty/>
          </cspf-group-computation>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### policy

Specifies the policy.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/lsp-xc-traps/enable

Enables the LSP cross connect up, down, logging, and traps.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <lsp-xc-traps>
          <lsp-xc-traps-enable/>
        </lsp-xc-traps>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### **lsp-xc-traps**

Specifies LSP cross connect traps.

### *lsp-xc-traps-enable*

Enables LSP cross connect traps.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp

Configures the MPLS RSVP.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <policy>
          <rsvp-periodic-flooding-time/>
        </policy>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### policy

Specifies the MPLS policy.

### *rsvp-periodic-flooding-tim*

Specifies the periodic flooding time.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/reliable-messaging/rapid-retry-limit

Configures the maximum number of retries for an unacknowledged message.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-reliable-messaging>
            <rapid-retry-limit/>
          </g-reliable-messaging>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- g-reliable-messaging**  
Specifies the group reliable messaging.
- bundle-message*  
Specifies the bundle message.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# router/mpls/rsvp/reliable-messaging/rapid-retrans-interval

Configures an interval for an unacknowledged message to be resent.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-reliable-messaging>
            <rapid-retrans-interval/>
          </g-reliable-messaging>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- g-reliable-messaging**  
Specifies group reliable messaging.
- rapid-retrans-interval*  
Specifies interval for rapid retransmission.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/reliable-messaging/rapid-retrans-decay

Percentage increase in the rapid retransmission interval for each consecutive unacknowledged RSVP message.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-reliable-messaging>
            <rapid-retrans-decay/>
          </g-reliable-messaging>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- g-reliable-messaging**  
Specifies group reliable messaging.
- rapid-retrans-decay*  
Specifies rapid retransmission decay.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/refresh-reduction/bundle-message/bundle-send-delay

Configure the bundle send delay value.

bundle-send-delay

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-refresh-reduction>
            <bundle-message>
              <bundle-send-delay/>
            </bundle-message>
          </g-refresh-reduction>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### **rsvp**

Specifies the MPLS Resource Reservation Protocol (RSVP).

### **g-refresh-reduction**

Specifies the group refresh reduction value.

### *bundle-message*

Specifies the bundle message.

### *bundle-send-delay*

Specifies the bundle send delay.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/refresh-multiple

Configures the MPLS RSVP refresh multiple.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <refresh-multiple/>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- refresh-multiple*  
Specifies refresh multiple.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/refresh-interval

Configures the MPLS RSVP refresh interval.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <refresh-interval/>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- refresh-interval*  
Specifies the refresh interval.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/g-rsvp-backup-bw-guarantee

Sets up a backup path requesting bandwidth.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-rsvp-backup-bw-guarantee/>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

### rsvp

Specifies the MPLS Resource Reservation Protocol (RSVP).

### g-rsvp-backup-bw-guarantee

Specifies bandwidth guarantee for the group RSVP backup.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/global-rsvp-hello-acknowledgements

Acknowledges the RSVP hellos on interfaces supporting RSVP hello and not having RSVP sessions.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <global-rsvp-hello-acknowledgements/>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- global-rsvp-hello-acknowledgements**  
Specifies global RSVP hello acknowledgements.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/global-rsvp-hello/tolerance

Configures the number of unacknowledged RSVP hello requests before timeout.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <global-rsvp-hello>
            <global-rsvp-hello-tolerance/>
          </global-rsvp-hello>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- global-rsvp-hello**  
Specifies the global RSVP hello.
- global-rsvp-hello-tolerance*  
Specifies the tolerance value for global RSVP hello.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# router/mpls/rsvp/global-rsvp-hello

Configures the interval between two RSVP hello requests.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <global-rsvp-hello>
            <global-rsvp-hello-interval/>
          </global-rsvp-hello>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- global-rsvp-hello**  
Specifies global RSVP hello
- global-rsvp-hello-interval*  
Specifies the interval for global RSVP hello.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# router/mpls/rsvp/refresh-reduction/summary-refresh

Configures the refresh reduction summary refresh feature.

## Usage

```
<mpls-config xmlns="urn:brocade.com:mgmt:brocade-mpls">
  <router>
    <mpls>
      <mpls-cmds-holder>
        <rsvp>
          <g-refresh-reduction>
            <summary-refresh/>
          </g-refresh-reduction>
        </rsvp>
      </mpls-cmds-holder>
    </mpls>
  </router>
</mpls-config>
```

## Parameters

- rsvp**  
Specifies the MPLS Resource Reservation Protocol (RSVP).
- summary-refresh**  
Specifies summary refresh.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# qos-mpls

Configures, retrieves, and modifies MPLS Quality of Service (QoS).

## Usage

```
<qos-mpls xmlns="urn:brocade.com:mgmt:brocade-qos-mpls">
  <map>
    <exp-traffic-class>
      <exp-traffic-class-map-name>{req_val}</exp-traffic-class-map-name>
    </exp-traffic-class>
  </map>
</qos-mpls>
```

## Parameters

### map

Specifies the map.

### *exp-traffic-class*

The EXP traffic class value. Valid values range from 0 through 7.

### *exp-traffic-class-map-name*

The EXP traffic class map name.

## History

Release version	History
16r.1.01	This call was introduced.

# sflow/agent-address

Configures the sFlow agent-ID address..

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
  <agent-address>
    <agent-interface-name/>
  </agent-address>
</sflow>
```

## Parameters

### ipv4

Specifies an agent-address configuration for IPv4 collectors.

### ipv6

Specifies an agent-address configuration for IPv6 collectors.

### ethernet *slot/port*

Specifies an Ethernet slot and port..

### loopback *loopback-number*

Specifies a loopback interface. Valid values range from 1 through 255.

### management *slot*

Specifies a management interface.

### ve *ve-inteface*

Specifies a virtual Ethernet (VE) interface. Valid values range from 1 through 4096.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# sflow/collector

Configures sFlow collector.

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">
  <collector>
    <collector-ip-address>1.1.1.1</collector-ip-address>
    <collector-port-number>50</collector-port-number>
    <use-vrf>mgmt-vrf</use-vrf>
  </collector>
</sflow>
```

## Parameters

*collector-ip-address*

Specifies the IP address of the sFlow collector

*collector-port-number*

Specifies the port number used by the sFlow collector. The value can range from 1 through 65535

*use-vrf*

Specifies the VRF to use for sending data to the collector

## History

Release version	History
7.0.0	This Netconf call was introduced.

Release version	History
16r.1.01	This NETCONF call was introduced.

# sflow/enable

Enables sFlow globally.

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">  
  <enable></enable>  
</sflow>
```

## Parameters

**enable**

Enable sFlow globally

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# sflow/polling-interval

Configures interface counter polling interval.

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">  
  <polling-interval>25</polling-interval>  
</sflow>
```

## Parameters

*polling-interval*

Specifies polling interval value. The value can range from 1 through 65535. The default value is 20

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# sflow/sample-rate

Configures interface sampling rate.

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">  
  <sample-rate>32768</sample-rate>  
</sflow>
```

## Parameters

*sample-rate*

Specifies sampling rate value. The value can range from 2 through 16777215. The default value is 32768

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# sflow/source-ip

Configures source IP address to use.

## Usage

```
<sflow xmlns="urn:brocade.com:mgmt:brocade-sflow">  
  <source-ip>chassis-ip</source-ip>  
</sflow>
```

## Parameters

*source-ip*

Specifies the source IP address to use

**chassis-ip**

Uses chassis IP as source address

**mm-ip**

Uses local MM IP as source address

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# sflow-profile

Configures sflow profile sampling rate.

## Usage

```
<sflow-profile xmlns="urn:brocade.com:mgmt:brocade-sflow">  
  <profile-name>sflow1</profile-name>  
  <profile-sampling-rate>4</profile-sampling-rate>  
</sflow-profile>
```

## Parameters

*profile-name*

Specifies Sflow profile name

*profile-sampling-rate*

Specifies Sflow sampling rate. The value can range from 2 through 8388608

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor

Configures, modifies, or retrieves FRU threshold and alert setting.

## Usage

```
<system-monitor xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <fan>
    <alert>
      <action/>
    </alert>
  </fan>
</system-monitor>

<system-monitor xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <power>
    <threshold/>
  </power>
</system-monitor>
```

## Parameters

<b>fan</b>	Specifies the fan.
<i>alert</i>	The fan alert notification.
<i>action</i>	Specifies the action to be taken.
<b>power</b>	Specifies power supply.
<i>threshold</i>	The power supply threshold.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/fru (email)

Configures e-mail address for FRU alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <fru>
    <email-list>
      <email>abc@brocade.com</email>
    </email-list>
  </fru>
</system-monitor-mail>
```

## Parameters

*email*

Specifies e-mail address for FRU alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/fru/enable

Enables FRU e-mail alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">  
  <fru>  
    <enable></enable>  
  </fru>  
</system-monitor-mail>
```

## Parameters

### enable

Enables FRU e-mail alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/interface (email)

Configures e-mail address for interface alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <interface>
    <email-list>
      <email>abc@brocade.com</email>
    </email-list>
  </interface>
</system-monitor-mail>
```

## Parameters

*email*

Specifies e-mail address for interface alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/interface/enable

Enables interface e-mail alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">  
  <interface>  
    <enable></enable>  
  </interface>  
</system-monitor-mail>
```

## Parameters

### enable

Enables interface e-mail alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/relay

Configures relay IP mail settings.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <relay>
    <host-ip>1.1.1.1</host-ip>
    <domain-name>domain1</domain-name>
  </relay>
</system-monitor-mail>
```

## Parameters

*host-ip*

Specifies host IP address

*domain-name*

Specifies domain server name

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# system-monitor-mail/security (email)

Configures e-mail address for security alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <security>
    <email-list>
      <email>abc@brocade.com</email>
    </email-list>
  </security>
</system-monitor-mail>
```

## Parameters

*email*

Specifies e-mail address for security alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/security/enable

Enables security e-mail alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">  
  <security>  
    <enable></enable>  
  </security>  
</system-monitor-mail>
```

## Parameters

### enable

Enables security e-mail alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/sfp (email)

Configures e-mail address for SFP alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">
  <sfp>
    <email-list>
      <email>abc@brocade.com</email>
    </email-list>
  </sfp>
</system-monitor-mail>
```

## Parameters

*email*

Specifies e-mail address for SFP alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-monitor-mail/sfp/enable

Enables sfp e-mail alerts.

## Usage

```
<system-monitor-mail xmlns="urn:brocade.com:mgmt:brocade-system-monitor">  
  <sfp>  
    <enable></enable>  
  </sfp>  
</system-monitor-mail>
```

## Parameters

### enable

Enables sfp e-mail alerts

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# system-watermark

Defines system-related information.

## Usage

```
<system-config xmlns="urn:brocade.com:mgmt:brocade-system-watermark">  
  <interface>  
    <utilization-watermark/>  
  </interface>  
</system-config>
```

## Parameters

### interface

Specifies the protocol.

### utilization-watermark

Specifies the utilization watermark.

## History

Release version	History
17r.1.00	This NETCONF call was introduced.

# topology-group

Configures topology VLAN group for L2 protocols.

## Usage

```
<topology-group xmlns="urn:brocade.com:mgmt:brocade-topology-group">
  <topology-group-id>{req_val}</topology-group-id>
  <member-vlan>
    <member-vlan-add/>
  </member-vlan>
</topology-group>>
```

## Parameters

*topology-group-id*

Specifies topology group ID.

**member-valn**

Configures member VLANs.

**master-vlan**

Configures master VLANs.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# uda-access-list

Creates a user-defined ACL (UDA).

## Usage

```
<uda xmlns="urn:brocade.com:mgmt:brocade-uda-access-list">
  <access-list>
    <extended>
      <name>%req_val%</name>
      <uda-acl-ext>
        <seq>
          <seq-id>%req_val%</seq-id>
          <count/>
        </seq>
      </uda-acl-ext>
    </extended>
  </access-list>
```

## Parameters

### extended

Specifies an extended ACL. Extended ACLs contain rules that permit or deny traffic according to source and destination addresses, as well as other parameters. UDAs cannot be standard ACLs, which filter by source address only.

### name

Specifies an ACL name unique among all ACLs (Layer 2, Layer 3, and UDAs). The name can be up to 63 characters in length, and must begin with an alphanumeric character. No special characters are allowed, except for the underscore and hyphen.

### seq seq-id

Enables you to assign a sequence number to the rule. If you do not specify seq seq-value, the rule is added at the end of the list. Valid values range from 1 through 65535.

## History

Release version	History
17r.2.00	This NETCONF call was introduced.

# vlan/{vlan-name}/mac

Configures a MAC access group.

## Usage

```
<interface-vlan xmlns="urn:brocade.com:mgmt:brocade-interface">
  <vlan>
    <name>{req_val}</name>
    <mac xmlns="urn:brocade.com:mgmt:brocade-mac-access-list">
      <access-group>
        <mac-access-list>{req_val}</mac-access-list>
        <mac-direction>{req_val}</mac-direction>
        <traffic-type/>
      </access-group>
    </mac>
  </vlan>
</interface-vlan>
```

## Parameters

### vlan

Specifies vlan.

### name

Specifies the VLAN name.

### access-group

Specifies the MAC access- group.

### mac-access-list

Specifies the mac-access list.

### mac-direction

Specifies the MAC direction.

### traffic-type

Specifies the traffic type.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# vlan/classifier/group

Configures VLAN classification group commands.

## Usage

```
<vlan xmlns="urn:brocade.com:mgmt:brocade-vlan">
  <classifier>
    <group>
      <groupid>2</groupid>
      <oper>add</oper>
      <rule-name>rule</rule-name>
      <ruleid>2</ruleid>
    </group>
  </classifier>
</vlan>
```

## Parameters

*groupid*

Specifies VLAN classifier group ID. The value can range from 1 through 16

*oper*

Specifies the operation

**add**

Add rule

**delete**

Delete rule

*rule-name*

Specifies VLAN classifier rule name

*ruleid*

Specifies VLAN classifier rule ID

## History

Release version	History
7.0.0	This NETCONF call was introduced.

# vlan/classifier/rule/mac

Configures VLAN classification rule commands.

## Usage

```
<vlan xmlns="urn:brocade.com:mgmt:brocade-vlan">
  <classifier>
    <rule>
      <ruleid>2</ruleid>
      <mac>
        <address>0011.1122.2233</address>
      </mac>
    </rule>
  </classifier>
</vlan>
```

## Parameters

*ruleid*

Specifies the rule ID. The value can range from 1 through 256

*address*

Specifies MAC address in HHHH.HHHH.HHHH format

## History

Release version	History
7.0.0	This NETCONF call was introduced.

# vlan/classifier/rule/proto

Configures the protocol to use for the VLAN classifier rule.

## Usage

```
<vlan xmlns="urn:brocade.com:mgmt:brocade-vlan">
  <classifier>
    <rule>
      <ruleid>2</ruleid>
      <proto>
        <proto-val>arp</proto-val>
        <encap>ethv2</encap>
      </proto>
    </rule>
  </classifier>
</vlan>
```

## Parameters

*ruleid*

Specifies the VLAN identification rule. The values can range from 1 through 2556

*proto-val*

Specifies the protocol to use for the VLAN classifier rule

*hex\_addr*

Specifies an Ethernet hexadecimal value. The value can range from 0x0000 through 0xffff

**arp**

Specifies to use the Address Resolution Protocol

**ip**

Specifies to use the Internet Protocol

**ipv6**

Specifies to use the Internet Protocol version 6

*encap*

Specifies to encapsulate the Ethernet frames sent for the VLAN classifier rule

**ethv2**

Specifies to use the Ethernet version 2 encapsulated frames

**nosnapllc**

Specifies to use the Ethernet version 2 non-SNA frames

**snapllc**

Specifies to use the Ethernet version 2 with SNA frames

## History

Release version	History
7.0.0	This NETCONF call was introduced.

# vlan/dot1q

Configures dot1q parameters.

## Usage

```
<vlan xmlns="urn:brocade.com:mgmt:brocade-vlan">  
  <dot1q>  
    <tag>  
      <native></native>  
    </tag>  
  </dot1q>  
</vlan>
```

## Parameters

**native**

Enables tagged behavior for native-VLANs

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vrf

Configures the virtual rounding and forwarding (VRF).

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vrf/{vrf-name}/address-family/ipv4/unicast

Configures the IPv4 address family configurations.

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
  <address-family>
    <ip>
      <unicast/>
    </ip>
  </address-family>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

**address-family**

Specifies address family.

**ip**

Specifies the IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vrf/{vrf-name}/address-family/ipv4/unicast/max-route

Configures IPv4 address family maximum route.

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
  <address-family>
    <ip>
      <unicast>
        <max-route/>
      </unicast>
    </ip>
  </address-family>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

**address-family**

Specifies address family.

**ip**

Specifies the IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vrf/{vrf-name}/address-family/ipv6/unicast

Configures the IPv6 address family configurations.

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
  <address-family>
    <ipv6>
      <unicast/>
    </ipv6>
  </address-family>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

**address-family**

Specifies address family.

**ipv6**

Specifies the IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# vrf/{vrf-name}/address-family/ipv6/unicast/max-route

Configures IPv6 address family maximum route.

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
  <address-family>
    <ipv6>
      <unicast>
        <max-route/>
      </unicast>
    </ipv6>
  </address-family>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

**address-family**

Specifies address family.

**ipv6**

Specifies the IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vrf/{vrf-name}/ip/router-id

Configures the IP route details..

## Usage

```
<vrf xmlns="urn:brocade.com:mgmt:brocade-vrf">
  <vrf-name>{req_val}</vrf-name>
  <ip>
    <vrf-router-id/>
  </ip>
</vrf>
```

## Parameters

*vrf-name*

Specifies the VRF name.

**vrf-router-id**

Specifies the VRF router ID..

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# vxlan-visibility

Configures an overlay transit.

## Usage

```
<overlay xmlns="urn:brocade.com:mgmt:brocade-vxlan-visibility">  
  <access-list>  
    <type>  
      <vxlan/>  
    </type>  
  </access-list>  
</overlay>
```

## Parameters

### access-list

Specifies the access list.

### type

Specifies the VXLAN type: extended or standard.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# bna-config-cmd

Copies configuration data to and from the system.

## Usage

```
<rpc xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="212">
  <bna-config-cmd xmlns="urn:brocade.com:mgmt:brocade-ras">
    <src>default-config</src>
    <dest>startup-config</dest>
  </bna-config-cmd>
</rpc>

<rpc-reply message-id="212" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <session-id xmlns="urn:brocade.com:mgmt:brocade-ras">5</session-id>
  <status xmlns="urn:brocade.com:mgmt:brocade-ras">in-progress</status>
</rpc-reply>
```

## Parameters

*session-id*

This id is used along with bna-config-cmd-status API to get the status of this operation (inprogress/complete).

*status*

Displays the status of this operation (inprogress/complete).

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# clear-mpls-ldp-statistics

Clears the MPLS LDP control plane statistics.

## Usage

```
<clear-mpls-ldp-statistics xmlns="urn:brocade.com:mgmt:brocade-mpls"/>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# clear-mpls-lsp

Resets a tunnel and enables it back.

## Usage

```
<clear-mpls-lsp xmlns="urn:brocade.com:mgmt:brocade-mpls">  
  <mpls-clear-lsp-name-in>lspto</mpls-clear-lsp-name-in>  
</clear-mpls-lsp>
```

## Parameters

*mpls-clear-lsp-name-in*

Specifies the LSP name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# clear-mpls-rsvp-statistics

Clears the MPLS RSVP control plane statistics.

## Usage

```
<clear-mpls-rsvp-statistics xmlns="urn:brocade.com:mgmt:brocade-mpls"/>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# clear-mpls-rsvp-statistics-neighbor-address

Clears an RSVP neighbor.

## Usage

```
<clear-mpls-rsvp-statistics-neighbor xmlns="urn:brocade.com:mgmt:brocade-mpls">  
  <clear-mpls-rsvp-statistics-neighbor-address>29.19.1.19</clear-mpls-rsvp-statistics-neighbor-address>  
</clear-mpls-rsvp-statistics-neighbor>
```

## Parameters

*clear-mpls-rsvp-statistics-neighbor-address*

Specifies the RSVP neighbor with the specific IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# clear-mpls-rsvp-statistics-neighbor-all

Clears all RSVP neighbors.

## Usage

```
<clear-mpls-rsvp-statistics-neighbor xmlns=""urn:brocade.com:mgmt:brocade-mpls"">
  <clear-mpls-rsvp-statistics-neighbor-all>true</clear-mpls-rsvp-statistics-neighbor-all>
</clear-mpls-rsvp-statistics-neighbor>
```

## Parameters

*clear-mpls-rsvp-statistics-neighbor-all*  
Clears all MPLS RSVP neighbors.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# dad-status

Displays the current status of firmware download.

## Usage

```
<dad-status></dad-status>
```

```
<rpc-reply message-id="1" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <dad-status xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <dad-status-entries>
      <index>1</index>
      <date-and-time-info>Fri Nov 25 21:01:12 GMT 2016</date-and-time-info>
      <message>DHCP Auto-deployment enabled.</message>
    </dad-status-entries>
  </dad-status>
</rpc-reply>
```

## Parameters

*index*

Displays the Index number

*date-and-time-info*

Displays the Date and time information

*message*

Displays the status message

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# fwdl-status

Returns the status of the firmware download operation.

## Usage

```
<fwdl-status></fwdl-status>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="71">
  <fwdl-state xmlns="urn:brocade.com:mgmt:brocade-firmware">completed</fwdl-state>
  <number-of-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">24</number-of-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>1</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:20:20</date-and-time-info>
    <message>Firmware install begins.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>2</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:23:25</date-and-time-info>
    <message>Firmware install ends.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>3</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:23:25</date-and-time-info>
    <message>Firmware install begins.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>4</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:26:27</date-and-time-info>
    <message>Firmware install ends.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>5</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:26:28</date-and-time-info>
    <message>Firmware starts to swap.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>6</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:26:28</date-and-time-info>
    <message>Firmware starts to swap.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>7</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:26:34</date-and-time-info>
    <message>Firmware is swapped.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>8</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:26:36</date-and-time-info>
    <message>Firmware is swapped.</message>
  </fwdl-entries>
```

```

<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>9</index>
  <blade-name>SW/0</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:26:36</date-and-time-info>
  <message>Firmware is downloaded successfully.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>10</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:26:37</date-and-time-info>
  <message>Firmware is downloaded successfully.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>11</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:17</date-and-time-info>
  <message>The DB/filesystem starts shutting down.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>12</index>
  <blade-name>SW/0</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:17</date-and-time-info>
  <message>The DB/filesystem starts shutting down.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>13</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:35</date-and-time-info>
  <message>The DB/filesystem has been shut down.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>14</index>
  <blade-name>SW/0</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:37</date-and-time-info>
  <message>The DB/filesystem has been shut down.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>15</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:38</date-and-time-info>
  <message>The blade begins to reboot.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>16</index>
  <blade-name>SW/0</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:34:38</date-and-time-info>
  <message>The blade begins to reboot.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>17</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:44:23</date-and-time-info>
  <message>The blade is rebooted.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>18</index>
  <blade-name>SW/1</blade-name>
  <message-id>0</message-id>
  <date-and-time-info>2016-11-29/01:44:23</date-and-time-info>
  <message>Firmware commit begins.</message>
</fwdl-entries>
<fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
  <index>19</index>

```

```

    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:44:23</date-and-time-info>
    <message>The blade is rebooted.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>20</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:44:23</date-and-time-info>
    <message>Firmware commit begins.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>21</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:48:42</date-and-time-info>
    <message>Firmware commit ends.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>22</index>
    <blade-name>SW/0</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:48:42</date-and-time-info>
    <message>Firmware is downloaded successfully.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>23</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:48:51</date-and-time-info>
    <message>Firmware commit ends.</message>
  </fwdl-entries>
  <fwdl-entries xmlns="urn:brocade.com:mgmt:brocade-firmware">
    <index>24</index>
    <blade-name>SW/1</blade-name>
    <message-id>0</message-id>
    <date-and-time-info>2016-11-29/01:48:51</date-and-time-info>
    <message>Firmware is downloaded successfully.</message>
  </fwdl-entries>
</rpc-reply>

```

## Parameters

### *fwdl-state*

Specifies the firmware download state.

### *number-of-entries*

Specifies the number of status entries.

### *index*

Specifies the sequence number for the message.

### *blade-name*

Specifies the name of the blade.

### *message-id*

Specifies the message identifier.

### *date-and-time-info*

Specifies the date and time of the message. The format is YYYY-MM-DD/HH:MM:SS.SSSS.

### *message*

Displays the textual description of the status.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-arp

Retrieves the ARP cache information.

## Usage

```
<get-arp xmlns="urn:brocade.com:mgmt:brocade-arp"></get-arp>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1">
  <arp-entry>
    <ip-address>20.0.0.122</ip-address>
    <mac-address>0005.3379.407a</mac-address>
    <interface-type>unknown</interface-type>
    <interface-name></interface-name>
    <is-resolved>true</is-resolved>
    <age>03:16:05</age>
    <entry-type>dynamic</entry-type>
  </arp-entry>
</rpc-reply>
```

## Parameters

*ip-address*

Displays the IP address of the ARP entry.

*mac-address*

Displays the MAC address of the ARP entry.

*interface-type*

Displays the interface type.

*interface-name*

Displays the interface name.

*is-resolved*

Indicates whether the ARP entry is resolved or not.

*age*

Displays the age of the ARP entry.

*entry-type*

Displays the type of the ARP entry.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-contained-in-ID

Retrieves enclosure related information on embedded platforms.

## Usage

```
<get-contained-in-ID xmlns="urn:brocade.com:mgmt:brocade-entity"></get-contained-in-ID>  
  
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1">  
  <contained-in-ID>Bay 7</contained-in-ID>  
</rpc-reply>
```

## Parameters

*contained-in-ID*

Displays present slot ID of switch.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



## get-interface-detail

Returns operational details of all the possible interfaces of the managed entity. Use this RPC to discover basic characteristics of all the interfaces in the system. Each sublayer below the internetwork layer of a network interface is considered to be an interface.

### Usage

```
<get-interface-detail></get-interface-detail>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="67">
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/4</interface-name>
    <port-role>edge</port-role>
    <port-mode>unknown</port-mode>
    <if-name>ethernet 2/4</if-name>
    <if-state>up</if-state>
    <line-protocol-state>down</line-protocol-state>
    <line-protocol-state-info> (link protocol down)</line-protocol-state-info>
    <hardware-type>ethernet</hardware-type>
    <current-hardware-address>50:eb:1a:17:40:28</current-hardware-address>
    <logical-hardware-address>50:eb:1a:17:40:28</logical-hardware-address>
    <ifindex>8791662784</ifindex>
    <mtu>2500</mtu>
    <actual-line-speed>nil</actual-line-speed>
    <configured-line-speed>auto</configured-line-speed>
    <line-duplex-state>full</line-duplex-state>
    <flow-control></flow-control>
    <queuing-strategy>fifo</queuing-strategy>
    <ifHCInOctets>0</ifHCInOctets>
    <ifHCInUcastPkts>0</ifHCInUcastPkts>
    <ifHCInMulticastPkts>0</ifHCInMulticastPkts>
    <ifHCInBroadcastPkts>0</ifHCInBroadcastPkts>
    <ifHCInErrors>0</ifHCInErrors>
    <ifHCOutOctets>0</ifHCOutOctets>
    <ifHCOutUcastPkts>0</ifHCOutUcastPkts>
    <ifHCOutMulticastPkts>0</ifHCOutMulticastPkts>
    <ifHCOutBroadcastPkts>0</ifHCOutBroadcastPkts>
    <ifHCOutErrors>0</ifHCOutErrors>
  </interface>
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/3</interface-name>
    <port-role>isl</port-role>
    <port-mode>unknown</port-mode>
    <if-name>ethernet 2/3</if-name>
    <if-state>up</if-state>
    <line-protocol-state>up</line-protocol-state>
    <line-protocol-state-info> (connected)</line-protocol-state-info>
    <hardware-type>ethernet</hardware-type>
    <current-hardware-address>50:eb:1a:17:3f:f8</current-hardware-address>
    <logical-hardware-address>50:eb:1a:17:3f:f8</logical-hardware-address>
    <media-type>sfp</media-type>
    <wavelength>1310</wavelength>
    <ifindex>8791269376</ifindex>
    <mtu>9216</mtu>
    <actual-line-speed>10Gbps</actual-line-speed>
    <configured-line-speed>auto</configured-line-speed>
    <line-duplex-state>full</line-duplex-state>
    <flow-control></flow-control>
    <queuing-strategy>fifo</queuing-strategy>
    <ifHCInOctets>303455437</ifHCInOctets>
    <ifHCInUcastPkts>301429</ifHCInUcastPkts>
    <ifHCInMulticastPkts>79743</ifHCInMulticastPkts>
    <ifHCInBroadcastPkts>0</ifHCInBroadcastPkts>
```

```

    <ifHCInErrors>0</ifHCInErrors>
    <ifHCOutOctets>300765428</ifHCOutOctets>
    <ifHCOutUcastPkts>301347</ifHCOutUcastPkts>
    <ifHCOutMulticastPkts>56906</ifHCOutMulticastPkts>
    <ifHCOutBroadcastPkts>0</ifHCOutBroadcastPkts>
    <ifHCOutErrors>0</ifHCOutErrors>
  </interface>
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/4</interface-name>
    <port-role>edge</port-role>
    <port-mode>unknown</port-mode>
    <if-name>ethernet 2/4</if-name>
    <if-state>up</if-state>
    <line-protocol-state>down</line-protocol-state>
    <line-protocol-state-info> (link protocol down)</line-protocol-state-info>
    <hardware-type>ethernet</hardware-type>
    <current-hardware-address>50:eb:1a:17:40:1d</current-hardware-address>
    <logical-hardware-address>50:eb:1a:17:40:1d</logical-hardware-address>
    <ifindex>8791572480</ifindex>
    <mtu>2500</mtu>
    <actual-line-speed>nil</actual-line-speed>
    <configured-line-speed>auto</configured-line-speed>
    <line-duplex-state>full</line-duplex-state>
    <flow-control></flow-control>
    <queuing-strategy>fifo</queuing-strategy>
    <ifHCInOctets>0</ifHCInOctets>
    <ifHCInUcastPkts>0</ifHCInUcastPkts>
    <ifHCInMulticastPkts>0</ifHCInMulticastPkts>
    <ifHCInBroadcastPkts>0</ifHCInBroadcastPkts>
    <ifHCInErrors>0</ifHCInErrors>
    <ifHCOutOctets>0</ifHCOutOctets>
    <ifHCOutUcastPkts>0</ifHCOutUcastPkts>
    <ifHCOutMulticastPkts>0</ifHCOutMulticastPkts>
    <ifHCOutBroadcastPkts>0</ifHCOutBroadcastPkts>
    <ifHCOutErrors>0</ifHCOutErrors>
  </interface>
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>l2vlan</interface-type>
    <interface-name>1</interface-name>
    <if-name>Vlan 1</if-name>
    <ifindex>1207959553</ifindex>
    <queuing-strategy>fifo</queuing-strategy>
  </interface>
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>l2vlan</interface-type>
    <interface-name>10</interface-name>
    <if-name>Vlan 10</if-name>
    <current-hardware-address>00:27:f8:fd:00:03</current-hardware-address>
    <logical-hardware-address>00:27:f8:fd:00:03</logical-hardware-address>
    <ifindex>1207959562</ifindex>
    <queuing-strategy>fifo</queuing-strategy>
  </interface>
  <has-more xmlns="urn:brocade.com:mgmt:brocade-interface-ext">false</has-more>
</rpc-reply>

```

## Parameters

### *interface-type*

Specifies the interface type.

### *interface-name*

Specifies the interface name.

### *port-role*

Displays the current role that the particular interface is playing. This is applicable only for physical interfaces.

*port-mode*

Displays the operational mode of the particular interface. This is applicable only for physical interfaces or port-channel interfaces.

*if-name*

Displays the interface display name as in MIB-II's ifTable. However interface-name and interface-type values of this instance forms fully qualified name for this interface.

*if-state*

Displays the current operational state of this interface.

*line-protocol-state*

Displays the 'Line protocol' state of the interface.

*line-protocol-state-info*

Displays the reason for the current line protocol state of the interface.

*hardware-type*

Displays the hardware type

*current-hardware-address*

Displays the address of the interface at its protocol sub-layer.

*logical-hardware-address*

Displays the address of the interface at its protocol sub-layer.

*ifindex*

Displays a unique value, greater than zero, for each interface.

*mtu*

Displays the IP MTU value of the interface.

*actual-line-speed*

Displays the actual line speed of this interface.

*configured-line-speed*

Displays the administratively configured line speed of the interface.

*line-duplex-state*

Displays the 'Line duplex state' of the interface.

*flow-control*

Displays the 'Flow control' for the interface.

*queuing-strategy*

Displays the 'Queuing strategy' for the interface.

*ifHCInOctets*

Displays the total number of octets received on the interface, including framing characters.

*ifHCInUcastPkts*

Displays the The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were not addressed to a multicast or broadcast address at this sub-layer.

*ifHCInMulticastPkts*

Displays The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address at the sub-layer. For a MAC layer protocol, this includes both Group and Functional addresses.

*ifHCInBroadcastPkts*

Displays the The number of packets, delivered by the sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at the sub-layer.

*ifHCInErrors*

For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.

*ifHCOctets*

Displays the total number of octets transmitted out of the interface, including framing characters

*ifHCOUcastPkts*

Displays the total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at the sub-layer, including those that were discarded or not sent.

*ifHCOMulticastPkts*

Dispalys the total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.

*ifHCOBroadcastPkts*

Displays the total number of packets that higher-level protocols requested be transmitted, and which were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.

*ifHCOErrors*

For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.

*ip-mtu*

Displays the IP MTU value of this interface.

*line-protocol-exception-info*

Displays the 'Exception information' of line protocol.

*media-type*

Displays the media type.

*wavelength*

Displays the wavelength of pluggable media.

*if-description*

Displays the textual string containing information about the interface.

*queuing-strategy*

Displays the 'Queuing strategy' for this interface.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-interface-switchport

Returns switch-port or Layer 2 characteristics of all the interfaces in the managed device.

## Usage

```
<get-interface-switchport></get-interface-switchport>
```

```
<rpc-reply message-id="303" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <switchport xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-name>2/1</interface-name>
    <interface-type>ethernet</interface-type>
    <mode>access</mode>
    <ingress-filter-enabled>true</ingress-filter-enabled>
    <acceptable-frame-type>admit-all</acceptable-frame-type>
    <default-vlan>1</default-vlan>
    <active-vlans>
      <vlanid>1</vlanid>
    </active-vlans>
  </switchport>
</rpc-reply>
```

## Parameters

*interface-name*

Specifies the interface value.

*interface-type*

Displays the type of the interface.

*mode*

Displays the mode of the port-channel.

*ingress-filter-enabled*

Indicates if the 'Ingress filtering' is enabled for the interface.

*acceptable-frame-type*

The switch-port ingress Frame admission policy - whether only tagged Frames are allowed or all.

*default-vlan*

Displays 'default vlan' identifier value for this switch-port.

*vlanid*

Displays the list of active VLAN identifiers.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-ip-interface

Returns brief details of all interfaces, loopback and VE interface details of particular managed entity.

## Usage

```
<get-ip-interface></get-ip-interface>

<rpc-reply message-id="307" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface">
    <interface-type>ethernet</interface-type>
    <interface-name>2/4</interface-name>
    <if-name>ethernet 2/4</if-name>
    <if-state>up</if-state>
    <line-protocol-state>down</line-protocol-state>
    <ip-address>
      <ipv4>unassigned</ipv4>
    </ip-address>
  </interface>
</rpc-reply>
```

## Parameters

### *interface-type*

Displays the network interface name in a VCS environment in the format: slot/port .

### *interface-name*

Displays the interface value.

### *if-name*

The interface display name as in MIB-II's ifTable. However interface-name and interface-type values of this instance forms fully qualified name for this interface.

### *if-state*

Displays the current operational state of the interface.

### *line-protocol-state*

Displays the 'Line protocol' state of the interface.

### *ipv4*

Displays the IP address in dotted decimal/Mask (A.B.C.D/M).

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-last-config-update-time

Returns the time stamp of the last configuration change done on the managed device.

## Usage

```
<get-last-config-update-time></get-last-config-update-time>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="64">
  <last-config-update-time xmlns="urn:brocade.com:mgmt:brocade-vcs">1401804078</last-config-update-
time>
</rpc-reply>
```

## Parameters

*last-config-update-time*

Displays the time stamp of the last configuration change.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-lldp-neighbor-detail

Returns the details of all the neighboring interfaces of the managed entity.

## Usage

```
<get-lldp-neighbor-detail></get-lldp-neighbor-detail>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="4">
  <lldp-neighbor-detail xmlns="urn:brocade.com:mgmt:brocade-lldp-ext">
    <local-interface-name>ethernet 1/3</local-interface-name>
    <local-interface-ifindex>203448320</local-interface-ifindex>
    <local-interface-mac>0005.3379.6de0</local-interface-mac>
    <remote-interface-name>port1</remote-interface-name>
    <remote-interface-mac>0005.3348.3043</remote-interface-mac>
    <dead-interval>120</dead-interval>
    <remaining-life>114</remaining-life>
    <remote-chassis-id>0005.3348.3043</remote-chassis-id>
    <lldp-pdu-transmitted>16159</lldp-pdu-transmitted>
    <lldp-pdu-received>15846</lldp-pdu-received>
  </lldp-neighbor-detail>
  <has-more xmlns="urn:brocade.com:mgmt:brocade-lldp-ext">false</has-more>
</rpc-reply>
```

## Parameters

### *local-interface-name*

Indicates the local interface display name.

### *local-interface-ifindex*

Indicates the local interface index.

### *local-interface-mac*

Indicates the local interface MAC address.

### *remote-interface-name*

Indicates the remote interface display name .

### *remote-interface-mac*

Indicates the remote interface MAC address.

### *dead-interval*

Indicates the dead interval.

### *remaining-life*

Indicates the remaining life period.

### *remote-chassis-id*

Indicates the remote chassis ID.

### *lldp-pdu-transmitted*

Number of LLDP PDUs transmitted from the interface.

### *lldp-pdu-received*

Number of LLDP PDUs received by the interface.



## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-mac-acl-for-intf

Returns information about the MAC ACL applied on the specified interfaces.

## Usage

```
<get-mac-acl-for-intf></get-mac-acl-for-intf>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="2407">
  <get-mac-acl-for-intf xmlns="urn:brocade.com:mgmt:brocade-mac-access-list">
    <interface>
      <interface-type>l2vlan</interface-type>
      <interface-name>50</interface-name>
      <ingress-policy>
        <policy-name>test_02</policy-name>
      </ingress-policy>
      <egress-policy>
        <policy-name>test_01</egress-policy>
      </egress-policy>
    </interface>
  </get-mac-acl-for-intf>
</rpc-reply>
```

## Parameters

*interface-type*

Displays the interface type.

*interface-name*

Displays the interface name.

*policy-name*

Displays the MAC ACL policy name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-mac-address-table

Returns the MAC address table for a given MAC address.

## Usage

```
<get-mac-address-table> <forwarding-interface> <interface-type>ethernet</interface-type>
<interface-name>2/4</interface-name> </forwarding-interface> <mac-type>static</mac-type>
</get-mac-address-table>

<rpc-reply xmlns=""urn:ietf:params:xml:ns:netconf:base:
1.0""xmlns:nc=""urn:ietf:params:xml:ns:netconf:base:1.0"" message-id=""2"">
  <mac-address-table xmlns=""urn:brocade.com:mgmt:brocade-mac-address-table"">
    <vlanid>10</vlanid>
    <mac-address>00:11:11:11:44:44</mac-address>
    <mac-type>static</mac-type>
    <mac-state>active</mac-state>
    <forwarding-interface>
      <interface-type>ethernet</interface-type>
      <interface-name>2/4</interface-name>
    </forwarding-interface>
  </mac-address-table>
  <has-more xmlns=""urn:brocade.com:mgmt:brocade-mac-address-table"">>false</has-more>
</rpc-reply>

<get-mac-address-table>
  <last-mac-address-details>
    <last-mac-address>00:11:11:82:12:92</last-mac-address>
    <last-vlan-id>10</last-vlan-id>
    <last-mac-type>static</last-mac-type>
  </last-mac-address-details>
  <forwarding-interface-type>ethernet</forwarding-interface-type>
  <forwarding-interface-name>2/4</forwarding-interface-name>
  <mac-address-type>static</mac-address-type>
</get-mac-address-table>

<rpc-reply xmlns=""urn:ietf:params:xml:ns:netconf:base:
1.0""xmlns:nc=""urn:ietf:params:xml:ns:netconf:base:1.0"" message-id=""2"">
  <mac-address-table xmlns=""urn:brocade.com:mgmt:brocade-mac-address-table"">
    <vlanid>10</vlanid>
    <mac-address>00:11:11:82:12:92</mac-address>
    <mac-type>static</mac-type>
    <mac-state>active</mac-state>
    <forwarding-interface>
      <interface-type>ethernet</interface-type>
      <interface-name>2/4</interface-name>
    </forwarding-interface>
  </mac-address-table>
  <has-more xmlns=""urn:brocade.com:mgmt:brocade-mac-address-table"">>false</has-more>
</rpc-reply>
```

## Parameters

*vlanid*

Displays the VLAN ID.

*mac-address*

Displays the MAC address.

*mac-type*

Displays the MAC type.

*mac-state*

Displays the MAC state.

*interface-type*

Displays the interface type.

*interface-name*

Displays the interface name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-media-detail

Returns the media properties of all the interfaces of the managed entity.

## Usage

```
<get-media-detail></get-media-detail>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="59">
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/5</interface-name>
    <qsfp>
      <speed>40Gbps</speed>
      <connector>lc</connector>
      <encoding>ieee-802-3ab</encoding>
      <vendor-name>BROCADE </vendor-name>
      <vendor-oui>00:05:1e</vendor-oui>
      <vendor-pn>57-1000263-01 </vendor-pn>
      <vendor-rev>A </vendor-rev>
      <distance>long-dist</distance>
      <media-form-factor>unknown</media-form-factor>
      <wavelength>26020</wavelength>
      <serial-no>LDF113390001CBS </serial-no>
      <date-code>130928 </date-code>
      <temperature>31</temperature>
      <voltage>3305.7</voltage>
      <current>37.364</current>
      <tx-power>0.0</tx-power>
      <rx-power>2.7</rx-power>
    </qsfp>
  </interface>
  <interface xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <interface-type>ethernet</interface-type>
    <interface-name>2/5</interface-name>
    <sfp>
      <speed>10Gbps</speed>
      <connector>lc</connector>
      <encoding>unknown</encoding>
      <vendor-name>BROCADE</vendor-name>
      <vendor-oui>00:05:1e</vendor-oui>
      <vendor-pn>57-0000076-01</vendor-pn>
      <vendor-rev>A</vendor-rev>
      <distance>unknown</distance>
      <media-form-factor>unknown</media-form-factor>
      <wavelength>1310</wavelength>
      <serial-no>ADF21346000071B </serial-no>
      <date-code>131110</date-code>
      <temperature>36</temperature>
      <voltage>3292.0</voltage>
      <current>38.602</current>
      <tx-power>700.5</tx-power>
      <rx-power>741.6</rx-power>
    </sfp>
  </interface>
</rpc-reply>
```

## Parameters

*interface-type*

Displays the interface type.

<i>interface-name</i>	Displays the interface name.
<i>speed</i>	Specifies the speed.
<i>connector</i>	Specifies the connector.
<i>encoding</i>	Displays the type of encoding used to transmit the data on this interface.
<i>vendor-name</i>	Displays the vendor of the interface.
<i>vendor-oui</i>	Displays the vendor IEEE company ID.
<i>vendor-pn</i>	Displays the vendor part number.
<i>vendor-rev</i>	Displays the vendor revision level.
<i>distance</i>	Displays the SFP distance.
<i>media-form-factor</i>	Displays the media form factor.
<i>wavelength</i>	Displays the wavelength of pluggable media.
<i>serial-no</i>	Displays the serial number.
<i>date-code</i>	Displays the vendor's manufacturing date code.
<i>temperature</i>	Displays the module temperature (degrees C).
<i>voltage</i>	Indicates the supply voltage (Volts).
<i>current</i>	Displays the laser diode drive current (milliAmps).
<i>tx-power</i>	Displays the transmitted optical power (microWatts).
<i>rx-power</i>	Displays the received optical power (microWatts).

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-nameserver-detail

Retrieves the detailed information of the devices stored in the name server database.

## Usage

```
<get-nameserver-detail xmlns=""urn:brocade.com:mgmt:brocade-nameserver""></get-nameserver-detail>

<rpc-reply xmlns=""urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1">
  <show-nameserver>
    <nameserver-portid>0d0000</nameserver-portid>
    <nameserver-portname>20:00:8C:7C:FF:21:C0:00</nameserver-portname>
    <nameserver-nodename>20:00:8C:7C:FF:21:C0:01</nameserver-nodename>
    <nameserver-cos>3</nameserver-cos>
    <nameserver-scr>0</nameserver-scr>
    <nameserver-fc4s>FCP </nameserver-fc4s>
    <nameserver-portsymb>[7] "13/0/52"</nameserver-portsymb>
    <nameserver-nodesymb>NULL</nameserver-nodesymb>
    <nameserver-fabric-portname>50:02:7F:8C:31:32:30:82</nameserver-fabric-portname>
    <nameserver-permanent-portname>20:00:8C:7C:FF:21:C0:00</nameserver-permanent-portname>
    <nameserver-devicetype>Physical Target</nameserver-devicetype>
    <nameserver-porttype>N</nameserver-porttype>
    <nameserver-index>130</nameserver-index>
    <nameserver-sharearea>Yes</nameserver-sharearea>
    <nameserver-redirect>No</nameserver-redirect>
    <nameserver-xlatedomain>No</nameserver-xlatedomain>
    <nameserver-connected-via-ag>No</nameserver-connected-via-ag>
    <nameserver-ag-base-device>No</nameserver-ag-base-device>
    <nameserver-real>No</nameserver-real>
    <nameserver-cascaded>No</nameserver-cascaded>
  </show-nameserver>
</rpc-reply>
```

## Parameters

### *nameserver-portid*

Displays the list of all Nx\_Ports registered in the name server database of this managed device.

### *nameserver-portname*

Displays the Port\_Name (WWN) of this Nx\_Port.

### *nameserver-nodename*

Displays the Node\_Name (WWN) of this Nx\_Port.

### *nameserver-cos*

Displays the Fibre Channel Class of service supported by the device.

### *nameserver-scr*

Displays the state change notifications that the device has registered for.

### *nameserver-fc4s*

Displays the Fibre Channel FC4 services supported by the device.

### *nameserver-portsymb*

Displays the user-defined name of this port.

### *nameserver-nodesymb*

Displays the user-defined name of the node of this port.

### *nameserver-fabric-portname*

Displays the Fabric port name (WWN) of this port.

*nameserver-permanent-portname*

Displays the type and role of the device.

*nameserver-devicetype*

Displays the type and role of the device.

*nameserver-porttype*

Displays the Fibre Channel port type.

*nameserver-index*

Displays the Port index number.

*nameserver-sharearea*

Indicates whether or not the port utilizes the Brocade shared area method of fibre channel addressing.

*nameserver-redirect*

Indicates whether or not the device is involved in Brocade frame redirection zoning.

*nameserver-xlatedomain*

Indicates whether or not the device enters the fabric via a translate domain.

*nameserver-connected-via-ag*

Indicates whether or not the device enters the fabric via access gateway.

*nameserver-ag-base-device*

Indicates whether or not the device is a base access gateway device.

*nameserver-real*

Indicates whether or not the device entered in the fabric via AG is a physical device.

*nameserver-cascaded*

Indicates whether or not the device enters the fabric via a cascaded AG.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# get-netconf-client-capabilities

Returns the vendor information for all NETCONF clients.

## Usage

```
<get-netconf-client-capabilities></get-netconf-client-capabilities>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="57">
  <session xmlns="urn:brocade.com:mgmt:brocade-netconf-ext">
    <session-id>30</session-id>
    <user-name>admin</user-name>
    <vendor>Brocade</vendor>
    <product>NOS Netconf Client</product>
    <version>0.8 beta</version>
    <identity>sgajaraj</identity>
    <af-type>IPV4</af-type>
    <host-ip>172.22.8.111</host-ip>
    <time>2014-06-04T11:00:35+00:00</time>
  </session>
</rpc-reply>
```

## Parameters

*session-id*

Displays the session ID of the NETCONF client session.

*user-name*

Displays the login name of the user for the NETCONF client session.

*vendor*

Displays the vendor name of the NETCONF client session.

*product*

Displays the product name of the NETCONF client session.

*version*

Displays the product version of the NETCONF client session.

*identity*

Displays the identity of the NETCONF client session.

*af-type*

Specifies the address family type.

*host-ip*

Displays IP address of NETCONF client session.

*time*

Displays the login time of NETCONF client session.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-port-channel-detail

Returns link aggregation control configuration parameters for all the port-channels in the system.

## Usage

```
<get-port-channel-detail></get-port-channel-detail>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1002">
  <get-port-channel-detail xmlns="urn:brocade.com:mgmt:brocade-lag">
    <lacp>
      <aggregator-id>27</aggregator-id>
      <aggregator-type>standard</aggregator-type>
      <isvlag>>false</isvlag>
      <aggregator-mode>none</aggregator-mode>
      <admin-key>0027</admin-key>
      <oper-key>0027</oper-key>
      <actor-system-id>00-05-33-6f-18-18</actor-system-id>
      <partner-system-id>00-05-1e-cd-6e-9f</partner-system-id>
      <system-priority>32768</system-priority>
      <partner-oper-priority>32768</partner-oper-priority>
      <rx-link-count>4</rx-link-count>
      <tx-link-count>4</tx-link-count>
      <individual-agg>0</individual-agg>
      <ready-agg>1</ready-agg>
      <partner-oper-key>0027</partner-oper-key>
      <aggr-member>
        <interface-type>ethernet</interface-type>
        <interface-name>231/0/22</interface-name>
        <actor-port>0xE718160201</actor-port>
        <sync>1</sync>
      </aggr-member>
    </lacp>
    <has-more>>true</has-more>
  </get-port-channel-detail>
</rpc-reply>
```

## Parameters

### *aggregator-id*

Displays the aggregator ID.

### *aggregator-type*

Displays the aggregator type.

### *isvlag*

Specifies if aggregator is VLAG.

### *aggregator-mode*

Displays aggregator mode.

### *admin-key*

Displays the admin key.

### *oper-key*

Displays the operational key.

### *actor-system-id*

Displays the actor system ID.

<i>partner-system-id</i>	Displays the partner system ID.
<i>system-priority</i>	Displays the system priority.
<i>partner-oper-priority</i>	Displays the partner operational priority.
<i>rx-link-count</i>	Displays the RX link counter.
<i>tx-link-count</i>	Displays the TX link counter.
<i>individual-agg</i>	Displays the Individual aggregator.
<i>ready-agg</i>	Displays the Ready aggregator.
<i>partner-oper-key</i>	Displays the Partner Operational key.
<i>interface-type</i>	Displays the interface type .
<i>interface-name</i>	Displays the interface name.
<i>actor-port</i>	Displays the actor port number.
<i>sync</i>	Displays the sync information.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-stp-brief-info

Returns Spanning Tree Protocol (STP) information.

## Usage

```
<get-stp-brief-info></get-stp-brief-info>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="2025">
  <get-stp-brief-info xmlns="urn:brocade.com:mgmt:brocade-xstp-ext">
    <spanning-tree-info>
      <stp-mode>STP</stp-mode>
      <stp>
        <route-bridge>
          <priority>32768</priority>
          <bridge-id>22</bridge-id>
          <hello-time>2</hello-time>
          <max-age>20</max-age>
          <forward-delay>15</forward-delay>
        </route-bridge>
        <bridge>
          <priority>32768</priority>
          <hello-time>2</hello-time>
          <max-age>20</max-age>
          <forward-delay>15</forward-delay>
          <transmit-hold-count>6</transmit-hold-count>
          <migrate-time>3</migrate-time>
          <port>
            <interface-type>ethernet</interface-type>
            <interface-name>2/5</interface-name>
            <spanningtree-enabled>true</spanningtree-enabled>
            (output truncated)
          </spanning-tree-info>
          <has-more>true</has-more>
          <last-instance>
            <instance-id>91</instance-id>
          </last-instance>
        </get-stp-brief-info>
      </rpc-reply>
```

## Parameters

### *stp-mode*

Displays the type of the Spanning Tree Protocol configured on the switch.

### *priority*

Displays the Bridge priority.

### *hello-time*

Displays the interval between two transmissions of BPDU packets sent by the Root Bridge to tell all other switches that it is indeed the Root Bridge (1 to 10 sec).

### *max-age*

The Max Age may be set to ensure that old information does not endlessly circulate through redundant paths in the network, preventing the effective propagation of new information (6 to 40 sec).

### *forward-delay*

Port on the Switch spends this time in the listening state while moving from the blocking state to the forwarding state (4 to 30 sec).

*transmit-hold-count*

Displays the transmin hold count.

*migrate-time*

Displays the migrate time.

*interface-type*

Displays the interface type.

*interface-name*

Displays the interface name.

*spanningtree-enabled*

Displays if the spanning tree is enabled.

*instance-id*

Specifies the instance ID.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-system-uptime

Returns the time since the managed entity was last reinitialized.

## Usage

```
<get-system-uptime></get-system-uptime>
```

```
<rpc-reply message-id="307" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0">
  <show-system-uptime xmlns="urn:brocade.com:mgmt:brocade-system">
    <days>0</days>
    <hours>5</hours>
    <minutes>53</minutes>
    <seconds>4</seconds>
  </show-system-uptime>
</rpc-reply>
```

## Parameters

*days*

Displays the number of days the managed node is up since its last re-initialization

*hours*

Displays the number of hours the managed node is up since its last re-initialization

*minutes*

Displays the number of minutes the managed node is up since its last re-initialization

*seconds*

Displays the number of seconds the managed node is up since its last re-initialization

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# get-vlan-brief

Returns operational data for a given VLAN and enumeration of all the interfaces belonging to this VLAN.

## Usage

```
<get-vlan-brief></get-vlan-brief>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="47">
  <configured-vlans-count xmlns="urn:brocade.com:mgmt:brocade-interface-ext">13</configured-vlans-
count>
  <provisioned-vlans-count xmlns="urn:brocade.com:mgmt:brocade-interface-ext">13</provisioned-vlans-
count>
  <unprovisioned-vlans-count xmlns="urn:brocade.com:mgmt:brocade-interface-ext">0</unprovisioned-
vlans-count>
  <vlan xmlns="urn:brocade.com:mgmt:brocade-interface-ext">
    <vlan-id>1</vlan-id>
    <vlan-type>static</vlan-type>
    <vlan-name>default</vlan-name>
    <vlan-state>members-down</vlan-state>
    <interface>
      <interface-type>unknown</interface-type>
      <interface-name></interface-name>
      <tag>tagged</tag>
      <classification>
        <classification-type>vni</classification-type>
        <classification-value>2</classification-value>
      </classification>
    </interface>
  </vlan>
  <last-vlan-id xmlns="urn:brocade.com:mgmt:brocade-interface-ext">200</last-vlan-id>
  <has-more xmlns="urn:brocade.com:mgmt:brocade-interface-ext">true</has-more>
</rpc-reply>
```

## Parameters

*configured-vlans-count*

Displays the number of VLANs configured.

*provisioned-vlans-count*

Displays the number of VLANs provisioned.

*unprovisioned-vlans-count*

Displays the number of VLANs unprovisioned.

*vlan-id*

Displays the VLAN ID

*vlan-type*

Displays the VLAN type

*vlan-name*

Displays the administrative name of the VLAN

*vlan-state*

Displays the operational state of the VLAN

*interface-type*

Displays the interface type

*interface-name*

Displays the interface name

*tag*

Displays the state of the interface - untagged, tagged, or converged

*classification-type*

Displays the type of classification

*classification-value*

Displays the value of the VLAN classification

*last-vlan-id*

Displays the last VLAN record that has been fetched

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# mpls-clear-all-ldp-sessions

Clears all LDP sessions.

## Usage

```
<clear-mpls-ldp-neighbor xmlns=""urn:brocade.com:mgmt:brocade-mpls"">  
  <mpls-clear-all-ldp-sessions>true</mpls-clear-all-ldp-sessions>  
</clear-mpls-ldp-neighbor>
```

## Parameters

*mpls-clear-all-ldp-sessions*

Clears all LDP sessions.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mpls-clear-one-ldp-sessions

Clears an LDP session.

## Usage

```
<clear-mpls-ldp-neighbor xmlns=""urn:brocade.com:mgmt:brocade-mpls"">  
  <mpls-clear-one-ldp-sessions>14.14.14.14</mpls-clear-one-ldp-sessions>  
</clear-mpls-ldp-neighbor>
```

## Parameters

*mpls-clear-one-ldp-sessions*

Clears an LDP session with a specific IP address.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mpls-clear-statistics-type

Clears the MPLS statistics of a specific type.

## Usage

```
<clear-mpls-statistics xmlns="urn:brocade.com:mgmt:brocade-mpls">  
  <mpls-clear-statistics-type>3</mpls-clear-statistics-type>  
  <tunnel-name>t2</tunnel-name>  
</clear-mpls-statistics>
```

## Parameters

*mpls-clear-statistics-type*

Specifies the MPLS statistics type.

*tunnel-name*

Specifies the tunnel name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# mpls-reopt-lsp

Directs the router to consider configuration changes made to an LSP and to optimize the LSP path based on those changes.

## Usage

```
<mpls-reopt-lsp xmlns="urn:brocade.com:mgmt:brocade-mpls">  
  <mpls-reoptimize-lsp-name-in>reopt1</mpls-reoptimize-lsp-name-in>  
</mpls-reopt-lsp>
```

## Parameters

*mpls-reoptimize-lsp-name-in*  
Specifies the LSP name.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# reload

Reloads the switch.

## Usage

```
<reload xmlns=""urn:brocade.com:mgmt:brocade-ha""></reload>
```

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# set-http-application-url

Updates the HTTP application URL.

## Usage

```
<set-http-application-url xmlns=""urn:brocade.com:mgmt:brocade-http-redirect">
  <config-http-app-url>
    <url>www.google.com</url>
    <op-type>l</op-type>
  </config-http-app-url>
</set-http-application-url>

<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1">
  <status-code>0</status-code>
  <status-string>Success</status-string>
</rpc-reply>
```

## Parameters

### *status-code*

Displays the status code as URL updated successfully - 0, Error not able to update configuration - 1 or Error not able to remove configuration - 2.

### *status-string*

Displays the error in string format.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# show-clock

Returns the date, time, and time zone.

## Usage

```
<show-clock></show-clock>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="7">
  <clock-time xmlns="urn:brocade.com:mgmt:brocade-clock">
    <current-time>2014-06-04T11:03:31+00:00</current-time>
    <timezone>Etc/GMT</timezone>
  </clock-time>
</rpc-reply>
```

## Parameters

*current-time*

Displays the switch date and time

*timezone*

Displays the region/city or region/state/city

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# show-ntp

Returns the active NTP server for the Brocade VCS fabric or specified switch.

## Usage

```
<show-ntp></show-ntp>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="12">
  <node-active-server xmlns="urn:brocade.com:mgmt:brocade-ntp">
    <LOCL>true</LOCL>
  </node-active-server>
</rpc-reply>
```

## Parameters

*LOCL*

Indicates whether the LOCL is true or false

## History

Release version	History
16r.1.01	This NETCONF call was introduced.



# show-raslog

Returns RASlog entries.

## Usage

```
<show-raslog></show-raslog>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="14">
  <show-all-raslog xmlns="urn:brocade.com:mgmt:brocade-ras-ext">
    <number-of-entries>2842</number-of-entries>
    <raslog-entries>
      <index>8288</index>
      <message-id>NSM-1019</message-id>
      <date-and-time-info>2013/12/07-03:21:17:69</date-and-time-info>
      <severity>informational</severity>
      <log-type>dce</log-type>
      <repeat-count>1</repeat-count>
      <message> Interface Ve 4093 is administratively up.</message>
      <message-flag>unknown</message-flag>
      <switch-or-chassis-name>sw0</switch-or-chassis-name>
    </raslog-entries>
    <raslog-entries>
      <index>13584</index>
      <message-id>SEC-3022</message-id>
      <date-and-time-info>2014/06/03-14:03:52:25</date-and-time-info>
      <severity>informational</severity>
      <log-type>system</log-type>
      <repeat-count>1</repeat-count>
      <message>Event: logout, Status: success, Info: Successful logout by user [admin].</message>
      <message-flag>unknown</message-flag>
      <switch-or-chassis-name>sw0</switch-or-chassis-name>
    </raslog-entries>
  </show-all-raslog>
</rpc-reply>
```

## Parameters

*number-of-entries*

Displays the number of recent events to be fetched from the RASLOG entries

*index*

Displays the sequence number for the message

*message-id*

Displays the message identifier

*date-and-time-info*

Displays the date and time of the message. The format is: YYYY-MM-DD/HH:MM:SS.SSSS

*severity*

Displays the severity of the message. Valid values include: INFO, WARNING, ERROR, and CRITICAL

*log-type*

Specifies if the message is a SYSTEM or DCE log

*repeat-count*

Displays the number of times the particular event has occurred

*message*

Displays the textual description of the event

*message-flag*

Displays the type of the message

*switch-or-chassis-name*

Displays the switch name for the generator of the message, or chassis

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# show-system-monitor

Returns system status information.

## Usage

```
<show-system-monitor></show-system-monitor>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="17">
  <switch-status xmlns="urn:brocade.com:mgmt:brocade-system-monitor-ext">
    <switch-name>sw0</switch-name>
    <switch-ip>10.25.224.18</switch-ip>
    <switch-state>state-marginal</switch-state>
    <switch-state-reason>Switch Status is MARGINAL. Contributors: * Power Supply: 1 bad.
(MARGINAL).</switch-state-reason>
    <report-time>2017-04-04T11:10:5711.668484+31:03</report-time>
    <component-status>
      <component-name>Power supplies monitor</component-name>
      <component-state>state-marginal</component-state>
    </component-status>
    <component-status>
      <component-name>Temperatures monitor</component-name>
      <component-state>state-healthy</component-state>
    </component-status>
    <component-status>
      <component-name>Fans monitor</component-name>
      <component-state>state-healthy</component-state>
    </component-status>
  </switch-status>
</rpc-reply>
```

## Parameters

*switch-name*

Displays the name of the switch

*switch-ip*

Displays the IP address of the switch

*switch-state*

Displays the switch status based on components

*switch-state-reason*

Displays the component reason for switch status

*report-time*

Displays the switch report time stamp

*component-name*

Displays the component name

*component-state*

Displays the component status based on thresholds

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# show-zoning-enabled-configuration

Returns the currently enabled zoning configuration information.

## Usage

```
<show-zoning-enabled-configuration></show-zoning-enabled-configuration>
```

```
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" xmlns="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="1">
  <enabled-configuration xmlns="urn:brocade.com:mgmt:brocade-zone">
    <cfg-name>cfg1</cfg-name>
    <enabled-zone>
      <zone-name>zone1</zone-name>
      <member-entry>
        <entry-name>10:00:00:00:00:00:01</entry-name>
      </member-entry>
      <member-entry>
        <entry-name>10:00:00:00:00:00:02</entry-name>
      </member-entry>
    </enabled-zone>
    <enabled-zone>
      <zone-name>zone2</zone-name>
      <member-entry>
        <entry-name>10:00:00:00:00:00:03</entry-name>
      </member-entry>
      <member-entry>
        <entry-name>10:00:00:00:00:00:04</entry-name>
      </member-entry>
    </enabled-zone>
    <has-more>false</has-more>
  </enabled-configuration>
</rpc-reply>
```

## Parameters

*cfg-name*

Displays the name of the zone configuration.

*zone-name*

Displays the name of a zone to be added to the configuration.

*entry-name*

Displays the WWN of the device.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.

# user-session-info

Returns user role information.

## Usage

```
<user-session-info></user-session-info>  
  
<rpc-reply xmlns="urn:ietf:params:xml:ns:netconf:base:1.0"  
xmlns:nc="urn:ietf:params:xml:ns:netconf:base:1.0" message-id="20">  
  <user-role xmlns="urn:brocade.com:mgmt:brocade-aaa-ext">admin</user-role>  
</rpc-reply>
```

## Parameters

*user-role*

Displays the user role.

## History

Release version	History
16r.1.01	This NETCONF call was introduced.