

AirDefense Services Platform 8.1 Service Module

Installation

Contents

1.0 Introduction	I
1.1 Document Conventions1	
2.0 Before You Begin	2
2.1 Back Up Configuration)
2.2 Launch the Command Line Interface)
2.3 Check File System Usage)
3.0 Install the Service Module4	ŀ
4.0 Check the System Status5	;
5.0 Install the ADSP Toolkit	;
6.0 Support and Sales	;

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. AirDefense is a registered trademark of AirDefense, Inc. All other product or service names are the property of their respective owners. © Motorola, Inc. 2010. All rights reserved.

1 Introduction

This document provides step-by-step instructions on how to install AirDefense Services Platform 8.1 Service Module.

1.1 Document Conventions

The following graphical alerts are used in this document to indicate notable situations:



NOTE Tips, hints, or special requirements that you should take note of.



CAUTION Care is required. Disregarding a caution can result in data loss or equipment malfunction.



WARNING! Indicates a condition or procedure that could result in personal injury or equipment damage.

2 Before You Begin

ADSP 8.1 Service Module can only be applied to a system running AirDefense Services Platform 8.0.0-15 or 8.0.3-07. If you are running 8.0.1-04b or 8.0.2-09a, you must upgrade to 8.0.3-07 before you apply 8.1.0-15.

2.1 Back Up Configuration

Before you upgrade your server software, you should back up your configuration to your local workstation. If you already have a recent configuration backup, you can skip this procedure.

NOTE This backup will not be used during the Service Module installation. It is intended as an emergency backup in case the installation is not completely successful.

- 1. Log into the AirDefense Services Platform GUI as an administrator.
- 2. Go to Menu > Appliance Manager > Backups.
- 3. Click the **Backup Now** button.

The **Backup Now** window displays.

- 4. Click the _____ button to open a window where you can select your destination directory (folder).
- 5. Navigate to the directory where you want to back up your server configuration.
- 6. Click **Select** to select the destination.

The destination path displays in the **Destination Directory** field.

7. Click Next.

The configuration is saved in the selected directory.

8. Click **Close** and then log off.

2.2 Launch the Command Line Interface

To install the ADSP 8.1 Service Module, you must log into the command line interface remotely using SSH and the **ADSPadmin** utilities. Leave **ADSPadmin** open until all steps are complete.

Prerequisites:

To launch the command line interface, you must have the default command line user name and password for your system. You must also know the ADSP appliance IP address.

1. Launch your SSH client and connect to the ADSP appliance's IP address.

I must have a client that supports SSH protocol 2 installed on
remote workstation used to connect to the ADSP appliance. our client attempts to use SSH protocol 1, you will receive tocol error messages in syslog
, , , ,

Example:

11/15/2010 16:45:22 sshd(pam_unix) LOGGED: authentication failure, logname= uid=0 euid=0 tty=NODEVssh ruser= rhost=tparkerpc.hitest.com user=root

2. At the login prompt, enter **smxmgr** as your command line user name, followed by your command line user password.

The **ADSPadmin** main screen appears.

2.3 Check File System Usage

Follow these steps to check file system usage.

1. On the **ADSPadmin** main screen, type **m**, then press **<Enter**>.

The **Manage** screen appears.

- 2. Type status, then press < Enter>.
- 3. Type **d**, then press <**Enter**>.

The system displays the current system status, including the usage of the /var partition, in percentage values.

IMPORTANT If your system usage is 60% or higher for /home, or 80% or higher for /var, **DO NOT PROCEED WITH THIS SERVICE MODULE INSTALLATION**. Contact Enterprise Mobility Support. See Enterprise Mobility Support at the end of these instructions.

- 4. Press <**Enter**> to return to the **Manage** screen.
- 5. Type **q**, then press **< Enter>** to return to the **ADSPadmin** main screen.

3 Install the Service Module

Do the following to install the Service Module on your ADSP appliance.

 Download the ADSP 8.1.0-15 Service Module file from the Enterprise Mobility Support Website and SCP (Secure Copy Protocol) it to a directory on your ADSP appliance, such as /usr/local/tmp. Go to <u>http://support.symbol.com</u> to request the download site credentials to obtain the Service Module file.

```
IMPORTANT Some browsers may modify the filename. The Service Module file name must exactly match the file name as shown below. If your browser changes the name, you must change it back before proceeding. AD-service-SM4-8.1.0-15.tar
```

2. On the ADSPadmin main screen, type servmod, then press < Enter>.

At the prompt, you are asked to enter the fully-qualified directory name where the Service Module resides on the appliance file system.

3. Enter the directory name, for example, /usr/local/tmp/, then press < Enter>.

A numbered list of the available Service Modules appears.

```
Enter fully-qualified directory name
                Where service module bundle resides
                (<C> if on CDROM) - This option is not available
                (<Q> to return to previous menu)
                -> /usr/local/tmp
Service modules available in /usr/local/tmp:
  (1)
          AD-update-7.3.4-10a.tar
         AD-service-SM1-8.0.1-04.tar
  (3)
         AD-service-SM2-8.0.2-09a.tar
  (4)
          AD-service-SM3-8.0.3-07.tar
          AD-service-SM4-8.1.0-15.tar
              Enter line number of service module to use
              (<Q> to return to previous menu)
              ->
```

 Enter the line number of the Service Module (in this case 5), and then press < Enter>. This action initiates the installation of the Service Module. When the following message appears:

Continue installing service module /usr/local/tmp/AD-service-SM4-8.1.0-15.tar? (yes/no)

type yes and then press <Enter>.

After the Service Module is successfully loaded to the ADSP appliance, press <**Enter**>, then type **q**<**Enter**> twice to exit **ADSPadmin**.



NOTE The ADSP processes are restarted.

4 Check the System Status

When the Service Module installation is complete, perform the following steps.

- 1. Using SSH, re-login to **ADSPadmin**.
- Type m, and then press <Enter>.
 The Manage screen appears.
- 3. Type **status**, and then press **<Enter**>.

The system displays two choices: Process Status and Disk Status.

4. Select **p** to display the process status.

The system displays the release, build number and lists the status of all system processes.

- IMPORTANT Do not launch the AirDefense Services Platform GUI until the following system processes indicate **RUNNING**: Health Monitor, Action Manager, RMI Registry, License Manager, Report Server, Backup Server, Schedule Server, Device Management Server, RF Modeling Engine, Protocol Analysis Engine, Database, postmaster, and Graphical User Interface. If any of these processes indicate **Stopped**, press <**Enter**> to go back to the **Manage** screen, type **restart**, and and then type **yes** to continue. Check the system Process Status again. If one or more processes are still **Stopped**, contact Motorola Customer Support.
- 5. Press <**Enter**> to return to the **Manage** screen.
- 6. Type **q**, then press **< Enter>** to return to the **ADSPadmin** main screen.

5 Install the ADSP Toolkit

The ADSP Toolkit is required to run some of the advanced features of ADSP. When attempting to access a feature which requires the toolkit, the browser will download a launcher file "adeapp.adx" and use the toolkit to run it. If the toolkit is not installed, the file will download but the feature selected will not be able to run.

You must access the AirDefense Services Platform graphical login page to install the ADSP Toolkit. Follow these steps:

- 1. Launch your web browser.
- Type the IP address or url you assigned to the computer hosting ADSP. Example: https://<server_ip_address>:8543 https://<server_name>:8543

The login page displays.

۸	AirDefense Services Platform							
						والبجد أيجعد لجريب وجعرا بعجرا بنعد أيجعد أجمعا حضرا بعر		
						USERNAME		
						PASSWORD.		
						Loge Read		
						© 2015 Multimia, Inc. All rights reserved		

 Click the Downloads link in the top right-hand corner of the login page. You may also click Menu > Download Toolkit if you are logged into ADSP.

The following page displays. This is where you download the ADSP Toolkit.

AirDefense Services Platform							
		and a state					
	ADSP TOOLKIT WINDOWS INSTALLATION MotorsiaADSP-install.exe						
	LINUX PACKAGES MotorstaADSP tar.az						
	Betwen to Login						

For Windows Installation

- 1. Click MotorolaADSP-install.exe. A Security Warning window displays.
- Click Run to install the ADSP Toolkit.
 A Download Status window displays. Then, another security window displays.
- Click Run to verify that you want to install the application. A License Agreement displays.
- 4. Read the **License Agreement** and then click **I Agree**. The installation location window appears.
- Accept the default location or browse to another location, and then click Install. An Installation Status window displays. Then, the Complete Installation window displays.
- 6. Click **Finish**.

For Linux Installation

1. Click MotorolaADSP.tar.gz.

A dialog window displays prompting you to open or save the file.

- 2. Save the file to a directory on your Linux system.
- 3. Unpack MotorolaADSP.tar.gz using the following command:

tar xzvf MotorolaADSP.tar.gz

The unpack files are placed in the ADSP installation directory. When you attempt to access an ADSP application that is part of the toolkit, your browser will prompt you on what to do with the file *adeapp.adx*. Select **Open with** and specify **adsp**. Make sure the **Do this automatically for files like this from now on** checkbox is checked, and then click **OK**. Now, when you attempt to open an ADSP application that is part of the toolkit, it will open automatically.

6 Support and Sales

Motorola's Enterprise Mobility Support Center

If you have a problem with your equipment, contact Enterprise Mobility support for your region. Contact information is available by visiting <u>http://support.symbol.com</u>. and after selecting your region, click on the appropriate link under Support for Business.

When contacting Enterprise Mobility support, please provide the following information:

- Serial number of the unit
- Model number or product name
- Software type and version number

Motorola responds to calls by email, telephone or fax within the time limits set forth in support agreements. If you purchased your Enterprise Mobility business product from a Motorola business partner, contact that business partner for support.

Customer Support Web Site

Motorola's Support Central Web site, accessed via the Symbol-branded products link under Support for Business, provides information and online assistance including developer tools, software downloads, product manuals and online repair requests.

MOTOROLA INC 1303 E. ALGONQUIN ROAD SCHAUMBURG, IL 60196 http://www.motorola.com

72E-145384-01 Rev A - November 2010