# Release Notes for BayRS Version 12.20

BayRS Version 12.20 Site Manager Software Version 6.20 BCC Version 4.00

Part No. 301151-B Rev. 00 September 1998





4401 Great America Parkway Santa Clara, CA 95054 8 Federal Street Billerica, MA 01821

#### Copyright © 1998 Bay Networks, Inc.

All rights reserved. Printed in the USA. September 1998.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Bay Networks, Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

#### Trademarks

AN, BCN, BLN, BN, FRE, and Bay Networks are registered trademarks and Advanced Remote Node, ANH, ARN, ASN, BayRS, BayStack, BCC, SPEX, System 5000, and the Bay Networks logo are trademarks of Bay Networks, Inc.

Microsoft, MS, MS-DOS, Win32, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

#### **Restricted Rights Legend**

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

#### **Statement of Conditions**

In the interest of improving internal design, operational function, and/or reliability, Bay Networks, Inc. reserves the right to make changes to the products described in this document without notice.

Bay Networks, Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

#### SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

#### Bay Networks, Inc. Software License Agreement

**NOTICE:** Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as "Software" in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH BAY NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

**1. License Grant.** Bay Networks, Inc. ("Bay Networks") grants the end user of the Software ("Licensee") a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Bay Networks Agent software or other Bay Networks software products. Bay Networks Agent software or other Bay Networks software products are licensed for use under the terms of the applicable Bay Networks, Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

**2. Restrictions on use; reservation of rights.** The Software and user manuals are protected under copyright laws. Bay Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Bay Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Bay Networks' and its licensors' confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Bay Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee's facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Bay Networks warrants each item of Software, as delivered by Bay Networks and properly installed and operated on Bay Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Bay Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Bay Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Bay Networks will replace defective media at no charge if it is returned to Bay Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Bay Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Bay Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Bay Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED. INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

**4. Limitation of liability.** IN NO EVENT WILL BAY NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF BAY NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF BAY NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO BAY NETWORKS FOR THE SOFTWARE LICENSE.

**5. Government Licensees.** This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

**6.** Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Bay Networks of any such intended examination of the Software and may procure support and assistance from Bay Networks.

**7. Term and termination.** This license is effective until terminated; however, all of the restrictions with respect to Bay Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Bay Networks copyright; those restrictions relating to use and disclosure of Bay Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Bay Networks the Software, user manuals, and all copies. Bay Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and Re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

**9. General.** If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Bay Networks, Inc., 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN BAY NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST BAY NETWORKS UNLESS BAY NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

# Contents

#### **Technical Support**

Bay Networks Technical Publications	xi
Bay Networks Customer Service	xii
How to Get Help	xii
Bay Networks Educational Services	xiii

### Release Notes for BayRS Version 12.20

Upgrading to Version 12.20	1-1
Upgrading L2TP Configurations to Version 12.20	1-2
Using the BCC	1-2
Platforms Supported	1-2
Number of BCC Sessions	1-3
Changing Sync to Serial	1-3
BCC Help Initialization	1-3
Interfaces Supported	1-3
Global Protocols Supported	1-4
Interface Protocols Supported	1-5
Getting Started	1-5
Deleting Interfaces with the BCC	1-6
Identifying Board Types	1-6
Sending BCC Feedback	1-12
New Features in BayRS Version 12.20	1-13
Cache Mode	1-13
ATM Configuration	1-13
ATM BCC Support	1-13
MPOA Server Configuration	1-13
ATM Router Redundancy	1-14
Next Hop Resolution Protocol for MPOA	1-14
OSI Configuration	1-14

OSI over ATM	1-14
TARP over OSI	1-15
8021.Q Tagging	1-15
Bay Dial VPN	1-15
BGP Route Reflector	1-16
IBGP Equal Cost Multipath	1-16
Generic Routing Encapsulation	1-16
IGMP Relay	1-17
Equal Cost Multipath IP Static Routes	1-17
L2TP Configuration	1-17
Domain Name Removal Prior to RADIUS Authentication	1-18
RIP Support	1-18
Flow Control	1-18
L2TP IP Address Assignment	1-18
Dial Backup	1-18
Data Collection Module	1-19
Domain Name System	1-19
NAT	1-19
ARN, ASN, and System 5000 Support	1-19
WAN Line Configuration	1-20
Frame Relay	1-20
HTTP Web Server	1-20
IP Adjacent Host Configuration	1-20
Telnet Passthrough	1-20
IPX Support	1-21
BCC show Commands	1-21
New Hardware	1-21
FE1/E1 WAN Adapter Module	1-21
FRE-2-060E Processor Module with Advanced Compression Copro	cessor
Daughterboard	1-22
Guidelines for Working with BayRS Version 12.20	1-23
AN/ANH and ARN Guidelines	1-23
Allocating Memory on ARN Routers	1-23
Cycling Power to the ARN	1-23
DSU/CSU Test LED Remains On After Reset	

Network Booting on DSU/CSU Interfaces	1-24
IP Fragmentation Not Supported over GRE Tunnels	1-24
Creating Multiple GRE Tunnels	1-24
BCC Help Not Supported on ARE Slots	1-24
ASN Boot and Diagnostic PROM Images	1-24
ATM Event Message Numbering Changed	1-25
ARN Router Not a Supported DVS Radius Client	1-25
Error Configuring NAT Dynamically	1-25
BayRS Version 12.20 Flash Memory Requirements	1-25
FT1/T1 DSU/CSU Guidelines	1-26
Allocating DS0s	1-26
FT1/T1 and ISDN Phone Line Configuration	1-26
FT1/T1 DSU/CSU Diagnostic PROM Requirements	1-26
Selecting 56K Rate Adaption on FT1/T1 DSU/CSU Lines	1-27
Hi/fn (Stac) LZS Compression Executable	1-27
L2TP Guidelines	1-27
Dial Backup on a Primary Leased Line	1-27
Dial Services	1-27
Dynamic L2TP Configuration	1-27
Modification to an L2TP Script	1-28
Outbound LAN Traffic Filters	1-28
Protocol Prioritization No Call Filters and TCP Applications	1-28
RMON and RMON2 Guidelines	1-29
DCM Memory Requirements for RMON2	1-29
Enabling RMON on the ARN 10/100 Router	1-29
Technician Interface Guidelines	1-29
Configuring NTP Using the Technician Interface	1-29
Setting Modem Initialization Strings Using the Technician Interface	1-30
X.25 PVCs	1-30
Protocols Supported	1-31
Standards Supported	1-33
Flash Memory Cards Supported	1-39

# Tables

Table 1.	BCC Board Types: AN and ANH Modules	1-7
Table 2.	BCC Board Types: BLN and BCN Modules	1-8
Table 3.	BCC Board Types: ASN Modules	1-10
Table 4.	BCC Board Types: ARN Modules	1-11
Table 5.	BCC Board Types: System 5000 Modules	1-12
Table 6.	Standards Supported by Version 12.20	1-33
Table 7.	Approved Flash Memory Cards	1-39

# **Technical Support**

# **Bay Networks Technical Publications**

You can now print technical manuals and release notes free, directly from the Internet. Go to *support.baynetworks.com/library/tpubs*. Find the Bay Networks products for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Using Adobe Acrobat Reader, you can open the manuals and release notes, search for the sections you need, and print them on most standard printers. You can download Acrobat Reader free from the Adobe Systems Web site, *www.adobe.com*.

Documentation sets and CDs are available through your local Bay Networks sales office or account representative.

# **Bay Networks Customer Service**

You can purchase a support contract from your Bay Networks distributor or authorized reseller, or directly from Bay Networks Services. For information about, or to purchase a Bay Networks service contract, either call your local Bay Networks field sales office or one of the following numbers:

Region	Telephone number	Fax number
United States and Canada	800-2LANWAN; then enter Express Routing Code (ERC) 290, when prompted, to purchase or renew a service contract 978-916-8880 (direct)	978-916-3514
Europe	33-4-92-96-69-66	33-4-92-96-69-96
Asia/Pacific	61-2-9927-8888	61-2-9927-8899
Latin America	561-988-7661	561-988-7550

Information about customer service is also available on the World Wide Web at *support.baynetworks.com*.

# How to Get Help

If you purchased a service contract for your Bay Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Bay Networks service program, call one of the following Bay Networks Technical Solutions Centers:

<b>Technical Solutions Center</b>	Telephone number	Fax number
Billerica, MA	800-2LANWAN	978-916-3514
Santa Clara, CA	800-2LANWAN	408-495-1188
Valbonne, France	33-4-92-96-69-68	33-4-92-96-69-98
Sydney, Australia	61-2-9927-8800	61-2-9927-8811
Tokyo, Japan	81-3-5402-0180	81-3-5402-0173

# **Bay Networks Educational Services**

Through Bay Networks Educational Services, you can attend classes and purchase CDs, videos, and computer-based training programs about Bay Networks products. Training programs can take place at your site or at a Bay Networks location. For more information about training programs, call one of the following numbers:

Region	Telephone number
United States and Canada	800-2LANWAN; then enter Express Routing Code (ERC) 282 when prompted
	978-918-3460 (ullect)
Europe, Middle East, and Africa	33-4-92-96-15-83
Asia/Pacific	61-2-9927-8822
Tokyo and Japan	81-3-5402-7041

# Release Notes for BayRS Version 12.20

This document contains the latest information about Bay Networks<sup>®</sup> BayRS<sup>TM</sup> Version 12.20.

These release notes include information about:

- Upgrading to Version 12.20
- Using the BCC
- New Features in BayRS Version 12.20
- <u>New Hardware</u>
- Guidelines for Working with BayRS Version 12.20
- Protocols Supported
- Standards Supported
- Flash Memory Cards Supported

# **Upgrading to Version 12.20**

To upgrade BayRS to Version 12.20, or to upgrade Site Manager software to Version 6.20, see *Upgrading Routers from Version 7-11.xx to Version 12.00*, also in your upgrade package, and the upgrade section of the *BayRS Version 12.20 Document Change Notice*.

## **Upgrading L2TP Configurations to Version 12.20**

If you have a BayRS Version 12.10 configuration file that includes L2TP operating on a router using BayRS Version 12.20, the router automatically upgrades the assigned user network addresses to Version 12.20 L2TP IP interface addresses are internal to the router. When communicating with the remote user, the router associates the user's IP address with an L2TP IP interface address that you configure.

The Version 12.10 assigned user network addresses apply to the entire router. In Version 12.20, each slot has a unique L2TP IP address. Consequently, if the number of configured L2TP slots is greater than the number of configured assigned user network addresses, the router may not be able to upgrade every slot from a Version 12.10 configuration to a Version 12.20 configuration.

The router automatically converts all assigned user network addresses to L2TP IP addresses. For slots that exceed the number of assigned user network addresses, you will need to manually configure L2TP IP interface addresses. To do this, delete L2TP from the slot, then configure a new L2TP interface. Each slot must have L2TP IP interface address.

# Using the BCC

The BCC<sup>™</sup> is a command-line interface for configuring Bay Networks devices. It also supports Technician Interface commands and scripts.

Before using the BCC, refer to the following sections listing the platforms, protocols, and interfaces that the BCC supports.

## **Platforms Supported**

The BCC runs on  $AN^{\text{(B)}}$ ,  $ANH^{\text{TM}}$ ,  $ARN^{\text{(B)}}$ ,  $ASN^{\text{(B)}}$ , System 5000<sup>TM</sup>, and  $BN^{\text{(B)}}$  platforms including ARE,  $FRE^{\text{(B)}}$ , and FRE-2 processor modules. Each slot must have:

- 16 MB of dynamic RAM (DRAM)
- 2 MB of free memory space available when you start the BCC

If you try to start the BCC with insufficient DRAM or free memory on a slot, the BCC returns an error message. In that case, use Site Manager instead of the BCC.

### Number of BCC Sessions

You can open one BCC session per slot in read-write (configuration) mode. Other users can open additional BCC sessions in read-only (nonconfiguration) mode, depending on memory resources available on the slot supporting your login session. When memory requirements are insufficient to support additional BCC sessions on a login slot, the system displays the following message:

BCC requires 2MB of free memory. Current available memory is <numeric value of current available memory>.

Each BCC session is mutually exclusive. If you make a change in a BCC session in read-write mode, this change does not appear in another BCC session.

## **Changing Sync to Serial**

In BCC syntax, the term "sync" has been changed to "serial." This global change affects all sync-related **config** or **show** commands.

# **BCC Help Initialization**

Obtaining a response from a BCC Help request may require an initialization time of about one minute. This initialization occurs only when issuing the first Help command after booting the device. Subsequent requests for BCC Help information take only one or two seconds.

## **Interfaces Supported**

You can use BCC commands to configure the following interfaces:

- ATM
- Console
- DCM
- DSU/CSU
- Ethernet
- FDDI
- FT1
- HSSI

- ISDN/BRI
- MCE1/MCT1
- Serial (synchronous)
- Token ring
- V.34 modem adapter (for the ARN router)
- Virtual (referred to in Site Manager as Circuitless IP)

Tables  $\underline{1}$  through  $\underline{5}$  list the link and net modules that the BCC supports.

## **Global Protocols Supported**

You can use BCC commands to configure the following global protocols:

- IP (including access policies, static routes, and adjacent hosts)
- ARP
- BGP (including accept and announce policies)
- HTTP
- IGMP
- IPX (including static-netbios-route)
- IPXWAN
- OSPF (including accept and announce policies)
- RIP (including accept and announce policies)
- FTP
- NTP
- SNMP
- Telnet
- TFTP

## **Interface Protocols Supported**

You can use BCC commands to configure the following interface protocols:

- IP
- ARP
- ATM
- Dial backup
- Frame relay (multiline not supported)
- IPX
- IGMP
- OSPF
- RIP
- Router Discovery (RDISC)
- Proprietary Standard Point-to-Point
- PPP (certain line parameters only; no multiline or multilink supported)

## **Getting Started**



**Caution:** BCC configuration and **source** commands make immediate changes to the active device configuration. Read about the **source** command in *Using the Bay Command Console*.

Before using the BCC, save your configuration files by copying them onto the same flash memory card using new file names.

To start the BCC, enter **bcc** at the Technician Interface prompt.

To display the online instructions for new BCC users, enter **help learning-bcc** at the bcc> prompt. Then to display a full summary of the Help features of the BCC interface, enter **help -more**.

For more information about how to use the BCC interface, see *Using the Bay Command Console*.

For instructions on using the BCC to add and change protocol services, see the documentation for that protocol.

If you use the BCC **show config** command to view a router configuration, the BCC displays only the components or protocols it supports.

## **Deleting Interfaces with the BCC**

Before using the BCC to delete an interface, make sure that you did not use Site Manager to configure it with a protocol that the BCC does not recognize. If you did, use Site Manager to delete the interface.

## **Identifying Board Types**

Tables  $\underline{1}$  through  $\underline{5}$  identify the Board Type parameter values displayed by the BCC. Use the "Board Type" column to identify a hardware module in an AN, ANH, ARN, ASN, System 5000, or BN router configuration.



**Note:** You cannot use BCC commands to configure the operation of an FE1 adapter module for any AN or ANH router or an X.25 PAD or V.34 console modem daugherboard for the ARN router. (Use Site Manager to configure these daughterboards.) Inserting a daughterboard into an AN base module redefines its module ID and board type.

## Table 1 lists the AN and ANH board types

#### Table 1. BCC Board Types: AN and ANH Modules

BCC Board Type	Technician Interface or MIB Module ID	Description
andeds	1033	AN-ENET (2 Ethernet ports, 2 serial ports)
andedsg	1050	ANH-8 (2 Ethernet ports, 2 serial ports) and an 8-port Ethernet hub active for the first Ethernet port
andedsh	1035	ANH-12 (2 Ethernet ports, 2 serial ports) and a 12-port Ethernet hub
andedst	1034	AN-ENET (2 Ethernet ports, 2 serial ports, 1 token ring port)
andst	1037	AN-TOKEN (2 serial ports, 1 token ring port)
ansdsedst	1041	AN-ENET/TOKEN (1 Ethernet port, 2 serial ports, 1 token ring port)
anseds	1024	AN-ENET (1 Ethernet port, 2 serial ports) with 16 MB DRAM
ansedsg	1047	ANH-8 (1 Ethernet port, 2 serial ports) and an 8-port Ethernet hub
ansedsh	1026	ANH-12 (1 Ethernet port, 2 serial ports) and a 12-port Ethernet hub
ansedst	1025	AN-ENET/TOKEN (1 Ethernet port, 2 serial ports, 1 token ring port) with 16 MB DRAM
ansets	1030	AN-ENET (1 Ethernet port, 3 serial ports) with16 MB DRAM
ansetsg	1049	ANH-8 (1 Ethernet port, 3 serial ports) and an 8-port Ethernet hub
ansetsh	1032	ANH-12 (1 Ethernet port, 3 serial ports) and a 12-port Ethernet hub
ansetst	1031	AN-ETS (1 Ethernet port, 3 serial ports, 1 token ring port)
antst	1039	AN-TOKEN (3 serial, 1 token ring port)
ansedsi	1027	AN-ENET with ISDN (2 Ethernet ports, 2 serial ports) with 16 MB DRAM
ansedsti	1028	AN-ENET/TOKEN with ISDN (1 Ethernet port, 2 serial ports, 1 token ring port)
ansedshi	1029	ANH-12 with ISDN (1 Ethernet port, 2 serial ports) and a 12-port Ethernet hub
andsti	1038	AN-TOKEN with ISDN (2 serial ports, 1 token ring port)
		(continued)
ansedsgx	1048	ANH-8 with DCM (1 Ethernet port, 2 serial ports) and an 8-port

Ethernet hub

Table 1.	BCC Board Types: AN and ANH Modules	(continued)
----------	-------------------------------------	-------------

BCC Board Type	Technician Interface or MIB Module ID	Description	
ansedsgi	1051	ANH-8 with ISDN (1 Ethernet port, 2 serial ports)and an 8-port Ethernet hub	
ansedsx	1055	AN-ENET with DCM (2 Ethernet ports, 2 serial ports)	
ansedstx	1058	AN-ENET/TOKEN with DCM (1 Ethernet port, 2 serial ports, 1 token ring port) with 16 MB DRAM	
ansedsc	1090	AN-ENET with CSU/DSU (2 Ethernet ports, 2 serial ports)	
andstc	1091	AN-TOKEN with CSU/DSU (2 serial ports, 1 token ring port)	
ansedstc	1092	AN-ENET/TOKEN with CSU/DSU (1 Ethernet port, 2 serial ports, 1 token ring port)	
ansedshc	1093	ANH-12 with CSU/DSU (1 Ethernet port, 2 serial ports) and a 12-port Ethernet hub	
ansedsgc	1094	ANH-8 with CSU/DSU (1 Ethernet port, 2 serial ports) and an 8-port Ethernet hub	
ansedsf	1100	AN-ENET with T1/FT1 (2 Ethernet ports, 2 serial ports)	
ansedshf	1106	ANH-12 with T1/FT1 (1 Ethernet port, 2 serial ports) and a 12-port Ethernet hub	
ansedsgf	1108	ANH-8 with T1/FT1 (1 Ethernet port, 2 serial ports) and an 8-port Ethernet hub	

Table 2 lists the BLN and BCN board types.

#### Table 2. BCC Board Types: BLN and BCN Modules

BCC Board Type	Technician Interface or MIB Module ID	Site Manager Model Number	Description
comp	4353	AG2104037	Octal Sync with 32-context compression daughterboard
comp128	4354	AG2104038	Octal Sync with 128-context compression daughterboard
de100	4864	50038	100BASE-T Ethernet
			(continued)
dst416	40	5740	Dual Sync with token ring

BCC Board Type	Technician Interface or MIB Module ID	Site Manager Model Number	Description
dtok	176	5710	Dual token ring
enet3	132	5505	Dual Ethernet
esaf	236	5531	Dual Sync Dual Ethernet with 2-CAM filters
		5532	Dual Sync Dual Ethernet with 6-CAM filters
esafnf	232	5431	Dual Sync Dual Ethernet without hardware filters
osync	4352	5008	Octal Sync
qef	164	5950	Quad Ethernet with hardware filters
qenf	162	5450	Quad Ethernet without hardware filters
qtok	256	50021	Quad token ring
shssi	225	5295	HSSI
sse	118	5410	Single Sync with Ethernet
sync	80	5280	Quad Sync
wffddi1m	193	5943	Hybrid FDDI with single mode on connector B
wffddi1mf	197	5949	Hybrid FDDI with single mode on connector B and with hardware filters
wffddi1s	195	5942	Hybrid FDDI with single mode on connector A
wffddi1sf	199	5948	Hybrid FDDI with single mode on connector A and with hardware filters
wffddi2m	192	5930	Multimode FDDI
wffddi2mf	196	5946	Multimode FDDI with hardware filters
wffddi2s	194	5940	Single Mode FDDI
wffddi2sf	198	5947	Single Mode FDDI with hardware filters
atmcoc3mm	4608	AG13110112	ATM STS-3/STM-1 MMF
atmcoc3sm	4609	AG13110113	ATM STS-3/STM-1 SMF
atmce3	5121	AG13110114	ATM E3
atmcds3	5120	AG13110115	ATM DS-3
smct1	169	5944	Single Port MCT1e
			(continued)
mct1	168	5945	Dual Port MCT1

#### Table 2. BCC Board Types: BLN and BCN Modules (continued)

BCC Board Type	Technician Interface or MIB Module ID	Site Manager Model Number	Description
qmct1db15	5377	AG2111007	Quad Port MCT1 DB15
qmct1ds0a	5378	AG2104052	Quad Port MCT1 DB15 with DS0A
smce1ii75	189	AG2111003	75 ohm Single Port Multichannel E1 (MCE1-II) for 75 ohm Leased Line
mce1ii75	188	AG2111004	75 ohm Dual Port Multichannel E1 (MCE1-II) for 75 ohm Leased Line
smce1ii120	191	AG2111001	120 ohm Single Port Multichannel E1 (MCE1-II) for ISDN PRI and Leased Line
mce1ii120	190	AG2111002	120 ohm Dual Port Multichannel E1 (MCE1-II) for ISDN PRI and Leased Line

#### Table 2. BCC Board Types: BLN and BCN Modules (continued)

Table 3 lists the ASN board types.

#### Table 3. BCC Board Types: ASN Modules

BCC Board Type	Technician Interface or MIB Module ID	Description
denm	1280	Dual Port Ethernet Net Module
dsnm1n	1540	Dual Port Synchronous Net Module
dtnm	2048	Dual Port Token Ring Net Module
qsyncm	1664	Quad Port Synchronous Net Module
spex	512	SPEX Net Module
spexhsd	769	SPEX - Hot Swap Net Module
mmfsddas	1793	Multimode FDDI Net Module
smfsddas	1801	Single Mode FDDI Net Module
smammbdas	1825	Hybrid PHY A FDDI Net Module
mmasmbdas	1833	Hybrid PHY B FDDI Net Module
dsnm1nisdn	1588	ISDN BRI/Dual Sync Net Module
mce1nm	2816	MCE1 Net Module
		(continued)

asnqbri 2560 Quad BRI Net Module	asnqbri	2560	Quad BRI Net Module	·	
----------------------------------	---------	------	---------------------	---	--

BCC Board Type	Technician Interface or MIB Module ID	Description
se100nm	2304	100BASE-T Ethernet Net Module
dmct1nm	2944	Dual Port MCT1 Net Module
shssinm	3584	HSSI Net Module

#### Table 3. BCC Board Types: ASN Modules (continued)

Table 4 lists the ARN board types.

#### Table 4. BCC Board Types: ARN Modules

BCC Board Type	Technician Interface or MIB Module ID	Description
arnmbstr	8704	ARN Token Ring Base Module with 0, 8, 16, or 32 MB DRAM
arnmbsen	8720	ARN Ethernet Base Module with 0, 4, 8, 16, or 32 DRAM
arnmbenx10	8896	ARN Ethernet Base Module - xxMB DRAM with DCM
arnssync	8736	ARN Serial Adapter Module
arnis	8784	ARN ISDN BRI S/T Adapter Module
arnisdnu	8800	ARN ISDN BRI U Adapter Module
arndcsu	8768	ARN 56/64K DSU/CSU Adapter Module
arnv34	8752	ARN V.34 Modem Adapter Module
arnft1	8776	T1/FT1 DSU/CSU Adapter Module
arntsync	8848	ARN Tri-Serial Port Expansion Module
arnsenet	8832	ARN Ethernet Port Expansion Module
arnstkrg	8816	ARN Token Ring Expansion Module
arnentsync	8864	ARN Ethernet and Tri-Serial Expansion Module
arnisdnu	8880	ARN Token Ring and Tri-Serial Expansion Module
arnpbtenx10	8960	ARN Ethernet and Tri-Serial Expansion Module with DCM
arnpbenx10	8928	ARN Ethernet Expansion Module with DCM

Table 5 lists the System 5000 board types.

BCC Board Type	Technician Interface or MIB Module ID	Description
se100nm	2304	Router 100BASE-T Ethernet Net Module
denm	1280	Router Dual Ethernet Net Module
dsnm1n	1540	Router Dual Synchronous Net Module
dtnm	2048	Router Dual Token Ring Net Module
qsyncnm	1664	Router Quad Port Synchronous Net Module
iqe	1408	5380 Ethernet Router Module
iqtok	2176	5580 Token Ring Router Module
mmfsddas	1793	Router Multimode FDDI Net Module
smfsddas	1801	Router Single Mode FDDI Net Module
smammbdas	1825	Router Hybrid PHY A FDDI Net Module
mmasmbdas	1833	Router Hybrid PHY B FDDI Net Module
asnqbri	2560	Router Quad Port ISDN BRI Net Module
mce1nm	2816	Router MCE1 Net Module
dmct1nm	2944	Router Dual Port MCT1 Net Module
shssinm	3584	Router HSSI Net Module
atm5000bh	524544	Centillion Multiprotocol Engine

#### Table 5.BCC Board Types: System 5000 Modules

## Sending BCC Feedback

After you use the BCC, we welcome your feedback. Please visit the BCC Web site at the following URL, where you can leave us a message:

http://support.baynetworks.com/library/tpubs/bccfeedbk

# New Features in BayRS Version 12.20

BayRS Version 12.20 provides the following new Site Manager and BCC features.

# Cache Mode

Site Manager Version 6.20 provides a fourth configuration mode, *cache mode*, which is a hybrid of the existing remote and dynamic modes. Cache mode addresses the problem of long response times that may be encountered while configuring a router in dynamic mode, while still providing real-time configuration to the target router. For information about cache mode, see the *BayRS Version 12.20 Document Change Notice*.

# **ATM Configuration**

The following features are new for ATM in BayRS Version 12.20. For more information about ATM, see *Configuring ATM Services*.

#### ATM BCC Support

You can use BCC commands to configure PVC, classical IP, and LAN emulation service records. You can also use BCC commands to configure IP (PVC, classical IP, and LEC service records) or IPX (PVC and LEC service records only) over ATM.

#### **MPOA Server Configuration**

BayRS Version 12.20 supports MPOA server (MPS) configuration over ATM. Multi-Protocol Over ATM (MPOA) is the ATM Forum standard that specifies a way to efficiently transport intersubnet, unicast data in a LANE environment.

MPOA provides a direct connection between MPOA clients that reside on separate ELANs by allowing the LAN emulation clients to establish "cut-through" VCs that bypass the MPS.

MPOA also ensures interoperability with the existing infrastructure of routers. MPOA servers make use of routers that run standard network layer protocols, such as OSPF, providing a smooth integration with existing networks.

#### ATM Router Redundancy

BayRS Version 12.20 supports warm standby redundancy for ATM routers. This redundancy protects a network from the irrecoverable failure of an entire ATM router.

Router redundancy for ATM enables you to switch over from a primary router connected to an ATM network to a secondary router connected to the same ATM network. The primary router is configured to be in a router redundancy group. One or more secondary routers are also configured to be members of the same RR group.

#### Next Hop Resolution Protocol for MPOA

The Next Hop Resolution Protocol (NHRP) resolves a layer 3 media-independent protocol address to a layer 2 media-dependent address. As implemented in BayRS Version 12.20, NHRP resolves layer 3 IP addresses and layer 2 ATM addresses. Specifically, NHRP works in conjunction with MultiProtocol Over ATM (MPOA) clients and servers to provide a facilitated SVC-based delivery of IP datagrams over an ATM cloud.

## **OSI** Configuration

The following features are new for OSI in BayRS Version 12.20. For information about OSI configuration, see the *BayRS Version 12.20 Document Change Notice*.

#### **OSI over ATM**

OSI over ATM includes support for the following encapsulation methods: LLC/SNAP 1483 encapsulation and NLPID 1490 encapsulation.

With OSI over ATM, you also can configure *manual area addresses*. Manual area addresses are synonymous area addresses configured on the same intermediate system. You may want to configure manual area addresses when more than one addressing authority can assign addresses to the routing domain, or to allow a routing domain to be reconfigured during operation.



**Note:** The OSI Area Address Alias 1 and Area Address Alias 2 parameters, used in previous releases to configure manual area addresses, no longer exist.

#### TARP over OSI

The Transport Identifiers (TID) Address Resolution Protocol (TARP) has been added to the OSI suite for BayRS Version 12.20. OSI uses TARP to map OSI network service access point (NSAP) Level 3 addresses to target identifier (TID) addresses. It is similar to the DNS protocol that IP uses, where names are converted to IP addresses.

A TID is a name that applies to an entire router. It can be any text string, up to 40 characters long, and is similar to a UNIX host name. OSI addresses also apply to an entire router. An OSI NSAP address consists of the domain address, area address, the router ID, and a value called the N selector, which is always 00. It can be up to 13 bytes long.

# 8021.Q Tagging

8021.Q virtual LAN (VLAN) tagging enables a router to connect VLANs in layer 2 VLAN environments, acting as a default router for VLANs performing a "one armed router" function, while continuing to deliver WAN connectivity and security/firewalling between domains. This is not an implementation of VLANs on the router. It only provides for termination of VLANs on a router and does not extend the VLAN across the wide area.

802.1Q tagging supports only 100BASE-T and is implemented on ASN, ARN, and BN router platforms. For information about 802.1Q, see the *BayRS Version* 12.20 Document Change Notice.

## **Bay Dial VPN**

Bay Dial Virtual Private Network (Dial VPN) services provide switched connectivity to virtual private networks (VPNs) based on Internet Engineering Task Force (IETF) specifications. Corporate customers can subscribe to this service for remote dial access to virtual private networks or to the Internet over telephone lines.

For information about configuring Bay Dial VPN, see *Configuring and Troubleshooting Bay Dial VPN Services*.

## **BGP Route Reflector**

A BGP router configured for internal BGP (IBGP) must establish a peer-to-peer session with every other IBGP speaker in the AS. In an AS with a large number of IBGP speakers, this full-mesh topology can result in high bandwidth and maintenance costs. For example, a full-mesh topology for an AS with 50 IBGP speakers requires 1,225 internal peer-to-peer connections.

To avoid the high cost of a full-mesh topology to support IBGP speakers within a large AS, you can configure a router to function as an IBGP route reflector. An IBGP speaker that needs to communicate with other BGP speakers in the AS establishes a peer-to-peer *RR client* session with the IBGP route reflector.

For more information about BGP Route Reflector, see Configuring IP Services.

## **IBGP Equal Cost Multipath**

BGP equal-cost multipath (ECMP) support allows an IBGP speaker to perform route balancing within an AS by using multiple equal-cost routes submitted to the routing table by OSPF or RIP. For more information about IBGP equal-cost multipath, see *Configuring IP Multicasting and Multimedia Services*.

## **Generic Routing Encapsulation**

Generic Routing Encapsulation (GRE), which is defined in RFCs 1701 and 1702, is a generalized protocol that defines a method for encapsulating any payload inside any network (layer 3) protocol. For BayRS Version 12.20, GRE allows the layer 3 protocol IP to be encapsulated in IP. GRE tunnels are manually configured on the routers. For the tunneled protocol, the tunnels will be viewed as a logical single-hop point-to-point link. Routing information for the tunneled protocol can be exchanged over GRE tunnels. For more information about GRE, see *Configuring IP Services*.

## **IGMP** Relay

A router configured as an IGMP Relay (IGMP-R) device provides the following services on behalf of an MOSPF AS boundary router:

- Solicits multicast group membership information by sending IGMP host membership queries to hosts on its attached local networks
- Receives host membership reports and unsolicited join messages from hosts on attached networks and forwards them to the MOSPF boundary router
- Forwards multicast data to group members on locally attached networks

To an IGMP host on a directly attached network, the IGMP-R device appears to be a multicast router. The host receives a host membership query from IGMP-R and responds by sending an IGMP response. A host can also send IGMP-R an unsolicited join message.

To the MOSPF AS boundary router, the IGMP-R device appears to be a locally attached host. The MOSPF router (which also runs IGMP) sends IGMP host queries to the IGMP-R. IGMP-R responds by forwarding -- relaying -- IGMP host reports and unsolicited join messages from its attached hosts.

For more information about IGMP Relay, see *Configuring IP Multicasting and Multimedia Services*.

## **Equal Cost Multipath IP Static Routes**

IP supports equal-cost multipath (ECMP) static routes for traffic load balancing. If IP considers the ECMP routes to be the best routes, IP uses them in the way you specify -- in round-robin fashion, for example -- to forward data.

## **L2TP Configuration**

The following features are new for L2TP in BayRS Version 12.20. For more information about L2TP, see *Configuring L2TP Services*.

#### **Domain Name Removal Prior to RADIUS Authentication**

In BayRS Version 12.20, there is a new feature for L2TP configuration that enables you to remove the domain name from the complete user name before RADIUS authentication takes place. By default, this feature is enabled; consequently, the LNS automatically removes the delimiter, which separates the user name and the domain name, and the entire domain name.

If your RADIUS server database includes domain names as part of the user name entries, you need to disable this feature. To do this, set the Remove Domain Name parameter to Disable.

#### **RIP Support**

For BayRS 12.20, the LNS now supports RIP. RIP is particularly useful when the remote host is a router, because it enables the LNS to learn routing information from the remote router.

#### Flow Control

For an L2TP session, you can enable flow control. Flow control manages congestion across the connection, ensures that packets are not lost, and makes sure the devices at each end of the connection are communicating properly.

### L2TP IP Address Assignment

When configuring the LNS, you must configure an IP address for every slot that has an L2TP interface. This address is referred to as the *L2TP IP interface address*.

The L2TP IP interface address is internal to the LNS. When communicating with the remote user, the LNS associates the user's IP address, which is assigned by the RADIUS server, with the L2TP IP interface address that you configured.

## **Dial Backup**

You can now use the BCC to configure dial backup service. For more information about using the BCC to configure dial backup service, see *Configuring Dial Services*.

### **Data Collection Module**

You can now use the BCC to configure a data collection module (DCM) for RMON and RMON2 on an AN/ANH and ARN router. For information about configuring a DCM, see *Configuring RMON and RMON2*.

### **Domain Name System**

The Domain Name System (DNS) is a distributed database system, with DNS clients requesting host name/address resolution information from various DNS servers. DNS is used with numerous types of networking applications and protocols.

Specifically, DNS provides a directory service that allows client devices to retrieve information from a server-based database. For the Internet, DNS enables a device to obtain the IP address of a host based on the host's domain name.

The Bay Networks router functions as a DNS client. For more information about DNS, see the *BayRS Version 12.20 Document Change Notice*.

# NAT

NAT "N to 1" translation is a feature enhancement to Network Address Translation (NAT). "N to 1" address translation allows you to use a single IP address to represent a range of IP addresses on the private network. "N to 1" translations allow multiple hosts on the private network to be mapped to a single source address on the global or public side of the NAT. For more information about NAT III, see *Configuring IP Services*.

## ARN, ASN, and System 5000 Support

You can use the BCC to configure the ARN, ASN, and System 5000 router and all related hardware modules, except for the X.25 PAD module, FE1 adapter module, and V.34 console modem. You cannot use the BCC to configure the ARN/10/100-TX or the ARN 100-FX base units.

## **WAN Line Configuration**

You can use BCC Version 4.00 to configure and customize line services for:

- Serial WAN circuits
- An internal DSU/CSU installed on a Bay Networks router
- Multichannel E1 (MCE1) or Multichannel T1 (MCT1) circuits
- Fractional T1 (FT1) circuits

For more information, see Configuring WAN Line Services.

### **Frame Relay**

You can use the BCC to configure frame relay on serial, HSSI, and MCT1/E1 modules. You can also use BCC commands to configure frame relay as a backup interface over dial services. Frame relay supports the BN, ASN, AN, ARN, and System 5000 platforms.

## **HTTP Web Server**

You can use the BCC to configure the HTTP Web server. The router operating system contains an embedded Web server engine which, along with Web-based management pages, provides a simple, easy, and cost-effective way to monitor Bay Networks devices. For information about configuring the HTTP Server, see the *BayRS Version 12.20 Document Change Notice*.

## **IP Adjacent Host Configuration**

You can use the BCC to configure IP adjacent hosts on the BN, ASN, AN, ARN, and System 5000 platforms. For information about configuring IP adjacent hosts, see *Configuring IP Services*.

## **Telnet Passthrough**

Telnet Passthrough allows centrally located technical customer personnel to monitor, control, and effect change to the operation of Sentry UPS units. By integrating Telnet Passthrough traffic onto a router-based multiprotocol backbone network, you can reduce costs by eliminating extra asynchronous lines and equipment. Requirements for access to devices other than Sentry alarm systems should be communicated to Router Product Management.

## **IPX Support**

You can use the BCC to configure IPX on Ethernet, FDDI, serial, token ring, ATM, BRI, MCT/E1, and HSSI interfaces. For information about IPX, see *Configuring IPX Services*.

# **BCC show Commands**

BCC **show** commands are available for all router platforms, hardware, and protocols supported by the BCC. For information about BCC **show** commands, see the appropriate protocol manual.

# **New Hardware**

BayRS Version 12.20 supports the following new hardware.

## FE1/E1 WAN Adapter Module

The FE1/E1 WAN adapter module works with Bay Networks AN, ANH, and ARN routers. It operates like a T1 CSU/DSU for E1 circuits. This adapter has an X.21 or V.35 serial interface through which it connects to the router and a G.703/G.704 interface through which it connects to the network.

To use the FE1/E1 WAN adapter module on the AN, ANH, or ARN router, you must upgrade the boot and diagnostic PROMs. For a complete list of boot and diagnostic PROMs for BayRS Version 12.20, see the *BayRS Version 12.20 Document Change Notice*.

For more information about configuring the FE1/E1 WAN adapter module, see *Configuring WAN Line Services*.

# FRE-2-060E Processor Module with Advanced Compression Coprocessor Daughterboard

The FRE-2-060E processor module is equipped with the advanced compression coprocessor daughterboard. Although it is interoperable with existing software-based compression services, the advanced compression coprocessor daughterboard performs all compression, decompression, and compression-related functions in hardware, so that the FRE-2-060E processor does not need to perform them.

This new hardware configuration for BN platforms offers a choice of hardware compression algorithms that interoperates with FRE-3, FRE-2-060, FRE-2-040, and FRE processors and all LMI- and PCI-based link modules.

The FRE-2-060E with advanced compression coprocessor daughterboard supports hardware data compression over the following WAN interfaces:

- Multichannel E1-II (MCE1-II)
- Dual Multichannel E1 (DMCE1-II)
- Multichannel T1 (MCT1)
- Dual Multichannel T1 (DMCT1)
- Quad Multichannel T1 (QMCT1)
- Octal Synchronous (OSync)
- Quad Synchronous (QSync)
- Ethernet Synchronous Advanced Filter (ESAF)

The FRE-2-060E with advanced compression coprocessor daughterboard supports MSA compression for the following WAN protocols on BN platforms:

- Frame relay
- PPP
- ISDN PRI

The FRE-2-060E with advanced compression coprocessor daughterboard supports Hi/fn LZS compression for the following WAN protocols on BN platforms:

• PPP

• ISDN PRI

For information about configuring the FRE-2-060E with advanced compression coprocessor daughterboard, see *Configuring Data Compression Services*.

# **Guidelines for Working with BayRS Version 12.20**

Note the following guidelines when using BayRS Version 12.20. These guidelines supplement the instructions in the Version 12.20 documentation set.

## **AN/ANH and ARN Guidelines**

Note the following operational guidelines when using AN, ANH, or ARN routers.

#### Allocating Memory on ARN Routers

Although you can change the default memory allocation on other Bay Networks router platforms, the ARN platform does not support this "buffer carving" feature.

On the ARN, Site Manager does not support the Admin > Kernel Configuration option, and the Technician Interface does not support the **set** command for wfKernCfgParamEntry objects. Attempting to set wfKernCfgParamGlobMem on the ARN results in a warning message.

#### **Cycling Power to the ARN**

To ensure a complete power cycle, Bay Networks recommends that you wait at least 4 seconds after turning off the ARN before you turn it back on.



#### **DSU/CSU Test LED Remains On After Reset**

The ARN DSU/CSU Test LED properly goes on when the interface enters test or loopback mode. However, the LED remains on after resetting the DSU/CSU module, even though all looping terminates and the module hardware resets.

Restarting the router turns the LED off. However, this action is not necessary for proper operation of the DSU/CSU interface.

#### **Network Booting on DSU/CSU Interfaces**

AN and ANH DSU/CSU interfaces do not support network booting in BayRS Version 12.20. The ARN DSU/CSU supports network booting only over interfaces configured for 64 Kb/s Clear Channel service.

## **IP Fragmentation Not Supported over GRE Tunnels**

IP packets will not be fragmented when encapsulated at the tunnel ingress point. If necessary, you can set MTU sizes to values large enough to prevent fragmentation on relevant interfaces on the GRE tunnel ingress router. Alternatively, you can configure your system to send MTU sizes less than the MTU sizes of the relevant interfaces on the GRE tunnel ingress router.

### **Creating Multiple GRE Tunnels**

When creating multiple GRE tunnels dynamically, you can configure a maximum of 5 point-to-point GRE tunnels. In multipoint configurations, you can configure 64 GRE tunnels per interface.

## **BCC Help Not Supported on ARE Slots**

When attempting to use BCC Help on an ARE slot (that is, an ATM ARE ILI pair or a Model 5782 VNR), the router returns the following message:

Help command is not available on this processor card.

For information about BCC ATM parameters, see Configuring ATM Services.

## **ASN Boot and Diagnostic PROM Images**

BayRS Version 12.20 includes a new boot PROM image (*asnboot.exe*) as well as a new diagnostic PROM image (*asndiag.exe*; Version 2.30). You must use these files together; in other words, when you upgrade the boot PROM, you must also upgrade the diagnostic PROM. The new boot PROM image corrects a problem with the previous boot PROM on the ASN. The previous boot PROM caused the boot/diagnostic PROM checksum to fail following a cold-start.

For information about upgrading boot and diagnostic PROMs for the ASN router, see *Upgrading Routers from Version 7-11.xx to Version 12.00*.

## ATM Event Message Numbering Changed

The ATM, ATM signaling, and ATM LAN emulation log event messages have changed in BayRS Version 12.20. The ATM\_SIG entity (entity #95) no longer exists as a separate entity, but has been combined with the ATM entity (entity #78). Combining and reorganizing these entities has resulted in changes to the ATM log event message numbers. New log events were added to the ATM\_LE entity (entity #100) resulting in log event message number changes for LAN emulation, as well.

If you have defined log event traps for ATM, ATM signaling, or ATM LAN emulation, you will need to redefine them. For information, contact the Bay Networks Technical Solutions Center.

## **ARN Router Not a Supported DVS Radius Client**

The ARN router is not a supported DVS Radius client.

## **Problem Configuring NAT Dynamically**

When you are configuring a local or global interface for NAT in dynamic mode, the router returns an SNMP set error. However, this error does not affect the configuration of the router.

## **NAT Interface Restriction**

The *Configuring IP Services* manual states that NAT is supported over all interfaces. However, NAT is not currently supported over ATM or X.25 interfaces using Site Manager Versions 6.xx.

Support for NAT over ATM is planned for BayRS 13.10/7.10.

## **DNS Not Fully Operational**

The *BayRS Version 12.20 Document Change Notice* provides information about the Domain Name System (DNS) client and how to configure it using Site Manager Version 6.20. Please disregard this information; DNS is not fully operational, and should not be configured using Site Manager.

Site Manager Version 6.20 (patch release) corrects this problem by disabling the DNS client feature. If you want to obtain a version of Site Manager 6.20, contact the Bay Networks Technical Support Center.

## **BayRS Version 12.20 Flash Memory Requirements**

Platform	Flash Memory Required	Associated Software Suites
AN/ANH	8 MB	ip_access, office_suite, corp_suite
ARN	4 MB	ip_access
ARN	8 MB	office_suite, corp_suite

BayRS Version 12.20 software ships on the following flash memory cards:

## FT1/T1 DSU/CSU Guidelines

Note the following operational guidelines when using the FT1/T1 DSU/CSU.

#### Allocating DS0s

If you have an FT1/T1 DSU/CSU or E1 module and an ISDN S/T or U module installed on the same ARN, you can alternate assigned DS0 channels with unassigned channels, up to a maximum rate of 512 Kb/s (8 channels).



**Caution:** You cannot alternate assigned and unassigned channels across the 24 channels in a T1 line (768 Kb/s).

If you have rates above 512 Kb/s, Bay Networks recommends that you configure the DS0s contiguously, even though some noncontiguous channel configurations may work. If you have an unsupported channel configuration, the following message appears in the event log: Connector COM <COM#>, Current timeslot assignment is not supported.

This message indicates an invalid assignment of DS0s for the specified connector; you should have your service provider change the T1 channel assignments. Using contiguous channel assignments addresses this problem.

#### FT1/T1 and ISDN Phone Line Configuration

If you configure FT1/T1 after configuring an ISDN ST or U interface, you may experience line manager faults if you have a 2B+D channel (one physical RJ-45 cable with two phone circuits) with only one phone line configured. To avoid any line manager faults, configure both phone lines.

#### FT1/T1 DSU/CSU Diagnostic PROM Requirements

The ARN requires diagnostic PROM (*arndiag.exe*) Version 2.00 or later to support the FT1/T1 DSU/CSU adapter module. The FT1/T1 hardware documentation incorrectly specifies diagnostic PROM Version 1.34 as the minimum required version.

#### Selecting 56K Rate Adaption on FT1/T1 DSU/CSU Lines

Rate adaption determines the number of bits and their bit positions within a time slot. The FT1/T1 logical line rate adaption is 64 Kb/s per DS0. You cannot change this rate.

### Hi/fn (Stac) LZS Compression Executable

Using Hi/fn<sup>TM</sup> (Stac) LZS data compression requires the purchase of a separate CD containing the Hi/fn LZS executable for BayRS Version 12.20 software. You must purchase this CD regardless of whether you plan to implement compression in hardware or software.

### L2TP Guidelines

Note the following operational guidelines when using L2TP.

#### **Dial Backup on a Primary Leased Line**

You cannot configure dial backup service for a primary leased line that is using L2TP, even if the dial backup line resides on a different slot than the primary line.

#### **Dial Services**

L2TP is not compatible with dial services. Do not enable L2TP on the same slot that you enable for a dial service, such as dial-on-demand, dial backup, or bandwidth-on-demand.

### Dynamic L2TP Configuration

When you configure L2TP in dynamic mode, Site Manager can take several minutes to create the required circuits and related MIB instances.

#### Modification to an L2TP Script

The **show l2tp sessions** script has been modified. The script now displays the following information:

LNS Tun ID	LNS tunnel ID for the L2TP session.
LNS Call ID	LNS call ID for the L2TP session.
LAC Tun ID	LAC tunnel ID for the L2TP session.
LAC Call ID	LAC call ID for the L2TP session.
Calling Number	Phone number of the remote user.
Called Number	Phone number of the router.
Conn. Speed	Speed of the connection in b/s.
Call Serial Number	Serial number assigned to the call.
Chan. ID	Physical channel ID used in the ICCN message.

# **Outbound LAN Traffic Filters**

When implementing outbound traffic filters for LAN protocols, note that in some configurations the filters may cause a decline in throughput performance. For LAN circuits where the forwarding rate of the router is critical, you should monitor the throughput performance after configuring outbound LAN filters. If you notice an unacceptable performance degradation, try using inbound traffic filters to accomplish the filtering goal.

# **Protocol Prioritization No Call Filters and TCP Applications**

Using a no call filter that applies to any TCP application can cause TCP to retransmit the filtered packet.

When two routers running a TCP application are connected using a demand line, and the demand line becomes inactive, the TCP application remains inactive.

If a demand line configured with a no call filter goes down, the no call filter drops any TCP packets it receives. Because TCP never receives an acknowledgment for transmitting its packets, the TCP application continues to retransmit packets until the connection eventually times out and the application stops operating.



**Note:** No call filters are specific to dial services. For additional information about traffic filters and protocol prioritization, see *Configuring Traffic Filters and Protocol Prioritization*.

## RMON and RMON2 Guidelines

Note the following operational guidelines when using RMON and RMON2.

#### DCM Memory Requirements for RMON2

RMON2 requires 8 MB of dynamic random access memory (DRAM) on the data collection module (DCM).

#### Enabling RMON on the ARN 10/100 Router

You cannot enable RMON through both the router software and the Ethernet DCM at the same time.

You can enable RMON to operate through the router software image on the base module or on an optional Ethernet DCM (residing on an optional Ethernet parallel daughterboard).

### **Technician Interface Guidelines**

The following sections pertain to the Technician Interface and BayRS Version 12.20 software.

#### **Configuring NTP Using the Technician Interface**

When you use the Technician Interface to configure the Network Time Protocol (NTP), you must configure NTP on each slot on the router to ensure that NTP initializes correctly.

You can configure NTP on each slot by setting the following MIB variable from the Technician Interface:

#### set wfProtocols.68.0 0xffffffff;commit

68 represents the wfNTPLoad attribute.

#### Setting Modem Initialization Strings Using the Technician Interface

Several AT modem commands contain a dollar sign (\$) or backslash (\). The Technician Interface uses the \$ to reference a variable and the \ to prevent the substitution of a variable. If one of these symbols appears in the wfModemEntry.wfModemCfgInitString initialization command, the Technician Interface does not set the string. For example:

```
[1:1]$ get wfModemEntry.wfModemCfgInitString.1.2
wfModemEntry.wfModemCfgInitString.1.2 = "ATF"
[1:1]$ set wfModemEntry.wfModemCfgInitString.1.2
"AT$SB64000";commit
Variable: Undefined Variable - SB64000
```

The Technician Interface interprets the command as containing an undefined variable and does not change the MIB value.

To set the MIB variable, you must add a backslash ( $\)$  in front of the symbol causing the confusion (that is, the \$ or  $\)$ ). For example:

[1:1]\$ get wfModemEntry.wfModemCfgInitString.1.2
wfModemEntry.wfModemCfgInitString.1.2 = "ATF"

[1:1]\$ set wfModemEntry.wfModemCfgInitString.1.2
"AT\\$SB64000";commit

## X.25 PVCs

BayRS Version 12.20 software supports X.25 PVCs for X.25 IPEX Gateway services only.

# **Protocols Supported**

BayRS Version 12.20 supports the following bridging/routing protocols and router configuration features:

- Advanced Peer-to-Peer Networking (APPN)
- AppleTalk and AppleTalk Update Routing Protocol (AURP)
- Asynchronous transfer mode (ATM)
- ATM Data Exchange Interface (ATM DXI)
- ATM Half Bridge (AHB)
- ATM LAN Emulation (802.3 and 802.5)
- Bandwidth Allocation Protocol (BAP)
- Binary Synchronous Communication Type 3 (BSC3)
- Bisync over TCP (BOT)
- Bootstrap Protocol (BootP)
- Border Gateway Protocol (BGP-3 and BGP-4)
- Classless interdomain routing (CIDR)
- Data compression (WCP and Hi/fn)
- Data link switching (DLSw)
- DECnet Phase IV
- Distance Vector Multicast Routing Protocol (DVMRP)
- Dynamic Host Configuration Protocol (DHCP)
- Encryption (WEP; proprietary)
- Exterior Gateway Protocol-2 (EGP-2)
- File Transfer Protocol (FTP)
- Frame relay (PVC, SVC)
- HP Probe
- Integrated Services Digital Network (ISDN)
- Interface redundancy (proprietary)
- Internet Control Message Protocol (ICMP)

- Internet Gateway Management Protocol (IGMP)
- Internet Packet Exchange (IPX)
- Internet Protocol (IP)
- Internet Protocol Version 6 (IPv6)
- IPv6 PPP Control Protocol (CP)
- Internet Stream Protocol (ST2)
- Layer 2 Tunneling Protocol (L2TP)
- Learning Bridge
- Logical Link Control 2 (LLC2)
- Multicast OSPF (MOSPF)
- Native Mode LAN (NML)
- Network Core
- Network Time Protocol (NTP)
- Open Shortest Path First (OSPF)
- Open Systems Interconnection (OSI)
- Point-to-Point Protocol (PPP)
- Polled Asynch (PAS), also called Asynch Passthru over TCP
- Protocol prioritization
- Qualified Logical Link Control (QLLC)
- RaiseDTR dialup
- Remote Authentication Dial-In User Service (RADIUS)
- Resource Reservation Protocol (RSVP)
- Router discovery
- Router redundancy (proprietary)
- Routing Information Protocol (RIP)
- Service Advertisement Protocol (SAP)
- Simple Network Management Protocol (SNMP)
- Source Routing Bridge

- Source Routing Bridge over ATM permanent virtual circuits (PVCs)
- Spanning Tree
- Switched Multimegabit Data Service (SMDS)
- Synchronous Data Link Control (SDLC)
- Telnet (inbound and outbound)
- Transmission Control Protocol (TCP)
- Transparent Bridge
- Transparent-to-Source Routing Translation Bridge
- Trivial File Transfer Protocol (TFTP)
- User Datagram Protocol (UDP)
- V.25bis dialup
- Virtual Network Systems (VINES)
- X.25 with QLLC
- Xerox Network System (XNS)
- XMODEM and YMODEM

# **Standards Supported**

<u>Table 6</u> lists the Request For Comments (RFCs) and other standards documents with which Version 12.20 complies. BayRS Version 12.20 may support additional standards that are not listed in this table.

Standard	Description
ANSI T1.107b-1991	Digital Hierarchy - Supplement to formats specifications
ANSI T1.404	DS3 Metallic Interface Specification
ANSI X3t9.5	Fiber Distributed Data Interface (FDDI)
Bellcore FR-440	Transport Systems Generic Requirements (TSGR)

 Table 6.
 Standards Supported by Version 12.20

Standard	Description
Bellcore TR-TSY-000009	Asynchronous Digital Multiplexes, Requirements and Objectives
Bellcore TR-TSY-000010	Synchronous DS3 Add-Drop Multiplex (ADM 3/X) Requirements and Objectives
IEEE 802.1	Logical Link Control (LLC)
IEEE 802.1Q	IEEE 802.1Q VLAN tagging
IEEE 802.3	Carrier Sense Multiple Access with Collision Detection (CSMA/CD)
IEEE 802.5	Token Ring Access Method and Physical Layer Specifications
IEEE 802.10	Bridge with Spanning Tree
ITU Q.921	ISDN Layer 2 Specification
ITU Q.931	ISDN Layer 3 Specification
ITU X.25	Interface between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) for terminals operating in the packet mode and connected to public data networks by dedicated circuits
RFC 768	User Datagram Protocol (UDP)
RFC 791	Internet Protocol (IP)
RFC 792	Internet Control Message Protocol (ICMP)
RFC 793	Transmission Control Protocol (TCP)
RFC 813	Window and Acknowledgment Strategy in TCP
RFC 826	Ethernet Address Resolution Protocol
RFC 827	Exterior Gateway Protocol (EGP)
RFC 854	Telnet Protocol Specification
RFC 855	Telnet Option Specification
RFC 856	Telnet Binary Transmission
RFC 857	Telnet Echo Option
RFC 858	Telnet Suppress Go Ahead Option

#### Table 6. Standards Supported by Version 12.20 (continued)

Standard	Description
RFC 859	Telnet Status Option
RFC 860	Telnet Timing Mark Option
RFC 861	Telnet Extended Options: List Option
RFC 863	Discard Protocol
RFC 877	Transmission of IP Datagrams over Public Data Networks
RFC 879	TCP Maximum Segment Size and Related Topics
RFC 888	"STUB" Exterior Gateway Protocol
RFC 894	Transmission of IP Datagrams over Ethernet Networks
RFC 896	Congestion Control in IP/TCP Internetworks
RFC 903	Reverse Address Resolution Protocol
RFC 904	Exterior Gateway Protocol Formal Specification
RFC 919	Broadcasting Internet Datagrams
RFC 922	Broadcasting Internet Datagrams in Subnets
RFC 925	Multi-LAN Address Resolution
RFC 950	Internet Standard Subnetting Procedure
RFC 951	Bootstrap Protocol
RFC 959	File Transfer Protocol
RFC 994	Protocol for Providing the Connectionless-mode Network Service
RFC 1009	Requirements for Internet Gateways
RFC 1027	Using ARP to Implement Transparent Subnet Gateways
RFC 1042	Transmission of IP over IEEE/802 Networks
RFC 1058	Routing Information Protocol
RFC 1075	Distance Vector Multicast Routing Protocol (DVMRP)
RFC 1076	Redefinition of Managed Objects for IEEE 802.3 Repeater Devices (AN hubs only)

 Table 6.
 Standards Supported by Version 12.20 (continued)

Standard	Description	
RFC 1079	Telnet Terminal Speed Option	
RFC 1084	BOOTP Vendor Information Extensions	
RFC 1091	Telnet Terminal-Type Option	
RFC 1108	Security Options for the Internet Protocol	
RFC 1112	Host Extensions for IP Multicasting Appendix I. Internet Group Management Protocol	
RFC 1116	Telnet Line-mode Option	
RFC 1139	Echo Function for ISO 8473	
RFC 1155	Structure and Identification of Management Information for TCP/IP-based Internets	
RFC 1157	Simple Network Management Protocol (SNMP)	
RFC 1163	BGP-2 (obsoleted by RFC 1267)	
RFC 1164	Application of BGP in the Internet	
RFC 1166	Internet Numbers	
RFC 1188	Proposed Standard for the Transmission of IP over FDDI	
RFC 1191	Path MTU Discovery	
RFC 1209	Transmission of IP Datagrams over SMDS	
RFC 1212	Concise MIB Definitions	
RFC 1213	MIB for Network Management of TCP/IP-based Internets	
RFC 1267	Border Gateway Protocol 3 (BGP-3; obsoletes RFC 1163)	
RFC 1293	Inverse ARP for Frame Relay	
RFC 1294	Multiprotocol Interconnect over Frame Relay (obsoleted by RFC 1490)	
RFC 1304	Definition of Managed Objects for the SIP Interface Type	
RFC 1305	Network Time Protocol	
RFC 1315	Management Information Base for Frame Relay DTEs	

Table 6	Standards Supported by	Version 12 20	(continued)
	Stanuarus Supporteu by		(continueu)

Standard	Description	
RFC 1323	TCP Extensions for High Performance	
RFC 1331	Point-to-Point Protocol (PPP; obsoleted by RFC 1661)	
RFC 1332	PPP Internet Protocol Control Protocol (IPCP)	
RFC 1333	PPP Link Quality Monitoring (obsoleted by RFC 1989)	
RFC 1334	PPP Authentication Protocols	
RFC 1350	The TFTP Protocol (Revision 2)	
RFC 1356	Multiprotocol Interconnect on X.25 and ISDN in the Packet Mode	
RFC 1376	PPP DECnet Phase IV Control Protocol (DNCP)	
RFC 1377	OSI over PPP	
RFC 1378	PPP AppleTalk Control Protocol (ATCP)	
RFC 1390	Transmission of IP and ARP over FDDI Networks	
RFC 1403	BGP OSPF Interaction	
RFC 1434	Data Link Switching: Switch-to-Switch Protocol	
RFC 1483	Multiprotocol Encapsulation over ATM AAL5	
RFC 1490	Multiprotocol Interconnect over Frame Relay (obsoletes RFC 1294)	
RFC 1552	The PPP Internetwork Packet Exchange Control Protocol (IPXCP)	
RFC 1577	Classical IP and ARP over ATM	
RFC 1583	OSPF Version 2	
RFC 1585	MOSPF: Analysis and Experience	
RFC 1634	Novell IPX over Various WAN Media (IPXWAN)	
RFC 1638	PPP Bridging Control Protocol (BCP)	
RFC 1654	Border Gateway Protocol 4 (BGP-4; obsoleted by RFC 1771)	
RFC 1661	Point-to-Point Protocol (PPP; obsoletes RFC 1331)	
RFC 1662	PPP in HDLC-like Framing	

 Table 6.
 Standards Supported by Version 12.20 (continued)

Standard	Description	
RFC 1717	PPP Multilink Protocol (MP; obsoleted by RFC 1990)	
RFC 1755	Signaling Support for IP over ATM	
RFC 1757	Remote Network Monitoring Management Information Base (RMON), for AN, ANH, and ARN equipped with data collection module only	
RFC 1762	PPP Banyan VINES Control Protocol (BVCP)	
RFC 1763	PPP DECnet Phase IV Control Protocol (DNCP)	
RFC 1764	PPP XNS IDP Control Protocol (XNSCP)	
RFC 1771	Border Gateway Protocol 4 (BGP-4; obsoletes RFC 1654)	
RFC 1795	Data Link Switching: Switch-to-Switch Protocol, Version 1	
RFC 1819	Internet Stream Protocol, Version 2	
RFC 1989	PPP Link Quality Monitoring (obsoletes RFC 1333)	
RFC 1990	PPP Multilink Protocol (MP; obsoletes RFC 1717)	
RFC 2138	Remote Authentication Dial In User Service (RADIUS)	
RFC 2139	RADIUS Accounting	
RFC 2166	Data Link Switching, Version 2.0, Enhancements	
RFC 2205	Resource ReSerVation Protocol (RSVP) Version 1 Functional Specification	
VINES 4.11	BayRS works with the Banyan VINES 4.11 standard. BayRS Version 8.10 (and later) also supports VINES 5.50 sequenced routing.	

Table 6.	Standards Supported by Version 12.20 (continued)
----------	--

# **Flash Memory Cards Supported**

You use Personal Computer Memory Card International Association (PCMCIA) flash memory cards to store the software image and the configuration files in Bay Networks routers. <u>Table 7</u> lists the flash memory cards approved for use.

Size	Vendor	Part Number
4 MB	Advanced Micro Devices (AMD)	AMC004CFLKA-150
	AMP	797262-3
		797263-2
	Centennial	FL04M-20-11119
		FL04M-20-11138
	Epson	HWB401BNX2
	IBM	IBM1700400D1DA-25
	Intel	IMC004FLSAQ1381
8 MB 16 MB	AMD	AMC008CFLKA-150
		AMC008CFLKA-200
		AMC008CFLKA-250
		AMC008DFLKA-150
		AMC008DFLKA-200
		AMC008DFLKA-250
	Centennial	FL08M-25-11119-01
		FL08M-15-11119-01
		FL08M-20-11138
		FL08M-20-11119-01
	Epson	HWB801BNX0
	Intel	IMC008FLSP/Q1422
	Centennial	FL16M-20-11119-03
	Epson	HWB161BNX2

 Table 7.
 Approved Flash Memory Cards