

## ExtremeXOS Release Notes

Software Version 32.2

9037552-00 Rev AB October 2022



Copyright © 2022 All rights reserved.

#### **Legal Notice**

Extreme Networks, Inc. reserves the right to make changes in specifications and other information contained in this document and its website without prior notice. The reader should in all cases consult representatives of Extreme Networks to determine whether any such changes have been made.

The hardware, firmware, software or any specifications described or referred to in this document are subject to change without notice.

#### **Trademarks**

Extreme Networks and the Extreme Networks logo are trademarks or registered trademarks of Extreme Networks, Inc. in the United States and/or other countries.

All other names (including any product names) mentioned in this document are the property of their respective owners and may be trademarks or registered trademarks of their respective companies/owners.

For additional information on Extreme Networks trademarks, see: www.extremenetworks.com/company/legal/trademarks

#### **Open Source Declarations**

Some software files have been licensed under certain open source or third-party licenses. End-user license agreements and open source declarations can be found at: https://www.extremenetworks.com/support/policies/open-source-declaration/



# **Table of Contents**

Pretace	5
Conventions	5
Text Conventions	5
Platform-Dependent Conventions	6
Terminology	7
Send Feedback	7
Help and Support	7
Subscribe to Product Announcements	88
Related Publications	8
ExtremeXOS Publications	8
Extreme Management Center Publications	8
Open Source Declarations	S
Overview	10
Security Information	
Linux Kernel	1C
OpenSSL Version	
Upgrading ExtremeXOS	
Newly Purchased Switches Require Software Upgrade	
Default ExtremeXOS® Settings	
Image File Names	14
New and Corrected Features in ExtremeXOS 32.2	14
Flood to VLAN Filters for mDNS, LLMNR, and UPnP Protocols	14
Online Certificate Status Protocol Enhancement	15
SSH X.509v3 Authentication Using RADIUS	15
ExtremeSwitching X435 to 5520-24X 2.5G over 10G Optics Connection	16
Support for TLS v1.2 for Chalet	17
Python 3 Support	17
ExtremeCloud IQ Agent Support	17
Extreme Hardware/Software Compatibility and Recommendation Matrices	18
Compatibility with Extreme Management Center	18
Supported MIBs	18
Tested Third-Party Products	18
Tested RADIUS Servers	19
Extreme Switch Security Assessment	
DoS Attack Assessment	19
ICMP Attack Assessment	19
Port Scan Assessment	19
Limits	20
Limits Overview	20
Value Edge License Limits	22

Edge License Limits	34
Advanced Edge License Limits	
Core License Limits	65
Notes for Limits Tables	70
Open Issues, Known Behaviors, and Resolved Issues	72
Open Issues, Known Behaviors, and Resolved Issues  Open Issues	
	72



## **Preface**

Read the following topics to learn about:

- The meanings of text formats used in this document.
- Where you can find additional information and help.
- How to reach us with questions and comments.

#### **Conventions**

To help you better understand the information presented in this guide, the following topics describe the formatting conventions used for notes, text, and other elements.

#### **Text Conventions**

Unless otherwise noted, information in this document applies to all supported environments for the products in question. Exceptions, like command keywords associated with a specific software version, are identified in the text.

When a feature, function, or operation pertains to a specific hardware product, the product name is used. When features, functions, and operations are the same across an entire product family, such as ExtremeSwitching switches or SLX routers, the product is referred to as *the switch* or *the router*.

**Table 1: Notes and warnings** 

Icon	Notice type	Alerts you to
-	Tip	Helpful tips and notices for using the product
<b>***</b>	Note	Useful information or instructions
-	Important	Important features or instructions
1	Caution	Risk of personal injury, system damage, or loss of data
<u> </u>	Warning	Risk of severe personal injury

Table 2: Text

Convention	Description
screen displays	This typeface indicates command syntax, or represents information as it is displayed on the screen.
The words <i>enter</i> and <i>type</i>	When you see the word <i>enter</i> in this guide, you must type something, and then press the Return or Enter key. Do not press the Return or Enter key when an instruction simply says <i>type</i> .
Key names	Key names are written in boldface, for example <b>Ctrl</b> or <b>Esc</b> . If you must press two or more keys simultaneously, the key names are linked with a plus sign (+). Example: Press <b>Ctrl+Alt+Del</b>
Words in italicized type	Italics emphasize a point or denote new terms at the place where they are defined in the text. Italics are also used when referring to publication titles.
NEW!	New information. In a PDF, this is searchable text.

**Table 3: Command syntax** 

Convention	Description
bold text	Bold text indicates command names, keywords, and command options.
italic text	Italic text indicates variable content.
[ ]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x   y   z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options.
ж   у	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, such as passwords, are enclosed in angle brackets.
	Repeat the previous element, for example, member [member].
	In command examples, the backslash indicates a "soft" line break. When a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

#### Platform-Dependent Conventions

Unless otherwise noted, all information applies to all platforms supported by ExtremeXOS software, which are the following:

- ExtremeSwitching® switches
- SummitStack™

When a feature or feature implementation applies to specific platforms, the specific platform is noted in the heading for the section describing that implementation in the ExtremeXOS command documentation (see the Extreme Documentation page at <a href="https://www.extremenetworks.com/documentation/">www.extremenetworks.com/documentation/</a>). In many cases, although the command is available on all platforms, each platform

Preface Terminology

uses specific keywords. These keywords specific to each platform are shown in the Syntax Description and discussed in the Usage Guidelines sections.

#### **Terminology**

When features, functionality, or operation is specific to a device family, such as ExtremeSwitching, the family name is used. Explanations about features and operations that are the same across all product families simply refer to the product as the *device*.

#### Send Feedback

The Information Development team at Extreme Networks has made every effort to ensure that this document is accurate, complete, and easy to use. We strive to improve our documentation to help you in your work, so we want to hear from you. We welcome all feedback, but we especially want to know about:

- Content errors, or confusing or conflicting information.
- Improvements that would help you find relevant information.
- Broken links or usability issues.

To send feedback, do either of the following:

- Access the feedback form at https://www.extremenetworks.com/documentation-feedback/.
- Email us at documentation@extremenetworks.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

### **Help and Support**

If you require assistance, contact Extreme Networks using one of the following methods:

#### Extreme Portal

Search the GTAC (Global Technical Assistance Center) knowledge base; manage support cases and service contracts; download software; and obtain product licensing, training, and certifications.

#### The Hub

A forum for Extreme Networks customers to connect with one another, answer questions, and share ideas and feedback. This community is monitored by Extreme Networks employees, but is not intended to replace specific guidance from GTAC.

#### Call GTAC

For immediate support: (800) 998 2408 (toll-free in U.S. and Canada) or 1 (408) 579 2826. For the support phone number in your country, visit: www.extremenetworks.com/support/contact

Before contacting Extreme Networks for technical support, have the following information ready:

- Your Extreme Networks service contract number, or serial numbers for all involved Extreme Networks products
- A description of the failure
- A description of any actions already taken to resolve the problem

- A description of your network environment (such as layout, cable type, other relevant environmental information)
- Network load at the time of trouble (if known)
- The device history (for example, if you have returned the device before, or if this is a recurring problem)
- Any related RMA (Return Material Authorization) numbers

#### Subscribe to Product Announcements

You can subscribe to email notifications for product and software release announcements, Field Notices, and Vulnerability Notices.

- 1. Go to The Hub.
- 2. In the list of categories, expand the **Product Announcements** list.
- 3. Select a product for which you would like to receive notifications.
- 4. Select Subscribe.
- 5. To select additional products, return to the **Product Announcements** list and repeat steps 3 and 4.

You can modify your product selections or unsubscribe at any time.

#### **Related Publications**

#### **ExtremeXOS Publications**

- ExtremeXOS 32.2 Command Reference Guide
- ExtremeXOS and Switch Engine 32.2 EMS Messages Catalog
- ExtremeXOS 32.2 Feature License Requirements
- ExtremeXOS and Switch Engine 32.2 SNMP Traps Reference
- ExtremeXOS 32.2 User Guide
- ExtremeXOS Release Notes
- ExtremeXOS Quick Guide
- ACL Solutions Guide
- Extreme Hardware/Software Compatibility and Recommendation Matrices
- Extreme Optics Compatibility
- Switch Configuration with Chalet for ExtremeXOS 21.x and Later
- Using AVB with Extreme Switches

#### **Extreme Management Center Publications**

- Extreme Management Center User Guide
- Management Center online help is available by clicking the ? icon on all screens. The online help
  provides detailed explanations of how to configure and manage your network using Management
  Center.

### **Open Source Declarations**

Some software files have been licensed under certain open source licenses. More information is available at: www.extremenetworks.com/support/policies/open-source-declaration/.



## **Overview**

**Security Information on page 10** 

**Upgrading ExtremeXOS on page 10** 

Newly Purchased Switches Require Software Upgrade on page 11

**Default ExtremeXOS Settings on page 11** 

**Image File Names on page 14** 

New and Corrected Features in ExtremeXOS 32.2 on page 14

**ExtremeCloud IQ Agent Support on page 17** 

Extreme Hardware/Software Compatibility and Recommendation Matrices on page 18

Compatibility with Extreme Management Center on page 18

Supported MIBs on page 18

**Tested Third-Party Products on page 18** 

**Extreme Switch Security Assessment on page 19** 

These release notes documents ExtremeXOS 32.2, which adds features and resolves software deficiencies.

### **Security Information**

The following section covers important security information for ExtremeXOS 32.2.

#### Linux Kernel

ExtremeXOS 32.2 uses Linux Kernel 5.4 for ExtremeSwitching X465, X590 and X695 series switches, and Linux Kernel 4.14 for all other switches.

#### **OpenSSL Version**

ExtremeXOS 32.2 uses FIPS openssl-fips-2.0.16.

### **Upgrading ExtremeXOS**

For instructions about upgrading ExtremeXOS software, see *Software Upgrade and Boot Options* in *ExtremeXOS 32.2 User Guide*.

An ExtremeXOS core image (.xos file) must be downloaded and installed on the alternate (non-active) partition. If you try to download to an active partition, the system displays the following error message: Error: Image can only be installed to the non-active partition.

An ExtremeXOS modular software package (.xmod file) can still be downloaded and installed on either the active or alternate partition.

### **Newly Purchased Switches Require Software Upgrade**

Newly delivered switches typically have pre-GA (general availability) ExtremeXOS software installed. You should promptly upgrade the software to the latest version available by visiting the Extreme Portal.

For information about upgrading the ExtremeXOS software, see the *ExtremeXOS Upgrade Process* topic in the *Software Upgrade and Boot Options* chapter of the *ExtremeXOS 32.2 User Guide*.

### **Default ExtremeXOS® Settings**

The following table shows the default settings for ExtremeXOS starting with version 31.4, and shows any changes that have been made to these settings and in what version these changes were made.

**Table 4: Default ExtremeXOS Settings** 

Feature	31.4 and earlier	31.5	31.6 and later
Account Lockout	After 3 consecutive login failures, account is locked for 5 minutes. <sup>a</sup>		
AVB	Disabled.		
BFD Strict Session Protection	Disabled.		
BGP	Disabled.		
Bluetooth	Enabled.		
BOOTP Relay	Disabled.		
CDP	Enabled.		
Configuration auto save	Disabled.		
Clear-flow	Disabled.		
Diagnostics	Admin level privileges required to show diagnostics. <sup>a</sup>		
DHCP	Disabled.		
DNS Cache Resolver and Analytics	Disabled.		
IPFIX	Disabled.		
IP NAT	Disabled.		
EAPS	Disabled.		
EDP	Enabled on management port.		
ELRP	Disabled.		
ESRP	Disabled.		

<sup>&</sup>lt;sup>a</sup> If you choose enhanced security mode when initially setting up the switch or after running unconfigure switch all.

Table 4: Default ExtremeXOS Settings (continued)

Feature	31.4 and earlier	31.5	31.6 and later
Extended Edge Switching (VPEX)	Disabled.		
ExtremeCloud IQ	Enabled		
FEC	Disabled.		Enabled on Native 25Gb ports.
Identity Management	Disabled.		
IGMP	Enabled, set to IGMPv2 compatibility mode.		
IGMP Snooping	Enabled.		
Image Integrity Check	Disabled.		
IP Route Compression	Enabled.		
ISIS	Disabled.		
LLDP	Enabled.		
Log	Admin level privileges required to show log. <sup>a</sup>		
Logging memory buffer	Generate an event when the logging memory buffer exceeds 90% of capacity. <sup>a</sup>		
MAC Security	Disabled.		
MLD	Disabled.		
MLD Snooping	Disabled.		
MPLS	Disabled.		
MSRP	Disabled.		
MSTP	Enabled.		
NetLogin	All types of authentication are disabled.		
NTP	Disabled.		
ONEPolicy	Disabled.		
Policy rule model	Hierarchical (Unless upgrading from 30.5 with a saved configuration set to access list.)		
OpenFlow	Not supported.		
OSPF	Disabled.		
OVSDB	Disabled.		
Passwords	Plain text password entry not allowed. <sup>a</sup>		

Table 4: Default ExtremeXOS Settings (continued)

Feature	31.4 and earlier	31.5	31.6 and later
PIM	Disabled.		
PIM Snooping	Disabled.		
PoE Fast PoE Perpetual PoE	Enabled. Disabled. Disabled.		
RADIUS	Disabled for both switch management and network login.		
RIP	Disabled.		
RMON	Disabled. However, even in the disabled state, the switch responds to RMON queries and sets for alarms and events.		
sFlow	Disabled.		
SNMP server	Disabled. <sup>a</sup>		
SSH	Disabled.		
Stacking-support	Disabled, except for X450-G2, X465.		
Stacking auto-discovery	Enabled.		
STP	Enabled.		
Syslog	Disabled.		
TACACS	Disabled.		
Telnet	Disabled. <sup>a</sup>		
VPEX IP Multicast Replication	Controlling Bridge		
VPLS	All newly created VPLS instances are enabled.		
Watchdog	Enabled.		
Web HTTP server	Enabled. <sup>a</sup>		
Web HTTPS server	Disabled. <sup>a</sup>		

Image File Names Overview

#### **Image File Names**

You can identify the appropriate image or module for your platform based on the file name prefix of the image.

Table 5: Image Types (Prefixes)

Switches	Image File Type (Prefix)
ExtremeSwitching X465, X695, and X590	onie- Example: onie-22.2.1.2.xos  Note: These image files use the Open Network Install Environment (ONIE).
ExtremeSwitching X440-G2, X450-G2, X460-G2, and X620	summitX- Example: summitX-22.2.1.2.xos
ExtremeSwitching X435	summitlite_arm- Example: summitlite_arm-30.5.0.102.xos

#### New and Corrected Features in ExtremeXOS 32.2

This section lists the new and corrected features supported in the 32.2 software:

#### Flood to VLAN Filters for mDNS, LLMNR, and UPnP Protocols

Version 32.2 introduces support for flood to VLAN Filters for mDNS, LLMNR, and UPnP protocols. This feature enables you to create filters that forward to VLAN for these three protocol packets on both standalone switches and stacks.

When **flood** to VLAN is enabled, an actual ACL filter is installed, and one ACL entry is consumed for each of the three protocols.

When in **learn** mode, no ACL filters are installed, and no ACL resources are consumed.

#### Supported Platforms

This command is available on ExtremeSwitching X435, X440-G2, X450-G2, X460-G2, X465, X590, X620, and X695 series switches.

#### New CLI Commands

```
configure forwarding ipmc all [flood | learn]
configure forwarding ipmc llmnr [flood | learn]
configure forwarding ipmc mdns [flood | learn]
configure forwarding ipmc upnp [flood | learn]
```

#### Online Certificate Status Protocol Enhancement

An Online Certificate Status Protocol (OCSP) is performed in order to verify the peer certificate's revocation status (Good/Revoked/Unknown). OCSP is currently used in the following applications:

- SSH-x509v3 based authentication (the peer is an SSH client)
- RADIUS-TLS (the peer is a RADIUS-TLS server)
- Secure-Syslog (the peer is a Syslog server)

Version 32.2 introduces the following enhancement OCSP attributes:

- The OCSP server URL is now configurable and overrides the servers in the AuthorityInformationAccess (AIA) section of the RADIUS TLS server's certificate.
- Different applications can choose to have a different override server.
- One override server per application is acceptable.

#### Supported Platforms

This command is available on ExtremeSwitching X435, X440-G2, X450-G2, X460-G2, X465, X590, X620, and X695 series switches.

#### New CLI Commands

```
configure radius tls ocsp nonce [on | off]

configure radius tls ocsp override [url | none]

configure radius tls ocsp signer ocsp-nocheck [on | off]

configure ssh2 x509v3 ocsp [on | off]

configure ssh2 x509v3 ocsp nonce [on | off]

configure ssh2 x509v3 ocsp override [url | none]

configure ssh2 x509v3 ocsp signer ocsp-nocheck [on | off]

configure syslog tls ocsp nonce [on | off]

configure syslog tls ocsp override [url | none]

configure syslog tls ocsp signer ocsp-nocheck [on | off]
```

#### SSH X.509v3 Authentication Using RADIUS

Version 32.2 introduces support for SSH X.509v3 Authentication Using RADIUS. When enabled, the SSH server requests a password from the client during X.509v3 key-certificate authentication. The user name and password received are then sent to Authentication, Authorization, and Accounting (AAA) for authentication. AAA sends these credentials to the RADIUS server for authentication. If the RADIUS server is not configured or is not reachable, then AAA will validate the user name and password through local authentication.

For authentication, you can use Principal Name as the user name in the client's certificate. The 'principalName' (OID: 1.3.18.0.2.4.318) is displayed below the 'otherName' identifier in the 'SubjectAltName' (SAN) extension of the X509v3 key-certificate.

The following is an example of openssl.cnf to generate X509v3 certificate with SAN extension having 'prinicipalName':

```
[ usr_cert ]
# Extensions for client certificates (`man x509v3_config`).
basicConstraints = CA:FALSE
#nsCertType = client, email
#nsComment = "OpenSSL Generated Client Certificate"
subjectKeyIdentifier = hash
authorityKeyIdentifier = keyid,issuer:always
keyUsage = critical, nonRepudiation, digitalSignature, keyEncipherment
extendedKeyUsage = clientAuth, emailProtection
authorityInfoAccess = OCSP;URI:http://ocspserver.extremenetworks.com:2561
subjectAltName = otherName:1.3.18.0.2.4.318;UTF8:exos-admin@sustaining.com
```

#### Supported Platforms

This command is available on ExtremeSwitching X435, X440-G2, X450-G2, X460-G2, X465, X590, X620, and X695 series switches.

#### New CLL Commands

The following new commands support the RADIUS password authentication feature:

```
configure ssh2 x509v3 radius-password-auth [on | off]

configure ssh2 x509v3 username overwrite [on | off]

configure ssh2 x509v3 username strip-domain [on | off]

configure ssh2 x509v3 username use-domain [domain name | none]
```

#### ExtremeSwitching X435 to 5520-24X 2.5G over 10G Optics Connection

This feature supports a 2.5G connection between ExtremeSwitching X435 uplink ports and 5520-24X front panel ports. This feature also supports connecting an X435 to another X435 and 5520-24X to another 5520-24X at 2.5G

Use of this feature requires 10G-SR-SFP300M-ET and 10G-LR-SFP10KM-ET 10G transceivers.



#### Note

2.5G support is only available with auto-negotiation disabled.

#### Supported Platforms

This feature is supported on ExtremeSwitching X435 uplink ports and 5520-24X front panel ports only.

#### Support for TLS v1.2 for Chalet

Chalet has been upgraded to support a more secure TLS v1.2. Support for versions v1.0 and v1.1 has been removed. Removal of previously supported versions prevents the operating system from being flagged as vulnerable.

#### Python 3 Support

Software version 32.2 adds support for Python 3.8. The support for all earlier versions including 2.7 have been removed. You can use the conversion tool to change your Python 2 scripts to Python 3. See <a href="https://docs.python.org/3/howto/pyporting.html">https://docs.python.org/3/howto/pyporting.html</a> for more information.

### **ExtremeCloud IQ Agent Support**

ExtremeXOS 32.2 supports ExtremeCloud IQ. For network administrators looking for unified management of access points, switches, and routers, ExtremeCloud IQ is a cloud-driven network management application that:

- Simplifies network operations through an easy to use and intuitive interface, including minimal touch onboarding of devices.
- Provides ultimate flexibility in deployment choice, cloud platform choice, and OS choice.
- Offers unlimited data duration for more informed networking decisions.



#### **Important**

Check the ExtremeCloud IQ release notes to ensure support for your version has been added before upgrading.

This release supports device discovery, basic monitoring, visibility into homogenous stacking, and the ability to configure an optional user-defined virtual router (VR) and server address for ExtremeCloud IQ agent to connect to. These values are used instead of any auto-detected values.

For more information about ExtremeCloud IQ, go to https://www.extremenetworks.com/support/documentation/extremecloud-iq/.

**Table 6: Supported Platforms** 

Switch Series	Switch Models
ExtremeSwitching X435	X435-8T-4S X435-8P-4S X435-8P-2T-W X435-24T-4S X435-24P-4S
ExtremeSwitching X440-G2	X440-G2-24P-10GE4 X440-G2-48P-10GE4 X440-G2-12T-10GE4 X440-G2-12P-10GE4 X440-G2-24T-10GE4 X440-G2-48T-10GE4

Table 6: Supported Platforms (continued)

Switch Series	Switch Models
ExtremeSwitching X450-G2	X450-G2-24P-10GE X450-G2-48P-10GE X450-G2-24P-GE4 X450-G2-48P-GE4
ExtremeSwitching X460-G2	X460-G2-24P-10GE4 X460-G2-48P-10GE4 X460-G2-16MP-32P-10GE4 X460-G2-24P-48HP-10GE4
ExtremeSwitching X465	X465-48P X465-24MU-24W X465-24W X465-48W X465-24MU

### **Extreme Hardware/Software Compatibility and Recommendation Matrices**

ExtremeXOS and Switch Engine Software Support provides information about the minimum version of ExtremeXOS software required to support switches.

The Extreme Optics Compatibility website displays supported hardware platforms, technical specifications, and usage considerations for pluggable optical devices (transceivers and cables) used in all Extreme Networks operating environments. To access the site, open https://optics.extremenetworks.com/EXOS/ in a web browser.

To find the recommended ExtremeXOS versions for specific hardware platforms, see *ExtremeXOS* and *Switch Engine Release Recommendations*.

The latest versions of this and other ExtremeXOS guides are at: www.extremenetworks.com/documentation/.

### **Compatibility with Extreme Management Center**

ExtremeXOS 32.2 is compatible with the version of Extreme Management Center shown in this table: http://emc.extremenetworks.com/content/common/releasenotes/extended firmware support.htm

### **Supported MIBs**

The Extreme Networks management information bases (MIBs) are located at www.extremenetworks.com/support/policies/mibs/.

When you provide your serial number or agreement number, the MIBs are available under each release.

For detailed information on which MIBs and SNMP traps are supported, see the *Extreme Networks Proprietary MIBs* and *MIB Support Details* sections in the *ExtremeXOS 32.2 User Guide*.

### **Tested Third-Party Products**

The following third-party products have been tested for ExtremeXOS 32.2.

Overview Tested RADIUS Servers

#### **Tested RADIUS Servers**

The following RADIUS servers are fully tested:

- Microsoft—Internet Authentication Server
- Meetinghouse
- FreeRADIUS

### **Extreme Switch Security Assessment**

#### DoS Attack Assessment

Tools used to assess DoS attack vulnerability:

• Network Mapper (NMAP)

#### **ICMP Attack Assessment**

Tools used to assess ICMP attack vulnerability:

- SSPing
- Twinge
- Nuke
- WinFreeze

#### Port Scan Assessment

Tools used to assess port scan assessment:

Nessus



## **Limits**

Limits Overview on page 20
Value Edge License Limits on page 22
Edge License Limits on page 34
Advanced Edge License Limits on page 57
Core License Limits on page 65
Notes for Limits Tables on page 70

This chapter summarizes the supported limits in ExtremeXOS 32.2.

#### **Limits Overview**

The limits data is grouped by license level that contains the associated features:


- Value Edge License Limits on page 22
- Edge License Limits on page 34
- Advanced Edge License Limits on page 57
- Core License Limits on page 65

Non-universal switches include the following license levels:

Switch Category	Switches	Applicable License Levels
Non-universal switches	X435 *, X440-G2, X450-G2, X460- G2, X465, X590, X620, X695	Value Edge *, Edge, Advanced Edge, Core
Note: * The X435 is the only switch that supports the Value Edge license level.		

The following figure illustrates that each license level builds on the features of the license level below it. For example, the Advanced Edge license includes all of the features in the Edge license, plus the features in the Advance Edge license level.

Limits Limits Overview



\* Value Edge applies to X435 switches only

Figure 1: License Levels for non-Universal Switches

For more information about licenses, see ExtremeXOS 32.2 Feature License Requirements.

The following tables summarize tested metrics for a variety of features, as measured in a per-system basis unless otherwise noted. These limits may change, but represent the current status. The contents of this table supersede any values mentioned in the ExtremeXOS books.

The scaling and performance information shown in the following tables is provided for the purpose of assisting with network design. It is recommended that network architects and administrators design and manage networks with an appropriate level of network scaling "head room." The scaling and performance figures provided have been verified using specific network topologies using limited switch configurations. There is no guarantee that the scaling and performance figures shown are applicable to all network topologies and switch configurations and are provided as a realistic estimation only. If you experience scaling and performance characteristics that you feel are sufficiently below what has been documented, contact Extreme Networks technical support for additional assistance.

The route limits shown in the following tables for IPv4 and IPv6 routing protocols are software limits only. The actual hardware limits may be higher or lower than the software limits, based on platform. The hardware limits for specific platforms are specified as "IPv4/IPv6 routes (LPM entries in hardware)" in the following tables.

In the Extended Edge Switching architecture, Layer-2, Layer-3, and multicast packet forwarding and filtering operations take place on the controlling bridge. The controlling bridge switch and attached BPEs (V400 Virtual Port Extenders) constitute a single, extended switch system. Therefore, the Extended Edge Switching system assumes the scale and limits from the specific controlling bridge model in use. For applicable limits, see the following tables for the controlling bridge you are using.

## **Value Edge License Limits**

The following table shows supported limits for features in the Value Edge License.

Table 7: Supported Limits for Value Edge License

Metric	Product	Limit
AAA (local)—maximum number of admin and local user accounts.	ExtremeSwitching X435	16
Access lists (meters)—maximum number of meters.	ExtremeSwitching X435	512 ingress
Access lists (policies)—suggested maximum number of lines in a single policy file.	ExtremeSwitching X435	300,000
Access lists (policies)—maximum number of rules in a single policy file. <sup>a</sup>	ExtremeSwitching X435	1,024 ingress 0 egress
Access lists (slices)—number of ACL slices.	ExtremeSwitching X435	8 ingress only
ACL Per Port Meters—number of meters supported per port.	ExtremeSwitching X435	8
ACL port ranges	ExtremeSwitching X435	32
Meters Packets-Per-Second Capable	ExtremeSwitching X435	Yes
AVB (audio video bridging)— maximum number of active streams.	ExtremeSwitching X435	512
BOOTP/DHCP relay—maximum number of BOOTP or DHCP servers per virtual router.	ExtremeSwitching X435	8
BOOTP/DHCP relay—maximum number of BOOTP or DHCP servers per VLAN.	ExtremeSwitching X435	8
BOOTP/DHCP relay—maximum number of DHCPv4/v6 relay agents.	ExtremeSwitching X435	30
Connectivity fault management (CFM)—maximum number or CFM domains.	ExtremeSwitching X435	8
<b>CFM</b> —maximum number of CFM associations.	ExtremeSwitching X435	256
<b>CFM</b> —maximum number of CFM up end points.	ExtremeSwitching X435	32
<b>CFM</b> —maximum number of CFM down end points.	ExtremeSwitching X435	32

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
CFM—maximum number of CFM remote end points per up/down end point.	ExtremeSwitching X435	2,000
<b>CFM</b> —maximum number of dot1ag ports.	ExtremeSwitching X435	128
<b>CFM</b> —maximum number of CFM segments.	ExtremeSwitching X435	1,000
CFM—maximum number of MIPs.	ExtremeSwitching X435	256
DHCPv6 Prefix Delegation Snooping—Maximum number of DHCPv6 prefix delegation snooped entries.	ExtremeSwitching X435	30 (with static routes)
DHCP snooping entries—maximum number of DHCP snooping entries.	ExtremeSwitching X435	30
Dynamic ACLs—maximum number of ACLs processed per second.  Note: Limits are load-dependent.	ExtremeSwitching X435 with 50 DACLs with 500 DACLs	10 5
EAPS domains—maximum number of EAPS domains.	ExtremeSwitching X435	4
EAPSv1 protected VLANs— maximum number of protected VLANs.	ExtremeSwitching X435	1,000
ERPS domains—maximum number of ERPS domains with or without CFM configured.	ExtremeSwitching X435	4
ERPSv1 protected VLANs— maximum number of protected VLANs.	ExtremeSwitching X435	1,000
ELSM (vlan-ports)—maximum number of VLAN ports.	ExtremeSwitching X435	2,000
Forwarding rate—maximum L3 software forwarding rate.	ExtremeSwitching X435	7,844 pps
FDB (unicast blackhole entries) —maximum number of unicast blackhole FDB entries.	ExtremeSwitching X435	16,019
FDB (multicast blackhole entries) —maximum number of multicast blackhole FDB entries.	ExtremeSwitching X435	16,384
FDB (maximum L2 entries)— maximum number of MAC addresses.	ExtremeSwitching X435	16,384 <sup>g</sup>

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
FDB (maximum L2 entries)— maximum number of multicast FDB entries.	ExtremeSwitching X435	512
Identity management—maximum number of Blacklist entries.	ExtremeSwitching X435	512
Identity management—maximum number of Whitelist entries.	ExtremeSwitching X435	512
Identity management—maximum number of roles that can be created.	ExtremeSwitching X435	64
Identity management—maximum role hierarchy depth allowed.	ExtremeSwitching X435	5
Identity management—maximum number of attribute value pairs in a role match criteria.	ExtremeSwitching X435	16
Identity management—maximum number of child roles for a role.	ExtremeSwitching X435	8
Identity management—maximum number of policies/dynamic ACLs that can be configured per role.	ExtremeSwitching X435	8
Identity management—maximum number of LDAP servers that can be configured.	ExtremeSwitching X435	8
Identity management—maximum number of Kerberos servers that can be configured.	ExtremeSwitching X435	20
Identity management—maximum database memory size.	ExtremeSwitching X435	512
Identity management— recommended number of identities per switch.	ExtremeSwitching X435	100
Note: Number of identities per switch is for a default identity management database size (512 Kbytes) across all platforms.		
Identity management— recommended number of ACL entries per identity.	ExtremeSwitching X435	20
<b>Note:</b> Number of ACLs per identity, based on system ACL limitation.		

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
Identity management—maximum number of dynamic ACL entries configured as an individual dynamic rule, or as an ACL entry in a policy file.	ExtremeSwitching X435	500
IGMP snooping per VLAN filters —maximum number of VLANs supported in per-VLAN IGMP snooping mode.	ExtremeSwitching X435	500
IGMPv2 subscriber—maximum number of IGMPv2 subscribers per port. <sup>n</sup>	ExtremeSwitching X435	2,500
IGMPv2 subscriber—maximum number of IGMPv2 subscribers per switch. <sup>n</sup>	ExtremeSwitching X435	12,500
IGMPv3 maximum source per group—maximum number of source addresses per group.	ExtremeSwitching X435	250
IGMPv3 subscriber—maximum number of IGMPv3 subscribers per port. <sup>n</sup>	ExtremeSwitching X435	1,000
IGMPv3 subscriber—maximum number of IGMPv3 subscribers per switch. <sup>n</sup>	ExtremeSwitching X435	10,000
IP ARP entries in software— maximum number of IP ARP entries in software.	ExtremeSwitching X435	20,424
Note: Might be limited by hardware capacity of FDB (maximum L2 entries).		
IPv4 ARP entries in hardware with minimum LPM routes—maximum recommended number of IPv4 ARP entries in hardware, with minimum LPM routes present. Assumes number of IP route reserved entries is 100 or less.	ExtremeSwitching X435	509 h
IPv4 ARP entries in hardware with maximum LPM routes—maximum recommended number of IPv4 ARP entries in hardware, with maximum LPM routes present. Assumes number of IP route reserved entries is "maximum."	ExtremeSwitching X435	500 h

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
IPv4 remote hosts in hardware with zero LPM routes—maximum recommended number of IPv4 remote hosts (hosts reachable through a gateway) in hardware when LPM routing is not used. Assumes number of IP route reserved entries is 0, and number of IPv4 ARP entries present is 100 or less.	ExtremeSwitching X435	3,100 h
IPv4 routes—maximum number of static IPv4 routes in software (combination of unicast and multicast routes).	ExtremeSwitching X435	32
IPv4 routes (LPM entries in hardware)— number of IPv4 routes in hardware.	ExtremeSwitching X435	32
IPv6 addresses on an interface —maximum number of IPv6 addresses on an interface.	ExtremeSwitching X435	15
IPv6 addresses on a switch —maximum number of IPv6 addresses on a switch.	ExtremeSwitching X435	15
IPv6 host entries in hardware —maximum number of IPv6 neighbor entries in hardware.	ExtremeSwitching X435	500
IPv6 routes in software—maximum number of static IPv6 routes in software.	ExtremeSwitching X435	16
IPv6 routes (LPM entries in hardware)—maximum number of IPv6 routes in hardware.	ExtremeSwitching X435	16
IP router interfaces—maximum number of VLANs performing IPv4 and/or IPv6 routing. Excludes sub-VLANs.	ExtremeSwitching X435	30
IP unicast static routes—maximum number of permanent IP unicast routes.	ExtremeSwitching X435	32
IP multinetting (secondary IP addresses)—maximum number of secondary IP addresses per VLAN.	ExtremeSwitching X435	30
Jumbo frames—maximum size supported for jumbo frames, including the CRC.	ExtremeSwitching X435	9,216

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
Layer-2 IPMC forwarding caches— (IGMP/MLD/PIM snooping) in mac- vlan mode.  Note:  The internal lookup table configuration used is "I2-and- I3".  IPv6 and IPv4 L2 IPMC scaling is the same for this mode.  Layer-2 IPMC forwarding cache limits—(IGMP/MLD/PIM snooping) in mixed-mode are the same.	ExtremeSwitching X435	5,000
Layer-3 IPv4 Multicast—maximum number of <s,g,v> entries installed in the hardware (IP multicast compression enabled).  Note:  Limit value is the same for MVR senders, PIM Snooping entries. PIM SSM cache, IGMP senders, PIM cache.  Assumes source-group-vlan mode as look up key.  Layer 3 IPMC cache limit in mixed mode also has the same value.</s,g,v>	ExtremeSwitching X435	1,500
Layer-3 IPv6 Multicast—maximum number of <s,g,v> entries installed in the hardware (IP multicast compression enabled).  Note:  Limit value is the same for MLD sender per switch, PIM IPv6 cache.  Assumes source-group-vlan mode as lookup key.</s,g,v>	ExtremeSwitching X435	700

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
Load sharing—maximum number of load sharing groups.  Note: The actual number of load-sharing groups that can	ExtremeSwitching X435	8
be configured is limited by the number of physical ports present in the switch or SummitStack.		
<b>Load sharing</b> —maximum number of ports per load-sharing group.	ExtremeSwitching X435 (standalone only)	8
Logged messages—maximum number of messages logged locally on the system.	ExtremeSwitching X435	20,000
MAC-based security—maximum number of MAC-based security policies.	ExtremeSwitching X435	1,024
MAC Locking—Maximum number of MAC locking stations that can be learned on a port.	ExtremeSwitching X435	64 (static MAC locking stations) 600 (first arrival MAC locking stations)
Meters—maximum number of meters.	ExtremeSwitching X435	512
Maximum mirroring instances.	ExtremeSwitching X435	1 (egress)
Mirroring (filters)—maximum number of mirroring filters.	ExtremeSwitching X435	128
<b>Note:</b> This is the number of filters across all the active mirroring instances.		
Mirroring, one-to-many (filters)— maximum number of one-to-many mirroring filters.	ExtremeSwitching X435	128
<b>Note:</b> This is the number of filters across all the active mirroring instances.		
Mirroring, one-to-many (monitor port)—maximum number of one-to-many monitor ports.	ExtremeSwitching X435	1
Multicast listener discovery (MLD) snooping per-VLAN filters—maximum number of VLANs supported in per-VLAN MLD snooping mode.	ExtremeSwitching X435	63

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
Multicast listener discovery (MLD)v1 subscribers—maximum number of MLDv1 subscribers per port. <sup>n</sup>	ExtremeSwitching X435	2,500
Multicast listener discovery (MLD)v1 subscribers—maximum number of MLDv1 subscribers per switch. <sup>n</sup>	ExtremeSwitching X435	12,500
Multicast listener discovery (MLD)v2 subscribers—maximum number of MLDv2 subscribers per port. <sup>n</sup>	ExtremeSwitching X435	2,000
Multicast listener discovery (MLD)v2 subscribers—maximum number of MLDv2 subscribers per switch. <sup>n</sup>	ExtremeSwitching X435	10,000
Multicast listener discovery (MLD)v2 maximum source per group—maximum number of source addresses per group.	ExtremeSwitching X435	200
Network Login—maximum number of clients being authenticated on MAC-based VLAN enabled ports.	ExtremeSwitching X435	1,024
Network Login—maximum number of dynamic VLANs.	ExtremeSwitching X435	1,024
Network Login VLAN VSAs— maximum number of VLANs a client can be authenticated on at any given time.	ExtremeSwitching X435	10
Network Service Identifiers (NSI)/VLAN mappings—maximum number of VLANs to NSI mappings.	ExtremeSwitching X435	94
ONEPolicy Roles/Profiles— maximum number of policy roles/ profiles.	ExtremeSwitching X435	63
ONEPolicy Rules per Role/Profile —maximum number of rules per role/policy.	ExtremeSwitching X435	IPv4 Rules: 128 L2 Rules: 56
ONEPolicy Authenticated Users per Switch—maximum number of authenticated users per switch with TCI-Overwrite disabled.	ExtremeSwitching X435	192
Note: The maximum values assume 75% utilization of VLAN-XLATE hash table.		

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
ONEPolicy Authenticated Users per Port per Switch— maximum number of authenticated users per port per switch with TCI overwrite disabled.  Note: The maximum values assume	ExtremeSwitching X435	187
75% utilization of VLAN-XLATE hash table.		
ONEPolicy Permit/Deny Traffic Classification Rules Types—total maximum number of unique permit/deny traffic classification rules types (system/stack).	ExtremeSwitching X435	184
ONEPolicy Permit/Deny Traffic Classification Rules Types—maximum number of unique IPv4 permit/deny traffic classification rules (typesipsource / ipdest / ipfrag / udpsourceportIP / udpdestportIP / tcpdestportIP / ipttl / iptos / iptype).	ExtremeSwitching X435	128
ONEPolicy Permit/Deny Traffic Classification Rules Types— maximum number of unique Layer 2 permit/deny traffic classification rules (ethertype/port).	ExtremeSwitching X435	56
Policy-based routing (PBR) redundancy—maximum number of flow-redirects.	ExtremeSwitching X435	256 <sup>0</sup>
Policy-based routing (PBR) redundancy—maximum number of next hops per each flow-direct.	ExtremeSwitching X435	320
Private VLANs—maximum number of subscribers. Assumes a minimum of one port per network and subscriber VLAN.	ExtremeSwitching X435	15
Private VLANs—maximum number of private VLANs with an IP address on the network VLAN.	ExtremeSwitching X435	15
Note: This limit is dependent on the maximum number of private VLANs in an L2-only environment if the configuration has tagged and translated ports.		

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
Private VLANs—maximum number of private VLANs in an L2-only environment.	ExtremeSwitching X435	15
Route policies—suggested maximum number of lines in a route policy file.	ExtremeSwitching X435	10,000
Spanning Tree (maximum STPDs) —maximum number of Spanning Tree Domains on port mode EMISTP.	ExtremeSwitching X435	16
Spanning Tree PVST+—maximum number of port mode PVST domains.	ExtremeSwitching X435	128
Note: For all platforms, the maximum number of active ports per PVST domain depends on the maximum number of spanning tree ports supported on given platform. For example, on a switch that supports 256 PVST domains (maximum) and 4,096 STP ports (maximum), the maximum number of active ports per PVST domain would be 16 ports (4,096 ÷ 256).		
Spanning Tree—maximum number of multiple spanning tree instances (MSTI) domains.	ExtremeSwitching X435	16
Spanning Tree—maximum number of VLANs per MSTI.	ExtremeSwitching X435	100
Note: Maximum number of 10 active ports per VLAN when all 100 VLANs are in one MSTI.		
Spanning Tree—maximum number of VLANs on all MSTP instances.	ExtremeSwitching X435	256
Spanning Tree (802.1d domains) —maximum number of 802.1d domains per port.	ExtremeSwitching X435	1
Spanning Tree (number of ports) —maximum number of ports including all Spanning Tree domains.	ExtremeSwitching X435	1,024
Spanning Tree (maximum VLANs) —maximum number of STP- protected VLANs (dot1d and dot1w).	ExtremeSwitching X435	256

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
SSH (number of sessions)— maximum number of simultaneous SSH sessions.	ExtremeSwitching X435	8
Static MAC multicast FDB entries —maximum number of permanent multicast MAC entries configured into the FDB.	ExtremeSwitching X435	1,024
Syslog servers—maximum number of simultaneous Syslog servers that are supported.	ExtremeSwitching X435	16
Syslog targets—maximum number of configurable Syslog targets.	ExtremeSwitching X435	16
Telnet (number of sessions)— maximum number of simultaneous Telnet sessions.	ExtremeSwitching X435	8
Virtual routers—maximum number of user-created virtual routers that can be created on a switch.	ExtremeSwitching X435	16 (local-only VRs)
Virtual router forwarding (VRFs)— maximum number of VRFs that can be created on a switch.	ExtremeSwitching X435	16 (local-only VRFs)
Note: * Subject to other system limitations.		
VLAN aggregation—maximum number of port-VLAN combinations on any one superVLAN and all of its subVLANs.	ExtremeSwitching X435	1,000
VLANs—includes all VLANs.	ExtremeSwitching X435	4,094
VLANs (Layer 2)—maximum number of Layer 2 VLANs.	ExtremeSwitching X435	4,094
VLANs (Layer 3)—maximum number of VLANs performing IPv4 and/or IPv6 routing. Excludes sub- VLANs.	ExtremeSwitching X435	IPv4: 30 IPv6: 15
VLANs (maximum active port- based)—maximum active ports per VLAN when 1,000 VLANs are configured with default license.	ExtremeSwitching X435	28
VLAN Port Interfaces (VPIF)— maximum number of VLAN port interfaces.	ExtremeSwitching X435	4,090

Table 7: Supported Limits for Value Edge License (continued)

Metric	Product	Limit
VLANs (maximum active protocol- sensitive filters)—number of simultaneously active protocol filters in the switch.	ExtremeSwitching X435	16
VLAN translation—maximum number of translation VLANs. Assumes a minimum of one port per translation and member VLAN.	ExtremeSwitching X435	15
VLAN translation—maximum number of translation VLAN pairs with an IP address on the translation VLAN.	ExtremeSwitching X435	15
Note: This limit is dependent on the maximum number of translation VLAN pairs in an L2-only environment if the configuration includes tagged and translated ports.		
VLAN translation—maximum number of translation VLAN pairs in an L2-only environment.	ExtremeSwitching X435	15
VMAN CEP—maximum number of CVIDs.	ExtremeSwitching X435	192
XML requests—maximum number of XML requests per second.  Note: Limits are dependent on load and type of XML request. These values are dynamic ACL data requests.	ExtremeSwitching X435	10 with 100 DACLs

Edge License Limits

Limits

## **Edge License Limits**

The following table shows supported limits for features in the Edge License.

**Table 8: Supported Limits for Edge License** 

Metric	Product	Limit
AAA (local)—maximum number of admin and local user accounts.	All platforms, except X435	16
Access lists (meters)— maximum number of meters.	ExtremeSwitching X620, X440-G2	1,024 ingress 256 egress
	ExtremeSwitching X450-G2, X460-G2	1,024 ingress 512 egress
	ExtremeSwitching X590, X465	2,048 ingress 512 egress
	ExtremeSwitching X695	6,000 ingress 2,000 egress
Access lists (policies)— suggested maximum number of lines in a single policy file.	All platforms, except X435	300,000
Access lists (policies)— maximum number of rules in a single policy file. <sup>a</sup>	ExtremeSwitching X460-G2, X450-G2	4,096 ingress 1,024 egress
	ExtremeSwitching X620, X440-G2	2,048 ingress 512 egress
	ExtremeSwitching X590, X465, X695	8,192 ingress 1,024 egress
Access lists (policies)— maximum number of rules in a	ExtremeSwitching X450-G2, X460-G2, X590, X465	2,048 ingress only
single policy file in first stage (VFP).	ExtremeSwitching X695	1,024 ingress only
,	ExtremeSwitching X620, X440-G2	512 ingress only
Access lists (slices)—number of ACL slices.	ExtremeSwitching X460-G2, X450-G2	16 ingress 4 egress
	ExtremeSwitching X590, X465, X695	12 ingress 4 egress
	ExtremeSwitching X440-G2, X620	8 ingress 4 egress
Access lists (slices)—number of ACL slices in first stage (VFP).	ExtremeSwitching X450-G2, X460-G2, X465, X620, X440-G2, X590, X695	4 ingress only
ACL Per Port Meters—number of meters supported per port.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16
ACL port ranges.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	32
Meters Packets-Per-Second Capable.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	Yes

Limits Edge License Limits

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
AVB (audio video bridging)— maximum number of active streams.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2	1,024
	ExtremeSwitching X465, X695, X590	4,096
BFD sessions (Software Mode) —maximum number of BFD sessions.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695 (default timers—1 sec)	512
	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695 (minimal timers—100 msec)	10 <sup>C</sup>
BFD IPv4 sessions (Hardware Assisted)—maximum number of IPv4 BFD sessions.	ExtremeSwitching X460-G2, X590, X465, X695	900 (PTP not enabled) 425 (PTP enabled) 256 (with 3 ms transmit interval)
BFD IPv6 sessions (Hardware Assisted)—maximum number of IPv6 BFD sessions.	ExtremeSwitching X460-G2, X590, X465, X695	425 (PTP not enabled)
BOOTP/DHCP relay—maximum number of BOOTP or DHCP servers per virtual router.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X465, X620, X590, X695	8
BOOTP/DHCP relay—maximum number of BOOTP or DHCP servers per VLAN.	ExtremeSwitching X460-G2, 450-G2, X440-G2, X465, X620, X590, X695	8
BOOTP/DHCP relay—maximum number of DHCPv4/v6 relay agents	ExtremeSwitching X460-G2, X450-G2, X440-G2, X465, X620, X590, X695	4,000
Connectivity fault management (CFM)—maximum number or CFM domains.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	8
<b>Note:</b> With Advanced Edge license or higher.		
<b>CFM</b> —maximum number of CFM associations.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	256
Note: With Advanced Edge license or higher.		
<b>CFM</b> —maximum number of CFM up end points.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	32
Note: With Advanced Edge license or higher.		

Edge License Limits

Limits

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
<b>CFM</b> —maximum number of CFM down end points.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	32
<b>Note:</b> With Advanced Edge license or higher.	ExtremeSwitching X460-G2	256 (non-load shared ports) 32 (load shared ports)
CFM—maximum number of CFM remote end points per up/down end point.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	2,000
<b>Note:</b> With Advanced Edge license or higher.		
<b>CFM</b> —maximum number of dotlag ports.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	128
<b>Note:</b> With Advanced Edge license or higher.		
<b>CFM</b> —maximum number of CFM segments.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	1,000
<b>Note:</b> With Advanced Edge license or higher.		
CFM—maximum number of MIPs.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	256
<b>Note:</b> With Advanced Edge license or higher.		
CLEAR-Flow—total number of	ExtremeSwitching X460-G2, X450-G2	4,094
rules supported. The ACL rules plus CLEAR-Flow rules must be less than the total number of supported ACLs.	ExtremeSwitching X440-G2, X620	1,024
	ExtremeSwitching X590, X465, X695	8,192
Data Center Bridging eXchange (DCBX) protocol Type Length Value (TLVs)— maximum number of DCBX application TLVs.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	8
DHCPv6 Prefix Delegation Snooping—Maximum number of DHCPv6 prefix delegation snooped entries.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	256 (with underlying protocol RIPng) 128 (with underlying protocol OSPFv3) 1,024 (with static routes)
DHCP snooping entries— maximum number of DHCP snooping entries.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	2,048

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Dynamic ACLs—maximum number of ACLs processed per second.  Note: Limits are load-	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695 with 50 DACLs with 500 DACLs	10 5
dependent.		
EAPS domains—maximum number of EAPS domains.	ExtremeSwitching X450-G2, X460-G2, X440-G2, X620, X590, X465, X695	4
Note: An EAPS ring that is being spatially reused cannot have more than four configured EAPS domains.		
Note: You can increase the number of domains by upgrading to the Advanced Edge license.		
EAPSv1 protected VLANs— maximum number of protected	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2-24T/P	1,000
VLANs.	ExtremeSwitching X590, X465, X695	2,000
ERPS domains—maximum number of ERPS domains with or without CFM configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	4
Note: You can increase the number of domains by upgrading to the Advanced Edge license.		
ERPSv1 protected VLANs—	ExtremeSwitching X590, X465, X695	2,000
maximum number of protected VLANs.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2-24T/P	1,000
ERPSv2 protected VLANs— maximum number of protected	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	2,000
VLANs.	ExtremeSwitching X620, X440-G2-24T/P	500
ELSM (vlan-ports)—maximum number of VLAN ports.	ExtremeSwitching X450-G2, X460-G2, X620, X590 , X465, X695	5,000
	ExtremeSwitching X440-G2-24T/P	4,000
Extended Edge Switching maximum BPEs—maximum number of attached bridge port extenders (BPEs).	ExtremeSwitching X465, X590	48

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Extended Edge Switching maximum cascade ports—maximum number of upstream ports on bridge port extenders (BPEs).	ExtremeSwitching X465, X590	2 on V400-24 and V300 models 4 on V400-48 models
Extended Edge Switching maximum tiers—maximum number of cascade levels (tiers) of bridge port extenders (BPEs).	ExtremeSwitching X465, X590	4 (except for V300-8P-2T- W, which support 1 tier)
Extended Edge Switching maximum ring BPEs— maximum number of bridge port extenders (BPEs) in a ring topology.	ExtremeSwitching X465, X590	8
Extended Edge Switching maximum VLANs—maximum number of VLANs - Includes all VLANs	ExtremeSwitching X465, X590	4,094
Extended Edge Switching VLAN+ port memberships—maximum number of VLAN+ (extended) port memberships.	ExtremeSwitching X465, X590	12,000 in hash mode (default) 131,000 in port-group mode
Forwarding rate—maximum L3	ExtremeSwitching X440-G2	6,460 pps
software forwarding rate.	ExtremeSwitching X450-G2	16,000 pps
	ExtremeSwitching X465	28,497 pps
	ExtremeSwitching X460-G2	17,000 pps
	ExtremeSwitching X590	18,162 pps
	ExtremeSwitching X620	6,968 pps
	ExtremeSwitching X695	34,813 pps
FDB (unicast blackhole entries)	ExtremeSwitching X460-G2	49,152 <sup>f</sup>
—maximum number of unicast blackhole FDB entries.	ExtremeSwitching X450-G2	34,816 <sup>f</sup>
	ExtremeSwitching X620, X440-G2	16,384 <sup>f</sup>
	ExtremeSwitching X590, X465	278,528 <sup>f</sup>
	ExtremeSwitching X695	294,912 <sup>f</sup>
FDB (multicast blackhole entries)—maximum number	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	1,024
of multicast blackhole FDB entries.	ExtremeSwitching X590, X465, X695	4,096

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
FDB (maximum L2 entries)—	ExtremeSwitching X460-G2	98,300 <sup>g</sup>
maximum number of MAC addresses.	ExtremeSwitching X450-G2	68,000 <sup>g</sup>
	ExtremeSwitching X620, X440-G2	16,384
	ExtremeSwitching X590, X465, X695	278,528 <sup>9</sup>
	ExtremeSwitching X695	294,912 <sup>g</sup>
FDB (maximum L2 entries)—	ExtremeSwitching X590, X465, X695	4,096
maximum number of multicast FDB entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2	1,024
Identity management— maximum number of Blacklist entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	512
Identity management— maximum number of Whitelist entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	512
Identity management— maximum number of roles that can be created.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	64
Identity management— maximum role hierarchy depth allowed.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	5
Identity management— maximum number of attribute value pairs in a role match criteria.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16
Identity management— maximum number of child roles for a role.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Identity management— maximum number of policies/ dynamic ACLs that can be configured per role.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Identity management— maximum number of LDAP servers that can be configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Identity management— maximum number of Kerberos servers that can be configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	20
Identity management— maximum database memory size.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	512

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Identity management— recommended number of identities per switch.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	100
Note: Number of identities per switch is for a default identity management database size (512 Kbytes) across all platforms.		
Identity management— recommended number of ACL entries per identity.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	20
<b>Note:</b> Number of ACLs per identity, based on system ACL limitation.		
Identity management— maximum number of dynamic ACL entries configured as an individual dynamic rule, or as an ACL entry in a policy file.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	500
IGMP snooping per VLAN filters	ExtremeSwitching X460-G2,	1,500
—maximum number of VLANs supported in per-VLAN IGMP	ExtremeSwitching X450-G2	2,048
snooping mode.	ExtremeSwitching X695	2,000
	ExtremeSwitching X620, X440-G2	1,000
	ExtremeSwitching X590, X465	4,000
IGMPv1/v2 SSM-map entries —maximum number of IGMPv1/v2 SSM mapping entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	500
IGMPv1/v2 SSM-map entries— maximum number of sources per group in IGMPv1/v2 SSM mapping entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	50
IGMPv2 subscriber—maximum number of IGMPv2 subscribers	ExtremeSwitching X590, X465, X695, X460-G2, X450-G2	4,000
per port. <sup>n</sup>	ExtremeSwitching X440-G2, X620	3,500
IGMPv2 subscriber—maximum	ExtremeSwitching X460-G2, X450-G2	20,000
number of IGMPv2 subscribers per switch. <sup>n</sup>	ExtremeSwitching X620, X440-G2	17,500
	ExtremeSwitching X465, X590, X695	45,000
IGMPv3 maximum source per group—maximum number of source addresses per group.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	250

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
IGMPv3 subscriber—maximum number of IGMPv3 subscribers per port. <sup>n</sup>	ExtremeSwitching X460-G2, X450-G2	4,000
	ExtremeSwitching X440-G2, X620	3,500
	ExtremeSwitching X590, X465, X695	4,000
IGMPv3 subscriber—maximum	ExtremeSwitching X460-G2, X450-G2	20,000
number of IGMPv3 subscribers per switch. <sup>n</sup>	ExtremeSwitching X620, X440-G2	17,500
	ExtremeSwitching X590, X465, X695	45,000
IP ARP entries in software—	ExtremeSwitching X460-G2	57,344 (up to) h
maximum number of IP ARP entries in software.	ExtremeSwitching X450-G2	47,000 (up to) <sup>h</sup>
<b>Note:</b> Might be limited by	ExtremeSwitching X440-G2, X620	20,480
hardware capacity of FDB	ExtremeSwitching X590, X465	157,694 (up to) h
(maximum L2 entries).	ExtremeSwitching X695	184,318 (up to) h
IPv4 ARP entries in hardware	ExtremeSwitching X460-G2	50,000 (up to) <sup>h</sup>
with minimum LPM routes —maximum recommended	ExtremeSwitching X450-G2	39,000 (up to) h
number of IPv4 ARP entries	ExtremeSwitching X620	1,500
in hardware, with minimum LPM routes present. Assumes	ExtremeSwitching X440-G2	1,000
number of IP route reserved entries is 100 or less.	ExtremeSwitching X590, X465	119,000 (up to) h
Chiches is 100 of less.	ExtremeSwitching X695	146,000 (up to) h
IPv4 ARP entries in hardware	ExtremeSwitching X460-G2	43,000 (up to) <sup>h</sup>
with maximum LPM routes —maximum recommended	ExtremeSwitching X450-G2	29,000 (up to) <sup>h</sup>
number of IPv4 ARP entries in hardware, with maximum	ExtremeSwitching X620	1,500
LPM routes present. Assumes	ExtremeSwitching X440-G2	1,000
number of IP route reserved entries is "maximum."	ExtremeSwitching X590, X465	109,000 (up to) h
	ExtremeSwitching X695	125,000 (up to) h
IP flow information export (IPFIX)—number of	ExtremeSwitching X460-G2	2,048 ingress 2,048 egress
simultaneous flows.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	N/A
IPv4 remote hosts in	ExtremeSwitching X460-G2	73,000 h
hardware with zero LPM routes —maximum recommended	ExtremeSwitching X450-G2	61,000 (up to) <sup>h</sup>
number of IPv4 remote hosts (hosts reachable through a	ExtremeSwitching X440-G2, X620	3,500
gateway) in hardware when	ExtremeSwitching X590, X465	216,000 (up to) h
LPM routing is not used. Assumes number of IP route reserved entries is 0, and number of IPv4 ARP entries present is 100 or less.	ExtremeSwitching X695	241,000 (up to) h

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
IPv4 routes—maximum number of IPv4 routes in software	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	25,000
(combination of unicast and multicast routes), including static and from all routing protocols.	ExtremeSwitchingX590, X465, X695	131,000
IPv4 routes (LPM entries in	ExtremeSwitching X460-G2	12,000
hardware)— number of IPv4 routes in hardware.	ExtremeSwitching X450-G2	16,000
	ExtremeSwitching X590, X465, X695	131,000 <sup>q</sup>
	ExtremeSwitching X620, X440-G2	480
IPv6 6in4 tunnel—maximum number of IPv6 6in4 tunnels.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	255
	ExtremeSwitching X440-G2, X620	N/A
IPv6 6to4 tunnel—maximum number of IPv6 6to4 tunnels.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	1 (per virtual router)
	ExtremeSwitching X440-G2, X620	N/A
IPv6 addresses on an interface —maximum number of IPv6 addresses on an interface.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	255
IPv6 addresses on a switch —maximum number of IPv6	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	2,048
addresses on a switch.	ExtremeSwitching X620, X440-G2	510
IPv6 host entries in hardware	ExtremeSwitching X460-G2,	22,000 <sup>h</sup>
—maximum number of IPv6 neighbor entries in hardware.	ExtremeSwitching X450-G2	12,000 <sup>h</sup>
_	ExtremeSwitching X440-G2	1,000
	ExtremeSwitching X620	1,500
	ExtremeSwitching X590, X465	24,500 <sup>S</sup>
	ExtremeSwitching X695	57,000 h
IPv6 routes in software— maximum number of IPv6	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2	25,000
routes in software, including static routes and routes from all routing protocols.	ExtremeSwitching X590, X465, X695	65,000 <sup>q</sup>
IPv6 routes (LPM entries in	ExtremeSwitching X460-G2	6,000
hardware)—maximum number of IPv6 routes in hardware.	ExtremeSwitching X450-G2	8,000
	ExtremeSwitching X590, X465, X695	65,000 q
	ExtremeSwitching X620, X440-G2	240

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
IPv6 routes with a mask greater	ExtremeSwitching X590, X465, X695	8,192 <sup>r</sup>
than 64 bits in hardware— maximum number of such IPv6	ExtremeSwitching X440-G2, X620	1,024
LPM routes in hardware.	ExtremeSwitching X450-G2, X460-G2	2,048
IPv6 route sharing in hardware —route mask lengths for which	ExtremeSwitching X460-G2, X450-G2, X620	0-64 >64 single path only
ECMP is supported in hardware.	ExtremeSwitching X590, X465, X695	0-128 <sup>r</sup>
	ExtremeSwitching X440-G2	Not supported
IP router interfaces—maximum number of VLANs performing	ExtremeSwitching X460-G2,X450-G2, X590, X465, X695	2,048
IPv4 and/or IPv6 routing. Excludes sub-VLANs.	ExtremeSwitching X620, X440-G2	510
IP multicast static routes —maximum number of permanent multicast IP routes.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	1,024
IP unicast static routes —maximum number of	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	1,024
permanent IP unicast routes.	ExtremeSwitching X620, X440-G2	480
IP route sharing (maximum gateways)—Configurable	ExtremeSwitching X460-G2, X450-G2, X620, X590, X465, X695	2, 4, 8, 16, 32, or 64
maximum number of gateways used by equal cost multipath OSPF, BGP, IS-IS, static routes, or L2VPNs. Static routes, OSPF, and BGP are limited to 64 ECMP gateways per destination, while IS-IS is limited to 8. L2VPNs are limited to 16 LSPs per pseudowire on platforms that support 32 gateways, and 64 LSPs per pseudowire on platforms that support 64 gateways.	ExtremeSwitching X440-G2	N/A

43

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
IP route sharing (total combinations of gateway sets)—maximum number of combinations of sets of adjacent gateways used by multipath OSPF, BGP, IS-IS, or static routes.	ExtremeSwitching X460-G2, X450-G2  if maximum gateways is 2 if maximum gateways is 4 if maximum gateways is 8 if maximum gateways is 16 (default) if maximum gateways is 32 if maximum gateways is 64	1,022 1,022 510 254 126 62
	ExtremeSwitching X620	
	if maximum gateways is 2 if maximum gateways is 4 if maximum gateways is 8 if maximum gateways is 16 (default) if maximum gateways is 32 if maximum gateways is 64	126 126 126 126 62 30
	ExtremeSwitching X590, X465, X695	
	if maximum gateways is 2 if maximum gateways is 4 if maximum gateways is 8 if maximum gateways is 16 (default) if maximum gateways is 32 if maximum gateways is 64	4,094 4,094 2,046 1,022 510 254
	Note: The values here represent the maximum attainable ECMP groups of which, due to the RIOT feature, half are reserved for overlay and half for underlay routing. For more information about RIOT, see ExtremeXOS 32.2 User Guide.	
	ExtremeSwitching	
	if maximum gateways is 2 if maximum gateways is 4 if maximum gateways is 8 if maximum gateways is 16 (default) if maximum gateways is 32 if maximum gateways is 64	2,046 2,046 2,046 1,022 510 254
	ExtremeSwitching X440-G2	N/A
IP multinetting (secondary IP addresses)—maximum number of secondary IP addresses per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	255
Jumbo frames—maximum size supported for jumbo frames, including the CRC.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	9,216

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Layer-2 IPMC forwarding caches—(IGMP/MLD/PIM snooping) in mac-vlan mode.  Note:  The internal lookup table configuration used is "I2-and-I3".  IPv6 and IPv4 L2 IPMC scaling is the same for this mode.  Layer-2 IPMC forwarding cache limits—(IGMP/MLD/PIM snooping) in mixed-mode are the same.	ExtremeSwitching X695 ExtremeSwitching X460-G2 ExtremeSwitching X450-G2 ExtremeSwitching X620, X440-G2 ExtremeSwitching X590, X465	73,000 24,000 14,000 5,000 67,000
Layer-3 IPv4 Multicast— maximum number of <s,g,v> entries installed in the hardware (IP multicast compression enabled).  Note:  Limit value is the same for MVR senders, PIM Snooping entries. PIM SSM cache, IGMP senders, PIM cache.  Assumes source-group-vlan mode as look up key.  Layer 3 IPMC cache limit in mixed mode also has the same value.</s,g,v>	ExtremeSwitching X460-G2 ExtremeSwitching X450-G2 ExtremeSwitching X620, X440-G2 ExtremeSwitching X590, X465 ExtremeSwitching X695	26,000 21,000 1,500 93,000 104,000
Layer-3 IPv6 Multicast— maximum number of <s,g,v> entries installed in the hardware (IP multicast compression enabled).  Note:  Limit value is the same for MLD sender per switch, PIM IPv6 cache.  Assumes source-group-vlan mode as lookup key.</s,g,v>	ExtremeSwitching X460-G2 ExtremeSwitching X450-G2 ExtremeSwitching X620, X440-G2 ExtremeSwitching X590, X465 ExtremeSwitching X695	14,000 10,000 700 48,000 52,000

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Load sharing—maximum number of load sharing groups.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	128
Note: The actual number of load-sharing groups that can be configured is limited by the number of physical ports present in the switch or SummitStack.		
Load sharing—maximum number of ports per load-	For standalone and stacked: ExtremeSwitching X620, X440-G2	8
sharing group.	For standalone: ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	32
	For stacked: ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	64
Logged messages—maximum number of messages logged locally on the system.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	20,000
MAC-based security— maximum number of MAC- based security policies.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1,024
MAC Locking—Maximum number of MAC locking stations that can be learned on a port.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	64 (static MAC locking stations) 600 (first arrival MAC locking stations)
Meters—maximum number of meters supported.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	2,048

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Maximum mirroring instances.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695  Note: Only two or four mirroring instances will be active at a time, depending on the mirroring filter added to it. There are four hardware resource slots. Each single instance uses one such slot, while each ingress plus egress instance uses two slots. You can use a total of four slots, while there are no more than two egress instances. The maximum possible combination for mirroring instances:  1. 4 ingress 2. 3 ingress + 1 egress 3. 2 ingress + 2 egress 4. 2 (ingress + egress) 5. 1 (ingress + egress) + 2 ingress 6. 1 (ingress + egress) + 1 egress + 1 ingress	16 (including default mirroring instance)
	ExtremeSwitching X620, X440-G2  Note: For stacks containing X620 or X440-G2, maximum supported egress mirror instances is 1.	1 (egress)
Mirroring (filters)—maximum number of mirroring filters.  Note: This is the number of filters across all the active mirroring instances.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	128
Mirroring, one-to-many (filters) —maximum number of one-to- many mirroring filters.  Note: This is the number of filters across all the active mirroring instances.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	128
Mirroring, one-to-many (monitor port)—maximum number of one-to-many monitor ports.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
MLAG ports—maximum number of MLAG ports allowed.	ExtremeSwitching X695	61
	ExtremeSwitching X440-G2, X450-G2	51
	ExtremeSwitching X460-G2	53
	ExtremeSwitching X620	15
	ExtremeSwitching X590	35
	ExtremeSwitching X465	55
	Stacking	480
MLAG peers—maximum number of MLAG peers allowed.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	2
Multicast listener discovery	ExtremeSwitching X460-G2	768
(MLD) snooping per-VLAN filters—maximum number of	ExtremeSwitching X450-G2	508
VLANs supported in per-VLAN	ExtremeSwitching X620, X440-G2	256
MLD snooping mode.	ExtremeSwitching X590, X465, X695	1,500
Multicast listener	ExtremeSwitching X450-G2, X460-G2	4,000
discovery (MLD)v1 subscribers —maximum number of MLDv1	ExtremeSwitching X620, X440-G2	3,500
subscribers per port. <sup>n</sup>	ExtremeSwitching X590, X465, X695	4,000
Multicast listener discovery (MLD)v1 subscribers	ExtremeSwitching X460-G2, X450-G2, X620, X440-G2	10,000
—maximum number of MLDv1 subscribers per switch. <sup>n</sup>	ExtremeSwitching X590, X465, X695	45,000
Multicast listener	ExtremeSwitching X460-G2, X450-G2	4,000
discovery (MLD)v2 subscribers —maximum number of MLDv2	ExtremeSwitching X620, X440-G2	3,500
subscribers per port. n	ExtremeSwitching X590, X465, X695	4,000
Multicast listener discovery (MLD)v2 subscribers	ExtremeSwitching X460-G2, X450-G2, X620, X440-G2	10,000
—maximum number of MLDv2 subscribers per switch. <sup>n</sup>	ExtremeSwitching X590, X465, X695	45,000
Multicast listener discovery (MLD)v2 maximum source per group—maximum number of source addresses per group.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465 , X695	200
Multicast listener discovery (MLD) SSM-map entries—	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	500
maximum number of MLD SSM mapping entries.	ExtremeSwitching X440-G2, X620	50
Multicast listener discovery (MLD) SSM-MAP entries— maximum number of sources per group in MLD SSM mapping entries.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	50

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Network Login—maximum number of clients being authenticated on MAC-based VLAN enabled ports.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1,024
Network Login—maximum number of clients being	ExtremeSwitching X450-G2, X460-G2, X590, X465	1,024
authenticated with policy mode enabled with TCI overwrite	ExtremeSwitching , X695	512
enabled.	ExtremeSwitching X620, X440-G2	256
Network Login—maximum number of dynamic VLANs.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	2,000
	ExtremeSwitching X440-G2, X620	1,024
Network Login VLAN VSAs— maximum number of VLANs a client can be authenticated on at any given time.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	10
Network Service Identifiers (NSI)/VLAN mappings— maximum number of VLANs to NSI mappings.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	94
Network Address Translation (NAT) VLANs—maximum number of NAT VLANs.	ExtremeSwitching X465, X590, X695,	4
Network Address Translation	ExtremeSwitching X465, X590,	1,024
(NAT) Sessions—number of NAT sessions supported (non twice-NAT).	ExtremeSwitchingX695	1,023
Node Alias—maximum number of entries per slot.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8,192
ONEPolicy Dynamic ACL Rules—maximum number of Dynamic ACLs supported via RADIUS VSA 232 per user in Access-List mode.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	64
ONEPolicy Roles/Profiles— maximum number of policy roles/profiles.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	63

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
ONEPolicy Rules per Role/ Profile—maximum number of rules per role/policy.	ExtremeSwitching X450-G2, X460-G2	IPv6 rules: 256 IPv4 rules: 256 L2 Rules: 184 MAC Rules: 256
	ExtremeSwitching X620, X440-G2	IPv6 and Mac Rules: 0 Ipv4 Rules: 256 (per switch) L2 Rules: 184 (per switch)
	ExtremeSwitching X465, X590, X695	IPv4 Rules: 512 IPv6 Rules: 512 MAC Rules: 512 L2 Rules: 440
ONEPolicy Authenticated Users per Switch—maximum number	ExtremeSwitching X450-G2, X460-G2, X590, X465	1,024
of authenticated users per switch only with TCI-Overwrite	ExtremeSwitching X695	512
enabled.	ExtremeSwitching X620, X440-G2	256
	Stacking	Depends on the stack nodes, but the maximum is 65,535.
ONEPolicy Authenticated Users	ExtremeSwitching X590, X465	24,576
per Switch—maximum number of authenticated users per	ExtremeSwitching X460-G2,, X695	12,288
switch with TCI-Overwrite disabled.	ExtremeSwitching X450-G2	6,144
	ExtremeSwitching X620, X440-G2	1,536
Note: The maximum values assume 75% utilization of VLAN-XLATE hash table.	Stacking	1,536-65,534
ONEPolicy Authenticated Users	ExtremeSwitching X450-G2	6,144
per Port per Switch— maximum number of authenticated users	ExtremeSwitching X460-G2, X695	12,288
per port per switch with TCI overwrite disabled.	ExtremeSwitching X590, X465	24,576
	ExtremeSwitching X440-G2, X620	1,536
Note: The maximum values assume 75% utilization of VLAN-XLATE hash table.		
ONEPolicy Authenticated Users per Port per Switch— maximum	ExtremeSwitching X450-G2, X460-G2, X590, X465	1,024
number of authenticated users per port with only with TCI-	ExtremeSwitching X695	512
Overwrite enabled.	ExtremeSwitching X620, X440-G2	256

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
ONEPolicy Permit/Deny Traffic	ExtremeSwitching X450-G2, X460-G2	952
Classification Rules Types— total maximum number of	ExtremeSwitching X620, X440-G2	440
unique permit/deny traffic classification rules types	ExtremeSwitching X590, X465, X695	1,976
(system/stack).		
ONEPolicy Permit/Deny Traffic	ExtremeSwitching X450-G2, X460-G2	256
Classification Rules Types— maximum number of unique	ExtremeSwitching X620, X440-G2	N/A
MAC permit/deny traffic classification rules types (macsource/macdest).	ExtremeSwitching X590, X465, X695	512
ONEPolicy Permit/Deny Traffic	ExtremeSwitching X450-G2, X460-G2	256
Classification Rules Types— maximum number of unique	ExtremeSwitching X620, X440-G2	N/A
IPv6 permit/deny traffic classification rules types (ipv6dest).	ExtremeSwitching X590, X465, X695	512
ONEPolicy Permit/Deny Traffic Classification Rules Types	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2,	256
-maximum number of unique IPv4 permit/deny traffic classification rules (typesipsource / ipdest / ipfrag / udpsourceportIP / udpdestportIP / tcpsourceportIP / tcpdestportIP / ipttl / iptos / iptype).	ExtremeSwitching X590, X465, X695	512
ONEPolicy Permit/Deny Traffic	ExtremeSwitching X450-G2, X460-G2	184
Classification Rules Types— maximum number of unique	ExtremeSwitching X620, X440-G2	184
Layer 2 permit/deny traffic classification rules (ethertype/port).	ExtremeSwitching X590, X465, X695	440
Policy-based routing (PBR) redundancy—maximum number of flow-redirects.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590 , X465 , X695	256°
Policy-based routing (PBR) redundancy—maximum number of next hops per each flow-direct.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	320

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
Private VLANs—maximum	ExtremeSwitching X460-G2	53
number of subscribers. Assumes a minimum of	ExtremeSwitching X450-G2	51
one port per network and subscriber VLAN.	ExtremeSwitching X440-G2	47
Subscriber VLAN.	ExtremeSwitching X620	15
	ExtremeSwitching X695	71
	ExtremeSwitching X590, X465	31
Private VLANs—maximum number of private VLANs with	ExtremeSwitching X460-G2, X590, X465, X695	1,024
an IP address on the network VLAN.	ExtremeSwitching X450-G2	510
<b>Note:</b> This limit is dependent	ExtremeSwitching X440-G2	255
on the maximum number of private VLANs in an L2-only environment if the configuration has tagged and translated ports.	ExtremeSwitching X620	510
Private VLANs—maximum number of private VLANs in an	ExtremeSwitching X460-G2, X590, X465, X695	1,280
L2-only environment.	ExtremeSwitching X450-G2	597
	ExtremeSwitching X440-G2, X620	255
PTP/1588v2 Clock Ports	ExtremeSwitching X460-G2	31 for boundary clock 1 for ordinary clock
	ExtremeSwitching X440-G2, X465, X620, X590, X695	N/A
PTP/1588v2 Clock Instances	ExtremeSwitching X460-G2	2 combinations:  Transparent clock + ordinary clock  Transparent clock + boundary clock
	ExtremeSwitching X440-G2, X465, X620, X590, X695	N/A
PTP/1588v2 Unicast Static	ExtremeSwitching X460-G2	40 entries per clock port
Slaves	ExtremeSwitching X440-G2, X465, X620, X590, X695	N/A
PTP/1588v2 Unicast Static	ExtremeSwitching X460-G2	10 entries per clock type
Masters	ExtremeSwitching X440-G2, X465, X620, X590, X695	N/A
Route policies—suggested maximum number of lines in a route policy file.	ExtremeSwitching X460-G2, X620, X440-G2, X590, X465, X695	10,000

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
RIP Learned Routes—maximum number of RIP routes supported without aggregation.	ExtremeSwitchingX460-G2, X440-G2, X620, X590, X465, X695	10,000
RIP interfaces on a single router —recommended maximum number of RIP routed interfaces	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695 ExtremeSwitching X440-G2, X620	256 128
on a switch.  RIPng learned routes— maximum number of RIPng	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	3,000
routes.	ExtremeSwitching X440-G2, X620	N/A
Spanning Tree (maximum STPDs)—maximum number of	ExtremeSwitching X450-G2, X460-G2, X620, X590, X465, X695	64
Spanning Tree Domains on port mode EMISTP.	ExtremeSwitching X440-G2	32
Spanning Tree PVST+—	ExtremeSwitching X620	256
maximum number of port mode PVST domains.	ExtremeSwitching X460-G2, X450-G2, X440-G2	128
Note: For all platforms, the maximum number of active ports per PVST domain depends on the maximum number of spanning tree ports supported on given platform. For example, on a switch that supports 256 PVST domains (maximum) and 4,096 STP ports (maximum), the maximum number of active ports per PVST domain would be 16 ports (4,096 ÷ 256).	ExtremeSwitching X590, X465, X695	384
Spanning Tree—maximum number of multiple spanning tree instances (MSTI) domains.	ExtremeSwitching X450-G2, X460-G2, X620, X590, X465, X695	64
, ,	ExtremeSwitching X440-G2,	32
Spanning Tree—maximum number of VLANs per MSTI.	ExtremeSwitching X460-G2, X450-G2, X620, X590, X465, X695	600
Note: Maximum number of 10 active ports per VLAN when all 500 VLANs are in one MSTI.	ExtremeSwitching X440-G2	256
Spanning Tree—maximum number of VLANs on all MSTP instances.	ExtremeSwitching X460-G2, X450-G2, X620, X590, X465, X695	1,024
	ExtremeSwitching X440-G2	512
Spanning Tree (802.1d domains)—maximum number of 802.1d domains per port.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1

Table 8: Supported Limits for Edge License (continued)

Mahria	. ,	Linait
Metric	Product	Limit
Spanning Tree (number of ports)—maximum number of	ExtremeSwitching X450-G2, X460-G2, X620, X590, X465, X695	4,096
ports including all Spanning Tree domains.	ExtremeSwitching X440-G2	2,048
Spanning Tree (maximum VLANs)—maximum number of STP-protected VLANs (dot1d	ExtremeSwitching X460-G2, X450-G2, X620, X590, X465, X695	1,024
and dot1w).	ExtremeSwitching X440-G2	600
SSH (number of sessions) —maximum number of simultaneous SSH sessions.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Static MAC multicast FDB entries—maximum number of permanent multicast MAC entries configured into the FDB.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1,024
Syslog servers—maximum number of simultaneous Syslog servers that are supported.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16
Syslog targets—maximum number of configurable Syslog targets.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16
Telnet (number of sessions)  —maximum number of simultaneous Telnet sessions.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Virtual routers—maximum number of user-created virtual routers that can be created on a	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	63
switch.	ExtremeSwitching X440-G2, X620	16 (local-only VRs)
Virtual router forwarding (VRFs)—maximum number of	ExtremeSwitching X460-G2,X450-G2, X590, X465, X695	960 *
VRFs that can be created on a switch.	ExtremeSwitching X440-G2, X620	16 (local-only VRFs)
Note: * Subject to other system limitations.		
Virtual router protocols per VR —maximum number of routing	ExtremeSwitching X460-G2,X450-G2, X590, X465, X695	8
protocols per VR.	ExtremeSwitching X440-G2, X620	N/A
Virtual router protocols per switch—maximum number of	ExtremeSwitching X460-G2,X450-G2, X590, X465, X695	64
VR protocols per switch.	ExtremeSwitching X440-G2, X620	N/A
VLAN aggregation—maximum number of port-VLAN combinations on any one superVLAN and all of its subVLANs.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1,000

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
VLANs—includes all VLANs.  Note: Only 4,092 user- configurable VLANs are supported. (VLAN 1 is the default VLAN, and 4,095 is the management VLAN, and you may not configure them.)	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	4,094
VLANs (Layer 2)—maximum number of Layer 2 VLANs.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	4,094
VLANs (Layer 3)—maximum number of VLANs performing IPv4 and/or IPv6 routing.	ExtremeSwitching X460-G2,X450-G2, X590, X465, X695	2,048
Excludes sub-VLANs.	ExtremeSwitching X440-G2, X620	510
VLAN Port Interfaces (VPIF)— maximum number of VLAN	ExtremeSwitching X440-G2, X450-G2, X460-G2, X620	65,536
port interfaces.	ExtremeSwitching X465, X590, X695	131,585
VLANs (maximum active port-	ExtremeSwitching X590 , X465, X695	32
based)—maximum active ports per VLAN when 4,094 VLANs	ExtremeSwitching X440-G2	28
are configured with the default license.	ExtremeSwitching X460-G2	26
licerise.	ExtremeSwitching X620	16
	ExtremeSwitching X450-G2	29
VLANs (maximum active protocol-sensitive filters)— number of simultaneously active protocol filters in the switch.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16
VLAN translation—maximum	ExtremeSwitching X460-G2	53
number of translation VLANs. Assumes a minimum of one port per translation and member VLAN.	ExtremeSwitching X450-G2	51
	ExtremeSwitching X620	15
INICHIDEL VLAIN.	ExtremeSwitching X440-G2	47
	ExtremeSwitching X695	71
	ExtremeSwitching X590, X465	31

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
VLAN translation—maximum	ExtremeSwitching X465, X590, X695	1,024
number of translation VLAN pairs with an IP address on the	ExtremeSwitching X450-G2	512
translation VLAN.	ExtremeSwitching X620	510
Note: This limit is dependent on the maximum number of translation VLAN pairs in an L2-only environment if the configuration includes tagged and translated ports.	ExtremeSwitching X440-G2	255
VLAN translation—maximum number of translation VLAN	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	2,046
pairs in an L2-only environment.	ExtremeSwitching X440-G2, X620	255
VMAN CEP—maximum number	ExtremeSwitching X440-G2	1,500
of CVIDs.	ExtremeSwitching X450-G2	6,000
<b>Note:</b> With 75% hash table utilization.	ExtremeSwitching X460-G2,	12,000
	ExtremeSwitching X590, X465	24,000
XML requests—maximum number of XML requests per second.  Note: Limits are dependent on load and type of XML request. These values are dynamic ACL data requests.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	10 with 100 DACLs
XNV authentication—maximum number of VMs that can be processed (combination of local and network VMs).	ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2, X440-G2, X620	1,024
XNV database entries— maximum number of VM database entries (combination of local and network VMs).	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	16,000
XNV database entries— maximum number of VPP database entries (combination of local and network VPPs).	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	2,048
XNV dynamic VLAN—Maximum number of dynamic VLANs created (from VPPs /local VMs).	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	2,048
XNV local VPPs—maximum number of XNV local VPPs.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	2,048 ingress 512 egress

Table 8: Supported Limits for Edge License (continued)

Metric	Product	Limit
XNV policies/dynamic ACLs—maximum number of policies/dynamic ACLs that can be configured per VPP.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8 ingress 4 egress
XNV network VPPs—maximum number of XNV network VPPs. p	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	2,048 ingress 512 egress

# **Advanced Edge License Limits**

The following table shows supported limits for features in the Advanced Edge License.

Table 9: Supported Limits for Advanced Edge License

Metric	Product	Limit
BGP auto-peering—maximum number of auto-peering nodes and VTEPs.	ExtremeSwitching X590, X465, X695	64
BGP auto-peering attached IPv4 hosts— maximum number of attached IPv4 hosts.	ExtremeSwitching X590, X465, X695	64,000
BGP auto-peering attached IPv6 hosts— maximum number of attached IPv6 hosts.	ExtremeSwitching X590, X465, X695	8,000
BGP auto-peering ECMP— maximum number of equal cost multipath for auto-peering.	ExtremeSwitching X590, X465, X695	16*
Note: * Subject to the limitation imposed by the number of physical ports on a switch.		
BGP auto-peering maximum IPv4 prefixes with ECMP—Maximum number of IPv4 Network prefixes with ECMP.	ExtremeSwitching X590, X465, X695	64,000
BGP auto-peering maximum IPv6 prefixes with ECMP—Maximum number of IPv6 Network prefixes with ECMP.	ExtremeSwitching X590, X465, X695	8,000
BGP auto-peering MLAG peers —maximum MLAG peers per AutoBGP node.	ExtremeSwitching X590, X465, X695	1
BGP auto-peering VRFs— maximum number of VRFs.	ExtremeSwitching X590, X465, X695	64
BGP auto-peering EVPN instances —maximum EVPN instances.	ExtremeSwitching X590, X465, X695	1,024

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
EAPS domains—maximum number	ExtremeSwitching X590, X465, X695	128
of EAPS domains.	ExtremeSwitching X450-G2, X460-G2	64
<b>Note:</b> An EAPS ring that is being spatially reused cannot have more than four configured EAPS domains.	ExtremeSwitching X440-G2, X620	32
EAPSv2 protected VLANs— maximum number of protected	ExtremeSwitching X450-G2, X460-G2, X440-G2, X620	500
VLANs.	ExtremeSwitching X590, X465, X695	2,000
ERPS domains—maximum number of ERPS domains without CFM configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	32
ERPS domains—maximum number of ERPS domains with CFM configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	32
ERPSv1 protected VLANs— maximum number of protected	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	2,000
VLANs.	ExtremeSwitching X620, X440-G2	1,000
ERPSv2 protected VLANs— maximum number of protected	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	2,000
VLANs.	ExtremeSwitching X620, X440-G2	500
ESRP groups—maximum number of ESRP groups	ExtremeSwitching X450-G2, X460-G2, X440-G2, X620, X590, X465, X695	32
<b>ESRP domains</b> —maximum number of ESRP domains.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	64
ESRP L2 VLANs—maximum number of ESRP VLANs without an IP address configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1,000
ESRP L3 VLANs—maximum number of ESRP VLANs with an IP address configured.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	511
ESRP (maximum ping tracks)— maximum number of ping tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
ESRP (IP route tracks)—maximum IP route tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
ESRP (VLAN tracks)—maximum number of VLAN tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	1
L2 VPN: VCCV (pseudowire Virtual Circuit Connectivity Verification) VPNs per switch—maximum number of VCCV enabled VPLS VPNs.	ExtremeSwitching X460-G2, X590, X465 ExtremeSwitching X450-G2, X620, X440-G2, X695	16 N/A

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
L2 VPN: VPLS MAC addresses	ExtremeSwitching X590, X465	140,000
—maximum number of MAC addresses learned by a switch.	ExtremeSwitching X460-G2	55,000
	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
L2 VPN: VPLS VPNs—maximum	ExtremeSwitching X460-G2, X590, X465	1,023
number of VPLS virtual private networks per switch.	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
L2 VPN: VPLS peers—maximum	ExtremeSwitching X460-G2, X590, X465	64
number of VPLS peers per VPLS instance.	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
L2 VPN: LDP pseudowires—	ExtremeSwitching X460-G2, X590, X465	7,000
maximum number of pseudowires per switch.	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
L2 VPN: static pseudowires—	ExtremeSwitching X460-G2, X590, X465	7,000
maximum number of static pseudowires per switch.	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
L2 VPN: Virtual Private Wire	ExtremeSwitching X590, X465	4,090
Service (VPWS) VPNs—maximum number of virtual private networks	ExtremeSwitching X460-G2	1,023
per switch.	ExtremeSwitching X450-G2, X620, X440-G2, X695	N/A
MPLS RSVP-TE interfaces—	ExtremeSwitching X460-G2, X590, X465,, X695,	32
maximum number of interfaces.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS RSVP-TE ingress LSPs—	ExtremeSwitching X460-G2, X590,X695, X465	2,000
maximum number of ingress LSPs.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS RSVP-TE egress LSPs— maximum number of egress LSPs.	ExtremeSwitching X460-G2, X590, X465, X695	2,000
maximum number of egress LSPs.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS RSVP-TE transit LSPs— maximum number of transit LSPs.	ExtremeSwitching X460-G2,	2,000
Thiaximum number of transit LSPS.	ExtremeSwitching X590, X465, X695	4,000
	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS RSVP-TE paths—maximum number of paths.	ExtremeSwitching X460-G2	1,000
That tiber of patris.	ExtremeSwitching X590, X465, X695	2,000
	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS RSVP-TE profiles—maximum number of profiles.	ExtremeSwitching X460-G2	1,000
The state of promoti	ExtremeSwitching X590, X465, X695	2,000
	ExtremeSwitching X450-G2, X440-G2, X620	N/A

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
MPLS RSVP-TE EROs—maximum number of EROs per path.	ExtremeSwitching X460-G2, X590, X465, X695	64
	ExtremeSwitching X450-G2, and ExtremeSwitching X440-G2, X620	N/A
MPLS LDP peers—maximum	ExtremeSwitching X460-G2, X590, X465, X695	128
number of MPLS LDP peers per switch.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS LDP adjacencies—maximum	ExtremeSwitching X460-G2	50
number of MPLS LDP adjacencies per switch.	ExtremeSwitching X590, X465, X695	64
	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS LDP ingress LSPs—maximum	ExtremeSwitching X460-G2, X590, X465, X695	2,048
number of MPLS LSPs that can originate from a switch.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS LDP-enabled interfaces—	ExtremeSwitching X460-G2, X590, X465, X695	128
maximum number of MPLS LDP configured interfaces per switch.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS LDP transit LSPs—maximum	ExtremeSwitching X460-G2, X590, X465, X695	4,000
number of MPLS transit LSPs per switch.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS LDP egress LSPs—maximum	ExtremeSwitching X460-G2, X590, X465, X695	4,000
number of MPLS egress LSPs that can terminate on a switch.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS static egress LSPs—	ExtremeSwitching X460-G2	7,116
maximum number of static egress LSPs.	ExtremeSwitching X590, X465, X695	8,000
	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS static ingress LSPs—	ExtremeSwitching X460-G2, X590, X465, X695	4,000
maximum number of static ingress LSPs.	ExtremeSwitching X450-G2, X440-G2, X620	N/A
MPLS static transit LSPs—	ExtremeSwitching X460-G2, X590, X465, X695	4,000
maximum number of static transit LSPs	ExtremeSwitching X450-G2, X440-G2, X620	N/A
OSPFv2/v3 ECMP—maximum number of equal cost multipath	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	64
OSPFv2 and OSPFv3.	ExtremeSwitching X620	4
	ExtremeSwitching X440-G2	N/A
OSPFv2 areas—as an ABR, how	ExtremeSwitching X460-G2, X590, X465, X695	8
many OSPF areas are supported within the same switch.	ExtremeSwitching X450-G2, X440-G2, X620	4
OSPFv2 external routes—	ExtremeSwitching X590, X465, X695	10,000
recommended maximum number of external routes contained in an	ExtremeSwitching X460-G2	5,000
OSPF LSDB.	ExtremeSwitching X450-G2, X440-G2, X620	2,400

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
OSPFv2 inter- or intra-area routes —recommended maximum number of inter- or intra-area routes	ExtremeSwitching X590, X465, X695	4,000
	ExtremeSwitching X460-G2	2,000
contained in an OSPF LSDB with one ABR in OSPF domain.	ExtremeSwitching X450-G2, X440-G2, X620	1,000
OSPFv2 interfaces—recommended maximum number of OSPF interfaces on a switch (active interfaces only).	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	4
OSPFv2 links—maximum number	ExtremeSwitching X460-G2, X590, X465, X695	400
of links in the router LSA.	ExtremeSwitching X450-G2, X620, X440-G2	4
OSPFv2 neighbors—maximum number of supported OSPF adjacencies.	ExtremeSwitching X450-G2, X460-G2, X440-G2, X620, X590, X465, X695	4
OSPFv2 routers in a single area—	ExtremeSwitching X590, X465, X695	100
recommended maximum number of routers in a single OSPF area.	ExtremeSwitching X460-G2	50
J J	ExtremeSwitching X450-G2, X440-G2, X620	4
OSPFv2 virtual links—maximum	ExtremeSwitching X460-G2, X590, X465, X695	32
number of supported OSPF virtual links.	ExtremeSwitching X450-G2, X440-G2, X620	4
OSPFv3 areas—as an ABR, the	ExtremeSwitching X590, X465, X695	100
maximum number of supported OSPFv3 areas.	ExtremeSwitching X460-G2	16
	ExtremeSwitching X450-G2, X440-G2, X620	4
OSPFv3 external routes—	ExtremeSwitching X460-G2,X590, X465, X695	10,000
recommended maximum number of external routes.	ExtremeSwitching X450-G2, X440-G2, X620	1,200
OSPFv3 inter- or intra-area routes	ExtremeSwitching X590, X465, X695	4.000
—recommended maximum number of inter- or intra-area routes.	ExtremeSwitching X460-G2	3,000
	ExtremeSwitching X450-G2, X440-G2, X620	500
OSPFv3 interfaces—maximum number of OSPFv3 interfaces (active interfaces only).	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	4
OSPFv3 neighbors—maximum number of OSPFv3 neighbors.	ExtremeSwitching X450-G2, X460-G2, X440-G2, X620, X590, X465, X695	4
OSPFv3 virtual links—maximum	ExtremeSwitching X460-G2, X590, X465, X695	16
number of OSPFv3 virtual links supported.	ExtremeSwitching X450-G2, X440-G2, X620	4
PIM IPv4 (maximum interfaces)— maximum number of PIM active interfaces.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	4

61

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
PIM IPv4 Limits—maximum number of multicast groups per dynamic rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	180
PIM IPv4 Limits—maximum number of multicast groups per static rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	3,000 (depends on policy file limits)
PIM IPv4 Limits—maximum number of multicast sources per	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	5,000
group.	ExtremeSwitching X440-G2, X620	1,500
PIM IPv4 Limits—maximum number of dynamic rendezvous points per multicast group.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	145
PIM IPv4 Limits—static rendezvous points.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	32
PIM IPv6 (maximum interfaces)— maximum number of PIM active interfaces.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620, X590, X465, X695	4
PIM IPv6 Limits—maximum	ExtremeSwitching X460-G2, X590 , X465, X695	1,750
number of multicast sources per group.	ExtremeSwitching X450-G2	1,500
	ExtremeSwitching X440-G2, X620	550
PIM IPv6 Limits—maximum number of multicast groups per dynamic rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	70
PIM IPv6 Limits—maximum number of multicast groups per static rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	3,000 (depends on policy file limits)
PIM IPv6 Limits—maximum number of dynamic rendezvous points per multicast group.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	64
PIM IPv6 Limits—maximum number of secondary addresses per interface.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	70
PIM IPv6 Limits—static rendezvous points.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590 , X465, X695	32
Port-specific VLAN tags—	ExtremeSwitching X460-G2, X590 , X465	1,023
maximum number of port-specific VLAN tags.	ExtremeSwitching X450-G2, X440-G2, X620, X695	N/A
Port-specific VLAN tags—	ExtremeSwitching X460-G2, X590, X465	4,000
maximum number of port-specific VLAN tag ports.	ExtremeSwitching X450-G2, X440-G2, X620, X695	N/A

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
VLAN Port Interfaces (VPIF)— maximum number of VLAN port interfaces.	ExtremeSwitching X460-G2	65,536
	ExtremeSwitching X465, X590, X695	131,585
VRRP (v2/v3-IPv4) (maximum	Normal Mode (as individual VRs):	
instances)—maximum number of VRRP instances for a single switch, with Advanced Edge license or	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	511
higher.	ExtremeSwitching X440-G2, X620	128
Note: These limits are applicable	Scaled Mode (with groups):	
for Fabric Routing configuration also.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	2,048
Note: Number of groups configured should not exceed the number of individual VRs supported (that is, in normal mode) for that platform type.	ExtremeSwitching X440-G2, X620	128
VRRP (v3-IPv6) (maximum	Normal Mode (as individual VRs):	
instances)—maximum number of VRRP instances for a single switch, with Advanced Edge or Base	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	511
license, or higher. (VRRP-VRRPv3-IPv6)	ExtremeSwitching X440-G2, X620	128
	Scaled Mode (with groups):	
<b>Note:</b> These limits are applicable for Fabric Routing configuration also.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	2,048
	ExtremeSwitching X440-G2, X620	128
Note: Number of groups configured should not exceed the number of individual VRs supported (that is, in normal mode) for that platform type.		
VRRP (v2/v3-IPv4/IPv6) (maximum VRID)—maximum	ExtremeSwitching X460-G2, X450-G2 X440-G2, X620, X590, X465, X695	255
number of unique VRID numbers per switch.	Note: With Advanced Edge license or higher.	
VRRP (v2/v3-IPv4/IPv6) (maximum VRIDs per VLAN)— maximum number of VRIDs per	ExtremeSwitching X460-G2, X450-G2 X440-G2, X620, X590, X465, X695	255
VLAN.	Note: With Advanced Edge license or higher.	
VRRP (v2/v3-IPv4/IPv6) (maximum ping tracks)—maximum number of ping tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
Thurnber of ping tracks per VLAIN.	Note: With Advanced Edge license or higher.	

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
VRRP (maximum ping tracks)— maximum number of ping tracks per VRRP Instance under 128 VRRP instances, with Advanced Edge license or higher.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8 (20 centisecond or 1 second hello interval)
VRRP (v3-IPv6) (maximum ping tracks)—maximum number of ping tracks per VRRP Instance under 128 VRRP instances, with Advanced Edge license or higher.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8 (20 centisecond or 1 second hello interval)
VRRP (v2/v3-IPv4/IPv6) (maximum iproute tracks)— maximum number of IP route tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
VRRP (v2/v3-IPv4/IPv6)— maximum number of VLAN tracks per VLAN.	ExtremeSwitching X450-G2, X460-G2, X620, X440-G2, X590, X465, X695	8
VXLAN—maximum virtual	ExtremeSwitching X590, X465, X695	2,048-4,000
networks.  Note: Every VPLS instance/PSTag VLAN reduces this limit by 1.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	N/A
Note: Assumption is all BUM (broadcast/unknown-unicast/multicast) FDB entries are pointing to the same set of RTEPs when all VNETs use explicit flooding. Depends on whether all VNETs use standard or explicit and the number of tenant VLAN ports.		
VXLAN—maximum tenant VLANs	ExtremeSwitching X590, X465, X695	4,096
Note: Every (VPLS/PSTag VLAN) + port reduces the limit by 1.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	N/A
VXLAN—maximum static MAC to	ExtremeSwitching X590, X465, X695	64,000
IP bindings.  Note: Every FDB entry configured reduces this limit by 1.	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	N/A
VXLAN—maximum RTEP IP	ExtremeSwitching X590, X465, X695	512
addresses	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	N/A

Limits Core License Limits

Table 9: Supported Limits for Advanced Edge License (continued)

Metric	Product	Limit
VXLAN—maximum virtual	ExtremeSwitching X590, X465, X695	4,000
networks with dynamic learning and OSPF extensions for VXLAN	ExtremeSwitching X460-G2, X450-G2, X440-G2, X620	N/A
VXLAN—or replicator role, maximum number of attached leafs per switch.	ExtremeSwitching X465, X590, X695	256

# **Core License Limits**

The following table shows supported limits for features in the Core License.

**Table 10: Supported Limits for Core License** 

Metric	Product	Limit
Anycast RP Using PIM—maximum number of IPv4 Anycast RP set per VR.	ExtremeSwitching X440-G2, X450-G2, X460-G2, X620, X590, X465, X695	32
Anycast RP Using PIM—maximum number of IPv6 Anycast RP set per VR.	ExtremeSwitching X440-G2, X450-G2, X460-G2, X620, X590, X465, X695	32
Anycast RP Using PIM—RP peers per Anycast RP set.	ExtremeSwitching X440-G2, X450-G2, X460-G2, X620, X590, X465, X695	10
BGP (aggregates)—maximum	ExtremeSwitching X460-G2, X590, X465, X695	256
number of BGP aggregates.	ExtremeSwitching X450-G2	204
BGP (networks)—maximum	ExtremeSwitching X460-G2, X590, X465, X695	1,024
number of BGP networks.	ExtremeSwitching X450-G2	820
BGP (peers)—maximum number of	ExtremeSwitching X460-G2	128
BGP peers.	ExtremeSwitching X590, X465, X695	300
Note: With default keepalive and hold timers.	ExtremeSwitching X450-G2	100
Note: Each BGPv4/BGPv6 peer handles a maximum of 50 routes.		
<b>Note:</b> ECMP should not be enabled for BGP.		
BGP (peer groups)—maximum	ExtremeSwitching X460-G2, X590, X465, X695	64
number of BGP peer groups.	ExtremeSwitching X450-G2	50
BGP (policy entries)—maximum	ExtremeSwitching X460-G2, X590, X465, X695	256
number of BGP policy entries per route policy.	ExtremeSwitching X450-G2	204

Core License Limits

Limits

Table 10: Supported Limits for Core License (continued)

Metric	Product	Limit
BGP (policy statements)—	ExtremeSwitching X460-G2, X590, X465, X695	1,024
maximum number of BGP policy statements per route policy.	ExtremeSwitching X450-G2	820
BGP multicast address-family	ExtremeSwitching X460-G2, X590, X465, X695	25,000
<b>routes</b> —maximum number of multicast address-family routes.	ExtremeSwitching X450-G2	20,000
BGP (unicast address-family routes)—maximum number of	ExtremeSwitching X460-G2, X590, X465, X695 (at default)	25,000
unicast address-family routes.	ExtremeSwitching X590, X465 (with ALPM enabled)	100,000
	ExtremeSwitching X450-G2	20,000
BGP (non-unique routes)—	ExtremeSwitching X460-G2, X590, X465, X695	25,000
maximum number of non-unique BGP routes.	ExtremeSwitching X450-G2	20,000
BGP ECMP—maximum number of equal cost paths per multipath for	ExtremeSwitching X460-G2, X590, X465, X695	2, 4, 8, 16, 32, or 64
BGP and BGPv6.	ExtremeSwitching X450-G2	64
BGPv6 (unicast address-family	ExtremeSwitching X460-G2	6,000
<b>routes)</b> —maximum number of unicast address family routes.	ExtremeSwitching X590, X465, X695	10,000
· · · · · · · · · · · · · · · · · · ·	ExtremeSwitching X450-G2	4,800
BGPv6 (non-unique routes)—	ExtremeSwitching X460-G2	18,000
maximum number of non-unique BGP routes.	ExtremeSwitching X590, X465, X695	24,000
	ExtremeSwitching X450-G2	14,000
<b>EVPN EVI instances</b> —maximum number of EVI instances.	ExtremeSwitching X590, X465, X695	1,024
<b>EVPN LAGs</b> —maximum number of LAGs.	ExtremeSwitching X590, X465, X695	128
<b>GRE Tunnels</b> —maximum number of GRE tunnels.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	255
	ExtremeSwitching X620, X440-G2	N/A
IS-IS adjacencies—maximum	ExtremeSwitching X460-G2, X590, X465, X695	128
number of supported IS-IS adjacencies.	ExtremeSwitching X450-G2	N/A
IS-IS ECMP—maximum number of	ExtremeSwitching X460-G2, X590, X465, X695	2, 4, or 8
equal cost paths per multipath for IS-IS.	ExtremeSwitching X450-G2	N/A
IS-IS interfaces—maximum number	ExtremeSwitching X460-G2, X590, X465, X695	255
of interfaces that can support IS-IS.	ExtremeSwitching X450-G2	N/A
IS-IS routers in an area—	ExtremeSwitching X460-G2, X590, X465, X695	256
recommended maximum number of IS-IS routers in an area.	ExtremeSwitching X450-G2	N/A

Limits Core License Limits

Table 10: Supported Limits for Core License (continued)

ExtremeSwitching X450-G2   N/A	Metric	Product	Limit
recommended maximum number of IS-IS IPv6 L1 routes in an L1 router —recommended maximum number of IS-IS Level 1 routes in an L1 router —recommended maximum number of IS-IS Level 2 routes.  ExtremeSwitching X450-G2  ExtremeSwit	IS-IS route origination—	ExtremeSwitching X460-G2, X590, X465, X695	20,000
recommended maximum number of IS-IS Level 1 routes in an LI/L2 router—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPV4 L2 routes—fecommended maximum number of IS-IS Level 2 routes.  IS-IS IPV4 L1 routes in an LI/L2 router—recommended maximum number of IS-IS Level 1 routes in an LI/L2 IS-IS router.  IS-IS IPV6 L1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in an Level 1 IS-IS router.  IS-IS IPV6 L1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router.  IS-IS IPV6 L2 routes—recommended maximum number of IS-IS Level 2 routes—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPV6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L2/L2 router—recommended maximum number of IS-IS Level 1 routes in a L2/L2 router—recommended maximum number of IS-IS Level 2 routes in a L2/L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 routes in a L2/L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended router—recommended router—recommended router—recommended router—recommended router—recommended ro	recommended maximum number of routes that can be originated by an IS-IS node.	ExtremeSwitching X450-G2	N/A
of IS-IS Level 1 routes in a Level 1 IS-IS router.  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X460-G2, X590, X465,	IS-IS IPv4 L1 routes in an L1 router	ExtremeSwitching X460-G2, X590, X465, X695	25,000
recommended maximum number of IS-IS Level 2 routes.  ExtremeSwitching X450-G2    S-IS IPV4 L1 routes in an L1/L2   ExtremeSwitching X450-G2   ExtremeSwitching X450-G2   N/A		ExtremeSwitching X450-G2	N/A
IS-IS Level 2 routes.  IS-IS IPV4 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS L2 router—recommended router—recom	IS-IS IPv4 L2 routes—	ExtremeSwitching X460-G2, X590, X465, X695	25,000
router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 IS-IS router.  IS-IS IPv6 L1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router.  IS-IS IPv6 L2 routes—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv6 L2 routes—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in a L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommend		ExtremeSwitching X450-G2	N/A
number of IS-IS Level 1 routes in an L1/L2 IS-IS router.  IS-IS IPv6 L1 routes in an L1 router recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router.  IS-IS IPv6 L2 routes— recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum n	IS-IS IPv4 L1 routes in an L1/L2	ExtremeSwitching X460-G2, X590, X465, X695	20,000
recommended maximum number of IS-IS Level 1 routes in a Level 1    IS-IS router.  IS-IS IPV6 L2 routes— recommended maximum number of IS-IS Level 2 routes.  IS-IS IPV6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in an L2 router IIS-IS IPV4/IPV6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPV4/IPV6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPV4 routes and 50% IPV6 routes.  IS-IS IPV4/IPV6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPV4 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 I routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 I routes in a	number of IS-IS Level 1 routes in an L1/L2 IS-IS router.	ExtremeSwitching X450-G2	N/A
of IS-IS Level 1 routes in a Level 1 IS-IS router.  IS-IS IPv6 L2 routes— recommended maximum number of IS-IS Level 1 routes in a L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/12 router—recommended maximum number of IS-IS Level 1 routes in a L1/12 router—recommended maximum number of IS-IS Level 1 routes in a L1/12 router—recommended maximum number of IS-IS Level 1 routes in a L1/12 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  N/A  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  N/A  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A	IS-IS IPv6 L1 routes in an L1 router	ExtremeSwitching X460-G2, X590, X465, X695	10,000
recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/l2 router.  IS-IS IPv4/IPv6 L1 routes in an L1 routes in a L1/l2 router—recommended maximum number of IS-IS Level 1 routes in a L1/l2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/l2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number o	l .	ExtremeSwitching X450-G2	N/A
of IS-IS Level 2 routes.  IS-IS IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a L1/I2 router—recommended maximum number of IS-IS Level 1 routes in a L1/I2 router—recommended maximum number of IS-IS Level 1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L2 router—recommended maximum number of IS-IS Level 1 routes in an L2 router—recommended maximum number of IS-IS Level IS-IS router. The numbers documented are based on 50% IPv6 routes in an L2 router—recommended maximum number of IS-IS Level 1 routes in an L2 router—recommended maximum number of IS-IS Level IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  ExtremeSwitching X450-G2 X590, X465, X695 ExtremeSwitching X450-G2 X590, X465, X695 N/A  ExtremeSwitching X450-G2 X590, X465, X695 N/A	IS-IS IPv6 L2 routes—	ExtremeSwitching X460-G2, X590, X465, X695	10,000
router—recommended maximum number of IS-IS Level 1 routes in a L1/I2 router.  IS-IS IPv4/IPv6 L1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv4/IPv6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv4/IPv6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 1/Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  N/A	of IS-IS Level 2 routes.	ExtremeSwitching X450-G2	N/A
number of IS-IS Level 1 routes in a L1/l2 router.  IS-IS IPv4/IPv6 L1 routes in an L1 router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv4 routes and 50% IPv4 routes and 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  IExtremeSwitching X450-G2  ExtremeSwitching X450-G2  N/A	IS-IS IPv6 L1 routes in an L1/L2	ExtremeSwitching X460-G2, X590, X465, X695	10,000
router—recommended maximum number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X460-G2, X590, X465, X695 ExtremeSwitching X450-G2  N/A	router—recommended maximum number of IS-IS Level 1 routes in a L1/I2 router.	ExtremeSwitching X450-G2	N/A
number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L2 routes in an L2 router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L2 router and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A	IS-IS IPv4/IPv6 L1 routes in an L1	ExtremeSwitching X460-G2, X590, X465, X695	20,000
router—recommended maximum number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv4 routes and 50% IPv4 routes and 50% IPv6 routes.  ExtremeSwitching X450-G2  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A	number of IS-IS Level 1 routes in a Level 1 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.	ExtremeSwitching X450-G2	N/A
number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  IS-IS IPv4/IPv6 L1 routes in an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  ExtremeSwitching X460-G2, X590, X465, X695  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  N/A	IS-IS IPv4/IPv6 L2 routes in an L2	ExtremeSwitching X460-G2, X590, X465, X695	20,000
an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  N/A  ExtremeSwitching X450-G2  64	number of IS-IS Level 2 routes in a Level 2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.	ExtremeSwitching X450-G2	N/A
maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.  MSDP active peers—maximum  ExtremeSwitching X450-G2  N/A  N/A  ExtremeSwitching X450-G2  N/A  64	IS-IS IPv4/IPv6 L1 routes in	ExtremeSwitching X460-G2, X590, X465, X695	20,000
	an L1/L2 router—recommended maximum number of IS-IS Level 1 routes in a Level 1/Level2 IS-IS router. The numbers documented are based on 50% IPv4 routes and 50% IPv6 routes.	ExtremeSwitching X450-G2	N/A
	MSDP active peers—maximum number of active MSDP peers.	=	64

Core License Limits

Limits

Table 10: Supported Limits for Core License (continued)

Metric	Product	Limit
MSDP SA cache entries—maximum number of entries in SA cache.	ExtremeSwitching X590, X465, X695	14,000
	ExtremeSwitching X450-G2	8,000
	ExtremeSwitching X460-G2	10,000
MSDP maximum mesh groups— maximum number of MSDP mesh groups.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	16
OSPFv2/v3 ECMP—maximum number of equal cost multipath OSPFv2 and OSPFv3.	ExtremeSwitching X460-G2, X450-G2, X590, X465, X695	64
OSPFv2 areas—as an ABR, how many OSPF areas are supported within the same switch.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	8
OSPFv2 external routes—	ExtremeSwitching X590, X465, X695	10,000
recommended maximum number of external routes contained in an	ExtremeSwitching X460-G2	5,000
OSPF LSDB.	ExtremeSwitching X450-G2	4,000
OSPFv2 inter- or intra-area routes	ExtremeSwitching X590, X465, X695	4,000
—recommended maximum number of inter- or intra-area routes	ExtremeSwitching X460-G2	2,000
contained in an OSPF LSDB with one ABR in OSPF domain.	ExtremeSwitching X450-G2	1,600
OSPFv2 interfaces—recommended maximum number of OSPF interfaces on a switch (active interfaces only).	ExtremeSwitching X460-G2, X590, X465, X695	400
	ExtremeSwitching X450-G2	320
OSPFv2 links—maximum number	ExtremeSwitching X460-G2, X590, X465, X695	400
of links in the router LSA.	ExtremeSwitching X450-G2	320
OSPFv2 neighbors—maximum	ExtremeSwitching X460-G2, X590, X465, X695	128
number of supported OSPF adjacencies.	ExtremeSwitching X450-G2	96
OSPFv2 routers in a single area—	ExtremeSwitching X590, X465, X695	100
recommended maximum number of routers in a single OSPF area.	ExtremeSwitching X460-G2	50
J	ExtremeSwitching X450-G2	40
OSPFv2 virtual links—maximum	ExtremeSwitching X460-G2, X590, X465, X695	32
number of supported OSPF virtual links.	ExtremeSwitching X450-G2	25
OSPFv3 areas—as an ABR, the	ExtremeSwitching X590, X465, X695	100
maximum number of supported OSPFv3 areas.	ExtremeSwitching X460-G2	16
	ExtremeSwitching X450-G2	12
OSPFv3 external routes—	ExtremeSwitching X460-G2, X590, X465, X695	10,000
recommended maximum number of external routes.	ExtremeSwitching X450-G2	7,500

Limits Core License Limits

Table 10: Supported Limits for Core License (continued)

Metric	Product	Limit
OSPFv3 inter- or intra-area routes —recommended maximum number of inter- or intra-area routes.	ExtremeSwitching X590, X465, X695	4.000
	ExtremeSwitching X460-G2	3,000
	ExtremeSwitching X450-G2	500
OSPFv3 interfaces—maximum	ExtremeSwitching X460-G2, X590, X465, X695	256
number of OSPFv3 interfaces (active interfaces only).	ExtremeSwitching X450-G2	192
OSPFv3 neighbors—maximum	ExtremeSwitching X460-G2, X590, X465, X695	64
number of OSPFv3 neighbors.	ExtremeSwitching X450-G2	48
OSPFv3 virtual links—maximum	ExtremeSwitching X460-G2, X590, X465, X695	16
number of OSPFv3 virtual links supported.	ExtremeSwitching X450-G2	12
PIM IPv4 (maximum interfaces)— maximum number of PIM active interfaces.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	255
PIM IPv4 Limits—maximum number of multicast groups per dynamic rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	180
PIM IPv4 Limits—maximum number of multicast groups per static rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	3,000 (depends on policy file limits)
PIM IPv4 Limits—maximum number of multicast sources per group.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	5,000
PIM IPv4 Limits—maximum number of dynamic rendezvous points per multicast group.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	145
PIM IPv4 Limits—static rendezvous points.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	32
PIM IPv6 (maximum interfaces)— maximum number of PIM active interfaces.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	255
PIM IPv6 Limits—maximum	ExtremeSwitching X460-G2, X590, X465, X695	1,750
number of multicast sources per group.	ExtremeSwitching X450-G2	1,500
PIM IPv6 Limits—maximum number of multicast groups per dynamic rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	70
PIM IPv6 Limits—maximum number of multicast groups per static rendezvous point.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	3,000 (depends on policy file limits)

Notes for Limits Tables Limits

Table 10: Supported Limits for Core License (continued)

Metric	Product	Limit
PIM IPv6 Limits—maximum number of dynamic rendezvous points per multicast group.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	64
PIM IPv6 Limits—maximum number of secondary addresses per interface.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	70
PIM IPv6 Limits—static rendezvous points.	ExtremeSwitching X450-G2, X460-G2, X590, X465, X695	32

#### **Notes for Limits Tables**

<sup>&</sup>lt;sup>a</sup> The table shows the total available. When installing ACL rules bound to a set of ports, rules are replicated for each port if there are ACL counters and counter compression is not enabled, or if the ports are Extended Edge Switching extended ports.

<sup>&</sup>lt;sup>c</sup> When there are BFD sessions with minimal timer, sessions with default timer should not be used.

f Effective capacity varies based on actual MAC addresses and VLAN IDs used and hash algorithm selected.

 $<sup>^{\</sup>rm g}\,$  Based on "configure forwarding internal-tables more l2".

h Based on "configure forwarding internal-tables more I3-and-ipmc".

<sup>&</sup>lt;sup>j</sup> The limit depends on setting configured with configure iproute reserved-entries.

m The IPv4 and IPv6 multicast entries share the same hardware tables, so the effective number of IPv6 multicast entries depends on the number of IPv4 multicast entries present and vice versa.

<sup>&</sup>lt;sup>n</sup> If IGMP and MLD are simultaneously configured on the switch, the number of effective subscribers supported are lessened accordingly.

<sup>&</sup>lt;sup>o</sup> The total of all PBR next hops on all flow redirects should not exceed 4,096.

<sup>&</sup>lt;sup>p</sup> The number of XNV authentications supported based on system ACL limitations.

<sup>&</sup>lt;sup>q</sup> Based on "configure forwarding internal-tables more routes".

 $<sup>^{\</sup>rm r}$  Based on configure forwarding internal-tables more routes ipv6-mask-length 128.

Limits Notes for Limits Tables

 $<sup>^{\</sup>rm S}$  Based on configure forwarding internal-tables more 13-and-ipmc or configure forwarding internal-tables 12-and-13.



# Open Issues, Known Behaviors, and Resolved Issues

Open Issues on page 72 Known Behaviors on page 72 Resolved Issues in ExtremeXOS 32.2 on page 73

This chapter lists open software issues, limitations in ExtremeXOS system architecture (known issues), and resolved issues in ExtremeXOS.

## **Open Issues**

There are no open issues in this release.

### **Known Behaviors**

The following is a list of limitations in ExtremeXOS system architecture that have yet to be resolved.

Table 11: Known Issues, Platform-Specific, and Feature Change Requests (CRs)

Defect Number	Description	
General		
EXOS-32111	Connecting a Cat5 or Cat6 Ethernet cable from an Ethernet switch access port to the Console port on an active X465 or X695 switch may cause the switch to hang in a boot cycle after reboot or power cycling the switch.  Workaround: Ensure you connect the console port on the switch to the proper terminating equipment, for example, to a PC, VT terminal, terminal server, etc.	
ExtremeSwitching X460-G2 Series Switches		
EXOS-32241	With ExtremeXOS 32.1, an X460-G2 populated with a SyncE VIM-TM-CLK clock module will experience a HAL crash and reboot if the command show iproute reserved-entries statistics is entered.	
ExtremeSwitching X465 Series Switches		

Table 11: Known Issues, Platform-Specific, and Feature Change Requests (CRs) (continued)

Defect Number	Description	
EXOS-31978	The X465 VIM-4Y and VIM-2Y do not support Auto Negotiation or FEC. If you enable Auto Neg for these ports, a false link-up may occur even with no cable connected.	
Universal Hardware		
EXOS-32459	Entering the configure stacking easy-setup command fails when building a stack from version 32.1 or earlier with nodes running on version 32.2. Workaround: Upgrade the clone on ExtremeXOS version 32.1 to version 1.2.1.4 or later by using clone XMOD.	

### **Resolved Issues in ExtremeXOS 32.2**

The following issues were resolved in ExtremeXOS 32.2. Version 32.2 includes all fixes up to and including the following versions: 11.6.5.3 and earlier, 12.0.5, 12.1.7, 12.2.2-patch1-12, 12.3.6, 12.4.5, 12.5.5, 12.6.3, 12.6.5, 12.7.1, 15.1.5, 15.2.4, 15.3.3, 15.4.1, 15.5.1, 15.5.2, 15.6.1, 15.6.2, 15.7.1, 16.1, 16.1.2, 16.1.3, 21.1, 22.1, 22.2, 22.3, 22.4, 22.5, 22.6, 30.1, 30.2, 30.3, 30.4, 30.5, 30.6, 30.7, 31.1, 31.2, 31.3, 31.4, 31.5, 31.6, 31.7, and 32.1. For information about those fixes, see the release notes for the specific release.

Table 12: Resolved Issues, Platform-Specific, and Feature Change Requests (CRs) in 32.2

Defect Number	Description
General	
EXOS-31439	Turning autopolarity off might not take effect on a port running at 10Mbps or 100Mbps.
EXOS-31666	ezspantree.py stops functioning after a certain amount of run time.
EXOS-31670	UDP profile doesn't forward traffic to /30 network if the switch interface has the same network configured.
EXOS-31700	Access VLAN traffic is not forwarded over MLAG port to networks VLAN.
EXOS-31742	HTTPS Chalet login failure with the message soap error session failed when attempting to log in via the same tab.
EXOS-31949	L3 Remote mirror not working properly.
EXOS-31998	OnePolicy rule precedence order can be changed using a command from 30.2 and later.
EXOS-32015	Temperature is incorrectly displayed in the <b>show temperature</b> command.
EXOS-32056	The footer should be printed without consideration of CLI paging.
EXOS-32259	Switch sends overheat condition as an SNMPv1 trap despite MIB files denying it as SNMPv2.
EXOS-32288	LLDP MED application configuration is removed from the port if the port is removed from the VLAN.

Table 12: Resolved Issues, Platform-Specific, and Feature Change Requests (CRs) in 32.2 (continued)

Defect Number	Description	
Extended Edge Switching		
EXOS-31638	ExtremeXOS should throw an error to disable SLPP before configuring VPEX when it was enabled.	
ExtremeSwitching X440-G2 Series Switches		
EXOS-31613	Switch does not respond to system API calls and the CPU stays high for HAL and EXPY processes.	
ExtremeSwitching X435 Series Switches		
EXOS-31362	ExtremeSwitching X435 switch inline-power goes into the disabled state until the switch is factory reset.	
ExtremeSwitching X870 Series Switches		
EXOS-31971	VLAN-based mirroring stops working if any port on the switch is partitioned.	
SummitStack		
EXOS-32335	SLPP configurations are removed from the port but retained in the configuration when sharing on the port is disabled.	