

Service Release Notes for WiNG 7.4.0.2-001R

Please Note: Service releases are made available to fix specific customer reported issues in a timely manner. Service releases are not as extensively tested as main releases (such as 7.4.0.0-025R). The next maintenance or manufacturing release will incorporate all qualifying and preceding service releases.

This document is an addendum to the release notes for the main release 7.4.0.0-025R.

CONTENTS

..... 1

1. Resolved Issues 1

2. Known issues 2

2. Important Notes..... 2

3. Platforms Supported 2

4. Firmware Upgrade/Downgrade Procedure 2

1. RESOLVED ISSUES

Service Release 7.4.0.2-001R

This service release is mainly for distributed mode. It contains critical fixes for this mode.

It also adds support for China on AP4xx and AP3xx.

Following is a list of SPRs/CRs fixed in this release:

CRID	Description
WING-43346	Smart-rf only assigns channel 1 on 2.4GHz and channel 36 on 5GHz

Previous Service Release 7.4.0.1-002R

This service release is mainly for distributed mode. It contains critical fixes for this mode.

It also adds support for Japan on AP410i, AP460i/e and AP310i/e.

Following is a list of SPRs/CRs fixed in this release:

CRID	Description
WING-42550	AP8432 low upload speed from MacBook
WING-43052	VX9/AP460i BLE Radio not displayed on RFD via CLI
WING-43104	Heartbeat message type is wrong which indicates a heartbeat without location
WING-43229	Add Request Retry timeout parameter in initial config
WING-43232	AP8533 Smart-RF never picks channel 1 for any APs

2. KNOWN ISSUES

CQ/ SPR	Headline	Comments

2. IMPORTANT NOTES

None

3. PLATFORMS SUPPORTED

This release applies to all platforms released with WiNG 7.4.0.0-025R.

4. FIRMWARE UPGRADE/DOWNGRADE PROCEDURE

The method described in this section uses the Command Line Interface (CLI) procedures. To log into the CLI, either SSH, Telnet or serial access can be used.

For detailed upgrade procedure – please refer to WiNG 7.4.0 release notes.

Upgrade from WiNG v7x.x.x to WiNG v7.4.0.2

1. Copy the controller image to your tftp/ftp server.
2. Use the **—upgrade ftp://<username>:<password>@<ip address of server>/<name of file>||**, or **—upgrade tftp://<ip address of server>/<name of file>** command from CLI or **Switch->Firmware->Update Firmware** option from the GUI. You may need to specify the username and password for your ftp server.
3. Restart the controller. From CLI the command is **—reload**.

© Extreme Networks. 2019. All rights reserved.